



NVIDIA DGX Software for Red Hat Enterprise Linux 9

NVIDIA Corporation

May 11, 2024

Contents

1	Introduction	1
1.1	Related Documentation	1
1.2	Prerequisites	2
1.2.1	Red Hat Subscription	2
1.2.2	Access to Repositories	2
1.2.2.1	NVIDIA Repositories	2
1.2.2.2	Red Hat Repositories	2
1.2.3	Network File System	2
1.2.4	BMC Password	3
2	Release Notes	5
2.1	Current Contents of the Repositories	5
2.2	Release Information	8
2.2.1	EL9-23.12 Release	8
2.2.2	EL9-23.08 Release	10
2.2.3	EL9-23.01 Release	12
3	Installing Red Hat Enterprise Linux	15
3.1	Obtaining Red Hat Enterprise Linux	15
3.2	Booting the Red Hat Enterprise Linux ISO Locally	16
3.3	Booting the Red Hat Enterprise Linux ISO Remotely	16
3.3.1	Booting the ISO Image on the DGX-2, DGX A100, DGX A800, or DGX H100 Remotely	16
3.3.2	Booting the ISO Image on the DGX-1 Remotely	20
3.4	Installing and Configuring Red Hat Enterprise Linux	23
3.5	Partitioning	28
3.5.1	Disk Partitioning for DGX-1, DGX Station, and DGX Station A100	28
3.5.2	Disk Partitioning with Encryption for DGX-1, DGX Station, and DGX Station A100	34
3.5.3	Disk Partitioning for DGX-2, DGX A100, DGX A800, and DGX H100	44
3.5.4	Disk Partitioning with Encryption for DGX-2, DGX A100, DGX A800, and DGX H100	51
4	Installing the DGX Software	61
4.1	Configuring a System Proxy	61
4.2	Enabling the DGX Software Repository	61
4.3	Installing Required Components	62
4.4	Configuring Data Drives	62
4.5	Installing the GPU Driver	63
4.5.1	Installing and Running Docker CE	65
4.5.2	Installing and Running Podman	67
4.6	Installing Optional Components	67
4.7	Installing NVIDIA GPUDirect Storage	68
4.7.1	Prerequisites	68
4.7.2	Procedure	69
4.8	Installing the Optional NVIDIA Desktop Theme	69

5	Installing on “Air-Gapped” Systems	71
5.1	Registering Your System	71
5.2	Creating a Local Mirror of the NVIDIA Repository	71
5.3	Installing Docker Containers	72
6	Installing with Local Repositories	75
6.1	Installing the Base Red Hat Enterprise Linux System	75
6.2	Downloading the Local Repositories	75
6.2.1	Release 23.12	76
6.2.2	Release 23.08	76
6.2.3	Release 23.01	76
6.3	Installing the Local Repositories	76
6.4	Installing the NVIDIA CUDA Driver from the Local Repository	77
7	Installing NVIDIA MLNX_OFED	79
7.1	Prerequisites	79
7.2	Installing and Configuring MLNX_OFED	79
7.3	Updating NVIDIA MLNX_OFED	82
8	Installing the ConnectX-7 Firmware	85
9	Installing with Kickstart	87
10	Configuring Storage	89
11	Upgrading	91
11.1	Upgrading the OS and DGX Software	92
11.1.1	Upgrading the Software without Moving to a New Driver Branch	92
11.1.2	Updating the Software and Moving to a New Driver Branch on non-NVSwitch Systems	92
11.1.3	Updating the Software and Moving to a New Driver Branch on NVSwitch Systems	92
11.2	Changing only the NVIDIA Driver Branch	93
11.3	Installing or Upgrading to a Newer CUDA Toolkit Release	93
11.3.1	Checking the Currently Installed CUDA Toolkit Release	94
11.3.2	Determining the New Available CUDA Toolkit Releases	94
11.3.3	Installing the CUDA Toolkit or Upgrading Your CUDA Toolkit to a Newer Release	95
11.4	Installing GPUDirect Storage Support	95
11.4.1	Installing nvidia-gds	95
12	Managing Self-Encrypting Drives	97
12.1	Overview	97
12.2	Installing the Software	98
12.3	Configuring Trusted Computing	98
12.3.1	Determining Whether Drives Support SID	99
12.3.2	Enabling the TPM and Preventing the BIOS from Sending Block SID Requests	99
12.4	Initializing the System for Drive Encryption	102
12.5	Enabling Drive Locking	102
12.6	Initialization Examples	103
12.6.1	Example 1: Passing in the JSON File	103
12.6.1.1	Determining Which Drives Can be Managed as Self-Encrypting	103
12.6.1.2	Creating the Drive/Password Mapping JSON Files and Using it to Initialize the System	104
12.6.2	Example 2: Generating Random Passwords	105
12.6.3	Example 3: Specifying Passwords One at a Time When Prompted	105
12.7	Disabling Drive Locking	105
12.8	Enabling Drive Locking	106

12.9	Exporting the Vault	106
12.10	Erasing Your Data	106
12.11	Clearing the TPM	107
12.12	Changing Disk Passwords, Adding Disks, or Replacing Disks	107
12.13	Recovering From Lost Keys	107
13	Known Issues	109
13.1	Reboot Hang after Configuring RAID	109
13.2	MOFED mlnxofedinstall reports “Current operation system is not supported” using RHEL 9.2	110
13.3	Precompiled GPU Driver 525 package is not available for Rocky 9.1	111
13.4	Yellow screen appears during RHEL 9.1 installation	111
13.5	DGX A100: VBIOS cannot update due to running service processes	112
13.6	NVSM Unsupported Drive Error	112
13.7	Tuned profiles do not take effect in graphical mode	113
14	Third-Party License Notices	115
14.1	Micron msecli	115
14.2	Mellanox (OFED)	116
15	Notices	117
15.1	Notice	117
15.2	Trademarks	118

Chapter 1. Introduction

This document explains the installation and configuration of the NVIDIA DGX Software Stack on DGX systems installed with Red Hat Enterprise Linux.

NVIDIA provides the NVIDIA DGX Software Stack targeted for installation on DGX systems that have been user-installed with Red Hat Enterprise Linux. The software stack provides the same features and functionality that are provided by the original DGX OS built on the Ubuntu.

Note: NVIDIA acknowledges the wide use of Rocky Linux and understands that it is a community-developed derivative of the NVIDIA supported Red Hat Enterprise Linux. Support for Rocky Linux is available directly from the Rocky Linux community. NVIDIA ensures that NVIDIA provided software runs on tested Rocky Linux versions and will try to identify and correct issues related to NVIDIA provided software.

While it might be possible to use other derived Linux distributions, not all have been tested and qualified by NVIDIA. Refer to the [Release Notes](#) for the list of tested and qualified software and Linux distributions.

1.1. Related Documentation

- ▶ [NVIDIA DGX-1 User Guide](#)
- ▶ [NVIDIA DGX-2 User Guide](#)
- ▶ [NVIDIA DGX Station User Guide](#)
- ▶ [NVIDIA DGX A100 User Guide](#)
- ▶ [NVIDIA DGX Station A100 User Guide](#)
- ▶ [NVIDIA DGX H100 User Guide](#)

1.2. Prerequisites

The following are required (or recommended wherever indicated).

1.2.1. Red Hat Subscription

You need a Red Hat subscription if you plan to install and use Red Hat Enterprise Linux on the DGX. A subscription also lets you obtain update packages and additional packages for Red Hat Enterprise Linux. You can either purchase a subscription or obtain a free evaluation subscription from the [Red Hat Software & Download Center](#).

1.2.2. Access to Repositories

The repositories can be accessed from the internet.

If you are using a proxy server, then follow the instructions in the section [Configuring a System Proxy](#) to make sure the system can access the necessary URIs.

1.2.2.1 NVIDIA Repositories

After installing Red Hat Enterprise Linux on the DGX system, you must enable the NVIDIA DGX software repository (<https://repo.download.nvidia.com>). The repository includes the NVIDIA drivers and software for supporting DGX systems.

See the section [Enabling the DGX Software Repository](#) for instructions on how to enable the repository.

1.2.2.2 Red Hat Repositories

Installation of the DGX Software over Red Hat Enterprise Linux 9 requires access to several additional repositories.

- ▶ Red Hat Enterprise BaseOS Repository: `rhel-9-for-x86_64-baseos-rpms`
- ▶ Red Hat Enterprise AppStream Repository: `rhel-9-for-x86_64-appstream-rpms`
- ▶ Red Hat Enterprise CodeReady Linux Builder Repository: `codeready-builder-for-rhel-9-x86_64-debug-rpms`

1.2.3. Network File System

On DGX servers, the data drives are meant to be used as a cache. DGX Station users can follow the same usage, or can alternatively opt to use these drives for storage. When using the data drives as cache, a network file system (NFS) is recommended to take advantage of the cache file system provided by the DGX software stack.

1.2.4. BMC Password

The NVIDIA DGX server includes a base management controller (BMC) for out-of-band management of the DGX system. NVIDIA recommends disabling the default username and creating a unique username and password as soon as possible.

Chapter 2. Release Notes

This section provides detailed information for releases and upgrades available for the DGX Software Stack for Red Hat Enterprise Linux 9 and Rocky Linux 9.

2.1. Current Contents of the Repositories

The following table shows the current version information of the software packages provided in the NVIDIA repositories for the NVIDIA DGX Software Stack.

Table 1: Current Software Versions (Last Updated on May 13, 2024)

Component	Version	Additional Information
GPU Driver	550.54.15	RHEL8: RPM installer RHEL9: RPM installer
GPU Driver	535.161.08	RHEL8: RPM installer RHEL9: RPM installer
GPU Driver	470.239.06	For RHEL8 and DGX OS 5 only. RHEL8: RPM installer
CUDA Toolkit	12.4	R550: 12.4 download
CUDA Toolkit	12.2 Update 2	R535: 12.2 update 2 download
CUDA Toolkit	11.4	R470: For RHEL8 and DGX OS 5 only.
MLNX_OFED	23.10-2.1.3.1	23.10-2.1.3.1 download
Inbox OFED	39.0-1	For DGX OS 6 only.
NCCL	2.21.5	
cuDNN	9.1.1	
DCGM	3.3.6	
GPUDirect Storage (GDS)	<ul style="list-style-type: none"> ▶ 1.9.1 for CUDA Toolkit 12.4 ▶ 1.7.2 for CUDA Toolkit 12.2 ▶ 1.0 for CUDA Toolkit 11.4 	
NVIDIA Container Toolkit	1.15.0	NVIDIA Container Toolkit includes the following packages: <ul style="list-style-type: none"> ▶ nvidia-container-toolkit: 1.15.0 ▶ libnvidia-container-tools: 1.15.0 ▶ libnvidia-container1: 1.15.0
nvidia-peer-memory	1.3	

Note:

- ▶ CUDA Toolkit is installed by default only for DGX stations and is optional for DGX servers. Refer

to the [CUDA Release Notes](#) for driver compatibility information.

- For CUDA Toolkit minor version compatibility and the minimum required driver version, refer to [CUDA Compatibility](#).

The following table provides information about the supported OS and matching firmware versions for NVIDIA® OpenFabrics Enterprise Distribution for Linux (MLNX_OFED) version 23.10-2.1.3.1. For more information about this long-term support (LTS) release, refer to

- [NVIDIA MLNX_OFED Documentation v23.10-2.1.3.1 LTS](#)
- Software download: version [23.10-2.1.3.1](#)

Table 2: Supported OS and Matching Firmware Versions (Last Updated on May 13, 2024)

OS	DGX-1, DGX-2 ConnectX-4 (CX-4) or ConnectX-5 (CX-5)	DGX A100 ConnectX-6	DGX A100 ConnectX-7	DGX H100 ConnectX-7
Ubuntu 22.04 DGX OS 6	CX-5: 16.35.3006 CX-4: 12.28.2006	20.39.3004	28.39.3004	28.39.3004
Ubuntu 20.04 DGX OS 5	CX-5: 16.35.3006 CX-4: 12.28.2006	20.39.3004	28.39.3004	Not applicable
RHEL 9 and RHEL 8	CX-5: 16.35.3006 CX-4: 12.28.2006	20.39.3004	28.39.3004	28.39.3004
COSS 9	Not applicable	20.39.3004	Not applicable	Not applicable

For installation instructions, refer to

- NVIDIA MLNX_OFED: [Installing NVIDIA MLNX_OFED](#)
- ConnectX®-7 adapter cards: [Installing the ConnectX-7 Firmware](#)
- ConnectX®-6 adapter cards: [Firmware Downloads](#)

Note: For information about LTS software versions for related networking components, refer to the [Networking Long-Term Support Releases](#) page.

2.2. Release Information

This section provides details of each DGX Software for Red Hat Enterprise Linux release. These include mostly new NVIDIA features and accumulated bug fixes and security updates.

- ▶ To check the latest Red Hat Enterprise Linux 9 version, Refer to Red Hat Knowledgebase article [3078](#).
- ▶ To check the MLNX_OFED package OS support, visit [Mellanox](#) and click the latest NVIDIA MLNX_OFED software version. Use the side menu to navigate to **Release Notes** > **General Support** and view Supported Operating Systems.

Important: Installing or updating to the DGX Software also updates the installed Red Hat Enterprise Linux 9 distribution to the latest version.

If you use NVIDIA MLNX_OFED, then before installing or updating to EL9-23.08, be sure that there is a MLNX_OFED package version available that supports the latest Red Hat Enterprise Linux 9 version.

2.2.1. EL9-23.12 Release

Release Highlights

- ▶ Added support for Red Hat Enterprise Linux 9.3 and Rocky 9.3.
- ▶ Continued support for Red Hat Enterprise Linux 9.2 and Rocky Linux 9.2.
- ▶ Added support for single-port ConnectX-7 VPI adapter card for DGX A100 System.
- ▶ Added support for NVIDIA® OpenFabrics Enterprise Distribution for Linux (MLNX_OFED) version 23.10-1.1.9.0 - a long-term support (LTS) release.
- ▶ Continued support for DGX H100.

Qualified Software Stack

The following table shows the current version information of the software packages provided in the NVIDIA repositories for the NVIDIA DGX Software Stack.

Component	Latest versions in the repositories
DGX Base OS	EL9-23.12
OS	Red Hat Enterprise Linux 9.3 and Rocky Linux 9.3
Kernel	5.14.0-362.8.1.el9_3
GPU Driver and CUDA Toolkit	CUDA Toolkit 12.2 and GPU Driver 535.129.03 (Default)
NCCL	2.19.3
cuDNN	8.9.6
DCGM	3.3.0-002
GPU Direct Storage	1.7.2 or later
NVIDIA System Management (NVSM)	23.09.02
Docker-CE	24.0.7-1
NVIDIA Container Runtime	<ul style="list-style-type: none"> ▶ nvidia-docker2: 2.13.0-1 ▶ nvidia-container-toolkit (and base): 1.14.3-1 ▶ libnvidia-container-tools: 1.14.3-1 ▶ libnvidia-container1: 1.14.3-1
MIG Configuration Tool	0.5.4-1
NGC CLI	3.17.0-1
DLFW (Deep Learning Frameworks)	23.10

The following table provides information about the supported OS and matching firmware versions for NVIDIA® OpenFabrics Enterprise Distribution for Linux (MLNX_OFED) version **23.10-1.1.9.0**.

OS	DGX-1, DGX-2 ConnectX-4 (CX-4) or ConnectX-5 (CX-5)	DGX A100 ConnectX-6	DGX A100 ConnectX-7	DGX H100 ConnectX-7
RHEL 9	CX-5: 16.35.3006 CX-4: 12.28.2006	20.39.1002	28.39.1002	28.39.1002

Supported DGX Systems

NVIDIA has validated and tested EL9-23.12 with the following DGX systems:

- ▶ DGX H100
- ▶ DGX A100 640 GB
- ▶ DGX A100 320 GB
- ▶ DGX A800 640 GB
- ▶ DGX-2
- ▶ DGX-1 32 GB
- ▶ DGX Station A100 320 GB
- ▶ DGX Station A100 160 GB
- ▶ DGX Station 32 GB

Resolved Issues

The following issues have been resolved in the EL9-23.12 release:

Bug ID	Issue
4108242	Running joc tests resulted in an unrecognized arguments: --local-rank error with GPU driver R525.105.17.
4386925	GPUDirect RDMA bandwidth test failed with the Xid (PCI:0000:0f:00): 79, pid='<unknown>', name=<unknown>, GPU has fallen off the bus message.

2.2.2. EL9-23.08 Release

Release Highlights

- ▶ Add support for NVIDIA DGX H100 System. Support is limited to the Red Hat Enterprise Linux 9.1 release.
- ▶ Add support for Red Hat Enterprise Linux 9.2 and Rocky Linux 9.2.

Qualified Software Stack

The following table provides version information for EL9-23.08 and the software it has been qualified:

Component	Latest versions in the repositories
Linux Distribution	Red Hat Enterprise Linux 9.2 and Rocky Linux 9.2 For NVIDIA DGX H100 Systems, only Red Hat Enterprise Linux 9.1 is supported.
GPU Driver	535.86.10
CUDA Toolkit	12.2.0
NCCL	2.18.3
CuDNN	8.9.2.26
DCGM	3.1.8
MLNX OFED	<ul style="list-style-type: none"> ▶ ConnectX-7 with DGX H100: 5.9-0.5.6.0.125 ▶ ConnectX-7 with DGX A100: 5.4-3.7.5.0 ▶ ConnectX-6 with DGX A100: 5.8-3.0.7.0 ▶ ConnectX-5 and ConnectX-4: 5.8-3.0.7.0
MLNX FW	<ul style="list-style-type: none"> ▶ ConnectX-7 and DGX H100: 28.36.2050 ▶ ConnectX-7 and DGX A100: 28.34.4000 ▶ ConnectX-6 and DGX A100: 20.35.4000 ▶ ConnectX-5: 16.35.3006 ▶ ConnectX-4: 12.28.2006
GPU Direct Storage	1.7.2
NVIDIA System Management (NVSM)	23.06.04
Docker Engine	23.0.4
NVIDIA Container Runtime	<ul style="list-style-type: none"> ▶ nvidia-docker2: 2.13.1-1 ▶ nvidia-container-toolkit (and base): 1.13.1-1 ▶ libnvidia-container-tools: 1.13.1-1 ▶ libnvidia-container1: 1.13.1-1
MIG Configuration Tool	0.5.1
NGC CLI	3.17.0
DLFW (Deep Learning Frameworks)	23.07

The following table provides information about the supported OS and matching firmware versions for Mellanox OFED.

OS	DGX-1, DGX-2 ConnectX-4 ConnectX-5	or	DGX A100 ConnectX-6 (CX-6)	DGX A100 ConnectX-7 (CX-7)	DGX H100 ConnectX-7 (CX-7)
RHEL 8	5.8-3.0.7.0 ▶ CX-5: 16.35.3006 ▶ CX-4: 12.28.2006 ▶ RHEL 8.8		5.8-3.0.7.0 ▶ CX-6: 20.35.3006 ▶ RHEL 8.8	5.4-3.7.5.0 ▶ CX-7: 28.34.4000 ▶ RHEL 8.8	5.9-0.5.6.0.127 ▶ CX-7: 28.36.2050 ▶ RHEL 8.7
RHEL 9	5.8-3.0.7.0 ▶ CX-5: 16.35.3006 ▶ CX-4: 12.28.2006 ▶ RHEL 9.2		5.8-3.0.7.0 ▶ CX-6: 20.35.3006 ▶ RHEL 9.2	5.4-3.7.5.0 ▶ CX-7: 28.34.4000 ▶ RHEL 9.2	5.9-0.5.6.0.127 ▶ CX-7: 28.36.2050 ▶ RHEL 9.1

Hardware Compatibility

NVIDIA has validated and tested EL9-23.08 with the following DGX systems:

- ▶ NVIDIA DGX H100
- ▶ NVIDIA DGX A100
- ▶ NVIDIA DGX Station A100
- ▶ NVIDIA DGX Station
- ▶ NVIDIA DGX-2
- ▶ NVIDIA DGX-1

2.2.3. EL9-23.01 Release

Initial release of the DGX Software Stack for Red Hat Enterprise Linux 9.

Qualified Software Stack

The following table provides version information for EL9-23.01 and the software it has been qualified:

Component	Versions in this release
Linux Distribution	Red Hat Enterprise Linux 9.1 and Rocky Linux 9.1
GPU Driver	525.105.17
CUDA Toolkit	12.0
NCCL	2.18.1
CuDNN	8.9.1.23
DCGM	3.1.8
NVIDIA MLNX_OFED	5.8-2.0.3.0
NVIDIA ConnectX Firmware	<ul style="list-style-type: none"> ▶ CX-4: 12.28.2006 ▶ CX-5: 16.35.2000 ▶ CX-6: 20.35.2000
NVIDIA System Management (NVSM)	22.12.04
Docker Engine	23.0.4
NVIDIA Container Runtime	<ul style="list-style-type: none"> ▶ nvidia-docker2: 2.13.0-1 ▶ nvidia-container-toolkit (and base): 1.13.1-1 ▶ libnvidia-container-tools: 1.13.1-1 ▶ libnvidia-container1: 1.13.1-1
MIG Configuration Tool	0.5.1
NGC CLI	3.17.0
DLFW (Deep Learning Frameworks)	23.03

Hardware Compatibility

NVIDIA has validated and tested EL9-23.01 with the following DGX systems:

- ▶ DGX-1
- ▶ DGX-2
- ▶ DGX Station
- ▶ DGX A100
- ▶ DGX Station A100

Chapter 3. Installing Red Hat Enterprise Linux

Red Hat provides several methods for installing Red Hat Enterprise Linux as described in [Performing a Standard RHEL 9 Installation](#).

The installation instructions in this topic are for the latest release of the DGX Software for Red Hat Enterprise Linux 9. The DGX Software does not include Extended Update Support (EUS), which is an optional subscription for Red Hat Enterprise Linux. For more information about EUS, refer to [Red Hat Enterprise Linux \(RHEL\) Extended Update Support \(EUS\) Overview](#).

For convenience, this topic describes how to install Red Hat Enterprise Linux using the Quick Install method, and shows when to reclaim disk space in the process. It describes a minimal installation. If you have a preferred method for installing Red Hat Enterprise Linux, then you can skip this section but be sure to reclaim disk space occupied by the existing Ubuntu installation.

The interactive method described here installs Red Hat Enterprise Linux on DGX using a connected monitor and keyboard and USB stick with the ISO image, or remotely through the remote console of the BMC.

Important: Refer to the [Release Notes](#) for any critical information regarding supported releases or dependencies. You will also find the version of Red Hat Enterprise Linux that is qualified and tested for use with the DGX Software.

3.1. Obtaining Red Hat Enterprise Linux

Obtain the Red Hat Enterprise Linux 9 ISO image and store on your local disk or create a boot USB drive formatted for UEFI. See [Downloading Red Hat Enterprise Linux](#) for instructions.

3.2. Booting the Red Hat Enterprise Linux ISO Locally

1. Plug the USB flash drive containing the Red Hat Enterprise Linux 9 ISO image into the DGX.
2. Connect a monitor and keyboard directly to the DGX.
3. Boot the system and press **F11** when the NVIDIA logo appears to get to the boot menu.
4. Select the USB volume name that corresponds to the inserted USB flash drive, and boot the system from it.
5. Follow the instructions at [Installing and Configuring Red Hat Enterprise Linux](#)

3.3. Booting the Red Hat Enterprise Linux ISO Remotely

This chapter describes the steps for booting the Red Hat Enterprise Linux ISO remotely using the BMC:

- For DGX-2, DGX A100, DGX A800, or DGX H100, refer to [Booting the ISO Image on the DGX-2, DGX A100, DGX A800, or DGX H100 Remotely](#).
- For DGX-1, refer to [Booting the ISO Image on the DGX-1 Remotely](#).

Skip this chapter if you are using a monitor and keyboard for installing locally, or if you are installing on a DGX Station. The DGX Station **cannot** be booted remotely.

3.3.1. Booting the ISO Image on the DGX-2, DGX A100, DGX A800, or DGX H100 Remotely

1. Connect to the BMC and ensure the required user privileges are set.
 - a. Open a browser within your LAN and go to `https://<BMC-ip-address>/`, then log in.
 - b. From the left-side menu, click Settings and then select User Management.
 - c. Click the card with the user name that you created for the BMC.
 - d. In the User Management Configuration dialog, make sure the VMedia Access checkbox is selected, then click Save.

User Management Configuration

Username
dgxuser

☐ Change Password

Password Size
16 bytes

Password

Confirm Password

☒ Enable User Access

Privilege
Administrator

☒ KVM Access

☒ VMedia Access

2. Set up the ISO image as virtual media.
 - a. From the left-side menu, click Remote Control.

NVIDIA DGX™ A100

Apr 24 2020 20:19:22 CST
FW: 9.11.12
IP: 172.18.205.154
MAC: 5C:FF:35:C2:50:7E
Chassis Part: 120-22987-2510-000
Chassis SN: 123456789123
Host Online
Chassis Identify LED

Quick Links...

- Dashboard
- Sensor
- System Inventory
- FRU Information
- GPU Information
- Logs & Reports
- Settings
- Remote Control
- Power Control
- Chassis ID LED Control
- Maintenance
- Sign out

Dashboard Control Panel

89 d 7 hrs Power-On Hours

181 Pending Disconnections

40 Access Logs

8 GPU Info


Firmware	BMC	BIOS	MB FPGA	MID FPGA	GB FPGA	PSU 0	PSU 1	PSU 2	PSU 3	PSU 4	PSU 5
Primary	9.11.12*	0.00	9.00.02	9.00.02	3.01	1.04	1.04	1.04	1.04	1.04	1.04
Secondary	9.08.11	0.10*	N/A	N/A	N/A	1.04	1.04	1.04	1.04	1.04	1.04
Communication	N/A	N/A	N/A	N/A	N/A	1.04	1.04	1.04	1.04	1.04	1.04

Front View

Rear View

Sensor Monitoring
All sensors are good now!
Currently recovered

- b. Select Launch KVM.



- c. From the top menu bar in the KVM window, click Browse File and select the ISO image, then click Start Media.



The CD image should now be connected.



- d. From the top menu bar in the KVM window, click Power and then select Reset Server.
3. Boot from the virtual media.


Typically, the default boot order does not boot the CDROM image. You can change this in the BIOS or as a one-time option in the boot menu.

 - a. To bring up the boot menu, press **F11** at the beginning of the boot process.


Pressing **F11** will display Entering Boot Menu in the virtual display before entering the boot menu.



- b. In the boot menu, select UEFI: AMI Virtual CDROM0 1.00 as the boot device and then press **ENTER**



If you are booting from the DGX-2, the boot device is labeled UEFI: Virtual CDROM0 1.00.



- c. Follow the instructions at *Installing and Configuring Red Hat Enterprise Linux*

3.3.2. Booting the ISO Image on the DGX-1 Remotely

1. Connect to the BMC and change user privileges.
 - a. Open a Java-enabled web browser within your LAN and go to `http://<BMC-ip-address>/`, then log in.

Use Firefox or Internet Explorer. Google Chrome is not officially supported by the BMC.
 - b. From the top menu, click Configuration and then select Users.
 - c. Select the user name that you created for the BMC, then click Modify User.
 - d. In the Modify User dialog, select the VMedia checkbox to add it to the extended privileges for the user, then click Modify.

✖

Modify User

Username

qct.admin

☐ Change Password

Password Size

☐ 16 Bytes ☐ 20 Bytes

Password

Confirm Password

User Access

☐ Enable

Network Privilege

Administrator ▾

Extended Privileges

☒ KVM ☒ VMedia

SNMPv3 Status

☐ Enable

SNMPv3 Access

Authentication Protocol

Privacy Protocol

Email ID

Email Format

AMI-Format ▾

Uploaded SSH Key

Not Available

New SSH Key

Choose File

No file chosen

Modify

Cancel

2. Set up the ISO image as virtual media and reboot the system.
 - a. From the top menu, click Remote Control and select Remote KVM.



- b. Click Launch KVM to open the remote console.
- c. From the top menu bar in the KVM window, click Browse File and select the ISO image, then click Start Media.




The CD image should now be connected.




- d. From the top menu bar in the KVM window, click Power and then select Reset Server.
3. Boot the CD ROM image.

The default boot order does not boot the CDROM image. This can be changed in the BIOS or as a one-time option in the boot menu. To bring up the boot menu, press F11 at the beginning of the boot process. Pressing **F11** will display Show Boot Options at the top of the virtual display before entering the boot menu. Use the “soft” keyboard (Menu ▢ Keyboard Layout ▢ SoftKeyboard ▢ <Language>) to bring up a virtual keyboard if pressing the physical key has no effect.



- a. In the boot menu, select UEFI: AMI Virtual CDROM 1.00 as the boot device and then press **ENTER**




- b. Follow the instructions at [Installing and Configuring Red Hat Enterprise Linux](#)

3.4. Installing and Configuring Red Hat Enterprise Linux

This section assumes you have booted the Red Hat Enterprise Linux ISO image.


Note: Rocky Linux: The procedures for installing Rocky Linux are essentially the same as those described here, except where noted. The bootup installation screen will refer to Rocky Linux instead of Red Hat Enterprise Linux, and the Quick Start installer for Rocky Linux is based on the Red Hat Enterprise Linux installer, so the look is similar except, again, for the naming.

1. After booting the ISO image, the GRUB menu for the installer appears.



2. If you wish to automate the installation with a kickstart file, see the section [Installing with Kickstart](#)
3. Select `Install Red Hat Enterprise Linux` and press 'e' to edit the selected option.
 - a. Add the "nomodeset" parameter as shown below.

"nomodeset" prevents the in-box Nouveau driver from loading as it might not properly support the GPUs used in the DGX systems, resulting in display issues.




```
setparams 'Install Red Hat Enterprise Linux 7.5'

linuxefi /images/pxeboot/vmlinuz inst.stage2=hd:LABEL=RHEL-7.5\x20Serv\
er.x86_64 quiet nomodeset_
initrdefi /images/pxeboot/initrd.img

Press Ctrl-x to start, Ctrl-c for a command prompt or Escape to
discard edits and return to the menu. Pressing Tab lists possible
completions.
```

- b. Press Ctrl-x to save your changes and start the installation.
4. Refer to the [Red Hat Enterprise Linux Quick Installation Guide](#) for guidance on using the installer.
5. Configure the language, region, date, time, keyboard, and other configuration options you might need from the Installation Summary Screen.
6. Set the Software Selection to the correct value.
 - ▶ For DGX Station and DGX Station A100: Set to Server with GUI.
 - ▶ For DGX Servers (DGX 1-1, DGX-2, DGX A100, DGX A800, and DGX H100): Set to Minimal Install.

Note: Setting the correct Software Selection is critical for proper operation.




7. Partition your disks based on the platform and whether or not you would like to use encryption:


- ▶ *Disk Partitioning for DGX-1, DGX Station, and DGX Station A100*
- ▶ *Disk Partitioning with Encryption for DGX-1, DGX Station, and DGX Station A100*
- ▶ *Disk Partitioning for DGX-2, DGX A100, DGX A800, and DGX H100*
- ▶ *Disk Partitioning with Encryption for DGX-2, DGX A100, DGX A800, and DGX H100*

8. Configure Ethernet.

From the Network & Host Name section, select and enable the Ethernet device. This defaults to DHCP and can be changed for static IP configurations under Configure.



9. From the INSTALLATION SUMMARY screen, set your password (at **User Settings > Root Password**) and create a new user (at **User Settings > User Creation**), then click Begin installation to start the installation.



When the system reboots, be sure and eject any still-mounted installation discs.

10. Complete the initial Red Hat Enterprise Linux setup.

- ▶ If you installed using the *Server with GUI* base environment, the Initial Setup starts automatically where you can accept the license agreement and register the system. See the [Red Hat instructions](#) for details.
- ▶ If you are using CentOS you will need to accept the license agreement.
- ▶ If you installed with any other base environment, log on to the system as root user and then register the system.

```
subscription-manager register --auto-attach --username=user_name --
  ↪password=password
```

See [How to register and subscribe a system to the Red Hat Customer Portal using Red Hat Subscription-Manager](#) for further information.

3.5. Partitioning


This chapter provides instructions for partitioning the DGX system:

- ▶ *Disk Partitioning for DGX-1, DGX Station, and DGX Station A100*
- ▶ *Disk Partitioning for DGX-2, DGX A100, DGX A800, and DGX H100*
- ▶ *Disk Partitioning with Encryption for DGX-1, DGX Station, and DGX Station A100*
- ▶ *Disk Partitioning with Encryption for DGX-2, DGX A100, DGX A800, and DGX H100*

3.5.1. Disk Partitioning for DGX-1, DGX Station, and DGX Station A100

Note: The screenshots in the following section are taken from a DGX-1. The screens for the DGX Station and DGX Station A100 installations can present slightly different information for such things as disk size, disk space available, interface names, and so on.


1. At the Installation Destination screen, *select the smaller* of the available drives to install on.




Under **Storage Configuration**, click the **Custom** radio button and then click **Done**.

This brings up the **Manual Partitioning** window.

2. Expand the drop-down menu for the device you've selected and delete all existing partitions until there are none remaining.



3. Click the **+** button on the bottom left to create a new partition.
Create the `/boot/efi` partition with a size of 512 MiB.



4. Select **Standard Partition** for the **Device Type**.

MANUAL PARTITIONING RED HAT ENTERPRISE LINUX 9.0 INSTALLATION

[Done](#) us [Help!](#)

New Red Hat Enterprise Linux 9.0 Installation

SYSTEM

Mount Point	Size
/boot/efi nvme0n1p1	512 MiB

+ - ↻

AVAILABLE SPACE: 1.75 TiB | TOTAL SPACE: 1.75 TiB

[1 storage device selected](#)

nvme0n1p1

Mount Point: /boot/efi

Desired Capacity: 512 MiB

Device(s): **Micron_7300_MTFDHBG1T9-TDF (nvme0n1)**

Device Type: **Stand...** ☐ Encrypt

File System: **EFI S...** ☒ Reformat

Label:


Name: nvme0n1p1

[Discard All Changes](#)

4

Under **Devices**, ensure only the drive you chose in step 1 is selected. Click **Update Settings** to confirm your changes.

- Click the **+** button on the bottom left again to create another new partition. Create the **/** partition, this time leaving the **Desired Capacity** field empty. This lets the installer know to use the remaining capacity of the disks.



6. For the `/` partition, again select **Standard Partition** for the **Device Type**. Under **Devices**, ensure that only the drive you chose in step 1 is selected. For the **File System**, select **XFS**.

MANUAL PARTITIONING RED HAT ENTERPRISE LINUX 9.0 INSTALLATION

[Done](#) us [Help!](#)

New Red Hat Enterprise Linux 9.0 Installation

SYSTEM

/boot/efi 512 MiB
nvme0n1p1

/ 1.75 TiB >
rhel_host-10-34-1-31-root

+ - ↻

AVAILABLE SPACE
1.3 MiB

TOTAL SPACE
1.75 TiB

[1 storage device selected](#)

rhel_host-10-34-1-31-root

Mount Point:
/

Desired Capacity:
1.75 TiB

Device(s):
Micron_7300_MTFDHBG1T9-TDF (nvme0n1)

Modify...

Device Type:
Stand... ☐ Encrypt

File System:
xfs ☒ Reformat

Label:


Name:

6

[Discard All Changes](#)

Under **Devices**, ensure that only the drive you chose in step 1 is selected. For the **File System**, select **XFS**. Click **Update Settings** to confirm your changes.

7. Click **Done**. This causes a yellow warning bar to appear on the bottom because no swap partition has been created.
8. Click **Done** again and then click **Accept Changes** to write all of our customizations to disk.



9. Return to step 8 in the *Installing and Configuring Red Hat Enterprise Linux* section.

3.5.2. Disk Partitioning with Encryption for DGX-1, DGX Station, and DGX Station A100

Note: The screenshots in the following section are taken from a DGX-1. The screens for the DGX Station and DGX Station A100 installations can present slightly different information for such things as disk size, disk space available, interface names, etc.

1. At the Installation Destination screen, *select the smaller* of the available drives to install on. Under **Storage Configuration**, click the **Custom** radio button and then click Done.

INSTALLATION DESTINATION

Done

RED HAT ENTERPRISE LINUX 9.0 INSTALLATION

us

Help!

Device Selection

Select the device(s) you'd like to install to. They will be left untouched until you click on the main menu's "Begin Installation" button.

Local Standard Disks

1.75 TiB

SAMSUNG MZ1LB1T9HALS-00007

nvme2n1 / 1.3 MiB free

1.75 TiB

SAMSUNG MZ1LB1T9HALS-00007

nvme3n1 / 1.3 MiB free

3.49 TiB

KCM6DRUL3

nvme4n1 / 3.49

Disks left unselected here will not be touched.

Specialized & Network Disks

Add a disk...

Disks left unselected here will not be touched.

Storage Configuration


☒ Automatic ☐ Custom

☐ I would like to make additional space available.


Full disk summary and boot loader...

2 disks selected; 3.49 TiB capacity; 2.61 MiB free [Refresh...](#)


- This brings up the **Manual Partitioning** window. Expand the drop-down menu for the device you've selected and delete all existing partitions until there are none remaining.



3. Click the + button on the bottom left to create a new partition.
Create the `/boot/efi` partition with a size of 512 MiB.



4. Select Standard Partition for the Device Type.




Under **Devices**, ensure only the drive you chose in step 1 is selected.

Click **Update Settings** to confirm your changes.

5. Click the **+** button on the bottom left again to create another new partition.

Create the `/boot` partition with a size of 2 GiB.



6. For the /boot partition, again select Standard Partition for the Device Type.

MANUAL PARTITIONING RED HAT ENTERPRISE LINUX 9.0 INSTALLATION

[Done](#) us [Help!](#)

New Red Hat Enterprise Linux 9.0 Installation

SYSTEM

/boot/efi 512 MiB

/boot 2 GiB

nvme2n1p1

nvme2n1p1

Mount Point: /boot

Desired Capacity: 2 GiB

Device Type: RAID

File System: xfs

Label:

Device(s): SAMSUNG MZ1LB1T9HALS-00C07 (nvme2n1) and 1 other

RAID Level: RAID1

Encrypt

Reformat

Name: boot

AVAILABLE SPACE 3.49 TiB TOTAL SPACE 3.49 TiB

[2 storage devices selected](#)

6


[Discard All Changes](#)

Under **Devices**, ensure that only the drive you chose in step 1 is selected. For the **File System**, select **XFS**.

Click Update Settings to confirm your changes.

7. Click the + button on the bottom left again to create another new partition.

Create the / partition, this time leaving the **Desired Capacity** field empty. This lets the installer know to use the remaining capacity of the disks.



8. For the `/` partition, again select **Standard Partition** for the **Device Type**. Be sure to check the **Encrypt** checkbox, and choose **luks2** for the **LUKS Version**. For the **File System**, select **XFS**. Again confirm that this partition uses both of the devices you selected in step 2. Then click **Done**.

MANUAL PARTITIONING RED HAT ENTERPRISE LINUX 9.0 INSTALLATION

[Done](#) us [Help!](#)

New Red Hat Enterprise Linux 9.0 Installation

SYSTEM

/boot	2 GiB
boot	
/boot/efi	512 MiB
boot_efi	
/	3.38 TiB >
rhel_cl1-fair-01-root	

+ - ↺

AVAILABLE SPACE
2.61 MiB

TOTAL SPACE
3.49 TiB

[2 storage devices selected](#)

rhel_cl1-fair-01-root

Mount Point:

Desired Capacity:

Device(s): SAMSUNG MZ1LB1T9HALS-00007 (nvme2n1) and 1 other [Modify...](#)

Device Type: RAID ☒ Encrypt

File System: xfs ☒ Reformat

RAID Level: RAID1

LUKS Version: luks2


Label:

Name:


8

[Discard All Changes](#)

9. A prompt will now appear, asking for a LUKS password. Be sure to choose a strong and secure password. After entering your password twice, click **Save Passphrase**
10. Click **Done**. This causes a yellow warning bar to appear on the bottom because no swap partition has been created.



11. Click **Done** again and then click **Accept Changes** to write all of our customizations to disk.




12. Return to step 8 in the *Installing and Configuring Red Hat Enterprise Linux* section.

3.5.3. Disk Partitioning for DGX-2, DGX A100, DGX A800, and DGX H100


Note: The screenshots in the following section are taken from a DGX A100. The instructions for the DGX-2, DGX H100, and DGX A800 installation can present slightly different information, such as disk size, disk space available, interface names, and so on.

1. At the **Installation Destination** screen, select the smaller of the available drives to install on. Under **Storage Configuration**, click the **Custom** radio button and then click **Done**.




This brings up the **Manual Partitioning** window.

- Expand the drop-down menu for the device you have selected and delete all existing partitions until there are none remaining.



3. Click the + button on the bottom left to create a new partition.
Create the /boot/efi partition with a size of 512 MiB.



4. Change the **Device Type** to **RAID**, change the **RAID Level** to **RAID1**, and confirm that this partition covers both of the devices you selected in step 2 by clicking **Modify** in the **Device(s)** section and making sure both disks are still selected.

Note that the partition information on the left might not reflect both devices yet. Click **Update Settings** to confirm your changes.

MANUAL PARTITIONING RED HAT ENTERPRISE LINUX 9.0 INSTALLATION

[Done](#) us [Help!](#)

New Red Hat Enterprise Linux 9.0 Installation

SYSTEM

/boot/efi 512 MiB >

nvme2n1p1

+ - ↺

AVAILABLE SPACE **3.49 TiB** TOTAL SPACE **3.49 TiB**

[2 storage devices selected](#)

nvme2n1p1

Mount Point: /boot/efi

Desired Capacity: 512 MiB

Device(s): SAMSUNG MZ1LB1T9HALS-00007 (nvme2n1) and 1 other [Modify...](#)

Device Type: RAID ☐ Encrypt

RAID Level: RAID1

File System: EFI S... ☒ Reformat

Label:


Name: boot_efi

[Discard All Changes](#)

4

5. Click the + button on the bottom left again to create another new partition.

Create the / partition, this time leaving the Desired Capacity field empty. This lets the installer know to use the remaining capacity of the disks.



6. For the **/** partition, again select **RAID** for the **Device Type** and **RAID1** for the **RAID Level**. For the **File System**, select **XFS**.

Confirm that this partition uses both of the devices you selected in step 2 by clicking **Modify** in the **Device(s)** section and making sure both disks are still selected.

MANUAL PARTITIONING RED HAT ENTERPRISE LINUX 9.0 INSTALLATION

[Done](#) us [Help!](#)

New Red Hat Enterprise Linux 9.0 Installation

SYSTEM

- /boot/efi 512 MiB
- /boot nvme2n1p1 2 GiB**

+ - ↺

AVAILABLE SPACE 3.49 TiB **TOTAL SPACE** 3.49 TiB

[2 storage devices selected](#)

nvme2n1p1

Mount Point: /boot

Desired Capacity: 2 GiB

Device(s): SAMSUNG MZ1LB1T9HALS-00007 (nvme2n1) and 1 other [Modify...](#)

Device Type: RAID ☐ Encrypt

File System: xfs ☒ Reformat

RAID Level: RAID1

Label:

Name: boot

[Discard All Changes](#)

6

7. Click **Done**.

This causes a yellow warning bar to appear on the bottom because no swap partition has been created.

8. Click **Done** again and then click **Accept Changes** to write all of our customizations to disk.

MANUAL PARTITIONING RED HAT ENTERPRISE LINUX 9.0 INSTALLATION

[Done](#) us [Help!](#)

SUMMARY OF CHANGES

Your customizations will result in the following changes taking effect after you return to the main menu and begin installation:

Order	Action	Type	Device	Mount point
1	destroy device	mdarray	MDRAID set (mirror) (boot-efi)	
2	destroy format	software RAID	nvme3n1p1 on SAMSUNG MZ1LB1T9HALS-00007	
3	destroy format	software RAID	nvme2n1p1 on SAMSUNG MZ1LB1T9HALS-00007	
4	destroy device	mdarray	MDRAID set (mirror) (root)	
5	destroy format	software RAID	nvme2n1p2 on SAMSUNG MZ1LB1T9HALS-00007	
6	destroy device	partition	nvme2n1p2 on SAMSUNG MZ1LB1T9HALS-00007	
7	destroy device	partition	nvme2n1p1 on SAMSUNG MZ1LB1T9HALS-00007	
8	destroy format	software RAID	nvme3n1p2 on SAMSUNG MZ1LB1T9HALS-00007	
9	destroy device	partition	nvme3n1p2 on SAMSUNG MZ1LB1T9HALS-00007	
10	destroy device	partition	nvme3n1p1 on SAMSUNG MZ1LB1T9HALS-00007	
11	create device	partition	nvme2n1p1 on SAMSUNG MZ1LB1T9HALS-00007	
12	create format	software RAID	nvme2n1p1 on SAMSUNG MZ1LB1T9HALS-00007	
13	create device	partition	nvme2n1p2 on SAMSUNG MZ1LB1T9HALS-00007	
14	create format	software RAID	nvme2n1p2 on SAMSUNG MZ1LB1T9HALS-00007	

[Cancel & Return to Custom Partitioning](#) [Accept Changes](#)

[Discard All Changes](#)

[2 storage devices selected](#)


8

- Return to step 8 in the *Installing and Configuring Red Hat Enterprise Linux* section.

3.5.4. Disk Partitioning with Encryption for DGX-2, DGX A100, DGX A800, and DGX H100

Note: The screenshots in the following section are taken from a DGX A100. The following instructions will use LUKS to create an encrypted root filesystem on your boot devices. This is a separate process from using self-encrypting data-drives.


- At the Installation Destination screen, *select the smaller* of the available drives to install on.




Under Storage Configuration, click the Custom radio button and then click Done.

This brings up the Manual Partitioning window.

- Expand the drop-down menu for the device you have selected and delete all existing partitions until there are none remaining.



3. Click the + button on the bottom left to create a new partition.
Create the /boot/efi partition with a size of 512 MiB.



4. Change the Device Type to RAID, change the RAID Level to RAID1, and confirm that this partition covers both of the devices you selected in step 2 by clicking Modify in the Device(s) section and making sure both disks are still selected.

MANUAL PARTITIONING RED HAT ENTERPRISE LINUX 9.0 INSTALLATION

[Done](#) us [Help!](#)

New Red Hat Enterprise Linux 9.0 Installation

SYSTEM

Partition	Size
/boot/efi	512 MiB
nvme2n1p1	

+ - ↺

AVAILABLE SPACE **3.49 TiB** TOTAL SPACE **3.49 TiB**

[2 storage devices selected](#)

nvme2n1p1

Mount Point:

Desired Capacity:

Device(s): SAMSUNG MZ1LB1T9HALS-00007 (nvme2n1) and 1 other [Modify...](#)

Device Type: **RAID** ☐ Encrypt

RAID Level: **RAID1**

File System: **EFI S...** ☒ Reformat

Label:

Name:

[Discard All Changes](#)


4

Note that the partition information on the left might not reflect both devices yet.

Click Update Settings to confirm your changes, and verify that the `/boot/efi` partition shown lists the partition name and not the individual device.

5. Click the + button on the bottom left again to create another new partition.

Create the `/boot` partition with a size of 2 GiB.



- For the /boot partition, again select RAID for the Device Type, RAID1, and the RAID Level. For the File System, select XFS.

MANUAL PARTITIONING RED HAT ENTERPRISE LINUX 9.0 INSTALLATION

[Done](#) us [Help!](#)

New Red Hat Enterprise Linux 9.0 Installation

SYSTEM

/boot/efi 512 MiB
nvme0n1p1

/ 1.75 TiB >
rhel_host-10-34-1-31-root

+ - ↺

AVAILABLE SPACE: 1.3 MiB
TOTAL SPACE: 1.75 TiB

[1 storage device selected](#)

rhel_host-10-34-1-31-root

Mount Point: /

Desired Capacity: 1.75 TiB

Device(s): Micron_7300_MTFDHBG1T9-TDF (nvme0n1) [Modify...](#)

Device Type: Standard ☐ Encrypt

File System: xfs ☒ Reformat

Label: Name:

6

[Discard All Changes](#)


Again confirm that this partition uses both of the devices you selected in step 2 by clicking **Modify** in the **Device(s)** section and making sure both disks are still selected.

Click Update Settings to confirm your changes. Click the + button on the bottom left again to create another new partition.

Create the / partition, this time leaving the Desired Capacity field empty. This lets the installer know to use the remaining capacity of the disks.

7. For the / partition, again select RAID for the Device Type, RAID1 and the RAID Level.

Be sure to check the Encrypt checkbox, and choose luks2 for the LUKS Version.



For the File System, select XFS. Again confirm that this partition uses both of the devices you selected in step 2.

Click Update Settings to confirm your changes, and Done to begin exiting the partition menu.

A prompt will now appear asking for a LUKS password.

8. Be sure to choose a strong and secure password.

MANUAL PARTITIONING RED HAT ENTERPRISE LINUX 9.0 INSTALLATION

[Done](#) us [Help!](#)

New Red Hat Enterprise Linux 9.0 Installation

SYSTEM

/boot 2 GiB
boot

/boot/efi 512 MiB
boot_efi

/ 3.38 TiB >
rhel_cl1-fair-01-root

+ - ↺

AVAILABLE SPACE
2.61 MiB

TOTAL SPACE
3.49 TiB

[2 storage devices selected](#)

rhel_cl1-fair-01-root

Mount Point:
/

Desired Capacity:
3.38 TiB

Device(s):
SAMSUNG MZ1LB1T9HALS-00007 (nvme2n1) and 1 other
[Modify...](#)

Device Type:
RAID ☒ Encrypt

File System:
xfs ☒ Reformat

RAID Level:
RAID1

LUKS Version:
luks2

Label:

Name:
root


8

[Discard All Changes](#)


After entering your password twice, click Save Passphrase.

9. Click Done.

This causes a yellow warning bar to appear on the bottom because no swap partition has been created.



10. Click Done again and then click Accept Changes to write all of our customizations to disk.



11. Return to step 8 in the *Installing and Configuring Red Hat Enterprise Linux* section.

Chapter 4. Installing the DGX Software

This section requires that you have already installed Red Hat Enterprise Linux or derived operating system on the DGX system. You can skip this section if you already installed the DGX software stack during a kickstart install.

Important: Before performing the installation, refer to the [Release Notes](#) for the latest information and additional instructions depending on the specific release.

4.1. Configuring a System Proxy

If your network requires you to use a proxy:

- Edit the file `/etc/dnf/dnf.conf` and make sure the following lines are present in the `[main]` section, using the parameters that apply to your network:

```
proxy=http://<Proxy-Server-IP-Address>:<Proxy-Port>
proxy_username=<Proxy-User-Name>
proxy_password=<Proxy-Password>
```

4.2. Enabling the DGX Software Repository

Attention: By running these commands you are confirming that you have read and agree to be bound by the [DGX Software License Agreement](#). You are also confirming that you understand that any pre-release software and materials available that you elect to install in a DGX might not be fully functional, might contain errors or design flaws, and might have reduced or different security, privacy, availability, and reliability standards relative to commercial versions of NVIDIA software and materials, and that you use pre-release versions at your own risk.

Install the NVIDIA DGX Package for Red Hat Enterprise Linux.

```
sudo dnf install -y https://repo.download.nvidia.com/baseos/el/el-files/9/
↪ nvidia-repo-setup-22.12-1.el9.x86_64.rpm
```

4.3. Installing Required Components

1. Upgrade to the latest software.

```
sudo dnf update -y --nobest
```

2. Install DGX tools and configuration files.

- ▶ For DGX-1, install DGX-1 Configurations.

```
sudo dnf group install -y 'DGX-1 Configurations'
```

- ▶ For the DGX-2, install DGX-2 Configurations.

```
sudo dnf group install -y 'DGX-2 Configurations'
```

- ▶ For the DGX A100, install DGX A100 Configurations.

```
sudo dnf group install -y 'DGX A100 Configurations'
```

- ▶ For the DGX A800, install DGX A800 Configurations.

```
sudo dnf group install -y 'DGX A800 Configurations'
```

- ▶ For the DGX H100, install DGX H100 Configurations.

```
sudo dnf group install -y 'DGX H100 Configurations'
```

- ▶ For the DGX Station, install DGX Station Configurations.

```
sudo dnf group install -y 'DGX Station Configurations'
```

- ▶ For the DGX Station A100, install DGX Station A100 Configurations.

```
sudo dnf group install -y 'DGX Station A100 Configurations'
```

The configuration changes take effect only after rebooting the system. To reduce the number of reboots, you can defer rebooting until after you install the drivers.

4.4. Configuring Data Drives

The data drives in the DGX systems can be configured as RAID 0 or RAID 5. RAID 0 provides the maximum storage capacity and performance, but does not provide any redundancy.

RAID 0 is often used for data caching. You can use `cachefilesd` to provide a cache for NFS shares.

Important: You can change the RAID level later but this will destroy the data on those drives.

Except for the DGX-1, the RAID configuration can be configured during the operating system installation. If you have already configured the RAID array during the installation, you can skip the first step and go to step 2.

1. Configure the `/raid` partition.

All DGX systems support RAID 0 or RAID 5 arrays.

The following commands create a RAID array, mount it to `/raid` and create an appropriate entry in `/etc/fstab`.

- ▶ To create a RAID 0 array:

```
sudo /usr/bin/configure_raid_array.py -c -f
```

- ▶ To create a RAID 5 array:

```
sudo /usr/bin/configure_raid_array.py -c -f -5
```

Note: The RAID array must be configured before installing `nvidia-conf-cachefilesd`, which places the proper SELinux label on the `/raid` directory. If you ever need to recreate the RAID array — which will wipe out any labeling on `/raid` — after `nvidia-conf-cachefilesd` has already been installed, be sure to restore the label manually before restarting `cachefilesd`.

```
sudo restorecon /raid
sudo systemctl restart cachefilesd
```

2. (Optional) Install tools for managing the self-encrypting drives (SED) for the data drives on DGX A100, DGX A800, or DGX H100 systems.

Refer to [Managing Self-Encrypting Drives](#) for more information.

3. (Optional) If you wish to use your RAID array for caching, install `nvidia-conf-cachefilesd`. This will update the `cachefilesd` configuration to use the `/raid` partition.

```
sudo dnf install -y nvidia-conf-cachefilesd
```

4.5. Installing the GPU Driver

You have the option to choose between different GPU driver branches for your DGX system. The latest driver release includes new features but might not provide the same support duration as an older release. Refer to the release notes at the [NVIDIA Driver Documentation](#) for more details and the minimum required driver release for the GPU architecture.

1. Display a list of available drivers.

```
dnf module list nvidia-driver
```

Example Output

Name	Stream	Summary
↪ Profiles		
nvidia-driver	latest	
↪ default [d], fm, ks, src		Nvidia driver for
↪ latest branch		
nvidia-driver	latest-dkms [d]	
↪ default [d], fm, ks		Nvidia driver for
↪ latest-dkms branch		

(continues on next page)

(continued from previous page)

nvidia-driver	open-dkms	Nvidia driver for
↪ default [d], fm, ks, src		
↪ open-dkms branch		
nvidia-driver	515	Nvidia driver for
↪ default [d], fm, ks, src		
↪ 515 branch		
nvidia-driver	515-dkms	Nvidia driver for
↪ default [d], fm, ks		
↪ 515-dkms branch		
nvidia-driver	515-open	Nvidia driver for
↪ default [d], fm, ks, src		
↪ 515-open branch		
nvidia-driver	520	Nvidia driver for
↪ default [d], fm, ks, src		
↪ 520 branch		
nvidia-driver	520-dkms	Nvidia driver for
↪ default [d], fm, ks		
↪ 520-dkms branch		
nvidia-driver	520-open	Nvidia driver for
↪ default [d], fm, ks, src		
↪ 520-open branch		
nvidia-driver	525	Nvidia driver for
↪ default [d], fm, ks, src		
↪ 525 branch		
nvidia-driver	525-dkms	Nvidia driver for
↪ default [d], fm, ks		
↪ 525-dkms branch		
nvidia-driver	525-open	Nvidia driver for
↪ default [d], fm, ks, src		
↪ 525-open branch		
nvidia-driver	530	Nvidia driver for
↪ default [d], fm, ks, src		
↪ 530 branch		
nvidia-driver	530-dkms	Nvidia driver for
↪ default [d], fm, ks		
↪ 530-dkms branch		
nvidia-driver	530-open	Nvidia driver for
↪ default [d], fm, ks, src		
↪ 530-open branch		
nvidia-driver	535 [e]	Nvidia driver for
↪ default [d] [i], fm, ks, src [i]		
↪ 535 branch		
nvidia-driver	535-dkms	Nvidia driver for
↪ default [d], fm, ks		
↪ 535-dkms branch		
nvidia-driver	535-open	Nvidia driver for
↪ default [d], fm, ks, src		
↪ 535-open branch		

The following steps install the NVIDIA CUDA driver and configure the system. Replace the release version used as an example (535) with the release you want to install. Ensure that the driver release you intend to install is supported by the GPU in the system.

2. Install the NVIDIA CUDA driver.

1. For non-NVSwitch systems, such as DGX-1, DGX Station, and DGX Station A100, install the driver using the default and src profiles:

```
sudo dnf module install --nobest -y nvidia-driver:535/{default,src}
sudo dnf install -y nv-persistence-mode libnvidia-nscq-535
```

2. For NVSwitch systems, such as DGX-2, DGX A100, and DGX A800, install the driver using the fabric manager (fm) and source (src) profiles:

```
sudo dnf module install --nobest -y nvidia-driver:535/{fm,src}
sudo dnf install -y nv-persistence-mode nvidia-fm-enable
```

3. For DGX H100, install the DKMS version of the driver using the fabric manager (fm) profile:

```
sudo dnf module install --nobest -y nvidia-driver:535-dkms/fm
sudo dnf install -y nv-persistence-mode nvidia-fm-enable
```

3. (DGX Station A100 Only) Install additional packages required for DGX Station A100.

These packages must be installed after installation of the `nvidia-driver` module.

```
sudo dnf install -y nvidia-conf-xconfig nv-docker-gpus
```

The configuration changes take effect only after rebooting the system. To reduce the number of reboots, you can defer rebooting until after you install the NVIDIA Container Runtime group.

4. Install and configure the NVIDIA Container Toolkit with Docker CE or Podman.

Choose one of the following options:

- ▶ *Installing and Running Docker CE*
- ▶ *Installing and Running Podman*

4.5.1. Installing and Running Docker CE

To run an NVIDIA container with Docker CE:

1. Install the NVIDIA container device plugin along with Docker CE.

Install the NVIDIA Container Runtime group:

```
sudo dnf group install -y --allowerase 'NVIDIA Container Runtime'
```

2. Reboot the system to load the drivers and to update system configurations.

1. Reboot the system.

```
sudo reboot
```

2. After the system reboots, verify that the drivers are loaded and are handling the NVIDIA devices.

```
nvidia-smi
```

The output shows all available GPUs.

Example Output

```

+-----+
↪+
| NVIDIA-SMI 535.86.10    Driver Version: 535.86.10    CUDA Version: 12.2
↪|
|-----+-----+-----+
↪+
| GPU   Name              Persistence-M| Bus-Id        Disp.A | Volatile Uncorr. ECC
↪|
| Fan   Temp   Perf    Pwr:Usage/Cap|      Memory-Usage | GPU-Util  Compute M.
↪|
|                                           |                      |              MIG M.
↪|
=====+=====+=====+
|    0   Tesla V100-SXM2...  On      | 00000000:06:00.0 Off  |              0
↪|
| N/A    35C    P0      42W / 300W |      0MiB / 16160MiB |      0%      Default
↪|
|                                           |                      |              N/A
↪|
+-----+-----+-----+
↪+
|    1   Tesla V100-SXM2...  On      | 00000000:07:00.0 Off  |              0
↪|
| N/A    35C    P0      44W / 300W |      0MiB / 16160MiB |      0%      Default
↪|
|                                           |                      |              N/A
↪|
+-----+-----+-----+
↪+
...
+-----+-----+-----+
↪+
|    7   Tesla V100-SXM2...  On      | 00000000:8A:00.0 Off  |              0
↪|
| N/A    35C    P0      43W / 300W |      0MiB / 16160MiB |      0%      Default
↪|
|                                           |                      |              N/A
↪|
+-----+-----+-----+
↪+
+-----+-----+-----+
↪+
| Processes:
↪|
| GPU   GI    CI          PID    Type    Process name                  GPU Memory
↪|
|      ID    ID                                   Usage
↪|
=====+=====+=====+
| No running processes found
↪|
+-----+-----+-----+
↪+

```

3. Run the following command to verify the installation:


```
sudo docker run --gpus=all --rm nvcr.io/nvidia/cuda:12.2.0-base-ubi8 nvidia-smi
```

The output shows all available GPUs.

For information about `nvcr.io`, refer to the [NGC Private Registry User Guide](#).

4.5.2. Installing and Running Podman

To run an NVIDIA container with Podman:

1. Install Podman.

```
sudo dnf install podman
```

2. Install the `nvidia-container-toolkit-base` package.

```
sudo dnf clean expire-cache && sudo dnf install -y nvidia-container-toolkit-base
```

3. Check the NVIDIA Container Toolkit version.

```
nvidia-ctk --version
```

4. Generate the Container Device Interface (CDI) specification file.

```
sudo nvidia-ctk cdi generate --output=/etc/cdi/nvidia.yaml
```

The sample command uses `sudo` to ensure that the file at `/etc/cdi/nvidia.yaml` is created. You can omit the `--output` argument to print the generated specification to STDOUT.

5. Verify that the GPU drivers are loaded and are handling the NVIDIA devices.

```
nvidia-smi -L
```

6. Run the following command to verify the installation.

```
sudo podman run --rm --device nvidia.com/gpu=all ubuntu nvidia-smi -L
```

7. Verify your installation by running a sample container with Podman.

```
podman run --security-opt=label=disable --rm --device nvidia.com/gpu=all ubuntu  
↪ nvidia-smi
```

4.6. Installing Optional Components

The DGX is fully functional after installing the components as described in [Installing Required Components](#). If you intend to launch NGC containers (which incorporate the CUDA toolkit, NCCL, cuDNN, and TensorRT) on the DGX system, which is the expected use case, then you can skip this section.

If you intend to use your DGX as a development system for running deep learning applications on bare metal, then install the optional components as described in this section. Install CUDA Toolkit 12.2 packages (see [Installing the NVIDIA CUDA Driver from the Local Repository](#))

```
sudo dnf install -y cuda-toolkit-12-2 cuda-compat-12-2 nvidia-cuda-compat-setup
```

Note: The output of `nvidia-smi` shows the version of CUDA that is native-compatible with the installed driver (e.g. “NVIDIA-SMI 535.86.10 Driver Version: 535.86.10 CUDA Version: 12.2” in the prior steps). It is recommended to install the CUDA toolkit and compatible packages which match this version.

- ▶ To install the NVIDIA Collectives Communication Library (NCCL) Runtime, refer to the [NCCL:Getting Started](#) documentation

```
sudo dnf group install -y 'NVIDIA Collectives Communication Library Runtime'
```

- ▶ To install the CUDA Deep Neural Networks (cuDNN) Library Runtime, refer to the [NVIDIA cuDNN](#) page.

```
sudo dnf group install -y 'CUDA Deep Neural Networks Library Runtime'
```

- ▶ To install NVIDIA TensorRT, refer to the [NVIDIA TensorRT](#) page.

4.7. Installing NVIDIA GPUDirect Storage

4.7.1. Prerequisites

- ▶ For systems other than NVIDIA DGX-1, DGX-2, and DGX Station, to use the latest GDS version, 12.2.2-1, that is provided by `nvidia-fs-dkms-2.17.5-1`, you must install an NVIDIA Open GPU Kernel module driver. Refer to [Installing the GPU Driver](#) for more information about installing the driver.
- ▶ For NVIDIA DGX-1, DGX-2, and DGX Station running the generic Linux Kernel, the GPUs in these systems are not supported with the NVIDIA Open GPU Kernel modules. The GDS versions 12.2.2-1 and higher only support the Open GPU Kernel modules.

For these systems, you must lock the `nvidia-fs` package to version 2.17.3 or lower and the `nvidia-gds` package to version 12.2.1-1 or lower.

```
sudo dnf install python3-dnf-plugin-versionlock
sudo dnf versionlock add nvidia-fs-0:2.17.3-1 nvidia-fs-dkms-0:2.17.3-1 nvidia-
↪gds-0:12.2.1-1
```

Example Output

```
Adding versionlock on: nvidia-fs-0:2.17.3-1.*
Adding versionlock on: nvidia-gds-0:12.2.1-1.*
```

4.7.2. Procedure

To install NVIDIA GPUDirect Storage (GDS), perform the following steps.

1. Install the kernel headers and development packages for your kernel.

```
sudo dnf install -y kernel-headers-$(uname -r) kernel-devel-$(uname -r)
```

2. Install the GDS package.

```
sudo dnf install -y nvidia-gds
```

Refer to [Verifying a Successful GDS Installation](#) in the *NVIDIA GPUDirect Storage Installation and Troubleshooting Guide*.

4.8. Installing the Optional NVIDIA Desktop Theme

The DGX Software Repository also provides optional theme packages and desktop wallpapers to give the user-interface an NVIDIA look-and-feel for the DGX Station desktop. These packages would have been installed as part of the **DGX Station Configurations** group.


1. To apply the theme and background images, first open `gnome-tweaks`.
2. Under **Applications**, select one of the **NV-Yaru** themes. This comes in default, light, and dark variations.
3. Under **Shell**, select the **NV-Yaru-dark** theme.

If this field is grayed out, you might need to reboot the system or restart GDM in order to enable the user-themes extension.

4. To restart GDM, issue the following.

```
sudo systemctl restart gdm
```

5. Select one of the NVIDIA wallpapers for the background image and lock screen.



Chapter 5. Installing on “Air-Gapped” Systems

For security purposes, some installations require that systems be isolated from the internet or outside networks. Since most DGX software updates are accomplished through an over-the-network process with NVIDIA servers, this section explains how updates can be made when using an over-the-network method is not an option. It includes a process for installing containers as well.

5.1. Registering Your System

See the Red Hat customer portal knowledge base article [How to register and subscribe a system offline to the Red Hat Customer Portal](#)

5.2. Creating a Local Mirror of the NVIDIA Repository

Instructions for setting up a private repository or mirroring the NVIDIA and the Red Hat repositories are beyond the scope of this document. It is expected that users are knowledgeable about those processes.

The Red Hat customer portal provides a knowledge base article for [creating a local mirror](#). Pay particular attention to the instructions under *Create a local repo with Red Hat Enterprise Linux 9*. The `reposync` command can now download repository metadata as well, so there is no longer a need to use `createrepo` after.

The repositories that will need to be mirrored are:

- ▶ `rhel-9-for-x86_64-appstream-rpms`
- ▶ `rhel-9-for-x86_64-baseos-rpms`
- ▶ `codeready-builder-for-rhel-9-x86_64-rpms`
- ▶ `nvidia-dgx-9`
- ▶ `CUDA`

Once mirrored, be sure to configure the target system to use your local repository. This can be accomplished by creating file under `/etc/yum.repos.d/my_mirror.repo` with the following contents:

```
[nvidia-dgx-9]
name=NVIDIA DGX EL9
baseurl=file:///path/to/your/nvidia-dgx-9-repo-mirror/
enabled=1
gpgcheck=1
gpgkey=file:///etc/pki/rpm-gpg/RPM-GPG-KEY-dgx-cosmos-support

[CUDA]
name=NVIDIA CUDA for EL9
baseurl=file:///path/to/your/CUDA-repo-mirror/
enabled=1
gpgcheck=1
gpgkey=file:///etc/pki/rpm-gpg/RPM-GPG-KEY-cuda
```

Note: The instructions assume that you have the repositories enabled on the local machine. See [Enabling the DGX Software Repository](#) for instructions on enabling the NVIDIA DGX EL8 repository.

The CUDA repository makes use of [modularity streams](#). If mirroring onto a Red Hat Enterprise Linux 9 (or Fedora) system, it's possible to synchronize the modularity metadata in a single command:

```
reposync -p /path/to/your/mirror/ --repoid=CUDA --download-metadata --downloadcomps
```

However, if you are mirroring the CUDA repository onto another distribution (for example Ubuntu, CentOS 7, Red Hat Enterprise Linux 7) then you will have to manually generate the repository metadata:

```
reposync -p /path/to/your/mirror/ --repoid=CUDA --downloadcomps
createrepo -v /path/to/your/mirror/
python3 genmodules.py /path/to/your/mirror/ /tmp/modules.yaml
modifyrepo /tmp/modules.yaml /path/to/your/mirror/repoata/
```

Note that you can find the `genmodules.py` script from NVIDIA's `yum-packaging-precompiled-kmod` repository on GitHub:

<https://github.com/NVIDIA/yum-packaging-precompiled-kmod>

5.3. Installing Docker Containers

This method applies to Docker containers hosted on the NGC Container Registry. Most container images are freely available, but some are locked and require that you have an NGC account to access. See the [NGC Private Registry User Guide](#) for instructions on accessing locked container images.

1. Enter the docker pull command, specifying the image registry, image repository, and tag.

```
docker pull nvcr.io/nvidia/repository:tag
```

2. Verify the image is on your system using `docker images`.

```
docker images
```

3. Save the Docker image as an archive.

```
docker save nvcr.io/nvidia/repository:tag > framework.tar
```

4. Transfer the image to the air-gapped system using removable media such as a USB flash drive.
5. Load the NVIDIA Docker image.

```
docker load -i framework.tar
```

6. Verify the image is on your system.

```
docker images
```

Chapter 6. Installing with Local Repositories

As an alternative to the method described in [Creating a Local Mirror of the NVIDIA Repository](#), the DGX software can also be installed using local repositories. These repositories are provided by NVIDIA for installing the required packages from local repositories, allowing installation of packages without network access.

6.1. Installing the Base Red Hat Enterprise Linux System

The Red Hat components of the software must be installed either using the standard network based installation, or as described in [Installing on “Air-Gapped” Systems](#). This includes registering and subscribing to the Red Hat Customer Portal.

If the system is connected to the network, follow the steps of the standard Red Hat Enterprise Linux installation, then enable the additional Red Hat repositories. Finally, execute:

```
sudo dnf update -y
sudo dnf install -y kernel-devel kernel-headers
sudo reboot
```

If the system is not connected to the network, follow the instructions in [Creating a Local Mirror of the NVIDIA Repository](#)

6.2. Downloading the Local Repositories

Download the packages that apply to your release.

6.2.1. Release 23.12

DGX Software local repository	<code>dgx-local-repo-23.12-3.el9.x86_64.rpm</code>
NVIDIA CUDA driver local repository	<code>nvidia-driver-local-repo-rhel9-535.129.03-1.0-1.x86_64.rpm</code>
NVIDIA CUDA Toolkit local repository	<code>cuda-repo-rhel9-12-2-local-12.2.2_535.104.05-1.x86_64.rpm</code>

6.2.2. Release 23.08

DGX Software local repository	<code>dgx-local-repo-23.08-11.el9.x86_64.rpm</code>
NVIDIA CUDA driver local repository	<code>nvidia-driver-local-repo-rhel9-535.104.05-1.0-1.x86_64.rpm</code>
NVIDIA CUDA Toolkit local repository	<code>cuda-repo-rhel9-12-2-local-12.2.2_535.104.05-1.x86_64.rpm</code>

6.2.3. Release 23.01

DGX Software local repository	<code>dgx-local-repo-23.01-14.el9.x86_64.rpm</code>
NVIDIA CUDA driver local repository	<code>nvidia-driver-local-repo-rhel9-525.105.17-1.0-1.x86_64.rpm</code>
NVIDIA CUDA Toolkit local repository	<code>cuda-repo-rhel9-12-1-local-12.1.1_530.30.02-1.x86_64.rpm</code>

6.3. Installing the Local Repositories

Install the local repositories:

```
sudo dnf install -y ./dgx-local-repo-23.12-3.el9.x86_64.rpm
sudo dnf install -y ./nvidia-driver-local-repo-rhel9-535.129.03-1.0-1.x86_64.rpm
sudo dnf install -y ./cuda-repo-rhel9-12-2-local-12.2.2_535.104.05-1.x86_64.rpm
```

With the local repositories installed, proceed with the standard *Installing the DGX Software* instructions, with the exception of the CUDA driver installation. To install the CUDA driver from the local repository, follow the steps in the next section *Installing the NVIDIA CUDA Driver from the Local Repository*.

6.4. Installing the NVIDIA CUDA Driver from the Local Repository

- For non-NVSwitch systems, such as DGX-1, DGX Station, and DGX Station A100, install the driver using the default profile:

```
sudo dnf module install -y nvidia-driver:535-dkms
sudo dnf install -y --allowerasing nv-persistence-mode libnvidia-nscq-535
```

- For NVSwitch systems, such as DGX-2, DGX A100, and DGX A800, install the driver using the fabric manager (fm) profile:

```
sudo dnf module install -y nvidia-driver:535-dkms/fm
sudo dnf install -y nv-persistence-mode nvidia-fm-enable
```

- For DGX H100, install the DKMS version of the driver using the fabric manager (fm) profile:

```
sudo dnf module install -y nvidia-driver:535-dkms/fm
sudo dnf install -y nv-persistence-mode nvidia-fm-enable
```

Chapter 7. Installing NVIDIA MLNX_OFED

The DGX software stack for Red Hat Enterprise Linux does not include the NVIDIA MLNX_OFED (Open-Fabrics Enterprise Distribution) for Linux. This is to ensure that the MLNX_OFED driver is in sync with the Red Hat distribution kernel. This section describes how to download, install, and upgrade MLNX_OFED on systems that are running Red Hat Enterprise Linux.

7.1. Prerequisites

- NVIDIA validates each release of NVIDIA DGX Software for Red Hat Enterprise Linux with a specific MLNX_OFED version. Refer to the [Release Notes](#) for the recommended MLNX_OFED version to install.

7.2. Installing and Configuring MLNX_OFED

This section describes how to install MLNX_OFED on systems that do not yet have it installed. It is imperative that a validated MLNX_OFED version is used for the RHEL version that the DGX system is running.

Important: Running the `dnf update` command at any time to install the drivers can update the system to the latest Red Hat Enterprise Linux version.

1. Determine which version of Red Hat Enterprise Linux is installed on the DGX system.

```
cat /etc/redhat-release
```

2. After referring to the release notes, download the MLNX_OFED software bundle.

1. Go to the [Linux InfiniBand Drivers](#) page, and scroll down to the **MLNX_OFED Download Center** matrix.

MLNX_OFED Download Center

Current Versions Archive Versions START OVER

Version (Current)	OS Distribution	OS Distribution Version	Architecture	Download/Documentation
23.10-1.1.9.0-LTS	Ubuntu	RHEL/Rocky 9.3	Select an Operating System from previous column	
5.8-3.0.7.0-LTS	UOS	RHEL/Rocky 9.2		
5.4-3.7.5.0-LTS	SLES	RHEL/Rocky 9.1		
4.9-7.1.0.0-LTS	RHEL/CentOS/Rocky	RHEL/Rocky 9.0		
	Oracle Linux	RHEL/Rocky 8.9		
	OPENEULER	RHEL/Rocky 8.8		
	KYLIN	RHEL/Rocky 8.7		
	EulerOS	RHEL/Rocky 8.6		
	Debian	RHEL/CentOS/Rocky 8.5		
	Community	RHEL/CentOS 8.4		
	Citrix XenServer Host	RHEL/CentOS 8.3		
	CTYUNOS	RHEL/CentOS 8.2		

- At the **MLNX_OFED Download Center** matrix, choose the MLNX_OFED version, OS distribution and distribution version, and architecture to show the software package and documentation. For example,

- **Version:** 23.10-1.1.9.0-LTS
- **OS Distribution:** RHEL/CentOS/Rocky
- **OS Distribution Version:** RHEL/Rocky 9.2
- **Architecture:** x86_64

MLNX_OFED Download Center

Current Versions Archive Versions START


Version (Current)	OS Distribution	OS Distribution Version	Architecture	Download/Documentation
23.10-0.5.5.0-LTS	Ubuntu	RHEL/Rocky 9.2	x86_64	ISO: MLNX_OFED_LINUX-23.10-0.5.5.0-rhel9.2-x86_64.iso
	UOS	RHEL/Rocky 9.1	aarch64	SHA256: 1a170f90b4af4836240203858aeeef1020f73b3097a57579cab5c0f5008f6e5
5.8-3.0.7.0-LTS	SLES	RHEL/Rocky 9.0		Size: 214M
	RHEL/CentOS/Rocky	RHEL/Rocky 8.8		tgz: MLNX_OFED_LINUX-23.10-0.5.5.0-rhel9.2-x86_64.tgz
5.4-3.7.5.0-LTS	Oracle Linux	RHEL/Rocky 8.7		SHA256: 9fe02f896f715ee3432493b8f4e4d48a9f7e6d82cb39bb709be878c7c413c4
4.9-7.1.0.0-LTS	OPENEULER	RHEL/Rocky 8.6		Size: 212M
	KYLIN	RHEL/CentOS/Rocky 8.5		SOURCES: MLNX_OFED_SRC-23.10-0.5.5.0.tgz
	EulerOS	RHEL/CentOS 8.4		SHA256:
	Debian	RHEL/CentOS 8.3		
	Community	RHEL/CentOS 8.2		
	Citrix XenServer Host	RHEL/CentOS 8.1		
	CTYUNOS	RHEL/CentOS 8.0		

- Click the supported ISO or tgz package.
The **Mellanox OFED (MLNX_OFED) Software: End-User Agreement** page appears.
- Accept the End User License Agreement by clicking **I Have Read the Above End User License Agreement**.
The selected software package starts to download.

3. After downloading the correct MLNX_OFED software package, proceed with the installation steps.

For issues during RHEL 9.2 install using MODEP `mlnxofedinstall`, refer to the Known Issues [MOFED `mlnxofedinstall` reports “Current operation system is not supported” using RHEL 9.2](#).

1. Go to the [MLNX_OFED Software Releases](#) site and select the MLNX_OFED software version that you downloaded.
2. Click the **User Manual** link and then navigate to **Installation > Installing MLNX_OFED**.



Follow the installation instructions.

Note: The system might report that additional software needs to be installed before performing the installation. If such a message appears, install the software and then retry installing the MLNX_OFED driver.

4. If you intend to use NVIDIA GPUDirect Storage (GDS), enable the driver's GDS support according to the instructions at [MLNX_OFED Requirements and Installation](#).
5. Install `nvidia-mlnx-config`.

```
sudo dnf install -y nvidia-mlnx-config
```

6. Install kernel headers and development packages for your kernel.

These are needed for the ensuing DKMS compilation.

```
sudo dnf install -y kernel-headers-$(uname -r) kernel-devel-$(uname -r)
```

7. After installing the MLNX_OFED drivers, install the NVIDIA peer memory module.

```
sudo dnf install -y nvidia-peer-memory-dkms
```

Note: `nvidia-peer-memory-dkms` version 1.2 or later, requires MOFED version 5.4-3.0.3.0 or later. Using MOFED versions that do not fit this criteria will result in a build failure of the `nv_peer_mem` DKMS

module. For more information, see: https://github.com/Mellanox/nv_peer_memory/issues/94#

Note: While in-box drivers might be available, using the in-box drivers is not recommended as they provide lower performance than the official MLNX OFED drivers and they do not support the GPUDirect™ RDMA feature. For more information on configuring the in-box drivers, see the following Red Hat Enterprise Linux documentation: [Configuring InfiniBand and RDMA Networks](#).

7.3. Updating NVIDIA MLNX_OFED

This section describes how to update MOFED on systems that already have it installed. The Mellanox InfiniBand Drivers in RPM packages are precompiled for a specific kernel version. Again – it is imperative that the correct MOFED version is used for the RHEL version that the DGX system has been updated to. There is no need to uninstall the current MOFED first, because the “mlnxofedinstall” script will automatically uninstall any previously installed versions.

1. Upgrade the Red Hat Enterprise Linux release and kernel version.

```
sudo dnf update --nobest
```

2. Determine which version of Red Hat Enterprise Linux is installed on the DGX system.

```
cat /etc/redhat-release
```

3. After referring to the release notes, download the MLNX_OFED software bundle.

1. Go to the [Linux InfiniBand Drivers](#) page, and scroll down to the **MLNX_OFED Download Center** matrix.
2. At the **MLNX_OFED Download Center** matrix, choose the MLNX_OFED version, OS distribution and distribution version, and architecture to show the software package and documentation. For example,
 - ▶ **Version:** 23.10-1.1.9.0-LTS
 - ▶ **OS Distribution:** RHEL/CentOS/Rocky
 - ▶ **OS Distribution Version:** RHEL/Rocky 9.2
 - ▶ **Architecture:** X86_64

MLNX_OFED Download Center

Current Versions Archive Versions START

Version (Current)	OS Distribution	OS Distribution Version	Architecture	Download/Documentation
23.10-0.5.5.0-LTS	Ubuntu	RHEL/Rocky 9.2	x86_64	ISO: MLNX_OFED_LINUX-23.10-0.5.5.0-rhel9.2-x86_64.iso
	UOS	RHEL/Rocky 9.1	aarch64	SHA256: 1a170f90b4af4836240203858aeef1020f73b3097a57579cab5c0f5008f6e5
5.8-3.0.7.0-LTS	SLES	RHEL/Rocky 9.0		Size: 214M
	RHEL/CentOS/Rocky	RHEL/Rocky 8.8		tgz: MLNX_OFED_LINUX-23.10-0.5.5.0-rhel9.2-x86_64.tgz
5.4-3.7.5.0-LTS	Oracle Linux	RHEL/Rocky 8.7		SHA256: 9fe02f896f715ee3432493b8f4e4d48a9f7e6d82cb39bb709be878c7c413c4
4.9-7.1.0.0-LTS	OPENEULER	RHEL/Rocky 8.6		Size: 212M
	KYLIN	RHEL/CentOS/Rocky 8.5		SOURCES: MLNX_OFED_SRC-23.10-0.5.5.0.tgz
	EulerOS	RHEL/CentOS 8.4		SHA256:
	Debian	RHEL/CentOS 8.3		
	Community	RHEL/CentOS 8.2		
	Citrix XenServer Host	RHEL/CentOS 8.1		

- Click the supported ISO or tgz package.

The **Mellanox OFED (MLNX_OFED) Software: End-User Agreement** page appears.

- Accept the End User License Agreement by clicking **I Have Read the Above End User License Agreement**.

The selected software package starts to download.

- Mount the downloaded ISO on the system.

The following example shows the ISO being mounted on the /mnt directory.

```
sudo mount MLNX_OFED_LINUX-<version>.iso /mnt
```

- Prepare to install the driver.

- Remove nvidia-mlnx-config and nvidia-peer-memory-dkms.

```
sudo dnf remove -y nvidia-mlnx-config nvidia-peer-memory-dkms
```

The `mlnxofedinstall` step will remove packages prior to installing new ones, causing `nvidia-mlnx-config` and `nvidia-peer-memory-dkms` to fall out because they depend on some of these removed packages. Removing those components ahead of time avoids issues. These will be reinstalled as a final step.

- Specify the new kernel version to use when installing the driver.

```
NEXTKERNEL=$(sudo grubby --default-kernel | sed 's/.*vmlinuz\-\-//g')
```

- Install the driver with the `-k` and `-s` flags to specify the new kernel version and kernel source path.

```
sudo /mnt/mlnxofedinstall -k ${NEXTKERNEL} -s /lib/modules/${NEXTKERNEL}/build --force
```

Note: Note: The system might report that additional software needs to be installed before performing the installation. If such a message appears, install the software and then repeat this step.

7. Reboot.

```
sudo reboot
```

8. Reinstall nvidia-mlnx-config and nvidia-peer-memory-dkms.

```
sudo dnf install -y nvidia-mlnx-config nvidia-peer-memory-dkms
```

Chapter 8. Installing the ConnectX-7 Firmware

Follow these steps to update firmware for the ConnectX®-7 InfiniBand/Ethernet PCI Express Adapter Cards using the NVIDIA Networking Firmware Downloads Page.

1. Navigate to the [NVIDIA Networking Firmware Downloads](#) page.
2. From the **ConnectX Adapter Cards Firmware** table, select version **ConnectX-7** and click the **InfiniBand/Ethernet** network protocol.

ConnectX Adapter Cards Firmware	
Product Line	Network Protocol
ConnectX-7	InfiniBand/Ethernet
ConnectX-6 DE	InfiniBand
ConnectX-6 Lx	Ethernet
ConnectX-6 Dx	Ethernet

The [Firmware for ConnectX®-7 InfiniBand](#) page opens.

3. At the **ConnectX-7 Firmware Download Center** matrix, choose
 - ▶ The firmware version under **CURRENT VERSIONS** to install, such as 28.39.2048-LTS
You might need to select a version under **ARCHIVE VERSIONS**, for example, 28.39.1002.
 - ▶ The **OPN** number of the ConnectX-7 adapter card
For example, MCX75510AAS-NEA.
4. Click the corresponding **PSID** number, for example, MT_0000000800, to show the firmware information and documentation.

ConnectX-7 Firmware Download Center

CURRENT VERSIONS		ARCHIVE VERSIONS	START OVER
Version (Current)	OPN	PSID	Download/Documentation
28.39.2048-LTS	MCX755206AS-NEA-N	MT_0000000800	ConnectX7IB: fw-ConnectX7-rel-28_39_2048-MCX75510AAS-NEA_Ax-UEFI-14.32.17-FlexBoot-3.7.300_signed MD5SUM: bf4759066164378c5c2f6e3e489491e4 SHA256: d5b9655e0d13da73e56ce8a8e03802a82cc30d750d34d0dbded0fd585bff5fe3 Release Date: 12-Dec-23 Documentation: Release Notes EULA
28.36.2050 - for DGX H100 Systems Only	MCX75510AAS-NEA		
28.35.3502-LTS	MCX75510AAS-HEA		
	MCX755106AS-HEA		
	MCX755106AC-HEA		
	MCX75343AMS-NEAC		
	MCX75343AMC-NEAC		

5. Click the **ConnectX7IB** link to download the firmware BIN file.

6. After downloading the correct ConnectX-7 firmware, proceed with the installation steps.

Alternatively, you can use the following methods to install the ConnectX-7 adapter card firmware:

► Using the `mstflint` tool

If you have installed the MTNIC Driver on your machine, you can update the firmware using the `mstflint` tool as described in the [mstflint FW Burning Tool README](#). You can download the `mstflint` tool from the OpenFabrics site at [mstflint_SW for Linux](#).

► Using the NVIDIA Firmware Tools (MFT)

For details, refer to [Updating Firmware for a Single Network Interface Card \(NIC\)](#).

Chapter 9. Installing with Kickstart

Kickstart provides a method of automating the installation process by providing a file which contains the answers to the questions that would be asked during installation. NVIDIA provides kickstart templates for all supported platforms in the following locations:

- ▶ <https://repo.download.nvidia.com/baseos/el/el-files/9/el9-ks/dgx-h100-ks.cfg>
- ▶ <https://repo.download.nvidia.com/baseos/el/el-files/9/el9-ks/dgx-a100-ks.cfg>
- ▶ <https://repo.download.nvidia.com/baseos/el/el-files/9/el9-ks/dgxstation-a100-ks.cfg>

For more information on using kickstart files with Red Hat 9, refer to the [Starting Kickstart Installations](#) chapter in Red Hat's documentation.

In these files are tags that you must replace with your site specific information: language, keyboard, timezone, hostname, etc.

Each tag is of the form "CHANGE_YOUR_xxxx". These tags **must** be replaced with your specific information.

Once you have a kickstart file customized for your installation, place that file in a location that can be accessed by NFS, FTP, HTTP, or HTTPS.

After booting from the installation medium, when the grub menu appears, press e to edit the grub entry as you normally would to add the "nomodeset" option. In addition to "nomodeset", add an option in the format "inst.ks=<URL>".

For example:

```
inst.ks=https://192.168.1.2/kickstart/dgx-a100-cfg.ks
```

Lastly, after using these kickstart files – remember to reboot the system one final time to apply all settings.

Chapter 10. Configuring Storage

By default, the DGX System includes multiple SSDs in a RAID configuration (4 SSDs in the DGX-1, 8 or 16 SSDs in the DGX-2, and 3 SSDs in the DGX Station). These SSDs are intended for application caching, so NVIDIA recommends that you set up your own NFS storage for long term data storage. The following instructions describe how to mount the NFS onto the DGX System, and how to cache the NFS using the DGX SSDs for improved performance.

Make sure that you have an NFS server with one or more exports with data to be accessed by the DGX System, and that there is network access between the DGX System and the NFS server.

1. Install the NFS packages.

```
$ sudo dnf install nfs-utils
```

2. Configure an NFS mount for the DGX.

- a. Edit the filesystem tables configuration.

```
sudo vi /etc/fstab
```

- b. Add a new line for the NFS mount, using the local mount point of /mnt.

```
<nfs_server>:<export_path> /mnt nfs rw,noatime,rsize=32768,wsz=32768,nolock,  
↪tcp,intr,fsc,nofail 0 0
```

/mnt is used here as an example mount point.

Consult your Network Administrator for the correct values for <nfs_server> and <export_path>.

The nfs arguments presented here are a list of recommended values based on typical use cases. However, “fsc” must always be included as that argument specifies use of FS-Cache.

- c. Save the changes.

3. Verify the NFS server is reachable.

```
ping <nfs_server>
```

Use the server IP address or the server name provided by your network administrator.

4. Mount the NFS export.

```
sudo mount /mnt
```

/mnt is the example mount point used in step 1.

5. Verify caching is enabled.

```
cat /proc/fs/nfsfs/volumes
```

Look for the text FSC=yes in the output. The NFS will be mounted and cached on the DGX System automatically upon subsequent reboot cycles.

Chapter 11. Upgrading

NVIDIA and Red Hat provide updates to the OS in the form of updated software packages between releases with security mitigations and bug fixes.

Important: Before you install or perform the upgrade, refer to the [Release Notes](#) for information about the latest release.

Important: Here is some important information you need to know **before** upgrading:

- ▶ An in-place upgrade from Red Hat Linux 8 to Red Hat Linux 9 with the DGX software stack installed is not supported.
 - ▶ Before you install or perform the upgrade, refer to the section in this release notes for the latest RedHat Linux version.
-

You should evaluate the available updates in regular intervals and update the system by using the `sudo dnf update --nobestcommand`.

For a list of the known Common Vulnerabilities and Exposures (CVEs), including those that can be resolved by updating the OS software, refer to the [Red Hat Security Updates](#)

Note: You are responsible for upgrading the software on the DGX system to install the updates from these sources.

If updates are available, you can obtain the package upgrades by running:

```
sudo dnf update -nobest
```

Upgrades to the NVIDIA Graphics Drivers for Linux requires a restart to complete the kernel upgrade. If you upgrade the NVIDIA Graphics Drivers for Linux without restarting the DGX system, when you run the `nvidia-smi` command, an error message is displayed.

```
nvidia-smi
Failed to initialize NVML: Driver/library version mismatch
```

11.1. Upgrading the OS and DGX Software

This section provides information for upgrading your DGX system and optionally upgrading to a different GPU branch.

11.1.1. Upgrading the Software without Moving to a New Driver Branch

To upgrade your DGX system with the latest Red Hat Linux upgrades, run the following command:

```
sudo dnf update -y --nobest
```

11.1.2. Updating the Software and Moving to a New Driver Branch on non-NVSwitch Systems

This procedure applies to DGX-1, DGX-2, DGX Station, and DGX Station A100 systems.

1. Issue the following to remove the current driver package and install the new driver package.

```
sudo dnf remove -y nv-persistence-mode libnvidia-nscq-<current driver version>
sudo dnf module remove --all -y nvidia-driver
sudo dnf module reset -y nvidia-driver
sudo dnf module install -y nvidia-driver:<new driver version>/{default,src}
sudo dnf install -y nv-persistence-mode libnvidia-nscq-<new driver version>
sudo dnf update -y --nobest
```

1. For DGX Station A100 only - Install additional required DGX Station A100 packages. These packages must be installed after the nvidia-driver module. `sudo dnf install nvidia-conf-xconfig nv-docker-gpus`

```
sudo dnf install nvidia-conf-xconfig nv-docker-gpus
```

2. Reboot the system.

```
sudo reboot
```

11.1.3. Updating the Software and Moving to a New Driver Branch on NVSwitch Systems

This procedure applies to DGX-2, DGX A100, and DGX A800 systems.

1. Run the following commands to remove the current driver package and install the new driver package:

```
sudo dnf remove -y nv-persistence-mode libnvidia-nscq-<current driver version> nvidia-
↪fm-enable
sudo dnf module remove --all -y nvidia-driver
sudo dnf module reset -y nvidia-driver
sudo dnf module install -y nvidia-driver:<new driver version>/{fm,src}
sudo dnf install -y nv-persistence-mode libnvidia-nscq-<new driver version> nvidia-fm-
↪enable
sudo dnf update -y --nobest
```

1. Reboot the system.

```
sudo reboot
```

11.2. Changing only the NVIDIA Driver Branch

To switch driver branches, you must first remove the existing branch before installing the new branch:

1. Remove and clear the existing stream:

```
sudo dnf module remove --all nvidia-driver
sudo dnf module reset nvidia-driver
```

2. Follow the “Install NVIDIA CUDA driver” section to install the new driver branch.
3. If the nvidia-peer-memory-dkms driver is installed it must be reinstalled to match the new driver branch:

```
sudo dnf reinstall -y nvidia-peer-memory-dkms
```

11.3. Installing or Upgrading to a Newer CUDA Toolkit Release

Important: Before you install or upgrade to any CUDA Toolkit release, ensure the release is compatible with the driver that is installed on the system. Refer to [CUDA Compatibility](#) for more information and a compatibility matrix.

Only DGX Station and DGX Station A100 have a CUDA Toolkit release installed by default. DGX servers are intended to be shared resources that use containers and do not have CUDA Toolkit installed by default. However, you have the option to install a qualified CUDA Toolkit release.

Although all CUDA Toolkit releases are supported that interoperate with the installed driver, DGX releases might include a default CUDA Toolkit release that might not be the most recently released version. Unless you must use a new CUDA Toolkit version that contains the new features, we recommend that you remain on the default version that is included in the DGX RHEL9 release. Refer to the [Release Notes](#) for the default CUDA Toolkit release.

11.3.1. Checking the Currently Installed CUDA Toolkit Release

Here is some information about the prerequisite to determine the CUDA Toolkit release that you currently have installed.

Important: The CUDA Toolkit is not installed on DGX servers by default, and if you try to run the following command, no installed package will be listed

Before you install a new CUDA Toolkit release, to check the currently installed release, run the following command:

```
sudo dnf list installed "cuda-toolkit-*
```

The following output shows that CUDA Toolkit 12.0 is installed:

```
Updating Subscription Management repositories.

Installed Packages
cuda-toolkit-12-0.x86_64 12.0.0-1 @CUDA
cuda-toolkit-12-0-config-common.noarch 12.0.107-1 @CUDA
cuda-toolkit-12-config-common.noarch 12.0.107-1 @CUDA
cuda-toolkit-config-common.noarch
```

11.3.2. Determining the New Available CUDA Toolkit Releases

These steps help you determine which new CUDA Toolkit releases are available. To see the new available CUDA Toolkit releases:

```
sudo dnf search "cuda-toolkit-*"
Updating Subscription Management repositories.
Last metadata expiration check: 1:47:39 ago on Wed 18 Jan 2023 08:10:38 AM PST.
===== Name Matched: cuda-toolkit-*
↪=====
cuda-toolkit-11-7.x86_64 : CUDA Toolkit 11.7 meta-package
cuda-toolkit-11-7-config-common.noarch : Common config package for CUDA Toolkit 11.7.
cuda-toolkit-11-8.x86_64 : CUDA Toolkit 11.8 meta-package
cuda-toolkit-11-8-config-common.noarch : Common config package for CUDA Toolkit 11.8.
cuda-toolkit-11-config-common.noarch : Common config package for CUDA Toolkit 11.
cuda-toolkit-12-0.x86_64 : CUDA Toolkit 12.0 meta-package
cuda-toolkit-12-0-config-common.noarch : Common config package for CUDA Toolkit 12.0.
cuda-toolkit-12-config-common.noarch : Common config package for CUDA Toolkit 12.
cuda-toolkit-config-common.noarch : Common config package for CUDA Toolkit.
```

The output shows that 11.7, 11.8, and 12.0 are the possible CUDA Toolkit versions that can be installed.

11.3.3. Installing the CUDA Toolkit or Upgrading Your CUDA Toolkit to a Newer Release

You can install or upgrade your CUDA Toolkit to a newer release.

To install or upgrade the CUDA Toolkit, run the following command:

```
sudo dnf install cuda-toolkit-12-0
```

Note: Version 12.0 is shown as an example - replace the value with the version you wish to install.

11.4. Installing GPUDirect Storage Support

NVIDIA® Magnum IO GPUDirect® Storage (GDS) enables a direct data path for direct memory access (DMA) transfers between GPU memory and storage, which avoids a bounce buffer through the CPU.

11.4.1. Installing nvidia-gds

To use GDS, perform the following steps:

1. Populate the `${NVIDIA_DRV_VERSION}` variable
2. Install `nvidia-gds` with the correct dependencies:

```
sudo install nvidia-gds-{ver} nvidia-dkms-${NVIDIA_DRV_VERSION}-server
```

Use the CUDA Toolkit version number in place of `<ver>`; for example, 12-0

Chapter 12. Managing Self-Encrypting Drives

The NVIDIA DGX OS software supports the ability to manage self-encrypting drives (SEDs), including setting an Authentication Key for locking and unlocking the drives on NVIDIA DGX H100, DGX A100, DGX A800, DGX Station A100, and DGX-2 systems.

You can manage only the SED data drives. The software cannot be used to manage OS drives even if they are SED-capable.

12.1. Overview

The SED management software is in the `nv-disk-encrypt` package.

The software supports the following configurations:

- ▶ NVIDIA DGX H100, DGX A100, DGX A800, DGX Station A100, and DGX-2 systems where all data drives are self-encrypting drives.
- ▶ Only SEDs used as data drives are supported.

The software will not manage SEDs that are OS drives.

The software provides the following functionality:

- ▶ Identifies eligible drives on the system.
- ▶ Allows you to assign Authentication Keys (passwords) for each SED as part of the initialization process.
 - ▶ Alternatively, the software can generate random passwords for each drive.
 - ▶ The passwords are stored in a password-protected vault on the system.
- ▶ Once initialized, SEDs are locked upon power loss, such as a system shutdown or drive removal. Locked drives get unlocked after power is restored and the root file system is mounted.
- ▶ Provides functionality to export the vault.
- ▶ Provides functionality for erasing the drives.
- ▶ Provides the ability to revert the initialization.

12.2. Installing the Software

Use the package manager to install the `nv-disk-encrypt` package and, optionally, the TPM2 tools package, and reboot the system. You need the TPM tools package if you plan to use the TPM2 to store security keys.

1. Update the packages.

```
sudo dnf update
```

2. Install `nv-disk-encrypt`.

```
sudo dnf install -y nv-disk-encrypt
```

3. (Optional) Install the TPM tools package.

- For DGX A100, DGX A800, DGX Station A100, or DGX H100, install the `tpm2-tools` package.

```
sudo dnf install -y tpm2-tools
```

- For DGX-2, install the `tpm-tools` package.

```
sudo dnf install -y tpm-tools
```

4. Reboot.

```
sudo reboot
```

If you plan to use TPM2, enable it. Refer to [Configuring Trusted Computing](#) for more information.

12.3. Configuring Trusted Computing

Here is some information about the controls that are required to configure Trusted Computing (TC).

The DGX H100 system BIOS provides setup controls for configuring the following TC features:

- Trusted Platform Module

The NVIDIA DGX H100, DGX A100, DGX A800, and DGX Station A100 incorporate Trusted Platform Module 2.0 (TPM 2.0). The DGX-2 incorporates a TPM module. These modules can be enabled from the system BIOS and used in conjunction with the `nv-disk-encrypt` tool. After being enabled, the `nv-disk-encrypt` tool uses the TPM for encryption and stores the vault and SED authentication keys on the TPM instead of on the file system. Using the TPM is preferred because this allows the vault data to persist even if the system is reimaged.

- Block SID

Certain drives shipped with the DGX systems support the Block SID authentication feature. Block SID authentication prevents malicious actors from taking ownership of drives and blocks others from using the drives. By default, the DGX BIOS will send the Block SID request. On such setups, you will need to enable the Disable Block Sid feature in the BIOS before proceeding with the initialization steps.

Note: Enabling the “Disable Block SID” option is only valid for one reboot, so if drive encryption needs to be enabled again, then the feature needs to be enabled in BIOS as well.

12.3.1. Determining Whether Drives Support SID

The drive model is a good indicator of whether the drive supports this feature. Issue the following and look for one of the following model strings:

- ▶ KCM6DRUL3T84
- ▶ KCM6DRUL7T68
- ▶ MZQLB7T6HMLA-00007


```
sudo nvme list
```

Node	SN	Model
/dev/nvme0n1	70H0A0AHTTHR	KCM6DRUL3T84 ...
/dev/nvme1n1	70H0A007TTHR	KCM6DRUL3T84


12.3.2. Enabling the TPM and Preventing the BIOS from Sending Block SID Requests

This section provides instructions to enable the TPM and prevent the SBIOS from sending Block SID request. Each task is independent, so you can select which task to complete.


1. Reboot the system, then press [Del] or [F2] at the NVIDIA splash screen to enter the BIOS Setup.
2. Navigate to the Advanced tab on the top menu, then scroll to Trusted Computing and press [Enter].



- To enable TPM, scroll to Security Device and switch the setting to Enabled.




- To disable Block SID, go to the Security tab to the right, and scroll to Disable Block Sid, then switch to Enabled.



3. Save and exit the BIOS Setup to continue the boot process.

If you disabled Block SID, you will be prompted to accept the request to disable issuing a Block SID Authentication command.



4. Press F10 at the prompt. After the system boots, you can proceed to initialize drive encryption.

12.4. Initializing the System for Drive Encryption

Here is some information about how to initialize the system for drive encryption.

Note: Before initializing drive encryption, review the information in [Configuring Trusted Computing](#) and follow the configuration instructions if needed.

Initialize the system for drive encryption using the `nv-disk-encrypt` command.

```
sudo nv-disk-encrypt init [-k <your-vault-password>] [-f <path/to/json-file>] [-g] [-r]
```

Here is a list of the options:

- ▶ **-k:** Lets you create the vault password in the command.
Otherwise, the software will prompt you to create a password before proceeding.
- ▶ **-f:** Lets you specify a JSON file that contains a mapping of passwords to drives.
Refer to “Example 1: Passing in the JSON File” for further instructions.
- ▶ **-g:** Generates random salt values (stored in `/etc/nv-disk-encrypt/.dgxenc.salt`) for each drive password.
Salt values are characters added to a password for enhanced password security. NVIDIA strongly recommends using this option for best security, otherwise the software will use a default salt value instead of a randomly generated one.
- ▶ **-r:** Generates random passwords for each drive.
This avoids the need to create a JSON file or the need to enter a password one by one during the initialization.

12.5. Enabling Drive Locking

After initializing the system for SED management, issue the following command, which uses the `nv-disk-encrypt` command to enable drive locking.

```
sudo nv-disk-encrypt lock
```

After initializing the system and enabling drive locking, the drives will become locked when they lose power. The system will automatically unlock each drive when power is restored to the system and the system is rebooted.

12.6. Initialization Examples

This section provides some initialization examples.

12.6.1. Example 1: Passing in the JSON File

The following instructions in this section describe a method to specify the drive/password mapping ahead of time. This method is useful for initializing several drives at a time and avoids the need to enter the password for each drive after issuing the initialization command, or if you want control of the passwords.

Refer to the following for more information:

- ▶ *Determining Which Drives Can be Managed as Self-Encrypting*
- ▶ *Creating the Drive/Password Mapping JSON Files and Using it to Initialize the System*

12.6.1.1 Determining Which Drives Can be Managed as Self-Encrypting

Here is some information about how you can determine which drives can be managed as self-encrypting.

Review the storage layout of the DGX system to determine which drives are eligible to be managed as SEDs.

```
sudo nv-disk-encrypt info
```

The default output shows which drives can be used for encryption and which drives cannot. The following status information is provided:

- ▶ SED capable: Is this a self-encrypting drive?
- ▶ Boot disk: Is this drive currently being used as a boot drive? Does it contain the root filesystem?
- ▶ Locked: Is this drive currently in the locked state? Is it able to accept I/O?. It can only be in this state after the following conditions have been met:
 - ▶ Locking has been enabled (nv-disk-encrypt init, followed by nv-disk-encrypt init lock)
 - ▶ The drive is coming back from power-off.
 - ▶ The user queries this state prior to it being (automatically) unlocked.
- ▶ Lock Enabled: Are locks enabled on this drive? It will be in this state after initialization (nv-disk-encrypt init).
- ▶ MBR done: This setting is only relevant for drives that support MBR shadowing. On drives that support this feature, this will report 'Y' after initialization (nv-disk-encrypt init)

MBR done: This setting is only relevant for drives that support MBR shadowing. On drives that support this feature, this will report 'Y' after initialization (nv-disk-encrypt init)

The following example output snippet shows drives that can be used for encryption. Notice SED capable = Y and Boot disk = N.

```
+-----+
| .Name | .Serial | .Status |
+-----+
| ./dev/nvme3n1 | .xxxxx1 | .SED.capable = .Y, .Boot.disk = .N, .Locked = .N, .Lock.Enabled = .N, .MBR.done = .N |
| ./dev/nvme6n1 | .xxxxx2 | .SED.capable = .Y, .Boot.disk = .N, .Locked = .N, .Lock.Enabled = .N, .MBR.done = .N |
| ./dev/nvme9n1 | .xxxxx3 | .SED.capable = .Y, .Boot.disk = .N, .Locked = .N, .Lock.Enabled = .N, .MBR.done = .N |
+-----+
```

The following example output snippet shows drives that cannot be used for encryption. Notice SED capable = Y and Boot disk = Y, or SED capable = N.

```
+-----+
| .Name | .Serial | .Status |
+-----+
| ./dev/nvme0n1 | .xxxxx1 | .SED.capable = .Y, .Boot.disk = .Y, .Locked = .N, .Lock.Enabled = .N, .MBR.done = .N |
| ./dev/sr0 | .xxxxx2 | .SED.capable = .N, .Boot.disk = .N, .Locked = .N, .Lock.Enabled = .N, .MBR.done = .N |
| ./dev/nvme1n1 | .xxxxx3 | .SED.capable = .Y, .Boot.disk = .Y, .Locked = .N, .Lock.Enabled = .N, .MBR.done = .N |
| ./dev/sda | .unknown | .SED.capable = .N, .Boot.disk = .N, .Locked = .N, .Lock.Enabled = .N, .MBR.done = .N |
+-----+
```

Alternatively, you can specify the output be presented in JSON format by using the `-j` option.

```
sudo nv-disk-encrypt info -j
```

In this case, drives that can be used for encryption are indicated by the following:

```
"sed_capable": true "used_for_boot": false
```

And drives that cannot be used for encryption are indicated by one of the following:

```
"sed_capable": true "used_for_boot": true
```

Or

```
"sed_capable": false
```

12.6.1.2 Creating the Drive/Password Mapping JSON Files and Using it to Initialize the System

You can initialize the system by creating the drive and password map the JSON files.

1. Create a JSON file that lists all the eligible SED-capable drives that you want to manage.

Note: These are the list of drives that you obtained from *Determining Which Drives Can be Managed as Self-Encrypting*

The following example shows the format of the JSON file.

```
{
  "/dev/nvme2n1": "<your-password>",
  "/dev/nvme3n1": "<your-password>",
  "/dev/nvme4n1": "<your-password>",
  "/dev/nvme5n1": "<your-password>",
}
```

- Ensure that you follow the syntax exactly.
 - Passwords must consist of only upper-case letters, lower-case letters, digits, and/or the following special characters: `~ : @ % ^ + = _`,
2. Initialize the system and then enable locking.

The following command assumes you have placed the JSON file in the `/tmp` directory.

```
sudo nv-disk-encrypt init -f /tmp/<your-file>.json -g
sudo nv-disk-encrypt lock
```

When prompted, enter a password for the vault.

Passwords must consist of only upper-case letters, lower-case letters, digits, and/or the following special characters: ~ : @ % ^ + = _ ,

12.6.2. Example 2: Generating Random Passwords

The commands in this topic use the `-k` and `-r` options so that you are not prompted to enter passwords. You pass the vault password into the command and then the command instructs the tool to generate random passwords for each drive.

The vault password must consist of only upper-case letters, lower-case letters, digits, and/or the following special-characters: ~ : @ % ^ + = _ ,

```
sudo nv-disk-encrypt init -k <your-vault-password> -g -r
sudo nv-disk-encrypt lock
```

12.6.3. Example 3: Specifying Passwords One at a Time When Prompted

If there are a small number of drives, or you do not want to create a JSON file, issue the following command.

```
sudo nv-disk-encrypt init -g
sudo nv-disk-encrypt lock
```

The software prompts you to enter a password for the vault and then a password for each eligible SED.

Passwords must consist of only upper-case letters, lower-case letters, digits, and/or the following special characters: ~ : @ % ^ + = _ ,

12.7. Disabling Drive Locking

To disable drive locking at any time after you initialize, run the following command: `$ sudo nv-disk-encrypt disable`

This command disables locking on all drives. You can run the initial set up again at any time after this process is complete.

12.8. Enabling Drive Locking

After initializing the system for SED management, issue the following command, which uses the `nv-disk-encrypt` command to enable drive locking.

```
sudo nv-disk-encrypt lock
```

After initializing the system and enabling drive locking, the drives will become locked when they lose power. The system will automatically unlock each drive when power is restored to the system and the system is rebooted.

12.9. Exporting the Vault

Here is some information about how to export the vault.

To export all drive keys out to a file, use the `export` function. This requires that you pass in the vault password.

```
sudo nv-disk-encrypt export -k yourvaultpassword  
Writing vault data to /tmp/secrets.out
```

12.10. Erasing Your Data

Here is some information about how you can erase your data.

Warning: Be aware when executing this that **all** data will be lost. On DGX H100 systems, these drives generally form a RAID 0 array, and this array will also be destroyed when you perform an erase.

After initializing the system for SED management, use the `nv-disk-encrypt` command to erase data on your drives after stopping `cachefilesd` and unmounting the RAID array as follows.

1. Completely stop the RAID.

```
systemctl stop cachefilesd  
sudo umount /raid  
sudo mdadm --stop /dev/md1
```

2. Perform the erase.

```
sudo nv-disk-encrypt erase
```

This command does the following:

- ▶ Sets the drives in an unlocked state.
- ▶ Disables locking on the drives.
- ▶ Removes the RAID 0 array configuration.

To rebuild the RAID array, issue the following command:

```
sudo /usr/bin/configure_raid_array.py -c -f
```

12.11. Clearing the TPM

If you've lost the password to your TPM, you will not be able to access its contents. In this case, the only way to regain access to the TPM is to clear the TPM's contents. After clearing the TPM, you will need to re-initialize the vault and SED authentication keys.

1. Reboot the system, then press [Del] or [F2] at the NVIDIA splash screen to enter the BIOS Setup.
2. Navigate to the Advanced tab on the top menu, scroll to Trusted Computing, and press [Enter].
3. Clear TPM2.
 1. Scroll to Trusted Computing and press [Enter].
 2. Scroll to Pending Operation and press [Enter].
 3. Select TPM Clear at the Pending Operation popup and press [Enter].
4. Save and exit the BIOS Setup.

12.12. Changing Disk Passwords, Adding Disks, or Replacing Disks

The same steps are needed for changing or rotating passwords, adding disks, or replacing disks.

1. Disable SED management.

```
sudo nv-disk-encrypt disable
```

2. Add or replace drives as needed and then rebuild the RAID array. Refer to your system's Service Manual for more information.
3. Enable SED management and assign passwords per the instructions in *Initializing the System for Drive Encryption*.

12.13. Recovering From Lost Keys

NVIDIA recommends backing up your keys and storing them in a secure location. If you lost the key used to initialize and lock your drives, you will not be able to unlock the drive again. If this happens, the only way to recover is to perform a factory-reset, which will result in a loss of data.

SED drives come with a PSID printed on the label; this value can only be obtained by physically examining the drive as exemplified in the following image.



Specify the PSID to reset the drive using the following `sedutil-cli` command:

```
sudo sedutil-cli ----yesIreallywanttoERASEALLmydatausingthePSID yourdrivesPSID /dev/  
↪ nvme3n1
```

Chapter 13. Known Issues

This section provides summaries of the issues in the DGX Software for Red Hat Enterprise Linux.

13.1. Reboot Hang after Configuring RAID

Platform

DGX H100 System with EL9-23.08 and RHEL 9.1 or 9.2

Issue

After installing the DGX H100 Configurations group and configuring RAID with the `sudo /usr/bin/configure_raid_array.py -c -f -5` command and rebooting, the system can hang and display console messages like the following example:

```
...  
[ 1944.542085] md: md124 stopped.  
[ 1944.545711] md: md124 stopped.  
...
```

Workaround

Perform a power cycle to reboot the system successfully. The system boots normally on subsequent reboots.

Explanation

Before rebooting, this issue is triggered by a RAID State of active, degraded, recovering that can be displayed by running the `sudo mdadm --detail /dev/mdXXX` command. Replace XXX with the RAID array that you configured with the `configure_raid_array.py` command.

Refer to the following sample output:

```
$ sudo mdadm --detail /dev/md125  
/dev/md125:  
    Version : 1.2
```

(continues on next page)

(continued from previous page)

```

Creation Time : Wed Aug 30 11:39:08 2023
  Raid Level : raid5
  Array Size : 26254240768 (24.45 TiB 26.88 TB)
Used Dev Size : 3750605824 (3.49 TiB 3.84 TB)
  Raid Devices : 8
  Total Devices : 8
  Persistence : Superblock is persistent

Intent Bitmap : Internal

Update Time : Wed Aug 30 11:55:51 2023
  State : active, degraded, recovering
Active Devices : 7
Working Devices : 8
Failed Devices : 0
Spare Devices : 1

Layout : left-symmetric
Chunk Size : 512K

Consistency Policy : bitmap

Rebuild Status : 5% complete

Name : nv-data-array
UUID : 2dbe34c6:70decf1e:c54206a6:e78b9161
Events : 204

Number   Major   Minor   RaidDevice State
  0       259      1         0      active sync  /dev/nvme2n1
  1       259      3         1      active sync  /dev/nvme3n1
  2       259      6         2      active sync  /dev/nvme4n1
  3       259      7         3      active sync  /dev/nvme5n1
  4       259      9         4      active sync  /dev/nvme6n1
  5       259     13         5      active sync  /dev/nvme7n1
  6       259     14         6      active sync  /dev/nvme8n1
  8       259     15         7      spare rebuilding /dev/nvme9n1

```

13.2. MOFED mlnxofedinstall reports “Current operation system is not supported” using RHEL 9.2

Platform

EL9-23.01 and RHEL 9.2 with MLNX_OFED_LINUX-5.8-2.0.3.0-rhel9.1-x86_64.iso

Issue

When installing MLNX MOFED driver from the downloaded ISO using `mlnxofedinstall --add-kernel-support` the system generates a warning: “Current operation system is not supported!”

Workaround

Specify the last supported version of RHEL on the commandline by adding “--distro rhel9.1” `` `mlnxofedinstall --distro rhel9.1 --add-kernel-support`

Explanation

The current MLNX MOFED installer script can require the most recent supported OS to be specified by name if the OS is upgraded before the installer support is added for that OS version.

13.3. Precompiled GPU Driver 525 package is not available for Rocky 9.1

Platform

Rocky 9.1 with EL9-23.01

Issue

The Pre-compiled GPU Driver might not support the installed Rocky Linux kernel.

Workaround

You can install the GPU driver by using the DKMS subsystem by running the following commands:

```
sudo dnf module reset -y nvidia-driver
sudo dnf install kernel-devel-$(uname -r) kernel-headers-$(uname -r)
sudo dnf module install nvidia-driver:525-dkms
```

13.4. Yellow screen appears during RHEL 9.1 installation

Issue

When installing the RedHat Enterprise Linux 9.1 ISO on a DGX Station V100, the first installation page shows a yellow screen. This can persist through the installation process and when complete.

Workaround

Install RedHat Enterprise Linux 9.0 on the DGX Station V100, then perform the over the air (OTA) update for the latest RHEL9 version and the DGX EL9-23.01 updates.

13.5. DGX A100: VBIOS cannot update due to running service processes

Issue

VBIOS fails to update on Red Hat Enterprise Linux 9 because service(s)/process(es) are holding onto the resource about to be upgraded.

Workaround

The following services (system processes) must be stopped manually for the firmware update to start:

- ▶ process nvidia-persistenced
- ▶ process nv-hostengine
- ▶ process cache_mgr_event
- ▶ process cache_mgr_main
- ▶ process dcgm_ipc

If *xorg* is holding the resources, try to stop it by running

```
sudo systemctl stop (display manager)
```

where the (display manager) can be acquired by

```
cat /etc/X11/default-display-manager
```

13.6. NVSM Unsupported Drive Error

Issue

When running `nvsm show storage`, the NV-DRIVE-01 alert displays an “Unsupported Drive Configuration” message.

Workaround

The following services (system processes) must be stopped manually for the firmware update to start:

1. Create a config file to disable nvme multipath:

```
sudo sh -c 'echo "options nvme-core multipath=n" > /etc/modprobe.d/nvidia-nvme.  
↪conf'
```

2. Recreate the initramfs.

```
dracut --force /boot/initramfs-$(uname -r).img $(uname -r)
```

3. Reboot the system.

```
sudo systemctl reboot
```

The message might be displayed when you log in or when you run the `nvsm show alert` and `nvsm show storage` commands and can be safely ignored. This issue will be fixed in a future release.

13.7. Tuned profiles do not take effect in graphical mode

Issue

DGX tuned profiles might not take effect due to a known Red Hat Enterprise Linux 9 issue. This affects systems that use a graphical target mode.

Workaround

This issue can be fixed by running the following commands:

- Mask the power-profiles-daemon service then tuned is able to start during boot.

```
systemctl mask power-profiles-daemon
```

- Reboot the system

```
reboot
```

Chapter 14. Third-Party License Notices

This NVIDIA product contains third party software that is being made available to you under their respective open source software licenses. Some of those licenses also require specific legal information to be included in the product. This section provides such information.

14.1. Micron msecli

The `msecli` utility is provided under the following terms:

Micron Technology, Inc. Software License Agreement PLEASE READ THIS LICENSE AGREEMENT ("AGREEMENT") FROM MICRON TECHNOLOGY, INC. ("MTI") CAREFULLY: BY INSTALLING, COPYING OR OTHERWISE USING THIS SOFTWARE AND ANY RELATED PRINTED MATERIALS ("SOFTWARE"), YOU ARE ACCEPTING AND AGREEING TO THE TERMS OF THIS AGREEMENT. IF YOU DO NOT AGREE WITH THE TERMS OF THIS AGREEMENT, DO NOT INSTALL THE SOFTWARE. LICENSE: MTI hereby grants to you the following rights: You may use and make one (1) backup copy the Software subject to the terms of this Agreement. You must maintain all copyright notices on all copies of the Software. You agree not to modify, adapt, decompile, reverse engineer, disassemble, or otherwise translate the Software. MTI may make changes to the Software at any time without notice to you. In addition MTI is under no obligation whatsoever to update, maintain, or provide new versions or other support for the Software. OWNERSHIP OF MATERIALS: You acknowledge and agree that the Software is proprietary property of MTI (and/or its licensors) and is protected by United States copyright law and international treaty provisions. Except as expressly provided herein, MTI does not grant any express or implied right to you under any patents, copyrights, trademarks, or trade secret information. You further acknowledge and agree that all right, title, and interest in and to the Software, including associated proprietary rights, are and shall remain with MTI (and/or its licensors). This Agreement does not convey to you an interest in or to the Software, but only a limited right to use and copy the Software in accordance with the terms of this Agreement. The Software is licensed to you and not sold.

DISCLAIMER OF WARRANTY:

THE SOFTWARE IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND. MTI EXPRESSLY DISCLAIMS ALL WARRANTIES EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO, NON-INFRINGEMENT OF THIRD PARTY RIGHTS, AND ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. MTI DOES NOT WARRANT THAT THE SOFTWARE WILL MEET YOUR REQUIREMENTS, OR THAT THE OPERATION OF THE SOFTWARE WILL BE UNINTERRUPTED OR ERROR-FREE. FURTHERMORE, MTI DOES NOT MAKE ANY REPRESENTATIONS REGARDING THE USE OR THE RESULTS OF THE USE OF THE SOFTWARE IN TERMS OF ITS CORRECTNESS, ACCURACY, RELIABILITY, OR OTHERWISE. THE ENTIRE RISK ARISING OUT OF USE OR PERFORMANCE OF THE SOFTWARE REMAINS WITH YOU. IN NO EVENT SHALL MTI, ITS AFFILIATED COMPANIES OR THEIR SUPPLIERS BE LIABLE FOR ANY DIRECT, INDIRECT, CONSEQUENTIAL, INCIDENTAL, OR SPECIAL DAMAGES (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF PROFITS, BUSINESS INTERRUPTION, OR LOSS OF

INFORMATION) ARISING OUT OF YOUR USE OF OR INABILITY TO USE THE SOFTWARE, EVEN IF MTI HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Because some jurisdictions prohibit the exclusion or limitation of liability for consequential or incidental damages, the above limitation may not apply to you.

TERMINATION OF THIS LICENSE: MTI may terminate this license at any time if you are in breach of any of the terms of this Agreement. Upon termination, you will immediately destroy all copies the Software.

GENERAL: This Agreement constitutes the entire agreement between MTI and you regarding the subject matter hereof and supersedes all previous oral or written communications between the parties. This Agreement shall be governed by the laws of the State of Idaho without regard to its conflict of laws rules.

CONTACT: If you have any questions about the terms of this Agreement, please contact MTI's legal department at (208) 368-4500. By proceeding with the installation of the Software, you agree to the terms of this Agreement. You must agree to the terms in order to install and use the Software.

14.2. Mellanox (OFED)

MLNX_OFED <<http://www.mellanox.com/>> is provided under the following terms:

Copyright (c) 2006 Mellanox Technologies. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Chapter 15. Notices

15.1. Notice

This document is provided for information purposes only and shall not be regarded as a warranty of a certain functionality, condition, or quality of a product. NVIDIA Corporation (“NVIDIA”) makes no representations or warranties, expressed or implied, as to the accuracy or completeness of the information contained in this document and assumes no responsibility for any errors contained herein. NVIDIA shall have no liability for the consequences or use of such information or for any infringement of patents or other rights of third parties that may result from its use. This document is not a commitment to develop, release, or deliver any Material (defined below), code, or functionality.

NVIDIA reserves the right to make corrections, modifications, enhancements, improvements, and any other changes to this document, at any time without notice.

Customer should obtain the latest relevant information before placing orders and should verify that such information is current and complete.

NVIDIA products are sold subject to the NVIDIA standard terms and conditions of sale supplied at the time of order acknowledgement, unless otherwise agreed in an individual sales agreement signed by authorized representatives of NVIDIA and customer (“Terms of Sale”). NVIDIA hereby expressly objects to applying any customer general terms and conditions with regards to the purchase of the NVIDIA product referenced in this document. No contractual obligations are formed either directly or indirectly by this document.

NVIDIA products are not designed, authorized, or warranted to be suitable for use in medical, military, aircraft, space, or life support equipment, nor in applications where failure or malfunction of the NVIDIA product can reasonably be expected to result in personal injury, death, or property or environmental damage. NVIDIA accepts no liability for inclusion and/or use of NVIDIA products in such equipment or applications and therefore such inclusion and/or use is at customer’s own risk.

NVIDIA makes no representation or warranty that products based on this document will be suitable for any specified use. Testing of all parameters of each product is not necessarily performed by NVIDIA. It is customer’s sole responsibility to evaluate and determine the applicability of any information contained in this document, ensure the product is suitable and fit for the application planned by customer, and perform the necessary testing for the application in order to avoid a default of the application or the product. Weaknesses in customer’s product designs may affect the quality and reliability of the NVIDIA product and may result in additional or different conditions and/or requirements beyond those contained in this document. NVIDIA accepts no liability related to any default, damage, costs, or problem which may be based on or attributable to: (i) the use of the NVIDIA product in any manner that is contrary to this document or (ii) customer product designs.

No license, either expressed or implied, is granted under any NVIDIA patent right, copyright, or other NVIDIA intellectual property right under this document. Information published by NVIDIA regarding third-party products or services does not constitute a license from NVIDIA to use such products or

services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property rights of the third party, or a license from NVIDIA under the patents or other intellectual property rights of NVIDIA.

Reproduction of information in this document is permissible only if approved in advance by NVIDIA in writing, reproduced without alteration and in full compliance with all applicable export laws and regulations, and accompanied by all associated conditions, limitations, and notices.

THIS DOCUMENT AND ALL NVIDIA DESIGN SPECIFICATIONS, REFERENCE BOARDS, FILES, DRAWINGS, DIAGNOSTICS, LISTS, AND OTHER DOCUMENTS (TOGETHER AND SEPARATELY, "MATERIALS") ARE BEING PROVIDED "AS IS." NVIDIA MAKES NO WARRANTIES, EXPRESSED, IMPLIED, STATUTORY, OR OTHERWISE WITH RESPECT TO THE MATERIALS, AND EXPRESSLY DISCLAIMS ALL IMPLIED WARRANTIES OF NONINFRINGEMENT, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE. TO THE EXTENT NOT PROHIBITED BY LAW, IN NO EVENT WILL NVIDIA BE LIABLE FOR ANY DAMAGES, INCLUDING WITHOUT LIMITATION ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES, HOWEVER CAUSED AND REGARDLESS OF THE THEORY OF LIABILITY, ARISING OUT OF ANY USE OF THIS DOCUMENT, EVEN IF NVIDIA HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Notwithstanding any damages that customer might incur for any reason whatsoever, NVIDIA's aggregate and cumulative liability towards customer for the products described herein shall be limited in accordance with the Terms of Sale for the product.

15.2. Trademarks

NVIDIA, the NVIDIA logo, DGX, DGX-1, DGX-2, DGX A100, DGX A800, DGX H100, DGX Station, and DGX Station A100 are trademarks and/or registered trademarks of NVIDIA Corporation in the United States and other countries. Other company and product names may be trademarks of the respective companies with which they are associated.

Copyright

©2022-2024, NVIDIA Corporation