



NVIDIA DOCA

Installation Guide for Linux

Table of Contents

Chapter 1. Introduction.....	1
1.1. Supported Platforms.....	1
1.1.1. Supported BlueField Devices.....	1
1.1.2. Supported ConnectX Devices.....	8
1.2. Hardware Prerequisites.....	8
1.3. DOCA Packages.....	8
1.4. Supported Operating System Distributions.....	9
Chapter 2. SDK Manager.....	10
Chapter 3. Manual BlueField Image Installation.....	11
3.1. Installation Files.....	11
3.2. Uninstalling Software from Host.....	12
3.3. Installing Prerequisites on Host for Target DPU.....	12
3.4. Determining DPU Device ID.....	13
3.5. Installing Software on Host.....	13
3.6. Installing Software on DPU.....	17
3.6.1. Installing Full DOCA Image on DPU.....	17
3.6.1.1. Option 1 - No Pre-defined Password.....	17
3.6.1.2. Option 2 - Set Pre-defined Password.....	17
3.6.2. Installing Full DOCA Image on Multiple DPUs.....	18
3.6.3. Installing DOCA Local Repo Package on DPU.....	19
3.7. Upgrading Firmware.....	19
3.8. Post-installation Procedure.....	20
Chapter 4. Building Your Own BFB Installation Image.....	21
Chapter 5. Setting Up Build Environment for Developers.....	22
Chapter 6. Additional SDKs for DOCA.....	23
6.1. Installing CUDA on NVIDIA Converged Accelerator.....	23
6.1.1. Configuring Operation Mode.....	23
6.1.2. Downloading and Installing CUDA Toolkit and Driver.....	24
6.1.3. GPUDirect RDMA.....	25
6.2. Installing Rivermax on DPU.....	25
6.2.1. Downloading Rivermax Driver.....	26
6.2.2. Installing Rivermax Driver.....	26
6.2.3. Installing Rivermax Libraries from DOCA.....	26

Chapter 1. Introduction

There are two ways to install the NVIDIA® BlueField® DPU software:

- ▶ Using the [SDK Manager](#) which provides a GUI/CLI for full DPU software installation
- ▶ [Manual installation](#) with a step-by-step procedure

1.1. Supported Platforms

DOCA is supported on the devices listed in the following subsections.

1.1.1. Supported BlueField Devices

NVIDIA SKU	Legacy OPN	PSID	Description
900-9D3B6-00CV-AA0	N/A	MT_0000000884	BlueField-3 B3220 P-Series FHHL DPU; 200GbE (default mode) / NDR200 IB; Dual-port QSFP112; PCIe Gen5.0 x16 with x16 PCIe extension option; 16 Arm cores; 32GB on-board DDR; integrated BMC; Crypto Enabled
900-9D3B6-00SV-AA0	N/A	MT_0000000965	BlueField-3 B3220 P-Series FHHL DPU; 200GbE (default mode) / NDR200 IB; Dual-port QSFP112; PCIe Gen5.0 x16 with x16 PCIe extension option; 16 Arm cores; 32GB on-board DDR; integrated BMC; Crypto Disabled
900-9D3B6-00CC-AA0	N/A	MT_0000001024	BlueField-3 B3210 P-Series FHHL DPU; 100GbE (default

NVIDIA SKU	Legacy OPN	PSID	Description
900-9D3B6-00SC-AA0	N/A	MT_0000001025	mode) / HDR100 IB; Dual-port QSFP112; PCIe Gen5.0 x16 with x16 PCIe extension option; 16 Arm cores; 32GB on-board DDR; integrated BMC; Crypto Enabled
900-9D219-0086-ST1	MBF2M516A-CECOT	MT_0000000375	BlueField-3 B3210 P-Series FHHL DPU; 100GbE (default mode) / HDR100 IB; Dual-port QSFP112; PCIe Gen5.0 x16 with x16 PCIe extension option; 16 Arm cores; 32GB on-board DDR; integrated BMC; Crypto Disabled
900-9D219-0086-ST0	MBF2M516A-EECOT	MT_0000000376	BlueField-2 E-Series DPU 100GbE Dual- Port QSFP56; PCIe Gen4 x16; Crypto and Secure Boot Enabled; 16GB on- board DDR; 1GbE OOB management; FHHL
900-9D219-0056-ST1	MBF2M516A-EENOT	MT_0000000377	BlueField-2 E-Series DPU 100GbE/EDR/ HDR100 VPI Dual- Port QSFP56; PCIe Gen4 x16; Crypto and Secure Boot Enabled; 16GB on- board DDR; 1GbE OOB management; FHHL
900-9D206-0053-SQ0	MBF2H332A-AENOT	MT_0000000539	BlueField-2 E-Series DPU 100GbE/EDR/ HDR100 VPI Dual- Port QSFP56; PCIe Gen4 x16; Crypto Disabled; 16GB on- board DDR; 1GbE OOB management; FHHL BlueField-2 P-Series DPU 25GbE Dual-Port SFP56; PCIe Gen4 x8; Crypto Disabled; 16GB on-board DDR; 1GbE

NVIDIA SKU	Legacy OPN	PSID	Description
900-9D206-0063-ST2	MBF2H332A-AEEOT	MT_0000000540	OOB management; HHHH BlueField-2 P-Series DPU 25GbE Dual-Port SFP56; PCIe Gen4 x8; Crypto Enabled; 16GB on-board DDR; 1GbE OOB management; HHHH
900-9D206-0083-ST3	MBF2H332A-AECOT	MT_0000000541	BlueField-2 P-Series DPU 25GbE Dual-Port SFP56; PCIe Gen4 x8; Crypto and Secure Boot Enabled; 16GB on-board DDR; 1GbE OOB management; HHHH
900-9D206-0083-ST1	MBF2H322A-AECOT	MT_0000000542	BlueField-2 P-Series DPU 25GbE Dual-Port SFP56; PCIe Gen4 x8; Crypto and Secure Boot Enabled; 8GB on-board DDR; 1GbE OOB management; HHHH
900-9D206-0063-ST1	MBF2H322A-AEEOT	MT_0000000543	BlueField-2 P-Series DPU 25GbE Dual-Port SFP56; PCIe Gen4 x8; Crypto Enabled; 8GB on-board DDR; 1GbE OOB management; HHHH
900-9D219-0066-ST0	MBF2M516A-EEEOT	MT_0000000559	BlueField-2 E-Series DPU 100GbE/EDR/HDR100 VPI Dual-Port QSFP56; PCIe Gen4 x16; Crypto Enabled; 16GB on-board DDR; 1GbE OOB management; FHHL
900-9D219-0056-SN1	MBF2M516A-CENOT	MT_0000000560	BlueField-2 E-Series DPU 100GbE Dual-Port QSFP56; PCIe Gen4 x16; Crypto Disabled; 16GB on-board DDR; 1GbE OOB management; FHHL
900-9D219-0066-ST2	MBF2M516A-CEEOT	MT_0000000561	BlueField-2 E-Series DPU 100GbE Dual-Port QSFP56; PCIe Gen4 x16; Crypto

NVIDIA SKU	Legacy OPN	PSID	Description
900-9D219-0006-ST0	MBF2H516A-CEEOT	MT_0000000702	Enabled; 16GB on-board DDR; 1GbE OOB management; FHHL BlueField-2 DPU 100GbE Dual-Port QSFP56; PCIe Gen4 x16; Crypto; 16GB on-board DDR; 1GbE OOB management; FHHL
900-9D219-0056-ST2	MBF2H516A-CENOT	MT_0000000703	BlueField-2 DPU 100GbE Dual-Port QSFP56; PCIe Gen4 x16; Crypto Disabled; 16GB on-board DDR; 1GbE OOB management; FHHL
900-9D219-0066-ST3	MBF2H516A-EEEOT	MT_0000000704	BlueField-2 DPU 100GbE/EDR/HDR100 VPI Dual-Port QSFP56; PCIe Gen4 x16; Crypto Enabled; 16GB on-board DDR; 1GbE OOB management; FHHL
900-9D219-0056-SQ0	MBF2H516A-EENOT	MT_0000000705	BlueField-2 DPU 100GbE/EDR/HDR100 VPI Dual-Port QSFP56; PCIe Gen4 x16; Crypto Disabled; 16GB on-board DDR; 1GbE OOB management; FHHL
900-9D250-0038-ST1	MBF2M345A-HESOT	MT_0000000715	BlueField-2 E-Series DPU; 200GbE/HDR single-port QSFP56; PCIe Gen4 x16; Secure Boot Enabled; Crypto Disabled; 16GB on-board DDR; 1GbE OOB management; HHHL
900-9D250-0048-ST1	MBF2M345A-HECOT	MT_0000000716	BlueField-2 E-Series DPU; 200GbE/HDR single-port QSFP56; PCIe Gen4 x16; Secure Boot Enabled; Crypto Enabled; 16GB on-board DDR; 1GbE OOB management; HHHL
900-9D218-0073-ST1	MBF2H512C-AESOT	MT_0000000723	BlueField-2 P-Series DPU 25GbE Dual-Port SFP56; integrated BMC; PCIe Gen4 x8;

NVIDIA SKU	Legacy OPN	PSID	Description
900-9D218-0083-ST2	MBF2H512C-AECOT	MT_0000000724	Secure Boot Enabled; Crypto Disabled; 16GB on-board DDR; 1GbE OOB management; FHHL BlueField-2 P-Series DPU 25GbE Dual-Port SFP56; integrated BMC; PCIe Gen4 x8; Secure Boot Enabled; Crypto Enabled; 16GB on-board DDR; 1GbE OOB management; FHHL
900-9D208-0086-ST4	MBF2M516C-EECOT	MT_0000000728	BlueField-2 E-Series DPU 100GbE/EDR/HDR100 VPI Dual-Port QSFP56; integrated BMC; PCIe Gen4 x16; Secure Boot Enabled; Crypto Enabled; 16GB on-board DDR; 1GbE OOB management; Tall Bracket; FHHL
900-9D208-0086-SQ0	MBF2H516C-CECOT	MT_0000000729	BlueField-2 P-Series DPU 100GbE Dual-Port QSFP56; integrated BMC; PCIe Gen4 x16; Secure Boot Enabled; Crypto Enabled; 16GB on-board DDR; 1GbE OOB management; Tall Bracket; FHHL
900-9D208-0076-ST5	MBF2M516C-CESOT	MT_0000000731	BlueField-2 E-Series DPU 100GbE Dual-Port QSFP56; integrated BMC; PCIe Gen4 x16; Secure Boot Enabled; Crypto Disabled; 16GB on-board DDR; 1GbE OOB management; Tall Bracket; FHHL
900-9D208-0076-ST6	MBF2M516C-EESOT	MT_0000000732	BlueField-2 E-Series DPU 100GbE/EDR/HDR100 VPI Dual-Port QSFP56; integrated BMC; PCIe Gen4 x16; Secure Boot Enabled;

NVIDIA SKU	Legacy OPN	PSID	Description
900-9D208-0086-ST3	MBF2M516C-CECOT	MT_0000000733	Crypto Disabled; 16GB on-board DDR; 1GbE OOB management; Tall Bracket; FHHL BlueField-2 E-Series DPU 100GbE Dual-Port QSFP56; integrated BMC; PCIe Gen4 x16; Secure Boot Enabled; Crypto Enabled; 16GB on-board DDR; 1GbE OOB management; Tall Bracket; FHHL
900-9D208-0076-ST2	MBF2H516C-EESOT	MT_0000000737	BlueField-2 P-Series DPU 100GbE/EDR/HDR100 VPI Dual-Port QSFP56; integrated BMC; PCIe Gen4 x16; Secure Boot Enabled; Crypto Disabled; 16GB on-board DDR; 1GbE OOB management; Tall Bracket; FHHL
900-9D208-0076-ST1	MBF2H516C-CESOT	MT_0000000738	BlueField-2 P-Series DPU 100GbE Dual-Port QSFP56; integrated BMC; PCIe Gen4 x16; Secure Boot Enabled; Crypto Disabled; 16GB on-board DDR; 1GbE OOB management; Tall Bracket; FHHL
900-9D218-0083-ST4	MBF2H532C-AECOT	MT_0000000765	BlueField-2 P-Series DPU 25GbE Dual-Port SFP56; integrated BMC; PCIe Gen4 x8; Secure Boot Enabled; Crypto Enabled; 32GB on-board DDR; 1GbE OOB management; FHHL
900-9D218-0073-ST0	MBF2H532C-AESOT	MT_0000000766	BlueField-2 P-Series DPU 25GbE Dual-Port SFP56; integrated BMC; PCIe Gen4 x8; Secure Boot Enabled; Crypto Disabled; 32GB on-board DDR; 1GbE

NVIDIA SKU	Legacy OPN	PSID	Description
900-9D208-0076-ST3	MBF2H536C-CESOT	MT_0000000767	OOB management; FHHL BlueField-2 P-Series DPU 100GbE Dual-Port QSFP56; integrated BMC; PCIe Gen4 x16; Secure Boot Enabled; Crypto Disabled; 32GB on-board DDR; 1GbE OOB management; FHHL
900-9D208-0086-ST2	MBF2H536C-CECOT	MT_0000000768	BlueField-2 P-Series DPU 100GbE Dual-Port QSFP56; integrated BMC; PCIe Gen4 x16; Secure Boot Enabled; Crypto Enabled; 32GB on-board DDR; 1GbE OOB management; FHHL
900-9D218-0073-ST4	MBF2H512C-AEUOT	MT_0000000972	BlueField-2 P-Series DPU 25GbE Dual-Port SFP56; integrated BMC; PCIe Gen4 x8; Secure Boot Enabled with UEFI disabled; Crypto Disabled; 16GB on-board DDR; 1GbE OOB management
900-9D208-0076-STA	MBF2H516C-CEUOT	MT_0000000973	BlueField-2 P-Series DPU 100GbE Dual-Port QSFP56; integrated BMC; PCIe Gen4 x16; Secure Boot Enabled with UEFI disabled; Crypto Disabled; 16GB on-board DDR; 1GbE OOB management
900-9D208-0076-STB	MBF2H536C-CEUOT	MT_0000001008	BlueField-2 P-Series DPU 100GbE Dual-Port QSFP56, integrated BMC, PCIe Gen4 x16, Secure Boot Enabled with UEFI Disabled, Crypto Disabled, 32GB on-board DDR, 1GbE OOB management, Tall Bracket, FHHL

NVIDIA SKU	Legacy OPN	PSID	Description
P1004/699-21004-0230N/A		NVD0000000015	BlueField-2 A30X, P1004 SKU 205, Generic, GA100, 24GB HBM2e, PCIe passive Dual Slot 230W GEN4, DPU Crypto ON W/ Bkt, 1 Dongle, Black, HF, VCPD
P4028/699140280000	N/A	NVD0000000020	ZAM / NAS

1.1.2. Supported ConnectX Devices

The following NVIDIA® ConnectX® devices are supported with DOCA for host:

- ▶ [ConnectX-7 devices](#)
- ▶ [ConnectX-6 Dx devices](#)
- ▶ [ConnectX-6 Lx devices](#)
- ▶ [ConenctX-6 device](#)

1.2. Hardware Prerequisites

This quick start guide assumes that an NVIDIA® BlueField® DPU has been installed in a server according to the instructions detailed in your [DPU's hardware user guide](#).

1.3. DOCA Packages

Device	Component	Version	Description
Host	DOCA SDK	2.0.2	Software development kit package for developing host software
	DOCA Runtime	2.0.2	Runtime libraries required to run DOCA-based software applications on host
	DOCA Tools	2.0.2	Tools for developers and administrators on host
	Arm emulated (QEMU) development container	4.0.3	Linux-based BlueField Arm emulated container for developers

Device	Component	Version	Description
Target BlueField DPU (Arm)	BlueField BSP	4.0.3	BlueField image and firmware
	DOCA SDK	2.0.2	Software development kit packages for developing Arm software
	DOCA Runtime	2.0.2	Runtime libraries required to run DOCA-based software applications on Arm
	DOCA Tools	2.0.2	Tools for developers and administrators for Arm target

1.4. Supported Operating System Distributions

The default operating system of the BlueField DPU (Arm) is Ubuntu 22.04.

The supported operating systems on the host machine are the following:



Note: Only the following generic kernel versions are supported for DOCA local repo package for host installation (whether by SDKM or manually).

Host Operation System	Kernel Support	Arch Support
CentOS 7.6	4.14.0-115.el7a.aarch64	aarch64
	3.10.0-957.el7.x86_64	x86
CentOS 8.0	4.18.0-80.el8.x86_64	
CentOS 8.2	4.18.0-193.el8.x86_64	
RHEL 7.6	3.10.0-957.el7.x86_64	
RHEL 8.0	4.18.0-80.el8.x86_64	
RHEL 8.2	4.18.0-193.el8.x86_64	
Rocky 8.6	4.18.0-372.41.1.el8.x86_64	
Ubuntu 18.04	4.15.0-20-generic	
Ubuntu 20.04	5.4.0-26-generic	
Ubuntu 22.04	5.15.0-52-generic	
Debian 10.8	4.19.0-14-amd64	
Windows	DOCA support for Windows is on DOCA's future roadmap. For Windows driver support, refer to WinOF-2 Release Notes .	

Chapter 2. SDK Manager

[NVIDIA SDK Manager](#) (SDKM) supports DOCA installation, including software packages on the host and the BlueField target. The SDKM automates the process of DOCA installation and other related configuration of the system.

- ▶ To use the SDK Manager CLI (recommended), please refer to [NVIDIA SDK Manager CLI installation guide for DOCA](#) for detailed instructions.
- ▶ To use the SDK Manager GUI, please refer to [NVIDIA SDK Manager GUI installation guide for DOCA](#) for detailed instructions.



Note: If installing DOCA using SDKM, please skip the remaining sections and follow the wizard instead.



Note: SDKM installation requires Internet connection through out-of-band (OOB) port.

The following example uses the SDKM CLI to install DOCA without any [additional SDKs](#):

```
host# sdkmanager --cli install --logintype devzone --product DOCA --version 2.0.2 --targetos Linux --host --target BLUEFIELD2_DPU_TARGETS --flash all
```

Chapter 3. Manual BlueField Image Installation

This guide provides the minimal first-step instructions for setting up DOCA on a standard system.

3.1. Installation Files

Device	Component	OS and Arch	Link
Host	These files contain the following components suitable for their respective OS version. <ul style="list-style-type: none"> ▶ DOCA SDK v2.0.2 ▶ DOCA Runtime v2.0.2 ▶ DOCA Tools v2.0.2 	CentOS/RHEL 7.6 on aarch64	doca-host-repo-rhel76-2.0.2-0.0.7.2.0.2027.1.el7a.23.04
		CentOS/RHEL 7.6 on x86	doca-host-repo-rhel76-2.0.2-0.0.7.2.0.2027.1.el7.23.04
		CentOS/RHEL 8.0 on x86	doca-host-repo-rhel80-2.0.2-0.0.7.2.0.2027.1.el8.23.04
		CentOS/RHEL 8.2 on x86	doca-host-repo-rhel82-2.0.2-0.0.7.2.0.2027.1.el8.23.04
		Rocky/RHEL 8.6 on x86	doca-host-repo-rhel86-2.0.2-0.0.7.2.0.2027.1.el8.23.04
		Ubuntu 18.04 on x86	doca-host-repo-ubuntu1804_2.0.2-0.0.7.2.0.2027.1.23.0
		Ubuntu 20.04 on x86	doca-host-repo-ubuntu2004_2.0.2-0.0.7.2.0.2027.1.23.0
		Ubuntu 22.04 on x86	doca-host-repo-ubuntu2204_2.0.2-0.0.7.2.0.2027.1.23.0
	Debian 10.8 on x86	doca-host-repo-debian108_2.0.2-0.0.7.2.0.2027.1.23.04	
	Arm Emulated Development Container	Arm container v4.0.3 on aarch64	doca_devel_ubuntu_22.04-inbox-5.5.tar
Target BlueField DPU (Arm)	BlueField Software v4.0.3	Ubuntu 22.04 on aarch64	doca_2.0.2_bsp_4.0.3_ubuntu_22.04-10
	DOCA SDK v2.0.2	Ubuntu 22.04 on aarch64	doca-dpu-repo-ubuntu2204-local_2.0.2027-1.23.04.0.5.3.0.bf.4.0.3.1
	DOCA Runtime v2.0.2		

Device	Component	OS and Arch	Link
	DOCA Tools v2.0.2		

3.2. Uninstalling Software from Host

If an older DOCA software version is installed on your host, make sure to uninstall it before proceeding with the installation of the new version:

- ▶ For Ubuntu/Debian:

```
host# for f in $( dpkg --get-selections | grep doca | awk '{print $2}' ); do echo $f ; apt
remove --purge $f -y ; done
host# sudo apt-get autoremove
```

- ▶ For CentOS/RHEL/Rocky:

```
host# for f in $(rpm -qa |grep -i doca ) ; do yum -y remove $f; done
host# yum autoremove
host# yum makecache
```

3.3. Installing Prerequisites on Host for Target DPU

Install `doca-tools` to manage and flash the BlueField DPU.

- ▶ For Ubuntu/Debian

1. Download the DOCA Tools host package from the [Installation Files](#) section.
2. Unpack the deb repo. Run:

```
host# sudo dpkg -i doca-host-repo-ubuntu<version>_amd64.deb
```
3. Perform apt update. Run:

```
host# sudo apt-get update
```
4. Run `apt install` for DOCA Tools.

- ▶ For DPU:

```
host# sudo apt install doca-tools
```

- ▶ For ConnectX on Ubuntu 20.04:

```
host# sudo apt install doca-cx-tools
```

- ▶ For CentOS/RHEL 8.x or Rocky 8.6

1. Download the DOCA Tools host package from the [Installation Files](#) section.
2. Unpack the RPM repo. Run:

```
host# sudo rpm -Uvh doca-host-repo-rhel<version>_x86_64.rpm
```
3. Enable new dnf repos. Run:

```
host# sudo dnf makecache
```
4. Run `dnf install` to install DOCA Tools.

- ▶ For DPU:

```
host# sudo dnf install doca-tools
```

- ▶ For ConnectX:

```
host# sudo dnf install doca-cx-tools
```

- ▶ For CentOS/RHEL 7.x

1. Download the DOCA Tools host package from the [Installation Files](#) section.

2. Unpack the RPM repo. Run:

```
host# sudo rpm -Uvh doca-host-repo-rhel<version>.x86_64.rpm
```

3. Enable new yum repos. Run:

```
host# sudo yum makecache
```

4. Run `yum install` to install DOCA Tools.

- ▶ For DPU:

```
host# sudo yum install doca-tools
```

- ▶ For ConnectX:

```
host# sudo yum install doca-cx-tools
```

3.4. Determining DPU Device ID

It is important to learn your DPU's `device-id` for performing some of the software installations or upgrades in this guide.

To determine the device ID of the DPUs on your setup, run:

```
mst start
mst status -v
```

Example output:

```
MST modules:
```

```
-----
MST PCI module is not loaded
MST PCI configuration module loaded
```

```
PCI devices:
```

```
-----
DEVICE_TYPE          MST          PCI          RDMA          NET
                     NUMA
BlueField2(rev:1)    /dev/mst/mt41686_pciconf0.1  3b:00.1  mlx5_1  net-
ens1f1               0
BlueField2(rev:1)    /dev/mst/mt41686_pciconf0    3b:00.0  mlx5_0  net-
ens1f0               0
BlueField3(rev:1)    /dev/mst/mt41692_pciconf0.1  e2:00.1  mlx5_1  net-
ens7f1np1           4
BlueField3(rev:1)    /dev/mst/mt41692_pciconf0    e2:00.0  mlx5_0  net-
ens7f0np0           4
```

The device IDs for the BlueField-2 and BlueField-3 DPUs in this example are `/dev/mst/mt41686_pciconf0` and `/dev/mst/mt41692_pciconf0` respectively.

3.5. Installing Software on Host

1. Make sure to follow the instructions under [Installing Prerequisites on Host for Target DPU](#).

2. Install DOCA local repo package for host:

For Ubuntu/Debian Host

a). Run `apt install` for DOCA runtime, tools, and SDK.

► For DPU:

```
host# sudo apt install -y doca-runtime doca-sdk
```

► For ConnectX:

```
host# sudo apt install -y doca-cx-runtime doca-cx-sdk
```

b). Extra package:

```
host# sudo apt install -y doca-extra
```

`doca-extra`, located under `/opt/mellanox/doca/tools/`, contains:

- `doca-info` – displays details of all installed dependencies in DOCA. To execute this helper script, run `sudo /opt/mellanox/doca/tools/doca-info`.
- `doca-kernel-support` – if using a kernel not listed under [Supported Operating System Distributions](#), this tool downloads the appropriate missing packages for your kernel to support DOCA. `doca-kernel-support` does not support customized or unofficial kernels. To execute this helper script, run `sudo /opt/mellanox/doca/tools/doca-kernel-support`.

For CentOS Host

a). Install the following software dependencies. Run:

```
host# sudo yum install -y epel-release
```

b). For CentOS 8.2 only, also run:

```
host# sudo yum config-manager --set-enabled powertools
```

c). Enable new yum repos. Run:

```
host# sudo yum makecache
```

d). Run `yum install` for DOCA runtime, tools, and SDK.

```
host# sudo yum install -y doca-runtime doca-sdk
```

e). Extra package:

```
host# sudo yum install -y doca-extra
```

`doca-extra`, located under `/opt/mellanox/doca/tools/`, contains:

- `doca-info` – displays details of all installed dependencies in DOCA. To execute this helper script, run `sudo /opt/mellanox/doca/tools/doca-info`.
- `doca-kernel-support` – if using a kernel not listed under [Supported Operating System Distributions](#), this tool downloads the appropriate missing packages for your kernel to support DOCA. `doca-kernel-support` does not support customized or unofficial kernels. To execute this helper script, run `sudo /opt/mellanox/doca/tools/doca-kernel-support`.

For Rocky 8.6 Host

a). Install the following software dependencies. Run:

```
host# sudo dnf install -y yum-utils
host# sudo yum-config-manager --enable powertools
```

b). Clean cache. Run:

```
host# sudo dnf clean dbcache
```


c). Run `dnf install` for DOCA SDK, DOCA runtime, DOCA tools.

```
host# sudo dnf install -y doca-runtime doca-sdk doca-tools
```

d). Extra package:

```
host# sudo dnf install -y doca-extra
```

`doca-extra`, located under `/opt/mellanox/doca/tools/`, contains:

- ▶ `doca-info` – displays details of all installed dependencies in DOCA. To execute this helper script, run `sudo /opt/mellanox/doca/tools/doca-info`.
- ▶ `doca-kernel-support` – if using a kernel not listed under [Supported Operating System Distributions](#), this tool downloads the appropriate missing packages for your kernel to support DOCA. `doca-kernel-support` does not support customized or unofficial kernels. To execute this helper script, run `sudo /opt/mellanox/doca/tools/doca-kernel-support`.

For RHEL Host



Note: For RHEL 7.6, only perform step d. from the following procedure.

a). Open a RedHat account.

- i. Log into RedHat website via the [developers tab](#).
- ii. [Create a developer user](#).

b). Run:

```
host# subscription-manager register --username=<username> --password=PASSWORD
```

To extract pool ID:

```
host# subscription-manager list --available --all
...
Subscription Name:   Red Hat Developer Subscription for Individuals
Provides:            Red Hat Developer Tools (for RHEL Server for ARM)
...
                    Red Hat CodeReady Linux Builder for x86_64
...
Pool ID:             <pool-id>
...
```

And use the pool ID for the Subscription Name and Provides that include Red Hat CodeReady Linux Builder for x86_64.

c). Run:

```
host# subscription-manager attach --pool=<pool-id>
host# subscription-manager repos --enable codeready-builder-for-rhel-8-x86_64-rpms
host# sudo yum makecache
```

d). Install the DOCA local repo package for host, enable new yum repos, and install DOCA runtime and SDK. Run:

```
host# sudo yum makecache
host# sudo yum install -y doca-runtime doca-sdk
```

e). Sign out from your RHEL account. Run:

```
host# subscription-manager remove --all
host# subscription-manager unregister
```

f). Extra package:

```
host# sudo yum install -y doca-extra
```

doca-extra, located under `/opt/mellanox/doca/tools/`, contains:

- ▶ `doca-info` – displays details of all installed dependencies in DOCA. To execute this helper script, run `sudo /opt/mellanox/doca/tools/doca-info`.
- ▶ `doca-kernel-support` – if using a kernel not listed under [Supported Operating System Distributions](#), this tool downloads the appropriate missing packages for your kernel to support DOCA. `doca-kernel-support` does not support customized or unofficial kernels. To execute this helper script, run `sudo /opt/mellanox/doca/tools/doca-kernel-support`.

3. Initialize MST. Run:

```
host# sudo mst start
```

4. Reset the `nvconfig` params to their default values:

```
host# sudo mlxconfig -d <device-id> -y reset
```

```
Reset configuration for device <device-id>? (y/n) [n] : y
Applying... Done!
-I- Please reboot machine to load new configurations.
```



Note: To learn the DPU's device ID, refer to [Determining DPU Device ID](#).

5. Skip this step if your BlueField DPU is Ethernet only. Please refer to [Supported Platforms](#) to learn your DPU type.

If you have a VPI DPU, the default link type of the ports will be configured to IB. To verify your link type, run:

```
host# sudo mst start
host# sudo mlxconfig -d <device-id> -e q | grep -i link_type
Configurations:
  Boot
*   LINK_TYPE_P1          Default      Current      Next
  IB(1)
*   LINK_TYPE_P2          IB(1)        ETH(2)
  IB(1)
```



Note: If your DPU is Ethernet capable only, then the `sudo mlxconfig -d <device>` command will not provide an output.

If the current link type is set to IB, run the following command to change it to Ethernet:

```
host# sudo mlxconfig -d <device-id> s LINK_TYPE_P1=2 LINK_TYPE_P2=2
```

6. Verify that RShim is active.

```
host# sudo systemctl status rshim
```

This command is expected to display `active (running)`. If RShim service does not launch automatically, run:

```
host# sudo systemctl enable rshim
host# sudo systemctl start rshim
```

7. Assign a dynamic IP to `tmfifo_net0` interface (RShim host interface).



Note: Skip this step if you are [installing the DOCA image on multiple DPUs](#).

```
host# ifconfig tmfifo_net0 192.168.100.1 netmask 255.255.255.252 up
```

3.6. Installing Software on DPU

Users have two options for installing DOCA on the DPU:

- ▶ Upgrading the full DOCA image on the DPU (recommended) - this option overwrites the entire boot partition.
- ▶ Upgrading DOCA local repo package on the DPU - this option upgrades DOCA components without overwriting the boot partition. Use this option to preserve configurations or files on the DPU itself.

3.6.1. Installing Full DOCA Image on DPU



Important: This step overwrites the entire boot partition.



Note: This installation sets up the OVS bridge.



Note: If you are installing DOCA on multiple DPUs, skip to section [Installing Full DOCA Image on Multiple DPUs](#).

3.6.1.1. Option 1 - No Pre-defined Password



Note: To set the password in advance, proceed to [Option 2](#).

BFB installation is executed as follows:

```
host# sudo bfb-install --rshim <rshimN> --bfb <image_path.bfb>
```

Where `rshimN` is `rshim0` if you only have one DPU. You may run the following command to verify:

```
host# ls -la /dev/ | grep rshim
```

3.6.1.2. Option 2 - Set Pre-defined Password

Ubuntu users can provide a unique password that will be applied at the end of the BlueField software image installation. This password needs to be defined in a `bf.cfg` configuration file.

To set the password for the "ubuntu" user:

1. Create password hash. Run:

```
host# openssl passwd -1
Password:
Verifying - Password:
$1$3B0RIrfX$TlHry93NFUJzg3Nya00rE1
```

2. Add the password hash in quotes to the `bf.cfg` file:

```
host# sudo vim bf.cfg
ubuntu_PASSWORD='$1$3B0RIrfX$TlHry93NFUJzg3Nya00rE1'
```

When running the installation command, use the `--config` flag to provide the file containing the password:

```
host# sudo bfb-install --rshim <rshimN> --bfb <image_path.bfb> --config bf.cfg
```



Note: If `--config` is not used, then upon first login to the BlueField device, users will be asked to update their password.

The following is an example of Ubuntu installation assuming the "pv" Linux tool has been installed (to view the installation progress).

```
host# sudo bfb-install --rshim rshim0 --bfb DOCA_<version>-aarch64.bfb --config
bf.cfg
Pushing bfb
1.08GiB 0:00:57 [19.5MiB/s] [      <=>      ]
Collecting BlueField booting status. Press Ctrl+C to stop..
INFO[BL2]: start
INFO[BL2]: DDR POST passed
INFO[BL2]: UEFI loaded
INFO[BL31]: start
INFO[BL31]: runtime
INFO[UEFI]: eMMC init
INFO[UEFI]: eMMC probed
INFO[UEFI]: PCIe enum start
INFO[UEFI]: PCIe enum end
INFO[MISC]: Ubuntu installation started
INFO[MISC]: Installation finished
INFO[MISC]: Rebooting...
```

3.6.2. Installing Full DOCA Image on Multiple DPUs

On a host with multiple DPUs, the BFB image can be installed on all of them using the `multi-bfb-install` [script](#).

```
host# ./multi-bfb-install --bfb <bfb-file> --password <password>
```

This script detects the number of RShim devices and configures them statically.

- ▶ For Ubuntu – the script creates a configuration file `/etc/netplan/20-tmfifo.yaml`
- ▶ For CentOS/RHEL 7.6 – the script creates a configuration file `/etc/sysconfig/network-scripts/ifcfg-br_tmfifo`
- ▶ For CentOS/RHEL 8.0 and 8.2 – the script installs `bridge-utils` package to use the command `brctl`, creates bridge `tm-br` and connects all RShim interfaces to it

After the installation is complete, the configuration of the bridge and each RShim interface can be observed using `ifconfig`. The expected result is to see the IP on the bridge `tm-br` configured to `192.168.100.1` with subnet `255.255.255.0`.



Note: To log into BlueField with `rshim0`, run:

```
ssh ubuntu@192.168.100.2
```

For each RShim after that, add 1 to the fourth octet of the IP address (e.g., `ubuntu@192.168.100.3` for `rshim1`, `ubuntu@192.168.100.4` for `rshim2`, etc).

The script burns a new MAC address to each DPU and configures a new IP, `192.168.100.x`, as described earlier.

3.6.3. Installing DOCA Local Repo Package on DPU

Note: If you have already [installed BlueField image](#), be aware that the DOCA SDK, Runtime, and Tools are already contained in the BFB, and this installation is not mandatory. If you have not installed the BlueField image and wish to update DOCA Local Repo package, proceed with the following procedure.

Note: Before installing DOCA on the target DPU, make sure the out-of-band interface (mgmt) is connected to the Internet.

1. Download the DOCA SDK, DOCA Runtime, and DOCA Tools package from section [Installation Files](#).

2. Copy deb repo package into BlueField. Run:

```
host# sudo scp -r doca-repo-aarch64-ubuntu2004-local_<version>_arm64.deb
ubuntu@192.168.100.2:/tmp/
```

3. Unpack the deb repo. Run:

```
dpu# sudo dpkg -i doca-dpu-repo-ubuntu2004-local_<version>_arm64.deb
```

4. Run apt update:

```
dpu# sudo apt-get update
```

5. Check for any DOCA package content upgrade. Run:

```
dpu# sudo apt install doca-runtime
dpu# sudo apt install doca-tools
dpu# sudo apt install doca-sdk
```

3.7. Upgrading Firmware

Note: If multiple DPUs are installed, the following steps must be performed on all of them after [BFB installation](#).

To upgrade firmware:

1. SSH to your BlueField device via 192.168.100.2 (preconfigured).

Note: If multiple DPUs are installed, the tmfifo IP interface does not have to be 192.168.100.2. The last octate changes and depends on the RShim number.

The default credentials for Ubuntu are as follows:

- ▶ Username: `ubuntu`
- ▶ Password: `ubuntu` or a unique password that you set in `bf.cfg`

For example:

```
host# ssh ubuntu@192.168.100.2 Password: <configured-password>
```

2. Upgrade firmware in BlueField DPU. Run:

```
dpu# sudo /opt/mellanox/mlnx-fw-updater/mlnx_fw_updater.pl --force-fw-update
```

Example output:

```
Device #1:
```

```
-----
Device Type:      BlueField-2
[...]
Versions:        Current      Available
FW               <Old_FW>    <New_FW>
```

3. Power cycle the host server for the firmware upgrade to take effect.



Note: The entire DPU will experience reset.

3.8. Post-installation Procedure

1. Restart the driver. Run:

```
host# sudo /etc/init.d/openibd restart
Unloading HCA driver:                [ OK ]
Loading HCA driver and Access Layer: [ OK ]
```

2. Configure the physical function (PF) interfaces.

```
host# sudo ifconfig <interface-1> <network-1/mask> up
host# sudo ifconfig <interface-2> <network-2/mask> up
```

For example:

```
host# sudo ifconfig p2p1 192.168.200.32/24 up
host# sudo ifconfig p2p2 192.168.201.32/24 up
```

Pings between the source and destination should now be operational.

Chapter 4. Building Your Own BFB Installation Image

Users wishing to build their own customized BlueField OS image can use the BFB build environment. Please refer to the bfb-build project in [this GitHub webpage](#) for more information.



Note: For a customized BlueField OS image to boot on the UEFI secure-boot-enabled DPU (default DPU secure boot setting), the OS must be either signed with an existing key in the UEFI DB (e.g., the Microsoft key), or UEFI secure boot must be disabled. Please refer to the [Secure Boot](#) section and its subpages of the *NVIDIA BlueField DPU Platform Operating System Documentation* for more details.

Chapter 5. Setting Up Build Environment for Developers

For full instructions about setting up a development environment, refer to the [NVIDIA DOCA Developer Guide](#).

Chapter 6. Additional SDKs for DOCA

6.1. Installing CUDA on NVIDIA Converged Accelerator

NVIDIA® CUDA® is a parallel computing platform and programming model developed by NVIDIA for general computing GPUs.

This section details the necessary steps to set up CUDA on your environment. This section assumes that a BFB image has already been installed on your environment.

To install CUDA on your converged accelerator:

1. Download and install the latest NVIDIA Data Center GPU driver.
2. Download and install CUDA.



Note: The CUDA version tested to work with DOCA SDK is 12.1.



Note: Downloading CUDA includes the latest NVIDIA Data Center GPU driver and CUDA toolkit. For more information about CUDA and driver compatibility please refer to [NVIDIA CUDA Toolkit Release Notes](#).

6.1.1. Configuring Operation Mode

There are two modes that the NVIDIA Converged Accelerator may operate in:

- ▶ Standard mode (default) – the BlueField DPU and the GPU operate separately
- ▶ BlueField-X mode – the GPU is exposed to the DPU and is no longer visible on the host

To verify which mode the system is operating in, run:

```
host# sudo mst start
host# sudo mlxconfig -d <device-id> q PCI_DOWNSTREAM_PORT_OWNER[4]
```



Note: To learn the DPU's device ID, refer to [Determining DPU Device ID](#).

+-----+
 3. Verify that the installation completed successfully.

a). Download CUDA samples repo. Run:

```
dpu# git clone https://github.com/NVIDIA/cuda-samples.git
```

b). Build and run `vectorAdd` CUDA sample. Run:

```
dpu# cd cuda-samples/Samples/0_Introduction/vectorAdd
dpu# make
dpu# ./vectorAdd
```



Note: If the `vectorAdd` sample works as expected, it should output "Test Passed".



Note: If it seems that the GPU is slow or stuck, stop execution and run:

```
dpu# sudo setpci -v -d ::0302 800.L=201 # CPL_VC0 = 32
```

6.1.3. GPUDirect RDMA

To enable CPU map GPU memory feature in DPDK's `gpubdev` library, you need the `gdrCOPY` library and driver to be installed on your system.

1. Install the `gdrCOPY` library. Run:

```
dpu# git clone https://github.com/NVIDIA/gdrCOPY.git
```

2. Install dependencies:

▶ For RHEL/CentOS:

```
# DKMs can be installed from epel-release. See https://fedoraproject.org/wiki/EPEL.
dpu# sudo yum install dkms check check-devel subunit subunit-devel
```

▶ For Ubuntu/Debian:

```
dpu# sudo apt install check libsubunit0 libsubunit-dev
```

3. Build the library and install the driver. Run:

```
dpu# cd gdrCOPY
dpu# make
# Launch gdrdrv kernel module on the system
dpu# ./insmod.sh
```

4. Setup the path to `gdrCOPY`. Run:

```
dpu# export GDRCOPY_PATH_L=/path/to/libgdrapi
```



Note: In general, the path to `libgdrapi` is `/path/to/gdrCOPY/src/`.

6.2. Installing Rivermax on DPU

NVIDIA Rivermax offers a unique IP-based solution for any media and data streaming use case.

This section provides the steps to install Rivermax assuming that a BFB image has already been installed on your environment.

6.2.1. Downloading Rivermax Driver

1. Navigate to the [NVIDIA Rivermax SDK](#) product page.
2. Register to be able to download the driver package using the JOIN button at the top of the page.
3. Download the appropriate driver package according to your BFB under the "Linux" subsection. For example, for Ubuntu 20.04 BFB, download `rivermax_ubuntu2004_<version>.tar.gz`.

6.2.2. Installing Rivermax Driver

1. Copy the `.tgz` file to the DPU:

```
host# sudo scp -r rivermax_ubuntu2004_<version>.tar.gz ubuntu@192.168.100.2:/tmp/
```

2. Extract the Rivermax file:

```
dpu# sudo tar xzf rivermax_ubuntu2004_<version>.tar.gz
```

3. Install the Rivermax driver package:

```
dpu# cd <rivermax-version>/Ubuntu.20.04/deb-dist/aarch64/  
dpu# sudo dpkg -i rivermax_<version>.deb
```

6.2.3. Installing Rivermax Libraries from DOCA

Rivermax libraries are compatibles with DOCA components and can be found inside the `doca-dpu-repo`.

1. Unpack the `doca-dpu-repo`:

```
dpu# sudo dpkg -i doca-dpu-repo-ubuntu2004-local_<version>_arm64.deb
```

2. Run `apt update`:

```
dpu# sudo apt-get update
```

3. Install the Rivermax libraries:

```
dpu# sudo apt install doca-rmax-libs  
dpu# sudo apt install libdoca-rmax-libs-dev
```

For additional details and guidelines, please visit the [NVIDIA Rivermax SDK](#) product page.

Notice

This document is provided for information purposes only and shall not be regarded as a warranty of a certain functionality, condition, or quality of a product. NVIDIA Corporation nor any of its direct or indirect subsidiaries and affiliates (collectively: "NVIDIA") make no representations or warranties, expressed or implied, as to the accuracy or completeness of the information contained in this document and assume no responsibility for any errors contained herein. NVIDIA shall have no liability for the consequences or use of such information or for any infringement of patents or other rights of third parties that may result from its use. This document is not a commitment to develop, release, or deliver any Material (defined below), code, or functionality.

NVIDIA reserves the right to make corrections, modifications, enhancements, improvements, and any other changes to this document, at any time without notice.

Customer should obtain the latest relevant information before placing orders and should verify that such information is current and complete.

NVIDIA products are sold subject to the NVIDIA standard terms and conditions of sale supplied at the time of order acknowledgement, unless otherwise agreed in an individual sales agreement signed by authorized representatives of NVIDIA and customer ("Terms of Sale"). NVIDIA hereby expressly objects to applying any customer general terms and conditions with regards to the purchase of the NVIDIA product referenced in this document. No contractual obligations are formed either directly or indirectly by this document.

NVIDIA products are not designed, authorized, or warranted to be suitable for use in medical, military, aircraft, space, or life support equipment, nor in applications where failure or malfunction of the NVIDIA product can reasonably be expected to result in personal injury, death, or property or environmental damage. NVIDIA accepts no liability for inclusion and/or use of NVIDIA products in such equipment or applications and therefore such inclusion and/or use is at customer's own risk.

NVIDIA makes no representation or warranty that products based on this document will be suitable for any specified use. Testing of all parameters of each product is not necessarily performed by NVIDIA. It is customer's sole responsibility to evaluate and determine the applicability of any information contained in this document, ensure the product is suitable and fit for the application planned by customer, and perform the necessary testing for the application in order to avoid a default of the application or the product. Weaknesses in customer's product designs may affect the quality and reliability of the NVIDIA product and may result in additional or different conditions and/or requirements beyond those contained in this document. NVIDIA accepts no liability related to any default, damage, costs, or problem which may be based on or attributable to: (i) the use of the NVIDIA product in any manner that is contrary to this document or (ii) customer product designs.

No license, either expressed or implied, is granted under any NVIDIA patent right, copyright, or other NVIDIA intellectual property right under this document. Information published by NVIDIA regarding third-party products or services does not constitute a license from NVIDIA to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property rights of the third party, or a license from NVIDIA under the patents or other intellectual property rights of NVIDIA.

Reproduction of information in this document is permissible only if approved in advance by NVIDIA in writing, reproduced without alteration and in full compliance with all applicable export laws and regulations, and accompanied by all associated conditions, limitations, and notices.

THIS DOCUMENT AND ALL NVIDIA DESIGN SPECIFICATIONS, REFERENCE BOARDS, FILES, DRAWINGS, DIAGNOSTICS, LISTS, AND OTHER DOCUMENTS (TOGETHER AND SEPARATELY, "MATERIALS") ARE BEING PROVIDED "AS IS." NVIDIA MAKES NO WARRANTIES, EXPRESSED, IMPLIED, STATUTORY, OR OTHERWISE WITH RESPECT TO THE MATERIALS, AND EXPRESSLY DISCLAIMS ALL IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE. TO THE EXTENT NOT PROHIBITED BY LAW, IN NO EVENT WILL NVIDIA BE LIABLE FOR ANY DAMAGES, INCLUDING WITHOUT LIMITATION ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES, HOWEVER CAUSED AND REGARDLESS OF THE THEORY OF LIABILITY, ARISING OUT OF ANY USE OF THIS DOCUMENT, EVEN IF NVIDIA HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Notwithstanding any damages that customer might incur for any reason whatsoever, NVIDIA's aggregate and cumulative liability towards customer for the products described herein shall be limited in accordance with the Terms of Sale for the product.

Trademarks

NVIDIA, the NVIDIA logo, and Mellanox are trademarks and/or registered trademarks of Mellanox Technologies Ltd. and/or NVIDIA Corporation in the U.S. and in other countries. The registered trademark Linux® is used pursuant to a sublicense from the Linux Foundation, the exclusive licensee of Linus Torvalds, owner of the mark on a world-wide basis. Other company and product names may be trademarks of the respective companies with which they are associated.

Copyright

© 2023 NVIDIA Corporation & affiliates. All rights reserved.