



Getting Started

Table of contents

Configuring the Switch for the First Time

Configuring the Switch with ZTP

Rerunning the Wizard

Starting the Command Line (CLI)

Starting the Web User Interface (WebUI)

Zero-touch Provisioning

Running DHCP-ZTP

ZTP on Modular Switches

ZTP and OS Upgrade

DHCPv4 Configuration Example

DHCPv6 Configuration Example

ZTP Commands

no zero-touch suppress-write

zero-touch abort

show zero-touch

Licenses

Installing OS License via CLI

Installing OS License via Web

Retrieving a Lost License Key

Additional Reading and Use Cases

License Commands

license delete

license install

show licenses

The procedures described in this page assume that you have already installed and powered on your switch according to the instructions in the Hardware Installation Guide, which was shipped with the product.

Configuring the Switch for the First Time

Note

Due to California Senate Bill No. 327, starting from software version 3.8.2000, Admin and Monitor passwords will need to be typed in manually—no automatic passwords will be created by default.

When the reset button is held for 15 seconds, the management module is reset and the password is deleted. You will then be able to enter without a password and make a new password for the user admin.




Note

Any account created with admin privileges can change all passwords of other user accounts, including other user accounts with admin privileges.

To initialize the switch do the following:

1. Connect the host PC to the console (RJ-45) port of the switch system using the supplied cable.

The console ports for systems are shown below.



Note

Make sure to connect to the console RJ-45 port of the switch and not to the MGT port.

Note

DHCP is enabled by default over the MGT port. Therefore, if you have configured your DHCP server and connected an RJ-45 cable to the MGT port, simply log in using the designated IP address.

2. Configure a serial terminal with the settings described below.

(i) Note

Using NVIDIA cables is mandatory.

(i) Note

This step may be skipped if the DHCP option is used and an IP is already configured for the MGT port.

Parameter	Setting
Baud Rate	115200
Data bits	8
Stop bits	1
Parity	None
Flow Control	None

3. The boot menu is prompted.

```
...  
.  
This terminal is not active for input or output while booting.  
  
    Boot Menu  
.  
-----  
-----  
0: <image #1>
```

```
1: <image #2>
```

```
-----  
-----
```

Use the ^ and v keys to select which entry is highlighted.

Press enter to boot the selected image or 'p' to enter a password to unlock the next set of features.

Highlighted entry is 0:

Note

Select “0” to boot with software version installed on partition #1.

Select “1” to boot with software version installed on partition #2.

The boot menu features a countdown timer. It is recommended to allow the timer to run out by not selecting any of the options.

4. Login as admin and use admin as password. If the machine is still initializing, you might not be able to access the CLI until initialization completes. As an indication that initialization is ongoing, a countdown of the number of remaining modules to be configured is displayed in the following format: “<no. of modules> Modules are being configured”.
5. Go through the Switch Management configuration wizard.

IP configuration by DHCP:

Wizard Session Display (Example)	Comments
Do you want to use the wizard for initial configuration? yes	You must perform this configuration the first time you operate the switch or after resetting the switch to the factory

Wizard Session Display (Example)	Comments
	defaults. Type "yes" and then press <Enter>.
Step 1: Hostname? [switch-1]	If you wish to accept the default hostname, then press <Enter>. Otherwise, type a different hostname and press <Enter>.
Step 2: Use DHCP on mgmt0 interface? [yes]	<p>Perform this step to obtain an IP address for the switch. (mgmt0 is the management port of the switch.)</p> <p>- If you wish the DHCP server to assign the IP address, type "yes" and press <Enter>.</p> <p>If you type "no" (no DHCP), then you will be asked whether you wish to use the "zeroconf" configuration or not. If you enter "yes" (yes Zeroconf), the session will continue as shown in the "IP zeroconf configuration" table.</p> <p>If you enter "no" (no Zeroconf), then you need to enter a static IP, and the session will continue as shown in the "Static IP configuration" table.</p>
Step 3: Enable IPv6 [yes]	<p>Perform this step to enable IPv6 on management ports. The default is "yes" (enabled).</p> <p>If you enter "no" (no IPv6), then you will automatically be referred to Step 5.</p>
Step 4: Enable IPv6 autoconfig (SLAAC) on mgmt0 interface? [no]	<p>Perform this step to enable stateless address autoconfig on external management port. The default is "no" (disabled).</p> <p>If you wish to enable it, type "yes" and press <Enter>.</p>
Step 5: Use DHCPv6 on mgmt0 interface? [yes]	Perform this step to enable DHCPv6 on the MGMT0 interface.
Step 6: Update time?	Perform this step to change the time configured. Press <enter> to leave the current time.

Wizard Session Display (Example)	Comments
Step 7: Enable password hardening? [yes]	Perform this step to enable/disable password hardening on your machine. If enabled, new passwords will be checked upon configured restrictions. The default is "yes" (enabled). If you wish to disable it, enter "no".
Step 8: Admin password (Must be typed)? <new_password>	To avoid illegal access to the machine, please type a password and then press <Enter>. Starting from the 3.8.2000 release, the user must type in the admin password upon initial configuration. Due to Senate Bill No. 327, this stage is required and cannot be skipped.
Step 9: Confirm admin password? <new_password>	Confirm the password by re-entering it. Note that password characters are not printed.
Step 10: Monitor password (Must be typed)? <new_password>	To avoid illegal access to the machine, please type a password and then press <Enter>. Starting from the 3.8.2000 release, the user must type in the admin password upon initial configuration. Due to Senate Bill No. 327, this stage is required and cannot be skipped.
Step 11: Confirm monitor password? <new_password>	Confirm the password by re-entering it. Note that password characters are not printed.
You have entered the following information: Hostname: <switch name> Use DHCP on mgmt0 interface: yes Enable IPv6: yes Enable IPv6 autoconfig (SLAAC) on mgmt0 interface: yes Enable DHCPv6 on mgmt0 interface: no Update time: <current time> Enable password hardening: yes Admin password (Enter to leave unchanged): (CHANGED) To change an answer, enter the step number to return to. Otherwise hit <enter> to save changes and exit.	The wizard displays a summary of your choices and then asks you to confirm the choices or to re-edit them. Either press <Enter> to save changes and exit, or enter the configuration step number that you wish to return to. To run the command "configuration jump-start" you must be in Config mode.

Wizard Session Display (Example)	Comments
Choice: <Enter> Configuration changes saved. To return to the wizard from the CLI, enter the "configuration jump-start" command from configuration mode. Launching CLI... <switch name> [standalone: master] >	

IP configuration by DHCP for modular switch systems:

Wizard Session Display (Example)	Comments
Do you want to use the wizard for initial configuration? yes	You must perform this configuration the first time you operate the switch or after resetting the switch to the factory defaults. Type "y" and then press <Enter>.
Step 1: Hostname? [switch-1]	If you wish to accept the default hostname, then press <Enter>. Otherwise, type a different hostname and press <Enter>.
Step 2: Use DHCP on mgmt0 interface? [yes]	Perform this step to obtain an IP address for the switch. (mgmt0 is the management port of the switch.) If you wish the DHCP server to assign the IP address, type "yes" and press <Enter>. If you type "no" (no DHCP), then you will be asked whether you wish to use the "zeroconf" configuration or not. If you enter "yes" (yes Zeroconf), the session will continue as shown in the IP zeroconf configuration table. If you enter "no" (no Zeroconf), then you need to enter a static IP, and the session will continue as shown in the Static IP configuration table.
Step 3: Enable IPv6 [yes]	Perform this step to enable IPv6 on management ports. If you wish to enable IPv6, type "yes" and press <Enter>. If you enter "no" (no IPv6), then you will automatically be referred to Step 5.

Wizard Session Display (Example)	Comments
Step 4: Enable IPv6 autoconfig (SLAAC) on mgmt0 interface	Perform this step to enable StateLess address autoconfig on external management port. If you wish to enable it, type “yes” and press <Enter>. If you wish to disable it, enter “no”.
Step 5: Use DHCPv6 on mgmt0 interface? [yes]	Perform this step to enable DHCPv6 on the MGMT0 interface.
Step 6: Admin password (Press <Enter> to leave unchanged)? <new_password>	To avoid illegal access to the machine, please type a password and then press <Enter>.
Step 7: Confirm admin password? <new_password> (this step only happens if you change the password)	Confirm the password by re-entering it. Note that password characters are not printed.
Step 9: HA Chassis Management IP netmask? (Example: [255.255.255.0])	Perform this step to configure the box IPv4 netmask. If you wish to accept the default value, type “yes” and press <Enter>. Otherwise, enter the desired box IPv4 netmask
Step 10: HA Chassis IPv6 address? (Example: [fdfd:fdfd:7:145::1000:4814])	Perform this step to configure the box IPv6. If you wish to accept the default value, type “yes” and press <Enter>. Otherwise, enter the desired box IPv6
Step 11: HA Chassis Management IPv6 masklen? (Example: [33])	Perform this step to configure the box IPv6 masklen. If you wish to accept the default value, type “yes” and press <Enter>. Otherwise, enter the desired box IPv6 masklen.
You have entered the following information: Hostname: <switch name> Use DHCP on mgmt0 interface: yes Enable IPv6: yes Enable IPv6 autoconfig (SLAAC) on mgmt0 interface: yes Enable DHCPv6 on mgmt0 interface: yes	The wizard displays a summary of your choices and then asks you to confirm the choices or to re-edit them. Either press <Enter> to save changes and exit, or enter the configuration step number that you wish to return to.

Wizard Session Display (Example)	Comments
<p>Admin password (Enter to leave unchanged): (CHANGED) HA Chassis IP address: 10.6.166.200 HA Chassis Management IP netmask: 255.255.255.0 HA Chassis IPv6 address: fdfd:fdfd:7:145::1000:4814 HA Chassis Management IPv6 masklen: 33 To change an answer, enter the step number to return to. Otherwise hit <enter> to save changes and exit. Choice: <Enter> Configuration changes saved. To return to the wizard from the CLI, enter the "configuration jump-start" command from configuration mode. Launching CLI... <switch name> [standalone: master] ></p>	<p>To run the command "configuration jump-start" you must be in Config mode.</p>

Static IP configuration:

Wizard Session Display (Example)
<p>Do you want to use the wizard for initial configuration? y</p> <p>Step 1: Hostname? [switch-112126] Step 2: Use DHCP on mgmt0 interface? [yes] n Step 3: Use zeroconf on mgmt0 interface? [no] Step 4: Primary IP address? 192.168.10.4 Mask length may not be zero if address is not zero (interface mgmt0)</p> <p>Step 5: Netmask? [0.0.0.0] 255.255.255.0 Step 6: Default gateway? 192.168.10.1 Step 7: Primary DNS server? Step 8: Domain name? Step 9: Enable IPv6? [yes] yes Step 10: Enable IPv6 autoconfig (SLAAC) on mgmt0 interface? [no] no Step 11: Update time? [yyy/mm/dd hh:mm:ss] Step 12: Enable password hardening? [yes] yes Step 13: Admin password (Enter to leave unchanged)?</p> <p>You have entered the following information:</p> <p>Hostname: switch-112126 Use DHCP on mgmt0 interface: no Use zeroconf on mgmt0 interface: no Primary IP address: 192.168.10.4 Netmask: 255.255.255.0 Default gateway: 192.168.10.1 Primary DNS server:</p>

Wizard Session Display (Example)

```
Domain name:
Enable IPv6: yes
Enable IPv6 autoconfig (SLAAC) on mgmt0 interface: no
Update time: yyyy/mm/dd hh:mm:ss
Enable password hardening: yes
Admin password (Enter to leave unchanged): (unchanged)

To change an answer, enter the step number to return to.
Otherwise hit <enter> to save changes and exit.

Choice:
Configuration changes saved.
To return to the wizard from the CLI, enter the "configuration jump-start" command from configure
mode. Launching CLI...
<hostname>[standalone: master] >
```

IP zeroconf configuration for modular switch systems:

Wizard Session Display (Example)

```
Configuration wizard

Do you want to use the wizard for initial configuration? y

Step 1: Hostname? [switch-mgmt1]
Step 2: Use DHCP on mgmt0 interface? [yes]
Step 3: Enable IPv6? [yes]
Step 4: Enable IPv6 autoconfig (SLAAC) on mgmt0 interface? [no]
Step 5: Enable DHCPv6 on mgmt0 interface? [yes]
Step 6: Admin password (Enter to leave unchanged)?
Step 7: HA Chassis IP address: [10.6.166.200]
Step 8: HA Chassis Management IP netmask: [255.255.255.0]
Step 9: HA Chassis IPv6 address: [fdfd:fdfd:7:145::1000:4814]
Step 10: HA Chassis Management IPv6 masklen: [33]

You have entered the following information:

1. Hostname: sw-mantaray-201-mgmt1
2. Use DHCP on mgmt0 interface: yes
3. Enable IPv6: yes
4. Enable IPv6 autoconfig (SLAAC) on mgmt0 interface: no
5. Enable DHCPv6 on mgmt0 interface: yes
6. Admin password (Enter to leave unchanged): (unchanged)
7. HA Chassis IP address: 10.6.166.200
8. HA Chassis Management IP netmask: 255.255.255.0
9. HA Chassis IPv6 address: fdfd:fdfd:7:145::1000:4814
10. HA Chassis Management IPv6 masklen: 33
```

Wizard Session Display (Example)

To change an answer, enter the step number to return to.
Otherwise hit <enter> to save changes and exit.

Choice:

Configuration changes saved.

To return to the wizard from the CLI, enter the "configuration jump-start"
command from configure mode. Launching CLI...

<hostname> [standalone: master] >

6. Check the mgmt0 interface configuration before attempting a remote (for example, SSH) connection to the switch. Specifically, verify the existence of an IP address.

```
switch # show interfaces mgmt0
```

```
Interface mgmt0 status:
```

```
Comment          :  
Admin up         : yes  
Link up          : yes  
DHCP running     : yes  
IP address       : 10.12.67.34  
Netmask          : 255.255.0.0  
IPv6 enabled     : yes  
Autoconf enabled: no  
Autoconf route  : yes  
Autoconf privacy: no  
DHCPv6 running  : no  
IPv6 addresses  : 1
```

```
IPv6 address:
```

```
fe80::268a:7ff:fe53:3d8e/64
```

```
Speed            : 1000Mb/s (auto)  
Duplex           : full (auto)  
Interface type   : ethernet  
Interface source: physical  
MTU              : 1500
```

```
HW address      : 00:02:c9:11:a1:b2
```

```
Rx:
```

```
11700449 bytes  
55753 packets  
0 mcast packets  
0 discards  
0 errors  
0 overruns  
0 frame
```

```
Tx:
```

```
5139846 bytes  
28452 packets  
0 discards  
0 errors  
0 overruns  
0 carrier  
0 collisions  
1000 queue len
```

Configuring the Switch with ZTP

Zero-touch Provisioning (ZTP) automates initial configuration of switch systems at boot time. It helps minimize manual operation and reduce customer initial deployment cost.

For more information, please refer to section [“Zero-touch Provisioning”](#).

Rerunning the Wizard

To rerun the wizard:

1. Enter Config mode. Run:

```
switch > enable  
switch # config terminal
```

2. Rerun the wizard. Run:

```
switch (config) # configuration jump-start
```

Starting the Command Line (CLI)

1. Set up an Ethernet connection between the switch and a local network machine using a standard RJ-45 connector.
2. Start a remote secured shell (SSH) to the switch using the command “ssh -l <username> <switch ip address>”.

```
rem_mach1 > ssh -l <username> <ip address>
```

3. Log into the switch (default username is admin, password admin).
4. Read and accept the EULA when prompted.
5. Once the following prompt appears, the system is ready to use.

```
NVIDIA MLNX-OS Switch Management  
  
Password:  
Last login: <time> from <ip-address>  
  
NVIDIA Switch
```


Please read and accept the End User License Agreement located at:
<https://docs.nvidia.com/networking/display/switchxmlnoseula>
[switch](#) >

Starting the Web User Interface (WebUI)

To start a WebUI connection to the switch platform, follow the steps below:

Note

WebUI access is enabled by default. To disable web access, run the command “no web http enable” or “no web https enable” on the CLI.

1. Set up an Ethernet connection between the switch and a local network machine using a standard RJ-45 connector.
2. Open a web browser that is Firefox, Chrome, Internet Explorer, or Safari.

Note

Make sure the screen resolution is set to 1024*768 or higher.

Note

In order to access WebUI through Sarafi 5.3, enable http:

```
no web https ssl secure-cookie enable
```


```
web http enable
```

3. Type the IP address of the switch or its DNS name in the following format:
https://<switch_IP_address>.
4. Log into the switch (default user name is admin, password admin).



5. Read and accept the EULA, if prompted.


The prompt will only occur if the switch has never been accessed through the CLI before.




6. The Welcome popup appears. After reading through the content, click OK to continue.

To reach the OS documentation, click on the links under the Documentation heading.

The link under What's New takes leads to the Changes and New Features section of the switch OS Release Notes. You may also tick the box to not show this popup again. To see this window again, click "Product Documents" on the upper right corner of the WebUI.



7. A default status summary is displayed.



The screenshot displays the NVIDIA MLNX-OS Management console interface. At the top, the NVIDIA logo is on the left, and the text 'NVIDIA MLNX-OS Management console' is on the right, along with 'Host: [redacted] User: admin Logout'. Below this is a navigation bar with icons for Setup, System, Security, Ports, Status (highlighted), Fabric, ETS, IP, and Router. The main content area is titled 'Summary' and features a sidebar with a list of menu items: Summary, Profile and Capabilities, Temperature, Power Supplies, Fans, CPU Utilization, Memory, Network, Logs, Maintenance, Alerts, and Virtualization. The 'Summary' section contains the following data:

Date and Time:	2021/07/25 12:11:51
Hostname:	[redacted]
Uptime:	45m 56s
Software Version:	[redacted]
Model:	x86
Host ID:	[redacted]
System memory:	557 MB used / 3206 MB free / 3763 MB total
CPU load averages:	0.72 / 0.24 / 0.14
System UUID:	[redacted]

To the right of the summary is an 'Active alerts' section with a box containing the text 'No alerts'.

Zero-touch Provisioning

Zero-Touch Provisioning (ZTP) automates initial configuration of switch systems at boot time. It helps minimize manual operation and reduce customer initial deployment cost. ZTP allows for automatic upgrade of the switch with a specified OS image, setting up initial configuration database, and to load and run a container image file.

The initial configuration is applied using a regular text file. The user can create such a configuration file by editing the output of a “show running-config” command.

Note

Only a textual configuration file is supported.

The user-defined docker image can be used by customers to run their own applications in a sandbox on their platform. They can therefore also be used for automating initial configuration.

Note

Only one docker container can be launched in ZTP.

Running DHCP-ZTP

There is no explicit command to enable ZTP. It is enabled by default. Disabling it is performed by a user-initiated configuration save (using the command “configuration write”). The only way to re-enable ZTP is to run a “reset factory” command, clearing the configuration of the switch and rebooting the system.

ZTP is based on DHCP. For ZTP to work, the software enables DHCP by default on all its management interfaces. The switch OS requests option 66 (tftp-server-name) and 67 (bootfile-name) from the DHCPv4 server or option 58 (bootfile-url) from the DHCPv6 server, and waits for the DHCP responses containing file URLs. The DHCP server must be configured to send back the URLs for the software image, configuration file, and docker container image via these two options. Option 66 would contain the URL prefix to the location of the files, option 67 would contain the name of files, and option 58 would contain the complete URLs of files. The format of these two options is a string list separated by commas. The list items are placed in a fixed order:

DHCPv4

```
option tftp-server-name "<image server url>, <config server url>, <docker container server url>";  
option bootfile-name "<image file>, <config file>, <docker container file>";
```

DHCPv6

```
option dhcp6.bootfile-url "<image server url/image file>, <config server url/config file>,  
<docker container server url/docker container file>";
```

Note

The item value can be empty, but the comma shall not be omitted.

The item value can be empty, but the comma shall not be omitted.

To have DHCP server discern the proper files based on switch-specific information, the OS must provide identifying information for the server to classify the switches. In addition, the OS attaches option 43 (vendor-specific information) and option 60 (vendor class identifier) in DHCPv4 requests and option 17 (vendor-opts) in DHCPv6. Option 60 is set as string “Mellanox” and options 17 and 43 contain the following specific sub-options:

- System Model
- Chassis Part Number
- Chassis Serial Number
- Management MAC
- System Profile
- MLNX-OS Release Version

The corresponding subtypes respectively are defined as:


DHCP_VENDOR_ENCAPSULATED_SUBOPTION_TLV_TYPE_MODEL	1
DHCP_VENDOR_ENCAPSULATED_SUBOPTION_TLV_TYPE_PARTNUM	2
DHCP_VENDOR_ENCAPSULATED_SUBOPTION_TLV_TYPE_SERIAL	3
DHCP_VENDOR_ENCAPSULATED_SUBOPTION_TLV_TYPE_MAC	4
DHCP_VENDOR_ENCAPSULATED_SUBOPTION_TLV_TYPE_PROFILE	5
DHCP_VENDOR_ENCAPSULATED_SUBOPTION_TLV_TYPE_RELEASE	6

Upon receiving such DHCP requests from a client, the server should be able to map the switch-specific information to the target file URLs according to predefined rules.

Once the OS receives the URLs from the DHCP server, it executes ZTP as follows:

1. If the software image URL is not specified, this step is skipped. Otherwise:

1. Perform disk space cleanup if necessary and fetch the image if it does not exist locally
2. Resolve the image version:
 3. If it is already installed on active partition, proceed to step 2
 4. If it is installed on a standby partition, switch partition and reboot
 5. If it is not installed locally, install it and switch to the new image and then reboot
 6. If a reboot occurs, ZTP performs step 1 again and no image upgrade will occur
2. If configuration file URL is not specified, skip this step. Otherwise:
 1. Fetch the configuration file
 2. Apply the configuration file
3. Skip these steps if a docker image file URL is not specified. Otherwise:
 1. Fetch the docker image file
 2. Load the docker image
 3. Clean up the docker images with the same name and different tag.
 4. Start the container based on the image
 5. Remove the downloaded docker image file

 **Note**

While performing file transfer via HTTP, the same information as DHCP option 43 is expected to be carried in a HTTP GET request. This switch software supports the following proprietary HTTP headers:

- MlnxSysProfile
- MlnxMgmtMac
- MlnxSerialNumber

- MlnxModelName
- MlnxPartNumber
- MlnxReleaseVersion

If some sort of failure occurs, the switch waits a random number of seconds between 1 and 20 and reattempts the operation. The switch attempts this up to 10 times.

ZTP progress is printed to terminals including console and active SSH sessions.

ZTP on Modular Switches

For modular switch systems, the two management nodes start ZTP individually. Status synchronization is then performed between the two nodes:

- Target software image version needs to be the same, otherwise ZTP fails
- Both nodes must install the software image successfully, otherwise ZTP fails
- ZTP failure for one node leads to failure for both
- ZTP disable on one node leads to ZTP disable for both
- ZTP abort on one node leads to ZTP abort for both

In ZTP configuration files, commands between #<CHASSIS_MASTER> and #</CHASSIS_MASTER> pair are only executed on the master.

```
#<CHASSIS_MASTER>  
    chassis ha bip 10.7.146.34 /24  
#</CHASSIS_MASTER>
```

Node reboot caused by ZTP is also synchronized:

1. Master node asks slave to reboot.

2. Slave node switches to next boot location and acknowledges the reboot request.
3. Master node reboots slave node via hardware.
4. Master node reboots itself.

ZTP and OS Upgrade

Software upgrade from non-ZTP versions to ZTP versions and vice versa is supported. When upgrading from a non-ZTP version, ZTP is disabled because ZTP is always assumed to start with an empty configuration, otherwise the final configuration becomes a mixture of the existing configuration from the stored database and new configuration from the server and hence not deterministic.

DHCPv4 Configuration Example

The following is a URL configuration example for ISC DHCPv4 server:

```
host master {
    hardware ethernet E4:1D:2D:5B:72:80;
    fixed-address 3.1.2.13;
    option tftp-server-name "scp://<user>:<password>@3.1.3.100/ztp/,scp://
                                <user>:
<password>@3.1.3.100/ztp/, scp://
                                <user>:
<password>@3.1.3.100/ztp/";
    option bootfile-name "image-X86_64-3.6.4612.img, switch-1.conf,
ubuntu.img.gz";
}
```

DHCPv4 request is made out of the following components:

- Option 43 (vendor-encapsulated-options) and option 60 (vendor-class-identifier) are added in the DHCPv4 request packet

- Option 66 (tftp-server-name) and option 67 (bootfile-name) are added in the parameter request list of DHCPv4 request packet

DHCPv6 Configuration Example

The following is a DHCPv6 configuration example:

```

host master {
    . . . . .
    option dhcp6.bootfile-url "scp://<user>:
<password>@[2000::1]/ztp/image-X86_64-
                                3.6.4612.img, scp://<user>:
<password>@[2000::1]/ztp/
                                switch.conf, scp://<user>:
<password>@[2000::1]/ztp/
                                ubuntu.img.gz";
}

```

DHCPv6 request is made out of the following components:

- Option 17 (vendor-opts) is added in the DHCPv6 request packet
- Option 59 (bootfile-url) is added in the parameter request list of DHCPv6 request packet

ZTP Commands

no zero-touch suppress-write

	no zero-touch suppress-write Disables suppression of configuration write.
Syntax Description	N/A
Default	Enabled

Configuration Mode	config
History	3.6.5000 3.9.2400: Added note
Example	switch (config) # no zero-touch suppress-write
Related Commands	show zero-touch
Notes	<ul style="list-style-type: none"> • When ZTP is active, “configuration write” is suppressed because it may interfere with ZTP operation. Therefore, after running “no zero-touch suppress-write” if “configuration write” is performed, then ZTP is disabled as a consequence of the database save. • To automatically save the configuration at the end of applying a configuration via ZTP, append the following two commands to the end of the config files. The first command will turn off the ZTP suppress-write, then the configuration write command should work. <ul style="list-style-type: none"> ◦ no zero-touch suppress-write ◦ configuration write

zero-touch abort

	zero-touch abort Aborts on-going zero-touch process.
Syntax Description	N/A
Default	Enabled
Configuration Mode	config
History	3.6.5000
Example	switch (config) # zero-touch abort Zero-touch failed [Zero-touch is aborted by operator] Zero-touch provisioning will be aborted
Related Commands	show zero-touch
Notes	

show zero-touch

	show zero-touch Displays zero-touch status.
Syntax Description	N/A
Default	N/A
Configuration Mode	Any command mode
History	3.6.5000
Example	switch (config) # show zero-touch Zero-Touch status: Active: yes Status: Waiting for zero-touch start Suppress-write: no Configured by zero-touch: no Configuration changed after zero-touch: no
Related Commands	zero-touch abort zero-touch suppress-write
Notes	

Licenses

The software package can be extended with premium features. Installing a license allows you to access the specified premium features

Note

This section is relevant only to switch systems with an internal management capability.

Installing OS License via CLI

To install a license via CLI:

1. Before applying a license, please make sure your system's time is configured correctly by manually setting it using the CLI command "clock set", or by using NTP using the command "ntp".
2. Login as admin and change to Config mode.

```
switch > enable  
switch # config terminal
```

3. Install the license using the key. Run:

```
switch (config) # license install <license key>
```


4. Display the installed license(s) using the following command. Run:

```
switch (config) # show licenses  
License 1: <license key>  
Feature: EFM_SX  
Valid: yes  
Active: yes
```

Make sure that the "Valid" and "Active" fields both indicate "yes".

5. Save the configuration to complete the license installation. Run:

```
switch (config) # configuration write
```




If you do not save the installation session, you will lose the license at the next system start up.

Installing OS License via Web

To install a license via WebUI:


1. Login as *admin*.
2. Click the Setup tab and then Licensing on the left side navigation pane.




3. Enter your license key(s) in the text box. If you have more than one license, please enter each license in a separate line. Click “Add Licenses” after entering the last license key to install them.

Note

If you wish to add another license key in the future, you can simply enter it in the text box and click “Add Licenses” to install it.



4. All installed licenses should now be displayed.



5. Save the configuration to complete the license installation.

Note

If you do not save the installation session, you will lose the installed licenses at the next system boot.

Retrieving a Lost License Key

In case of a lost license key, contact your authorized NVIDIA reseller and provide the switch's chassis serial number.

To obtain the switch's chassis serial number:

1. Log in to the switch.
2. Retrieve the switch's chassis serial number using the command "show inventory".

```
switch (config) # show inventory
-----
-----
Module          Part Number      Serial Number     Asic
Rev.           HW Rev.
-----
-----
CHASSIS         MSB7800-ES2F     MT1602X17464     N/A
A1
MGMT            MSB7800-ES2F     MT1602X17464     0
A1
FAN1           MTEF-FANF-A     MT1602X16943     N/A
A3
FAN2           MTEF-FANF-A     MT1602X16944     N/A
A3
FAN3           MTEF-FANF-A     MT1602X16956     N/A
A3
FAN4           MTEF-FANF-A     MT1602X16957     N/A
A3
PS1            MTEF-PSF-AC-A   MT1601X09908     N/A
A3
```

3. Provide your authorized NVIDIA reseller with the chassis serial number for your system.

4. Once you receive the license key, you can install the license as described in the previous pages.

Additional Reading and Use Cases

For more information about getting started with NVIDIA Switches, please refer to the following Community post:

- [How To Get Started with NVIDIA Switches](#)

License Commands

license delete

	license delete <license-number> Removes license keys by ID.
Syntax Description	N/A
Default	N/A
Configuration Mode	config
History	3.4.1 100
Example	switch (config) # license delete <license-number>
Related Commands	license install show licenses
Notes	Before deleting a license from a switch which is configured to a system profile other than its default, the user must first disable all interfaces and then return the switch to its default system profile.

license install

	license install<license-number>
--	---------------------------------

	Installs a new license key.
Syntax Description	N/A
Default	N/A
Configuration Mode	config
History	3.4.1 100
Example	switch (config) # licenses install <license-key>
Related Commands	license delete show licenses
Notes	

show licenses

	show licenses Displays a list of all installed licenses.
Syntax Description	N/A
Default	N/A
Configuration Mode	config
History	3.4.1 100
Example	switch (config) # show licenses License 1: <license key> Feature: SX_CONFIG Valid: yes Active: yes
Related Commands	license delete license install
Notes	For each license, the following is displayed: <ul style="list-style-type: none"> • A unique ID which is a small integer • The text of the license key as it was added • Whether or not it is valid and active • Which feature(s) it is activating

- A list of all licensable features specifying whether or not it is currently activated by a license

Notice

This document is provided for information purposes only and shall not be regarded as a warranty of a certain functionality, condition, or quality of a product. NVIDIA Corporation (“NVIDIA”) makes no representations or warranties, expressed or implied, as to the accuracy or completeness of the information contained in this document and assumes no responsibility for any errors contained herein. NVIDIA shall have no liability for the consequences or use of such information or for any infringement of patents or other rights of third parties that may result from its use. This document is not a commitment to develop, release, or deliver any Material (defined below), code, or functionality.

NVIDIA reserves the right to make corrections, modifications, enhancements, improvements, and any other changes to this document, at any time without notice.

Customer should obtain the latest relevant information before placing orders and should verify that such information is current and complete.

NVIDIA products are sold subject to the NVIDIA standard terms and conditions of sale supplied at the time of order acknowledgement, unless otherwise agreed in an individual sales agreement signed by authorized representatives of NVIDIA and customer (“Terms of Sale”). NVIDIA hereby expressly objects to applying any customer general terms and conditions with regards to the purchase of the NVIDIA product referenced in this document. No contractual obligations are formed either directly or indirectly by this document.

NVIDIA products are not designed, authorized, or warranted to be suitable for use in medical, military, aircraft, space, or life support equipment, nor in applications where failure or malfunction of the NVIDIA product can reasonably be expected to result in personal injury, death, or property or environmental damage. NVIDIA accepts no liability for inclusion and/or use of NVIDIA products in such equipment or applications and therefore such inclusion and/or use is at customer’s own risk.

NVIDIA makes no representation or warranty that products based on this document will be suitable for any specified use. Testing of all parameters of each product is not necessarily performed by NVIDIA. It is customer’s sole responsibility to evaluate and determine the applicability of any information contained in this document, ensure the product is suitable and fit for the application planned by customer, and perform the necessary testing for the application in order to avoid a default of the application or the product. Weaknesses in customer’s product designs may affect the quality and reliability of the NVIDIA product and may result in additional or different conditions and/or requirements beyond those contained in this document. NVIDIA accepts no liability related to any default, damage, costs, or problem which may be based on or attributable to: (i) the use of the NVIDIA product in any manner that is contrary to this document or (ii) customer product designs.

No license, either expressed or implied, is granted under any NVIDIA patent right, copyright, or other NVIDIA intellectual property right under this document. Information published by NVIDIA regarding third-party products or services does not constitute a license from NVIDIA to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property rights of the third party, or a license from NVIDIA under the patents or other intellectual property rights of NVIDIA.

Reproduction of information in this document is permissible only if approved in advance by NVIDIA in writing, reproduced without alteration and in full compliance with all applicable export laws and regulations, and accompanied by all associated conditions, limitations, and notices.

THIS DOCUMENT AND ALL NVIDIA DESIGN SPECIFICATIONS, REFERENCE BOARDS, FILES, DRAWINGS, DIAGNOSTICS, LISTS, AND OTHER DOCUMENTS (TOGETHER AND SEPARATELY, “MATERIALS”) ARE BEING PROVIDED “AS IS.” NVIDIA MAKES NO WARRANTIES, EXPRESSED, IMPLIED, STATUTORY, OR OTHERWISE WITH RESPECT TO THE MATERIALS, AND EXPRESSLY DISCLAIMS ALL IMPLIED WARRANTIES OF NONINFRINGEMENT, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE. TO THE EXTENT NOT PROHIBITED BY LAW, IN NO EVENT WILL NVIDIA BE LIABLE FOR ANY DAMAGES, INCLUDING WITHOUT LIMITATION ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES, HOWEVER CAUSED AND REGARDLESS OF THE THEORY OF LIABILITY, ARISING OUT OF

ANY USE OF THIS DOCUMENT, EVEN IF NVIDIA HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Notwithstanding any damages that customer might incur for any reason whatsoever, NVIDIA's aggregate and cumulative liability towards customer for the products described herein shall be limited in accordance with the Terms of Sale for the product.

Trademarks

NVIDIA and the NVIDIA logo are trademarks and/or registered trademarks of NVIDIA Corporation in the U.S. and other countries. Other company and product names may be trademarks of the respective companies with which they are associated.

© Copyright 2024, NVIDIA. PDF Generated on 11/18/2024