



General Troubleshooting

Table of contents

Server unable to find the BlueField

BlueField no longer works

BlueField stopped working after installing another BFB

Link indicator light is off

Link light is on but no communication is established

Server unable to find the BlueField

- Ensure that the NVIDIA BlueField networking platform (DPU or SuperNIC) is placed correctly
- Make sure the BlueField slot and the BlueField are compatible
- Install BlueField in a different PCI Express slot
- Use the drivers that came with BlueField or download the latest
- Make sure your motherboard has the latest BIOS
- Perform a [graceful shutdown](#) then power cycle the server

BlueField no longer works

- Reseat BlueField in its slot or a different slot, if necessary
- Try using another cable
- Reinstall the drivers for the network driver files may be damaged or deleted
- Perform a [graceful shutdown](#) then power cycle the server

BlueField stopped working after installing another BFB

- Try removing and reinstalling all BlueFields
- Check that cables are connected properly
- Make sure your motherboard has the latest BIOS

Link indicator light is off

- Try another port on the switch
- Make sure the cable is securely attached

- Check you are using the proper cables that do not exceed the recommended lengths
- Verify that your switch and BlueField port are compatible

Link light is on but no communication is established

- Check that the latest driver is loaded
- Check that both BlueField and its link are set to the same speed and duplex settings

© Copyright 2024, NVIDIA. PDF Generated on 08/20/2024