



# **NVIDIA UFM Enterprise User Manual v6.18.2**

# Table of contents

<b>Release Notes</b>	6
Changes and New Features	7
Installation Notes	11
Bug Fixes in This Release	18
Known Issues in This Release	18
Changes and New Features History	19
Bug Fixes History	28
Known Issues History	34
<b>UFM Overview</b>	43
UFM Benefits	44
Main Functionality Modules	45
UFM Communication Requirements	47
UFM Software Architecture	52
Getting Familiar with UFM's Data Model	55
UFM Web UI Overview	56
Access the WebUI	57
WebUI Layout	58
Set User Preferences	60
<b>UFM Installation and Initial Configuration</b>	66
UFM Installation Steps	66
Downloading UFM Software and License File	67
Installing UFM Server Software	70
Installing UFM Server on Bare Metal Server	76
Installing UFM on Bare Metal Server - High Availability Mode	76

Installing UFM on Bare Metal Server- Standalone Mode	83
Installing UFM Docker Container Mode	84
Installing UFM on Docker Container - High Availability Mode	88
Installing UFM on Docker Container - Standalone Mode	95
Replacing the Standby Node	96
Activating Software License	97
UFM Configuration	101
Initial Configuration	101
Optional Configuration	102
Running UFM Server Software	141
Upgrading UFM Software	157
Upgrading UFM on Bare Metal Server	158
Upgrading UFM on Docker Container	162
Uninstalling UFM	165
UFM Configuration Backup and Restore	167
UFM Factory Reset	172
Manage Users	176
Authentication Methods	178
UFM Server Health Monitoring	193
Events and Alarms	202
Threshold-Crossing Events Reference	203
Reports	221
Telemetry	222
High-Frequency (Primary) Telemetry Fields	224
Low-Frequency (Secondary) Telemetry Fields	228

UFM Web UI	235
Access the WebUI	57
WebUI Layout	58
Set User Preferences	60
Multi-Subnet UFM	244
UFM Plugins	260
Plugins Bundle	264
REST-RDMA Plugin	265
NDT Plugin	273
UFM Telemetry Fluentd Streaming (TFS) Plugin	290
UFM Events Fluent Streaming (EFS) Plugin	291
UFM Bright Cluster Integration Plugin	292
UFM Cyber-AI Plugin	296
Autonomous Link Maintenance (ALM) Plugin	298
ClusterMinder Plugin	309
GRPC-Streamer Plugin	313
Sysinfo Plugin	326
SNMP Plugin	328
Packet Level Monitoring Collector (PMC) Plugin	332
PDR Deterministic Plugin	336
GNMI-Telemetry Plugin	343
UFM Telemetry Manager (UTM) Plugin	360
Overview	375
Fast-API Plugin	377

UFM Light Plugin	383
Key Performance Indexes (KPI) Plugin	387
Troubleshooting	405
Appendixes	408
SM Configurations	408
Appendix – SM Default Files	409
Appendix – UFM Subnet Manager Default Properties	409
Appendix – Partitioning	423
Appendix – Enhanced Quality of Service	431
OpenSM Configuration	433
Appendix – Routing Chains	435
Appendix – Adaptive Routing	446
Appendix – Security Features	446
Appendix – SM Activity Report	450
Appendix – Diagnostic Utilities	452
Appendix - Supported Port Counters and Events	483
Appendix – Used Ports	504
Appendix – Configuration Files Auditing	505
Appendix – IB Router	507
Appendix – NVIDIA SHARP Integration	515
Appendix - UFM SLURM Integration	520
Appendix - Switch Grouping	525
Appendix – Device Management Feature Support	532
Document Revision History	538
EULA, Legal Notices and 3rd Party Licenses	547

## **About This Document**

NVIDIA® UFM® Enterprise is a powerful platform for managing InfiniBand scale-out computing environments. UFM enables data center operators to efficiently monitor and operate the entire fabric, boost application performance and maximize fabric resource utilization.

This user guide provides documentation for network administrators responsible for deploying, configuring, monitoring, and troubleshooting the network in their data center.

For a list of the new features, bug fixes and known issues in this release, see [Release Notes](#).

## **Software Download**

To download the UFM software, please visit [NVIDIA's Licensing Portal](#).

If you do not have a valid license, please fill out the [NVIDIA Enterprise Account Registration](#) form to get a UFM evaluation license.

## **Document Revision History**

For the list of changes made to this document, refer to [Document Revision History](#).

---

# Release Notes

NVIDIA® UFM® is a powerful platform for managing InfiniBand scale-out computing environments. UFM enables data center operators to efficiently monitor and operate the entire fabric, boost application performance and maximize fabric resource utilization.

## Key Features

UFM provides a central management console, including the following main features:

- Fabric dashboard including congestion detection and analysis
- Advanced real-time health and performance monitoring
- Fabric health reports
- Threshold-based alerts
- Fabric segmentation/isolation
- Quality of Service (QoS)
- Routing optimizations
- Central device management
- Task automation
- Logging
- High availability
- Daily report: Statistical information of the fabric during the last 24 hours
- Event management
- Switch auto-provisioning
- UFM-SDN Appliance in-service software upgrade

- Fabric validation tests
- Client certificate authentication
- IPv6 on management ports

 **Warning**

Prior to installation, please verify that all prerequisites are met. Please refer to [System Requirements](#).

## Changes and New Features

This section lists the new and changed features in this software version.

 **Note**

For an archive of changes and features from previous releases, please refer to [Changes and New Features History](#).

Feature	Description
UFM Reports Enhancements	Added an option for excluding unhealthy ports from UFM reports based on ibdiagnet (for example: Fabric Health report, Fabric Validation tests). For more information, refer to <a href="#">Excluding Unhealthy Ports from Fabric Health Report</a> .
Telemetry Enhancements	Added support for Egress Queue depth indications (as part of UFM secondary telemetry instance). For more information, refer to <a href="#">Exposing Performance Histogram Counters</a> .
	Added support for Extended Port VL Xmit Time Congestion counters (as part of UFM secondary telemetry instance).
UFM Configuration	Added the option for auto-setting of UFM configuration based on fabric size (large scale, small scale). For more information, refer to <a href="#">Adjusting</a>

Feature	Description	
n Adjustments	<a href="#">UFM Configuration Files Based on Fabric Size.</a>	
UFM Container Timezone	The UFM Container has been updated to operate in the host machine's time zone instead of UTC.	
UFM Events	Added the ability to update thresholds, severities, and durations (TTL) for selected UFM Events.	
	Added a new UFM event for indicating asymmetric Adaptive Routing (based on SM trap). For more information, refer to <a href="#">Appendix - Supported Port Counters and Events.</a>	
Topology Changes Reports Enhancements	Enhanced the topology change indication from the master topology and enabled a quick drill-down to the associated topology change report. For more information, refer to <a href="#">Topology Compare Tab</a> and <a href="#">Events &amp; Alarms.</a>	
Multi-Subnet UFM	Added support for running UFM Fabric validation Tests from UFM Multi-Subnet Consumer. For more information, refer to <a href="#">Multi-Subnet UFM.</a>	
UFM Docker Container Deployment	Added support for deploying UFM as a docker on Oracle Linux 8. For more information, refer to <a href="#">Installation Notes.</a>	
UFM-HA	HA Deployment: Added support for deploying UFM HA on Ubuntu24.04.	
	HA Configuration: Added configurable failover criteria (management interface loss-of-link).	
UFM System Dump Analyser	Introduced an internal debugging tool for more efficient analysis of UFM system dumps.	
Plugins	<a href="#">REST-RDMA Plugin</a>	Added support for client certificate authentication when communicating between the client and the REST over RDMA plugin server.
	<a href="#">UFM Light Plugin</a>	Added support for UFM Light Plugin to create a reduced UFM model and deliver a high-performance REST API.
	<a href="#">Key Performance Indexes (KPI) Plugin</a>	Added support for the KPI plugin which periodically collects telemetry metrics and topology data from one or multiple UFM Telemetry and UFM clusters to calculate high-level Key Performance Indicators (KPIs).

Feature	Description	
	<a href="#">ClusterMind er Plugin</a>	Added support for the ClusterMind plugin which collects telemetry data from multiple data sources and aggregates, streams and visualizes the backend.
	<a href="#">Packet Mirroring Collector (PMC) Plugin</a>	Added the option to collect PHY link-down event indications through fast-recovery notification channels.
	<a href="#">UFM Plugins Management</a>	Added support for UFM plugin management using the <code>manage_ufm_plugins.sh</code> script.
	<a href="#">Plugins Bundle</a>	Added support for a single deployment of plugins to extend functionalities of the UFM ecosystem.
REST APIs	UFM-Forge Integration	Added support for setting SM resource limitation. For more information, refer to the <a href="#">Physical-Virtual GUID Mapping REST API</a> .
	SHARP Jobs Performance Analysis	Added a new REST API which expose SHARP Job statistics data. For more information, refer to <a href="#">NVIDIA SHARP REST API</a>
	UFM Logging	Added caller (IP Address) and duration logging info for all REST API calls.
	UFM Version API Enhancement	Added a REST API to retrieve the versions of major UFM components and enabled plugins.

** Note**

The items listed in the table below apply to all UFM license types.

** Note**

For bare metal installation of UFM, it is required to install MLNX\_OFED 5.X (or newer) before the UFM installation.

Please make sure to use the UFM installation package that is compatible with your setup, as detailed in [Bare Metal Deployment Requirements](#).

## Unsupported Functionalities/Features

**The following distributions are no longer supported in UFM:**

- RH7.0-RH7.7 / CentOS7.0-CentOS7.7
- SLES12 / SLES 15
- EulerOS2.2 / EulerOS2.3

**Deprecated Features:**

- Mellanox Care (MCare) Integration
- UFM on VM (UFM with remote fabric collector)
- Logical server auditing
- The UFM high availability script - **/etc/init.d/ufmha** - is no longer supported
- The **UFM Multi-site portal** feature is no longer supported. The Multi-Subnet feature can be used instead
- As of UFM Enterprise v6.18.0, **UFM Agent discovery** will be disabled by default, and managed switches will be discovered in-band
- As of UFM Enterprise v6.18.0, the `ibdiagpath` diagnostic utility is deprecated
- As of UFM Enterprise version 6.14.0, **UFM Monitoring Mode** is deprecated and is no longer supported
- As of UFM Enterprise v6.12.0, the **Logical Elements tab** is removed
- Removed the following fabric validation tests: **CheckPortCounters & CheckEffectiveBER**

## Note

In order to continue working with **/etc/init.d/ufmha** options, use the same options using the **/etc/init.d/ufmd** script.

For example:

Instead of using **/etc/init.d/ufmha model\_restart**, please use **/etc/init.d/ufmd model\_restart** (on the primary UFM server)

Instead of using **/etc/init.d/ufmha sharp\_restart**, please use **/etc/init.d/ufmd sharp\_restart** (on the primary UFM server)

The same goes for any other option that was supported on the **/etc/init.d/ufmha** script

# Installation Notes

## Supported Devices

### Supported NVIDIA Externally Managed Switches

Type	Model	Latest Tested Firmware Version
NDR switches	<ul style="list-style-type: none"><li>MQM9790</li></ul>	31.2021.4036
HDR switches	<ul style="list-style-type: none"><li>MQM8790</li></ul>	27.2012.4036
EDR switches	<ul style="list-style-type: none"><li>SB7790</li><li>SB7890</li></ul>	15.2010.4402

### Supported NVIDIA Internally Managed Switches

Type	Model	Latest Tested OS Version
NDR switches	<ul style="list-style-type: none"> <li>MQM9700</li> </ul>	MLNX-OS 3.12.1002 NVOS 25.01.4000
HDR switches	<ul style="list-style-type: none"> <li>MQ8700</li> <li>MCS8500</li> <li>TQ8100-HS2F</li> <li>TQ8200-HS2F</li> </ul>	MLNX-OS 3.12.1002
EDR switches	<ul style="list-style-type: none"> <li>SB7700</li> <li>SB7780</li> <li>SB7800</li> <li>CS7500</li> <li>CS7510</li> <li>CS7520</li> </ul>	MLNX-OS 3.10.4400

## System Requirements

### Bare Metal Deployment Requirements

Platform	Type and Version
OS (Relevant for Standalone and High-Availability deployments)	64-bit OS: <ul style="list-style-type: none"> <li>RedHat 8</li> <li>RedHat 9</li> <li>Ubuntu 20.04</li> <li>Ubuntu 22.04</li> </ul>
CPU <sup>(a)</sup>	x86_64
HCAs	<ul style="list-style-type: none"> <li>NVIDIA ConnectX®-4 with Firmware 12.28.2006 and above</li> <li>NVIDIA ConnectX®-5 with Firmware 16.35.4030 and above</li> <li>NVIDIA ConnectX®-6 with Firmware 20.24.4702 and above</li> <li>NVIDIA ConnectX®-7 with Firmware 28.42.0428 and above</li> <li>NVIDIA Mezzanine Board with Four ConnectX-7 ASICs for Multi-GPU Connectivity (CEDAR) with Firmware 28.36.0394 and above</li> <li>NVIDIA BlueField with Firmware 24.33.900 and above</li> </ul>

Platform	Type and Version
	<ul style="list-style-type: none"> <li>• NVIDIA BlueField-2 with Firmware 24.33.900 and above</li> <li>• NVIDIA BlueField-3 with Firmware 32.42.0148 and above</li> </ul>
OFED <sup>(b)</sup>	<ul style="list-style-type: none"> <li>• MLNX_OFED 5.X</li> <li>• MLNX_OFED23.x</li> <li>• MLNX_OFED24.x</li> </ul>

**i Note**

<sup>(a)</sup> CPU requirements refer to resources consumed by UFM. You can also dedicate a subset of cores on a multicore server. For example, 4 cores for UFM on a 16-core server.

<sup>(b)</sup> For supported HCAs in each MLNX\_OFED version, please refer to MLNX\_OFED Release Notes.

<sup>(c)</sup> UFM v6.15.0 is the last version to support NVIDIA ConnectX-4 adapter cards

**i Note**

For running SHARP Aggregation Manager within UFM, it is recommended to use MLNX\_OFED-5.4.X version or newer.

**i Note**

Installation of UFM on minimal OS distribution is not supported.

**Note**

UFM does not support systems in which NetworkManager service is enabled.

Before installing UFM on RedHat OS, make sure to disable the service.

## Docker Installation Requirements

UFM Docker Container is supported on the standard docker environment (engine).

The following operating systems were tested with Docker Container (as standalone container):

Component	Type and Version
Supported OS	<ul style="list-style-type: none"><li>• RHEL8</li><li>• RHEL9</li><li>• Ubuntu18.04</li><li>• Ubuntu20.04</li><li>• Ubuntu22.04</li></ul>

**Note**

For UFM Docker Container installation in HA mode, please refer to [Bare Metal Deployment Requirements](#) for the list of operating systems and kernels which support HA.

**Note**

On some Ubuntu OSs, Docker is installed via SNAP, which might lead to errors when trying to use UFM Plugins.

To solve this issue, perform the following:

1. Remove Docker installed via SNAP, run:

```
snap remove --purge docker
```

2. Update the local package index, run :

```
apt update
```

3. Install native Docker, run:

```
apt install-y docker.io
```

## UFM Server Resource Requirements per Cluster Size

Fabric Size	CPU Requirements*	Memory Requirements	Disk Space Requirements	
			Minimum	Recommended
Up to 1000 nodes	4-core server	4 GB	20 GB	50 GB
1000-5000 nodes	8-core server	16 GB	40 GB	120 GB
5000-10000 nodes	16-core server	32 GB	80 GB	160 GB
Above 10000 nodes	Contact NVIDIA Support			

## UFM GUI Client Requirements

The platform and GUI requirements are detailed in the following tables:

Platform	Details
Browser	Edge, Internet Explorer, Firefox, Chrome, Opera, Safari
Memory	<ul style="list-style-type: none"><li>• Minimum: 8 GB</li><li>• Recommended: 16 GB</li></ul>

## MFT Package Version

Platform	Details
MFT	Integrated with MFT version 4.29.0-131

## UFM SM Version

Platform	Type and Version
SM	UFM package includes SM version 5.20.0

### **Note**

Assuming the SM is connected to the production cluster, it can handle any events (IB traps) coming from the fabric that is being built; such events should not affect the routing on the production cluster. If events occurred in the production cluster, the routing could be changed.

However, NVIDIA recommends isolating fabric sections to allow faster bring-ups, **faster troubleshooting and misconfiguration avoidance** that can cause routing errors. Isolation provides clearer SM and

CollectX logs, avoiding warnings/errors from masking real production issues.

## UFM NVIDIA SHARP Software Version

Platform	Type and Version
NVIDIA® Scalable Hierarchical Aggregation and Reduction Protocol (SHARP)™	UFM package includes NVIDIA SHARP software version 3.8.0

## Used Ports by UFM Server

For a list of ports used by the UFM Server for internal and external communication, refer to [Appendix – Used Ports](#).

## Software Update from Prior Versions

The installer detects versions previously installed on the machine and prompts you to run a clean install of the new version or to upgrade while keeping user data and configuration unchanged.

The upgrade from previous versions maintains the existing database and configuration, allowing a seamless upgrade process.

### Info

Upgrading UFM Enterprise software version is supported up to two previous GA software versions (GA -1 or -2).

For example, if you wish to upgrade to UFM Enterprise v6.17.0, it is possible to do so only from UFM Enterprise v6.16.0 or v6.15.0.

## **Note**

Due to a possible conflict, SM and SHARP installed by the MLNX\_OFED must be uninstalled. The installation procedure will detect and print all MLNX\_OFED packages that must be removed.

## Bug Fixes in This Release

Ref #	Description
40529 78	Description: Fixed issue with UFM PKey programming failure with HTTP 413 (Content Too Large)
	Keywords: PKey, HTTP 413
	Discovered in Release: 6.17.2

## Known Issues in This Release

Ref #	Description
39911 99	<b>Description:</b> Dynamic Telemetry instances are not recovered during the backup/restore procedure
	<b>Keywords:</b> Dynamic Telemetry, Backup, Restore
	<b>Workaround:</b> N/A
	<b>Discovered in Release:</b> 6.17.5

## **Info**

For a list of known issues from previous releases, please refer to [Known Issues History](#).

# Changes and New Features History

## Note

The items listed in the table below apply to all UFM license types.

Feature	Description
Rev 6.16.0	
Syslog Streaming	Added the option for setting UFM syslog streaming facility. For more information, refer to <a href="#">Configuring Syslog</a> .
Switch Cables REST API	Added the option to query specific switch cables (using Ports API).
Switch Power Information	Added support for switch and modules power usage data in UFM telemetry and REST API. For more information, refer to <a href="#">Devices Window</a> and <a href="#">Inventory Window</a> .
UFM Data Streaming	Added the ability to change the UFM Data streaming log facility. For more information, refer to <a href="#">Configuring Syslog</a> and <a href="#">Configuring UFM Logging</a> .
Kerberos Authentication	Added the ability for Kerberos authentication, a strong network authentication protocol for client-server applications. For more information, refer to <a href="#">Kerberos Authentication</a> and <a href="#">Enabling Kerberos Authentication</a> .
SM Settings	Changed the default maximal number of VLs to 2 (VL0 – VL1). For more information, refer to <a href="#">Appendix – UFM Subnet Manager Default Properties</a> .
Cable Management	Added support for showing transceiver information for downed links. For more information, refer to <a href="#">Cables Window</a> and <a href="#">Network Map</a> .
Secondary Telemetry	Added the <code>secondary_slvl_support</code> flag and information on the default counters. For more information, refer to <a href="#">Secondary Telemetry</a> .
Congestion Control	Added support for SM congestion control settings. For more information, refer to <a href="#">Appendix - OpenSM Configuration Files for Congestion Control</a> .
UFM HA	Enhanced reliability and added support for setting UFM HA on LVM (Logical Volume Manager). For more information, refer to <a href="#">UFM High-</a>

Feature	Description
	<a href="#">Availability Documentation</a> .
Plugins	Packet Mirroring Collector (PMC) Plugin: Added support for event on PF indicating a QP closing with error on any other GVMI/VF. For more information, refer to <a href="#">Packet Level Monitoring Collector (PMC) Plugin</a> .
	PDR Deterministic Plugin: Updated instructions. For more information, refer to <a href="#">PDR Deterministic Plugin</a> .
	GNMI-Telemetry Plugin: Added gNMI telemetry streaming support (supporting secured mode streaming). For more information, refer to <a href="#">GNMI-Telemetry Plugin</a> .
	NDT Plugin (Subnet Merger): Added the option to validate the extended fabric using cable validation tool. For more information, refer to the <a href="#">NDT Plugin</a> .
Rev 6.15.2	
UFM SM	New routing algorithm for asymmetric QFT topologies
Rev 6.15.1	
SHARP Reservation	Added support for Auto-cleanup of zombie SHARP reservations
Rev 6.15.0	
Defining Node Description	To prevent the formation of incorrect multi-NIC groups based on these default labels, this feature offers the option to establish a blacklist containing possible node descriptions that should be avoided when grouping Multi-NIC HCAs during host startup. For more information, refer to <a href="#">Defining Node Description Black-List</a> .
Network Reports	Added the ability to view topology change events related to devices and links. For more information, refer to <a href="#">Events History</a> , <a href="#">Device Status Events</a> and <a href="#">Link Status Events</a> .
User Authentication	Introduced a new user authentication login page. For more information, refer to <a href="#">Azure Authentication Login Page</a> and <a href="#">Enabling Azure AD Authentication</a> .
	Added support for a separate authentication server. For more information, refer to <a href="#">UFM Authentication Server</a> and <a href="#">Enabling UFM Authentication Server</a> .
Secondary Telemetry	Added the ability to expose SHARP telemetry in UFM Telemetry. For more information, refer to <a href="#">Exposing Switch Aggregation Nodes Telemetry</a> .

Feature	Description
	Added the ability to stop SHARP telemetry endpoint using CLI commands. For more information, refer to <a href="#">Stopping Telemetry Endpoint Using CLI Command</a> .
REST APIs	Enhanced the logging REST API by adding the ability to get event logs in JSON file format. For more information, refer to <a href="#">Get Events Logs in JSON Format</a> .
	Added the ability to expose managed switch power consumption in Web UI. For more information, refer to <a href="#">Get Managed Switches Power Consumption</a> .
	Added ability to filter the event logs by source. For more information, refer to <a href="#">Create Log History</a> .
	Added the ability to generate enterprise network reports. For more information, refer to <a href="#">Events History</a> , <a href="#">Device Status Events</a> and <a href="#">Link Status Events</a> .
	Introduced REST APIs for various authentication types. For more information, refer to <a href="#">Examples of REST APIs Using Various Authentication Types</a> .
	Added the ability to update UFM Configuration REST API. For more information, refer to <a href="#">UFM Configuration REST API</a> .
	Added the option to expose cable information. For more information, refer to <a href="#">Get Ports with Cable Information</a> .
	Improved dynamic telemetry by adding the ability to instantiate a new instance and delete a running instance. For more information, refer to <a href="#">UFM Dynamic Telemetry Instances REST API</a> .
	Added the option to set “down” ports as unhealthy. For more information, refer to <a href="#">Unhealthy Ports REST API</a> .
	Added forge InfiniBand anti-spoofing support. For more information, refer to <a href="#">Forge InfiniBand Anti-Spoofing REST API</a> .
Added the ability to expose the "site_name" field in all supported REST APIs. For more information, refer to <a href="#">REST API Complementary Information</a> .	
Plugins	Added support for the gNMI-Telemetry plugin that employs the gNMI protocol to stream data from UFM telemetry. In addition, added support for secure mode based on client authentication. For more information, refer to the <a href="#">GNMI-Telemetry Plugin</a> .
	Added support for ALM configuration for controlling isolation/de-isolation. For more information, refer to <a href="#">ALM Configurations</a> .

Feature	Description
	REST over RDMA Plugin: Moved to Ubuntu 22-based docker container, OFED 5.8-3.0.7.0, ucx_py 0.35.0 and Python 3.10.
Supported Transceivers	Added support for FR4 transceivers
Rev 6.14.2	
Cable and Transceivers Burning	UFM supports second-source cable transceivers burn.
Module REST API	Added HW revision field in GET module REST API response.
Telemetry	Added support for the MRCS register read in UFM Telemetry.
UFM Reports	UFM Daily report will be disabled by default after upgrade or clean installation.
Rev 6.14.0	
UFM Upgrade	<p>Added support for in-service upgrade procedure for UFM HA. Refer to the following sections:</p> <ul style="list-style-type: none"> <li>• <a href="#">Upgrading UFM on Bare Metal - High Availability Upgrade</a></li> <li>• <a href="#">Upgrading UFM Container in High Availability Mode</a></li> </ul>
User Authorization	Added support for user-defined roles based on REST APIs subsets. Refer to <a href="#">Rest Roles Access Control</a> .
User Authentication	Added support for user authentication based on Azure Active Directory. Refer to <a href="#">Azure AD Authentication</a> .
Plugins Management	Added support for loading UFM plugin to both master and standby nodes in case of UFM HA deployment. Refer to <a href="#">Plugin Management</a> .
Unhealthy Ports Policy Management	Added support for unhealthy ports policy management via UFM Web UI. Refer to <a href="#">Health Policy Management</a> .
REST over RDMA Plugin	Added support for remote ibdiagnet authentication. Refer to <a href="#">rest-rdma Plugin</a> .

Feature	Description
SHARP Reservation	Added support for synchronous SHARP reservation REST API (in addition to the existing asynchronous REST API). Refer to the <a href="#">NVIDIA SHARP REST API</a> .
Secondary Telemetry	Added support for secondary telemetry running by default upon UFM startup, fetching NVIDIA Amber counters. Refer to <a href="#">Secondary Telemetry</a> .
	Added support for down ports telemetry. Refer to <a href="#">Secondary Telemetry</a> .
PCI Analysis	Added support for PCI analysis as part of UFM Fabric Analysis Report (added new events for degraded hosts PCI devices). Refer to <a href="#">Appendix - Supported Port Counters and Events</a> .
UFM System Dump	Added human readable time to the dmsg de-message output as part of UFM system dump.
Factory Reset	Added support for UFM Factory Reset. Refer to <a href="#">UFM Factory Reset</a> .
Rev 6.13.0	
Network Fast Recovery	Added the ability to automatically isolate a malfunctioning switch port as detected by the switch. Refer to <a href="#">Enabling Network Fast Recovery</a>
Multi-Subnet UFM	Added support for multiple UFM instances, wherein multiple instances are aggregated, managed and controlled by a centralized UFM instance. Refer to <a href="#">Multi-Subnet UFM</a> .
Switch ASIC Failure Detection	Added support for a new indication (UFM event) that identifies a failure of a specific switch ASIC. Refer to <a href="#">Configuring Partial Switch ASIC Failure Events</a> .
UFM High-Availability Enhancements	Added support for configuring high-availability with dual-link connections to improve the high-availability robustness.
Automatic Switch Grouping	Added support for enabling automatic grouping of 1U switches by UFM, as per a pre-defined user-configured mapping. Refer to <a href="#">Appendix - Switch Grouping</a> .
SHARP Trees APIs	Incorporated support for a new UFM REST API that presents the current active SHARP trees. <a href="#">Refer to NVIDIA SHARP Resource Allocation REST API</a> .
SHARP Reservation APIs	Added support for SHARP Reservation API enhancements. Refer to <a href="#">NVIDIA SHARP Resource Allocation REST API</a> .

Feature	Description
Operating System Update support	Implemented functionality to support the installation and upgrade of a standalone UFM after the upgrade of operating system packages (e.g., using yum update/apt upgrade). Furthermore, upgrading operating system packages will not impact a standalone UFM installation.
Email Time-Zone Settings	Added the ability to configure time-zone settings for UFM email notifications, ensuring that sent events or daily reports align with the configured time zone. Refer to <a href="#">Email</a> .
Switch Connectivity Failure Indication	Incorporated support for a new UFM event indication that identifies failed communication with a specified managed switch. <a href="#">Appendix - Supported Port Counters and Events</a>
Dynamic Telemetry	Added APIs that enable the creation and management of UFM Telemetry instances, allowing users to select desired counters and ports as per their requirements. Refer to UFM Dynamic Telemetry Instances REST API.
TFS (Telemetry Fluent Streaming) Plugin	Added support for UFM telemetry data streaming from multiple endpoints to Fluent Bit. Refer to <a href="#">Telemetry to Fluent Streaming (TFS) Plugin REST API</a> .
	Added support for enabling white/black counters lists within the TFS Plugin. Refer to <a href="#">Telemetry to Fluent Streaming (TFS) Plugin REST API</a> .
DTS (DPU Telemetry) Plugin	Added support for displaying DPUs data within the UFM Web UI. Refer to <a href="#">DTS Plugin</a> .
Cyber-AI Plugin	Added support for displaying Cyber-AI software within the UFM Web UI. Refer to <a href="#">UFM Cyber-AI Plugin</a> .
Packet Mirroring Collector (PMC) Plugin	Added the Packet Mirroring Collector (PMC) plugin that allows users to catch and collect mirrored pFRN and congestion notifications from switches for enhanced real-time network visibility. Refer to <a href="#">Packet Level Monitoring Collector (PMC) Plugin</a> .
SNMP Traps Listener Plugin	Added the capability to enable registration and monitoring of SNMP traps from managed switches, in addition to updating UFM with the relevant trap information. Refer to <a href="#">SNMP Plugin</a> .
Bright Cluster Integration Plugin	Added support for integration of data from Bright Cluster Manager (BCM) into UFM, providing a more comprehensive network perspective. Refer to <a href="#">UFM Bright Cluster Integration Plugin</a> .

Feature	Description
UFM System Dump	UFM System Dump collection enhancement. Refer to UFM System Dump Tab.
Expanding Non-Blocking Fabric (NDT Plugin extension)	Added a feature that facilitates seamless expansion of the IB fabric, ensuring uninterrupted functionality and optimal performance throughout the fabric. Refer to <a href="#">NDT Format – Merger</a> .
PDR (Packet Drop Rate) Plugin	Added a new functionality that enables automatic detection and isolation of port failures through monitoring of PDR (Packet Drop Rate), BER (Bit Error Rate), and high cable temperatures. Refer to <a href="#">PDR Deterministic Plugin</a> .
Rev 6.12.0	
Managed Switches - Sysinfo Mechanism	Added the ability to save switches inventory data into JSON format files and present the latest fetched switches data upon UFM start-up. The saved switches data is available UFM upon system dump. Refer to Appendix - Managed Switches Configuration Info Persistency
REST over RDMA Plugin	Introduced security improvements (allowed read-only options in remote ibdiagnet) and added support for Telemetry API. Refer to <a href="#">REST-RDMA Plugin</a> .
Events and Notifications	Added support for indicating potential switch ASIC failure by detecting a defined percentage of unhealthy switch ports. Refer to <a href="#">Additional Configuration (Optional)</a> .
SHARP AM Multi-Port	Added support for detecting IB fabric interface failure and automatic failover to an alternative active port in SHARP Aggregation Manager (AM). Refer to <a href="#">Multi-port SM</a>
UFM System Dump	Added support for downloading the generated UFM system dump. Refer to UFM System Dump Tab
UFM REST API	Added support for adding or removing hosts to Partition key (PKey) assignments (when adding/removing hosts, all the related host GUIDs are assigned to/removed from the PKey). Refer to <a href="#">Add Host REST API</a>
	UFM System Dump Improvements including <a href="#">Creating New System Dump API</a>
UFM SLURM Integration	Enhanced UFM SLURM integration; allow flexible configuration of PKey and SHARP resources usage. Refer to <a href="#">Appendix - UFM SLURM Integration</a>

Feature	Description
UFM HA	Improved UFM HA configuration by setting UFM HA nodes using IP addresses only (removed the need of using hostnames and sync interface names). Refer to <a href="#">Configuring UFM Docker in HA Mode</a> and <a href="#">Installing UFM Server Software for High Availability</a>
Managed Switch Operations	Added support for persistent enablement/disablement of managed switches ports. Refer to <a href="#">Ports Window</a>
UFM SDK	Created a script to get TopX data by category. Refer to <a href="#">UFM Aggregation TopX README.md file</a>
Proxy Authentication	Added option to delegate authentication to a proxy. Refer to <a href="#">Delegate Authentication to a Proxy</a>
UFM Initial Settings	Removed the requirement to set the IPoIB address to the main IB interface used by UFM/SM (gv.cfg → fabric_interface)
Port auto-isolation	Symbol BER <b>warning</b> does not trigger port auto-isolation, only symbol BER <b>error</b>
MFT Package	Integrated with MFT version 4.23.0-104
Rev 6.11.0	
UFM Discovery and Device Management	<ul style="list-style-type: none"> <li>• InBand autoscovery of switches' IP addresses using ibdiagnet</li> <li>• Discovering the device's PSID and FW version using ibdiagnet by default instead of using an SM vendor plugin</li> </ul>
CPU Affinity	Enabling the user to control CPU affinity of UFM's major processes
gRPC API	Added support for streaming UFM REST API data over gRPC as part of new UFM plugin. Refer to <a href="#">GRPC-Streamer Plugin</a>
Telemetry	<ul style="list-style-type: none"> <li>• Added support for flexible counters infrastructure (ability to change counter sets that are sampled by the UFM)</li> <li>• Updated the set of available counters for Telemetry (removed General counters from default view: Row BER, Effective BER and Device Temperature. Now available through the secondary telemetry instance). Refer to <a href="#">Secondary Telemetry</a>.</li> </ul>

Feature	Description
EFS UFM Plugin	Added support for streaming UFM events data to FluentD destination as part of a new UFM plugin. Refer to <a href="#">UFM Telemetry Fluentd Streaming (TFS) Plugin</a>
General UI Enhancements	<ul style="list-style-type: none"> <li>• Displayed columns of all tables are persistent per user, with the option to restore defaults. Refer to <a href="#">Displayed Columns</a></li> <li>• Improved look and feel in Network Map. Refer to <a href="#">Network Map</a></li> <li>• Added Reveal Uptime to the general tab in the devices information tabs. Refer to <a href="#">Device General Tab</a></li> </ul>
High Availability Deployment	<ul style="list-style-type: none"> <li>• Added support for joining a new UFM device into the HA pair without stopping the UFM HA (in case of a secondary UFM node permanent failure). For more information, refer to <a href="#">Installing UFM Server Software for High Availability</a></li> <li>• Changed UFM HA package installation command parameters. For more information, refer to <a href="#">Installing UFM Server Software for High Availability</a></li> </ul>
REST APIs	Added support for PKey filtering for default session data. Refer to <a href="#">Get Default Monitoring Session Data by PKey Filtering</a> .
	Added support for filtering session data by groups. Refer to <a href="#">Monitoring Sessions REST API</a> .
	Added support for resting all unhealthy ports at once. Refer to <a href="#">Mark All Unhealthy Ports as Healthy at Once</a>
	Added support for presenting system uptime in UFM REST API. Refer to <a href="#">Systems REST API</a> .
Deployment Installation	UFM installation is now based on Conda-4.12 (or newer) for python3.9 environment and third party packages deployments.
NVIDIA SHARP Software	Updated NVIDIA SHARP software version to v3.1.1.
UFM Logical Elements	UFM Logical Elements (Environments, Logical Servers, Networks) views are deprecated and will no longer be available starting from UFM v6.12.0 (January 2023 release)
Rev 6.10.0	
System health enhancements	Add support for the periodic fabric health report, and reflected the ports' results in UFM's dashboard

Feature	Description
UFM Plugins Management	Add support for plugin management via UFM web UI
UFM Extended Status	<ul style="list-style-type: none"> <li>Add support for showing UFM's current processes status (via shell script)</li> <li>Added REST API for exposing UFM readiness</li> </ul>
Failover to Other Ports	Add support for SM and UFM Telemetry failover to other ports on the local machine
UFM Appliance Upgrade	Added a set of REST APIs for supporting the UFM Appliance upgrade
Configuration Audit	Add support for tracking changes made in major UFM configuration files (UFM, SM, SHARP, Telemetry)
UFM Plugins	Add support for new SDK plugins
Telemetry	Add support for statistics processing based on UFM telemetry csv format
UFM High Availability Installation	UFM high availability installation has changed and it is now based on an independent high availability package which should be deployed in addition to the UFM Enterprise standalone package. for further details about the new UFM high availability installation, please refer to - <a href="#">Installing UFM Server Software for High Availability</a>

## Bug Fixes History

Ref. #	Description
Rev 6.17.0	
391 241 6	Description: Fixed issue with the authentication server being repeatedly restarted by the UFM health check after the default admin password is changed
	Keywords: Authentication, Server, Disable
	Discovered in Release: v6.17.0
386 395 8	Description: Fixed issue where IB-IB go to INIT states due to failed UFM failover after enabling SHARP with PKeys

Ref. #	Description
	Keywords: SHARP, PKey, IB-IB Link, Failover
	Discovered in Release: v6.16.0
3850673	Description: Fixed issue where multiple ports go down simultaneously (link-downed counter increment)
	Keywords: Ports, down, simultaneous
	Discovered in Release: v6.15.1
3850217	Description: Fixed issues with ALM plugin (disabled handling topology changes and limited the number of trials of creating dynamic telemetry sessions by configurable variables)
	Keywords: ALM Plugin
	Discovered in Release: v6.15.0
3826544	Description: Fixed node info discovery issue
	Keywords: Node, Info, Discovery
	Discovered in Release: v6.16.0
3826069	Description: Fixed HCA port naming convention inconsistencies in UFM WebUI
	Keywords: HCA port, Port name, WebUI
	Discovered in Release: v6.15.2
3816196	Description: Fixed issue where UFM creates empty PKeys by UFM Rest API
	Keywords: Empty, PKey, REST API
	Discovered in Release: v6.15.2
3811475	Description: Fixed issue where UFM loggings REST API omits additional contents of the log when it spans over multiple lines
	Keywords: UFM Loggings, REST API, Span over, Multiple Lines
	Discovered in Release: v6.15.3
3803527	Description: Fixed issue with Create History REST API while collecting SM Logs Error
	Keywords: Create History, SM Log Error
	Discovered in Release: v6.15.3

Ref. #	Description
375 219 6	Description: Fixed intermittent UFM REST API Failures
	Keywords: UFM REST API, Failures
	Discovered in Release: v6.16.0
386 487 6	Description: Fixed issue with UFM events not appearing in remote syslog
	Keywords: UFM Events, Remote syslog
	Discovered in Release: v6.15.1
380 957 4:	Description: Fixed WebUI issues in the "Power" column
	Keywords: WebUI, Power
	Discovered in Release: v6.16.0
376 607 9	Description: Fixed issue with UFM not showing SSH user/pass tab
	Keywords: SSH, User/Pass Tab
	Discovered in Release: v6.15.0
391 665 6	Description: Fixed issue with releasing lock without acquiring when handling MC join requests from unknown source.
	Keywords: MC, lock
	Discovered in Release: v6.17.0
Rev 6.16.0	
375 494 0	Description: Fixed issue where following the UFM HA upgrade from version 5.0.1-2 to version 5.3.1-2, the ufm_ha_cluster config command wiped the root partition
	Keywords: UFM HA Upgrade, ufm_ha_cluster config, Root Partition, Wipe
	Discovered in Release: 6.15.2
375 219 6	Description: Fixed intermittent UFM REST API Failures
	Keywords: REST API, Failure
	Discovered in Release: 6.15.1
375 887 4	Description: Fixed manage_the_unmanaged tool failure
	Keywords: manage_the_unmanaged, Failure
	Discovered in Release: 6.15.2

Ref. #	Description
377 390 2	Description: Fixed the issue in congestion control, where cc-policy.conf file remains unchanged following the upgrade of the container version ( with no changes made by the user)
	Keywords: Congestion Control, cc-policy.conf, Upgrade, Container
	Discovered in Release: 6.16.0-4
Rev 6.15.1	
367 018 3	<b>Description:</b> Monitoring endpoint not returning counters for an active interface
	<b>Keywords:</b> Monitoring, Active Interface, Counters
	<b>Discovered in release:</b> v6.15.0
367 018 2	<b>Description:</b> Inconsistent port format type returned from the UFM
	<b>Keywords:</b> Inconsistent, Port, Format Type
	<b>Discovered in release:</b> v6.14.1
366 694 4	<b>Description:</b> Port auto isolation failed to activate when a port consistently exhibited a high Symbol BER (1e-7)
	<b>Keywords:</b> Port Auto Isolation, Symbol BER
	<b>Discovered in release:</b> v6.13.1
366 531 6	<b>Description:</b> The UFM REST API endpoint /ufmRest/resources/ports provide inaccurate port state information
	<b>Keywords:</b> Ports REST API, Port State
	<b>Discovered in release:</b> v6.14.1
360 419 4	<b>Description:</b> UFM Fabric Validation "CheckPortCounters" failure
	<b>Keywords:</b> Fabric Validation, CheckPortCounters
	<b>Discovered in release:</b> v6.13.2
Rev 6.15.0	
366 500 1	<b>Description:</b> UFM Web UI does not display Network Map (stuck with "please wait" message)
	<b>Keywords:</b> Web UI, Network Map
	<b>Discovered in release:</b> v6.14.1

Ref. #	Description
364 455 3	<b>Description:</b> When querying the ports, adding a cable_info=true as an argument will give cable information per port
	<b>Keywords:</b> Ports, Query, cable_info=true
	<b>Discovered in release:</b> v6.14.0
360 421 2	<b>Description:</b> Broken links REST API
	<b>Keywords:</b> REST API, Broken link
	<b>Discovered in release:</b> v6.13.2
360 418 3	<b>Description:</b> UFM error UFM NOT performed OpenSM polling for fabric changes more than 230742 seconds
	<b>Keywords:</b> OpenSM, UFM Error
	<b>Discovered in release:</b> v6.13.2-5
360 402 1	<b>Description:</b> UFM Enterprise installation under Ubuntu 22.04 fails on configure_ha_nodes.sh
	<b>Keywords:</b> Ubuntu 22.04, Installation, configure_ha_nodes.sh
	<b>Discovered in release:</b> v6.14.1-5
358 784 9	<b>Description:</b> OpenSM restarted when backup UFM lost power
	<b>Keywords:</b> OpenSM, Restart
	<b>Discovered in release:</b> v6.9
357 742 7	<b>Description:</b> UFM REST API returns wrong switch type for NDR unmanaged switch
	<b>Keywords:</b> Unmanaged Switch, NDR, REST API
	<b>Discovered in release:</b> v6.13.1
357 588 2	<b>Description:</b> UFM event is not generated for a switch down
	<b>Keywords:</b> UFM Event, Switch Down
	<b>Discovered in release:</b> v6.13.1
362 842 1	<b>Description:</b> UFM Web UI timezone issue when selecting Local Time
	<b>Keywords:</b> Timezone, Web UI, Local Time
	<b>Discovered in release:</b> v6.14.1-5

Ref. #	Description
356 619 3	<b>Description:</b> Request for docker UFM HA support on Debian OS 10.13
	<b>Keywords:</b> Docker, HA support, Debian
	<b>Discovered in release:</b> v6.14.1-5
356 582 0	<b>Description:</b> UFM container CLI bugs
	<b>Keywords:</b> CLI, Container
	<b>Discovered in release:</b> v6.13.2-5
Rev 6.14.0	
359 077 7	<b>Description:</b> After upgrading UFM new telemetry data is not being collected and presented in UI Telemetry tab.
	<b>Keywords:</b> Telemetry, Coredump
	<b>Discovered in release:</b> 6.14.0
Rev 6.13.2	
322 889 3	Description: ufm-prolog.sh failure: hostnames are not found in the fabric after reboot
	Keywords: Hostnames; ufm-prolog.sh, reboot
	Discovered in Release: 6.10.0
349 569 2	Description: UFM Enterprise v6.13.1 server hangs intermittently, blocking UFM REST server, and UFM GUI
	Keywords: UFM REST, UFM GUI
	Discovered in Release: 6.13.1
N/A	Description: Reverted setGuidsForPkey APIs for supporting SHARP reservation (in case it is enabled)
	Keywords: setGuidsForPkey, SHARP Reservation
	Discovered in Release: 6.13.1
<b>Rev 6.13.1</b>	
345 943 1	Description: UFM System Dump cannot be extracted from UFM 3.0 Enterprise Appliance host when running in high-availability mode.
	Keywords: System Dump, High-Availability
	Discovered in Release: 6.12.0

Ref. #	Description
346 165 8	Description: The network fast recovery configuration (/opt/ufm/files/conf/opensm/fast_recovery.conf) is missing when UFM is deployed in Docker Container mode.
	Keywords: Network Fast Recovery; Docket Container; Missing Configuration
	Discovered in Release: 6.12.0
346 105 8	Description: When using the Dynamic Telemetry API to create a new telemetry instance, the log rotation mechanism will not be applied for the newly generated logs of the UFM Telemetry instance
	Keywords: Dynamic, Telemetry, Log-rotate
	Discovered in Release: 6.13.0

## Known Issues History

Ref #	Issue
Rev 6.17.0	
38593 62	<b>Description:</b> UFM TFS endpoint dashboard report Switch port TX/RX rate reach Tbps
	<b>Keywords:</b> TFS, Switch Port, TX/RX
	<b>Workaround:</b> N/A
	<b>Discovered in Release:</b> v6.15.1
38813 65	<b>Description:</b> Malfunctioning of the rest API when deleting port associated to a pkey
	<b>Keywords:</b> CloudX, API, Bare-Metal
	<b>Workaround:</b> N/A
	<b>Discovered in Release:</b> v6.15.2
38628 47	<b>Description:</b> UFM reports wrong cable length for NDR optical cables connected to Quantum-2 NDR switch
	<b>Keywords:</b> NDR, Optical Cables, Quantum-2, Switch
	<b>Workaround:</b> N/A
	<b>Discovered in Release:</b> v6.17.0

Ref #	Issue
Rev 6.16.0	
37918 20	<p><b>Description:</b> Configuring the collection of SLVL on the secondary telemetry will result in SLVL data being sampled at a reduced rate.</p>
	<p><b>Keywords:</b> SLVL, Multi-Rate, Reduced Rate</p>
	<p><b>Workaround:</b> Edit the launch_ibdiagnet_config.ini file and restart the UFM telemetry.</p> <p>1. Edit the launch_ibdiagnet_config.ini file by running the following command:</p> <pre data-bbox="362 558 1463 814">vi /opt/ufm/files/conf/secondary_telemetry_defaults/launch_ibdiagnet_config.ini</pre> <p>Comment the following line:</p> <pre data-bbox="362 852 1463 1010">#base_freq=1</pre> <p>2. Restart UFM telemetry:</p> <pre data-bbox="362 1052 1463 1262">/etc/init.d/ufmd ufm_telemetry_stop /etc/init.d/ufmd ufm_telemetry_start</pre>
	<p><b>Discovered in Release:</b> 6.15.0</p>
37754 05	<p><b>Description:</b> Upon UFM startup, an empty temporary folder will be created at /tmp folder every 10 minutes (due to periodic telemetry status check)</p>
	<p><b>Keywords:</b> Empty folder, temporary, /tmp</p>
	<p><b>Workaround:</b> Add 'rm -f /tmp/tmp*' to crontab to run daily or change instances_sessions_compatibility_interval parameter in gv.cfg to 30/60 minutes</p>
<p><b>Discovered in Release:</b> v6.15.0</p>	
35606 59	<p><b>Description:</b> Modifying the mtu_limit parameter for [MngNetwork] in gv.cfg does not accurately reflect changes upon restarting UFM.</p>
	<p><b>Keywords:</b> mtu_limit, MngNetwork, gv.cfg, UFM restart</p>
	<p><b>Workaround:</b> UFM needs to be restarted twice in order for the changes to take</p>

Ref #	Issue
	effect.
	<b>Discovered in Release:</b> v6.15.0
37298 22	<b>Description:</b> The Logs API temporarily returns an empty response when SM log file contains messages from both previous year (2023) and current year (2024).
	<b>Keywords:</b> Logs API, Empty response, Logs file
	<b>Workaround:</b> N/A (issue will be automatically resolved after the problematic SM log file, which include messages from 2023 and 2024 years, will be rotated)
	<b>Discovered in Release:</b> v6.15.0
36750 71	<b>Description:</b> UFM stops gracefully after the b2b primary cable is physically disconnected
	<b>Keywords:</b> UFM HA, B2B, Primary Cable Disconnection
	<b>Workaround:</b> N/A
	<b>Discovered in Release:</b> 6.14.1
N/A	<b>Description:</b> Execution of UFM Fabric Health Report (via UFM Web UI / REST API) will trigger ibdiagnet to use SLRG register which might cause some of the switch and HCA's firmware to stuck and cause the HCA's ports to stay at "Init" state.
	<b>Keywords:</b> Fabric Health Report, SLRG register, "Init" state, Switch, HCA
	<b>Discovered in Release:</b> 6.14.0
35386 40	<b>Description:</b> Fixed ALM plugin log rotate function.
	<b>Keywords:</b> ALM, Plugin, Log rotate
	<b>Discovered in Release:</b> 6.13.0
35321 91	<b>Description:</b> Fixed UFM hanging (database is locked) after corrective restart of UFM health.
	<b>Keywords:</b> Hanging, Database, Locked
	<b>Discovered in Release:</b> 6.13.0
35555 83	<b>Description:</b> Resolved REST API links' inability to return hostname for computer nodes.
	<b>Keywords:</b> REST API, Links, Hostname, Computer Nodes
	<b>Discovered in Release:</b> 6.12.1

Ref #	Issue
35497 95	<b>Description:</b> Fixed ufm_ha_cluster status to show DRBD sync status.
	<b>Keywords:</b> ufm_ha_cluster, DRBD, Sync Status
	<b>Discovered in Release:</b> 6.13.0
35497 93	<b>Description:</b> Fixed UFM HA installation failure.
	<b>Keywords:</b> HA, Installation
	<b>Discovered in Release:</b> 6.13.0
35475 17	<b>Description:</b> Fixed UFM logs REST API returning empty result when SM logs exist on the disk.
	<b>Keywords:</b> Logs, SM logs, Empty
	<b>Discovered in Release:</b> 6.11.0
35461 78	<b>Description:</b> Fixed SHARP jobs failure when SHARP reservation feature is enabled.
	<b>Keywords:</b> SHARP, Jobs, Reservation
	<b>Discovered in Release:</b> 6.13.0
35414 77	<b>Description:</b> Fixed UFM module temperature alerting on wrong thresholds.
	<b>Keywords:</b> Module Temperature, Alert Threshold
	<b>Discovered in Release:</b> 6.13.0
31914 19	<b>Description:</b> Fixed UFM default session API returning port counter values as NULL.
	<b>Keywords:</b> Null, Port Counter, Value, API
	<b>Discovered in Release:</b> 6.9.0
35606 59	<b>Description:</b> Fixed proper update in [MngNetwork] mtu_limit in gv.cfg when restarting UFM.
	<b>Keywords:</b> mtu_limit, gv.cfg, Update, UFM restart
	<b>Discovered in Release:</b> 6.13.1
35343 74	<b>Description:</b> Fixed configure_ha_nodes.sh failure when deploying UFM6.13.x HA on Ubuntu22.04.
	<b>Keywords:</b> configure_ha_nodes.sh, HA, Ubuntu22.04
	<b>Discovered in Release:</b> 6.13.0

Ref #	Issue
34968 53	<b>Description:</b> Fixed daily report not being sent properly.
	<b>Keywords:</b> Daily Report, Failure
	<b>Discovered in Release:</b> 6.13.0
34696 39	<b>Description:</b> Fixed REST RDMA server failure every couple of days, causing inability to retrieve ibdiagnet data.
	<b>Keywords:</b> REST RDMA, ibdiagnet
	<b>Discovered in Release:</b> 6.12.0
34557 67	<b>Description:</b> Fixed incorrect combination of multiple devices in monitoring.
	<b>Keywords:</b> Monitoring, Incorrect combination
	<b>Discovered in Release:</b> 6.12.0
35114 10	<b>Description:</b> Collect system dump for DGX host does not work due to missing sshpass utility.
	<b>Workaround:</b> Install sshpass utility on the DGX.
	<b>Keywords:</b> System Dump, DGX, sshpass utility
34323 85	<b>Description:</b> UFM does not support HDR switch configured with hybrid split mode, where some of the ports are split and some are not.
	<b>Workaround:</b> UFM can properly operate when <b>all</b> or <b>none</b> of the HDR switch ports are configured as split.
	<b>Keywords:</b> HDR Switch, Ports, Hybrid Split Mode
34723 30	<b>Description:</b> On bare-metal high availability (HA), when initiating a UFM system dump from either the master or standby node, the collection process will not include the HA dumps (pacemaker and DRBD).
	<b>Workaround:</b> To extract the HA system dump from bare-metal, run the following command from the master/standby nodes:
	<pre>/usr/bin/vsysinfo -S all -e -f /etc/ufm/ufm-ha-sysdump.conf -O /tmp/HA_sysdump</pre>
	The extracted HA system dump are stored in /tmp/HA_sysdump.gz.tar
	<b>Keywords:</b> UFM System Dump, HA, Bare-Metal
34616 58	<b>Description:</b> After the upgrade from UFM Enterprise v6.13.0 GA to UFM Enterprise v6.13.1 FUR, the network fast recovery path in opensm.conf is not

Ref #	Issue
	<p>automatically updated and remains with a null value (fast_recovery_conf_file (null))</p> <p><b>Workaround:</b> If you wish to enable the network fast recovery feature in UFM, make sure to set the appropriate path for the current fast recovery configuration file (/opt/ufm/files/conf/opensm/fast_recovery.conf) in the opensm.conf file located at /opt/ufm/files/conf/opensm, before starting UFM.</p> <p><b>Keywords:</b> Network fast recovery, Missing, Configuration</p>
N/A	<p><b>Description:</b> Enabling a port for a managed switch fails in case that port is not disabled in a persistent way (this may occur in ports that were disabled on previous versions of UFM - prior to UFM v6.12.0)</p> <p><b>Workaround:</b> Set "persistent_port_operation=false" in gv.cfg to use non-persistent (legacy) disabling or enabling of the port. UFM restart is required.</p> <p><b>Keywords:</b> Disable, Enable, Port, Persistent</p>
33463 21	<p><b>Description:</b> Failover to another port (multi-port SM) will not work as expected in case UFM was deployed as a docker container</p> <p><b>Workaround:</b> Failover to another port (multi-port SM) works properly on UFM Bare-metal deployments</p> <p><b>Keywords:</b> Failover to another port, Multi-port SM</p>
33485 87	<p><b>Description:</b> Replacement of defected nodes in the HA cluster does not work when PCS version is 0.9.x</p> <p><b>Workaround:</b> N/A</p> <p><b>Keywords:</b> Defected Node, HA Cluster, pcs version</p>
33367 69	<p><b>Description:</b> UFM-HA: In case the back-to-back interface is disabled or disconnected, the HA cluster will enter a split-brain state, and the "ufm_ha_cluster status" command will stop functioning properly.</p> <p><b>Workaround:</b> To resolve the issue:</p> <ol style="list-style-type: none"> <li>1. Connect or enable the back-to-back interface</li> <li>2. Run <div data-bbox="360 1602 1463 1759" style="border: 1px solid #ccc; padding: 10px; margin: 10px 0;"> <pre>pcs cluster start --all</pre> </div> </li> <li>3. Follow instructions in <a href="#">Split-Brain Recovery in HA Installation</a>.</li> </ol> <p><b>Keywords:</b> HA, Back-to-back Interface</p>

Ref #	Issue
33611 60	<b>Description:</b> Upgrading UFM Enterprise from versions 6.8.0, 6.9.0 and 6.10.0 results in cleanup of UFM historical telemetry database (due to schema change). This means that the new telemetry data will be stored based on the new schema.
	<b>Workaround:</b> To preserve the historical telemetry database data while upgrading from UFM version 6.8.0, 6.9.0 and 6.10.0, perform the upgrade in two phases. First, upgrade to UFM v6.11.0, and then upgrade to the latest UFM version (UFM v6.12.0 or newer). It is important to note that the upgrade process may take longer depending on the size of the historical telemetry database.
	<b>Keywords:</b> UFM Historical Telemetry Database, Cleanup, Upgrade
33463 21	<b>Description:</b> In some cases, when multiport SM is configured in UFM, a failover to the secondary node might be triggered instead of failover to the local available port
	<b>Workaround:</b> N/A
	<b>Keywords:</b> Multiport SM, Failover, Secondary port
32406 64	<b>Description:</b> This software release does not support upgrading the UFM Enterprise version from the latest GA version (v6.11.0). UFM upgrade is supported in UFM Enterprise v6.9.0 and v6.10.0.
	<b>Workaround:</b> N/A
	<b>Keywords:</b> UFM Upgrade
32423 32	<b>Description:</b> Upgrading MLNX_OFED uninstalls UFM
	<b>Workaround:</b> Upgrade UFM to a newer version (v6.11.0 or newer), then upgrade MLNX_OFED
	<b>Keywords:</b> MLNX_OFED, Uninstall, UFM
32373 53	<b>Description:</b> Upgrading from UFM v6.10 removes MLNX_OFED crucial packages
	<b>Workaround:</b> Reinstall MLNX_OFED/UFM
	<b>Keywords:</b> MLNX_OFED, Upgrade, Packages
N/A	<b>Description:</b> Running UFM software with external UFM-SM is no longer supported
	<b>Workaround:</b> N/A
	<b>Keywords:</b> External UFM-SM
31447 32	<b>Description:</b> By default, a managed Ubuntu 22 host will not be able to send system dump (sysdump) to a remote host as it does not include the sshpass

Ref #	Issue
	<p>utility.</p> <p><b>Workaround:</b> In order to allow the UFM to generate system dump from a managed Ubuntu 22 host, install the sshpass utility prior to system dump generation.</p> <p><b>Keywords:</b> Ubuntu 22, sysdump, sshpass</p>
31294 90	<p><b>Description:</b> HA uninstall procedure might get stuck on Ubuntu 20.04 due to multipath daemon running on the host.</p> <p><b>Workaround:</b> Stop the multipath daemon before running the HA uninstall script on Ubuntu 20.04.</p> <p><b>Keywords:</b> HA uninstall, multipath daemon, Ubuntu 20.04</p>
31471 96	<p><b>Description:</b> Running the upgrade procedure on bare metal Ubuntu 18.04 in HA mode might fail.</p> <p><b>Workaround:</b> For instructions on how to apply the upgrade for bare metal Ubuntu 18.04, refer to <a href="#">High Availability Upgrade for Ubuntu 18.04</a> .</p> <p><b>Keywords:</b> Upgrade, Ubuntu 18.04, Docker Container, failure</p>
31450 58	<p><b>Description:</b> Running upgrade procedure on UFM Docker Container in HA mode might fail.</p> <p><b>Workaround:</b> For instructions on how to apply the upgrade for UFM Docker Container in HA, refer to Upgrade Container Procedure.</p> <p><b>Keywords:</b> Upgrade, Docker Container, failure</p>
30614 49	<p><b>Description:</b> Upon upgrade of UFM all telemetry configurations will be overridden with the new telemetry configuration of the new UFM version.</p> <p><b>Workaround:</b> If the telemetry configuration is set manually, the user should set up the configuration after upgrading the UFM for the changes to take effect. Telemetry manual configuration should be set on the following telemetry configuration file right after UFM upgrade: /opt/ufm/conf/telemetry_defaults/launch_ibdiagnet_config.ini.</p> <p><b>Keywords:</b> Telemetry, configuration, upgrade, override.</p>
30534 55	<p><b>Description:</b> UFM “Set Node Description” action for unmanaged switches is not supported for Ubuntu18 deployments</p> <p><b>Workaround:</b> N/A</p> <p><b>Keywords:</b> Set Node Description, Ubuntu18</p>


Ref #	Issue
30534 55	<b>Description:</b> UFM Installations are not supported on RHEL8.X or CentOS8.X
	<b>Workaround:</b> N/A
	<b>Keywords:</b> Install, RHEL8, CentOS8
30526 60	<b>Description:</b> UFM monitoring mode is not working
	<b>Workaround:</b> In order to make UFM work in monitoring mode, please edit telemetry configuration file: /opt/ufm/conf/telemetry_defaults/launch_ibdiagnet_config.ini Search for arg_12 and set empty value: arg_12= Restarting the UFM will run the UFM in monitoring mode. Before starting the UFM make sure to set: monitoring_mode = yes in gv.cfg
	<b>Keywords:</b> Monitoring, mode
30543 40	<b>Description:</b> Setting non-existing log directory will fail UFM to start
	<b>Workaround:</b> Make sure to set a valid (existing) log directory when setting this parameter (gv.cfgàlog_dir)
	<b>Keywords:</b> Log, Dir, fail, start

# UFM Overview

## Scale-Out Your Fabric with Unified Fabric Manager

NVIDIA®UFM is a host-based solution that provides all the management functionalities required for managing fabrics.

### *Fabric Topology with UFM*



**UFM Server** is a server on which UFM is installed and has complete visibility over the fabric to manage routing on all devices.

**UFM HA Server** is a UFM installed server on a secondary server for High Availability deployment.

**Managed Switching Devices** are fabric switches, gateways, and routers managed by UFM.

**Managed Servers** are the compute nodes in the fabric on which the various applications are running, and UFM manages all servers connected to the fabric.

**UFM Host Agent** is an optional component that can be installed on the Managed Servers. UFM Host Agent provides local host data and host device management functionality.

The UFM Host Agent provides the following functionality:

- Discovery of IP address, CPU, and memory parameters on host
- Collection of CPU/Memory/Disk performance statistics on host
- Upgrading HCA Firmware and OFED remotely
- Creating an IP interface on top of the InfiniBand partition

**UFM Switch Agent** is an embedded component in NVIDIA switches that allows IP address discovery on the switch and allows UFM to communicate with the switch. For more information, please refer to [Device Management Feature Support](#).

## UFM Benefits

Benefit	Description
<b>Central Console for Fabric Management</b>	UFM provides all fabric management functions in one central console. The ability to monitor, troubleshoot, configure and optimize all fabric aspects is available via one interface. UFM's central dashboard provides a one-view fabric-wide status view.
<b>In-Depth Fabric Visibility and Control</b>	UFM includes an advanced granular monitoring engine that provides real-time access to switch and host data, enabling cluster-wide monitoring of fabric health and performance, real-time identification of fabric-related errors and failures, quick problem resolution via granular threshold-based alerts and a fabric utilization dashboard.
<b>Advanced Traffic Analysis</b>	Fabric congestion is difficult to detect when using traditional management tools, resulting in unnoticed congestion and fabric under-utilization. UFM's unique traffic map quickly identifies traffic trends, traffic bottlenecks, and congestion events spreading over the fabric, which enables the administrator to identify and resolve problems promptly and accurately.
<b>Enables Multiple Isolated</b>	Consolidating multiple clusters into a single environment with multi-tenant data centers and heterogeneous application landscapes requires specific policies for the different parts of the fabric. UFM enables segmentation of

Benefit	Description
<b>Application Environments on a Shared Fabric</b>	the fabric into isolated partitions, increasing traffic security and application performance.
<b>Service-Oriented Automatic Resource Provisioning</b>	UFM uses a logical fabric model to manage the fabric as a set of business-related entities, such as time critical applications or services. The logical fabric model enables fabric monitoring and performance optimization on the application level rather than just at the individual port or device level. Managing the fabric using the logical fabric model provides improved visibility into fabric performance and potential bottlenecks, improved performance due to application-centric optimizations, quicker troubleshooting and higher fabric utilization.
<b>Quick Resolution of Fabric Problems</b>	UFM provides comprehensive information from switches and hosts, showing errors and traffic issues such as congestion. The information is presented in a concise manner over a unified dashboard and configurable monitoring sessions. The monitored data can be correlated per job and customer, and threshold-based alarms can be set.
<b>Seamless Failover Handling</b>	Failovers are handled seamlessly and are transparent to both the user and the applications running on the fabric, significantly lowering downtime. The seamless failover makes UFM in conjunction with other Mellanox products, a robust, production-ready solution for the most demanding data center environments.
<b>Open Architecture</b>	UFM provides an advanced Web Service interface and CLI that integrate with external management tools. The combination enables data center administrators to consolidate management dashboards while flawlessly sharing information among the various management applications, synchronizing overall resource scheduling, and simplifying provisioning and administration.

## Main Functionality Modules

Module	Description
Fabric Dashboard	UFM's central dashboard provides a one-view fabric-wide status view. The dashboard shows fabric utilization status, performance metrics, fabric-wide events, and fabric health alerts.

Module	Description
	The dashboard enables you to efficiently monitor the fabric from a single screen and serves as a starting point for event or metric exploration.
Fabric Segmentation (PKey Management)	In the PKey Management view you can define and configure the segmentation of the fabric by associating ports to specific defined PKeys. You can add, remove, or update the association of ports to the related PKeys and update the qos_parameters for PKey (mtu, rate, service_level).
Fabric Discovery and Physical View	UFM discovers the devices on the fabric and populates the views with the discovered entities. In the physical view of the fabric, you can view the physical fabric topology, model the data center floor, and manage all the physical-oriented events.
Central Device Management	UFM provides the ability to centrally access switches and hosts, and perform maintenance tasks such as firmware and software upgrade, shutdown and restart.
Monitoring	UFM includes an advanced granular monitoring engine that provides real-time access to switch and server data. Fabric and device health, traffic information and fabric utilization are collected, aggregated and turned into meaningful information.
Configuration	In-depth fabric configuration can be performed from the Settings view, such as routing algorithm selection and access credentials. The Event Policy Table, one of the major components of the Configuration view, enables you to define threshold-based alerts on a variety of counters and fabric events. The fabric administrator or recipient of the alerts can quickly identify potential errors and failures, and actively act to solve them.
Fabric Health	The fabric health tab contains valuable functions for fabric bring-up and on-going fabric operations. It includes one-click fabric health status reporting, UFM Server reporting, database and logs' snapshots and more.
Logging	The Logging view enables you to view detailed logs and alarms that are filtered and sorted by category, providing visibility into traffic and device events as well as into UFM server activity history.
High Availability	In the event of a failover, when the primary (active) UFM server goes down or is disconnected from the fabric, UFM's High Availability (HA) capability allows for a secondary (standby) UFM server to immediately and seamlessly take over fabric management tasks. Failovers are handled seamlessly and are transparent to

Module	Description
	both the user and the applications running in the fabric. UFM's High Availability capability, when combined with NVIDIA's High Availability switching solutions allows for non-disruptive operation of complex and demanding data center environments.

Please refer to the following sections for UFM's main functionalities:

- [Events and Alarms](#)
- [Reports](#)
- [Telemetry](#)


## UFM Communication Requirements

This chapter describes how the UFM server communicates with InfiniBand fabric components.

### UFM Server Communication with Clients

The UFM Server communicates with clients over IP. The UFM Server can belong to a separate IP network, which can also be behind the firewall.

#### ***UFM Server Communication with Clients***



## UFM Server Communication with UFM Web UI Client

Communication between the UFM Server and the UFM web UI client is HTTP(s) based. The only requirement is that TCP port 80 (443) must not be blocked.

## UFM Server Communication with SNMP Trap Managers

The UFM Server can send SNMP traps to configured SNMP Trap Manager(s). By default, the traps are sent to the standard UDP port 162. However, the user can configure the destination port. If the specified port is blocked, UFM Server traps will not reach their destination.


## Summary of UFM Server Communication with Clients

Affected Service	Network	Address / Service / Port	Direction
Web UI Client	Out-of-band management*	HTTP / 80 HTTPS / 443	Bi-directional
SNMP Trap Notification	Out-of-band management*	UDP / 162 (configurable)	UFM Server to SNMP Manager

\*If the client machine is connected to the IB fabric, IPoIB can also be used.

## UFM Server Communication with InfiniBand Switches

### *UFM Server Communication with InfiniBand Switches*



## UFM Server InfiniBand Communication with Switch

The UFM Server must be connected directly to the InfiniBand fabric (via an InfiniBand switch). The UFM Server sends the standard InfiniBand Management Datagrams (MAD) to the switch and receives InfiniBand traps in response.

## UFM Server Communication with Switch Management Software (Optional)

The UFM Server auto-negotiates with the switch management software on Mellanox Grid Director switches. The communication is bound to the switch Ethernet management port.

The UFM Server sends a multicast notification to MCast address 224.0.23.172, port 6306 (configurable). The switch management replies to UFM (via port 6306) with a unicast message that contains the switch GUID and IP address. After auto-negotiation, the UFM server uses Switch JSON API (HTTPS based) to retrieve inventory data and to apply switch actions (software upgrade and reboot) on the managed switch.

The following Device Management tasks are dependent on successful communication as described above:

- Switch IP discovery
- FRU Discovery (PSU, FAN, status, temperature)

- Software and firmware upgrades

The UFM Server manages IB Switch Devices over **HTTPS** (default port **443** – configurable) and / or SSH (default port 22 – configurable).

## UFM Server Communication with Externally Managed Switches (Optional)

UFM server uses lbdagnet tool to discover chassis information (PSU, FAN, status, temperature) of the externally managed switches.


By monitoring chassis information data, UFM can trigger selected events when module failure occurs or a specific sensor value is above threshold.

## Summary of UFM Server Communication with InfiniBand Switches

Affected Service	Network	Address / Service / Port	Direction
InfiniBand Management / Monitoring	InfiniBand	Management Datagrams	Bi-directional
Switch IP Address Discovery (auto-negotiation with switch management software)	Out-of-band management	Multicast 224.0.23.172, TCP / 6306 (configurable)	Multicast: UFM Server to switch TCP: Bi-directional
Switch Chassis Management / Monitoring	Out-of-band management	TCP / UDP / 6306 (configurable) SNMP / 161 (configurable) SSH / 22 (configurable)	Bi-directional

# UFM Server Communication with InfiniBand Hosts

## UFM Server Communication with InfiniBand Hosts



# UFM Server InfiniBand Communication with HCAs


The UFM Server must be connected directly to the InfiniBand fabric. The UFM Server sends the standard InfiniBand Management Datagrams (MADs) to the Host Card Adapters (HCAs) and receives InfiniBand traps.

# UFM Server Communication with InfiniBand Hosts

Affected Service	Network	Address / Service / Port	Direction
InfiniBand Management / Monitoring	InfiniBand	Management Datagrams	Bi-directional

# UFM Server High Availability (HA) Active—Standby Communication

## UFM Server HA Active—Standby Communication



## UFM Server HA Active—Standby Communication

UFM Active — Standby communication enables two services: heartbeat and DRBD.

- *heartbeat* is used for auto-negotiation and keep-alive messaging between active and standby servers. *heartbeat* uses port 694 (udp).
- DRBD is used for low-level data (disk) synchronization between active and standby servers. DRBD uses port 8888 (tcp).


Affected Service	Network	Address / Service / Port	Direction
UFM HA heartbeat	Out-of-band management*	UDP / 694	Bi-directional
UFM HA DRBD	Out-of-band management*	TCP / 8888	Bi-directional

\*An IPoIB network can be used for HA, but this is not recommended, since any InfiniBand failure might cause split brain and lack of synchronization between the active and standby servers.

## UFM Software Architecture

The following figure shows the UFM high-level software architecture with the main software components and protocols. Only the main logical functional blocks are displayed and do not necessarily correspond to system processes and threads.

### ***UFM High-Level Software Architecture***



## Graphical User Interface

UFM User Interface is a web application based on JavaScript and Angular JS, which is supported by any Web Browser. The Web application uses a standard REST API provided by the UFM server.

## Client Tier API

Third-party clients are managed by the REST API.

## Client Tier SDK Tools

Support for UFM's API and a set of tools that enhance UFM functionality and interoperability with third-party applications are provided as part of UFM.

## UFM Server

UFM server is a central data repository and management server that manages all physical and logical data. UFM-SDN Appliance receives all data from the Device and Network tiers and invokes Device and Network tier components for management and configuration

tasks. UFM-SDN Appliance uses a database for data persistency. The UFM-SDN Appliance is built on the Python twisted framework.

## **Subnet Manager**

Subnet Manager (SM) is the InfiniBand “Routing Engine”, a key component used for fabric bring-up and routing management. UFM uses the Open Fabric community OpenSM Subnet Manager. UFM uses a plug-in API for runtime management and fabric data export.

## **NVIDIA Scalable Hierarchical Aggregation and Reduction Protocol (SHARP)™ Aggregation Manager**

NVIDIA Scalable Hierarchical Aggregation and Reduction Protocol (SHARP) is a technology that improves the performance of mathematical and machine learning applications by offloading collective operations from the CPU to the switch network.

Aggregation Manager (AM) is a key component of NVIDIA SHARP software, used for NVIDIA SHARP resources management.

For further information about NVIDIA SHARP AM, refer to [Appendix - NVIDIA SHARP Integration](#).

## **Performance Manager**

The UFM Performance Manager component collects performance data from the managed fabric devices and sends the data to the UFM-SDN Appliance for fabric-wide analysis and display of the data.

## **Device Manager**

The Device Manager implements the set of common device management tasks on various devices with varying management interfaces. The Device Manager uses SSH protocol and operates native device CLI (command-line interface) commands.

## **UFM Switch Agent**

UFM Switch Agent is an integrated part of NVIDIA switch software. The agent supports system parameter discovery and device management functionality on switches.

## **Communication Protocols**

UFM uses the following communication protocols:

- Web UI communicates with the UFM server utilizing **Web Services** carried on **REST API**.
- The UFM server communicates with the switch Agent located on managed switches by proprietary **TCP/UDP**-based discovery and monitoring protocol and **SSH**.
- Monitoring data is sent by the switch Agent to UFM server Listener by a proprietary **TCP**-based protocol.

## Getting Familiar with UFM's Data Model

### Overview of Data Model

UFM enables the fabric administrator to manage the fabric based on discovery data collected from the fabric. This data is mapped into model elements (objects) available to the end user via UFM REST API and UFM Web UI.

### UFM Model Basics

The fabric managed by UFM consists of a set of physical and logical objects, including their connections. The Object Model has a hierarchical object-oriented tree structure with objects as the tree elements. Each object defines an abstraction for physical or logical fabric elements.

### Physical Model

The Physical Model represents the physical resources and connectivity topology of the Network. UFM enables discovery, monitoring and configuration of the managed physical objects.

#### *Physical Objects*

Icon	Name	Description
N/A	Port Object	Represents the external physical port on switch or on Host Channel Adapter (HCA). A port is identified by its number. UFM provides InfiniBand standard management and monitoring capabilities on the port level.

Icon	Name	Description
N/A	Module Object	Represents the Field Removable Unit, Line card, and Network card on switch or HCA on host. For NVIDIA Switches, Line and Network Cards are modeled as modules.
	Link Object	Represents the physical connection between two active ports.
N/A	Cable Object	Represents the physical cable or the transceiver connected to one of the link edges.
	Computer Object	Represents the computer (host) connected to the Fabric. The UFM Agent installed on the host provides extended monitoring and management capabilities. Hosts without agents are limited to InfiniBand standard management and monitoring capabilities.
	Switch Object	Represents the switch chassis in the Fabric. A Switch object is created for every NVIDIA Switch. Switches of other vendors are represented as InfiniBand Switches and limited by InfiniBand standard management and monitoring capabilities.
	Rack Object	Represents the arbitrary group of switches or computers. When linked devices are shown as a group, the link is shown between the group and the peer object.

## UFM Web UI Overview

The UFM Web User Interface (GUI) lets you access UFM through a web browser, where you can visualize your network and interact with the display using a keyboard and mouse.

The UFM WebUI is supported on Google Chrome and TBD. It is designed to be viewed on a display with a minimum resolution of 1920 × 1080 pixels.

- [Access the WebUI](#)
- [WebUI Layout](#)
- [Set User Preferences](#)

## Access the WebUI

# UFM Web UI Supported Browsers

UFM Web UI is supported on all the following web browsers: Internet Explorer, Firefox, Chrome and Opera.

For optimal UFM Web UI performance, make sure you are using the latest version available of Google Chrome.

For more information, see *UFM User Manual*.

## Launching UFM Web UI Session

Before accessing the UFM Web UI:


- If required, you can change the configuration of the connection (port and protocol) between the UFM server and the APACHE server in the file *gv.cfg*:
  - *ws\_protocol* = http or https
    - Setting the parameter *ws\_protocol* to *http* allows unsecured access
    - Setting the parameter *ws\_protocol* to *https* denies unsecured access.
  - *ws\_port* = port number

**➤ To launch a UFM Web UI session, do the following:**

1. Launch the Web UI by entering the following URL in your browser:

**http://<UFM\_server\_IP>/ufm**

**https://<UFM\_server\_IP>/ufm**

The image shows the login interface for NVIDIA UFM. At the top, there is a black header with the NVIDIA logo (a green eye-like shape) on the left, the word "nVIDIA" in white, and "UFM" in white on the right. Below the header, there is a white login form with a thin grey border. Inside the form, there are two input fields: the first is labeled "Username" and the second is labeled "Password". Below these fields is a green button with the word "Login" in white text.

2. In the Login page, enter your **User Name** and your predefined user **Password** and click **Login**.


Once you have entered your user name and password, the main window shows the UFM Dashboard. For more information, see the [Fabric Dashboard](#).

## WebUI Layout

The UFM WebUI contains two main areas:

1. Top Bar - Contains local time zone and user information on the top right side of the screen.
2. Sidebar Menu - Contains a taskbar accessible from a sidebar menu on the left side of the screen. For more information on each tab, refer to [UFM Web UI](#).


## Sidebar Menu



## Top Bar

## Top Bar

Each user can customize the UFM display, time zone, and date format, change their account password, and manage their preferences. For details, refer to [Set User Preferences](#).



## Sidebar Menu

Tab Icon	Description
 <b>Dashboard</b>	Provides a summary view of the fabric status.
	Provides a hierarchical topology view of the fabric.


Tab Icon	Description
 Network Map	
 Managed Elements	Provides information on all fabric devices. This information is presented in a table format.
 Logical Elements	Provides information on all logical servers. This information is presented in a table format.
 Events & Alarms	Provides information on the events & alarms generated by the system.
 Telemetry	Enables establishing monitoring sessions on devices or ports.
 System Health	Enables running and viewing fabric reports, UFM reports, and system logs. You can also back up UFM configuration files.
 Jobs	Provides information on all jobs created, as a result of UFM actions.
 Settings	Enables configuring UFM server and UFM fabric settings, including events policy, device access, network management, subnet manager, and user management

## Set User Preferences


This section describes how to customize your UFM display settings and change your password,

### Dark/Light Theme

1. Select **Preferences**.




2. In **User Preferences**, enable dark mode for UFM presentation in a dark theme. The following figure shows the dark theme:



## Time Zone Converter

Allows you to unify all times in UFM like events and alarms, ibdiagnet, telemetry and logs. You can switch between local and machine time.

In the status bar drop-down menu, switch between local and server/machine time.



Events & Alarms Local Time Last Update: 09 Apr 2022 17:25 admin

Alarms

Clear All Alarms ↻ Displayed Columns CSV

Severity	Date/Time ↓	Alarm Name	Source	Source Type	Reason	Count
Minor	2022-04-09 17:25:09	Non-optimal ...	default(3) / Switch: r-hyp-sw-01 /	IBPort	Found a [25.0] link that operates in [14.0] speed mode.	1180
Minor	2022-04-09 17:25:09	Non-optimal ...	default(3) / Switch: SwitchIB Mell	IBPort	Found a [25.0] link that operates in [14.0] speed mode.	1180
Minor	2022-04-09 17:25:09	Non-optimal ...	default(3) / Switch: SwitchIB Mell	IBPort	Found a [25.0] link that operates in [14.0] speed mode.	1180
Warning	2022-04-05 15:26:47	Unhealthy IB...	default(3) / Switch: r-hyp-sw-01 /	IBPort	Peer Port is considered by SM as unhealthy due to MANUAL.	1
Warning	2022-04-05 15:26:27	Unhealthy IB...	default(3) / Switch: SwitchIB Mell	IBPort	Peer Port is considered by SM as unhealthy due to MANUAL.	1

Events & Alarms Server Time Last Update: 09 Apr 2022 11:31 admin

Alarms

Clear All Alarms ↻ Displayed Columns CSV

Severity	Date/Time ↓	Alarm Name	Source	Source Type	Reason	Count
Minor	2022-04-09 11:25:09	Non-optimal ...	default(3) / Switch: r-hyp-sw-01 /	IBPort	Found a [25.0] link that operates in [14.0] speed mode.	1180
Minor	2022-04-09 11:25:09	Non-optimal ...	default(3) / Switch: SwitchIB Mell	IBPort	Found a [25.0] link that operates in [14.0] speed mode.	1180
Minor	2022-04-09 11:25:09	Non-optimal ...	default(3) / Switch: SwitchIB Mell	IBPort	Found a [25.0] link that operates in [14.0] speed mode.	1180
Warning	2022-04-05 9:26:47	Unhealthy IB...	default(3) / Switch: r-hyp-sw-01 /	IBPort	Peer Port is considered by SM as unhealthy due to MANUAL.	1
Warning	2022-04-05 9:26:27	Unhealthy IB...	default(3) / Switch: SwitchIB Mell	IBPort	Peer Port is considered by SM as unhealthy due to MANUAL.	1

**Note**

In the screenshots, the difference between Server Time and Local Time is 6 hours.

## Table Enhancements

## Look and Feel Improvements

All Refresh Displayed Columns CSV

Severity	Name	GUID	Type	Model	IP	Firmware Ve...
Info	r-hyp-sw-01	0x248a070300...	switch	MSB7700	N/A	N/A
Info	SwitchIB Mell...	0xe41d2d0300...	switch	EDR	N/A	N/A
Info	ufm-host86	0x7cfe9003002...	host	Computer	192.168....	N/A
Info	r-ufm254-hyp...	0x043f720300d...	host	Computer	N/A	N/A
Info	r-ufm254-hyp...	0x0c42a10300...	host	Computer	N/A	N/A

Viewing 1-5 of 5 Navigation icons 10

## Displayed Columns


Refresh Displayed Columns CSV

ID ↓ 1	Description	Created ↓ 2	Last Update ↓ 3	Status	Summary
2	mark_device_healthy	2022-10-20 17:03:14	2022-10-20 17:03:14	Completed	View Summary
1	mark_device_unhealthy	2022-10-20 17:02:24	2022-10-20 17:02:24	Completed	View Summary

Viewing 1-2 of 2 Navigation icons 10

Restore Default

- ID
- Description
- Created
- Last Update
- Status
- Summary
- Progress



### **Note**

Displayed columns of all tables are persistent per user, with the option to restore defaults.

## **Export All Data as CSV**

There are two options for exporting as CSV

- All Data: all data returned from server.
- Displayed Data: only displayed rows.

>

All  Displayed Columns  CSV 

S...	Name	GUID	Type	Model	IP	
 	<input type="text" value="Filter..."/>	<input type="text" value="Filter..."/>	<input type="text" value="Filter..."/>	<input type="text" value="Filter..."/>	<input type="text" value="Filter..."/>	
 I...	r-hyp-sw-01	0x248a070300...	switch	 MSB7700	N/A	N/A
 I...	SwitchIB Mell...	0xe41d2d0300...	switch	 EDR	N/A	N/A
 I...	ufm-host86	0x7cfe9003002...	host	 Computer	192.168.1.30	N/A
 I...	r-ufm254-hyp...	0x043f720300d...	host	 Computer	N/A	N/A
 I...	r-ufm254-hyp...	0x0c42a10300...	host	 Computer	N/A	N/A

Viewing 1-5 of 5     10 

---

# UFM Installation and Initial Configuration

UFM® software includes Server and Agent components. UFM Server software should be installed on a central management node. For optimal performance, and to minimize interference with other applications, it is recommended to use a dedicated server for UFM. The UFM Agent is an optional component and should be installed on fabric nodes. The UFM Agent should not be installed on the Management server.

The following sections provide step-by-step instructions for installing and activating the license file, installing the UFM server software, and installing the UFM Agent.

## Prerequisites for UFM Server Software Installation

Please refer to [Installation Notes](#) for information on system prerequisites.

## UFM Installation Steps

To install the UFM software:

1. [Download the UFM software and license file](#)
2. [Install the UFM Server Software and Activate the Software License](#)
3. [Perform initial configuration](#)
4. [Run the UFM server software](#)

## UFM Installation Steps

- [Downloading UFM Software and License File](#)
- [Installing UFM Server Software](#)

# Downloading UFM Software and License File

Before you obtain a license for the UFM® software, prepare a list of servers with the MAC address of each server on which you plan to install the UFM software. These MAC addresses are requested during the licensing procedure.

## Obtaining License


UFM is licensed per managed device according to the UFM license agreement.

When you purchase UFM, you will receive an email with instructions on obtaining your product license. A valid UFM license is a prerequisite for the installation and operation of UFM.


UFM licenses are per managed node and are aggregative. If you install an additional license, the system adds the previous node number and the new node number and manages the sum of the nodes. For example, if you install a license for 10 managed nodes and an additional license for 15 nodes, UFM will be licensed for up to 25 managed nodes.

To obtain the license:

1. Go to NVIDIA's [Licensing and Download Portal](#) and log in as specified in the licensing email you received.
  - If you did not receive your NVIDIA Licensing and Download Portal login information, contact your product reseller.
2. If you purchased UFM directly from NVIDIA and you did not receive the login information, contact [enterprisesupport@nvidia.com](mailto:enterprisesupport@nvidia.com). Click on the Network Entitlements tab. You'll see a list with the serial licenses of all your software products and software product license information and status.



3. Select the license you want to activate and click on the “Actions” button.
4. In the MAC Address field, enter the MAC address of the delegated license-registered host. If applicable, in the HA MAC Address field, enter your High Availability (HA) server MAC address. If you have more than one NIC installed on a UFM Server, use any of the MAC addresses.



5. Click on Generate License File to create the license key file for the software.
6. Click on Download License File and save it on your local computer.

If you replace your NIC or UFM server, repeat the process of generating the license to set new MAC addresses. You can only regenerate a license two times. To regenerate the license after that, contact NVIDIA Sales Administration at [enterprisesupport@nvidia.com](mailto:enterprisesupport@nvidia.com).

## Downloading UFM Software

### **Note**

Due to internal packaging incompatibility, this release has two different packages for each of the supported distributions:

- One for UFM deployments over MLNX\_OFED 5.X (or newer)


Please make sure to use the UFM installation package compatible to your setup.

This software download process applies to software updates and first-time installation.

If you own the UFM Media Kit and this is your first-time installation, skip this section.

To download the UFM software:

1. Click on Software Downloads, filter the product family to UFM, and select the relevant version of the software. Click on Download.



PLATFORM	PLATFORM VERSION	PRODUCT VERSION	DESCRIPTION	RELEASE DATE	Download
Other		6.9	UFM SW Enterprise 6.9	May 4, 2022	Download
RHEL/CentOS		6.9	UFM SW Enterprise 6.9 RHEL 7	May 4, 2022	Download
RHEL/CentOS		6.9	UFM SW Enterprise 6.9 RHEL 8	May 4, 2022	Download
Ubuntu	18	6.9	UFM SW Enterprise 6.9 Ubuntu 18	May 4, 2022	Download
CyberAI Appliance		2	UFM SW CyberAI 2.0	May 3, 2022	Download

2. Save the file on your local drive.
3. Click Close.

## Installing UFM Server Software

The default UFM® installation directory is */opt/ufm*.

For instructions on installing the UFM server software, please refer to following instructions per desired installation mode.

- [Installing UFM Server on Bare Metal Server](#)
  - [Installing UFM on Bare Metal Server- Standalone Mode](#)
  - [Installing UFM on Bare Metal Server - High Availability Mode](#)
- [Installing UFM Docker Container Mode](#)
  - [Installing UFM on Docker Container - Standalone Mode](#)
  - [Installing UFM on Docker Container - High Availability Mode](#)

The following processes might be interrupted during the installation process:

- httpd (Apache2 in Ubuntu)
- dhcpd

### **Note**

To install UFM over static IPv4 configuration (instead of DHCP) please refer to [Configuring UFM Over Static IPv4 Address](#) before installation.

After installation:

1. Activate the software license
2. [Perform initial configuration](#)

**Note**

Before you run UFM, ensure that all ports used by the UFM server for internal and external communication are open and available. For the list of ports, see [Appendix – Used Ports](#).

## Prerequisites for UFM Server Software Installation

Verify that a supported version of Linux is installed on your machine. For details, see UFM System Requirements.

The following table lists the packages that must be installed on your machine (according to the system OS) before you install the UFM server software.

RedHat 7	RedHat 8	RedHat 9	Ubuntu 18.04	Ubuntu 20.04	Ubuntu 22.04
acl	acl	acl	acl	acl	acl
apr-util-openssl	apr-util-openssl	apr-util-openssl	apache2	apache2	apache2
bc	bc	bc	bc	bc	bc
cairo	gnutls	gnutls	chrpath	chrpath	chrpath
gnutls	httpd	httpd	cron	cron	cron
httpd	iptables	iptables-nft	gawk	gawk	gawk
iptables	jansson	jansson	lftp	lftp	lftp
lftp	lftp	lftp	libcurl4	libcurl4	libcurl4
libxml2	libnsl	libnsl	logrotate	logrotate	logrotate
libxslt	libxml2	libxml2	python3	python3	python3
mod_session	libxslt	libxslt	qperf	qperf	qperf
mod_ssl	mod_session	mod_session	rsync	rsync	rsync
net-snmp	mod_ssl	mod_ssl	snmpd	snmpd	snmpd
net-snmp-libs	net-snmp	net-snmp	sqlite3	sqlite3	sqlite3

RedHat 7	RedHat 8	RedHat 9	Ubuntu 18.04	Ubuntu 20.04	Ubuntu 22.04
net-snmp-utils	net-snmp-libs	net-snmp-libs	sshpas	sshpas	sshpas
net-tools	net-snmp-utils	net-snmp-utils	ssl-cert	ssl-cert	ssl-cert
php	net-tools	net-tools	sudo	sudo	sudo
psmisc	php	php	telnet	telnet	telnet
python3	psmisc	psmisc	zip	zip	zip
python3-libs	python36	python3			
qperf	qperf	qperf			
rsync	rsync	rsync			
sqlite	sqlite	sqlite			
sshpas	sshpas	sshpas			
sudo	sudo	sudo			
telnet	telnet	telnet			
zip	zip	zip			

**i Note**

On some Ubuntu OSs, Docker is installed via SNAP, which might lead to errors when trying to use UFM Plugins.

To solve this issue, perform the following:

1. Remove Docker installed via SNAP, run:

```

snap remove --purge docker

```

2. Update the local package index, run :

```
apt update
```

3. Install native Docker, run:

```
apt install-y docker.io
```

**In addition, ensure the following before you begin installation:**

- The computer hostname is not defined as 127.0.0.1 and localhost is defined as 127.0.0.1.
- The hostname must NOT appear on the loopback address line. An example of the loopback address is: 127.0.0.1 localhost.localdomain localhost.
- Disable the firewall service (`/etc/init.d/iptables stop`), or ensure that the required ports are open (see the prerequisite script, refer to [Used Ports](#)).
- Disable SELinux.
- If more than one fabric is managed by different UFM instances, set up different management network spaces for each fabric (not the same LAN).
- Uninstall any previously installed Subnet Manager from the UFM server machine.
- MLNX\_OFED 5.x version is installed prior to installing UFM.
- As of UFM v.6.12.0, it is **NOT mandatory** to configure the IPoIB fabric interface with an IP address.

In cases where the IP is configured, it is **mandatory** that the IP is permanently configured and that it starts automatically upon server reboot (the IPoIB fabric interface should be active even if the network is down).

 **Note**

The user can set a persistent IP address using Netplan (mainly for Ubuntu systems) or modifying the interface network script (RedHat systems).

- The default MLNX\_OFED installation includes opensm. Remove the MLNX\_OFED opensm before UFM installation like the following examples:

RedHat:

```
rpm -e opensm-3.3.9.MLNX_20111006_e52d5fc-0.1
```

Ubuntu:

```
apt purge opensm
```

By default, ib0 and eth0 are configured as primary access points for the UFM management. If different management and/or InfiniBand interfaces (including bond interfaces) are used as the primary access points, you should modify the configuration file by running the script `/opt/ufm/scripts/change_fabric_config.sh` as described in the section Configuring General Settings in `gv.cfg`.

Change the UFM Agent interface to the Ethernet and/or IPoIB interfaces used for communication with UFM Agent:

```
ufma_interfaces = ib0,eth0
```

## Additional Prerequisites for UFM High Availability Installation

- Reliable and high-capacity out-of-band IP connectivity between the UFM Primary and Secondary servers (1 Gb Ethernet is recommended). This connectivity is used for DRBD synchronization.

- Format two identical servers with dedicated disk partitions for UFM replication. Since the UFM configuration file is replicated to the standby server, both master and standby servers must have the same interfaces.
- Allocate exactly the same size partition on both servers (master and slave) for the replicated data. See UFM Server Requirements for the recommended partition size.

Partitions should not be mounted and must be zeroed (the file system should not be installed on the partitions). For disk partitioning, see the Linux user manual (man fdisk).

- We recommend establishing a passwordless SSH (via `/root/.ssh/authorized_keys` file) between the two servers before the installation.
- In fabrics consisting of multiple tiers of switches, it is recommended that the management ports (ib0) of the primary and secondary UFM server be connected to different fabric switches on the same tier (the outermost edge in CLOS 5 designs).

This is because by default, UFM manages the IB fabric via ib0, port 1 of the HCA. Failure or disconnect of ib0, the IB management port, causes a failure condition in UFM resulting in HA failover.

When the management ports (ib0) of the primary and secondary UFM server are connected to the same switch, a failure of this switch will result in a disconnect of both UFM servers from the fabric, and therefore UFM will not be able to manage the fabric.

### **Note**

Subnet Manager is running over the native InfiniBand layer, therefore bonding the IpoIB interfaces will not provide high availability. For additional information, please refer to section UFM Failover to Another Port.

The UFM installation includes the InfiniBand Performance Management module (IBPM). This module is responsible for reporting performance information back to UFM and upper layer applications. When available, this process is offloaded to the non-management port (default ib1) of the UFM server. Failure or disconnect of the non-management port (ib1) on the primary UFM server will not cause UFM to failover. By default, the UFM Health Monitoring process is

configured to try to restart the IBPM. For more information, see UFM Health Configuration in the UFM User Manual.

## Installing UFM Server on Bare Metal Server

Installing UFM server on Bare Metal server can be done with the following modes:

- [Installing UFM on Bare Metal Server- Standalone Mode](#)
- [Installing UFM on Bare Metal Server - High Availability Mode](#)

## Installing UFM on Bare Metal Server - High Availability Mode

Before installing UFM server software in High-Availability mode, ensure that the [Additional Prerequisites for UFM High Availability Installation](#) are met.

The UFM High-Availability configuration requires dual-link connectivity based on two separate interfaces between the two UFM HA nodes. This configuration comprises of a primary link that is exclusively reserved for DRBD operations and a secondary link designated for backup purposes. Crucially, it is imperative that communication between the servers is established in a bidirectional manner across both interfaces and validated through user-initiated testing, such as a 'ping' command or other suitable alternatives before HA configuration can be implemented. In cases where only one link is available among the two UFM HA nodes/servers, manually configure UFM with a single link. Refer to [Configure HA without SSH Trust \(Single Link Configuration\)](#).

### **Note**

UFM HA package requires a dedicated partition with the same name for DRBD on both servers. This guide uses `/dev/sda5` as an example.

1. On both servers, Install UFM Enterprise in Stand Alone (SA) mode.

**Note**

Do not start UFM service.

2. Install the latest pcs and drbd-utils drivers on both servers.

For Ubuntu:

```
apt install pcs pacemaker drbd-utils
```

For CentOS/Red Hat:

```
yum install pcs pacemaker drbd84-utils kmod-drbd84
```

OR

```
yum install pcs pacemaker drbd90-utils kmod-drbd90
```

3. Download UFM-HA latest package from using this command:

The included page could not be found.

**Note**

For more information on the UFM-HA package and all installation and configuration options, please refer to [UFM High-Availability](#)

## User Guide.

4. Extract the downloaded UFM-HA package on both servers under /tmp/.
5. Go to the directory you extracted /tmp/ufm\_ha\_XXX and run the installation script. For example, if your DRBD partition is /dev/sda5 run:

```
./install.sh -l /opt/ufm/files/ -d /dev/sda5 -p enterprise
```

6. Configure the HA cluster. There are the three methods:

- [Configure HA with SSH Trust \(Dual Link Configuration\)](#) - Requires passwordless SSH connection between the servers.
- [Configure HA without SSH Trust \(Dual Link Configuration\)](#) - Does not require passwordless SSH connection between the servers, but asks you to run configuration commands on both servers.
- [Configure HA without SSH Trust \(Single Link Configuration\)](#) - Can be used in cases where only one link is available among the two UFM HA nodes/servers.

### **Configure HA with SSH Trust (Dual Link Configuration)**

- 1.

1. On the **master server only**, configure the HA nodes. To do so, from /tmp, run the configure\_ha\_nodes.sh command as shown in the below example

```
configure_ha_nodes.sh \  
--cluster-password 12345678 \  
--master-primary-ip 10.10.10.1 \  
--standby-primary-ip 10.10.10.2 \  
--master-secondary-ip 192.168.10.1 \  
--standby-secondary -ip 192.168.10.2 \  
--no-vip
```

**(i) Note**

The script `configure_ha_nodes.sh` is located under `/usr/local/bin/`, therefore, by default, you do not need to use the full path to run it.

**(i) Note**

The `--cluster-password` must be at least 8 characters long.

**(i) Note**

To set up a Virtual IP for UFM and gain access to UFM through this IP, regardless of which server is running UFM, you may employ the `--no-vip` OR `--virtual-ip` command and provide an IP address as an argument. This can be achieved by navigating to `https://<Virtual-IP>/ufm` on your web browser.

**(i) Note**

When using back-to-back ports with local IP addresses for HA sync interfaces, ensure that you add your IP addresses and hostnames to the `/etc/hosts` file. This is needed to allow the HA configuration to resolve hostnames correctly based on the IP addresses you are using.

**Note**

configure\_ha\_nodes.sh requires SSH connection to the standby server. If SSH trust is not configured, then you are prompted to enter the SSH password of the standby server during configuration runtime

2. Depending on the size of your partition, wait for the configuration process to complete and DRBD sync to finish.

### Configure HA without SSH Trust (Dual Link Configuration)

If you cannot establish an SSH trust between your HA servers, you can use **ufm\_ha\_cluster** directly to configure HA. To configure HA, follow the below instructions:

**Note**

Please change the variables in the commands below based on your setup.

1.

1. [On Standby Server] Run the following command to configure Standby Server:

```
ufm_ha_cluster config -r standby \  
--local-primary-ip 10.10.50.1 \  
--peer-primary-ip 10.10.50.2 \  
--local-secondary-ip 192.168.10.1 \  
--peer-secondary-ip 192.168.10.2 \  
--hacluster-pwd 123456789 \  
--no-vip
```

2. [On Master Server] Run the following command to configure Master Server:

```
ufm_ha_cluster config -r master --local-primary-ip  
10.10.50.1 \  
--peer-primary-ip 10.10.50.2 \  
--local-secondary-ip 192.168.10.1 \  
--peer-secondary-ip 192.168.10.2 \  
--hacluster-pwd 123456789 \  
--no-vip
```

You must wait until after configuration for DRBD sync to finish, depending on the size of your partition. To check the DRBD sync status, run:

```
ufm_ha_cluster status
```

### Configure HA without SSH Trust (Single Link Configuration)

#### **Warning**

This is not the recommended configuration and, in case of network failure, it might cause HA cluster split brain.

If you cannot establish an SSH trust between your HA servers, you can use **ufm\_ha\_cluster directly to configure HA. To configure HA, follow the below instructions:**

#### **Note**

Please change the variables in the commands below based on your setup.

1.

1. [On Standby Server] Run the following command to configure Standby Server:

```
ufm_ha_cluster config \  
-r standby \  
-e 10.212.145.5 \  
-l 10.212.145.6 \  
--enable-single-link
```

2. [On Master Server] Run the following command to configure Master Server:

```
ufm_ha_cluster config -r master \  
-e 10.212.145.6 \  
-l 10.212.145.5 \  
-i 10.212.145.50 \  
--enable-single-link
```

You must wait until after configuration for DRBD sync to finish, depending on the size of your partition. To check the DRBD sync status, run:

```
ufm_ha_cluster status
```

## Starting HA Cluster

- To start UFM HA cluster:

```
ufm_ha_cluster start
```

- To check UFM HA cluster status:

```
ufm_ha_cluster status
```

### Stopping UFM HA cluster:

```
ufm_ha_cluster stop
```

#### **Note**

For complete details on high availability, refer to [NVIDIA UFM High-Availability User Guide](#).

## Installing UFM on Bare Metal Server-Standalone Mode

To install the UFM server software as a standalone for InfiniBand:

1. Create a temporary directory (for example `/tmp/ufm`).
2. Open the UFM software zip file that you downloaded. The zip file contains the following installation files:
  - RedHat 7/CentOS 7/OEL 7: `ufm-X.X-XXX.el7.x86_64.tgz`
  - RedHat 8/Centos 8: `ufm-X.X-XXX.el8.x86_64.tgz`
  - Ubuntu 18.04: `ufm-X.X-XXX.Ubuntu18.x86_64.tgz`
  - Ubuntu 20.04: `ufm-X.X-XXX.Ubuntu20.x86_64.tgz`
  - Ubuntu 22.04: `ufm-X.X-XXX.Ubuntu22.x86_64.tgz`

3. Extract the installation file for your system's OS to the temporary directory that you created.
4. From within the temporary directory, run the following command as root:

```
./install.sh
```

### **Note**

Running with the option "-o ib" is no longer required. For automatic installation, use the -q flag.

For "quiet" installation -q flag can be added (automatically answer yes for each question the installer asks).

### **Note**

Export MULTISUBNET\_CONSUMER=1 environment variable before running the installation script to install the UFM server in Multisubnet Consumer mode.

The UFM software is installed. You can now remove the temporary directory.

## Installing UFM Docker Container Mode

### General Prerequisites

- MLNX\_OFED must be installed on the server that will run UFM Docker
- For UFM to work, you must have an InfiniBand port configured with an IP address and in "up" state.

### **(i) Note**

For InfiniBand support, please refer to [NVIDIA Inbox Drivers](#) , or MLNX\_OFED guides.

- Make sure to stop the following services before running UFM Docker container, as it utilizes the same default ports that they do: Pacemaker, httpd, OpenSM, and Carbon.
- If firewall is running on the host, please make sure to add an allow rule for UFM used ports (listed below):

### **(i) Note**

If the default ports used by UFM are changed in UFM configuration files, make sure to open the modified ports on the host firewall.

- 80 (TCP) and 443 (TCP) are used by WS clients (Apache Web Server)
- 8000 (UDP) is used by the UFM server to listen for REST API requests (redirected by Apache web server)
- 6306 (UDP) is used for multicast request communication with the latest UFM Agents
- 8005 (UDP) is used as a UFM monitoring listening port
- 8888 (TCP) is used by DRBD to communicate between the UFM Primary and Standby servers
- 2022 (TCP) is used for SSH

## **Prerequisites for Upgrading UFM Docker Container**

- Supported versions for upgrade are UFM v.6.10.0 and above.

- UFM files directory from previous container version mounted on the host.

## Step 1: Loading UFM Docker Image

To load the UFM docker image, pull the latest image from docker hub:

```
docker pull mellanox/ufm-enterprise:latest
```

### Note

You can see full usage screen for ufm-installation by running the container with `-h` or `-help` flag:

```
docker run --rm mellanox/ufm-enterprise-  
installer:latest -h
```

If an Internet connection is not available, perform the following:

- Copy the UFM image to your machine.
- Load the image from the file using this command:

```
docker image load -i <image-path>
```

## Step 2: Installing UFM Docker

### Installation Command Usage

```
docker run -it --name=ufm_installer --rm \
```

```

-v /var/run/docker.sock:/var/run/docker.sock \
-v /etc/systemd/system:/etc/systemd_files/ \
-v /opt/ufm/files:/installation/ufm_files/ \
-v [LICENSE_DIRECTORY]:/installation/ufm_licenses/ \
mellanox/ufm-enterprise:latest \
--install [OPTIONS]

```

Modify the variables in the installation command as follows:

- [UFM\_LICENSES\_DIR]: UFM license file or files location.

### Note

Example: If your license file or files are located under `/downloads/ufm_license_files/` then you must set this volume to be `-v /downloads/ufm_license_files:/installation/ufm_licenses/`

- [OPTIONS]: UFM installation options. For more details see the table below.

## Command Options

Flag	Description	Default Value
-f   --fabric-interface	IB fabric interface name.	ib0
-g   --mgmt-interface	Management interface name.	eth0
-h   --help	Show help	N/A
-m   --multisubnet-consumer	UFM Multisubnet Consumer mode	N/A

## Installation Modes

UFM Enterprise installer supports several deployment modes:

- [Installing UFM on Docker Container - High Availability Mode](#)
- [Installing UFM on Docker Container - Standalone Mode](#)

# Installing UFM on Docker Container - High Availability Mode

## Pre-deployments requirements

- Install **pacemaker**, **pcs**, and **drbd-utils** on both servers

### For Ubuntu:

```
apt install pcs pacemaker drbd-utils
```

### For CentOS/Red Hat:

```
yum install pcs pacemaker drbd84-utils kmod-drbd84
```

### OR

```
yum install pcs pacemaker drbd90-utils kmod-drbd90
```

- A partition for DRBD on each server (**with the same name** on both servers) such as `/dev/sdd1`. Recommended partition size is 10-20 GB, otherwise DRBD sync will take a long time to complete.
- CLI command `hostname -i` must return the IP address of the management interface used for pacemaker sync correctly (update `/etc/hosts/` file with machine IP)
- Create the directory on each server under `/opt/ufm/files/` with read/write permissions on each server. This directory will be used by UFM to mount UFM files, and it will be synced by DRBD.

## Installing UFM Containers

On the main server, install UFM Enterprise container with the command below:

```
docker run -it --name=ufm_installer --rm \  
-v /var/run/docker.sock:/var/run/docker.sock \  
-v /etc/systemd/system:/etc/systemd_files/ \  
-v /opt/ufm/files:/installation/ufm_files/ \  
-v /tmp/license_file:/installation/ufm_licenses/ \  
mellanox/ufm-enterprise:latest \  
--install
```

On the standby (secondary) server, install the UFM Enterprise container like the following example with the command below:

```
docker run -it --name=ufm_installer --rm \  
-v /var/run/docker.sock:/var/run/docker.sock \  
-v /etc/systemd/system:/etc/systemd_files/ \  
-v /opt/ufm/files:/installation/ufm_files/ \  
mellanox/ufm-enterprise:latest \  
--install
```

## Downloading UFM HA Package

Download the UFM-HA package on both servers using the following command:

```
wget https://www.mellanox.com/downloads/UFM/ufm_ha_5.5.0-9.tgz
```

For Sha256:

```
wget https://download.nvidia.com/ufm/ufm_ha/ufm_ha_5.5.0-9.sha256
```

## Installing UFM HA Package

For more information on the UFM-HA package and all installation and configuration options, please refer to [UFM High Availability User Guide](#).

1. [On Both Servers] Extract the downloaded UFM-HA package under /tmp/
2. [On Both Servers] Go to the extracted directory /tmp/ufm\_ha\_XXX and run the installation script. For example, if your DRBD partition is /dev/sda5 run the following command:

```
./install.sh -l /opt/ufm/files/ -d /dev/sda5 -p enterprise
```

## Configuring UFM HA

There are the three methods to configure the HA cluster:

- [Configure HA with SSH Trust \(Dual Link Configuration\)](#) - Requires passwordless SSH connection between the servers.
- [Configure HA without SSH Trust \(Dual Link Configuration\)](#) - Does not require passwordless SSH connection between the servers, but asks you to run configuration commands on both servers.
- [Configure HA without SSH Trust \(Single Link Configuration\)](#) - Can be used in cases where only one link is available among the two UFM HA nodes/servers.

## Configure HA with SSH Trust (Dual Link Configuration)

1. On the **master server only**, configure the HA nodes. To do so, from /tmp, run the `configure_ha_nodes.sh` command as shown in the below example

```
configure_ha_nodes.sh \
```

```
--cluster-password 12345678 \  
--master-primary-ip 10.10.50.1 \  
--standby-primary-ip 10.10.50.2 \  
--master-secondary-ip 192.168.10.1 \  
--standby-secondary-ip 192.168.10.2 \  
--no-vip
```

**(i) Note**

The script `configure_ha_nodes.sh` is located under `/usr/local/bin/`, therefore, by default, you do not need to use the full path to run it.

**(i) Note**

The `--cluster-password` must be at least 8 characters long.

**(i) Note**

When using back-to-back ports with local IP addresses for HA sync interfaces, ensure that you add your IP addresses and hostnames to the `/etc/hosts` file. This is needed to allow the HA configuration to resolve hostnames correctly based on the IP addresses you are using.

**(i) Note**

configure\_ha\_nodes.sh requires SSH connection to the standby server. If SSH trust is not configured, then you are prompted to enter the SSH password of the standby server during configuration runtime

2. Depending on the size of your partition, wait for the configuration process to complete and DRBD sync to finish. To check the DRBD sync status, run:

```
ufm_ha_cluster status
```

## Configure HA without SSH Trust (Dual Link Configuration)

If you cannot establish an SSH trust between your HA servers, you can use `ufm_ha_cluster` directly to configure HA. You can see all the options for configuring HA in the Help menu:

```
ufm_ha_cluster config -h
```

To configure HA, follow the below instructions:

### **Note**

Please change the variables in the commands below based on your setup.

1. [On Standby Server] Run the following command to configure Standby Server:

```
ufm_ha_cluster config -r standby -e <peer ip address> -l  
<local ip address> -p <cluster_password>
```

2. [On Master Server] Run the following command to configure Master Server:

```
ufm_ha_cluster config -r master -e <peer ip address> -l  
<local ip address> -p <cluster_password> -i <virtual ip  
address>
```

### Configure HA without SSH Trust (Single Link Configuration)

#### **Warning**

This is not the recommended configuration and, in case of network failure, it might cause HA cluster split brain.

If you cannot establish an SSH trust between your HA servers, you can use **ufm\_ha\_cluster** directly to configure HA. To configure HA, follow the below instructions:

#### **Note**

Please change the variables in the commands below based on your setup.

1.

1. [On Standby Server] Run the following command to configure Standby Server:

```
ufm_ha_cluster config \  
-r standby \  
-e 10.212.145.5 \  
-l 10.212.145.6 \  
--enable-single-link
```

2. [On Master Server] Run the following command to configure Master Server:

```
ufm_ha_cluster config -r master \  
-e 10.212.145.6 \  
-l 10.212.145.5 \  
-i 10.212.145.50 \  
--enable-single-link
```

You must wait until after configuration for DRBD sync to finish, depending on the size of your partition. To check the DRBD sync status, run:

```
ufm_ha_cluster status
```

IPv6 Example:

```
ufm_ha_cluster config -r standby -l  
fcfc:fcfc:209:224:20c:29ff:fee7:d5f2 -e  
fcfc:fcfc:209:224:20c:29ff:feeb:4962 --enable-single-link -  
p some_secret
```

## Starting HA Cluster

- To start UFM HA cluster:

```
ufm_ha_cluster start
```

- To check UFM HA cluster status:

```
ufm_ha_cluster status
```

- To stop UFM HA cluster:

```
ufm_ha_cluster stop
```

- To uninstall UFM HA, first stop the cluster and then run the uninstallation command as follows:

```
/opt/ufm/ufm_ha/uninstall_ha.sh
```

## Installing UFM on Docker Container - Standalone Mode

1. Copy only your UFM license file(s) to a temporary directory which we're going to use in the installation command. For example: `/tmp/license_file/`
2. Run the UFM installation command according to the following example which will also configure UFM fabric interface to be `ib1`:

```
docker run -it --name=ufm_installer --rm \  
-v /var/run/docker.sock:/var/run/docker.sock \  
ufm_installer
```

```
-v /etc/systemd/system/ : /etc/systemd_files/ \  
-v /opt/ufm/files/ : /installation/ufm_files/ \  
-v /tmp/license_file/ : /installation/ufm_licenses/ \  
mellanox/ufm-enterprise:latest \  
--install \  
--fabric-interface ib1
```

3. Reload systemd:

```
systemctl daemon-reload
```

4. To Start UFM Enterprise service run:

```
systemctl start ufm-enterprise
```

## Replacing the Standby Node

- Install the HA package for the new node (standby).
- Disconnect the standby node (the old standby) and run the following command on the master node:

```
ufm_ha_cluster detach
```

- Configure the new standby node; please refer to the relevant section depending on the installation
- Connect the new standby to the cluster by running the command on the master node:

```
ufm_ha_cluster attach -l <local primary ip address> -e <peer  
primary ip address> -E <peer secondary ip address> -p <clust
```

## Activating Software License

1. Before starting the UFM software, copy your license file(s) downloaded from [NVIDIA Licensing and Download Portal](#) (*volt-ufm-<serial-number>.lic*) to the master server under the */opt/ufm/files/licenses* directory. We recommend that you back up the license file(s).

In High Availability mode, the license files are replicated to the standby machine automatically. Your software is now activated.


2. Run the UFM software as described in the following sections.

### Note


When a UFM license is not provided for activation upon the first UFM installation, the UFM runs on an auto-generated evaluation license which expires after 30 days from the first start-up of the UFM.

## Licensing

1. After installing and activating your software, you can view your licenses in the Web UI by clicking the About icon () in the main window.



2. To view the advanced license information, click the Advanced button. The advanced license details will be displayed below.



- Product Functionality is updated only after startup. If you replace the UFM license, UFM continues to work in the previous mode until the UFM server is restarted.

### ***To view license information from the CLI:***



Run CLI Command "**ufmlicense**" to display information about all installed licenses on the UFM server under `/opt/ufm/files/licenses`. This includes invalid and expired license information.

There are two UFM HA licenses where each license includes 2 different MACs: one for the primary machine and one for the standby machine.

In a given time, for each license, only one MACs is detected to be "Valid" (exists on the local machine) where the other MAC is detected as "Invalid" (exist on the standby machine).

See below *output example* when running the CLI command *ufmlicense* in SA and HA Modes.

### HA Mode Output Example:

```
[root@ip-10-224-16-49-dg11 ~]# docker exec -ti ufm bash
root@ ip-10-224-16-49-dg11~# ufmlicense
|-----|
|NVIDIA Corp|xxxxxxx-xxxxxxx|UFM Enterprise|Subscription |e4:43:4b:18:3c:e0|2025-08-29 |128 |3 Years
|Invalid |
|-----|
|NVIDIA Corp|xxxxxxx-xxxxxxx|UFM Enterprise|Subscription |e4:43:4b:18:49:a0|2025-08-29 |128 |3 Years
|Valid |
|-----|
|NVIDIA Corp|xxxxxxx-xxxxxxx|UFM Enterprise|Subscription |e4:43:4b:18:3c:e0|2025-07-13 |128 |3 |Invalid
|
|-----|
|BBK Electronics Corp Ltd|xxxxxxx-xxxxxxx|UFM Enterprise|Subscription |e4:43:4b:18:49:a0|2025-07-13 |128
|3 |Valid |
```

### SA Mode Output Example:

```
root@ufm-production:~# ufmlicense
|-----|
|-----|
| Customer ID | SN | swName | Type
| MAC Address | Exp. Date |Limit| Functionality | Status
|
|-----|
|-----|
|495760397 |123456778 |UFM Enterprise |Evaluation
|NA |2090-11-21 |1024 |Advanced |Valid |
|-----|
|-----|
```

### To remove a license:



Delete the license file from `/opt/ufm/files/licenses`.

# UFM Configuration

## Initial Configuration

After installing the UFM® server software and before running UFM, perform the following:

- Mandatory Configuration:
  - Configure General Settings in gv.cfg
- Additional Configurations Options:
  - General Configuration options
  - Quality of Service
  - Activate and Enable Lossy Configuration Manager (Advanced License Only)
  - Activate and Enable Congestion Control Manager (Advanced License Only)

### Configuring Fabric Interface

In most common cases, UFM is run in management mode; the UFM SM manages the InfiniBand fabric. In such cases, the only mandatory configuration is setting the **fabric\_interface** parameter.

The fabric interface should be set to one of the InfiniBand IPoIB interfaces, which connect the UFM/SM to the fabric:

```
fabric_interface = ib0
```

#### Note

- By default, fabric\_interface is set to ib0

- fabric\_interface must be up and running before UFM startup. Otherwise, UFM will not be able to run.

For additional configuration options, please refer to the [Optional Configuration](#).

## Optional Configuration

### General Settings in gv.cfg

Configure general settings in the conf/gv.cfg file.

#### Note

When running UFM in HA mode, the gv.cfg file is replicated to the standby server.

### Enabling SHARP Aggregation Manager

SHARP Aggregation Manager is disabled by default. To enable it, set:

```
[Sharp]
sharp_enabled = true
```

#### Note

Upon startup of UFM or SHARP Aggregation Manager, UFM will resend all existing tenant allocations to SHARP AM.

## Enabling Predefined Groups

```
enable_predefined_groups = true
```

### **Note**

By default, pre-defined groups are enabled. In very large-scale fabrics, pre-defined groups can be disabled in order to allow faster startup of UFM.

## Enabling Multi-NIC Host Grouping

```
multinic_host_enabled = true
```

### **Note**

Upon first installation of UFM 6.4.1 and above, multi-NIC host grouping is enabled by default. However, if a user is upgrading from an older version, then this feature will be disabled for them.

### **Note**

It is recommended to set the value of this parameter before running UFM for the first time.

## Defining Node Description Black-List

### **Note**

Node descriptions from the black-list should not be used for Multi-NIC grouping.

During the process of host reboot or initialization/bringup, the majority of HCAs receive a default label rather than an actual, real description. To prevent the formation of incorrect multi-NIC groups based on these default labels, this feature offers the option to establish a blacklist containing possible node descriptions that should be avoided when grouping Multi-NIC HCAs during host startup. Once a legitimate node description is assigned to the host, the HCAs are organized into multi-NIC hosts based on their respective descriptions. It is recommended to configure this parameter before initiating the UFM for the first time.

For instance, nodes initially identified with descriptions listed in the `exclude_multinic_desc` will not be initially included in Multi-NIC host groups until they obtain an updated, genuine node description.

Modify the `exclude_multinic_desc` parameter in the `cv.fg` file:

```
exclude_multinic_desc = localhost, generic_name_1, generic_name_2
```

## Running UFM Over IPv6 Network Protocol

The default multicast address is configured to an IPv4 address. To run over IPv6, this must be changed to the following in section `UFMAgent` of `gv.cfg`.

```
[UFMAgent]
...
# if ufmagent works in ipv6 please set this multicast address to
FF05:0:0:0:0:0:0:15F
mcast_addr = FF05:0:0:0:0:0:0:15F
```

## Adding SM Plugin (e.g. lossymgr) to event\_plugin\_name Option

The following options allow users to set the SM plugin options via the UFM configuration. Once SM is started by UFM, it will start the SM plugin with the specified options.

```
# Event plugin name(s)
event_plugin_name osmufmpi lossymgr
```

Add the plug-in options file to the event\_plugin\_options option:

```
# Options string that would be passed to the plugin(s)
event_plugin_options --lossy_mgr -f <lossy-mgr-options-file-name>
```

These plug-in parameters are copied to the opensm.conf file in Management mode only.

## Multi-port SM

SM can use up to eight-port interfaces for fabric configuration. These interfaces can be provided via `/opt/ufm/conf/gv.cfg`. The users can specify multiple IPoIB interfaces or bond interfaces in `/opt/ufm/conf/gv.cfg`, subsequently, the UFM translates them to GUIDs and adds them to the SM configuration file (`/opt/ufm/conf/opensm/opensm.conf`). If users specify more than eight interfaces, the extra interfaces are ignored.

```
[Server]
```

```
# disabled (default) | enabled (configure opensm with multiple GUIDs) | ha_enabled (configure multiport SM with high availability)
```

```
multi_port_sm = disabled
```

```
# When enabling multi_port_sm, specify here the additional fabric interfaces for OpenSM conf
```

```
# Example: ib1,ib2,ib5 (OpenSM will support the first 8 GUIDs where first GUID will
```

```
# be extracted the fabric_interface, and remaining GUIDs from additional_fabric_interfaces
```

```
additional_fabric_interfaces =
```

### **Note**

UFM treats bonds as a group of IPoIB interfaces. So, for example, if bond0 consists of the interfaces ib4 and ib8, then expect to see GUIDs for ib4 and ib8 in opensm.conf.

### **Note**

Duplicate interface names are ignored (e.g. ib1,ib1,ib1,ib2,ib1 = ib1,ib2).

## Configuring UDP Buffer

This section is relevant only in cases where `telemetry_provider=ibpm`. (By default, `telemetry_provider=telemetry`).

To work with large-scale fabrics, users should set the `set_udp_buffer` flag under the [IBPM] section to "yes" for the UFM to set the buffer size (default is "no").

```
# By default, UFM does not set the UDP buffer size. For large
scale fabrics
# it is recommended to increase the buffer size to 4MB (4194304
bits).
set_udp_buffer = yes
# UDP buffer size
udp_buffer_size = 4194304
```

## Virtualization

This allows for supporting virtual ports in UFM.

```
[Virtualization]
# By enabling this flag, UFM will discover all the virtual ports
assigned for all hypervisors in the fabric
enable = false
# Interval for checking whether any virtual ports were changed in
the fabric
interval = 60
```

## Static SM LID

Users may configure a specific value for the SM LID so that the UFM SM uses it upon UFM startup.

```
[SubnetManager]
# 1- Zero value (Default): Disable static SM LID functionality
and allow the SM to run with any LID.
#   Example: sm_lid=0
# 2- Non-zero value: Enable static SM LID functionality so SM
will use this LID upon UFM startup.
sm_lid=0
```

### **Note**

To configure an external SM (UFM server running in `sm_only` mode), users must manually configure the `opensm.conf` file (`/opt/ufm/conf/opensm/opensm.conf`) and align the value of `master_sm_lid` to the value used for `sm_lid` in `gv.cfg` on the main UFM server.

## Configuring Log Rotation

This section enables setting up the log files rotate policy. By default, log rotation runs once a day by cron scheduler.

```
[logrotate]
#max_files specifies the number of times to rotate a file before
it is deleted (this definition will be applied to
#SM and SHARP Aggregation Manager logs, running in the scope of
UFM).
#A count of 0 (zero) means no copies are retained. A count of 15
means fifteen copies are retained (default is 15)
max_files = 15
```

```
#With max_size, the log file is rotated when the specified size
is reached (this definition will be applied to
#SM and SHARP Aggregation Manager logs, running in the scope of
UFM). Size may be specified in bytes (default),
#kilobytes (for example: 100k), or megabytes (for example: 10M).
if not specified logs will be rotated once a day.
max_size = 3
```

## Configuring UFM Logging

The [Logging] section in the gv.cfg enables setting the UFM logging configurations.

Field	Default Value	Value Options	Description
level	WARNING	CRITICAL, ERROR, WARNING, INFO, DEBUG	The definition of the maub logging level for UFM components.
smclient_level	WARNING	CRITICAL, ERROR, WARNING, INFO, DEBUG	The logging level for SM client log messages
event_log_level	INFO	CRITICAL, ERROR, WARNING, INFO, DEBUG	The logging level for UFM events log messages
rest_log_level	INFO	CRITICAL, ERROR, WARNING, INFO, DEBUG	Logging level for REST API related log messages
authentication_service_log_level	INFO	CRITICAL, ERROR, WARNING, INFO, DEBUG	logging level for UFM authentication log messages
log_dir	/opt/ufm/files/	N/A	It is possible to change the default path to the UFM log directory.

Field	Default Value	Value Options	Description
	log		The configured log_dir must have read, write and execute permission for ufmapp user (ufmapp group). In case of HA, UFM should be located in the directory which is replicated between the UFM master and standby servers. A change of the default UFM log directory may affect UFM dump creation and inclusion of UFM logs in dump.
max_history_lines	100000	N/A	The maximum number of lines in log files to be shown in UI output for UFM logging.

```
[Logging]
# Optional logging levels: CRITICAL, ERROR, WARNING, INFO, DEBUG.
level = WARNING
smclient_level = WARNING
event_log_level = INFO
rest_log_level = INFO
authentication_service_log_level = INFO
# The configured log_dir must have read, write and execute
permission for ufmapp user (ufmapp group).
log_dir = /opt/ufm/files/log
max_history_lines = 100000
```

## Configuring UFM Over Static IPv4 Address

Follow this procedure to to run UFM on a static IP configuration instead of DHCP:

1. Modify the defined management Ethernet interface network script to be static. Run:

```
# vi /etc/sysconfig/network-scripts/ifcfg-enp1s0
```

Update the required interface with the static IP configuration (IP address, netmask, broadcast, and gateway):

```
NAME="enp1s0"DEVICE="enp1s0"  
ONBOOT="yes"  
BOOTPROTO="static"  
IPADDR="10.209.37.153"  
NETMASK="255.255.252.0"  
BROADCAST="10.209.39.255"  
GATEWAY="10.209.36.1"  
TYPE=Ethernet  
DEFROUTE="yes"
```

2. Add host entries to the `/etc/hosts` file. Run:

```
# vi /etc/hosts  
127.0.0.1    localhost localhost.localdomain localhost4  
localhost4.localdomain4  
::1         localhost localhost.localdomain localhost6  
localhost6.localdomain6  
  
10.209.37.153 <hostname>
```

3. Check hostname. Run:

```
# vi /etc/hostname  
<hostname>
```

4. Set up DNS resolution at `/etc/resolv.conf`. Run:

```
# vi /etc/resolv.conf
```

```
search mtr.labs.mlnx
nameserver 8.8.8.8
```

5. Restart network service. Run:

```
service network restart
```

6. Check Configuration. Run:

```
# hostname
<hostname>
# hostname -i
10.209.37.153
```

## Configuring Syslog

This configuration enables the UFM to send log messages to syslog, including remote syslog. The configuration described below is located in the [Logging] section of the gv.cfg file.

Field	Default Value	Value Options	Description
syslog	false	True or False	Enables/disables UFM syslog option
syslog_addr	/dev/log # for remote rsyslog_hostname:514	N/A	UFM syslog configuration (syslog_addr) For working with local syslog, set value to: /dev/log For working with external machine, set value to: host:port Important note: the default remote syslog server port is 514 As the UFM log messages could be sent to remote server, change the

Field	Default Value	Value Options	Description
			<p>rsyslog configuration on the remote server</p> <p>The /etc/rsyslog.conf file should be edited and two sections should be uncommented as shown below:</p> <pre># Provides UDP syslog reception \$ModLoad imudp \$UDPServerRun 514 # Provides TCP syslog reception \$ModLoad imtcp \$InputTCPServerRun 514</pre> <p>Restart the remote syslog service, run:</p> <pre>service rsyslog restart</pre>
ufm_syslog	false	True or False	Sets syslog option for main UFM process logging messages - False - Not to send. True: Send
smclient_syslog	false	True or False	Sets syslog option for OpenSM logging messages - False - Not to send. True: Send
event_syslog	false	True or False	Sets syslog option for events logging messages - False - Not to send. True: Send
rest_syslog	false	True or False	Sets syslog option for UFM REST API logging messages - False - Not to send. True: Send
authentication_syslog	false	True or False	Set syslog option for UFM authentication logging messages. False - Not to send. True: Send
syslog_level	WARNING	CRITICAL, ERROR, WARNING, INFO, DEBUG	<p>Sets global syslog messages logging level. The syslog level is common for all the UFM components.</p> <p>The syslog level that is sent to syslog is the highest among the syslog level and component log level defined in the above section.</p>
syslog_facility	LOG_USER	LOG_KERN, LOG_USER, LOG_MAIL, LOG_DAEMON, LOG_AUTH,	Includes the remote syslog package header value for log message facility.

Field	Default Value	Value Options	Description
		LOG_SYSLOG, LOG_LPR, LOG_NEWS, LOG_UUCP, LOG_CRON, LOG_AUTHPRIV, LOG_FTP, LOG_NTP, LOG_SECURITY, LOG_CONSOLE, LOG_SOLCRON	

```

syslog = false
#syslog configuration (syslog_addr)
# For working with local syslog, set value to: /dev/log
# For working with external machine, set value to: host:port
syslog_addr = /dev/log
# The configured log_dir must have read, write and execute
permission for ufmapp user (ufmapp group).
log_dir = /opt/ufm/files/log
# Main ufm log.
ufm_syslog = false
smclient_syslog = false
event_syslog = false
rest_syslog = false
authentication_syslog = false
syslog_level = WARNING
# Syslog facility. By default - LOG_USER
# possible facility codes:
LOG_KERN, LOG_USER, LOG_MAIL, LOG_DAEMON, LOG_AUTH, LOG_SYSLOG,
# LOG_LPR, LOG_NEWS, LOG_UUCP, LOG_CRON, LOG_AUTHPRIV, LOG_FTP,
LOG_NTP, LOG_SECURITY, LOG_CONSOLE, LOG_SOLCRON
# for reference https://en.wikipedia.org/wiki/Syslog
syslog_facility = LOG_USER

```

## Excluding Unhealthy Ports from Fabric Health Report

In `gv.cfg` file there is a section named **UnhealthyPorts** and parameters in this section are used for unhealthy ports managing in UFM.

Unhealthy port state could be defined by used using UI or REST API request or reported by OpenSM or ibutilities.

UFM has an ability to check periodically fabric ports healthiness and to report unhealthy ports out or to perform automatically predefined isolation action for unhealthy ports.

In addition, using `exclude_unhealthy_ports` key in **UnhealthyPorts** section unhealthy ports could be excluded from `ibdiagnet` report.

By default, the value for this parameter is set as *false*. It means that unhealthy ports will appear in `ibdiagnet` reports, but if need to exclude unhealthy port from `ibdiagnet` reports

this parameter should be set to true and UFM server should be restarted so this action will take effect.

UFM starting flow will configure `indiagnet` configuration file with appropriate parameters and unhealthy ports will not appear in UFM health and Fabric health reports.

```
[UnhealthyPorts]
enable_ibdiagnet = true
log_level = INFO
syslog = false
# scheduling_mode possible values: fixed_time/interval.
# If fixed_time - ibdiagnet will run every 24 hours on the
# specified time - <fixed_time>.
# If interval - ibdiagnet will run first time after <start_delay>
# minutes from UFM startup and every <interval> hours (default
# scheduling mode).
scheduling_mode = interval
# First ibdiagnet start delay interval (minutes)
start_delay = 5
# ibdiagnet run interval (hours)
interval = 3
# ibdiagnet run at a fixed time (example: 23:17:35)
fixed_time = 23:00:00
```

```
# By enabling this flag all the discovered high ber ports will be
marked as unhealthy automatically by UFM
high_ber_ports_auto_isolation = false
# Auto isolation mode - which type of ports should be isolated.
# Options: switch-switch, switch-host, all (default: switch-switch).
auto_isolation_mode = switch-switch
# Trigger Partial Switch ASIC Failure whenever number of
unhealthy ports exceed the defined percent of the total number of
the switch ports.
switch_asic_fault_threshold = 20
# exclude unhealthy ports from ibdiagnet reports
exclude_unhealthy_ports=false
```

## Configuration Examples in gv.cfg

The following show examples of configuration settings in the gv.cfg file:

- Polling interval for Fabric Dashboard information

```
ui_polling_interval = 30
```

- **[Optional]** UFM Server local IP address resolution (by default, the UFM resolves the address by gethostip). UFM Web UI should have access to this address.

```
ws_address = <specific IP address>
```

- HTTP/HTTPS Port Configuration

```
# WebServices Protocol (http/https) and Port
ws_port = 8088
```

```
ws_protocol = http
```

- Connection (port and protocol) between the UFM server and the APACHE server

```
ws_protocol = <http or https>  
ws_port = <port number>
```

For more information, see [Launching a UFM Web UI Session](#).

- SNMP `get-community` string for switches (fabric wide or per switch)

```
# default snmp access point for all devices  
[SNMP]  
port = 161  
gcommunity = public
```

- Enhanced Event Management (Alarmed Devices Group)

```
[Server]  
auto_remove_from_alerted = yes
```

- Log verbosity

```
[Logging]  
# optional logging levels  
#CRITICAL, ERROR, WARNING, INFO, DEBUG  
level = INFO
```

For more information, see "[UFM Logs](#)".

- Settings for saving port counters to a CSV file

```
[CSV]
write_interval = 60
ext_ports_only = no
```

For more information, see "[Saving the Port Counters to a CSV File](#)".

- Max number of CSV files (UFM Advanced)

```
[CSV]
max_files = 1
```

For more information, see "[Saving Periodic Snapshots of the Fabric \(Advanced License Only\)](#)".

### **Note**

The access credentials that are defined in the following sections of the conf/gv.cfg file are used only for initialization:

- SSH\_Server
- SSH\_Switch
- TELNET
- IPMI
- SNMP
- MLNX\_OS

To modify these access credentials, use the UFM Web UI. For more information, see "[Device Access](#)".

- Configuring the UFM communication protocol with MLNX-OS switches. The available protocols are:
  - http
  - https (default protocol for secure communication)

➤ ***For configuring the UFM communication protocol after fresh installation and prior to the first run, set the MLNX-OS protocol as shown below.***

**Example:**

```
[MLNX_OS]
protocol = https
port = 443
```

Once UFM is started, all UFM communication with MLNX-OS switches will take place via the configured protocol.

➤ ***For changing the UFM communication protocol while UFM is running, perform the following:***

1. Set the desired protocol of MLNX-OS in the conf/gv.cfg file (as shown in the example above).
2. Restart UFM.
3. Update the MLNX-OS global access credentials configuration with the relevant protocol port. Refer to "[Device Access](#)" for help.

For the http protocol - default port is 80.

For the https protocol - default port is 443.

4. Update the MLNX-OS access credentials with the relevant port in all managed switches that have a valid IP address.

## Managing Dynamic Telemetry

The management of dynamic telemetry instances involves the facilitation of user requests for the creation of multiple telemetry instances. As part of this process, the UFM enables users to establish new UFM Telemetry instances according to their preferred counters and configurations. These instances are not initiated by the UFM but rather are monitored for their operational status through the use of the UFM Telemetry bring-up tool

For more information on the supported REST APIs, please refer to [UFM Dynamic Telemetry Instances REST API](#).

The configuration parameters can be found in the `gv.cfg` configuration file under the DynamicTelemetry section.

Name	Description	Default value
<code>max_instances</code>	Maximum number of simultaneous running UFM Telemetries.	5
<code>new_instance_delay</code>	Delay time between the start of two UFM Telemetry instances, in minutes.	5
<code>update_discovery_delay</code>	The time to wait before updating the discovery file of each telemetry instance if the fabric has changed, in minutes.	10
<code>endpoint_timeout</code>	Telemetry endpoint timeout, in seconds.	5
<code>bringup_timeout</code>	Telemetry bringup tool timeout, in seconds.	60
<code>initial_exposed_port</code>	Initial port for the available range of ports (range(initial_exposed_port, initial_exposed_port + max_instances)).	9003
<code>instances_sessions_compatibility_interval</code>	Every instances_sessions_compatibility_interval minutes the UFM verifies compliance between instances and sessions to avoid zombie sessions. if 0 is configured this process won't be activate	10

## SM Trap Handler Configuration

The SMTrap handler is the SOAP server that handles traps coming from OpenSM.

There are two configuration values related to this service:

- `osm_traps_debounce_interval` – defines the period the service holds incoming traps
- `osm_traps_throttle_val` – once `osm_traps_debounce_interval` elapses, the service transfers `osm_traps_throttle_val` to the Model Main

### Note

By default, the SM Trap Handler handles up to 1000 SM traps every 10 seconds.

## Setting CPU Affinity on UFM

This feature allows setting the CPU affinity for the major processes of the UFM (such as ModelMain, SM, SHARP, Telemetry).

In order to increase the UFM's efficiency, the number of context-switches is reduced. When each major CPU is isolated, users can decrease the number of context-switches, and the performance is optimized.

The CPU affinity of these major processes is configured in the following two levels:

- Level 1- The major processes initiation.
- Level 2- Preceding initiation of the model's main subprocesses which automatically uses the configuration used in level 1 and designates a CPU for each of the subprocesses.

According to user configuration, each process is assigned with affinity.

By default, this feature is disabled. In order to activate the feature, configure `ls_cpu_affinity_enabled` with `true`, check how many CPUs you have on the machine, and set the

desired affinity for each process.

For example:

```
[CPUAffinity]
Is_cpu_affinity_enabled=true
Model_main_cpu_affinity=1-4
Sm_cpu_affinity=5-13
SHARP_cpu_affinity=14-22
Telemetry_cpu_affinity=22-23
```

The format should be a comma-separated list of CPUs. For example: 0,3,7-11.

The ModelMain should have four cores, and up to five cores. The SM should have as many cores as you can assign. You should isolate between the ModelMain cores and the SM cores.

SHARP can be assigned with the same affinity as the SM. The telemetry should be assigned with three to four CPUs.

## Quality of Service (QoS) Support

Infiniband Quality of Service (QoS) is disabled by default in the UFM SM configuration file.

To enable it and benefit from its capabilities, set the qos flag to TRUE in the `/opt/ufm/files/conf/opensm/opensm.conf` file.

Example:

```
# Enable QoS setup
qos FALSE
```

### Note


The QoS parameters settings should be carefully reviewed before enablement of the qos flag. Especially, sl2vl and VL arbitration mappings should be correctly defined.

For information on Enhanced QoS, see [Appendix – SM Activity Report](#).

## UFM Failover to Another Port

When the UFM Server is connected by two or more InfiniBand ports to the fabric, you can configure UFM Subnet Manager failover to one of the other ports. When failure is detected on an InfiniBand port or link, failover occurs without stopping the UFM Server or other related UFM services, such as mysql, http, DRDB, and so on. This failover process prevents failure in a standalone setup, and preempts failover in a High Availability setup, thereby saving downtime and recovery.

### ***Network Configuration for Failover to IB Port***



To enable UFM failover to another port:

- Configure bonding between the InfiniBand interfaces to be used for SM failover. In an HA setup, the UFM active server and the UFM standby server can be connected differently; but the bond name must be the same on both servers.
- Set the value of fabric\_interface to the bond name. using the `/opt/ufm/scripts/change_fabric_config.sh` command as described in [Configuring](#)

General Settings in gv.cfg. If `ufma_interface` is configured for IPoIB, set it to the bond name as well. These changes will take effect only after a UFM restart. For example, if `bond0` is configured on the `ib0` and `ib1` interfaces, in `gv.cfg`, set the parameter `fabric_interface` to `bond0`.

- If IPoIB is used for UFM Agent, add `bond` to the `ufma_interfaces` list as well.

When failure is detected on an InfiniBand port or link, UFM initiates the give-up operation that is defined in the Health configuration file for OpenSM failure. By default:

- UFM discovers the other ports in the specified bond and fails over to the first interface that is up (SM failover)
- If no interface is up:
  - In an HA setup, UFM initiates UFM failover
  - In a standalone setup, UFM does nothing

If the failed link becomes active again, UFM will select this link for the SM only after SM restart.

## Configuring Managed Switches Info Persistency

UFM uses a periodic system information-pulling mechanism to query managed switches inventory data. The inventory information is saved in local JSON files for persistency and tracking of managed switches' status.

Upon UFM start up, UFM loads the saved JSON files to present them to the end user via REST API or UFM WebUI.

After UFM startup is completed, UFM pulls all managed switches data and updates the JSON file and the UFM model periodically (the interval is configurable). In addition, the JSON files are part of UFM system dump.

The following parameters allow configuration of the feature via `gv.cfg` file:

```
[SrvMgmt]
# how often UFM should send json requests for sysinfo to switches
(in seconds)
```

```

systems_poll = 180
# To create UFM model in large setups might take a lot of time.
# This is an initial delay (in minutes) before starting to pull
sysinfo from switches.
systems_poll_init_timeout = 5
# to avoid sysinfo dump overloading and multiple writing to host
# switches sysinfo will be dumped to disc in json format every
set in this variable
# sysinfo request. If set to 0 - will not be dumped, if set to 1 -
will be dumped every sysinfo request
# this case (as example defined below) dump will be created every
fifth sysinfo request, so if system_poll is 180 sec (3 minutes)
sysinfo dump to the file will e performed every 15 minutes.
sysinfo_dump_interval = 5
# location of the sysinfo dump file (it is in /opt/ufm/files/logs
(it will be part of UFM dump)
sysinfo_dump_file_path = /opt/ufm/files/log/sysinfo.dump

```

## Configuring Partial Switch ASIC Failure Events

UFM can identify switch ASIC failure by detecting pre-defined portion of the switch ports, reported as unhealthy. By default, this portion threshold is set to 20% of the total switch ports. Thus, the UFM will trigger the partial switch ASIC event in case the number of unhealthy switch ports exceeds 20% of the total switch ports.

You can configure UFM to control Partial Switch ASIC Failure events. To configure, you may use the `gv.cfg` file by updating the value of `switch_asic_fault_threshold` parameter under the `UnhealthyPorts` section. For an example, in case the switch has 32 ports, once 7 ports are detected as unhealthy ports, the UFM will trigger the partial switch ASIC event.

Example:

Warning	2023-01-25 10:41:22	Unhealthy IB Port	default(2) / Switch: sw-ufm-qr	IBPort	Peer Port is considered by SM as unhealthy due to MANUAL.
Warning	2023-01-25 10:41:02	Unhealthy IB Port	default(2) / Switch: sw-ufm-qr	IBPort	Peer Port "r-ufm51 HCA-1" is considered by SM as unhealthy due to MANUAL.
Critical	2023-01-25 10:41:02	Partial Switch ASIC Failure	default / Switch: sw-ufm-qm0	Switch	Number of switch unhealthy ports has been exceeded the defined threshold which is (4) perc
Info	2023-01-25 10:40:43	MCast Group Deleted	default(2)	Site	Mcast group is deleted: ff12601bffff0000, 1ff18fe80

## Enabling Network Fast Recovery

## **i** Note

To enable the Network Fast Recovery feature, ensure that all switches in the fabric use the following MLNX-OS/firmware versions:

- MLNX-OS version 3.10.6004 and up
- Quantum firmware versions:
  - Quantum FW v27.2010.6102 and up
  - Quantum2 FW v31.2010.6102 and up

Fast recovery is a switch-firmware based facility for isolation and mitigation of link-related issues. This system operates in a distributed manner, where each switch is programmed with a simple set of rule-based triggers (conditions) and corresponding action protocols. These rules permit the switch to promptly react to substandard links within its locality, responding at a very short reaction time - as little as approximately 100 milliseconds. The policy is provided and managed via the UFM and SM channel. Moreover, every autonomous action taken by a switch in the network is reported to the UFM.

The immediate reactions taken by the switch enable SHIELD and pFRN. These mechanisms collaborate to rectify routing within the proximity of the problematic link before it can disrupt transactions at the transport layer. Importantly, this process occurs rapidly, effectively limiting the spreading of congestion to a smaller segment of the network.

To use the Network Fast Recovery feature, you need to enable the designated trigger (condition) in the `gv.cfg` file. By doing this, you can specify which of the below four triggers the UFM will support.

As stated in the `gv.cfg` file, the feature is disabled by default and the below are the supported fields and options:

```
[NetworkFastRecovery]
# Fast Recovery configuration.
# Supported values:
```

```

#    0: Ignore fast recovery related MADs and configuration
#    (default)
#    1: Disable fast recovery
#    2: Enable fast recovery
fast_recovery_mode = 0

# This will be supported by the Network Fast Recovery.
network_fast_recovery_conditions =
SWITCH_DECISION_CREDIT_WATCHDOG, SWITCH_DECISION_RAW_BER, SWITCH_DEC:

```

**Note**

To enable the Network Fast Recovery feature, the value of `fast_recovery_mode` should be set to 2. For the change to take effect, restart of UFM Enterprise is required.

Parameter	Description
SWITCH_DECISION_CREDIT_WATCHDOG	The Switch decided to close the port due to Credit watchdog
SWITCH_DECISION_RAW_BER	The Switch decided to close the port due to High raw errors
SWITCH_DECISION_EFFECTIVE_BER	The Switch decided to close the port due to High effective errors (after FEC)
SWITCH_DECISION_SYMBOL_BER	The Switch decided to close the port due to High symbol errors (after PLR)

By default, the Network Fast Recovery feature operates in monitoring mode. This means the switch does not reset ports, however, it reports issues related to them. To view these port-related issues, you must deploy the UFM PMC (Packet Monitoring Collector) plugin and use its UI to access the relevant network events.

For more details on the PMC plugin, including deployment instructions and how to view Network Fast Recovery events, please refer to [Packet Level Monitoring Collector \(PMC\) Plugin](#).

## Disabling Rest Roles Access Control

By default, the Rest Roles Access Control feature is enabled. It can be disabled by setting the `roles_access_control_enabled` flag to `false`:

```
[RolesAccessControl]
roles_access_control_enabled = true
```

## Enabling/Disabling Authentication

### Kerberos Authentication

By default, [Kerberos Authentication](#) is disabled. To enable it, set the `kerberos_auth_enabled` flag to `true`. Additionally, provide the required configurations such as `kerberos_cred_key_path`, `kerberos_use_local_name` and `kerberos_auto_sign_up`.

```
[KerberosAuth]
# This section responsible to manage kerberos authentication
# Set to true to enable the kerberos auth feature, and set to false
to disable it. Default is false.
kerberos_auth_enabled = false
# The path of the keytab file containing credentials for GSSAPI
authentication.
kerberos_cred_key_path = /etc/kadm5.keytab
# Set to true to configure the Apache server to map authenticated
principal names (which represent different clients) to local
usernames,
# and set to false to use the principle names as usernames. Default
is true (this value will be reflected in the 'GssapiLocalName' directive
in Apache).
kerberos_use_local_name = true
```

```
# Set to true to enable auto sign up of users who do not exist in
UFM DB. Default is true.
kerberos_auto_sign_up = true
# The default role assigned to create users if they do not exist when
'kerberos_auto_sign_up' is set to true.
kerberos_default_role = System_Admin
```

**kerberos\_auth\_enabled:** By default, Kerberos authentication remains disabled. To activate it, the user must set this flag to 'true' and then restart UFM.

**kerberos\_cred\_key\_path:** This specifies the path to the keytab file containing credentials for GSSAPI authentication.

**kerberos\_use\_local\_name:** Set to true to configure the Apache server to map authenticated principal names (which represent different clients) to local usernames, and set to false to use the principal names as usernames. Default is true (this value will be reflected in the 'GssapiLocalName' directive in Apache).

**kerberos\_auto\_signup:** For successful authentication via Kerberos, the user must already exist within the UFM database, otherwise, the authentication will be refused by UFM. If this property is set to 'true,' UFM will create the non-existing users in the UFM DB.

**kerberos\_default\_role:** The default role is assigned to create users if they do not exist when 'kerberos\_auto\_sign\_up' is set to true.

Finally, restart the UFM to use Kerberos authentication.

## UFM Authentication Server

By default, [UFM Authentication Server](#) is enabled. To disable it, you need to set the "auth\_service\_enabled" parameter to 'false' and then restart the UFM service to initiate the authentication server. Additionally, you can use enable/disable flags for Basic, Session, and Token authentication:

```
[AuthService]
auth_service_enabled = true
auth_service_interface = 127.0.0.1
```

```
auth_service_port = 8087 # the serving port for the authentication
server
basic_auth_enabled = true
session_auth_enabled = true
token_auth_enabled = true
```

## Azure AD Authentication

By default, [Azure AD Authentication](#) is disabled. To enable it, set the `azure_auth_enabled` flag to 'true'. Additionally, provide the required configurations from the Azure AD Application such as `TENANT_ID`, `CLIENT_ID` and `CLIENT_SECRET` which can be found under the "**Overview**" section of the registered application in the Azure portal. Finally, the [UFM Authentication Server](#) should be enabled to use the Azure AD Authentication.

```
[AzureAuth]
azure_auth_enabled = false
# TENANT ID of app registration
TENANT_ID =
# Application (client) ID of app registration
CLIENT_ID =
# Application's generated client secret
CLIENT_SECRET =
```

## Adjusting UFM Configuration Files Based on Fabric Size

This function allows users to automate the process of updating the UFM configuration files by parsing a primary configuration file called `large_scale_subnet.cfg` file and applying the values to multiple target files or resetting to default values using the `small_scale_subnet.cfg`.

The below are instructions on how to use a Python script to parse a configuration file (`large_scale_subnet.cfg`) and update the values of specific parameters in multiple target UFM configuration files (`gv.cfg`, `reports.cfg`, `opensm.cfg`, and `sharp_am.cfg`). The script can operate in two modes:

- **Large Scale Subnet Mode:** This mode directly updates the UFM configuration files based on the parsed configuration from the `large_scale_subnet.cfg` file.
- **Small Scale Subnet (Default) Mode:** Sets the UFM configuration files to their default values by parsing the `small_scale_subnet.cfg` file.

## Configuration File and Parameters

The primary configuration file contains all the parameters, and their values must be updated over the multiple UFM configuration files.

### Primary Configuration Files

- `/opt/ufm/files/conf/ large_scale_subnet.cfg`
- `/opt/ufm/files/conf/ small_scale_subnet.cfg`

### Target UFM Configuration Files

- `/opt/ufm/files/conf/gv.cfg`
- `/opt/ufm/files/conf/reports.cfg`
- `/opt/ufm/files/conf/opensm/opensm.conf`
- `/opt/ufm/files/conf/sharp/sharp_am.cfg`

Example structure of `large_scale_subnet.cfg` and `small_scale_subnet.cfg`:

```
[GV]
[GV.Server]
# disabled (default) | enabled (configure opensm with multiple
GUIDs) | ha_enabled (configure multiport SM with high
availability).
multi_port_sm = ha_enabled
# report_events that will determine which trap to send to ufm
all/security/none
report_events = security
```

```

[GV.FabricAnalysis]
# initial_delay (in minutes) - the initial delay for running
fabric analysis for the first time after UFM was started
initial_delay = 10

[GV.logrotate]
#max_files specifies the number of times to rotate a file before
it is deleted.
#A count of 0 (zero) means no copies are retained. A count of 10
means fifteen copies are retained (default is 10)
max_files = 10

[REPORTS]
[REPORTS.FabricHealth]
# Fabric health report timeout
timeout = 1800

[REPORTS.TopologyCompare]
# Topology compare report timeout
timeout = 1800

[REPORTS.FabricAnalysis]
# Fabric analysis report timeout
timeout = 1800

[OPENSMB]
#Amount of physical port to handle in one shot
virt_max_ports_in_process = 512
max_op_vls = 2
qos = TRUE
# Single MAD Sl2vl for all ports
use_optimized_slvl = TRUE
# Timeout for long MAD config time. might need to change 1000
long_transaction_timeout = 500
routing_engine = ar_updn

```

```

use_ucast_cache = TRUE
root_guid_file = /opt/ufm/files/conf/opensm/root_guid.conf
pgrp_policy_file = /opt/ufm/files/conf/opensm/pgrp_policy.conf

[SHARP]
ib_qpc_sl = 1
fabric_update_interval = 10
lst_file_timeout = 10
lst_file_retries = 30
max_tree_radix = 80
generate_dump_files = TRUE
dynamic_tree_allocation = TRUE
dynamic_tree_algorithm = 1
smx_keepalive_interval = 10

```

### Script Usage Example in the CLI:

- **Large Scale Subnet Mode:** `/opt/ufm/scripts/set_ufm_scale_profile.sh --mode large_scale_subnet --force_update`
- **Small Scale Subnet (Default) Mode:** `/opt/ufm/scripts/ set_ufm_scale_profile.sh --mode small_scale_subnet`

The `force_update` script parameter adds any parameters found in `large_scale_subnet.cfg` and `small_scale_subnet.cfg` that are not present in the UFM configuration files. For example, if a user adds a new parameter called `test_param = 500` to the `large_scale_subnet.cfg` file under the `[Server]` section and this parameter does not exist in the `gv.cfg` file, running the script with the `--force_update` option will add `test_param = 500` to the `[Server]` section of the `gv.cfg` file.

### Expected Output

#### 1. Large Scale Subnet Mode:

- The script reads `large_scale_subnet.cfg`.
- It updates the parameters in the target UFM configuration files based on the parsed data.
- It logs messages for any skipped parameters.

## 1. **Small Scale Subnet - Default Mode:**

- The script reads `small_scale_subnet.cfg`.
- It updates the parameters in the target UFM configuration files based on the parsed data.
- It logs messages for any skipped parameters or adds the parameter to the configuration file if the `force_update` was `True`.

### **Note**

**Note:** In case of the script running failure, the script will reset the UFM configuration files to their default values.

## Setting up Telemetry in UFM

Setting up telemetry deploys UFM Telemetry as bare metal on the same machine. Historical data is sent to SQLite database on the server and live data becomes available via UFM UI or REST API.

## Enabling UFM Telemetry

The UFM Telemetry feature is enabled by default and the provider is the UFM Telemetry. The user may change the provider via flag in `conf/gv.cfg`

The user may also disable the History Telemetry feature in the same section.

```
[Telemetry]
history_enabled=True
```

# Changing UFM Telemetry Default Configuration

There is an option to configure parameters on a telemetry configuration file which takes effect after restarting the UFM or failover in HA mode. The `launch_ibdiagnet_config.ini` default file is located under `/opt/ufm/conf/telemetry_defaults` and is copied to the telemetry configuration location (`/opt/ufm/conf/telemetry`) upon startup UFM.

All values taken from the default file take effect at the deployed configuration file except for the following:

Note that normally the user does not have to do anything and they get two pre-configured instances – one for low frequency and one for higher-frequency sampling of the network.

Value	Description
<code>hca</code>	-
<code>scope_file</code>	-
<code>plugin_env_PROMETHEUS_ENDPOINT</code>	The port on which HTTP endpoint is configured
<code>plugin_env_PROMETHEUS_INDEXES</code>	Configures how data is indexed and stored in memory
<code>config_watch_enabled=true</code>	Configures network watcher to inform ibdiagnet that network topology has changed (as ibdiagnet lacks the ability to re-discover network changes)
<code>plugin_env_PROMETHEUS_CSET_DIR</code>	Specifies where the counterset files, which define the data to be retrieved and the corresponding counter names.
<code>num_iterations</code>	The number of iterations to run before 'restarting', i.e. rediscovering fabric.
<code>plugin_env_CLX_RESTART_FILE</code>	A file that is 'touched' to indicate that an ibdiagnet restart is necessary

The following attributes are configurable via the `gv.cfg`:

- `sample_rate` (`gv.cfg` → `dashboard_interval`) – only if `manual_config` is set to `false`
- `prometheus_port`

# Supporting Generic Counters Parsing and Display

As of UFM v6.11.0, UFM can support any numeric counters from the HTTP endpoint. The list of supported counters are fetched upon starting the UFM from all the endpoints that are configured.

Some of the implemented changes are as follows:

1. Counter naming – all counters naming convention is extracted from the HTTP endpoint. The default `cset` file is configured as follows:

“`Infiniband_LinkIntegrityErrors=^LocalLinkIntegrityErrorsExtended$`” to get this name to the UFM.

Counters received as floats should contain an “\_f” suffix such as:

`Infiniband_CBW_f=^infiniband_CBW$`

2. Attribute units – To see units of a specific counter on the UI graphs, configure the `cset` file to have the counter returned as “`counter_name_u_unit`”.

3. Telemetry History:

The SQLite history table (`/opt/ufm/files/sqlite/ufm_telemetry.db – telemetry_calculated`), contains the new naming convention of the telemetry counters.

In the case of an upgrade, all previous columns that were configured are renamed following the new naming convention, and then, the data is saved. If a new counter that is not in the table needs to be supported, the table is altered upon UFM start.

4. New counter/`cset` to fetch – if there is a new `cset`/counter that needs to be supported AFTER the UFM already started, perform system restart.
5. Created New API/`UfmRestV2/telemetry/counters` for the UI visualization. This API returns a dictionary containing the counters that the UFM supports, based on the fetched URLs and their units (if known).

# Supporting Multiple Telemetry Instances Fetch

This functionality allows users to establish distinct Telemetry endpoints that are defined to their preferences.

Users have the flexibility to set the following aspects:

- Specify a list of counters they wish to pull. This can be achieved by selecting from an existing, predefined counters set (cset file) or by defining a new one.
- Set the interval at which the data should be pulled.

Upon initiating the Telemetry endpoint, users can access the designated URL to fetch the desired counter data.

To enable this feature, under the [Telemetry] section in `gv.cfg`, the flag named “additional\_cset\_url” holds the list of additional URLs to be fetched.

the URLs should be separated by “ ” (with a space) and should follow the following format: `http://:/csv/`. For example <http://10.10.10.10:9001/csv/minimal> <http://10.10.10.10:9002/csv/test>.

### Note

Only csv extensions are supported.

Each UFM Telemetry instance run by UFM can support multiple cset (counters set) in parallel. If the user would like to have a second cset file fetched by UFM and exposed by the same UFM Telemetry instance, the new cset file should be placed under `/opt/ufm/files/conf/telemetry/prometheus_configs/cset/` and configured in `gv.cfg` to fetch its data as described above.

## Low-Frequency (Secondary) Telemetry

As a default configuration, a second UFM Telemetry instance runs, granting access to an extended set of counters that are not available in the default telemetry session. The default telemetry session is used for the UFM Web UI dashboard and user-defined telemetry views. These additional counters can be accessed via the following API endpoint: **`http://<UFM_IP>:9002/csv/xcset/low_freq_debug`**. It is important to note that these exposed counters are not accessible through UFM's REST APIs. All the configurations for the second telemetry can be found under `/opt/ufm/files/conf/secondary_telemetry/`, where the defaults are located under `/opt/ufm/files/conf/secondary_telemetry_defaults/`. The second telemetry instance also allows telemetry data to be exposed on disabled ports, although this feature can be disabled if desired.

The relevant flags in the gv.cfg file are as follows:

- secondary\_telemetry = true (To enable or disable the entire feature)
- secondary\_endpoint\_port = 9002 (The endpoint's exposed port)
- secondary\_disabled\_ports = true (If set to true, secondary telemetry will expose data on disabled ports)
- secondary\_slvl\_support = false (if set to true, low-frequency (secondary) Telemetry will collect counters per slvl, the corresponding supported xcset can be found under /opt/ufm/files/conf/secondary\_telemetry/prometheus\_configs/cset/low\_freq\_debug\_

The counters that are supported by default, collected, and exposed can be located in the directory /opt/ufm/files/conf/secondary\_telemetry/prometheus\_configs/cset/low\_freq\_debug\_per\_slvl.xcset.

For the list of low-frequency (secondary) telemetry fields and available counters, please refer to [Low-Frequency \(Secondary\) Telemetry Fields](#).

## Low-Frequency (Secondary) Telemetry - Exposing IPv6 Counters

To allow the low-frequency (secondary) telemetry instance to expose counters on its IPv6 interfaces, perform the following:

1. Change the following flag in the gv.cfg:

```
secondary_ip_bind_addr =0:0:0:0:0:0:0:0
```

2. Restart UFM telemetry or restart UFM.

## Stopping Telemetry Endpoint Using CLI Command

To stop low-frequency (secondary) telemetry endpoint only using the CLI you may run the following command:

```
/etc/init.d/ufmd ufm_telemetry_secondary_stop
```

## Exposing Switch Aggregation Nodes Telemetry

To expose switches SHARP aggregation nodes telemetry, follow the below steps:

- Configure the low-frequency (secondary) telemetry instance. Run:

```
vi
/opt/ufm/files/conf/secondary_telemetry_defaults/launch_ibdiag
```

- Set the following:
  - `arg_16=--sharp --sharp_opt dsc`
  - `plugin_env_CLX_EXPORT_API_SKIP_SHARP_PM_COUNTERS=0`
- Add the wanted attributes to the default `xcset` or to a new one:

- New `xcset` –

```
vi
/opt/ufm/files/conf/secondary_telemetry/prometheus
for your choise>.xcset
```

- After restarting, query `curl http://<UFM_IP>:9002/csv/xcset/<chosen_name>`

- Existing `xcset` –

```
vi
/opt/ufm/files/conf/secondary_telemetry/prometheus
```

- -

- Add the following attributes:
  - packet\_sent
  - ack\_packet\_sent
  - retry\_packet\_sent
  - rnr\_event
  - timeout\_event
  - oos\_nack\_rcv
  - rnr\_nack\_rcv
  - packet\_discard\_transport
  - packet\_discard\_sharp
  - aeth\_syndrome\_ack\_packet
  - hba\_sharp\_lookup
  - hba\_received\_pkts
  - hba\_received\_bytes
  - hba\_sent\_ack\_packets
  - rcds\_sent\_packets
  - hba\_sent\_ack\_bytes
  - rcds\_send\_bytes
  - hba\_multi\_packet\_message\_dropped\_pkts
  - hba\_multi\_packet\_message\_dropped\_bytes
- Restart telemetry:

```
/etc/init.d/ufmd ufm_telemetry_stop  
/etc/init.d/ufmd ufm_telemetry_start
```

## Exposing Performance Histogram Counters for Egress Queue Depth Indications (Secondary) Telemetry

To enable the secondary telemetry instance to expose performance histogram counters for all VLs, perform the following:

1. Change the following flag in the `gv.cfg` file:

```
queue_depth_indications_all_vls = true
```

If this flag remains set to `false`, the secondary telemetry instance will only collect counters for VLs 0 and 1.

2. Restart UFM telemetry or restart UFM.

After the secondary telemetry instance restarts, you can find the collected counters at:

```
/opt/ufm/conf/secondary_telemetry/prometheus_configs/cset/low_freq.
```

# Running UFM Server Software

Before running UFM:

- Perform [Initial Configuration](#)

- Ensure that all ports used by the UFM server for internal and external communication are open and available. For the list of ports, see [Used Ports](#).

You can run the UFM server software in the following modes:

- - [Running UFM Server Software in Management Mode](#)
  - [Running UFM Software in High Availability Mode](#)
  - Running UFM in High Availability with failover to an external SM

### **Note**

In Management or High Availability mode, ensure that all Subnet Managers in the fabric are disabled *before* running UFM. Any remaining active Subnet Managers will prevent UFM from running.

## Running UFM Server Software in Management Mode

After installing, run the UFM Server by invoking:

```
systemctl start ufm-enterprise.service
```

### **Note**

`/etc/init.d/ufmd` - Available for backward compatibility.

Log files are located under `/opt/ufm/files/log` (the links to log files are in `/opt/ufm/log`).

## Running UFM Software in High Availability Mode

On the Master server, run the UFM Server by invoking:

```
ufm_ha_cluster start
```

You can specify additional command options for the `ufmha` service.

### ***ufm\_ha\_cluster Command Options***

Command	Description
start	Starts UFM HA cluster.
stop	Stops UFM HA cluster.
failover	Initiates failover (change mastership from local server to remote server).
takeover	Initiates takeover (change mastership from remote server to local server).
status	Shows current HA cluster status.
cleanup	Cleans the HA configurations on this node.
help	Displays help text.

## **HTTP/HTTPS Configuration**

By default, UFM is configured to work with the secured HTTPS protocol.

After installation, the user can change the the Web Server configuration to communicate in secure (HTTPS) or non-secure (HTTP) protocol.

For changing the communication protocol, use the following parameter under the [Server] section in the `gv.cfg` file:

- `ws_protocol = https`

Changes will take effect after restarting UFM.

## **UFM Internal Web Server Configuration**

UFM uses Apache as the main Web Server for client external access. The UFM uses an internal web server process to where the Apache forwards the incoming requests.

By default, the internal web server listens to the local host interface (127.0.0.1) on port 8000.

For changing the listening local interface or port, use the following parameters under the [Server] section in the `gv.cfg` file:

- `rest_interface = 127.0.0.1`
- `rest_port = 8000`

Changes will take effect after restarting UFM.

## User Authentication

UFM User Authentication is based on standard Apache User Authentication. Each Web Service client application must authenticate against the UFM server to gain access to the system.

The UFM software comes with one predefined user:

- Username: admin
- Password: 123456

You can add, delete, or update users via [User Management Tab](#).

## UFM Authentication Server

The UFM Authentication Server, a centralized HTTP server, is responsible for managing various authentication methods supported by UFM.

## Configurations of the UFM Authentication Server

The UFM Authentication Server is designed to be configurable and is initially turned off by default. This means that existing authentication methods are managed either by the native Apache functionality (such as Basic, Session, and Client Certificate authentication) or at the UFM level (including Token-Based authentication and Proxy Authentication).

Enabling the UFM Authentication Server provides a centralized service that oversees all supported authentication methods within a single service, consolidating them under a unified authentication API.

Apache utilizes the authentication server's APIs to determine a user's authentication status.

To enable the UFM Authentication Server, refer to [Enabling UFM Authentication Server](#).

All activities of the UFM Authentication Server are logged in the `authentication_service.log` file, located at `/opt/ufm/files/log`.

## Azure AD Authentication


Microsoft Azure Authentication is a service provided by Microsoft Azure, the cloud computing platform of Microsoft. It is designed to provide secure access control and authentication for applications and services hosted on Azure.

UFM supports Authentication using Azure Active Directory, and to do so, you need to follow the following steps:

### Register UFM in Azure AD Portal

To log in via Azure, UFM must be registered in the Azure portal using the following steps:

1. Log in to [Azure Portal](#), then click "**Azure Active Directory**" in the side menu.
2. If you have access to more than one tenant, select your account in the upper right. Set your session to the Azure AD tenant you wish to use.
3. Under "**Manage**" in the side menu, click App Registrations > New Registration.



#### 4. Provide the application details:

1. **Name:** Enter a descriptive name.
2. **Supported account types:** Account types that are allowed to login and use the registered application.
3. **Redirect URL:** select the app type **Web**, and Add the following redirect URL `https:///auth/login`

## Register an application ...

### \* Name

The user-facing display name for this application (this can be changed later).

UFM\_APP ✓

### Supported account types

Who can use this application or access this API?

- Accounts in this organizational directory only (NVIDIA Corporation only - Single tenant)
- Accounts in any organizational directory (Any Azure AD directory - Multitenant)
- Accounts in any organizational directory (Any Azure AD directory - Multitenant) and personal Microsoft accounts (e.g. Skype, Xbox)
- Personal Microsoft accounts only

[Help me choose...](#)

### Redirect URI (optional)

We'll return the authentication response to this URI after successfully authenticating the user. Providing this now is optional and it can be changed later, but a value is required for most authentication scenarios.

Web ✓  ✓

Register an app you're working on here. Integrate gallery apps and other apps from outside your organization by adding from [Enterprise applications](#).

By proceeding, you agree to the [Microsoft Platform Policies](#)

[Register](#)

Then, click **Register**. The app's **Overview** page opens.

5. Under **Manage** in the side menu, click **Certificates & Secrets** > New client secret.

## Add a client secret



Description

UFM\_APP\_sec


Expires

Recommended: 180 days (6 months) ✓

Provide a description for the client secret and set an expiration time, then click **"Add."**

6. Copy the client secret key value which will be needed to configure the UFM with Azure AD (Please note that the value of the generated secret will be hidden and will not be able to be copied/read after you leave the page.

Under **"Manage"** in the side menu, click App roles > Create app role.



7. Provide the role details. Please note that the role value must be a valid UFM role; otherwise, the login will fail.

## Create app role ✕

Display name \* ⓘ

System\_Admin ✓

Allowed member types \* ⓘ

Users/Groups  
 Applications  
 Both (Users/Groups + Applications)

Value \* ⓘ

System\_Admin ✓

Description \* ⓘ

System\_Admin

Do you want to enable this app role? ⓘ

8. Assign the created role to the user. Follow the below steps:

✦ ...

+ Create app role | 🗨️ Got feedback?

📘 Got a second to give us some feedback? →

### App roles

App roles are custom roles to assign permissions to users or apps. The application determines the permissions during authorization.

**How do I assign App roles** 1

Display name	Description	Allowed member ty...	Value
System_Admin	System_Admin	Users/Groups,Applicat...	Syste

## Assigning app roles ✕

App roles for Users/Groups

Assign app roles with 'User' allowed member types in **Enterprise** applications or in Microsoft Graph APIs. 2

[Learn more about how to assign App roles for Users/Groups](#)

App roles for applications

Assign app roles with 'Applications' allowed member types in API permissions blade.

## Properties

**UF** Name ⓘ Copy to clipboard  
UFM-APP

Application ID ⓘ  
0d5e6cda-9144-47a2-b685-...

Object ID ⓘ  
dd2a68d5-a3e0-45e3-9c1c-...

## Getting Started

3

 **1. Assign users and groups**  
Provide specific users and groups access to the applications  
[Assign users and groups](#)

 **2. Provision User Accounts**  
You'll need to create user accounts in the application  
[Learn more](#)

 **3. Self service**  
Enable users to request access to the application using their Azure AD credentials  
[Get started](#)

+ Add user/group **4** [Edit assignment](#) [Remove](#) [Update credentials](#) | [Columns](#) | [Got feedback?](#)

**i** The application will not appear for assigned users within My Apps. Set 'visible to users?' to yes in properties to enable this. →

Assign users and groups to app-roles for your application here. To create new app-roles for this application, use the [application registration](#).

Display Name	Object Type	Role assigned
No application assignments found		

## Add Assignment

NVIDIA Corporation

Users and groups

1 user selected.

Select a role \*

System\_Admin


9. Click on "**Overview**" in the side menu to view the application information, such as tenant ID, client ID, and other details.

## Enable Azure Authentication From UFM

Azure authentication is disabled by default. To enable it, please refer to [Enabling Azure AD Authentication](#).

## Azure Authentication Login Page

After enabling and configuring Azure AD authentication, an additional button will appear on the primary UFM login page labeled 'Sign In with Microsoft,' which will lead to the main Microsoft sign-in page:



The screenshot shows the NVIDIA UFM login interface. At the top, there is a black header with the NVIDIA logo and the text 'NVIDIA. UFM'. Below the header, there are two input fields: 'Username' and 'Password'. A green 'Login' button is positioned below the password field. Below the 'Login' button, the word 'OR' is centered. At the bottom, there is a green button labeled 'Sign in with Microsoft'.

# Kerberos Authentication

Kerberos is a network authentication protocol designed to provide strong authentication for client-server applications by using secret-key cryptography.

The Kerberos protocol works on the basis of tickets, it helps ensure that communication between various entities in a network is secure. It uses symmetric-key cryptography, which means both the client and servers share secret keys for encrypting and decrypting communication.

To enable Kerberos Authentication, refer to [Enabling Kerberos Authentication](#).

## Setting Up Kerberos Server Machine

To set up a system as a Kerberos server, perform the following:

1. Install the required packages:

```
#Redhat
sudo yum install krb5-libs krb5-server
# Ubuntu
sudo apt-get install krb5-kdc krb5-admin-server
```

2. Edit the Kerberos configuration file '/etc/krb5.conf' to reflect your realm, domain and other settings:

```
[libdefaults]
    default_realm = YOUR-REALM

[realms]
    YOUR-REALM = {
        kdc = your-kdc-server
        admin_server = your-admin-server
    }

[domain_realm]
```

```
your-domain = YOUR-REALM  
your-domain = YOUR-REALM
```

3. Use the `kdb5_util` command to create the Kerberos database:

```
kdb5_util create -r YOUR-REALM -s
```

4. Add administrative principals:

```
Kadmin.local addprinc -randkey HTTP/YOUR-HOST-NAME@YOUR-  
REALM
```

5. Start KDC and Kadmin services:

```
sudo systemctl start krb5kdc kadmin  
sudo systemctl enable krb5kdc kadmin
```

6. Generate a keytab file. The keytab file contains the secret key for a principal and is used to authenticate the service.

```
kadmin.local ktadd -k /path/to/your-keytab-file HTTP/YOUR-  
HOST-NAME@YOUR-REALM
```

Replace `/path/to/your-keytab-file` with the actual path where you want to store the keytab file.

## Setting Up Kerberos Client Machine

Follow the below steps to set up a system as a Kerberos client.

1. Install the required packages. When installing the UFM, the following packages will be installed as dependencies:

```
#Redhat
krb5-libs krb5-workstation mod_auth_gssapi
# Ubuntu
krb5-config krb5-user libapache2-mod-auth-gssapi
```

2. Configure the `/etc/krb5.conf` file to reflect your realm, domain, local names map and other settings:

```
[libdefaults]
    default_realm = YOUR-REALM

[realms]
    YOUR-REALM = {
        kdc = your-kdc-server
        admin_server = your-admin-server
        auth_to_local_names = {
            your-principle-name = your-local-user
        }
    }

[domain_realm]
    your-domain = YOUR-REALM
    your-domain = YOUR-REALM
```

3. Copy the keytab file from the Kerberos server to the machine where your service runs (the client). It is important to ensure that it is kept confidential.

Please ensure that the keytab file exists and that Apache has the necessary read permissions to access the keytab file; otherwise, Kerberos authentication will not function properly.

4. Obtain a Kerberos ticket-granting ticket (TGT):

```
kinit -k -t /path/to/your-keytab-file HTTP/YOUR-HOST-NAME@YOUR-REALM
```

5. Enable Kerberos Authentication from UFM. Kerberos authentication is disabled by default. To enable it, please refer to [Enabling Kerberos Authentication](#).

6. Test the Kerberos Authentication. You can use curl to test whether the user can authenticate to UFM REST APIs using Kerberos.

```
curl --negotiate -i -u : -k 'https://ufmc-eos01/ufmRestKrb/app/tokens'
```

## Licensing

UFM license is subscription-based featuring the following subscription options:

- 1-year subscription
- 3-year subscription
- 5-year subscription
- Evaluation 30-day trial license

### Note

UFM will continue to support old license types, but they are no longer available to obtain.

2 months before the expiration of your subscription license, UFM will warn you that your license will expire soon. After the subscription expires, UFM will continue to work with the expired license for two months beyond its expiration.

During this extra two-month period, UFM will generate a critical alarm indicating that the UFM license has expired and that you need to renew your subscription. Failing to do so within that 2-month period activates UFM Limited Mode. Limited mode blocks all REST APIs and access to the UFM web UI.

UFM enables functionality based on the license that was purchased and installed. This license determines the functionality and the maximum allowed number of nodes in the fabric.

To renew your UFM subscription, purchase a new license and install the new license file by downloading the license file to a temp directory on the UFM master server and then copying the license file to `/opt/ufm/files/licenses/` directory.

### **Note**

UFM may not detect new license files if downloaded directly to `/opt/ufm/files/licenses`. If UFM does not detect the new license file, a UFM restart may be required.

If several licenses are installed on the server (more than one license file exists under `/opt/ufm/files/licenses/`), UFM uses only the strongest license and takes into consideration the expiration date, and the managed device limits on it, regardless of any other licenses that may exist on the server.

## **Showing UFM Processes Status**

This functionality allows users to view the current status of main processes handled by the UFM.

- To view the main UFM processes, run the script `show_ufm_status.sh` under the `/opt/ufm/scripts`. Example: `/opt/ufm/scripts/show_ufm_status.sh`
- To view the UFM main and child processes, run the script `show_ufm_status.sh` with `-e` (extended\_processes).

Example: `/opt/ufm/scripts/show_ufm_status.sh -e`

```
[root@r-ufm77 gvm_github]# /opt/ufm/scripts/show_ufm_status.sh
=====
                        UFM Main Processes
=====
ModelMain      Process is : [ Running ]
Opensm         Process is : [ Running ]
SHARP          Process is : [ Running ]
Unhealthy Ports Process is : [ Running ]
Daily Report   Process is : [ Running ]
UFM Health     Process is : [ Running ]
UFM Telemetry  Process is : [ Running ]

-----

[root@r-ufm77 gvm_github]# /opt/ufm/scripts/show_ufm_status.sh -e
=====
                        UFM Main Processes
=====
ModelMain      Process is : [ Running ]
Opensm         Process is : [ Running ]
SHARP          Process is : [ Running ]
Unhealthy Ports Process is : [ Running ]
Daily Report   Process is : [ Running ]
UFM Health     Process is : [ Running ]
UFM Telemetry  Process is : [ Running ]

-----
                        UFM ModelMain Child Processes
-----
SMClientConsumer Process is : [ Running ]
SMTrapHandler    Process is : [ Running ]
SysinfoJsonAgent Process is : [ Running ]
Telemetry Agent  Process is : [ Running ]
Telemetry History Process is : [ Running ]
```

## Upgrading UFM Software

After UFM installation, UFM detects existing UFM versions previously installed on the machine and prompts you to run a clean install of the new version or to upgrade. We recommend backing up the UFM configuration before upgrading the UFM as specified in the section UFM Database and Configuration File Backup.

### Info

Upgrading the UFM Enterprise software version is supported up to two previous GA software versions (GA -1 or GA -2).

For example, if you wish to upgrade to UFM Enterprise v6.11.0, it is possible to do so only from UFM Enterprise v6.9.0 or v6.10.0.

- [Upgrading UFM on Bare Metal Server](#)
- [Upgrading UFM on Docker Container](#)

# Upgrading UFM on Bare Metal Server

## Upgrading UFM on Bare Metal - Standalone Server Upgrade

You can upgrade the UFM standalone server software for InfiniBand from the previous UFM version.

To upgrade the UFM server software:

1. Create a temporary directory (for example `/tmp/ufm`).
2. Open the UFM software zip file that you downloaded. The zip file contains the following installation files for:
  - RedHat 7/CentOS 7/OEL 7: `ufm-X.X -XXX.el7.x86_64.tgz`
  - RedHat 8/CentOS 8/OEL 8: `ufm-X.X -XXX.el8.x86_64.tgz`
  - Ubuntu 18.04: `ufm-X.X -XXX.ubuntu18.x86_64.tgz`
  - Ubuntu 20.04: `ufm-X.X -XXX.ubuntu20.x86_64.tgz`
  - Ubuntu 22.04: `ufm-X.X-XXX.ubuntu22.x86_64.tgz`
3. Extract the installation file for your system's OS to the temporary directory that you created.
4. Stop the UFM server. Run:

```
systemctl stop ufm-enterprise
```

5. From within the temporary directory, run the following command as root:

```
./upgrade.sh
```

**Note**

A configuration backup ZIP file will be created in the running directory (e.g. /tmp/ufm). The backup file name is ufm\_X.X.X\_bkp.zip (X.X.X is the previous version).

1. Upgrade from the previous version: the existing UFM data and configuration are preserved.
2. In case upgrade.sh script stops before completion (e.g. missing prerequisite), the upgrade procedure can be resumed by fixing the issue (e.g. installing missing prerequisite) and rerunning ./upgrade.sh again.

6. Restart the UFM server. Run:

```
systemctl start ufm-enterprise.service
```

**Note**

/etc/init.d/ufmd start - Available for backward compatibility.

7. After the upgrade, remove the temporary directory

## Upgrading UFM on Bare Metal - High Availability Upgrade

**Note**

As of UFM version 6.14.0, UFM upgrade on HA supports in-service upgrade, meaning UFM can continue running during the steps of the upgrade, and there is no need to stop UFM before the upgrade (although this is also supported).

You can upgrade the UFM server HA software for InfiniBand from the previous release. The upgrade is performed on both servers.

To upgrade the UFM server software:

### Upgrading the UFM Enterprise Package

1. On the standby server, extract the new UFM Enterprise package to the /tmp folder:

```
tar -xzf ufm-X.X.X-XXXXX.tgz -C /tmp
```

2. On the standby server, enter to the installation folder and upgrade script:

```
standby# cd /tmp/ ufm-X.X.X-X.<OS_NAME>.x86_64.mofed5/
```

3. Run the UFM upgrade script on the standby server:

```
./upgrade.sh
```

4. After the completion of the upgrade script, the UFM code will undergo an upgrade, while the UFM data will remain unchanged. The automatic upgrade of UFM data will take place during the next startup of UFM. To initiate this process, execute a failover from the Master node (or perform a takeover from the Standby node).

```
master# ufm_ha_cluster failover
```

## **Note**

UFM will log the data upgrade to the syslog of the server, in case of issue a backup of the UFM data is saved prior to the upgrade in /opt/ufm/BACKUP directory and can be restored. For more information, refer to [Appendix – Restoring UFM Data](#).

5. Once UFM is operational on the upgraded node (formerly the standby node), proceed to replicate steps 1 to 3 on the non-upgraded node (previously the master node).

## **Upgrading the UFM HA Package**

1. On **both servers**, download latest UFM-HA package:

The included page could not be found.

2. On **both servers**, extract the HA package under /tmp/ and enter the new directory
3. On the UFM **Standby server**, run the upgrade command from within the extracted HA package located in /tmp:

```
./install.sh --upgrade
```

4. On the UFM **Master server**, run the upgrade command from within the extracted HA package located in /tmp:

```
./install.sh --upgrade
```

5. Run the following command to verify that the UFM HA cluster is up and running:

```
ufm_ha_cluster status
```

## Upgrading UFM on Docker Container

### Note

Upgrade the UFM container based on the existing UFM configuration files that are mounted on the server. It is important to use that same directory as a volume for the UFM installation command.

In the below example `/opt/ufm_files` is used.

## Upgrading UFM on Docker Container in Standalone Mode

1. Stop the UFM Enterprise service. Run:

```
systemctl stop ufm-enterprise
```

2. Remove the existing docker image. Run:

```
docker rmi mellanox/ufm-enterprise:latest
```

3. Load the new UFM Enterprise docker image. Run:

```
docker pull mellanox/ufm-enterprise:latest
```

4. Run the docker upgrade command:

```
docker run -it --name=ufm_installer --rm \  
-v /var/run/docker.sock:/var/run/docker.sock \  
-v /etc/systemd/system:/etc/systemd_files/ \  
-v /opt/ufm/files:/opt/ufm/shared_config_files/ \  
mellanox/ufm-enterprise:latest --upgrade
```

5. Reload system manager configuration:

```
systemctl daemon-reload
```

6. Start UFM Enterprise service:

```
systemctl start ufm-enterprise
```

## Upgrading UFM Container in High Availability Mode

### Note

As of UFM version 6.14.0, UFM upgrade on HA supports in-service upgrade, meaning UFM can continue running during the steps of the upgrade, and there is no need to stop UFM before the upgrade (although this is also supported).

### Upgrading the UFM Enterprise Package

1. Remove the old docker image from the **Standby** server. Run:

```
Stand-by# docker rmi mellanox/ufm-enterprise:latest
```

2. Pull the new UFM Enterprise docker image on the **Standby** server. Run:

```
docker pull mellanox/ufm-enterprise:latest
```

**Note**

At this stage, the UFM container has been updated with the latest code. The UFM data, however, will be updated during the next UFM run.

3. Perform a failover to start UFM on the upgraded node. On the **Master** node, run:

```
ufm_ha_cluster failover
```

**Note**

When UFM starts, it will automatically update the UFM configuration.

4. Repeat steps 1-2 on the un-upgraded node (previous **Master** node).

## Upgrading the UFM HA Package

1. On **both servers**, download and extract the latest UFM HA package. Run:

The included page could not be found.

2. On both the **Master** and **Standby** servers, execute the upgrade command from within the extracted HA package. Ensure you run it first on the **Standby** server, then on the **Master** server:

```
./install.sh --upgrade
```

3. Run the following command to verify that the UFM HA cluster is up and running:

```
ufm_ha_cluster status
```

## Uninstalling UFM

The UFM Server can be uninstalled by running an uninstall script in the different server modes:

- [Uninstalling UFM in Standalone Mode](#)
- [Uninstalling UFM in High Availability](#)
- [Uninstalling UFM in Docker Deployment](#)

### Uninstalling UFM in Standalone Mode

To uninstall the UFM Server:

1. Go to `/opt/ufm`.
2. Run `./uninstall.sh`.

 **Note**

Child interfaces are not deleted.

3. To delete primary interfaces, restart `/etc/init.d/openibd`.

## Uninstalling UFM in High Availability

To uninstall the UFM Server in high availability mode:

1. Run the following on the master and slave to clean up the UFM HA configuration:

```
ufm_ha_cluser cleanup
```

2. To uninstall the UFM HA configuration, run:

```
/opt/ufm/ufm_ha/uninstall_ha.sh
```

3. To uninstall UFM Enterprise software, run the following on the master and slave:

```
/opt/ufm/uninstall.sh
```

## Uninstalling UFM in Docker Deployment

To uninstall the UFM Server in high availability mode:

1. Run the following on the master and slave:

```
ufm_ha_cluser cleanup
```

2. Run:

```
/opt/ufm/ufm_ha/uninstall_ha.sh
```

3. Run the following on the master and slave:

```
/opt/ufm/files/uninstall.sh
```

# UFM Configuration Backup and Restore

## Overview

UFM migration enables backup and restores UFM configuration files.

## Backup UFM configuration

By default, the following folders (placed in `/opt/ufm/files`) are being backed up:

- conf
- dashboardViews
- licenses
- networkViews
- scripts
- sqlite
- templates/user-defined
- ufmhealth/scripts
- userdata

- users\_preferences

### **Note**

The user may also backup the UFM historical telemetry data ("-t" argument).

## UFM (Bare Metal)

```
/opt/ufm/scripts/ufm_backup.sh --help  
usage: ufm_backup.pyc [-h] [-f BACKUP_FILE] [-t]
```

### Optional Arguments

-h	--help	show this help message and exit
-f	--backup-file BACKUP_FILE	full path of zip file to be generated
-t	--telemetry	backup UFM historical telemetry

## UFM Docker Container

1. Backup UFM configuration. Run:

```
docker exec ufm /opt/ufm/scripts/ufm_backup.sh
```

2. Copy the backup file from UFM docker container to the host. Run:

```
docker cp ufm:/root/<backup file> <path on host>
```

## UFM Appliance

1. Backup UFM configuration. Run:

```
ufm data backup [with-telemetry]
```

2. Upload the backup file to a remote host. Run:

```
ufm data upload <backup file> <upload URL>
```

### Note

More details can be found in the log file `/tmp/ufm_backup.log`.

## Restore UFM Configuration

### Note

All folders which are a part of the UFM backup are restored (filter is done during the backup stage).

## UFM Bare Metal

```
/opt/ufm/scripts/ufm_restore.sh --help  
usage: ufm_restore.pyc [-h] -f BACKUP_FILE [-u] [-v]
```

### Optional Arguments

-h	--help	show this help message and exit
-f BACKUP_FILE	--backup-file BACKUP_FILE	full path of zip file generated by backup script
-u	--upgrade	upgrades the restored UFM files
-v	--verbose	makes the operation more talkative

## UFM Docker Container

1. Stop UFM. Run:

```
docker exec ufm /etc/init.d/ufmd stop
```

2. Copy the backup file from the host into UFM docker container. Run:

```
docker cp <backup file> ufm:/tmp/<backup file>
```

3. Restore UFM configuration. Run:

```
docker exec ufm /opt/ufm/scripts/ufm_restore.sh -f
```

```
/tmp/<backup file> [--upgrade]
```

4. Start UFM. Run:

```
docker exec ufm /etc/init.d/ufmd start
```

## UFM Appliance

1. Stop UFM. Run:

```
no ufm start
```

2. Copy the backup file from a remote host into UFM appliance. Run:

```
ufm data fetch <download URL>
```

3. Restore UFM configuration. Run:

```
ufm data restore <backup file>
```

4. Start UFM. Run:

```
ufm start
```

### **Note**

When restoring the UFM configuration from host to a container, the following parameters in `/opt/ufm/files/conf/gv.cfg` may be reset the following:

- `fabric_interface`
- `ufma_interfaces`
- `mgmt_interface`

### **Note**

UFM configuration upgrade during restore is not supported in UFM Appliance GEN2/GEN2.5

More details can be found in the log files `/tmp/ufm_restore.log` and `/tmp/ufm_restore_upgrade.log`

## UFM Factory Reset

This section provides a comprehensive guide on resetting UFM to its original factory settings.

### **Note**

WARNING!!! this operation will remove all user data and configuration and will restore UFM to its factory defaults.

## **Note**

The UFM Factory-Reset will exclusively revert UFM to its original factory settings, leaving HA configurations unaffected. To remove HA, it is essential to execute `ufm_ha_cluster cleanup` before initiating the factory reset.

## UFM Docker Container Factory Reset

To reset UFM to its factory defaults when using UFM on a Docker container, follow these steps.

1. Ensure that UFM is not up and running. If UFM is running, stop it.

For Stand-alone (SA) installations:

```
systemctl stop ufm-enterprise
# validate that ufm is not running
systemctl status ufm-enterprise
```

For High-Availability setups (perform the following on the master node only):

```
ufm_ha_cluster stop
# validate that ufm is not running
ufm_ha_cluster status
```

2. Run `mellanox/ufm-enterprise` Docker Container with the following flags:

## **Note**

WARNING: This operation will erase all user data and configurations, resetting UFM to its factory defaults.

CAUTION: This step does not require user confirmation, meaning UFM will be restored to factory defaults immediately once initiated.

```
docker run -it --name=ufm_installer --rm \
    -v /var/run/docker.sock:/var/run/docker.sock \
    -v /tmp:/tmp \
    -v /opt/ufm/files:/opt/ufm/shared_config_files/ \
    mellanox/ufm-enterprise:latest \
    --factory-reset
```

Flag	Type	Description
--name=ufm_installer	Mandatory	The container name must be called ufm_installer.
-v /var/run/docker.sock:/var/run/docker.sock	Mandatory	The docker socket must be mounted on the docker container.
-v /tmp:/tmp	Optional	Logs of the operation can be viewed in /tmp on the host in case it is mounted.
-v /opt/ufm/files:/opt/ufm/shared_config_ufm/	Mandatory	For the factory reset to persist, it is essential to have the /opt/ufm/files directory mounted from the host.
mellanox/ufm-enterprise:latest	Mandatory	The docker image name.
--factory-reset	Mandatory	This action will signal the UFM container to initiate the factory reset process.

## UFM Enterprise Factory Reset

To restore UFM Enterprise to factory defaults:

1. Ensure that UFM is not up and running. If UFM is running, stop it.

For Stand-alone (SA) installations:

```
systemctl stop ufm-enterprise
# validate that ufm is not running
systemctl status ufm-enterprise
```

For High-Availability setups (perform the following on the master node only):

```
ufm_ha_cluster stop
# validate that ufm is not running
ufm_ha_cluster status
```

2. Run the `ufm_factory_reset.sh` script:

### **Note**

WARNING: This operation will erase all user data and configurations, resetting UFM to its factory defaults.

```
/opt/ufm/scripts/ufm_factory_reset.sh [-y]
```

Flag:

Flag	Type	Description
-y	Optional	Does not require user confirmation.

---

# Manage Users

## Accounts and Roles

Each UFM user can be assigned to one of the following four roles:

- **System Admin** – users can perform all operations including managing other users accounts.
- **Fabric Admin** – users can perform fabric administrator actions such as update SM configuration, update global credentials, manage reports, managing unhealthy ports, and manage PKeys, etc.
- **Fabric Operator** – users can perform fabric operator actions such as device management actions (enable/disable port, add/remove devices to/from groups, reboot device, upgrade software, etc.)
- **Monitoring Only** – users can perform monitoring actions such as view the fabric configuration, open monitoring sessions, define monitoring templates, and export monitoring data to CSV files, etc.

## User Account Management


By default and upon every UFM deployment, the **admin** user (System Admin) is generated to allow initial access to the UFM.

A user with system Administration rights can manage other users' accounts, including the creation, deletion, and modification of accounts.

To edit existing user accounts, right-click the account from the list of user accounts and perform the desired action (Change Password/Remove).

## Add New User

1. Click the “New” button.



2. Fill in the required fields in the dialog box.


The 'Create A User' dialog box contains the following fields:

- User Name:
- Group:
- Password:
- Confirm Password:

A green 'Create' button is located at the bottom right of the dialog.

## Edit/Remove Existing User

Right-click the account from the list of user accounts and perform the desired action (Change Password/Remove).



## Authentication Methods

UFM User Authentication is based on standard Apache User Authentication or Internal UFM Authentication Server.

Each Web Service client application must authenticate against the UFM server to gain access to the system.

The available authentication methods supported by UFM are as follows:

Authentication Method	Description	UFM Related Prefix	REST API Reference
Basic Authentication	Based on user and password, provided by the client. This method is enabled by default.	/ufmRest	<a href="#">Basic Authentication</a>

Authentication Method	Description	UFM Related Prefix	REST API Reference
<a href="#">Session-Based Authentication</a>	A stateful authentication technique where sessions are used to keep track of the authenticated user. This method is enabled by default and is used by the UFM WebUI.	/ufmRestV2	<a href="#">Session-Based Authentication</a>
<a href="#">Client-Based Authentication</a>	Refers to an end user's device proving its own identity by providing a digital certificate that can be verified by a server in order to gain access to UFM resources	/ufmRest	<a href="#">Client-Based Authentication</a>
<a href="#">Token-Based Authentication</a>	Token-based authentication is a protocol which allows users to verify their identity, and in return receive a unique access token. To use UFM, the user should create a token using UFM Web UI or UFM REST API	/ufmRestV3	<a href="#">Token-Based Authentication</a>
<a href="#">Proxy Authentication</a>	Proxy authentication delegates the user authentication to a remote Proxy server.	/ufmRestV2 or /ufmRestV3	N/A
<a href="#">Azure AD Authentication</a>	Microsoft Azure Authentication is a service provided by Microsoft Azure, the cloud computing platform of Microsoft. It is designed to provide secure access control and authentication for applications and services hosted on Azure.	/ufmRestV2	N/A
<a href="#">Kerberos Authentication</a>	Kerberos is a protocol designed to authenticate service requests between trusted hosts over an untrusted network	/ufmRestKrb	N/A

There are two optional services which can provide authentication handling of UFM.

1. Apache Web Server (used by default) - Standard Apache web server and supports the above-mentioned authentication methods.
2. UFM Authentication Server - a centralized HTTP server, is responsible for managing various authentication methods supported by UFM.

## UFM Authentication Server

# Configurations of the UFM Authentication Server

The UFM Authentication Server is designed to be configurable and is initially turned on by default.

Enabling the UFM Authentication Server provides a centralized service that oversees all supported authentication methods within a single service, consolidating them under a unified authentication API.

Apache utilizes the authentication server's APIs to determine a user's authentication status.

All activities of the UFM Authentication Server are logged in the `authentication_service.log` file, located at `/opt/ufm/files/log`.

To enable/disable the UFM Authentication Server, refer to [Enabling UFM Authentication Server](#).

## Token-Based Authentication

Token-based authentication is a protocol which allows users to verify their identity, and in return receive a unique access token. During the life of the token, users then access the UFM APIs that the token has been issued for, rather than having to re-enter credentials each time they need to use any UFM API.

### **Note**

Under the Settings section there is a tab titled called “Access Tokens”.

The functionality of the added tab is to give the user the ability to create new tokens & manage the existing ones (list, copy, revoke, delete):

Access Tokens		
Access Token	Issued At ↓	Actions
TZhcEdLFHpKrdC9DBdwK9A9iajyJ0m	2022-04-28 17:34:41	  
tb5s5gfp68LeTx09m7CtFPs6DN9cqV	2022-04-28 17:34:40	  
nINcqmrBgdroFhBLBG0AJV7movZgR4	2022-04-28 17:34:39	  

Viewing 1-3 of 3

Actions:

Name	Icon	Description
Revoke		Revoke a specific token.  <div style="background-color: #ffffcc; padding: 5px;"> <p> <b>Note</b> The revoked token will no longer be valid.</p> </div>
Delete		Delete a specific token.
Copy		Copy specific token into the clipboard.

 **Note**

Each user is able to list and manage only the tokens that have been created by themselves. Only the users with system\_admin role will be able to create tokens.

## Proxy Authentication

## Delegating Authentication to a Proxy

To allow a custom user authentication, you can configure UFM to delegate the user authentication to a remote Proxy server. The remote Proxy server is written by the user, thus, allowing flexibility on deciding how the authentication is performed.

By default, the feature is disabled. To activate the feature, configure `auth_proxy_enabled` with `true`.

In case server authentication is enabled, use `/ufmRestV2`, otherwise, use `/ufmRestV3` to send requests to UFM.

The request header should contain a username and role. The available roles are `System_Admin`, `Fabric_Admin`, `Fabric_Operator`, and `Monitoring_Only`. If the request header is sent without a username or a role, it is rejected by the UFM.

For example:

```
[AuthProxy]
# Defaults to false, but set to true to enable this feature
auth_proxy_enabled = true
# HTTP Header name that will contain the username
auth_proxy_header_name = X_WEBAUTH_USER
# HTTP Header name that will contain the user roles. The
available roles are as follows: System_Admin, Fabric_Admin,
Fabric_Operator, and Monitoring_Only
auth_proxy_header_role = X_WEBAUTH_ROLE

# Set to `true` to enable auto sign up of users who do not exist in
UFM DB. Defaults to `true`.
auth_proxy_auto_sign_up = true
# Limit where auth proxy requests come from by configuring a list
of IP addresses.
# This can be used to prevent users spoofing the X_WEBAUTH_USER
header.
# This option is required
# Example `whitelist = 192.168.1.1, 192.168.1.0/24, 2001::23, 2001::0/120`
```

```
auth_proxy_whitelist =
```

## Azure AD Authentication


Microsoft Azure Authentication is a service provided by Microsoft Azure, the cloud computing platform of Microsoft. It is designed to provide secure access control and authentication for applications and services hosted on Azure.

UFM supports Authentication using Azure Active Directory, and to do so, you need to follow the following steps:

## Register UFM in Azure AD Portal

To log in via Azure, UFM must be registered in the Azure portal using the following steps:

1. Log in to [Azure Portal](#), then click "**Azure Active Directory**" in the side menu.
2. If you have access to more than one tenant, select your account in the upper right. Set your session to the Azure AD tenant you wish to use.
3. Under "**Manage**" in the side menu, click App Registrations > New Registration.



4. Provide the application details:

1. **Name:** Enter a descriptive name.
2. **Supported account types:** Account types that are allowed to login and use the registered application.
3. **Redirect URL:** select the app type **Web**, and Add the following redirect URL `https:///auth/login`

Home > NVIDIA Corporation | App registrations >

## Register an application

**\* Name**  
The user-facing display name for this application (this can be changed later).

 ✓

### Supported account types

Who can use this application or access this API?

- Accounts in this organizational directory only (NVIDIA Corporation only - Single tenant)
- Accounts in any organizational directory (Any Azure AD directory - Multitenant)
- Accounts in any organizational directory (Any Azure AD directory - Multitenant) and personal Microsoft accounts (e.g. Skype, Xbox)
- Personal Microsoft accounts only

[Help me choose...](#)

### Redirect URI (optional)

We'll return the authentication response to this URI after successfully authenticating the user. Providing this now is optional and it can be changed later, but a value is required for most authentication scenarios.

✓

Register an app you're working on here. Integrate gallery apps and other apps from outside your organization by adding from [Enterprise applications](#).

By proceeding, you agree to the [Microsoft Platform Policies](#)

[Register](#)

Then, click **Register**. The app's **Overview** page opens.

5. Under **Manage** in the side menu, click **Certificates & Secrets** > New client secret.

## Add a client secret




Description	<input type="text" value="UFM_APP_sec"/>
Expires	<input type="text" value="Recommended: 180 days (6 months)"/> <span>▼</span>

Provide a description for the client secret and set an expiration time, then click **"Add."**

- Copy the client secret key value which will be needed to configure the UFM with Azure AD (Please note that the value of the generated secret will be hidden and will not be able to be copied/read after you leave the page.

Under **"Manage"** in the side menu, click App roles > Create app role.



- Provide the role details. Please note that the role value must be a valid UFM role; otherwise, the login will fail.

## Create app role ✕

Display name \* ⓘ

System\_Admin ✓

Allowed member types \* ⓘ

Users/Groups  
 Applications  
 Both (Users/Groups + Applications)

Value \* ⓘ

System\_Admin ✓

Description \* ⓘ

System\_Admin

Do you want to enable this app role? ⓘ

8. Assign the created role to the user. Follow the below steps:

✦ ...

+ Create app role | 🗨️ Got feedback?

📘 Got a second to give us some feedback? →

### App roles

App roles are custom roles to assign permissions to users or apps. The application determines permissions during authorization.

**How do I assign App roles** 1

Display name	Description	Allowed member ty...	Value
System_Admin	System_Admin	Users/Groups,Applicat...	Syste

## Assigning app roles ✕

App roles for Users/Groups

Assign app roles with 'User' allowed member types in **Enterprise** applications or in Microsoft Graph APIs.

[Learn more about how to assign App roles for Users/Groups](#)

App roles for applications

Assign app roles with 'Applications' allowed member types in API permissions blade.

## Properties

**UF** Name ⓘ Copy to clipboard  
UFM-APP

Application ID ⓘ  
0d5e6cda-9144-47a2-b685-...

Object ID ⓘ  
dd2a68d5-a3e0-45e3-9c1c-...

## Getting Started

3

 **1. Assign users and groups**  
Provide specific users and groups access to the applications  
[Assign users and groups](#)

 **2. Provision User Accounts**  
You'll need to create user accounts in the application  
[Learn more](#)

 **3. Self service**  
Enable users to request access to the application using their Azure AD credentials  
[Get started](#)

+ Add user/group 4 Edit assignment Remove Update credentials | Columns | Got feedback?

**i** The application will not appear for assigned users within My Apps. Set 'visible to users?' to yes in properties to enable this. →

Assign users and groups to app-roles for your application here. To create new app-roles for this application, use the [application registration](#).

First 200 shown, to search all users & gro...

Display Name	Object Type	Role assigned
No application assignments found		

## Add Assignment

NVIDIA Corporation

Users and groups

1 user selected.

Select a role \*

System\_Admin


9. Click on "**Overview**" in the side menu to view the application information, such as tenant ID, client ID, and other details.

## Enable Azure Authentication From UFM

Azure authentication is disabled by default. To enable it, please refer to [Enabling Azure AD Authentication](#).

## Azure Authentication Login Page

After enabling and configuring Azure AD authentication, an additional button will appear on the primary UFM login page labeled 'Sign In with Microsoft,' which will lead to the main Microsoft sign-in page:



The screenshot shows the NVIDIA UFM login interface. At the top, there is a black header with the NVIDIA logo and the text 'NVIDIA. UFM'. Below the header, there are two input fields: 'Username' and 'Password'. A green 'Login' button is positioned below the password field. Below the 'Login' button, the word 'OR' is centered. At the bottom, there is a green button labeled 'Sign in with Microsoft'.

# Kerberos Authentication

Kerberos is a network authentication protocol designed to provide strong authentication for client-server applications by using secret-key cryptography.

The Kerberos protocol works on the basis of tickets, it helps ensure that communication between various entities in a network is secure. It uses symmetric-key cryptography, which means both the client and servers share secret keys for encrypting and decrypting communication.

To enable Kerberos Authentication, refer to [Enabling Kerberos Authentication](#).

## Setting Up Kerberos Server Machine

To set up a system as a Kerberos server, perform the following:

1. Install the required packages:

```
#Redhat
sudo yum install krb5-libs krb5-server
# Ubuntu
sudo apt-get install krb5-kdc krb5-admin-server
```

2. Edit the Kerberos configuration file '/etc/krb5.conf' to reflect your realm, domain and other settings:

```
[libdefaults]
    default_realm = YOUR-REALM

[realms]
    YOUR-REALM = {
        kdc = your-kdc-server
        admin_server = your-admin-server
    }

[domain_realm]
```

```
your-domain = YOUR-REALM  
your-domain = YOUR-REALM
```

3. Use the `kdb5_util` command to create the Kerberos database:

```
kdb5_util create -r YOUR-REALM -s
```

4. Add administrative principals:

```
Kadmin.local addprinc -randkey HTTP/YOUR-HOST-NAME@YOUR-  
REALM
```

5. Start KDC and Kadmin services:

```
sudo systemctl start krb5kdc kadmin  
sudo systemctl enable krb5kdc kadmin
```

6. Generate a keytab file. The keytab file contains the secret key for a principal and is used to authenticate the service.

```
kadmin.local ktadd -k /path/to/your-keytab-file HTTP/YOUR-  
HOST-NAME@YOUR-REALM
```

Replace `/path/to/your-keytab-file` with the actual path where you want to store the keytab file.

## Setting Up Kerberos Client Machine

Follow the below steps to set up a system as a Kerberos client.

1. Install the required packages. When installing the UFM, the following packages will be installed as dependencies:

```
#Redhat
krb5-libs krb5-workstation mod_auth_gssapi
# Ubuntu
krb5-config krb5-user libapache2-mod-auth-gssapi
```

2. Configure the `/etc/krb5.conf` file to reflect your realm, domain, local names map and other settings:

```
kinit -k -t /path/to/your-keytab-file HTTP/YOUR-HOST-
NAME@YOUR-REALM
```

```
[libdefaults]
    default_realm = YOUR-REALM

[realms]
    YOUR-REALM = {
        kdc = your-kdc-server
        admin_server = your-admin-server
        auth_to_local_names = {
            your-principle-name = your-local-user
        }
    }

[domain_realm]
    your-domain = YOUR-REALM
    your-domain = YOUR-REALM
```

3. Copy the keytab file from the Kerberos server to the machine where your service runs (the client). It is important to ensure that it is kept confidential.

Please ensure that the keytab file exists and that Apache has the necessary read permissions to access the keytab file; otherwise, Kerberos authentication will not function properly.

4. Obtain a Kerberos ticket-granting ticket (TGT):
5. Enable Kerberos Authentication from UFM. Kerberos authentication is disabled by default. To enable it, please refer to [Enabling Kerberos Authentication](#).
6. Test the Kerberos Authentication. You can use curl to test whether the user can authenticate to UFM REST APIs using Kerberos.

```
curl --negotiate -i -u : -k 'https://ufmc-eos01/ufmRestKrb/app/tokens'
```

---

# UFM Server Health Monitoring

The UFM Server Health Monitoring module is a standalone module that monitors UFM resources and processes according to the settings in the `/opt/ufm/files/conf/UFMHealthConfiguration.xml` file.

For example:

- Each monitored resource or process has its own failure condition (number of retries and/or timeout), which you can configure.
- If a test fails, UFM will perform a *corrective operation*, if defined for the process, for example, to restart the process. You can change the configured corrective operation. If the corrective operation is set to "None", after the defined number of failures, the *give-up* operation is performed.
- If a test reaches the configured threshold for the number of retries, the health monitoring initiates the *give-up* operation defined for the process, for example, UFM failover or stop.
- By default, events and alarms are sent when a process fails, and they are also recorded in the internal log file.

Each process runs according to its own defined schedule, which you can change in the configuration file.

Changes to the configuration file take effect only after a UFM Server restart. (It is possible to kill and run in background the process `nohup python /opt/ufm/ufmhealth/UfmHealthRunner.pyo &`.)

You can also use the configuration file to improve disk space management by configuring:

- How often to purge MySQL binary log files.
- When to delete compressed UFM log files (according to free disk space).

The settings in the `/opt/ufm/files/conf/UFMHealthConfiguration.xml` file are also used to generate the UFM Health Report.

The following section describes the configuration file options for UFM server monitoring.

## UFM Health Configuration

The UFM health configuration file contains three sections:

- Supported Operations—This section describes all the operations that can be used in tests, and their parameters.
- Supported Tests—This section describes all the tests. Each test includes:
  - The main test operation.
  - A corrective operation, if the main operation fails.
  - A give-up operation, if the main operation continues to fail after the corrective operation and defined number of retries.

The number of retries and timeout is also configured for each test operation.

- Test Schedule - This section lists the tests in the order in which they are performed and their configured frequency.

The following table describes the default settings in the */opt/ufm/files/conf/UFMHealthConfiguration.xml* file for each test. The tests are listed in the order in which they are performed in the default configuration file.

You might need to modify the default values depending on the size of your fabric.

For example, in a large fabric, the SM might not be responsive for *sminfo* for a long time; therefore, it is recommended to increase the values for timeout and number of retries for **SMResponseTest**.

Recommended configurations for *SMResponseTest* are:

- For a fabric with 5000 nodes:
  - Number of retries = 12
  - Frequency = 10
- For a fabric with 10000 nodes:
  - Number of retries = 12

- o Frequency = 20

Test Name / Description	Test Operation	Corrective Operation (if Test Operation fails)	No. Retries / Give-up Operation	Test Frequency
CpuUsageTest Checks total CPU utilization.	CPUtest Tests that overall CPU usage does not exceed 80% (this percentage is configurable).	None If UFM Event Burst Management is enabled, it is automatically initiated when the test operation fails	1 Retry None	1 minute
AvailableDiskSpaceTest Checks available disk space.	FreeDiskTest Tests that disk space usage for <i>/opt/ufm</i> does not exceed 90% (this percentage is configurable).	CleanDisk Delete compressed UFM log files under <i>/opt/ufm</i>	3 Retries None	1 hour
CheckIBFabricInterface Checks state of active fabric interface.	IBInterfaceTest Tests that active fabric interface is up.	BringUpIBFabricInterface Bring up the fabric interface	3 Retries SMOrUFMFailoverOrDoNothing	35 seconds
CheckIBFabricInterfaceStandby (HA only) Checks state of fabric interface on standby.	IBInterfaceTestOnStandby Tests that fabric interface on standby is up.	None	1 Retry None	1 minute
MemoryTest Checks total memory usage.	MemoryUsageTest Tests that memory usage does not exceed 90% (this percentage is configurable).	None	1 Retry None	1 minute
SMProcessTest Checks status of the OpenSM service.	SMRunningTest Tests that the SM process is	RestartProcess Restart the SM process	1 Retry UFMFailoverOrDoNothing	10 seconds

Test Name / Description	Test Operation	Corrective Operation (if Test Operation fails)	No. Retries / Give-up Operation	Test Frequency
	running.			
SMResponseTest Checks responsiveness of SM (when SM process is running).	SMTTest Tests SM responsiveness by sending the sminfo query to SM.	None	9 Retries UFMFailoverOrDoNothing	10 seconds
lbpmTest Checks status of the IBPM (Performance Manager) service.	ProcessIsRunningTest Tests that the IBPM service is running.	RestartProcess Restart the IBPM service	3 Retries None	1 minute
ModelMainTest Checks status of the main UFM service	ProcessIsRunningTest Tests that the UFM service is running.	RestartProcess Restart the UFM service	3 Retries UFMFailoverOrDoNothing	20 seconds
HttpdTest Checks status of the httpd service.	ProcessIsRunningTest Tests that the httpd service is running.	RestartProcess Restart the httpd service	3 Retries None	20 seconds
MySqlTest Checks status of the MySql service.	ConnectToMySql Tests that the MySql service is running.	None	1 Retry UFMFailoverOrDoNothing	20 seconds
CleanMySql Purges MySql Logs	AlwaysFailTest Fails the test in order to perform the corrective action.	PurgeMySqlLogs Purge all MySql Logs on each test	1 Retry None	24 hours
UFMServerVersionTest Checks UFM software version and build.	UfmVersionTest Returns UFM software version information.	None	1 Retry None	24 hours

Test Name / Description	Test Operation	Corrective Operation (if Test Operation fails)	No. Retries / Give-up Operation	Test Frequency
UFMServerLicenseTest Checks UFM License information.	UfmLicenseTest Returns UFM License information.	None	1 Retry None	24 hours
UFMServerHAConfigurationTest (HA only) Checks the configuration on master and standby.	UfmHAConfigurationTest Returns information about the master and standby UFM servers.	None	1 Retry None	24 hours
UFMMemoryTest Checks available UFM memory.	UfmMemoryUsageTest Tests that UFM memory usage does not exceed 80% (this percentage is configurable).	None	1 Retry None	1 minute
UFMCpuUsageTest Checks UFM CPU utilization.	CPUTest Tests that UFM CPU usage does not exceed 60% (this percentage is configurable).	None	1 Retry None	1 minute
CheckDrbdTcpConnectionPerformanceTest (HA only) Checks the tcp connection between master and standby	TcpConnectionPerformanceTest Tests that bandwidth is greater than 100 Mb/sec and latency is less than 70 usec (configurable).	None	2 Retry None	10 minute

**Note**

The Supported Operations section of the configuration file includes additional optional operations that can be used as corrective operations or give-up operations.

## UFM Core Files Tracking

To receive a notification every time OpenSM or ibpm creates a core dump, please refer to the list of all current core dumps of OpenSM and ibpm in the UFM health report.

### ➤ To receive core dump notifications, do the following:

1. Set the `core_dumps_directory` field in the `gv.cfg` file to point to the location where all core dumps are created (by default, this location is set to `/tmp`).

```
core_dumps_directory = /tmp
```

2. Set the naming convention for the core dump file. The name must include the directory configured in the step above.

The convention we recommend is:

```
echo "/tmp/%t.core.%e.%p.%h" > /proc/sys/kernel/core_pattern
```

3. Make sure core dumps directory setting is persistent between reboots. Add the `kernel.core_pattern` parameter with the desired file name format to the `/etc/systctl.conf` file. Example:

```
kernel.core_pattern=/tmp/%t.core.%e.%p.%h
```

4. Configure the core file size to be unlimited.

```
ulimit -c unlimited
```

5. (Only on UFM HA master) Update the UFM configuration file `gv.cfg` to enable core dump tracking.

```
track_core_dumps = yes
```

## Example of Health Configuration

The default configuration for the overall memory test in the `opt/ufm/files/conf/UFMHealthConfiguration.xml` file is:

```
<Test Name="MemoryTest" NumOfRetriesBeforeGiveup="3"
RetryTimeoutInSeconds="10">
  <TestOperation Name="MemoryUsageTest">
    <Parameters>
      <Parameter Name="ThresholdInPercents" Value="90"/>
    </Parameters>
  </TestOperation>
  <CorrectiveOperation Name="None" />
  <GiveupOperation Name="None" />
</Test>
```

This configuration tests the available memory. If memory usage exceeds 90%, the test is repeated up to 3 times at 10 second intervals, or until memory usage drops to below 90%. No corrective action is taken and no action is taken after 3 retries.

To test with a usage threshold of 80%, and to initiate UFM failover or stop UFM after three retries, change the configuration to:

```

<Test Name="MemoryTest" NumOfRetriesBeforeGiveup="3"
RetryTimeoutInSeconds="10">
  <TestOperation Name="MemoryUsageTest">
    <Parameters>
      <Parameter Name="ThresholdInPercents" Value="80" />
    </Parameters>
  </TestOperation>
  <CorrectiveOperation Name="None" />
  <GiveupOperation Name="UFMFailoverOrStop" />
</Test>

```

## Event Burst Management

UFM event burst management can lower the overall CPU usage following an event burst by suppressing events. Event burst management is configured in the *gv.cfg* configuration file.

When the overall CPU usage exceeds the threshold configured by the *CpuUsageTest* in the */opt/ufm/files/conf/UFMHealthConfiguration.xml* file, a High CPU Utilization event occurs.

This event initiates the UFM event burst management, which:

- Suppresses events. The default level of suppression enables critical events only.
- If, after a specified period of time (30 seconds, by default), no further High CPU Utilization event occurs, the UFM server enables all events.

To modify Event burst management configuration, change the following parameters in the *gv.cfg* file:

```

# The events' level in case events are suppressed (the possible
levels are disable_all_events, enable_critical_events, and
enable_all_events)
# The entire feature can be turned off using the level
"enable_all_events"

```

```
suppress_events_level = enable_critical_events  
# The amount of time in seconds which events are suppressed  
suppress_events_timeout = 30
```

---

# Events and Alarms

UFM offers comprehensive diagnostics for your InfiniBand fabric, covering a range of categories:

1. Fabric configurations
2. Fabric topology
3. Hardware issues
4. Communication errors
5. Maintenance
6. Security
7. Switch module status
8. NVIDIA SHARP notifications

Events are notifications generated by UFM, indicating issues within the mentioned categories in the InfiniBand fabric. On the other hand, alerts are urgent notifications derived from events (many events can be configured as alarms based on customer preferences).

These detections are performed both before running applications and during standard operation. They help troubleshoot and notify network administrators of potential network issues before they escalate.

Events can originate from various sources:

- SM traps
- SHARP AM traps
- UFM internal analysis, encompassing:
  - Internal detection of topology changes
  - Internal fabric analysis (based on IBDiagnet)

- Internal monitoring of managed switches
- Maintenance activities (device action tracking, licensing, cable integrity)
- Threshold-crossing events determined by telemetry counter readings

	WebUI	REST API
<b>Events</b>	UFM events can be viewed via the Events and Alarms WebUI view. Refer to <a href="#">Events &amp; Alarms</a> .	<a href="#">Events REST API</a>
	For device-specific events, refer to the <a href="#">Events &amp; Alarms</a> .	N/A
	Configuration of events is managed within the <a href="#">Events Policy Tab</a> in the Settings window	<a href="#">Events Policy REST API</a>
<b>Alarms</b>	UFM alarms can be viewed via the Events and Alarms WebUI view. Refer to <a href="#">Events &amp; Alarms</a> .	<a href="#">Alarms REST API</a>
	Configuration of alarms is managed within the <a href="#">Events Policy Tab</a> in the Settings window	N/A

For showing all the UFM supported events, refer to [Threshold-Crossing Events Reference](#).

## Threshold-Crossing Events Reference

This reference lists the threshold-based events that UFM supports, each including a set of attributes listed below. You can view these messages through TBD. For details about configuring notifications for these events, refer to TBD.

- **Event ID:** Unique event identifier
- **Event Name:** Short description of the event
- **To log:** A flag which defines whether the event will be sent to UFM events log or not (1 or 0, respectively).
- **Alarm:** A flag which defines whether UFM alarm is generated when the specified event is triggered by UFM (1 means an alarm is generated). Alarms are used to allow a notification with significant indication.
- **Default Severity:** Indicates the alarm severity (Info, Warning, Minor, Critical)
- **Default Threshold:** Event dependent threshold (for example, event occurrence, counter threshold or temperature threshold).

- **Default TTL:** TTL (Alarm Time to Live) sets the time during which the alarm on the event is visible on UFM Web UI. TTL is defined in seconds. CAUTION: Setting the TTL to 0 makes the alarm permanent, meaning that the alarm does not disappear from the Web UI until cleared manually.
- **Related Object:** The object (context) to which the UFM event is related to (port, switch, gateway, grid, etc).
- **Category:** Indicates the category to which the event is related to.
- **Source:** Indicates the origin source of the specified event (SM, Telemetry, Licensing, UFM)

For information about defining event policy, see [Configuring Event Management](#).

Event ID	Event Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
64	GID Address In Service	1	0	Info	1	300	Port	Fabric Notification	SM
65	GID Address Out of Service	1	0	Warning	1	300	Port	Fabric Notification	SM
66	New MCast Group Created	1	0	Info	1	300	Port	Fabric Notification	SM
67	MCast Group Deleted	1	0	Info	1	300	Port	Fabric Notification	SM
110	Symbol Error	1	1	Warning	200	300	Port	Hardware	Telemetry
111	Link Error Recovery	1	1	Minor	1	300	Port	Hardware	Telemetry
112	Link Downed	1	1	Critical	1	300	Port	Hardware	Telemetry
113	Port Receive Errors	1	1	Minor	5	300	Port	Hardware	Telemetry

Event ID	Event Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
114	Port Receive Remote Physical Errors	0	0	Minor	5	300	Port	Hardware	Telemetry
115	Port Receive Switch Relay Errors	1	1	Minor	999	300	Port	Fabric Configuration	Telemetry
116	Port Xmit Discards	1	1	Minor	200	300	Port	Communication Error	Telemetry
117	Port Xmit Constraint Errors	1	1	Minor	200	300	Port	Communication Error	Telemetry
118	Port Receive Constraint Errors	1	1	Minor	200	300	Port	Communication Error	Telemetry
119	Local Link Integrity Errors	1	1	Minor	5	300	Port	Hardware	Telemetry
120	Excessive Buffer Overrun Errors	1	1	Minor	100	300	Port	Communication Error	Telemetry
121	VL15 Dropped	1	1	Minor	50	300	Port	Communication Error	Telemetry
122	Congested Bandwidth (%) Threshold Reached	1	1	Minor	10	300	Port	Hardware	Telemetry
123	Port Bandwidth (%) Threshold Reached	1	1	Minor	95	300	Port	Communication Error	Telemetry
130	Non-optimal link width	1	1	Minor	1	0	Port	Hardware	SM
134	T4 Port Congested Bandwidth	1	1	Warning	10	300	Port	Communication Error	Telemetry

Event ID	Event Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
141	Flow Control Update Watchdog Timer Expired	1	0	Warning	1	300	Port	Hardware	SM
144	Capability Mask Modified	1	0	Info	1	300	Port	Fabric Notification	SM
145	System Image GUID changed	1	0	Info	1	300	Port	Communication Error	SM
156	Link Speed Enforcement Disabled	1	0	Critical	0	300	Site	Fabric Notification	SM
250	Running in Limited Mode	1	1	Critical	1	0	Grid	Maintenance	Licensing
251	Switching to Limited Mode	1	1	Critical	1	0	Grid	Maintenance	Licensing
252	License Expired	1	1	Warning	1	0	Grid	Maintenance	Licensing
253	Duplicated licenses	1	0	Critical	1	0	Grid	Maintenance	Licensing
254	License Limit Exceeded	1	0	Critical	1	0	Grid	Maintenance	Licensing
255	License is About to Expire	1	0	Warning	1	0	Grid	Maintenance	Licensing
256	Bad M_Key	1	0	Minor	1	300	Port	Security	SM
257	Bad P_Key	1	0	Minor	1	300	Port	Security	SM
258	Bad Q_Key	1	0	Minor	1	300	Port	Security	SM
259	Bad P_Key Switch External Port	1	0	Critical	1	300	Port	Security	SM
328	Link is Up	1	0	Info	1	0	Link	Fabric Topology	SM

Event ID	Event Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
329	Link is Down	1	0	Warning	1	0	Site	Fabric Topology	SM
331	Node is Down	1	0	Warning	1	0	Site	Fabric Topology	SM
332	Node is Up	1	0	Info	1	300	Site	Fabric Topology	SM
336	Port Action Succeeded	1	0	Info	1	0	Port	Maintenance	UFM
337	Port Action Failed	1	0	Minor	1	0	Port	Maintenance	UFM
338	Device Action Succeeded	1	0	Info	1	0	Port	Maintenance	UFM
339	Device Action Failed	1	0	Minor	1	0	Port	Maintenance	UFM
344	Partial Switch ASIC Failure	1	1	Critical	1	0	Switch	Maintenance	UFM
370	Gateway Ethernet Link State Changed	1	0	Warning	1	0	Gateway	Gateway	SM
371	Gateway Reregister Event Received	1	0	Warning	1	0	Gateway	Gateway	SM
372	Number of Gateways Changed	1	0	Warning	1	0	Gateway	Gateway	SM
373	Gateway will be Rebooted	1	0	Warning	1	0	Gateway	Gateway	SM
374	Gateway Reloading Finished	1	0	Info	1	0	Gateway	Gateway	SM
380	Switch Upgrade Error	1	1	Critical	1	0	Switch	Maintenance	UFM

Event ID	Event Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
381	Switch Upgrade Failed	1	0	Info	1	0	Switch	Maintenance	UFM
328	Module status NOT PRESENT	1	1	Warning	1	420	Switch	Module Status	UFM
383	Host Upgrade Failed	1	0	Info	1	0	Computer	Maintenance	UFM
384	Switch Module Powered Off	1	1	Info	1	420	Switch	Module Status	UFM
385	Switch FW Upgrade Started	1	0	Info	1	0	Switch	Maintenance	UFM
386	Switch SW Upgrade Started	1	0	Info	1	0	Switch	Maintenance	UFM
387	Switch Upgrade Finished	1	0	Info	1	0	Switch	Maintenance	UFM
388	Host FW Upgrade Started	1	0	Info	1	0	Computer	Maintenance	UFM
389	Host SW Upgrade Started	1	0	Info	1	0	Computer	Maintenance	UFM
391	Switch Module Removed	1	0	Info	1	0	Switch	Fabric Notification	Switch
392	Module Temperature Threshold Reached	1	0	Info	40	0	Module	Hardware	Switch
393	Switch Module Added	1	0	Info	1	0	Switch	Fabric Notification	Switch
394	Module Status FAULT	1	1	Critical	1	420	Switch	Module Status	Switch
395	Device Action Started	1	0	Info	1	0	Port	Maintenance	UFM
396	Site Action Started	1	0	Info	1	0	Port	Maintenance	UFM

Event ID	Event Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
397	Site Action Failed	1	0	Minor	1	0	Port	Maintenance	UFM
398	Switch Chip Added	1	0	Info	1	0	Switch	Fabric Notification	Switch
399	Switch Chip Removed	1	0	Critical	1	0	Switch	Fabric Notification	Switch
403	Device Pending Reboot	1	1	Warning	0	300	Device	Maintenance	UFM
404	System Information is missing	1	1	Warning	1	300	Switch	Communication Error	UFM
405	Switch Identity Validation Failed	1	1	Warning	1	300	Switch	Communication Error	UFM
406	Switch System Information is missing	1	1	Warning	1	300	Switch	Communication Error	UFM
407	COMEX Ambient Temperature Threshold Reached	1	1	Minor	60	300	Switch	Hardware	Switch
408	Switch is Unresponsive	1	1	Critical	1	300	Switch	Communication Error	UFM
502	Device Upgrade Finished	1	0	Info	1	300	Device	Maintenance	UFM
506	Device Upgrade Finished	1	0	Info	1	300	Device	Maintenance	UFM
508	Core Dump Created	1	1	Info	1	300	Grid	Maintenance	UFM
510	SM Failover	0	1	Critical	1	300	Grid	Fabric Notification	SM

Event ID	Event Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
								ion	
511	SM State Change	0	1	Info	1	300	Grid	Fabric Notification	SM
512	SM UP	0	1	Info	1	300	Grid	Fabric Notification	SM
513	SM System Log Message	0	1	Minor	1	300	Grid	Fabric Notification	SM
514	SM LID Change	0	1	Warning	1	300	Grid	Fabric Notification	SM
515	Fabric Health Report Info	1	1	Info	1	300	Grid	Fabric Notification	UFM
516	Fabric Health Report Warning	1	1	Warning	1	300	Grid	Fabric Notification	UFM
517	Fabric Health Report Error	1	1	Critical	1	300	Grid	Fabric Notification	UFM
518	UFM-related process is down	1	1	Critical	1	300	Grid	Maintenance	UFM
519	Logs purge failure	1	1	Minor	1	300	Grid	Maintenance	UFM
520	Restart of UFM-related process succeeded	1	1	Info	1	300	Grid	Maintenance	UFM
521	UFM is being stopped	1	1	Critical	1	300	Grid	Maintenance	UFM
522	UFM is being restarted	1	1	Critical	1	300	Grid	Maintenance	UFM

Event ID	Event Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
523	UFM failover is being attempted	1	1	Info	1	300	Grid	Maintenance	UFM
524	UFM cannot connect to DB	1	1	Critical	1	300	Grid	Maintenance	UFM
525	Disk utilization threshold reached	1	1	Critical	1	300	Grid	Maintenance	UFM
526	Memory utilization threshold reached	1	1	Critical	1	300	Grid	Maintenance	UFM
527	CPU utilization threshold reached	1	1	Critical	1	300	Grid	Maintenance	UFM
528	Fabric interface is down	1	1	Critical	1	300	Grid	Maintenance	UFM
529	UFM standby server problem	1	1	Critical	1	300	Grid	Maintenance	UFM
530	SM is down	1	1	Critical	1	300	Grid	Maintenance	UFM
531	DRBD Bad Condition	1	1	Critical	1	300	Grid	Maintenance	UFM
532	Remote UFM-SM Sync	1	1	Info	1	0	Grid	Maintenance	UFM
533	Remote UFM-SM problem	1	1	Critical	1	0	Site	Maintenance	UFM
535	MH Purge Failed	1	1	Warning	1	300	Grid	Maintenance	UFM
536	UFM Health Watchdog Info	1	1	Info	1	300	Grid	Maintenance	UFM
537	UFM Health Watchdog Critical	1	1	Critical	1	300	Grid	Maintenance	UFM
538	Time Diff Between HA Servers	1	1	Warning	1	300	Grid	Maintenance	UFM

Event ID	Event Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
539	DRBD TCP Connection Performance	1	1	Warning	1	900	Grid	Maintenance	UFM
540	Daily Report Completed successfully	1	0	Info	1	300	Grid	Maintenance	UFM
541	Daily Report Completed with Error	1	0	Minor	1	300	Grid	Maintenance	UFM
542	Daily Report Failed	1	0	Critical	1	300	Grid	Maintenance	UFM
543	Daily Report Mail Sent successfully	1	0	Info	1	300	Grid	Maintenance	UFM
544	Daily Report Mail Sent Failed	1	0	Minor	1	300	Grid	Maintenance	UFM
545	SM is not responding	1	1	Critical	1	300	Grid	Maintenance	UFM
560	User Connected							Security	UFM
561	User Disconnected							Security	UFM
602	UFM Server Failover	1	1	Critical	1	0	Site	Fabric Notification	UFM
603	Events Suppression	1	0	Critical	0	300	Site	Maintenance	UFM
604	Report Succeeded	1	1	Info	1	300	Grid	Maintenance	UFM
605	Report Failed	1	1	Critical	1	300	Grid	Maintenance	UFM
606	Correction Attempts Paused	1	0	Warning	1	0	Site	Fabric Notification	UFM
701	Non-optimal Link Speed	1	1	Minor	1	0	Port	Hardware	UFM

Event ID	Event Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
702	Unhealthy IB Port	1	1	Warning	1	0	Port	Hardware	SM
703	Fabric Collector Connected	1	0	Info	1	0	Grid	Maintenance	UFM
704	Fabric Collector Disconnected	1	1	Critical	1	0	Grid	Maintenance	UFM
750	High data retransmission count on port	1	1	Warning	500	1	Port	Hardware	SM
901	Fabric Configuration Started	0	1	Info	1	0	Grid	Fabric Notification	UFM
902	Fabric Configuration Completed	0	1	Info	1	0	Grid	Fabric Notification	UFM
903	Fabric Configuration Failed	0	1	Critical	1	0	Grid	Fabric Notification	UFM
904	Device Configuration Failure	0	1	Critical	1	0	Device	Fabric Notification	UFM
905	Device Configuration Timeout	0	1	Critical	1	0	Device	Fabric Notification	UFM
906	Provisioning Validation Failure	0	1	Critical	1	0	Grid	Fabric Notification	UFM
907	Switch is Down	1	1	Critical	1	0	Site	Fabric Topology	UFM
908	Switch is Up	1	1	Info	1	300	Site	Fabric Topology	UFM

Event ID	Event Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
909	Director Switch is Down	1	1	Critical	1	300	Site	Fabric Topology	UFM
910	Director Switch is Up	1	1	Info	1	0	Site	Fabric Topology	UFM
911	Module Temperature Low Threshold Reached	1	1	Warning	60	300	Module	Hardware	Telemetry
912	Module Temperature High Threshold Reached	1	1	Critical	60	300	Module	Hardware	Telemetry
913	Module High Voltage	1	1	Warning	10	420	Switch	Module Status	Telemetry
914	Module High Current	1	1	Warning	10	420	Switch	Module Status	Telemetry
915	BER_ERROR	1	1	Critical	1e-8	420	Port	Hardware	Telemetry
916	BER_WARNING	1	1	Warning	1e-13	420	Port	Hardware	Telemetry
917	SYMBOL_BER_ERROR	1	1	Critical	10	420	Port	Hardware	Telemetry
918	High Symbol BER reported	1	1	Warning	10	420	Port	Hardware	Telemetry
919	Cable Temperature High	1	1	Critical	0	0	Port	Hardware	Telemetry
920	Cable Temperature Low	1	1	Critical	0	0	Port	Hardware	Telemetry
1300	SM_SAKKEY_VIOLATION	1	1	Warning		5300	Port	Security	SM
1301	SM_SGID_SPOOFED	1	1	Warning		5300	Port	Security	SM

Event ID	Event Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
1302	SM_RATE_LIMIT_EXCEEDED	1	1	Warning		5300	Port	Security	SM
1303	SM_MULTICAST_GROUPS_LIMIT_EXCEEDED	1	1	Warning		5300	Port	Security	SM
1304	SM_SERVICES_LIMIT_EXCEEDED	1	1	Warning		5300	Port	Security	SM
1305	SM_EVENT_SUBSCRIPTION_LIMIT_EXCEEDED	1	1	Warning		5300	Port	Security	SM
1306	Unallowed SM was detected in the fabric	1	1	Warning	0	300	Port	Fabric Notification	SM
1307	SMInfo SET request was received from unallowed SM	1	1	Warning	0	300	Port	Fabric Notification	SM
1309	SM was detected with non-matching SMKey	1	1	Warning	0	300	Port	Fabric Notification	SM
1310	Duplicated node GUID was detected	1	1	Critical	1	0	Device	Fabric Notification	SM
1311	Duplicated port GUID was detected	1	1	Critical	1	0	Port	Fabric Notification	SM
1312	Switch was Rebooted	1	1	Info	1	0	Device	Fabric Notification	UFM
1315	Topo Config File Error	1	1	Critical	1	0	Grid	Fabric Notification	UFM
1316	Topo Config Subnet Mismatch	1	1	Critical	1	0	Grid	Fabric Notification	Topodiff

Event ID	Event Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
1400	High Ambient Temperature	1	1	Warning	0	86400	Switch	Hardware	Switch
1401	High Fluid Temperature	1	1	Warning	0	86400	Switch	Hardware	Switch
1402	Low Fluid Level	1	1	Warning	0	86400	Switch	Hardware	Switch
1403	Low Supply Pressure	1	1	Warning	0	86400	Switch	Hardware	Switch
1404	High Supply Pressure	1	1	Warning	0	86400	Switch	Hardware	Switch
1405	Low Return Pressure	1	1	Warning	0	86400	Switch	Hardware	Switch
1406	High Return Pressure	1	1	Warning	0	86400	Switch	Hardware	Switch
1407	High Differential Pressure	1	1	Warning	0	86400	Switch	Hardware	Switch
1408	Low Differential Pressure	1	1	Warning	0	86400	Switch	Hardware	Switch
1409	System Fail Safe	1	1	Warning	0	86400	Switch	Hardware	Switch
1410	Fault Critical	1	1	Critical	0	86400	Switch	Hardware	Switch
1411	Fault Pump1	1	1	Critical	0	86400	Switch	Hardware	Switch
1412	Fault Pump2	1	1	Critical	0	86400	Switch	Hardware	Switch
1413	Fault Fluid Level Critical	1	1	Critical	0	86400	Switch	Hardware	Switch
1414	Fault Fluid Over Temperature	1	1	Critical	0	86400	Switch	Hardware	Switch
141	Fault Primary DC	1	1	Critical	0	86400	Switch	Hardware	Switch

Event ID	Event Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
5				al		0	h	e	h
1416	Fault Redundant DC	1	1	Critical	0	86400	Switch	Hardware	Switch
1417	Fault Fluid Leak	1	1	Critical	0	86400	Switch	Hardware	Switch
1418	Fault Sensor Failure	1	1	Critical	0	86400	Switch	Hardware	Switch
1419	Cooling Device Monitoring Error	1	0	Critical	0	1	Grid	Hardware	Switch
1420	Cooling Device Communication Error	1	1	Critical	0	86400	Switch	Hardware	Switch
1500	New cable detected	1	0	Info	1	0	Link	Security	UFM
1502	Cable detected in a new location	1	0	Warning	1	0	Link	Security	UFM
1503	Duplicate Cable Detected	1	0	Critical	1	0	Link	Security	UFM
1315	Topo Config File Error	1	1	Critical	1	0	Grid	Fabric Notification	UFM
1504	SHARP Allocation Succeeded	1	1	Info	1	0	Grid	SHARP	SHARP
1505	SHARP Allocation Failed	1	0	Warning	1	0	Grid	SHARP	SHARP
1506	SHARP Deallocation Succeeded	1	0	Info	1	0	Grid	SHARP	SHARP
1507	SHARP Deallocation Failed	1	0	Warning	1	0	Grid	SHARP	SHARP
1508	Device Collect System Dump Started	1	0	Info	1	300	Device	Maintenance	UFM
1509	Device Collect System Dump Finished	1	0	Info	1	300	Device	Maintenance	UFM

Event ID	Event Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
1510	Device Collect System Dump Error	1	0	Critical	1	300	Device	Maintenance	UFM
1511	Virtual Port Added	1	0	Info	1	0	Port	Fabric Notification	SM
1512	Virtual Port Removed	1	0	Warning	1	0	Port	Fabric Notification	SM
1513	Burn Cables Transceivers Started	1	0	Info	1	0	Device	Maintenance	UFM
1514	Burn Cables Transceivers Finished	1	0	Info	1	0	Device	Maintenance	UFM
1515	Burn Cables Transceivers Failed	1	0	Warning	1	0	Device	Maintenance	UFM
1516	Activate Cables Transceivers FW Finished	1	0	Info	1	0	Device	Maintenance	UFM
1517	Activate Cables Transceivers FW Failed	1	0	Warning	1	0	Device	Maintenance	UFM
1520	Aggregation Node Discovery Failed	1	0	Critical	1	0	SHARP AM	SHARP	SHARP
1521	Job Started	1	0	Info	1	0	SHARP AM	SHARP	SHARP
1522	Job Ended	1	0	Info	1	0	SHARP AM	SHARP	SHARP
1523	Job Start Failed	1	0	Critical	1	0	SHARP AM	SHARP	SHARP
1524	Job Error	1	0	Critical	1	0	SHARP AM	SHARP	SHARP
1525	Trap QP Error	1	0	Critical	1	0	SHARP AM	SHARP	SHARP

Event ID	Event Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
1526	Trap Invalid Request	1	0	Critical	1	0	SHARP AM	SHARP	SHARP
1527	Trap Sharp Error	1	0	Critical	1	0	SHARP AM	SHARP	SHARP
1528	Trap QP Alloc timeout	1	0	Critical	1	0	SHARP AM	SHARP	SHARP
1529	Trap AMKey Violation	1	0	Critical	1	0	SHARP AM	SHARP	SHARP
1530	Unsupported Trap	1	0	Critical	1	0	SHARP AM	SHARP	SHARP
1531	Reservation Updated	1	0	Info	1	0	SHARP AM	SHARP	SHARP
1532	Sharp is not Responding	1	0	Critical	1	0	SHARP AM	SHARP	SHARP
1533	Agg Node Active	1	0	Info	1	0	SHARP AM	SHARP	SHARP
1534	Agg Node Inactive	1	0	Warning	1	0	SHARP AM	SHARP	SHARP
1535	Trap AMKey Violation Triggered by AM	1	0	Warning	1	0	SHARP AM	SHARP	SHARP
1550	Guids Were Added to Pkey	1	0	Info	1	0	Port	Fabric Notification	UFM
1551	Guids Were Removed from Pkey	1	0	Info	1	0	Port	Fabric Notification	UFM
1600	VS/CC Classes Key Violation							Security	SM
1602	PCI Speed Degradation Warning	1	1	Warning	1	0	Port	Fabric Notification	UFM

Event ID	Event Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
1603	PCI Width Degradation Warning	1	1	Warning	1	0	Port	Fabric Notification	UFM

# Reports

UFM reports provide summarized information about selected topics. Through the different UFM WebUI tabs, you can create reports that run a series of checks on UFM components.

The table below summarizes the types of reports and provides useful links for more information.

Report Type	Description	WebUI	REST API
UFM Health Report	A report that run a series of checks related to UFM server health, including CPU, memory, license, configurations and disk monitoring.	<a href="#">UFM Health Tab</a>	<a href="#">Reports REST API</a>
Fabric Health Report	Through the Fabric Health tab, you can access the fabric health reports. There are two kinds of reports: <ul style="list-style-type: none"> <li>• Custom Reports - The user can generate a report that runs a series of checks on the fabric on demand.</li> <li>• Periodic Reports - An automatically generated report that is periodically generated by the UFM.</li> </ul>	<a href="#">Fabric Health Tab</a>	<a href="#">Reports REST API</a> <a href="#">Periodic Fabric Health REST API</a>
Topology Comparison Report	Reports on topology comparison, available as: <ul style="list-style-type: none"> <li>• Periodic Comparison - allows users to compare the current fabric topology with a preset master topology.</li> <li>• Custom Comparison - compares user-defined topology with the current fabric topology.</li> </ul>	<a href="#">Topology Compare Tab</a>	<a href="#">Topology Compare REST API</a>
Daily Reports	The Daily Report feature collects, analyzes, and reports the most significant issues of the fabric in the last 24 hours	<a href="#">Daily Reports Tab</a>	N/A

---

# Telemetry

UFM Telemetry allows the collection and monitoring of InfiniBand fabric port statistics, such as network bandwidth, congestion, errors, latency, and more.

UFM provides a range of telemetry capabilities:

- Real-time monitoring views
- Monitoring of multiple attributes
- Intelligent Counters for error and congestion counters
- InfiniBand port-based error counters
- InfiniBand congestion XmitWait counter-based congestion measurement
- InfiniBand port-based bandwidth data

The telemetry session panels support the following actions:

- Rearrangement via a straightforward drag-and-drop function
- Resizing by hovering over the panel's border

UFM Telemetry data is collected via UFM telemetry instances invoked during UFM startup.

Telemetry Instance	Description	REST API
<b>High-Frequency (Primary) Telemetry Instance</b>	<p>A default telemetry session that collects a predefined set of ~30 counters covering bandwidth, congestion, and error metrics, which UFM analyzes and reports. These counters are used for:</p> <ul style="list-style-type: none"> <li>• Default Telemetry Session - An ongoing session used by the UFM to display UFM WebUI dashboard charts information and for monitoring and analyzing ports threshold events (the session interval is 30 secs by default)</li> <li>• Real-Time Telemetry - allows users to define live telemetry sessions for monitoring small subsets of devices or ports and a selected set of counters. For more information, refer to <a href="#">Telemetry - User-Defined Sessions</a></li> <li>• <a href="#">Historical Telemetry</a> - based on the primary telemetry and collects statistical data from all fabric ports and stores them in an internal UFM SQLite database (the session interval is 5 mins by default)</li> </ul>	<p>For Default and Real-time Telemetry: <a href="#">Monitoring REST API</a></p> <p>For Historical Telemetry: <a href="#">History Telemetry Sessions REST API</a></p>
<b>Low-Frequency (Secondary) Telemetry Instance</b>	<p>Operates automatically upon UFM startup, offering an extended scope of 120 counters. For a list of the Secondary Telemetry Fields, refer to <a href="#">Low-Frequency (Secondary) Telemetry Fields</a>.</p>	N/A

For direct telemetry endpoint access, which exposes the list of supported counters:

For the **High-Frequency (Primary) Telemetry Instance**, run the following command:

```
curl http://r-ufm114:9001/csv/cset/converted_enterprise
```

For the **Low-Frequency (Secondary) Telemetry Instance**, run the following command:

```
curl http://r-ufm114:9002/csv/xcset/low_freq_debug
```

# Historical Telemetry Collection in UFM

## Storage Considerations

UFM periodically collects fabric port statistics and saves them in its SQLite database. Before starting up UFM Enterprise, please consider the following disk space utilization for various fabric sizes and duration.

The measurements in the table below were taken with sampling interval set to once per 30 seconds.

### Note

Be aware that the default sampling rate is once per 300 seconds. Disk utilization calculation should be adjusted accordingly.

Number of Nodes	Ports per Node	Storage per Hour	Storage per 15 Days	Storage per 30 Days
16	8	1.6 MB	576 MB (0.563 GB)	1152 MB (1.125 GB)
100	8	11 MB	3960 MB (3.867 GB)	7920 MB (7.734 GB)
500	8	50 MB	18000 MB (17.58 GB)	36000 MB (35.16 GB)
1000	8	100 MB	36000 MB (35.16 GB)	72000 MB (70.31 GB)

## High-Frequency (Primary) Telemetry Fields

The following is a list of available counters which includes a variety of metrics related to timestamps, port and node information, error statistics, firmware versions, temperatures, cable details, power levels, and various other telemetry-related data.

Field Name	Description
timestamp	
source_id	
tag	
node_guid	node GUID
port_guid	Port GUID
port_num	Port Number
PortXmitDataExtended	Transmitted data rate per egress port in bytes passing through the port during the sample period
PortRcvDataExtended	The received data on the ingress port in bytes during the sample period
PortXmitPktsExtended	Total number of packets transmitted on the port.
PortRcvPktsExtended	Total number of packets received on the port
SymbolErrorCounterExtended	This counter provides information on error bits that were not corrected by phy correction mechanisms.
LinkErrorRecoveryCounterExtended	Total number of times the Port Training state machine has successfully completed the link error recovery process.
LinkDownedCounterExtended	Perf.PortCounters
PortRcvErrorsExtended	Total number of packets containing an error that were received on the port
PortRcvRemotePhysicalErrorsExtended	Total number of packets marked with the EBP delimiter received on the port.
PortRcvSwitchRelayErrorsExtended	Total number of packets received on the port that were discarded because they could not be forwarded by the switch relay.
PortXmitDiscardsExtended	Total number of outbound packets discarded by the port because the port is down or congested.
PortXmitConstraintE	Total number of packets not transmitted from the switch physical

Field Name	Description
rrorsExtended	port.
PortRcvConstraintErrorsExtended	Total number of packets received on the switch physical port that are discarded.
LocalLinkIntegrityErrorsExtended	The number of times that the count of local physical errors exceeded the threshold specified by LocalPhyErrors
ExcessiveBufferOverflowErrorsExtended	The number of times that OverrunErrors consecutive flow control update periods occurred, each having at least one overrun error
VL15DroppedExtended	Number of incoming VL15 packets dropped due to resource limitations (e.g., lack of buffers) in the port
PortXmitWaitExtended	The time an egress port had data to send but could not send it due to lack of credits or arbitration - in time ticks within the sample-time window
hist[0-4]	Hist[i] give the number of FEC blocks that had RS-FEC symbols errors of value i or range of errors
infiniband_CBW	
Normalized_CBW	
NormalizedXW	
Normalized_XmitData	

The following is a list of available counters which includes a variety of metrics related to timestamps, port and node information, error statistics, firmware versions, temperatures, cable details, power levels, and various other telemetry-related data.

Field Name	Description
timestamp	
source_id	
tag	
node_guid	node GUID
port_guid	Port GUID
port_num	Port Number

Field Name	Description
PortXmitDataExtended	Transmitted data rate per egress port in bytes passing through the port during the sample period
PortRcvDataExtended	The received data on the ingress port in bytes during the sample period
PortXmitPktsExtended	Total number of packets transmitted on the port.
PortRcvPktsExtended	Total number of packets received on the port
SymbolErrorCounterExtended	
LinkErrorRecoveryCounterExtended	
LinkDownedCounterExtended	
PortRcvErrorsExtended	
PortRcvRemotePhysicalErrorsExtended	
PortRcvSwitchRelayErrorsExtended	
PortXmitDiscardsExtended	
PortXmitConstraintErrorsExtended	
PortRcvConstraintErrorsExtended	
LocalLinkIntegrityErrorsExtended	
ExcessiveBufferOverrunErrorsExtended	
VL15DroppedExtended	
PortXmitWaitExtended	
hist[0-4]	Hist[i] give the number of FEC blocks that had RS-FEC symbols errors of value i or range of errors
infiniband_CBW	

Field Name	Description
Normalized_CBW	
NormalizedXW	
Normalized_XmitData	

## Low-Frequency (Secondary) Telemetry Fields

The following is a list of available counters which includes a variety of metrics related to timestamps, port and node information, error statistics, firmware versions, temperatures, cable details, power levels, and various other telemetry-related data.

Field Name	Description
Node_GUID	node GUID
Device_ID	PCI device ID
node_description	node description
lid	lid
Port_Number	port number
port_label	port label
Phy_Manager_State	FW Phy Manager FSM state
phy_state	physical state
logical_state	Port Logical link state
Link_speed_active	ib link active speed
Link_width_active	ib link active widthsource_id
Active_FEC	Active FEC
Total_Raw_BER	Pre-FEC monitor parameters

Field Name	Description
Effective_BER	Post FEC monitor parameters
Symbol_BER	BER after all phy correction mechanism: post FEC + PLR monitor parameters
Raw_Errors_Lane_[0-3]	This counter provides information on error bits that were identified on lane X. When FEC is enabled this induction corresponds to corrected errors. In PRBS test mode, indicates the number of PRBS errors on lane X.
Effective_Errors	This counter provides information on error bits that were not corrected by FEC correction algorithm or that FEC is not active.
Symbol_Errors	This counter provides information on error bits that were not corrected by phy correction mechanisms.
Time_since_Last_clear_Min	The time passed since the last counters clear event in msec. (physical layer statistical counters)
hist[0-15]	Hist[i] give the number of FEC blocks that had RS-FEC symbols errors of value i or range of errors
FW_Version	Node FW version
Chip_Temp	switch temperature
Link_Down	Perf.PortCounters(LinkDownedCounter)
Link_Down_Link_B	Total number of times the Port Training state machine has failed the link error recovery process and downed the link.
LinkErrorRecoveryCounter	Total number of times the Port Training state machine has successfully completed the link error recovery process.
PlrRcvCodes	Number of received PLR codewords
PlrRcvCodeError	The total number of rejected codewords received
PlrRcvUncorrectableCode	The number of uncorrectable codewords received
PlrXmitCodes	Number of transmitted PLR codewords
PlrXmitRetryCodes	The total number of codewords retransmitted

Field Name	Description
PlrXmitRetryEvents	The total number of retransmitted event
PlrSyncEvents	The number of sync events
HiRetransmissionRate	Recieved bandwidth loss due to codes retransmission
PlrXmitRetryCodesWithinTSecMax	The maximum number of retransmitted events in t sec window
link_partner_description	node description of the link partner
link_partner_node_guid	node_guid of the link partner
link_partner_lid	lid of the link partner
link_partner_port_num	port number of the link partner
Cable_PN	Vendor Part Number
Cable_SN	Vendor Serial Number
cable_technology	
cable_type	Cable/module type
cable_vendor	
cable_length	
cable_identifier	
vendor_rev	Vendor revision
cable_fw_version	
rx_power_lane_[0-7]	RX measured power

Field Name	Description
tx_power_lane_[0-7]	TX measured power
Module_Voltage	Internally measured supply voltage
Module_Temperature	Module temperature
fast_link_up_status	Indicates if fast link-up was performed in the link
time_to_link_up_ext_msec	Time in msec to link up from disable until phy up state. While the phy manager did not reach phy up state the timer will return 0.
Advanced_Status_Opcode	Status opcode: PHY FW indication
Status_Message	ASCII code message
down_blame	Which receiver caused last link down
local_reason_opcode	Opcode of link down reason - local
remote_reason_opcode	Opcode of link down reason - remote
e2e_reason_opcode	see local_reason_opcode for local reason opcode for remote reason opcode: local_reason_opcode+100
PortRcvRemotePhysicalErrors	Total number of packets marked with the EBP delimiter received on the port.
PortRcvErrors	Total number of packets containing an error that were received on the port
PortXmitDiscards	Total number of outbound packets discarded by the port because the port is down or congested.
PortRcvSwitchRelayErrors	Total number of packets received on the port that were discarded because they could not be forwarded by the switch relay.
ExcessiveBufferOverrunErrors	The number of times that OverrunErrors consecutive flow control update periods occurred, each having at least one overrun error

Field Name	Description
rors	
LocalLinkIntegrityErrors	The number of times that the count of local physical errors exceeded the threshold specified by LocalPhyErrors
PortRcvConstraintErrors	Total number of packets received on the switch physical port that are discarded.
PortXmitConstraintErrors	Total number of packets not transmitted from the switch physical port.
VL15Dropped	Number of incoming VL15 packets dropped due to resource limitations (e.g., lack of buffers) in the port
PortXmitWait	The time an egress port had data to send but could not send it due to lack of credits or arbitration - in time ticks within the sample-time window
PortXmitDataExtended	Transmitted data rate per egress port in bytes passing through the port during the sample period
PortRcvDataExtended	The received data on the ingress port in bytes during the sample period
PortXmitPacketsExtended	Total number of packets transmitted on the port.
PortRcvPktsExtended	Total number of packets received on the port
PortUniCastXmitPkts	Total number of unicast packets transmitted on all VLS from the port. This may include unicast packets with errors, and excludes link packets
PortUniCastRcvPkts	Total number of unicast packets, including unicast packets containing errors, and excluding link packets, received from all VLS on the port.
PortMultiCastXmitPkts	Total number of multicast packets transmitted on all VLS from the port. This may include multicast packets with errors.
PortMultiCastRcvPkts	Total number of multicast packets, including multicast packets containing errors received from all VLS on the port.
SyncHeaderErrorCounter	Count of errored block sync header on one or more lanes
PortSwLifetimeLimitDiscards	Total number of outbound packets discarded by the port because the Switch Lifetime Limit was exceeded. Applies to switches only.

Field Name	Description
PortSwHOQ LifetimeLimit Discards	Total number of outbound packets discarded by the port because the switch HOQ Lifetime Limit was exceeded. Applies to switches only.
rq_num_wrf e	Responder - number of WR flushed errors
rq_num_lle	Responder - number of local length errors
sq_num_wrf e	Requester - number of WR flushed errors
Temp_flags	Latched temperature flags of module
Vcc_flags	Latched VCC flags of module
device_hw_rev	Node HW Revision
sw_revision	switch revision
sw_serial_number	switch serial number
measured_freq_[0-1]	Clock frequency measurement in last 100msec
min_freq_[0-1]	Minutes of clock frequency measured. Units of 0.1 KHz
max_freq_[0-1]	Max of clock frequency measured. Units of 0.1 KHz
max_delta_freq_[0-1]	Observed max delta frequency in window of 100msec. Units of 0.1 KHz
snr_media_lane_[0-7]	SNR value on the media lane <i>. In unit scale of 1/256 dB. The SNR value represents the electrical signal-to-noise ratio on an optical lane, and is defined as the minimum of the three individual eye SNR values.
snr_host_lane_[0-7]	SNR value on the host lane <i>. In unit scale of 1/256 dB. The SNR value represents the electrical signal-to-noise ratio on an optical lane, and is defined as the minimum of the three individual eye SNR values.
tx_cdr_lol	Bitmask for latched Tx cdr loss of lock flag per lane.
rx_cdr_lol	Bitmask for latched Rx cdr loss of lock flag per lane.

Field Name	Description
tx_los	Bitmask for latched Tx loss of signal flag per lane.
rx_los	Bitmask for latched Rx loss of signal flag per lane.
phy_received_bits	This counter provides information on the total amount of traffic (bits) received
rq_general_error	The total number of packets that were dropped since it contained errors. Reasons for this include: Dropped due to MPR mismatch.

---

# UFM Web UI

This section is constituted by the following sub-sections:

- [Fabric Dashboard](#)
- [Network Map](#)
- [Managed Elements](#)
- [Events & Alarms](#)
- [Telemetry - User-Defined Sessions](#)
- [System Health](#)
- [Jobs](#)
- [Settings](#)

## Access the WebUI

### UFM Web UI Supported Browsers

UFM Web UI is supported on all the following web browsers: Internet Explorer, Firefox, Chrome and Opera.

For optimal UFM Web UI performance, make sure you are using the latest version available of Google Chrome.

For more information, see *UFM User Manual*.

### Launching UFM Web UI Session

Before accessing the UFM Web UI:

- If required, you can change the configuration of the connection (port and protocol) between the UFM server and the APACHE server in the file *gv.cfg*:


- *ws\_protocol* = http or https
  - Setting the parameter *ws\_protocol* to *http* allows unsecured access
  - Setting the parameter *ws\_protocol* to *https* denies unsecured access.
- *ws\_port* = port number

➤ **To launch a UFM Web UI session, do the following:**

1. Launch the Web UI by entering the following URL in your browser:

**http://<UFM\_server\_IP>/ufm**

**https://<UFM\_server\_IP>/ufm**



The image shows a login form for the NVIDIA UFM. At the top, there is a black header bar containing the NVIDIA logo (a green eye-like shape) and the text 'nVIDIA. UFM'. Below the header, there are two white input fields with rounded corners. The first field is labeled 'Username' and the second is labeled 'Password'. Below the password field is a green rectangular button with the word 'Login' in white text.

2. In the Login page, enter your **User Name** and your predefined user **Password** and click **Login**.


Once you have entered your user name and password, the main window shows the UFM Dashboard. For more information, see the [Fabric Dashboard](#).

## WebUI Layout

The UFM WebUI contains two main areas:


1. Top Bar - Contains local time zone and user information on the top right side of the screen.
2. Sidebar Menu - Contains a taskbar accessible from a sidebar menu on the left side of the screen. For more information on each tab, refer to [UFM Web UI](#).

## Sidebar Menu



## Top Bar

Each user can customize the UFM display, time zone, and date format, change their account password, and manage their preferences. For details, refer to [Set User Preferences](#).



## Sidebar Menu


Tab Icon	Description
 Dashboard	Provides a summary view of the fabric status.
 Network Map	Provides a hierarchical topology view of the fabric.
 Managed Elements	Provides information on all fabric devices. This information is presented in a table format.
 Logical Elements	Provides information on all logical servers. This information is presented in a table format.
 Events & Alarms	Provides information on the events & alarms generated by the system.
 Telemetry	Enables establishing monitoring sessions on devices or ports.
 System Health	Enables running and viewing fabric reports, UFM reports, and system logs. You can also back up UFM configuration files.
 Jobs	Provides information on all jobs created, as a result of UFM actions.
 Settings	Enables configuring UFM server and UFM fabric settings, including events policy, device access, network management, subnet manager, and user management

## Set User Preferences


This section describes how to customize your UFM display settings and change your password,

### Dark/Light Theme

1. Select **Preferences**.




2. In **User Preferences**, enable dark mode for UFM presentation in a dark theme. The following figure shows the dark theme:



## Time Zone Converter

Allows you to unify all times in UFM like events and alarms, ibdiagnet, telemetry and logs. You can switch between local and machine time.

In the status bar drop-down menu, switch between local and server/machine time.



Events & Alarms Local Time Last Update: 09 Apr 2022 17:25 ? admin

Alarms

Clear All Alarms ↻ Displayed Columns CSV

Severity	Date/Time ↓	Alarm Name	Source	Source Type	Reason	Count
Minor	2022-04-09 17:25:09	Non-optimal ...	default(3) / Switch: r-hyp-sw-01 /	IBPort	Found a [25.0] link that operates in [14.0] speed mode.	1180
Minor	2022-04-09 17:25:09	Non-optimal ...	default(3) / Switch: SwitchIB Mell...	IBPort	Found a [25.0] link that operates in [14.0] speed mode.	1180
Minor	2022-04-09 17:25:09	Non-optimal ...	default(3) / Switch: SwitchIB Mell...	IBPort	Found a [25.0] link that operates in [14.0] speed mode.	1180
Warning	2022-04-05 15:26:47	Unhealthy IB...	default(3) / Switch: r-hyp-sw-01 /	IBPort	Peer Port is considered by SM as unhealthy due to MANUAL.	1
Warning	2022-04-05 15:26:27	Unhealthy IB...	default(3) / Switch: SwitchIB Mell...	IBPort	Peer Port is considered by SM as unhealthy due to MANUAL.	1

Events & Alarms Server Time Last Update: 09 Apr 2022 11:31 ? admin

Alarms

Clear All Alarms ↻ Displayed Columns CSV

Severity	Date/Time ↓	Alarm Name	Source	Source Type	Reason	Count
Minor	2022-04-09 11:25:09	Non-optimal ...	default(3) / Switch: r-hyp-sw-01 /	IBPort	Found a [25.0] link that operates in [14.0] speed mode.	1180
Minor	2022-04-09 11:25:09	Non-optimal ...	default(3) / Switch: SwitchIB Mell...	IBPort	Found a [25.0] link that operates in [14.0] speed mode.	1180
Minor	2022-04-09 11:25:09	Non-optimal ...	default(3) / Switch: SwitchIB Mell...	IBPort	Found a [25.0] link that operates in [14.0] speed mode.	1180
Warning	2022-04-05 9:26:47	Unhealthy IB...	default(3) / Switch: r-hyp-sw-01 /	IBPort	Peer Port is considered by SM as unhealthy due to MANUAL.	1
Warning	2022-04-05 9:26:27	Unhealthy IB...	default(3) / Switch: SwitchIB Mell...	IBPort	Peer Port is considered by SM as unhealthy due to MANUAL.	1

**Note**

In the screenshots, the difference between Server Time and Local Time is 6 hours.

## Table Enhancements

## Look and Feel Improvements

All Refresh Displayed Columns CSV

Severity	Name	GUID	Type	Model	IP	Firmware Ve...
Info	r-hyp-sw-01	0x248a070300...	switch	MSB7700	N/A	N/A
Info	SwitchIB Mell...	0xe41d2d0300...	switch	EDR	N/A	N/A
Info	ufm-host86	0x7cfe9003002...	host	Computer	192.168....	N/A
Info	r-ufm254-hyp...	0x043f720300d...	host	Computer	N/A	N/A
Info	r-ufm254-hyp...	0x0c42a10300...	host	Computer	N/A	N/A

Viewing 1-5 of 5 Navigation icons 10

## Displayed Columns


Refresh Displayed Columns CSV

ID ↓ 1	Description	Created ↓ 2	Last Update ↓ 3	Status	Summary
2	mark_device_healthy	2022-10-20 17:03:14	2022-10-20 17:03:14	Completed	View Summary
1	mark_device_unhealthy	2022-10-20 17:02:24	2022-10-20 17:02:24	Completed	View Summary

Viewing 1-2 of 2 Navigation icons 10

Restore Default

- ID
- Description
- Created
- Last Update
- Status
- Summary
- Progress



### **Note**

Displayed columns of all tables are persistent per user, with the option to restore defaults.

## **Export All Data as CSV**

There are two options for exporting as CSV

- All Data: all data returned from server.
- Displayed Data: only displayed rows.

>

All Displayed Columns CSV

S...	Name	GUID	Type	Model	IP	
	Filter...	Filter...	Filter...	Filter...	Filter...	
	r-hyp-sw-01	0x248a070300...	switch	MSB7700	N/A	N/A
	SwitchIB Mell...	0xe41d2d0300...	switch	EDR	N/A	N/A
	ufm-host86	0x7cfe9003002...	host	Computer	192.168.1.30	N/A
	r-ufm254-hyp...	0x043f720300d...	host	Computer	N/A	N/A
	r-ufm254-hyp...	0x0c42a10300...	host	Computer	N/A	N/A

Viewing 1-5 of 5 10

---

# Multi-Subnet UFM

## Overview

The Multi-Subnet UFM feature allows for the management of large fabrics, consisting of multiple sites, within a single product, namely Multi-Subnet UFM.

This feature is comprised of two layers: UFM Multi-Subnet Provider and UFM Multi-Subnet Consumer.

The UFM Provider functions as a Multi-Subnet Provider, exposing all local InfiniBand fabric information to the UFM consumer. On the other hand, the UFM Consumer acts as a Multi-Subnet Consumer, collecting and aggregating data from currently configured UFM Providers, enabling users to manage multiple sites in one place. While UFM Consumer offers similar functionality to regular UFM, there are several behavioral differences related to aggregation.

## Setting Up Multi-Subnet UFM

In `/opt/ufm/files/conf/gv.cfg`, fill in the section named `[Multisubnet]` for UFM Multi-Subnet Provider and Consumer.

### To set up UFM as a Multi-Subnet Provider, perform the following:

- Set `multisubnet_enabled` to `true`
- Set `multisubnet_role` to `provider`
- Set `multisubnet_site_name` (optional, if not set, it will be randomly generated); e.g., `provider_1`
- Start UFM


### To set up UFM as a Multi-Subnet Consumer, perform the following:

- Set `multisubnet_enabled` to `True`
- Set `multisubnet_role` to `consumer`
- Start UFM

It is important to note that UFM Multi-Subnet Consumer can be configured on a machine or VM without an established InfiniBand connectivity. Additionally, users may customize UFM Provider and Consumer using optional configuration parameters found in the [Multisubnet] section of /opt/ufm/files/conf/gv.cfg.


## Functionality

1. Following the initial launch of the Consumer, the Dashboard view is devoid of data, and a message containing a hyperlink leading to the Provider Management section is displayed.




 No providers connected, please go to [Providers Management](#) to add providers

2. As shown in the below snapshot, a new section for Provider Management has been added, enabling users to configure UFM Providers.




1. To add a provider, the user is required to enter its IP address and credentials. Unless there are multiple instances of UFM providers on a single machine, the advanced section parameters should be set with default values. However, if there are multiple instances, the advanced parameters may be set per Provider and then be configured in the Providers Management view.



2. By editing the Provider view, you can change Provider's credentials.



- The "Delete Provider" function removes the selected Provider from the Consumer. Please note that this action may take some time to complete, and changes may only be reflected in the view after approximately 30 seconds.



- A general filter has been added to the top right corner of the page, enabling users to filter displayed data by site.



Local Time (Asia/Jerusalem) Site: All Last Update: 12 Apr 2023 16:35

Severity	Name	GUID	Type	Model	IP	Firmware Version	Site Name
Warn...	r-utm83	0xecDd9a0300b152f4	host		0.0.0.0	16.33.1048	provider_2000
Info	sharp2	0x7cfe900300a5a7a0	switch	MS18/800	0.0.0.0		provider_1000
Info	switchib	0xecDd9a030079dba0	switch	FDR	0.0.0.0		provider_1000
Info	utm-host87	0xecDd9a03007d7f0a	host		0.0.0.0		provider_1000
Info	r-utm2/4-hyp-04	0x043f720300d1d3c	host		0.0.0.0		provider_1000
Info	r-utm2/4-hyp-03	0x0c47a103007aca90	host		0.0.0.0		provider_1000
Warn...	desc1	0x043f720300206650	switch	FDR	0.0.0.0	15.2007.354	provider_2000
Info	node001	0xecDd9a0300c04b74	host		0.0.0.0	16.31.1046	provider_2000
Info	swx-tor01	0xecDd9a0300469ffc	host		0.0.0.0		provider_2000

Viewing 1-9 of 9

Devices Local Time (Asia/Jerusalem) Site: provider\_2000 Last Update: 12 Apr 2023 16:35 admin

All Types All Groups Displayed Columns CSV

Severity	Name	GUID	Type	Model	IP	Firmware Version	Site Name
Warn...	r-ufm83	0xec0d9a0300bf52f4	host		0.0.0.0	16.33.1048	provider_2000
Warn...	desc1	0x043f720300206650	switch	EDR	0.0.0.0	15.2007.354	provider_2000
Info	node001	0xec0d9a0300c04bf4	host		0.0.0.0	16.31.1046	provider_2000
Info	swx-tor01	0xec0d9a0300469ffc	host		0.0.0.0		provider_2000

Viewing 1-4 of 4

#### 4. Network map contains “clouds” for each provider.

Network Map Local Time Site: All Last Update: 20 Oct 2022 14:44 admin

Layout: Hierarchical Graph Views: Default Regex Filters: Starts With: Enter filter

View: Zoom In Filters: Select nodes to highlight and display in Zoom In tab



4 Nodes  
provider\_2000



19 Nodes  
provider\_1000

View Properties

Display Label: System Name

Type


- Rack
- Host
- Gateway
- Switch
- Router

Severity


- Info
- Warning
- Minor
- Critical

Network Analysis

- Link Analysis



5. A "Site Name" column is present in all Managed Elements sections. The column is disabled (hidden) by default.



Devices Local Time (Asia/Jerusalem) Site All Last Update: 12 Apr 2023 16:56 admin

All Types All Groups Displayed Columns CSV

Severity	Name	GUID	Type	Model	IP
Info	r-ufm83	0xec0d9a0300b52f4	host		0.0.0.0
Info	sharp2	0x7cfe900300a5a2a0	switch	MSB7800	0.0.0.0
Info	switchib	0xec0d9a030029dba0	switch	LDIR	0.0.0.0
Info	ufm-host87	0xec0d9a03007d7f0a	host		0.0.0.0
Info	r-ufm254-hyp-04	0x043f720300d1d3c	host		0.0.0.0
Info	r-ufm254-hyp-03	0x0c42a103007aca90	host		0.0.0.0
Info	desc1	0x043f720300206650	switch	FDR	0.0.0.0
Info	node001	0xec0d9a0300c04bf4	host		0.0.0.0
Info	swx-tor01	0xec0d9a0300469ffc	host		0.0.0.0

Viewing 1-9 of 9

- Restore Default
- Severity
  - Name
  - GUID
  - Type
  - Model
  - IP
  - Firmware Version
  - Site Name

Devices Local Time (Asia/Jerusalem) Site All Last Update: 12 Apr 2023 16:56 admin


All Types All Groups Displayed Columns CSV

Severity	Name	GUID	Type	Model	IP	Site Name
Info	r-ufm83	0xec0d9a0300b52f4	host		0.0.0.0	provider_2000
Info	sharp2	0x7cfe900300a5a2a0	switch	MSB7800	0.0.0.0	provider_1000
Info	switchib	0xec0d9a030029dba0	switch	EDR	0.0.0.0	provider_1000
Info	ufm-host87	0xec0d9a03007d7f0a	host		0.0.0.0	provider_1000
Info	r-ufm254-hyp-04	0x043f720300d1d3c	host		0.0.0.0	provider_1000
Info	r-ufm254-hyp-03	0x0c42a103007aca90	host		0.0.0.0	provider_1000
Info	desc1	0x043f720300206650	switch	EDR	0.0.0.0	provider_2000
Info	node001	0xec0d9a0300c04bf4	host		0.0.0.0	provider_2000
Info	swx-tor01	0xec0d9a0300469ffc	host		0.0.0.0	provider_2000


Viewing 1-9 of 9


- Restore Default
- Severity
  - Name
  - GUID
  - Type
  - Model
  - IP
  - Firmware Version
  - Site Name

6. The "Group" and "Telemetry" sections include "Site" filters.




7. The filter in "Groups" impacts the Members table only.






8. In the System Health tab, subsections for Consumer and Provider are available.


1. Consumer System Health tab contains sections applicable to Consumer UFM specifically (e.g., logs from Consumer UFM).



2. Provider System Health contains sections applicable to one or multiple providers (e.g., Fabric Health Report can be triggered on multiple Providers from the Consumer).



9. UFM Health tab contains sub report tables for each provider.



10. Fabric Health contains sub report tables for each provider.

System Health Local Time Site: All Last Update: 20 Oct 2022 15:14 ? admin

UFM Health UFM Logs UFM Snapshot **Fabric Health** Daily Reports Topology Compare Fabric Validation IBDiagnet

**Fabric Health Report**

Date: 2022-10-20 14:49:44 Show Problems Only Collapse All Run New Report

Created By: admin

**Report Summary**

Site: provider\_1000 Displayed Columns

Fabric Test	Warnings	Errors	Total
Non-unique and Zero LID Values	0	0	0
Non-unique Node Descriptions	2	0	2
SM Status	0	0	0
Bad Links	0	0	0
Link Width	0	0	0
Link Speed	0	6	6
Firmware Versions	2	0	2
UFM Alarms	0	1	1
BER Error and Warning check	0	0	0
Symbol BER Error and Warning check	0	0	0

Viewing 1-10 of 11

Site: provider\_2000 Displayed Columns

Fabric Test	Warnings	Errors	Total
Non-unique and Zero LID Values	0	0	0
Non-unique Node Descriptions	2	0	2
SM Status	0	0	0
Bad Links	0	0	0
Link Width	0	0	0
Link Speed	0	6	6
Firmware Versions	2	0	2
UFM Alarms	198	2	200
BER Error and Warning check	0	0	0
Symbol BER Error and Warning check	0	0	0

Viewing 1-10 of 11

**Fabric Summary**

## 11. Daily Reports:

### 1. Consumer Daily reports display consumer reports.

Consumer System Health Local Time (Asia/Jerusalem) Site: All

UFM Logs UFM System Dump **Daily Reports**


Recipients List Displayed Columns

Report ↓


2023-04-11

Viewing 1-1 of 1 20

2. Providers Daily reports display reports from all providers.



12. The "Fabric Validation" tab contains sub report tables for each provider.



13. In "UFM Logs" Tab:

1. Consumer logs:

Consumer System Health Local Time (Asia/Jerusalem) Site All Last Update: 12 Apr 2023 18:01 admin

UFM Logs UFM System Dump Daily Reports

Event Logs Time Last 24 hours 10000 Search... Occurrences Show Hide

Log View

- 1 2023-04-11 18:11:44 [1] [352] INFO [Logical\_Model] Grid [Grid]: Network management is added
- 2 2023-04-11 18:12:09 [3] [604] INFO [Maintenance] Grid [Grid]: Fabric Analysis Report succeeded
- 3 2023-04-11 18:12:44 [4] [525] CRITICAL [Maintenance] Grid [Grid]: Disk space usage in /opt/ufm/files/log is above the threshold of 90.0%
- 4 2023-04-11 18:16:44 [10] [701] MINOR [Hardware] IBPort [default / Switch: r-hyp-sw-01 / 36] [dev\_id: 268a070300e1f9a0]: Found a [25.0] link that operates in [14.0] speed mode.
- 5 2023-04-11 18:16:44 [11] [701] MINOR [Hardware] IBPort [default / Switch: SwitchB Mellanox Technologies / 36] [dev\_id: e41d2d030003e3b0]: Found a [25.0] link that operates in [14.0] speed mode.
- 12 2023-04-12 1:06:34 [230] [517] CRITICAL [Fabric\_Notification] Grid [Grid]: FabricHealth Report completed with 2 Errors and 2 Warnings
- 13 2023-04-12 1:06:34 [231] [604] INFO [Maintenance] Grid [Grid]: Fabric Health Report succeeded
- 14 2023-04-12 1:06:47 [234] [540] INFO [Maintenance] Grid [Grid]: Daily Report Completed successfully:/opt/ufm/files/reports/Daily/2023-04-11
- 15 2023-04-12 1:06:47 [235] [544] MINOR [Maintenance] Grid [Grid]: Unable to send mail - no recipients list
- 29 2023-04-12 14:46:10 [635] [332] INFO [Fabric\_Topology] Site [default(0) / NA / NA / NA]: Site configuration changes: ec0d9a0300469ffc (swx-tor01) node is Up
- 31 2023-04-12 14:46:20 [637] [112] WARNING [Hardware] IBPort [default(0) / Switch: desc1 / 26] [dev\_id: 043f720300206650]: Link-Downed counter delta threshold exceeded. Threshold is 0, calculated delta is 1. Peer info: default(3) / Computer: node001 / HCA-1/1.
- 32 2023-04-12 14:46:20 [638] [112] WARNING [Hardware] IBPort [default(0) / Switch: desc1 / 28] [dev\_id: 043f720300206650]: Link-Downed counter delta threshold exceeded. Threshold is 0, calculated delta is 1. Peer info: default(3) / Computer: node001 / HCA-1/2.
- 33 2023-04-12 14:46:20 [639] [112] WARNING [Hardware] IBPort [default(0) / Switch: desc1 / 30] [dev\_id: 043f720300206650]: Link-Downed counter delta threshold exceeded. Threshold is 0, calculated delta is 87. Peer info: default(3) / Computer: swx-tor01 / HCA-1/1.
- 34 2023-04-12 14:46:20 [640] [112] WARNING [Hardware] IBPort [default(0) / Switch: desc1 / 32] [dev\_id: 043f720300206650]: Link-Downed counter delta threshold exceeded. Threshold is 0, calculated delta is 87. Peer info: default(3) / Computer: swx-tor01 / HCA-1/2.
- 35 2023-04-12 14:46:20 [641] [112] WARNING [Hardware] IBPort [default(0) / Computer: r-ufm83 / HCA-1/2] [dev\_id: ec0d9a0300b52f4]: Link-Downed counter delta threshold exceeded. Threshold is 0, calculated delta is 2. Peer info: default(3) / Switch: desc1 / 24.
- 36 2023-04-12 16:28:20 [642] [332] INFO [Fabric\_Topology] Site [default(0) / NA / NA / NA]: Site configuration changes: ec0d9a0300b52f4 (r-ufm83) node is Up
- 38 2023-04-12 16:29:10 [644] [525] CRITICAL [Maintenance] Grid [Grid]: Disk space usage in /opt/ufm/tmp is above the threshold of 80.0%
- 39 2023-04-12 16:29:10 [645] [605] CRITICAL [Maintenance] Grid [Grid]: Fabric Analysis Report failed, Return code: 1
- 40 2023-04-12 16:31:40 [647] [112] WARNING [Hardware] IBPort [default(6) / Computer: r-ufm83 / HCA-1/2] [dev\_id: ec0d9a0300b52f4]: Link-Downed counter delta threshold exceeded. Threshold is 0, calculated delta is 2. Peer info: default(3) / Switch: desc1 / 24.
- 41 2023-04-12 16:31:40 [648] [112] WARNING [Hardware] IBPort [default(6) / Switch: desc1 / 26] [dev\_id: 043f720300206650]: Link-Downed counter delta threshold exceeded. Threshold is 0, calculated delta

2. Providers logs display providers log separately, displaying logs for all providers is not supported.

Providers System Health Local Time (Asia/Jerusalem) Site provider\_2000 Last Update: 12 Apr 2023 18:05 admin

UFM Health UFM Logs UFM System Dump Fabric Health Daily Reports Fabric Validation


Event Logs Time Last 24 hours 10000 Search... Occurrences Show Hide

Log View

- 1 2023-04-12 1:07:52 [53] [516] WARNING [Fabric\_Notification] Grid [Grid]: FabricHealth Report completed with 4 Warnings
- 2 2023-04-12 1:07:52 [54] [604] INFO [Maintenance] Grid [Grid]: Fabric Health Report succeeded
- 3 2023-04-12 1:08:03 [55] [540] INFO [Maintenance] Grid [Grid]: Daily Report Completed successfully:/opt/ufm/files/reports/Daily/2023-04-11
- 4 2023-04-12 1:08:03 [56] [544] MINOR [Maintenance] Grid [Grid]: Unable to send mail - no recipients list
- 5 2023-04-12 2:34:20 [57] [65] WARNING [Fabric\_Notification] IBPort [default(3) / Computer: swx-tor01 / HCA-1/2] [dev\_id: ec0d9a0300469ffc]: GID Address Out of Service: prefix fe80000000000000.guid ec0d9a0300469fd Link Source 043f720300206650\_32 TO Dest: ec0d9a0300469fd\_2
- 6 2023-04-12 2:34:20 [58] [65] WARNING [Fabric\_Notification] IBPort [default(3) / Computer: swx-tor01 / HCA-1/1] [dev\_id: ec0d9a0300469ffc]: GID Address Out of Service: prefix fe80000000000000.guid ec0d9a0300469fc Link Source 043f720300206650\_30 TO Dest: ec0d9a0300469fc\_1
- 7 2023-04-12 2:34:20 [59] [329] WARNING [Fabric\_Topology] Link [Source 043f720300206650\_30 TO Dest: ec0d9a0300469fc\_1]: Link went down: [Switch:desc1:30]043f720300206650:30 - [Computer:swx-tor01 mlx5\_0]ec0d9a0300469fc:1, cable S/N: MT2042V504276
- 8 2023-04-12 2:34:20 [60] [329] WARNING [Fabric\_Topology] Link [Source 043f720300206650\_32 TO Dest: ec0d9a0300469fd\_2]: Link went down: [Switch:desc1:32]043f720300206650:32 - [Computer:swx-tor01 mlx5\_1]ec0d9a0300469fc:2, cable S/N: MT2042V504200
- 9 2023-04-12 2:34:20 [61] [331] WARNING [Fabric\_Topology] Site [default(2) / NA / NA / NA]: Site configuration changes: ec0d9a0300469ffc (swx-tor01) node is Down
- 10 2023-04-12 2:36:45 [63] [64] INFO [Fabric\_Notification] Site [default(2) / NA / NA / NA]: GID Address In Service: prefix fe80000000000000.guid ec0d9a0300469fd
- 11 2023-04-12 2:36:50 [65] [332] INFO [Fabric\_Topology] Site [default(3) / NA / NA / NA]: Site configuration changes: ec0d9a0300469ffc (swx-tor01) node is Up
- 12 2023-04-12 2:36:50 [66] [329] INFO [Fabric\_Topology] Link [Source 043f720300206650\_30 TO Dest: ec0d9a0300469fc\_1]: Link is up: [Switch:desc1:30]043f720300206650:30 - [Computer:swx-tor01 mlx5\_0]ec0d9a0300469fc:1
- 13 2023-04-12 2:36:50 [67] [328] INFO [Fabric\_Topology] Link [Source 043f720300206650\_32 TO Dest: ec0d9a0300469fd\_2]: Link is up: [Switch:desc1:32]043f720300206650:32 - [Computer:swx-tor01 mlx5\_1]ec0d9a0300469fc:2
- 14 2023-04-12 2:36:58 [68] [1500] INFO [Security] Link [Source 043f720300206650\_30 TO Dest: ec0d9a0300469fc\_1]: New cable S/N: MT2042V504276 is detected
- 15 2023-04-12 2:36:58 [69] [1500] INFO [Security] Link [Source 043f720300206650\_32 TO Dest: ec0d9a0300469fd\_2]: New cable S/N: MT2042V504200 is detected
- 16 2023-04-12 2:36:58 [70] [604] INFO [Maintenance] Grid [Grid]: Fabric Analysis Report succeeded
- 26 2023-04-12 7:38:24 [82] [702] WARNING [Hardware] IBPort [default(3) / Switch: desc1 / 30] [dev\_id: 043f720300206650]: Peer Port swx-tor01 mlx5\_0 is considered by SM as unhealthy due to FLAPPING.
- 27 2023-04-12 7:38:24 [83] [702] WARNING [Hardware] IBPort [default(3) / Computer: swx-tor01 / HCA-1/1] [dev\_id: ec0d9a0300469ffc]: Peer Port desc1:30 is considered by SM as unhealthy due to FLAPPING.

14. In the "System Dump" tab:

1. "Consumer System Dump" collects system dump for consumer




2. "Providers System Dump" collect system dumps for one or all providers and mergeS them into one folder



15. Under "Settings", subsections for Consumer and Provider are available.

1. "Consumer Settings" contain sections applicable to Consumer UFM specifically (e.g., creation of access tokens for UFM consumer authentication);



2. "Provider Settings" contain sections applicable to one or multiple providers (e.g., Event Policies can be changed for multiple Providers at once from the Consumer).

UFM Enterprise

Dashboard  
Network Map  
Managed Elements  
Events & Alarms  
Telemetry  
System Health  
Jobs  
Settings  
**Consumer Settings**  
Providers Settings

User Management | Access Tokens | Plugin Management | Providers Management

+ New | Displayed Columns

ID ↓	Name	Group
1	admin	System Admin

Viewing 1-1 of 1

---

# UFM Plugins

## UFM Plugins Management

UFM plugin management can be done either via the `manage_ufm_plugins.sh` script or via the Web UI.

### UFM Plugin Management Using `themanage_ufm_plugins.sh` Script

The `manage_ufm_plugins.sh` script, located in the `/opt/ufm/scripts` directory, is designed to manage UFM plugins through the command line interface.

To see the actions supported by this script, run:

```
/manage_ufm_plugins.sh --help
usage: manage_ufm_plugins.sh <command> [<args>]
positional arguments:
  {show,get-
all,enable,start,stop,disable,add,upgrade,remove_image,remove,is-
running,is-enable,get-http-proxy-port,debug,deploy,deploy-bundle}

Commands
show          Show plugins info
get-all      get all loaded plugins
enable       Enable plugin
start        Start plugins
stop         Stop all plugins
disable      Disable plugin
add          Add plugin
upgrade      Upgrade plugin
remove_image Remove plugin`s image
remove       Remove plugin
is-running   Test plugin is running
```

is-enable	Test plugin is enabled
get-http-proxy-port	Get plugin HTTP proxy port
debug	Debug
deploy	Deploy plugin image
deploy-bundle	Deploy bundle of plugins

### Optional Arguments:

-h, --help	show <a href="#">this</a> help message and exit
-v, --version	Print version information

Each supported option has its own help flag, which can be received by requesting help for a specific parameter. For example:

```
./manage_ufm_plugins.sh add --help
```

### Usage:

```
manage_ufm_plugins.pyc <command> [<args>] add [-h] -p <[A-Za-z0-9_-] Name size: 32> [-t <[A-Za-z0-9._-] Name size: 128>]
```

### Optional Arguments:

-h, --help	show <a href="#">this</a> help message and exit
-p <[A-Za-z0-9_-] Name size: 32>	--plugin-name <[A-Za-z0-9_-] Name size: 32>
	Plugin name
-t <[A-Za-z0-9._-] Name size: 128>	--plugin-tag <[A-Za-z0-9._-] Name size: 128>
	Plugin tag

The following table lists the supported commands and provides their description and information on the parameters.

Command	Description	Parameters
show	Shows information about running plugins	N/A
get-all	Gets information about deployed plugins in JSON format	N/A
enable	Enables plugin	Loaded Parameter: plugin image name
start	Starts UFM plugin	Loaded Parameter: plugin name
stop	Stops UFM plugin	Loaded Parameter: plugin name
disable	Disables UFM plugin	Loaded Parameter: plugin name
add	Adds UFM plugin	Loaded Parameter: image name
upgrade	Upgrades UFM plugin	Loaded Parameter: plugin name
remove_image	Removes UFM plugin's image	Loaded Parameter: plugin image name
remove	Removes UFM plugin	Loaded Parameter: plugin name
is-running	Tests plugin is running	Loaded Parameter: plugin name

Command	Description	Parameters
is-enabled	Tests plugin is enabled	Loaded Parameter: plugin name
get-http-proxy-port	Gets plugin HTTP proxy port	Loaded Parameter: plugin name
deploy	Deploys plugin image	Loaded Parameter: -f flag with path to UFM plugin image
deploy-bundle	Deploys bundle of plugins	Loaded Parameter: -f flag with path to tarball file, that will contain number of UFM plugins. All the plugin images from the tar ball will be deployed to UFM. Operation could take some time. The progress of the plugin images from the tar file deployment will be printed to terminal, including error messages, if exists.

## UFM Plugins

- [Plugins Bundle](#)
- [REST-RDMA Plugin](#)
- [NDT Plugin](#)
- [UFM Telemetry Fluentd Streaming \(TFS\) Plugin](#)
- [UFM Events Fluent Streaming \(EFS\) Plugin](#)
- [UFM Bright Cluster Integration Plugin](#)
- [UFM Cyber-AI Plugin](#)
- [Autonomous Link Maintenance \(ALM\) Plugin](#)
- [ClusterMinder Plugin](#)
- [GRPC-Streamer Plugin](#)
- [Sysinfo Plugin](#)

- [SNMP Plugin](#)
- [Packet Level Monitoring Collector \(PMC\) Plugin](#)
- [PDR Deterministic Plugin](#)
- [GNMI-Telemetry Plugin](#)
- [UFM Telemetry Manager \(UTM\) Plugin](#)
- [UFM Consumer Plugin](#)
- [Fast-API Plugin](#)
- [UFM Light Plugin](#)
- [Key Performance Indexes \(KPI\) Plugin](#)

## Plugins Bundle

The default plugin bundle contains the NDT, TFS, KPI, PMC, and Cluster Minders plugins, packaged in a tarball file. To download this bundle, refer to [NVIDIA's Licensing Portal](#).

To deploy the plugin bundle within the UFM ecosystem, follow these steps:

### For a UFM Bare Metal Deployment:

1. Download the bundle from NVIDIA's Licensing Portal.
2. Run the following command:

```
/opt/ufm/scripts/manage_ufm_plugins.sh deploy-bundle -f  
<plugins bundle file name>
```

### For Docker Container-based UFM Deployment:

1. Download the bundle from NVIDIA's Licensing Portal and move the file to the `/opt/ufm/ufm_plugins_data` directory.
2. Run the following command:

```
docker exec ufm /opt/ufm/scripts/manage_ufm_plugins.sh
deploy-bundle -f /opt/ufm/ufm_plugins_data/<plugins bundle
file name>
```

All plugin images from the tarball will be deployed to UFM. The process may take some time, and progress, including any error messages, will be displayed in the terminal.

## REST-RDMA Plugin

The REST-RDMA is a tool designed for sending requests over InfiniBand to the UFM server. These REST requests can fall into three categories:

1. UFM REST API requests
2. ibdiagnet requests
3. Telemetry requests

The rest-rdma utility is distributed as a Docker container, capable of functioning both as a server and a client.

## Deployment Server

### Deploy Plugin on UFM Appliance

1. Log into your UFM as admin.
2. Enter config mode. Run:

```
enable
config terminal
```

 **Note**

Make sure that UFM is running with `show ufm status`. If UFM is down, then run with `ufm start`.

3. Ensure that rest-rdma plugin is disabled with the `show ufm plugin` command.
4. Pull the plugin container with `docker pull mellanox/ufm-plugin-rest-rdma:[version]`.
5. Run `ufm plugin rest-rdma add tag [version]` to enable the plugin.
6. Check that plugin is up and running with `docker pull mellanox/ufm-plugin-rest-rdma:[version]`

## Deploy Plugin on Bare Metal Server

1. Verify that UFM is installed and running.
2. Pull image from docker hub:

```
docker pull mellanox/ufm-plugin-rest-rdma:[version]
```

3. To load image run:

```
/opt/ufm/scripts/manage_ufm_plugins.py add -p rest-rdma
```

Example with credentials:

## Deployment Client

Run the following command to pull the image from the docker hub:

```
docker pull mellanox/ufm-plugin-rest-rdma:[version]
```

Verify that the `/tmp/ibdiagnet` directory exists on the client's computer. If not – create it.

To start container as client (on any host in the same fabric as UFM server) run:

```
docker run -d --network=host --privileged --name=ufm-plugin-rest-  
rdma --rm -v /tmp/ibdiagnet:/tmp/ibdiagnet mellanox/ufm-plugin-  
rest-rdma:[version] client
```

To check that plugin is up and running, run:

```
docker ps
```

## How to Run

### Server

In server mode `ufm_rdma.py` is started automatically and is restarted if exited. If the `ufm_rdma.py` server is not running – enter to the docker and run the following commands to start the server:

```
cd /opt/ufm/src/ufm-plugin-ufm-rest  
./ufm_rdma.py -r server
```

### Client

There are three options to run client. Running the client from inside the Docker container, using a custom script from the hosting server to execute the client or using the "docker exec" command from the hosting server.

1. **Option 1:** Run the client from inside the Docker container

1. Enter the docker container using `docker exec -it ufm-plugin-rest-rdma bash`
2. Then, run `cd /opt/ufm/src/ufm-plugin-rest-rdma`
3. Use the `-h` help option to see the available parameters

```
./ufm_rdma.py -h
```

2. **Option 2:** From the host server, the scripts can be located at /opt/ufm/ufm-plugin-ufm-rest/ directory inside the docker container. They can be copied using the following command:

**Note**

```
cp <containerId>:/opt/ufm/ufm-plugin-ufm-rest/[script name]
/host/path/target
```

Example:

**Note**

```
cp <containerId>:/opt/ufm/ufm-plugin-ufm-rest/ufm-rest-
rdma_client.sh /host/path/target
```

1. To see the available options, run:

```
./ufm-rest-rdma_client.sh -h
```

3. **Option 3:** From hosting server, use the docker exec command.

**Note**

To run from inside docker, run:

```
docker exec ufm-plugin-rest-rdma prior to the command.
```

For example: `docker exec ufm-plugin-rest-rdma /opt/ufm/ufm-plugin-ufm-rest/src/ufm_rdma.py -r client -u admin -p password -t simple -a GET -w ufmRest/app/ufm_version`

## Authentication Configuration

Telemetry and ibdiagnet request authentication options could be enabled or disabled (enabled by default – set to True) in `ufm_rdma.ini` file in [Server] section on the server. The `rest_rdma` server performs simple requests to UFM server, using supplied credentials to verify that the user is allowed to run telemetry or ibdiagnet requests.

```
[Server]
use_ufm_authentication=True
```

## Remote ibdiagnet Request

The following two user scripts can run on the hosting server.

- `remote_ibdiagnet_auth.sh`
- `remote_ibdiagnet.sh`

These scripts should be copied from the container to the hosting server using the following command:

```
cp <containerId>:/opt/ufm/ufm-plugin-ufm-rest/[script name]
/host/path/target
```

Example :

```
cp <containerId>:/opt/ufm/ufm-plugin-ufm-
rest/remote_ibdiagnet_auth.sh /host/path/target
```

The `remote_ibdiagnet.sh` script does not require authentication as the server side can run on a machine which does not run UFM (which is responsible for the authentication). This means it can run from the hosting server.

```
/remote_ibdiagnet.sh [options]
```

## Authenticated Remote ibdiagnet Request

The `remote_ibdiagnet_auth.sh` script can receive parameters as credentials for authentication with UFM server.

```
/remote_ibdiagnet_auth.sh [options]
```

To get all the options, run the following command:

```
/remote_ibdiagnet_auth.sh -h
```

### Note

Important Note:

When using `remote_ibdiagnet.sh`, authentication is not required and the the `ibdiagnet` parameters should be sent in `ibdiagnet` format.

Example: `./remote_ibdiagnet.sh --get_phy_info`

When using the `remote_ibdiagnet_auth.sh`, the `ibdiagnet` parameters should be sent using the `-I` key.

Examples without credentials:

- `./remote_ibdiagnet_auth.sh -I '--get_phy_info'`
- `./remote_ibdiagnet_auth.sh -u username -p password`
- `./remote_ibdiagnet_auth.sh -u username -p password -I '--get_phy_info'`

- `./remote_ibdiagnet_auth.sh -k [token string] -l '--get_phy_info'`
- `./remote_ibdiagnet_auth.sh -s [defined for client certificate host name] -d [path to client certificate pfx file] -l '--get_phy_info'`

Please use the `-h` option to see the examples of credential usage.

## Rest Request with Username/Password Authentication

To get the UFM version from inside the docker:

```
./ufm_rdma.py -r client -u admin -p admin_pwd -t simple -a GET -w ufmRest/app/ufm_version
```

To get the UFM version from hosting server using script:

```
./ufm_rest_rdma_client.sh -u admin -p admin_pwd -t simple -a GET -w ufmRest/app/ufm_version
```

For telemetry:

```
./ufm_rdma.py -r client -u admin -p admin_pwd -t telemetry -a GET -g 9001 -w /csv/enterprise
```

To get ibdiagnet run result using UFM REST API from inside the docker:

```
./ufm_rdma.py -r client -u admin -p admin_pwd -t ibdiagnet -a POST -w ufmRest/reports/ibdiagnetPeriodic -l '{"general":{"name":
```

```
"IBDiagnet_CMD_1234567890_199_88", "location": "local", "running_mode": "once"}, "command_flags": {"--pc": ""}}
```

## Rest Request with Client Certificate Authentication

need to pass path to client certificate file and name of UFM server machine:

```
6. ./ufm_rdma.py -r client -t simple -a GET -w
ufmRest/resources/modules -d /path/to/certificate/file/ufm-
client.pfx -s ufm.azurehpc.core.azure-test.net
for telemetry if need authentication from inside the docker
./ufm_rdma.py -r client -t telemetry -a GET -g 9001 -w
csv/enterprise -d /path/to/certificate/file/ufm-client.pfx -s
ufm.azurehpc.core.azure-test.net
```

### Note

Client certificate file should be located INSIDE the docker container.

## Rest Request with Token Authentication

need to pass token for authentication

```
./ufm_rdma.py -r client -k OGUY7TwLvTmFkXyTkcsEWD9KKNvq6f -t
simple -a GET -w ufmRestV3/app/ufm_version
for telemetry if need to perform authentication
```

```
./ufm_rdma.py -r client -k 4rQRf7i7wEeliuJEurGbeecc210V6G -t  
telemetry -a GET -g 9001 -w /csv/enterprise
```

### **Note**

Token could be generated using UFM UI.

### **Note**

If a token is used for client authentication, `ufmRestV3` must be used.

# NDT Plugin

## Overview

NDT plugin is a self-contained Docker container with REST API support managed by UFM. The NDT plugin introduces the following capabilities:

1.
  1. **NDT topology comparison:** Allows the user to compare InfiniBand fabric managed by the UFM and NDT files which are used for the description of InfiniBand clusters network topology.
    - Verifies the IB fabric connectivity during cluster bring-up.
    - Verifies the specific parts of IB fabric after component replacements.
    - Automatically detects any changes in topology.

## 2. Subnet Merger - Expansion of the fabric based on NDT topology files

Allows users to gradually extend the InfiniBand fabric without causing any disruption to the running fabric. The system administrator should prepare the NDT topology files, which describe the InfiniBand fabric extensions. Then, an intuitive and user-friendly UI wizard facilitates the topology extension process with a step-by-step guidance for performing necessary actions.

- The Subnet Merger tool verifies the fabric topology within a predefined NDT file, and reports issues encountered for immediate resolution.
- Once the verification results are acceptable by the network administrator, the tool creates a topoconfig file to serve as input for OpenSM. This allows setting the physical port states of the designated boundary ports as desired (physical ports can be set as disabled or no-discover).
- Once the topoconfig file is deployed, the IB network can be extended and verified for the next IB extension.

## Deployment

The following are the possible ways NDT plugin can be deployed:

1. On UFM Appliance
2. On UFM Software

For detailed instructions on how to deploy the NDT plugin refer to this [page](#).

## Authentication

Following authentication types are supported:

- basic (/ufmRest)
- client (/ufmRestV2)
- token (/ufmRestV3)

## REST API

The following REST APIs are supported:

## Topodiff

- GET /help
- GET /version
- POST /upload\_metadata
- GET /list
- POST /compare
- POST /cancel
- GET /reports
- GET /reports/<report\_id>
- POST /delete

## Subnet Merger

- GET /merger\_ndts\_list
- GET /merger\_ndts\_list/<ndt\_file\_name>
- POST /merger\_upload\_ndt
- POST /merger\_verify\_ndt
- GET /merger\_verify\_ndt\_reports
- GET /merger\_verify\_ndt\_reports/<report\_id>
- POST /merger\_update\_topoconfig
- POST /merger\_deploy\_ndt\_config
- POST /merger\_update\_deploy\_ndt\_config
- POST /merger\_delete\_ndt

- GET /merger\_deployed\_ndt
- POST /merger\_create\_topoconfig

For detailed information on how to interact with NDT plugin, refer to the [NVIDIA UFM Enterprise > Rest API > NDT Plugin REST API](#).

## NDT Format – Topodiff

NDT is a CSV file containing data relevant to the IB fabric connectivity. The NDT plugin extracts the IB connectivity data based on the following fields:

1. Start device
2. Start port
3. End device
4. End port
5. Link type

## Switch to Switch NDT

By default, IB links are filtered by:

- Link Type is Data
- Start Device and End Device end with IBn, where n is a numeric value.

For TOR switches, Start port/End port field should be in the format **Port N**, where **N** is a numeric value.

For Director switches, Start port/End port should be in the format **Blade N\_Port i/j**, where **N** is a leaf number, **i** is an internal ASIC number and **j** is a port number.

Examples:

Start Device	Start Port	End Device	End Port	Link Type
DSM07-0101-0702-01IB0	Port 21	DSM07-0101-0702-01IB1	Blade 2_Port 1/1	Data
DSM07-0101-0702-01IB0	Port 22	DSM07-0101-0702-01IB1	Blade 2_Port 1/1	Data
DSM07-0101-0702-01IB0	Port 23	DSM07-0101-0702-02IB1	Blade 3_Port 1/1	Data
DSM09-0101-0617-001IB2	Port 33	DSM09-0101-0721-001IB4	Port 1	Data
DSM09-0101-0617-001IB2	Port 34	DSM09-0101-0721-001IB4	Port 2	Data
DSM09-0101-0617-001IB2	Port 35	DSM09-0101-0721-001IB4	Port 3	Data

## Switch to Host NDT

NDT is a CSV file containing data not only relevant to the IB connectivity.

Extracting the IB connectivity data is based on the following five fields:

1. Start device
2. Start port
3. End device
4. End port
5. Link type

IB links should be filtered by the following:

- Link type is "Data".
- "Start Device" or "End Device" end with **IBN**, where **N** is a numeric value.

- The other Port should be based on persistent naming convention: **ibpXsYfZ**, where **X**, **Y** and **Z** are numeric values.

For TOR switches, Start port/End port field will be in the format Port n, where n is a numeric value.

For Director switches, Start port/End port will be in the format **Blade N\_Port i/j**, where **N** is a leaf number, **i** is an internal ASIC number and **j** is a port number.

Examples:

Start Device	Start Port	End Device	End Port	Link Type
DSM071081704019	DSM071081704019 ibp11s0f0	DSM07-0101-0514-01IB0	Port 1	Data
DSM071081704019	DSM071081704019 ibp21s0f0	DSM07-0101-0514-01IB0	Port 2	Data
DSM071081704019	DSM071081704019 ibp75s0f0	DSM07-0101-0514-01IB0	Port 3	Data

## Other

Comparison results are forwarded to syslog as events. Example of `/var/log/messages` content:

1. Dec 9 12:32:31 <server\_ip> ad158f423225[4585]: NDT: missing in UFM "SAT111090310019/SAT111090310019 ibp203s0f0 - SAT11-0101-0903-19IB0/15"
2. Dec 9 12:32:31 <server\_ip> ad158f423225[4585]: NDT: missing in UFM "SAT11-0101-0903-09IB0/27 - SAT11-0101-0905-01IB1-A/Blade 12\_Port 1/9"
3. Dec 9 12:32:31 <server\_ip> ad158f423225[4585]: NDT: missing in UFM "SAT11-0101-0901-13IB0/23 - SAT11-0101-0903-01IB1-A/Blade 08\_Port 2/13"

For detailed information about how to check syslog, please refer to the [NVIDIA UFM-SDN Appliance Command Reference Guide](#) > UFM Commands > UFM Logs.

Minimal interval value for periodic comparison in five minutes.

In case of an error the clarification will be provided.

For example, the request “POST /compare” without NDTs uploaded will return the following:

- URL: [https://<server\\_ip>/ufmRest/plugin/ndt/compare](https://<server_ip>/ufmRest/plugin/ndt/compare)
- response code: 400
- Response:

```
{
  "error": [
    "No NDTs were uploaded for comparison"
  ]
}
```

Configurations could be found in “ufm/conf/ndt.conf”

- Log level (default: INFO)
- Log size (default: 10240000)
- Log file backup count (default: 5)
- Reports number to save (default: 10)
- NDT format check (default: enabled)
- Switch to switch and host to switch patterns (default: see NDT format section)

For detailed information on how to export or import the configuration, refer to the [NVIDIA UFM-SDN Appliance Command Reference Guide > UFM Commands > UFM Configuration Management](#).

Logs could be found in “ufm/logs/ndt.log”.

For detailed information on how to generate a debug dump, refer to the [NVIDIA UFM-SDN Appliance Command Reference Guide > System Management > Configuration Management > File System](#).

# NDT Format – Subnet Merger

The Subnet Merger tool facilitates the seamless expansion of the InfiniBand fabric based on Non-Disruptive Topology (NDT) files. This section outlines the process of extending the fabric while ensuring uninterrupted operation. The tool operates through an intuitive UI wizard, guiding users step-by-step in extending the fabric topology.


The Subnet Merger tool enables the gradual expansion of the InfiniBand fabric without causing disruptions to the existing network. To achieve this, system administrators need to prepare NDT topology files that describe the planned fabric extensions. The tool offers an intuitive UI wizard that simplifies the extension process.

## Functionality


1. **NDT Topology File Verification:** The Subnet Merger tool verifies the InfiniBand fabric topology specified in a predefined NDT file. During this verification, any issues encountered are reported to the user for immediate resolution. This step ensures the integrity of the planned fabric extension.
1. **Topology Extension Preparation:** Upon successful verification of the NDT topology file, the tool generates a comprehensive verification report. The network administrator reviews this report and ensures its acceptability.
1. **Topoconfig File Generation:** After obtaining acceptable verification results, the tool generates a topoconfig file. This file serves as input for OpenSM, the Subnet Manager for InfiniBand fabrics. The topoconfig file allows the network administrator to define the desired physical port states for designated boundary ports. These states include "disabled" or "no-discover."
1. **Fabric Extension and Verification:** With the topoconfig file prepared, the Subnet Merger tool initiates the deployment of the extended fabric configuration. The tool ensures that the defined physical port states are implemented. Once the extension is in place, the IB network can be extended further as needed. The fabric extension is executed while maintaining the operational stability of the existing network.
1. **Conclusion:** The Subnet Merger tool offers a reliable and user-friendly solution for expanding InfiniBand fabrics using NDT topology files. By following the steps provided in the intuitive UI wizard, system administrators can seamlessly extend the fabric while adhering to predefined physical port states. This tool ensures the smooth operation of the fabric throughout the expansion process, eliminating disruptions and enhancing network scalability.

# Subnet Merger Flow

## Initial Fabric Topology



## Target Fabric Topology



1. Create NDT, file that describes initial topology with definition of boundary ports. Boundary ports – switch ports that will be used for fabric extension. In our case it will be r-ufm-sw13 switch ports number 1 and 3. In NDT file those ports should be defined as boundary and disabled:

```
rack #,U
height,#Fields:StartDevice,StartPort,StartDeviceLocation,EndDe
height_1,LinkType,Speed,_2,Cable
Length,_3,_4,_5,_6,_7,State,Domain
,,MF0;r-ufm-sw13:MQM8700/U1,Port
1,,,,,,,,,Disabled,Boundary
,,MF0;r-ufm-sw13:MQM8700/U1,Port 30,,r-ufm55 mlx5_1,Port
1,,,,,,,,,Active,In-Scope
,,MF0;r-ufm-sw13:MQM8700/U1,Port 29,,r-ufm55 mlx5_0,Port
1,,,,,,,,,Active,In-Scope
,,MF0;r-ufm-sw13:MQM8700/U1,Port 26,,r-ufm64 mlx5_0,Port
1,,,,,,,,,Active,In-Scope
,,MF0;r-ufm-sw13:MQM8700/U1,Port
3,,,,,,,,,Disabled,Boundary
```

2. Upload a new NDT topology file which describes the desired topology. Before deploying to UFM, the new NDT topology file should be verified against the existing topology – to find out mismatches and problems.

After the verification, the plugin generates reports including information about:

- - Duplicated GUIDs
  - Misswired links
  - Non-existent links in the pre-defined NDT files
- 1.
  - Links that exist in the fabric and not in the NDT file
- 2. Following the issues detected in the plugin reports, the network administrator changes the NDT file or the fabric. The verification process can be repeated as many times as necessary until the network administrator is satisfied with the results.
- 3. If the NDT verification results are satisfactory, a topoconfig file is generated and can be deployed to the UFM server to be used as configuration input for OpenSM. Topoconfig file should be located at /opt/ufm/files/conf/opensm/topoconfig.cfg on UFM server. By sending SIGHUP signal to opensm it forced to read configuration and to deploy it. In topoconfig file at this stage boundary ports will be defined as **Disabled**.

Example of topoconfig.cfg:

```
0xb83fd2030080302e,1,-,-,Any, Disabled
0xb83fd2030080302e,30,0xf452140300280081,1,Any,Active
0xb83fd2030080302e,29,0xf452140300280080,1,Any,Active
0xb83fd2030080302e,26,0xf452140300280040,1,Any,Active
0xb83fd2030080302e,3,-,-,Any, Disabled
```

4. Next stage is to extend the fabric. Prepare separately new subnet that will be added to the existing fabric and, once it is ready, connect to the boundary ports, that are defined as Disabled in configuration file, so newly added subnet will not be discovered by opensm and will not affect in any way current setup functionality.

- Once new subnet connected to the fabric - prepare next NDT file, that contains setup, that describes current fabric with extended, when previously defined as boundary ports defined as Active and if planned to continue with extension new ports defined as boundary.

For example port number 9 of switch r-ufm-sw13:

```

rack #,U
height,#Fields:StartDevice,StartPort,StartDeviceLocation,EndDe
height_1,LinkType,Speed,_2,Cable
Length,_3,_4,_5,_6,_7,State,Domain
,,MF0;r-ufm-sw13:MQM8700/U1,Port 1,,NEMO-LEAF-2,Port
1,,,,,,,,,,,,Active,In-Scope
,,MF0;r-ufm-sw13:MQM8700/U1,Port 30,,r-ufm55 mlx5_1,Port
1,,,,,,,,,,,,Active,In-Scope
,,MF0;r-ufm-sw13:MQM8700/U1,Port 29,,r-ufm55 mlx5_0,Port
1,,,,,,,,,,,,Active,In-Scope
,,NEMO-LEAF-2,Port 11,,r-ufm57 mlx5_0,Port
1,,,,,,,,,,,,Active,In-Scope
,,MF0;r-ufm-sw13:MQM8700/U1,Port 26,,r-ufm64 mlx5_0,Port
1,,,,,,,,,,,,Active,In-Scope
,,NEMO-LEAF-2,Port 1,,MF0;r-ufm-sw13,Port
1,,,,,,,,,,,,Active,In-Scope
,,MF0;r-ufm-sw13:MQM8700/U1,Port 3,,NEMO-LEAF-2,Port
3,,,,,,,,,,,,Active,In-Scope
,,NEMO-LEAF-2,Port 3,,MF0;r-ufm-sw13,Port
3,,,,,,,,,,,,Active,In-Scope
,,MF0;r-ufm-sw13:MQM8700/U1,Port
9,,,,,,,,,,,,Disabled,Boundary

```

- After new subnet connected physically to the fabric, in opensm configuration file (topoconfig.cfg) boundary ports previously defined as Disabled should be set as No-discover. Example:

```

0xb83fd2030080302e,1,-,-,Any,No-discover

```

```
0xb83fd2030080302e , 30, 0xf452140300280081 , 1, Any, Active
0xb83fd2030080302e , 29, 0xf452140300280080 , 1, Any, Active
0xb83fd2030080302e , 26, 0xf452140300280040 , 1, Any, Active
0xb83fd2030080302e , 3, -, -, Any, No-discover
```

7. Updated file should be deployed to UFM. In case boundary ports will be defined as No-discover – fabric, connected beyond those ports will not be discovered by opensm, but all the ibutils (ibdiagnet...) could send mads beyond those ports to newly added subnet - so NDT file verification for extended setup could be performed.
8. Upload new NDT file and run verification for this file. Fix problems detected by verification. Once satisfied with results – deploy configuration to UFM.

Example of topoconfig file for extended setup:


```
0xb83fd2030080302e , 1, 0x98039b0300867bba , 1, Any, Active
0xb83fd2030080302e , 30, 0xf452140300280081 , 1, Any, Active
0xb83fd2030080302e , 29, 0xf452140300280080 , 1, Any, Active
0x98039b0300867bba , 11, 0x248a0703009c0066 , 1, Any, Active
0xb83fd2030080302e , 26, 0xf452140300280040 , 1, Any, Active
0x98039b0300867bba , 1, 0xb83fd2030080302e , 1, Any, Active
0xb83fd2030080302e , 3, 0x98039b0300867bba , 3, Any, Active
0x98039b0300867bba , 3, 0xb83fd2030080302e , 3, Any, Active
0xb83fd2030080302e , 9, -, -, Any, Disabled
```

9. Repeat previous steps if need to perform additional setup extension.


## Subnet Merger UI

### Bring-Up Merger Wizard

1. Add the NDT plugin to UFM by loading the plugin's image through Settings->Plugins Management. A new item will appear in the main left navigator menu of the UFM labeled "Subnet Merger".





2. Access "Subnet Merger" to initiate the bring-up wizard.





3. The wizard will guide you through the process, containing the following steps:

1. Upload the initial NDT tab and validate it.




2. Once you are satisfied with the results of the validation in the previous tab, you can proceed to deploy the file.






## New Subnet Merger


Once you have successfully deployed the initial NDT file, you can initiate a new merger process by clicking the "New Merger" button.




1. "Connect" Tab, it is important to physically connect the new equipment and confirm the connection. Then, click on a button which will open the boundary ports, change their state from Disabled to No-discover, and then deploy the active file again.



2. "Merge" Tab: Once the new equipment is connected and the boundary ports are updated, upload a new NDT file that includes both the current and newly added equipment, along with their boundary ports for future merges. Please note that you cannot merge the file if there are duplicate GUIDs in the report's results.



3. After completing the merge wizard, and if necessary, you can further proceed to extend the IB fabric.



## Extending the InfiniBand Setup via Subnet Merger

The following instructions outline the necessary steps for expanding the InfiniBand setup or fabric using subnet merging.

### 1. Step 1: NDT File Upload (Repeatable)

Upload the NDT file, performing this action as many times as required, especially when addressing file-related issues.

## 2. **Step 2: NDT File Validation and Verification (Repeatable)**

Validate the NDT file, a process that can be repeated multiple times, particularly after fixing fabric topology or NDT file errors. After initiating this call, you will obtain a validation report ID. The progress of this process is asynchronous, with the report's status initially indicated as "running." Once the report is completed, the status will change to either "Successfully completed" or "Completed with errors."

## 3. **Step 3: Retrieving and Monitoring the Validation Report**

Retrieve the validation report by its corresponding ID, running this step through continuous polling until the report reaches completion.

## 4. **Step 4: Review and Potential Fixes**

Inspect the report and address any necessary fixes to either the NDT file or the topology. Should changes be made to the file, upload the corrected NDT file anew. Alternatively, in case of topology has changed, repeat the verification process.

## 5. **Step 5: Topology Deployment to UFM**

Deploy the verified topology to UFM once you are satisfied with the verification outcomes.

## 6. **Step 6: Adjusting Boundary Ports and Deployment**

Following the physical connection of the setup extension, change the boundary ports' state from "Disabled" to "No-discover."

## 7. **Step 7: Uploading Updated Topoconfig File**

Deploy the updated topoconfig file to the UFM server.

## 8. **Step 8: Next NDT File Upload (Combined Fabric and Extension)**

Upload the next NDT file, which consolidates the current fabric and extension components.

## 9. **Step 9: NDT File Verification**

Conduct the NDT file verification process.

## 10. **Step 10: Reviewing Verification Report**

Review the verification report.

### 11. **Step 11: Addressing Setup or NDT File Issues**

If necessary, make necessary adjustments to the setup or NDT file.

### 12. **Step 12: Final Configuration Deployment**

Once content with the modifications, proceed to deploy the configuration to UFM.

### 13. **Step 13: Iterative Workflow**


Repeat this flow as many times as needed to further the expansion process.

# UFM Telemetry Fluentd Streaming (TFS) Plugin

## Overview

The TFS plugin is designed to extract UFM Telemetry counters from specified telemetry HTTP endpoints and stream them to the designated [Fluentd](#) collector destination.

The diagram below illustrates the plugin's stream flow:



## Deployment

The following are the possible ways the TFS plugin can be deployed:

1. On UFM Appliance
2. On UFM Software

For complete instructions on deploying the TFS plugin, refer to [UFM Telemetry endpoint stream To Fluentd endpoint \(TFS\)](#).

## Authentication

The following authentication types are supported:

- basic (/ufmRest)
- client (/ufmRestV2)
- token (/ufmRestV3)

## Rest API

The following REST APIs are supported:

- POST /plugin/tfs/conf
- GET /plugin/tfs/conf
- POST /plugin/tfs/conf/attributes
- GET /plugin/tfs/conf/attributes

For detailed information on interacting with TFS plugin, refer to the [NVIDIA UFM Enterprise > Rest API > TFS Plugin REST API](#).

# UFM Events Fluent Streaming (EFS) Plugin

## Overview

EFS plugin is a self-contained Docker container with REST API support managed by UFM. EFS plugin extracts the UFM events from UFM Syslog and streams them to a remote FluentD destination. It also has the option to duplicate current UFM Syslog messages and forward them to a remote Syslog destination. As a fabric manager, it will be useful to collect the UFM Enterprise events/logs, stream them to the destination endpoint and monitor them.

## Deployment

The following are the ways EFS plugin can be deployed:

1. On UFM Appliance
2. On UFM Software

For detailed instructions on how to deploy EFS plugin, refer to [UFM Event Stream to FluentBit endpoint \(EFS\)](#).

## Authentication

The following authentication types are supported:

- basic (/ufmRest)
- client (/ufmRestV2)
- token (/ufmRestV3)

## Rest API

The following REST APIs are supported:

- PUT /plugin/efs/conf
- GET /plugin/efs/conf

For detailed information on how to interact with EFS plugin, refer to the [NVIDIA UFM Enterprise > Rest API > EFS Plugin REST API](#).

# UFM Bright Cluster Integration Plugin

## Overview

The Bright Cluster Integration plugin is a self-contained docker container managed by UFM and is managed by the REST APIs. It enables integrating data from Bright Cluster Manager (BCM) into UFM, providing a more comprehensive network perspective. This integration improves network-centered Root Cause Analysis (RCA) tasks and enables better scoping of workload failure domains.

## Deployment

The Bright Cluster Integration plugin can be deployed either on the UFM Appliance or on UFM Software.

For detailed instructions on Bright Cluster Integration plugin deployment, refer to [UFM Bright Cluster Integration Plugin](#).

## Authentication

The following authentication types are supported:

- basic (/ufmRest)
- client (/ufmRestV2)
- token (/ufmRestV3)

## Bright Cluster Integration UI

1. After the successful deployment of the plugin, a new tab is shown under the UFM settings section for bright configurations management:

**NVIDIA UFM Enterprise**

Settings

Events Policy | Device Access | Network Management | Subnet Manager | Non-Optimal Links | User Management | Email | Remote Lo

Bright Configuration

**Bright Configurations**

Status:  Disabled  Enabled

Connection Status: **Healthy**

Host: 10.209.36.79 : 8081

Certificate (.pem):  
-----BEGIN CERTIFICATE-----  
MIIDfzCCAmegAwIBAgIBEDANBgkqhkiG9w0BAQ0FAD

Certificate Key(.key):  
-----BEGIN PRIVATE KEY-----  
MIIEvQIBADANBgkqhkiG9w0BAQEFAASCBCkwwggSjAg

Data Retention Period: 30 Days

Save

**NVIDIA UFM Enterprise**

Settings

Events Policy | Device Access | Network Management | Subnet Manager | Non-Optimal Links | User Management | Email | Remote Lo

Bright Configuration

**Bright Configurations**

Status:  Disabled  Enabled

Connection Status: **Disabled**

Host: IP/Hostname : 8081

Certificate (.pem):

Certificate Key(.key):


Data Retention Period: 30 Days

Save

Fill the below required configurations:

Parameter	Description
Host	Hostname or IP of the BCM server
Port	Port of the BCM server, is typically 8081
Certificate	BMC client certificate content that could be located in the BMC server machine under .cm/XXX.pem
Certificate key	BMC client certificate key that could be located in the BMC server machine under .cm/XXX.key
Data retention period	UFM erases the data gathered in the database after the configured retention period. By default, after 30 days.

- After you ensure you have successfully completed the plugin configuration, and that you have established a healthy connection with the BMC, navigate to the UFM Web GUI -> Managed Elements -> Devices



## Rest API

The following REST APIs are supported:

- PUT plugin/bright/conf
- GET plugin/bright/conf
- GET plugin/bright/data/nodes
- GET plugin/bright/data/jobs

For detailed information on how to interact with bright plugin APIs, refer to [NVIDIA UFM Enterprise > Rest API > UFM Bright Cluster Integration Plugin REST API](#).

# UFM Cyber-AI Plugin

## Overview

The primary objective of this plugin is to integrate the UFM CyberAI product into the UFM Enterprise WEB GUI. This integration would result in both products being available within a single application.

## Deployment

The following are the ways UFM CyberAI plugin can be deployed:


1. On UFM Appliance
2. On UFM Software

First, download the `ufm-plugin-cyberai-image` from the [NVIDIA License Portal \(NLP\)](#), then load the image on the UFM server, using the UFM GUI -> Settings -> Plugins Management tab or by loading the image via the following command:


1. Login to the [UFM server terminal](#).
2. Run:

```
docker load -I <path_to_image>
```

Once the plugin's image has been successfully loaded, you can locate the plugin in the Plugins management table within the UFM GUI. You can then run the plugin by right-clicking on the row associated with the plugin.



After running the plugin successfully. You should be able to see the Cyber-AI items under the main UFM navigation menu:



For more details, please refer to the [UFM Cyber-AI User Manual](#)

# Autonomous Link Maintenance (ALM) Plugin

# Overview

The primary objective of the Autonomous Link Maintenance (ALM) plugin is to enhance cluster availability and improve the rate of job completion. This objective is accomplished by utilizing machine learning (ML) models to predict potential link failures. The plugin then isolates the expected failing links, implements maintenance procedures on them, and subsequently restores the fixed links to their original state by removing the isolation.


The ALM plugin performs the following tasks:

1. Collects telemetry data from UFM and employs ML jobs to predict which ports need to be isolated/de-isolated
2. Identifies potential link failures and isolates them to avert any interruption to traffic flow
3. Maintains a record of maintenance procedures that can be executed to restore an isolated link
4. After performing the required maintenance, the system verifies if the links can be de-isolated and restored to operational status (brought back online)

The ALM plugin operates in the following two distinct modes:

1. Shadow mode
  - Collects telemetry data, runs ML prediction jobs, and saves the predictions to files.
2. Active mode
  - Collects telemetry data, runs ML prediction jobs, and saves the predictions to files.
  - Automatically isolates and de-isolates based on predictions.
  - It is essential to note that a subset of the links must be specified in the allow list to enable this functionality.

## Schematic Flow



## Deployment

The Autonomous Link Maintenance (ALM) plugin can be deployed using the following methods:

1. On the UFM Appliance
2. On the UFM Software

To deploy the plugin, follow these steps:

1. Download the `ufm-plugin-alm-image` from the [NVIDIA License Portal \(NLP\)](#).
2. Load the downloaded image onto the UFM server. This can be done either by using the UFM GUI by navigating to the Settings -> Plugins Management tab or by loading the image via the following instructions:
3. Log in to the UFM server terminal.

4. Run:

```
docker load -I <path_to_image>
```

5. After successfully loading the plugin image, the plugin should become visible within the plugins management table within the UFM GUI. To initiate the plugin's execution, simply right-click on the respective in the table.

Name	Enabled	Tags	Port	Shared Volumes	Status
alm	<input checked="" type="checkbox"/>	LATEST	NA	/opt/ufm/files/log/alm:/var/log/cyb...	running

### **Note**

**The supported InfiniBand hardware technologies are HDR, Beta on NDR.**

## Data Collection

The ALM plugin collects data from the UFM Enterprise appliance in the following two methods:

1. Low-frequency collection: This process occurs every 5 minutes in case the Alm use secondary telemetry(default) or 7 minutes when alm use adynamic telemetry api and gathers data for the following counter:  
hist0,hist1,hist2,hist3,hist4,hist5,hist6,hist7,hist8,hist9,hist10,hist11,hist12,hist13,his

phy\_effective\_errors,phy\_symbol\_errors,CableInfo.Temperature,switch\_temperature,C  
PortRcvErrorsExtended,PortRcvDataExtended,snr\_host\_lane0,snr\_host\_lane1,snr\_ho  
snr\_media\_lane0,snr\_media\_lane1,snr\_media\_lane2,snr\_media\_lane3,link\_down\_ever  
time\_since\_last\_clear

2. High-frequency collection(disabled by default) : This process occurs every 10 seconds and gathers data for the following counters:  
phy\_state,logical\_state,link\_speed\_active,link\_width\_active,fec\_mode\_active,  
raw\_ber,eff\_ber,symbol\_ber,phy\_raw\_errors\_lane0,phy\_raw\_errors\_lane1,phy\_raw\_err  
phy\_raw\_errors\_lane3,phy\_effective\_errors,phy\_symbol\_errors,time\_since\_last\_clear,  
hist0,hist1,hist2,hist3,hist4,switch\_temperature,CableInfo.temperature,link\_down\_ever  
plr\_rcv\_codes,plr\_rcv\_code\_err,plr\_rcv\_uncorrectable\_code,plr\_xmit\_codes,plr\_xmit\_r  
plr\_xmit\_retry\_events,plr\_sync\_events,hi\_retransmission\_rate,fast\_link\_up\_status,  
time\_to\_link\_up,status\_opcode,status\_message,down\_blame,local\_reason\_opcode,  
remote\_reason\_opcode,e2e\_reason\_opcode,num\_of\_ber\_alarms,PortRcvRemotePhy  
PortRcvErrorsExtended,PortXmitDiscardsExtended,PortRcvSwitchRelayErrorsExtend  
VL15DroppedExtended,PortXmitWaitExtended,PortXmitDataExtended,PortRcvDataE  
PortRcvPktsExtended,PortUniCastXmitPktsExtended,PortUniCastRcvPktsExtended,F
3. The collected counters can be configurable and customized to suit your requirements. The counters can be found at /opt/ufm/conf/plugins/alm/counters.cfg

```

root@r-ufm116:~# cat /opt/ufm/conf/plugins/alm/counters.cfg
[HighFreq]
phy_state = last_update_value
logical_state = last_update_value
link_speed_active = last_update_value
link_width_active = last_update_value
fec_mode_active = last_update_value
raw_ber = last_update_value
eff_ber = last_update_value
symbol_ber = last_update_value
phy_raw_errors_lane0 = delta
phy_raw_errors_lane1 = delta
phy_raw_errors_lane2 = delta
phy_raw_errors_lane3 = delta
phy_effective_errors = delta
phy_symbol_errors = delta
time_since_last_clear = last_update_value
hist0 = delta
hist1 = delta
hist2 = delta
hist3 = delta
hist4 = delta
switch_temperature = last_update_value
CableInfo.Temperature = last_update_value
link_down_events = delta
plr_rcv_codes = delta
plr_rcv_code_err = delta
plr_rcv_uncorrectable_code = delta
plr_xmit_codes = delta
plr_xmit_retry_codes = delta
plr_xmit_retry_events = delta
plr_sync_events = delta
hi_retransmission_rate = delta
fast_link_up_status = last_update_value
time_to_link_up = last_update_value
status_opcode = last_update_value
status_message = last_update_value
down_blame = last_update_value
local_reason_opcode = last_update_value
remote_reason_opcode = last_update_value
e2e_reason_opcode = last_update_value
num_of_ber_alarms = delta
PortRcvRemotePhysicalErrorsExtended = delta
PortRcvErrorsExtended = delta
PortXmitDiscardsExtended = delta
PortRcvSwitchRelayErrorsExtended = delta

```

## ALM Configuration

The ALM configuration is used for controlling data collection and isolation/de-isolation. The configuration can be found under `/opt/ufm/cyber-ai/conf/cyberai.cfg`.


Name	Section name	Description
mode	Prediction	<p>The mode can be either "active" or "shadow."</p> <p>In active mode, the ALM will enforce isolation/deisolation rules on all ports which predict to fail except those listed in the "expect" list.</p> <p>In shadow mode, the ALM will enforce isolation/deisolation rules on the ports listed in the "except" list, and predict to fail.</p>

Name	Section name	Description
except_list	Prediction	Includes the ports that receive the opposite treatment compared to the mode. the expect list saved in location /opt/ufm/files/conf/plugin/alm/predict.csv Format: port_guid,port_number 0x1070fd03001769b4,1 0x1070fd03001769b4,3
mode	NOC	The mode can be either "active" or "shadow." In active mode, the ALM will enforce isolation/deisolation rules on all ports that considered as out of nominal condition except those listed in the "expect" list. In shadow mode, the ALM will enforce isolation/deisolation rules on the ports listed in the "except" list.
except_list	NOC	Includes the ports that receive the opposite treatment compared to the mode. the expect list saved in location /opt/ufm/files/conf/plugin/alm/noc.csv Format: port_guid,port_number 0x1070fd03001769b4,1 0x1070fd03001769b4,3
max_per_hour	Isolation	The maximum number of ports that can be isolated in a hour
max_per_week	Isolation	Maximum number of ports that can be isolated in a week
max_per_month	Isolation	Maximum number of the ports that can be isolated in a month
min_links_per_switch_pair	Isolation	Minimum links between two switches to perform isolation
min_active_ports_per_switch	Isolation	Minimum number of active ports per switch before perform isolation
Deisolation_time	Delsolation	The waiting time before deisolate the isolated port
max_per_hour	Delsolation	The maximum number of deisolated port per hour
absolute_threshold_of_isolated_ports	Isolation	The maximum number of ports than can be isolated in one sample

Name	Section name	Description
LowFreqCollector	use_secondary	the flag to determine if we need to use secondary telemetry or dynamic telemetry, if the flag true alm will use secondary else will use dynamic telemetry
LowFreqCollector	secondary_interval	the periodic interval for low frequency collection in case use secondary set to true
LowFreqCollector	interval	periodic interval for low frequency collection in case use alm dynamic telemetry

## ALM UI

After the successful deployment of the plugin, a new item is shown in the UFM side menu for the ALM plugin:



## Current State

This page displays a table presenting the current cluster status, outlining the following counts:

1. Number of ports
2. Number of isolated ports
3. Number of ports in active/shadow prediction mode
4. Number of ports in active/shadow NOC mode
5. Number of ports out of NOC

Current State			
	Switch to Switch	Switch to Host	Total, currently
Number of ports	8(57.14%)	6(42.86%)	14(100%)
Number of isolated ports	1(7.14%)	0(0%)	1(7.14%)
Number of ports in active prediction mode	8(57.14%)	6(42.86%)	14(100%)
Number of ports in shadow prediction mode	0(0%)	0(0%)	0(0%)
Number of ports in active NOC mode	0(0%)	0(0%)	0(0%)
Number of ports in shadow NOC mode	8(57.14%)	6(42.86%)	14(100%)
Out of NOC	0(0%)	0(0%)	0(0%)

## Events Summary

This page displays a table presenting a port count summary, outlining the following counts:

1. Number of isolated ports in the past hour, week, and month for 'host to switch' and 'switch to switch'.
2. Number of de-isolated ports in the past hour, week, and month for 'host to switch' and 'switch to switch'.

- Number of isolation actions **not** taken from prediction by ALM in the past hour, week, and month for 'host to switch' and 'switch to switch'.
- Number of isolation actions **not** taken from NOC by ALM in the past hour, week, and month for 'host to switch' and 'switch to switch'.

Events Summary

Displayed Columns CSV

	Switch to Switch			Switch to Host		
	Past Hour	Past Week	Past Month	Past Hour	Past Week	Past Month
Number of isolation	1	2	2	0	0	0
Number of de-isolation	1	2	2	0	0	0
Number of isolation actions not taken from prediction	3	4	4	0	0	0
Number of isolation actions not taken from NOC	0	0	0	0	0	0

Viewing 1-4 of 4

## Port Level Status

This page displays a table presenting the cluster ports.

Port Level Status

Displayed Columns CSV

Node ID	Port Number	Prediction Mode	NOC Mode	Isolation Status	Type	Last Recommendation	Last Recommendation Time	Last Action	Last Action Time	Last Reason
0x248a070300bee960	9	active	shadow	Health	switch_switch	NA	N/A	NA	N/A	NA
0x043f7203001949e0	3	active	shadow	Health	switch_switch	NA	N/A	NA	N/A	NA
0x043f7203001949e0	5	active	shadow	Health	switch_switch	NA	N/A	NA	N/A	NA
0x98039b0300dfe80	13	active	shadow	De_Isolate	switch_switch	NA	N/A	De-Isolation	N/A	UFM_User
0x0c42a103005bf438	1	active	shadow	Health	host_switch	NA	N/A	NA	N/A	NA
0x1070f03001769b4	1	active	shadow	Health	host_switch	NA	N/A	NA	N/A	NA
0x98039b030000e5c6	1	active	shadow	Health	host_switch	NA	N/A	NA	N/A	NA
0x98039b0300dfe80	11	active	shadow	Health	switch_switch	NA	N/A	NA	N/A	NA
0x043f720300206630	1	active	shadow	Health	switch_switch	NA	N/A	NA	N/A	NA
0x248a070300bee960	7	active	shadow	Health	switch_switch	NA	N/A	NA	N/A	NA

Viewing 1-10 of 14

## Configuration

This page displays ALM plugin configuration update method.

The ALM configuration is divided into four sections:

- General Configurations

**General Configurations** ▼

**Max Number of Isolated Ports by ALM**

**Max Number of Isolated by ALM Per Time Window**

 Hour  Day  Week  Month

**Max Number of De-isolated by ALM Per Time Window**

 Hour

**Minimum Time Port Should be Healthy Before De-isolation**

 Minutes

**Minimum Number of Links Between Two Switches**

**Minimum Number of Active Ports Per Switch**

- Prediction Mode

**Prediction Mode** ▼

**Default Mode**

 Active  Shadow

**Exception List**

 ▼

- NOC Mode

NOC Mode ⓘ

Default Mode

Active Shadow

Exception List

Select Ports

- ML Model Configurations

ML Model Configurations

Threshold

0.65

## ALM Jobs

The table presented below displays the names and descriptions of ALM jobs. These jobs are designed to predict the ports that require isolation/de-isolation. Upon enabling the ALM plugin, these ALM jobs run periodically.

ALM Job Name	Description	Frequency
Port_hist	By using <b>the</b> low frequency bit error histogram counters, the ALM job identifies the ports that will be monitored at high frequency in the next time interval. The job generates an output file that is later read by the high frequency telemetry monitoring job. It prioritizes links that are more susceptible to failure.	5 mins or 7 mins based on configuration
Low_freq_predict	Predicts the likelihood of a port failure by analyzing input data from low frequency telemetry, while only utilizing physical layer counters. The prediction works for isolated ports as well. The resulting output from this task serves as a critical input for determining whether to isolate or de-isolate ports.	5 mins or 7 mins based on

ALM Job Name	Description	Frequency
		configuration
Data Filter	Due to the vast amounts of data generated by the ALM in real time, it's impossible to store all the data for offline analysis. As such, the data filter applies a set of rules to select the N (N << total number of ports in cluster) "most interesting" ports in a given timepoint based on the current, past and future telemetry data. The data of the selected ports will persist for a longer time period, and thus enable to use it offline for debug, model validation, model training and so forth.	5 mins or 7 mins based on configuration
Metric Filter	This job maintains only data samples that are needed for the purpose of online calculation of the model's performance. Specifically, it will only collect samples where a failure was either predicted or actually occurred (e.g. there was an event of packet drop or symbol error). This filtering is required in order to enable the performance calculation to be executed for the entire history of the running plugin, without having to store excessive amounts of data.	5 mins or 7 mins based on configuration

## ClusterMinder Plugin

### Note

This plugin is supported on UFM Enterprise Appliance only.

## Overview

The ClusterMinder plugin collects telemetry data from multiple data sources and aggregates, streams and visualizes the backed. The plugin can cluster/group aggregated Redfish data from multiple machines that allows operational anomaly and misconfigurations detection. The plugin provides Cluster-wide histograms of hardware telemetry which details compute node configuration and inventory, PCIe bus, hardware

information (SN and FW version) and health alerts of all relevant devices on each Redfish category.

The plugin can be deployed as a container and supports multiple data sources, including:

- Redfish on Host
- Redfish on DPU
- MLNX Switch Data
- DOCA Telemetry Service on DPU (BlueField)
- DOCA Telemetry Service on Host
- Unmanaged InfiniBand Switches

## Deployment

The plugin can be deployed using the following methods:

1. On the UFM Appliance
2. On the UFM Software

To deploy the plugin, follow these steps:

- The plugin is included in the default plugin bundle available at [NVIDIA's Licensing Portal](#).
- Load the downloaded image onto the UFM server. This can be done either by using the UFM GUI by navigating to the Settings -> Plugins Management tab or by loading the image via the following instructions:
  - Log in to the UFM server terminal.
  - Run:

```
docker load < <path_to_image>
```


- o After successfully loading the plugin image, the plugin should become visible within the plugins management table within the UFM GUI. To initiate the plugin's execution, simply right-click on the respective in the table.

Name	Enabled	Tags	Port	Shared Volumes	Status
clusterminder	✓	1.1.4	8688		running

## ClusterMinder Plugin UI

After the successful deployment of the plugin, a new item is shown in the UFM side menu for the ClusterMinder plugin:

## Example of Adding Data Source



## Example of Adding the Redfish Host

After inputting the "BMC IP", "Protocol", "Username" and "Password". Pressing the button tests the connection and allows to hosts if successful.

New Source
×

BMC IP

Protocol

Username

Password


Test Result: ✔

bmc_ip	username	protocol	status
<input type="text" value="Filter..."/>	<input type="text" value="Filter..."/>	<input type="text" value="Filter..."/>	<input type="text" value="Filter..."/>
hgx-isr1-pre-03-bmc	redfish	https	Up
hgx-isr1-pre-02-bmc	redfish	https	Up
hgx-isr1-pre-04-bmc	redfish	https	Up
hgx-isr1-pre-01-bmc	redfish	https	Up

Viewing 1-4 of 4

## Example of Removing Data Source

Removing hosts is done through the "Data Sources" section, Right click any available host and click the remove option.



# GRPC-Streamer Plugin

## Authentication

The following authentication types are supported:

- Basic (/ufmRest)
- Token (/ufmRestV3)

## Create a Session to UFM from GRPC

**Description:** Creates a session to receive REST API results from the UFM's GRPC server. After a stream or one call, the session is deleted so the server would not save the authorizations.

- Call: CreateSession in the grpc
- Request Content Type – message SessionAuth
- Request Data:

```
message SessionAuth{
  string job_id=1;
  string username = 2;
  string password = 3;
```

```
optional string token = 4;
}
```

- Job\_id - The unique identifier for the client you want to have
- Username - The authentication username
- Password – The authentication password
- Token – The authentication token
- Response:

```
message SessionRespond{
    string respond=1;
}
```

- Respond types:
  - Success – Ok.
  - ConnectionError – UFM connection error (bad parameters or UFM is down).
  - Other exceptions – details sent in the respond.
- Console command:

```
client session --server_ip=server_ip --id=client_id --
auth=username,password --token=token
```

## Create New Subscription

- Description: Only after the server has established a session for this grpc client, add all the requested REST APIs with intervals and delta requests.
- Call: AddSubscriber

- Request Content Type – Message SubscriberParams
- Request Data:

```
message SubscriberParams{
  message APIParams {
    string ufm_api_name = 1;
    int32 interval = 2;
    optional bool only_delta = 3;
  }
  string job_id = 1;
  repeated APIParams apiParams = 2;
}
```

- Job\_id – A unique subscriber identifier
- apiParams – The list of apiParams from the above message above:
  - ufm\_api\_name – The name from the known to server request api list
  - interval – The interval between messages conducted in a stream run. Presented in seconds.
  - only\_delta – Receives the difference between the previous messages in a stream run.
- Response content type:

```
message SessionRespond{
  string respond=1;
}
```

- Respond Types:
  - Created a user with session and added new IP– Ok.

- Cannot add subscriber that do not have an established session – need to create a session before creating subscriber.
- The server already have the ID – need to create new session and new subscriber with a new unique ID.
- Console command:

```
client create --server_ip=localhost --id=client_id --
apis=events;40;True,links,alarms;10
```

The API's list is separated by commas, and each modifier for the REST API is separated by a semi comma.

If the server is not given a modifier, default ones are used (where only\_delta is False and interval is based on the API).

## Edit Known Subscription

- Description: Changes a known IP. Whether the server has the IP or not.
- Call: AddSubscriber
- Request Content Type – Message SubscriberParams
- Request Data:

```
message SubscriberParams{
  message APIParams {
    string ufm_api_name = 1;
    int32 interval = 2;
    optional bool only_delta = 3;
  }
  string job_id = 1; //unique identifier for this job
  repeated APIParams apiParams = 2;
}
```

- Job\_id – The subscriber unique identifier
- apiParams – A list of apiParams from the above message.
  - ufm\_api\_name – name from the known to server request api list
  - interval – The interval between messages conducted in a stream run. Presented in seconds.
  - only\_delta – Receives the difference between the previous messages in a stream run.
- Response content type:

```
message SessionRespond{
  string respond=1;
}
```

- Respond Types:
  - Created user with new IP– Ok.
  - Cannot add subscriber without an established session – need to create a session before creating subscriber.
  - Cannot add subscriber illegal apis – cannot create subscriber with empty API list, call again with correct API list.

## Get List of Known Subscribers

- Description: Gets the list of subscribers, including the requested list of APIs.
- Call: ListSubscribers
- Request Content Type: google.protobuf.Empty
- Response:

```
message ListSubscriberParams{
```

```
    repeated SubscriberParams subscribers = 1;
}
```

- Console command: server subscribes --server\_ip=server\_ip

## Delete a Known Subscriber

- Description: Deletes an existing subscriber and removes the session.
- Call: DeleteSubscriber
- Request Content Type: Message gRPCStreamerID
- Request Data:

```
message gRPCStreamerID{
  string job_id = 1;
}
```

- Response: protobuf.Empty

## Run a Known Subscriber Once

- Description: Runs the Rest API list for a known subscriber once and returns the result in message runOnceRespond, and then delete the subscriber's session.
- Call: RunOnceJob
- Request Content Type: Message gRPCStreamerID
- Request Data:

```
message gRPCStreamerID{
  string job_id = 1;
}
```

- Response content type:

```
message runOnceRespond{
  string job_id=1;
  repeated gRPCStreamerParams results = 2;
}
```

- Job\_id- The first message unique identifier.
- Results – list of gRPCStreamerParams contains results from each REST API
- Responses:
  - Job id - Cannot run a client without an established session. Empty results – an existing session for this client is not found, and the client is not known to the server.
  - Job id - Cannot run the client without creating a subscriber. Empty results – a session was created for the client but the subscription is not created.
  - Job\_id - Cannot connect to the UFM. empty result – the GRPC server cannot connect to the UFM machine and receive empty results, because it cannot create a subscriber with an empty API list. This means that the UFM machine is experiencing a problem.
  - Job\_id - The first unique message identifier of the messages. Not empty results – Ok
- Console command:

```
client once_id --server_ip=server_ip --id=client_id
```

## Run Streamed Data of a Known Subscriber

- Description: Run a stream of results from the Rest API list for a known Subscriber and return the result as iterator, where each item is message gRPCStreamerParams. at the end, delete the session.

- Call: RunStreamJob
- Request Content Type: Message gRPCStreamerID
- Request Data:

```
message gRPCStreamerID{
  string job_id = 1;
}
```

- Response content type: iterator of messages gRPCStreamerParams

```
message gRPCStreamerParams{
  string message_id = 1; // unique identifier for messages
  string ufm_api_name = 2; // what rest api receive the data from
  google.protobuf.Timestamp timestamp = 3; //what time we created the
  message, can be converted to Datetime
  string data = 4; // data of rest api call
}
```

- Response:
  - One message only containing "Cannot run a client without a session" – A session has not been established
  - No message – A session and/or a subscriber with this ID does not exist.
  - Messages with interval between with the modifiers – Ok
- Console command:

```
client stream_id --server_ip=server_ip --id=client_id
```

## Run a New Subscriber Once

- Description: After ensuring that a session for this specific job ID is established, the server runs the whole REST API list for the new subscriber once and returns the following result in message `runOnceRespond`. This action does not save the subscribe ID or the established session in the server.
- Call: `RunOnce`
- Request Content Type: `Message SubscriberParams`
- Request Data:

```
message SubscriberParams{
  message APIParams {
    string ufm_api_name = 1;
    int32 interval = 2;
    optional bool only_delta = 3;
  }
  string job_id = 1; //unique identifier for this job
  repeated APIParams apiParams = 2;
}
```

- Response content type:

```
message runOnceRespond{
  string job_id=1;
  repeated gRPCStreamerParams results = 2;
}
```

- Responses:
  - Job id = Cannot run a client without an established session. Empty results – no session for this client.
  - Job\_id = 0 – The GRPC server cannot connect to the UFM machine and receive empty results, or it cannot create a subscriber with an empty API list.

- Job\_id = The messages' first unique identifier, and not an empty result – Ok.
- Console command:

```
client once --server_ip=server_ip --id=client_id --  
auth=username,password --token=token --  
apis=events;40;True,links;20;False,alarms;10
```

- The console command creates a session for this specific client.
- A token or the basic authorization is needed, not both.

## Run New Subscriber Streamed Data

- Description: After the server checks it has a session for this job ID, Run a stream of results from the Rest API list for a new Subscriber and return the result as iterator, where each item is message gRPCStreamerParams. at the end, delete the session.
- Call: RunPeriodically
- Request Content Type: Message SubscriberParams
- Request Data:

```
message SubscriberParams{  
  message APIParams {  
    string ufm_api_name = 1;  
    int32 interval = 2;  
    optional bool only_delta = 3;  
  }  
  string job_id = 1; //unique identifier for this job  
  repeated APIParams apiParams = 2;  
}
```

- Response content type: iterator of messages gRPCStreamerParams

- Response:
  - Only one message with data equals to Cant run client without session – no session
  - Messages with intervals between with the modifiers – Ok
- Console command:

```
client stream --server_ip=server_ip --id=client_id --
auth=username,password --token=token --
apis=events;40;True,links;20;False,alarms;10
```

- console command also create session for that client.
- no need for both token and basic authorization, just one of them.

## Run A Serialization on All the Running Streams

- Description: Run a serialization for each running stream. The serialization will return to each of the machines the results from the rest api list.
- Call: Serialization
- Request Content Type: google.protobuf.Empty
- Response: google.protobuf.Empty

## Stop a Running Stream

- Description: Cancels running stream using the client id of the stream and stop it from outside, If found stop the stream.
- Call: StopStream
- Request Content Type: Message gRPCStreamerID
- Request Data:

```
message gRPCStreamerID{
  string job_id = 1;
}
```

- Response: google.protobuf.Empty

## Run a subscribe stream

- Description: Create a subscription to a client identifier, all new messages that go to that client, will be copied and also sent to this stream.
- Call: Serialization
- Request Content Type: message gRPCStreamerID
- Response: iterator of messages gRPCStreamerParams

```
message gRPCStreamerParams{
  string message_id = 1; // unique identifier for messages
  string ufm_api_name = 2; // what rest api receive the data from
  google.protobuf.Timestamp timestamp = 3; //what time we created the
  message, can be converted to Datetime
  string data = 4; // data of rest api call
}
```

- the identifier may or may not be in the grpc server.
- Cannot be stop streamed using StopStream.
- Console command:

```
client subscribe --server_ip=server_ip --id=client_id
```

## Get the variables from a known subscriber

- Description: Get the variables of known subscriber if found, else return empty variables.
- Call: GetJobParams
- Request Content Type: message gRPCStreamerID
- Response:

```
message SubscriberParams{
  message APIParams {
    string ufm_api_name = 1; //currently the list of api from ufm that are
supported are [Jobs, Events, Links, Alarms]
    int32 interval = 2;
    optional bool only_delta = 3;
  }
  string job_id = 1; //unique identifier for this job
  repeated APIParams apiParams = 2;
}
```

## Get Help / Version

- Description: Get help and the version of the plugin, how to interact with the server. What stages need to be done to extract the rest apis (Session>run once/stream or Session>AddSubscriber>once\_id/stream\_id)
- Call: Help or Version
- Request Content Type: google.protobuf.Empty
- Response:

```
message SessionRespond{
  string respond=1;
```

```
}
```

# Sysinfo Plugin

## Overview

The Sysinfo plugin is a Docker container that is managed by UFM and comes with REST API support. Its purpose is to allow users to run commands and extract information from managed switches. This feature enables users to schedule runs at regular intervals and execute commands on switches directly from UFM.

The plugin takes care of managing sessions to the switches and can extend them if necessary. It also enables users to send both synchronous and asynchronous commands to all the managed switches. Additionally, it can intersect the given switches with the running UFM to ensure that only those switches that are on the UFM are activated.

## Deployment

The following are the possible ways plugin plugin can be deployed:

1. On UFM Appliance
2. On UFM Software.
3. Authentication

Following authentication types are supported:

- basic (/ufmRest)
- client (/ufmRestV2)
- token (/ufmRestV3)

## REST API

The following REST APIs are supported:

- GET /help
- GET /version
- POST /query
- POST /update
- POST /cancel
- POST /delete

## Sysinfo Query Format

The Sysinfo plugin is responsible for extracting basic data needed to create a query. This is done using the following five fields:

1. Switches - An array of switch IP addresses. If this field is left empty, the plugin will gather all switches from the running UFM.
2. Callback - The URL location to which the answers should be sent.
3. Commands - An array of commands that need to be executed.
4. Schedule\_run - An optional field used to set intervals for running the commands. The interval can be specified in seconds and can be set to run until a certain duration or end time. The start time can also be controlled.

There are additional flags for a configurable query:

- ignore\_ufm=True: Does not check the UFM for switches or intersect it with given switches
- username: Overrides the switches' default username
- password: Overrides the switches' default password
- is\_async: Rather than attempting to execute all commands simultaneously at the switch, the commands are executed one after the other in sequence.
- one\_by\_one=False: Instead of sending results from each switch as soon as information is obtained, all data is sent at once to the callback. This change eliminates multiple small sends and replaces them with a single large send.

For detailed information on how to interact with Sysinfo plugin, refer to the [NVIDIA UFM Enterprise > Rest API > Sysinfo Plugin REST API](#).

## SNMP Plugin

The SNMP plugin is a self-contained Docker container that includes REST API support and is managed by UFM. Its primary function is to receive SNMP traps from switches and forward them to UFM as external events. This feature enhances the user experience by providing additional information about switches in the InfiniBand fabric via UFM events and alarms.

### Deployment

There are two potential deployment options for the SNMP plugin:

- On UFM Appliance
- On UFM Software

For detailed instructions on how to deploy the SNMP plugin, refer to [this page](#).

### Authentication

The following authentication types are supported:

- basic (/ufmRest)
- client (/ufmRestV2)
- token (/ufmRestV3)

### REST API

The following REST API are supported:

- GET /switch\_list
- GET /trap\_list
- POST /register
- POST /unregister

- POST /enable\_trap
- POST /disable\_trap
- GET /version

For more information, please refer to [UFM Enterprise Documentation](#) → UFM REST API → SNMP Plugin REST API.

## Usage

By default, upon initialization, the SNMP plugin captures traps from all switches within the fabric. However, this behavior can be modified through configuration settings utilizing the "snmp\_mode" option, with available values of "auto" or "manual".


It is important to ensure that the switch is visible to UFM and has a valid IP address. As illustrated in the following example, switch traps will only be received from "r-ufm-sw61".

Severity	Name	GUID	Type	Model	IP	Firmware Version
Info	r-ufm-248	Dx1070f603001763ec	host		192.168.1.30	16.35.2000
Info	r-ufm-247	Dx248a070300554548	host		0.0.0.0	12.29.312
Info	r-ufm-sw61	Dxe41d2d0300092200	switch	5K6012	10.209.36.61	9.4.5070
Info	r-ufm-sw62	Dx7cfe900300fce8e0	switch	MSB7700	0.0.0.0	11.2008.3336

The following is an instance of a trap received by the SNMP plugin and displayed as a UFM event:

Severity	Event Name	Source	Description	Category
Critical	General External Event Error	Grid	SNMP traps from 10.209.24.108: 'oid=MELLANX-EFM-MIB::systemHealthStatus, MELLANX-EFM-MIB::invHealthStatus.1 = Power Supply 2 is unresponsive', happened 1 times	
Critical	General External Event Error	default / Switch: r-ufm-sw61	SNMP traps from r-ufm-sw61: 'oid=MELLANX-EFM-MIB::systemHealthStatus, MELLANX-EFM-MIB::invHealthStatus.1 = Power Supply 1 is unresponsive', happened 1 times	
Critical	Disk utilization threshold reached	Grid	Disk space usage in /opt/ufm/files/log is above the threshold of 90.0%.	
Warning	General External Event Alert	default / Switch: r-ufm-sw61	SNMP traps from r-ufm-sw61: 'oid=MELLANX-EFM-MIB::resetTrap, IF-MIB::PhysAddress.2 = e1-1d-2d-d0-91:20', happened 1 times	

Additionally, there is an option to verify events/alarms for a particular switch:



The SNMP plugin performs a periodic check of the fabric every 180 seconds, allowing for prompt receipt of traps from new switches or updated IP addresses of existing switches in under 180 seconds. This interval may be adjusted via the "ufm\_switches\_update\_interval" option. To manually register or unregister a switch, please refer to the [UFM Enterprise Documentation](#) → UFM REST API → SNMP Plugin REST API.

The SNMP plugin employs the most up-to-date SNMP v3 protocol, which incorporates advanced security measures such as authentication and encryption. The "snmp\_version" option enables the selection of SNMP versions "1" or "3". It is essential to note that only switch-exposed traps will be transmitted to UFM as events.

OID	Name	Description	Status	Severity
MELLANOX-EFM-MIB::testTrap	send-test	A test trap ordered by the system administrator	Enabled	Warning
MELLANOX-EFM-MIB::asicChipDown	asic-chip-down	ASIC (Chip) Down	Enabled	Critical
MELLANOX-EFM-MIB::cpuUtilHigh	cpu-util-high	CPU utilization has risen too high	Enabled	Warning
MELLANOX-EFM-MIB::diskSpaceLow	disk-space-low	Filesystem free space has fallen too low	Enabled	Warning
MELLANOX-EFM-MIB::expectedShutdown	expected-shutdown	Expected system shutdown	Enabled	Info
MELLANOX-EFM-MIB::systemHealthStatus	health-module-status	Health module Status	Enabled	Critical
MELLANOX-EFM-MIB::insufficientFans	insufficient-fans	Insufficient amount of fans in system	Enabled	Warning
MELLANOX-EFM-MIB::insufficientFansRecover	insufficient-fans-recover	Insufficient amount of fans in system recovered	Enabled	Info


OID	Name	Description	Status	Severity
MELLANOX-EFM-MIB::insufficientPower	insufficient-power	Insufficient power supply	Enabled	Warning
RFC1213::linkdown	interface-down	An interface's link state has changed to down	Enabled	Minor
RFC1213::linkup	interface-up	An interface's link state has changed to up	Enabled	Info
MELLANOX-EFM-MIB::unexpectedShutdown	unexpected-shutdown	Unexpected system shutdown	Enabled	Minor
SNMPv2-MIB::coldStart	cold-start	SNMP entity reinitialized	Enabled	Info

To learn more about how to enable or disable a specific trap, please refer to the [UFM Enterprise Documentation](#) → UFM REST API → SNMP Plugin REST API.

If some traps are not included in the default list, they may be added using the "snmp\_additional\_traps" option. The SNMP plugin will consider these traps as "enabled" and transmit them to UFM as events with an "Info" severity level.

To ensure the uninterrupted reception of traps from switches within a large fabric, changes must be made to the UFM configuration in the [/opt/ufm/conf/gv.cfg] file's [Events] section. Specifically, the "max\_events" option should be raised from 100 to 1000, while "medium\_rate\_threshold" and "high\_rate\_threshold" should both be set to 500. To implement configuration adjustments, disable and then enable the plugin.

In case of an event storm, it is necessary to adjust the Event Policy settings such that General Events are non-alarmable and the TTL is set to zero, as illustrated in the following screenshot:



## Other

Additional configurations are located in "/opt/ufm/conf/plugins/snmp/snmp.conf". To implement configuration adjustments, disable and then enable the plugin. For instructions

on modifying the appliance, please refer to the [UFM-SDN App CLI Guide](#).

Logs for the SNMP plugin are stored in "/opt/ufm/logs/snmptrap.log". For guidance on accessing logs on the appliance, please refer to the [UFM-SDN App CLI Guide](#).

# Packet Level Monitoring Collector (PMC) Plugin

## Overview

The Packet Monitoring Collector/Controller plugin facilitates the configuration capture and display of a variety of events, enabling users to conduct real-time monitoring of network events. The PMC plugin is included in the plugins bundle, which can be downloaded from [NVIDIA's Licensing Portal](#).

Supported triggers are pFRN, Congestion, Fast Recovery, CQE and PHY Error Links.

Network events are stored as UFM events and are archived in files for later retrieval. Additionally, they can be observed through the PMC user interface. Events can be streamed externally via UFM REST API in the same way that UFM events are streamed. The REST APIs are described in the [UFM Enterprise REST API Guide](#).

## pFRN

- pFRN Notifications - Enables/Disables mirroring on pFRN trigger for entire network or list of GUIDs

## Fast Recovery

- Fast Recovery Notifications - Enables/Disables mirroring on Fast Recovery trigger for entire network or list of GUIDs
- Notifications Level - Specifies threshold for Fast Recovery mirroring. (Thresholds are configured in SM configuration)

## PHY Error Links

- PHY Error Links Notifications - Enables/Disables mirroring on PHY Link Error trigger for entire network or list of GUIDs
- Specifies threshold for PHY Link Error mirroring. (Thresholds are configured in SM configuration)

## CQE

- CQE Notifications - Enables/Disables mirroring on CQE Notifications trigger for entire network or list of GUIDs

## Congestion

- Congestion Notifications - Enables/Disables mirroring on Congestion Notifications trigger for entire network or list of GUIDs
  - Mirrored packets (%) - Specifies the percent of congested packets to be mirrored.
  - High threshold - High threshold percentage for InfiniBand switch egress port queue size. Values are in the [1,1023] range.
  - Low threshold - Low threshold percentage for InfiniBand switch egress port queue size. Values are in the [1,1023] range.

### **Note**

When a packet enters an InfiniBand switch, its data is stored at an ingress port buffer. A pointer to the packet's data is inserted into the egress port's queue, from which the packet will be exiting the switch. At that point, the threshold given by this command line argument is compared to the egress queue data size. If the queue data size exceeds the threshold, a congestion event is reported. The threshold is given in percent of the ingress port size.

An egress port queue can point data coming from multiple ingress port buffers, therefore the threshold can be bigger than 100%.


## Deployment

### Installation

Load the image on the UFM server; either using the UFM GUI -> Settings -> Plugins Management tab, or by loading the image via the following command:

1. [Login to the UFM server terminal.](#)
2. [Run](#)

```
docker load -I <path_to_image>
```



Upon completion of the plugin addition and subsequent refresh of the UFM GUI, the left navigation bar will display two new menu items. These two tabs can be observed in the following GUI screenshots

## PMC UI

### Network Event Collector Display

timestamp	src guid	src lid	src desc	local qpn	dst lid	remote qpn	transport	syndrome
2024-01-02 11:20:13.607486	0x98039b03009fce86	1	smg-ib-svr065 mib5_0	72	6	224	RC	Remote Access Error

### Network Event Collector Configuration

Network Event Collector Configuration

**Collectors**

pFRN Notifications on Entire Network

Fast Recovery Notifications on Entire Network

Notification Level Normal

PHY Error Links Notifications on Entire Network

Notification Level Normal

CQE Notifications on Entire Network

Congestion Notifications Disabled

Mirrored packets (%)

High threshold

Low threshold

**General Options**

enable adaptive routing

enable aggregation

enable autostart

# PDR Deterministic Plugin

## Overview

The PDR deterministic plugin, overseen by the UFM, is a docker container that isolates malfunctioning ports, and then reinstates the repaired links to their previous condition by lifting the isolation. The PDR plugin uses a specific algorithm to isolate ports, which is based on telemetry data from the UFM Telemetry. This data includes packet drop rate, BER counter values, link down counter, and port temperature. Any decisions made by the plugin will trigger an event in the UFM for tracking purposes.


The PDR plugin performs the following tasks:

1. Collects telemetry data using UFM Dynamic Telemetry
2. Identifies potential failures based on telemetry calculations and isolates them to avert any interruption to traffic flow

3. Maintains a record of maintenance procedures that can be executed to restore an isolated link
4. After performing the required maintenance, the system verifies if the ports can be de-isolated and restored to operational status (brought back online).

The plugin can simulate port isolation without actually executing it for the purpose of analyzing the algorithm's performance and decision-making process in order to make future adjustments. This behavior is achieved through the implementation of a "dry\_run" flag that changes the plugin's behavior to solely record its port "isolation" decisions in the log, rather than invoking the port isolation API. All decisions will be recorded in the plugin's log.

## **Schematic Flow**



## Deployment

To deploy the plugin, follow these steps:


1. Download the `ufm-plugin-pdr_deterministic-image` from the **Docker Hub**.
2. Load the downloaded image onto the UFM server. This can be done either by using the UFM GUI by navigating to the Settings -> Plugins Management tab or by loading the image via the following instructions:

1. Log in to the UFM server terminal.

2. Run:

```
docker load -I <path_to_image>
```

3. After successfully loading the plugin image, the plugin should become visible in the plugin management table within the UFM GUI. To initiate the plugin's execution, simply right-click on the respective in the table.



## Isolation Decisions

### NDR Link Validation Procedure

Verify ports that are in INIT, ARMED or ACTIVE states only. Track the SymbolErrorsExt of every such link for at least 120m. If polling period is  $P_m$ , need to keep  $N = (125 + P_m + 1) / P_m$  samples. Also, two delta samples are computed: number of samples covering 12 minutes  $S_{12m} = (12 + P_m + 1) / P_m$  and  $S_{125m} = (125 + P_m + 1) / P_m$ .  $12m\_thd = LinkBW\_Gbps * 1e9 * 12 * 60 * 1e-14$  (2.88 for NDR) and

$125m\_thd = LinkBW\_Gbps * 1e9 * 125 * 60 * 1e-15$  (3 for NDR).

Check the following conditions for every port in the given set:

1. If the  $\Delta(LinkDownedCounterExt)$  port is  $> 0$  and the  $\Delta(LinkDownedCounterExt)$  remote port is  $> 0$ , add it to the list of bad\_ports. This condition should be ignored if the --no\_down\_count flag is provided.
2. If the  $symbol\_errors[now\_idx] - symbol\_errors[now\_idx - S_{12m}]$  is  $> 12m\_thd$ , add the link to the list of bad\_ports, and continue with next link.

- If the `symbol_errors[now_idx] - symbol_errors[now_idx - S125m]` is  $> 125m\_thd$ , add the link to the list of `bad_ports`, continue with next linkPacket drop rate criteria

When packet drops due to the link health are detected, isolate the problematic link. To achieve this, a target `packet_drop/packet_delivered` ratio can be employed to include TX ports with a receiver exceeding this threshold in the list of `bad_ports`. However, the drawback of this method is that such links may fluctuate between bad/good state since their BER may be normal. Therefore, it is advisable to track their statistics over time and refrain from reintegrating them after their second or third de-isolation.

## Return to Service

Continuously monitoring the collection of `bad_ports`, the plugin persistently assess their Bit Error Rate (BER) and determines their reintegration when they successfully pass the 126m test without errors.

## Configuration

The following parameters are configurable via the plugin's configuration file. (`pdr_deterministic.conf`)

Name	Description	Default Value
INTERVAL	Interval for requesting telemetry counters, in seconds.	300
MAX_NUM_ISOLATE	Maximum ports to be isolated. $\max(\text{MAX\_NUM\_ISOLATE}, 0.5\% * \text{fabric\_size})$	10
TMAX	Maximum temperature threshold	70 (Celsius)
D_TMAX	Maximum allowed Temperature Delta	10
MAX_PDR	Maximum allowed packet drop rate	1e-12
CONFIGURED_BER_CHECK	If set to true, the plugin will isolate based on BER calculations	True
CONFIGURED_TEMP_CHECK	If set to true, the plugin will isolate based on temperature measurements	True

Name	Description	Default Value
LINK_DOWN_ISOLATION	If set to true, the plugin will isolate based on LinkDownedCounterExt measurements	False
SWITCH_TO_HOST_ISOLATION	If set to true, the plugin will isolate ports connected via access link	False
DRY_RUN	Isolation decisions will be only logged and will not take effect	False
DEISOLATE_CONSIDER_TIME	Consideration time for port de-isolation (in minutes)	5
DO_DEISOLATION	If set to false, the plugin will not perform de-isolation	True
DYNAMIC_WAIT_TIME	Seconds to wait for the dynamic telemetry session to respond	30

## Calculating BER Counters

For calculating BER counters, the plugin extracts the maximum window it needs to wait for calculating the BER value, using the following formula:

$$seconds = \frac{max\_BER\_target^{-1}}{min\_port\_rate}$$

### Example:

Rate	BER Target	Minimum Bits	Minimum Time in Seconds	In Minutes
HDR 2.00E+11	1.00E-12	1.00E+12	5	0.083333
HDR 2.00E+11	1.00E-13	1.00E+13	50	0.833333
HDR 2.00E+11	1.00E-14	1.00E+14	500	8.333333
HDR 2.00E+11	1.00E-16	1.00E+16	50000	833.3333

BER counters are calculated with the following formula:

$$BER = \frac{error\ bits_i - error\ bits_{i-1}}{total\ bits_i - total\ bits_{i-1}} = \frac{error\ bits_i - error\ bits_{i-1}}{Link\ data\ rate * (time_i - time_{i-1})}$$

## Ports Exclusion List

You can designate specific ports to be excluded from PDR analysis, isolation, or de-isolation for an indefinite or limited period. Already excluded ports can also be removed from this list.

Ports are added to or removed from the exclusion list via the PDR plugin's REST API.

To add ports to the exclusion list (to be excluded from analysis), run:

```
curl -k -i -u <user:password> -X PUT
'https://<host_ip>/ufmRest/plugin/pdr_deterministic/excluded' -d '[<formatted_ports_list>]' -H
"Content-Type: application/json"
```

Optionally, you can specify a TTL (time to live in the exclusion list) following the port after the comma. If zero or not specified, the port is excluded. For example:

```
-d '[["9c0591030085ac80_45"],["9c0591030085ac80_46",300]]'
```

To remove ports from the exclusion list:

```
curl -k -i -u <user:password> -X DELETE
'https://<host_ip>/ufmRest/plugin/pdr_deterministic/excluded' -d '[<comma_separated_port_names>]'
-H "Content-Type: application/json"
```

Example:

```
-d '["9c0591030085ac80_45","9c0591030085ac80_46"]'
```

To retrieve ports and their remaining exclusion times from the exclusion list:

```
curl -k -i -u <user:password> -X GET  
'https://<host_ip>/ufmRest/plugin/pdr_deterministic/excluded'
```

## GNMI-Telemetry Plugin

The GNMI Telemetry Plugin is a server that uses the gNMI protocol to stream data from UFM telemetry. Users can select the data to stream, specify intervals, and choose to include only deltas (on-change mode).

The server supports three functions: Capability, Get and Subscribe.

**Data Streaming:** The streamed data is delivered in CSV format. Headers are provided in the first message and included in subsequent messages. Data is presented in hex format to conserve space for unchanged data. Values are displayed as an array of strings, each representing a unique identifier (GUID) and port. Depending on the mode, values may have missing rows if there are no changes in the GUID and port.

**Metadata Streaming:** The plugin can stream UFM's metadata, providing an inventory of it. For convenience, examples use the gNMIc client, but any gNMI client can be used.

**Configuration and Polling Intervals:** The polling intervals for each server cache are configurable with the following defaults:

- Telemetry: every 5 minutes
- Inventory: every minute
- Events: every minute
- Switch rank: every 6 hours

The service supports telemetry from switch-level data (fset) and port-level data (xcset), querying `low_freq_debug xcset` by default. Multiple telemetries can be polled simultaneously.

**Data Sharding:** The service supports sharding the cache data on request, allowing many clients to request the same data while each receiving a different part.

## Deployment

To deploy the plugin with UFM (SA or HA):

1. Install the latest version of UFM.
2. Run UFM with `/etc/init.d/ufmd start`.
3. Pull the plugin image from the Docker Hub.
4. Run `/opt/ufm/scripts/manage_ufm_plugins.sh add -p gnmi_telemetry -t <version>` to enable the plugin, or use the UFM UI to add the plugin via Setting → Plugin Management → Right Click on GNMI-telemetry → Add → select version → Add.
5. Check that the plugin is running with `docker ps`.
6. If the gNMI default port is unavailable, change the config file `gnmi_telemetry.env` and restart the plugin.

## Authentication

The server's authentication is determined by the gNMI protocol. Two configurable items require authentication: the UFM Telemetry URL and the UFM inventory IP.

- Authentication is not necessary for the UFM telemetry URL. Therefore, only the telemetry URL is required.
- The inventory is sourced from the UFM of the local host, but can be changed to a different machine in the config file. To do so, token access to that machine is necessary.

## Secure Server

The server can be secured using certificates. To secure the server, set the "secure\_mode\_enabled" flag to "true" in the configuration (default is true). Upon initialization, the gNMI server retrieves UFM certificates from the `/opt/ufm/conf/webclient` folder. The certificate folder can be changed by modifying the shared volume.

The server requires client-call certificates, granting access only if client certificates match its own. The gNMI server periodically checks its certificates for updates, ensuring they remain up-to-date. The client certification naming convention must align with the DNS name (SAN) as the UFM.

## Supported API Requests

The service supports the following requests:

- **Capability:** Describes the YANG files the service supports (UFM telemetry).
- **Get:** Requires legal paths; receives the cache data from the service.
- **Subscribe:** Requires legal paths and an interval; receives cache data at the specified interval. The first message contains headers extracted from the path, and subsequent messages include only the headersID. In on-change subscribe mode, a heartbeat interval is provided instead of an interval. During the heartbeat interval, if no data changes, no notification is sent; A full notification message, similar to the first message, is sent. If some data changes a notification of the change is sent; No heart message is send.

## Capability Request

The capability request provides information about the YANG files that the server supports, including their versions. This request can be fulfilled without requiring a connection to the telemetry or inventory.

### Example:

```
gnmic -a localhost:9339 capability
```

Example Response:

```
gNMI version: 1.2.11
supported models:
  - nvidia-ib-amber, Nvidia IB, 1.0.0
  - nvidia-ib-amber-ext, Nvidia IB, 1.0.0
  - nvidia-ib-amber-inventory-counters, Nvidia IB, 1.0.0
  - nvidia-ib-amber-port-counters, Nvidia IB, 1.0.0
supported encodings:
  - JSON
  - JSON_IETF
```

# Supported Paths

## Telemetry Request Path Construction

To construct a path for a telemetry request, follow these steps:

1. Begin with "nvidia/ib".
2. Specify sharding if desired. For example, to partition the data into 10 pieces and take the second partition, use 2/10.
3. Specify the `node_guid` to select, using an asterisk (\*) to select all nodes.
4. Specify the desired ports for the selected nodes, using an asterisk (\*) to select all ports.
5. Select "amber" for amBER telemetry.
6. Specify the desired counters group. If unknown, this step can be skipped.
7. Specify the counter, using an asterisk (\*) to select all the counters in the cache. If a counters group is used, it will return all counters in the specified group.

## Other Information Requests (Events, Inventory)

1. Begin with "nvidia/ib".
2. Specify `inventory` or `events`.

## Switch Rank Information Path Construction

To construct a path for switch rank information, follow these steps:

1. Begin with "nvidia/ib".
2. Specify the `node_guid` to select, using an asterisk (\*) to select all nodes.
3. Select "amber" for amBER telemetry.
4. Use `Switch_rank` as the counter name.

## Additional Configurations

Name	Description	Default
grpc_port	The port that the service uses for the gNMI protocol	9339
cpu_list	The CPU cores that the server is allowed to use	3
include_port_sharding	Includes the ports in the sharding. Ports of the node may not be in the same shard	false
filtered_columns	Specifies which counters to ignore when querying the telemetry	port_guid
ufm_ip	If querying events and inventory from a different UFM instance, provide the IP of that host machine and a UFM token for remote UFM	127.0.0.1
ufm_access_token	Required if the ufm_ip is not local	

## Telemetry Messages - Data Format

Telemetry messages consist of two key components: Headers and Values, both representing telemetry data in a CSV format.

- **Headers:** Initially provided in a full mode, but transition to a string hash format after the second message when using a subscribe request to reduce message size.
- **Values:** Each value begins with a timestamp, followed by the `node_guid` and port number, and then the counter value in the same order as the headers. If a counter is not present for a node, it will be empty in the message.

In on-change subscribe messages, only nodes with changes and their corresponding modified values are included. All other counters for that node will remain empty.

Example:

```
gnmic -a localhost:9339 --insecure sub --path
nvidia/ib/guid[guid=*]/port[port_number=*]/amber/port_counters/his
```

```

--path
nvidia/ib/guid[guid=*]/port[port_number=*]/amber/port_counters/hist
-i 30s
[ { "source": "localhost:9339",
  "subscription-name": "default-1690282472",
  "timestamp": 1690282475124352063,
  "time": "2023-07-25T13:54:35.124352063+03:00",
  "updates": [ { "Path": "nvidia/ib/amber/reply/sample", "values": {
"nvidia/ib/amber/reply/sample": {
  "Headers": "timestamp,guid,port,hist0,hist1",
  "HeaderID": "5246201354",
  "Values": [ "240771222771818,0x8168793592c6a790,1,,2",
"240771222771818,0x47a67159c915493f,1,1,2",
...
"240771222771818,0x667203ac69f3f2bf,1,2,",
"240771222771818,0x113cd807bfed3853,1,0,"
]}}}}]

```

The second message on the headers will be set to hash values.

## Get Request

The Get request retrieves data at a specified path. If the telemetry is devoid of information, the server will respond with an empty response. Otherwise, it will respond with counters it can locate.

### Example:

```

gnmic -a localhost:9339 --insecure get --path
nvidia/ib/guid[guid=0x5255456]/port[port_number=2]/amber/port_counter

```

The request retrieves data from node\_guid 0x5255456, specifically in port number 2, with the request counter set to hist0.

### Example 2:

```
gnmic -a localhost:9339 --insecure get --path  
nvidia/ib/guid[guid=*]/port[port_number=*]/amber/port_counters/hist0
```

The request retrieves the data from all the ports and the node\_guids, with the request counter set to hist0.

### Example3:

```
gnmic -a localhost:9339 --insecure get --path  
nvidia/ib/guid[guid=0x5255456]/port[port_number=2]/amber/*
```

The request retrieves the data from node\_guid 0x5255456, port 2, with the request counters set to "all".

### Example for multi path:

```
gnmic -a localhost:9339 --insecure get  
nvidia/ib/guid[guid=*]/port[port_number=*]/amber/CableInfo.transmit  
--path  
nvidia/ib/guid[guid=*]/port[port_number=*]/amber/sel_gctrln_en_5_1  
--path  
nvidia/ib/guid[guid=*]/port[port_number=*]/amber/num_pll5_7nm --  
path  
nvidia/ib/guid[guid=*]/port[port_number=*]/amber/rcal_fsm_done --  
path  
nvidia/ib/guid[guid=*]/port[port_number=*]/amber/LinkErrorRecoveryC  
--path  
nvidia/ib/guid[guid=*]/port[port_number=*]/amber/sel_enc2_ib0_lane2  
--path  
nvidia/ib/guid[guid=*]/port[port_number=*]/amber/lockdet_err_cnt_ur
```

## Response Example:

```
[ {
  "source": "localhost:9339",
  "timestamp": 1719232374915165166,
  "time": "2024-06-24T15:32:54.915165166+03:00",
  "updates": [ {
    "Path": "nvidia/ib/amber/reply",
    "values": {
      "nvidia/ib/amber/reply": {
        "Headers":
[ "timestamp", "Node_GUID", "Port_Number", "CableInfo.transmitter_technology", "sel_gctrln_en_5_lane0", "i
        "Values": [

"1719232345757948,0x91f87bf42deb3e03,1,5091,7826,6290,8615,4247,8586,6214" ,

"1719232345757948,0x7b8c2e08907250ce,1,2891,3293,5774,4398,3681,3548,7408" ,

"1719232345757948,0x48b60e6f3670eaca,1,9477,3847,1184,5527,4783,2102,8192" ,

"1719232345757948,0xabccdad7f8a3eda6,1,7976,6143,8257,3770,6166,6690,2835" ,

"1719232345757948,0x6d9ec4bb5fa45736,1,9051,2982,7145,3604,9256,1061,2638" ,

"1719232345757948,0x028cf9e0f9ed7c32,1,5623,7483,2263,2265,6890,4875,5564" ,

"1719232345757948,0x92a984c1a491b72a,1,6732,7795,6411,8569,3370,705,5536" ,

"1719232345757948,0x8b4b404acd2f34da,1,7610,7128,10064,1880,4834,3411,6724" ,

"1719232345757948,0x20f92ed58991d56c,1,6805,1632,5407,2038,1865,7279,8350" ,

"1719232345757948,0x1dac004a426bb5f5,1,8351,5757,7925,6181,3260,3081,1554"

        ]
      }
    }
  ]
}
```

```
}}}]}
```

## Subscribe Stream Request

The Subscribe request, similar to the get request, provides data from the specified path. When the telemetry is empty, the server responds with an empty result. If data is available, the server responds with the retrieved counters. The stream delivers information at the specified interval. If no interval is specified, the server transmits the information at the default server rate, which is configurable and defaults to 10s.

### Example:

```
gnmic -a localhost:9339 --insecure sub --path  
nvidia/ib/guid[guid=0x5255456]/port[port_number=2]/amber/port_counter  
-i 30s
```

This request retrieves data from the node\_guid 0x5255456, port 2, where the request counter is hist0, and the interval is configured for 30 seconds. If the user wishes to test the stream, the stream mode can be configured to "once," and following a single response, the stream will be stopped.

### Example:

```
gnmic -a localhost:9339 --insecure sub --path  
nvidia/ib/guid[guid=0x5255456]/port[port_number=2]/amber/port_counter  
-i 30s --mode once
```

This request retrieves the data from node\_guid 0x5255456, port 2, where the request counter is hist0. The stream shuts down after one response, similar to a Get request.

### Example:

```
gnmic -a localhost:9339 --insecure sub --path
```

```
nvidia/ib/guid[guid=*]/port[port_number=*]/amber/* -i 10s
```

The server responds for the first two notifications, as follows:

```
{
  "source": "localhost:9339",
  "subscription-name": "default-1719233128",
  "timestamp": 1719233128171946518,
  "time": "2024-06-24T15:45:28.171946518+03:00",
  "updates": [ {
    "Path": "nvidia/ib/amber/reply/sample",
    "values": {
      "nvidia/ib/amber/reply/sample": {
        "HeaderID": "970426048",
        "Headers":
[ "timestamp", "Node_GUID", "Port_Number", "Counter1", "Counter2", "Counter3", "Counter4", "Counter5",
"Counter7" ],
        "Values": [
          "1719232345757948,0x91f87bf42deb3e03,1,5091,7826,6290,8615,4247,8586,6214" ,
          "1719232345757948,0x7b8c2e08907250ce,1,2891,3293,5774,4398,3681,3548,7408" ,
          "1719232345757948,0x1dac004a426bb5f5,1,8351,5757,7925,6181,3260,3081,1554" ,
          "1719232345757948,0x48b60e6f3670eaca,1,9477,3847,1184,5527,4783,2102,8192" ,
          "1719232345757948,0xabccdad7f8a3eda6,1,7976,6143,8257,3770,6166,6690,2835" ,
          "1719232345757948,0x6d9ec4bb5fa45736,1,9051,2982,7145,3604,9256,1061,2638" ,
          "1719232345757948,0x028cf9e0f9ed7c32,1,5623,7483,2263,2265,6890,4875,5564" ,
          "1719232345757948,0x92a984c1a491b72a,1,6732,7795,6411,8569,3370,705,5536" ,

"1719232345757948,0x8b4b404acd2f34da,1,7610,7128,10064,1880,4834,3411,6724" ,
          "1719232345757948,0x20f92ed58991d56c,1,6805,1632,5407,2038,1865,7279,8350"
        ]}}}}] }

{
  "source": "localhost:9339",
  "subscription-name": "default-1719233128",
  "timestamp": 1719233138173907825,
```

```

"time": "2024-06-24T15:45:38.173907825+03:00",
"updates": [ {
  "Path": "nvidia/ib/amber/reply/sample",
  "values": {
    "nvidia/ib/amber/reply/sample": {
      "HeaderID": "970426048",
      "Values": [
        "1719232345757948,0x20f92ed58991d56c,1,6805,1632,5407,2038,1865,7279,8350" ,
        "1719232345757948,0x1dac004a426bb5f5,1,8351,5757,7925,6181,3260,3081,1554" ,
        "1719232345757948,0x48b60e6f3670eaca,1,9477,3847,1184,5527,4783,2102,8192" ,
        "1719232345757948,0xabccdad7f8a3eda6,1,7976,6143,8257,3770,6166,6690,2835" ,
        "1719232345757948,0x6d9ec4bb5fa45736,1,9051,2982,7145,3604,9256,1061,2638" ,
        "1719232345757948,0x028cf9e0f9ed7c32,1,5623,7483,2263,2265,6890,4875,5564" ,
        "1719232345757948,0x92a984c1a491b72a,1,6732,7795,6411,8569,3370,705,5536" ,

"1719232345757948,0x8b4b404acd2f34da,1,7610,7128,10064,1880,4834,3411,6724" ,
        "1719232345757948,0x91f87bf42deb3e03,1,5091,7826,6290,8615,4247,8586,6214" ,
        "1719232345757948,0x7b8c2e08907250ce,1,2891,3293,5774,4398,3681,3548,7408"
      ]}}}}]

```

## Subscribe On-Change Request

The subscribe on-change request, similar to the standard subscribe request, provides data from the specified path. If the telemetry lacks data, the server responds with an empty result. When data is available, the server responds with the located counters. The stream delivers information at the specified interval, but only if there is new information to transmit. Otherwise, it waits for the next interval to check for updates. The path construction follows the same pattern as the get request and includes inventory and event paths.

Only updated data will be included in the response, with all other parts remaining empty but retaining the specified format. Similarly, only the nodes that have been updated will be included in the response.

### Example:

```
gnmic -a localhost:9339 --insecure sub --path
nvidia/ib/guid[guid=0x5255456]/port[port_number=2]/amber/port_counters
--stream-mode on-change --heartbeat-interval 1m
```

This request retrieves data from node\_guid 0x5255456, port 2, with the request counters set to hist0. It periodically checks for changes every minute, and when changes are detected, it promptly sends the updated values.

### Example:

```
gnmic -a localhost:9339 --insecure sub --path
nvidia/ib/guid[guid=*]/port[port_number=*]/amber/port_counters/*
--stream-mode on-change --heartbeat-interval 1m
```

This request involves all nodes and ports, aiming to retrieve all counters from the telemetry. It periodically checks for changes every minute, and when changes are detected, it promptly sends the updated values.

The below is an example of the response to a particular GUID, which represents an on-change request for a few counters. However, only specific counters have been updated, those who have not updated have a value of 0. Because the flag include\_old\_data\_on\_change default is true

```
1706532307824, 0x0002c903007e5220, 1, 0, 0, 0, 41447490564, 617155163, 41423305825, 617155163,
```

The same example with the flag set to true will give this:

```
1706532307824, 0x0002c903007e5220, 1, , , , 41447490564, 617155163, 41423305825, 617155163, 2,
```

Only the values that have changed return while the others are empty values. To get this format of data, one need to change the include\_old\_data\_on\_change in the config file to false.

## Example:

```
gnmic -a localhost:9339 --insecure sub --path
nvidia/ib/guid[guid=*]/port[port_number=*]/amber/* --stream-mode
on-change --heartbeat-interval 24h
```

The server responds for the first 2 notifications are the following (where `include_old_data_on_change` is true), one can see the last two columns have not changed but still return the data before, the second message was send due to some rows have changed, those rows

```
{
  "source": "localhost:9339",
  "subscription-name": "default-1719236764",
  "timestamp": 1719236764654659517,
  "time": "2024-06-24T16:46:04.654659517+03:00",
  "updates": [ {
    "Path": "nvidia/ib/amber/reply/onchange",
    "values": {
      "nvidia/ib/amber/reply/onchange": {
        "HeaderID": "912200528",
        "Headers":
        ["timestamp", "Node_GUID", "Port_Number", "Counter1", "Counter2", "Counter3", "Counter4", "Counter5"
        "Values": [

"1719236753818594,0x7e680fb8f81a1950,1,100531,107250,100999,107455,109258,3716,5329" ,

"1719236753818594,0x0176438fe4ee507c,1,104269,108884,104887,108502,105366,4540,6673" ,

"1719236753818594,0x2e36224302959e79,1,101228,100555,105616,102767,108899,87,9953" ,

"1719236753818594,0x8e62a55d7571a9b8,1,100684,108124,106670,102400,106689,2910,4203" ,

"1719236753818594,0x0be75a9e97016f5e,1,102227,102735,108903,103547,108705,2629,1830" ,
```

```
"1719236753818594,0x8307bfad0672adbd,1,106033,103906,106185,107450,105736,2567,6914" ,  
"1719236753818594,0x2cbe66ec0b1af84c,1,105958,106959,100349,107704,105073,8330,4962" ,  
"1719236753818594,0x6b6da39a9ec4bbfc,1,104340,106752,109134,103796,103500,7136,3493" ,  
"1719236753818594,0x6d122dbdd99cfb60,1,104941,107630,104190,105392,109582,5480,7934" ,  
"1719236753818594,0xfeed4bd9cd3b7f325,1,102416,100164,106731,102033,103807,3048,6316"
```

```
]}}}]}
```

```
{  
  "source" : "localhost:9339",  
  "subscription-name" : "default-1719236764",  
  "timestamp" : 1719237054620929561 ,  
  "time" : "2024-06-24T16:50:54.620929561+03:00",  
  "updates" : [  
    {  
      "Path" : "nvidia/ib/amber/reply/onchange",  
      "values" : {  
        "nvidia/ib/amber/reply/onchange" : {  
          "HeaderID" : "912200528",  
          "Values" : [  

```

```
"1719237054172043,0xfeed4bd9cd3b7f325,1,117416,115164,121731,117033,118807,3048,6316" ,  
"1719237054172043,0x2e36224302959e79,1,116228,115555,120616,117767,123899,87,9953" ,  
"1719237054172043,0x8e62a55d7571a9b8,1,115684,123124,121670,117400,121689,2910,4203" ,  
"1719237054172043,0x7e680fb8f81a1950,1,115531,122250,115999,122455,124258,3716,5329" ,  
"1719237054172043,0x0176438fe4ee507c,1,119269,123884,119887,123502,120366,4540,6673"
```

```
]}}}]}
```

## Inventory Requests

Inventory messages are conveyed in separate updates, presenting the inventory details of the UFM associated with the provided IP. These messages display comprehensive information, including the total count of various components within the UFM, such as switches, routers, servers, and more, along with details about active ports and the total number of ports, including disabled ones. Moreover, inventory requests include the size of the telemetry, which is not always the same as the active ports. In cases where the plugin is unable to establish contact with the UFM, it will revert to using default values defined in the configuration file. It is worth noting that the path for inventory requests differs from the conventional path structure, as they do not rely on specific nodes or ports. Consequently, inventory requests are initiated after "nvidia/ib."

### Example:

```
gnmic -a localhost:9339 --insecure get -path  
nvidia/ib/inventory/*
```

Response:

```
[ {  
  "source": "localhost:9339",  
  "timestamp": 1698824237536878067,  
  "time": "2023-11-01T09:37:17.536878067+02:00",  
  "updates": [ {  
    "Path": "nvidia/ib/inventory",  
    "values": {  
      "nvidia/ib/inventory": {  
        "ActivePorts": 4, "Cables": 2, "Gateways": 0, "HCAs": 2, "Routers":  
0, "Servers": 2, "Switches": 1, "TotalPorts": 38, "TelemetrySize": 4, "timestamp":  
1698824211535069000 }  
      }  
    }  
  ]  
}
```

```
}}]}}
```

## Events Requests

Events messages are provided in separate updates, offering insights into the events occurring within the UFM associated with the specified IP. Given that the event metadata remains consistent, even when numerous events are part of a request, the message format adopts a CSV-like structure. The Headers section contains essential metadata regarding UFM events, while the Values section contains the raw event data. Users can subscribe to these events with the on-change feature enabled, receiving only the events triggered within the subscription interval. Notably, the path structure for event requests differs from the typical node or port-based structure and is requested after "nvidia/ib."

### Example:

```
gnmic -a localhost:9339 --insecure get -path nvidia/ib/events/*
```

Response:

```
[ {
  "source": "localhost:9339",
  "timestamp": 1698824809647515575,
  "time": "2023-11-01T09:46:49.647515575+02:00",
  "updates": [ {
    "Path": "nvidia/ib/events",
    "values": {
      "nvidia/ib/events": {
        "Headers": [
          "id", "object_name", "write_to_syslog", "description", "type", "event_type", "severity", "timestamp", "counter"
        ],
        "Values": [
          "7718,Grid,false,Disk space usage in /opt/ufm/files/log is above the threshold of 90.0%,Grid,525,Critical,2023-11-01 07:25:54,N/A,Maintenance,Grid,Disk utilization threshold reached",
          "7717,Grid,false,Disk space usage in /opt/ufm/files/log is above the threshold of 90.0%,Grid,525,Critical,2023-11-01 07:24:54,N/A,Maintenance,Grid,Disk utilization threshold reached",
```

```

"7716,Grid,false,Disk space usage in /opt/ufm/files/log is above the threshold of
90.0%,Grid,525,Critical,2023-11-01 07:23:54,N/A,Maintenance,Grid,Disk utilization threshold reached" ,
...
"7491,ec0d9a0300d42e54,false,Mcast group is deleted: ff12601bffff0000,
00000002,Computer,67,Info,2023-10-31 06:39:21,N/A,Fabric Notification,default / Computer: r-
ufm59,Mcast Group Deleted" ]
}}}]

```

## Switch Rank Requests

Switch rank updates are conveyed in separate messages, presenting the rank of the switches in the UFM. This data is derived from a file in the UFM and is updated by the server every 6 hours by default. The `switch_rank` counter is associated only with switch-level data, so there is no need to specify a port in the path. However, this counter is not connected to the telemetry cache of switch-level data. **Note that if the `ufm_ip` is changed, the `switch_rank` information will not be available.**

Example:

```

gnmic -a localhost:9339 --insecure get --path
nvidia/ib/guid[guid=*]/amber/switch_rank

```

Respond for example:

```

{
  "source": "localhost:9339",
  "timestamp": 1719296207323383222,
  "time": "2024-06-25T09:16:47.323383222+03:00",
  "updates": [
    {
      "Path": "nvidia/ib/guid[guid=*]/amber/amber/switch_rank",
      "values": {
        "nvidia/ib/guid/amber/amber/switch_rank": {
          "Headers": "Timestamp,Node_GUID,switch_rank",

```

```
"Values" : [  
    "1719296205612,0x0002c903007e5220,0"  
  ]}}}}}
```

# UFM Telemetry Manager (UTM) Plugin

## Overview

Managed telemetry is a mode of high availability and improved performance of UFM Telemetry processes.

Governed by UFM Telemetry Manager (UTM) several UFM Telemetry Instances (TIs) run on one or more machines, each collecting a subset of the cluster fabric.

UTM manages the following aspects:

- monitoring of TI states: down, initializing, running, paused
- TI management commands: add, remove, pause, start, restart
- partitioning of fabric based on TIs health and fabric changes
- assigning fabric segments to TIs
- telemetry coverage check of a cluster


The UFM Telemetry Manager (UTM) Plugin facilitates managed telemetry in high availability mode, enhancing the performance of UFM Telemetry operations.

Under the governance of UFM Telemetry Manager (UTM), multiple UFM Telemetry Instances (TIs) are executed on one or more machines, with each TI responsible for collecting a specific portion of the cluster fabric.

Key functionalities managed by UTM include:

- Monitoring TI statuses: down, initializing, running, paused
- Execution of TI management commands: add, remove, pause, start, restart
- Fabric partitioning based on TI health and fabric changes

- Assigning fabric segments to TIs
- Verification of telemetry coverage across the cluster



## Deployment

As a first step, get the UTM image:

```
docker pull mellanox/ufm-plugin-utm
```

The UTM plugin is designed to operate either as a UFM plugin or in standalone mode.

In both setups, it is advisable to utilize UTM deployment scripts. These scripts streamline the process by enabling the deployment or cleanup of the entire setup with just a single command. This includes UTM, host TIs, and preparation of the Switch Telemetry image.

## UTM Deployment Scripts

Get deployment scripts and examples by mounting the local folder `UTM_DEPLOYMENT_SCRIPTS` (`/tmp/utm_deployment_scripts` in this example) and running `get_deployment_scripts.sh` :

```
$ export UTM_DEPLOYMENT_SCRIPTS=/tmp/utm_deployment_scripts
$ docker run -v "$UTM_DEPLOYMENT_SCRIPTS:/deployment_scripts" --rm --name utm-
deployment-scripts -ti mellanox/ufm-plugin-utm:latest /bin/sh
/get_deployment_scripts.sh
```

The content of the script folder consists of:

- Examples - Contains run/stop scripts for both standalone and UFM plugin modes. Each example script is an example of actual deployment script usage.
- hostlist.txt - Specifies the hosts, ports, and HCAs for TIs to be deployed
- Scripts - Contains actual deployment scripts. Entry-point script `deploy_managed_telemetry.sh` triggers the rest two scripts, depending on input arguments.

```
$ cd $UTM_DEPLOYMENT_SCRIPTS
$ tree
.
  examples
    run_standalone.sh
    run_with_plugin.sh
    stop_standalone.sh
    stop_with_plugin.sh
  hostlist.txt
  README.md
  scripts
    deploy_bringup.sh
    deploy_managed_telemetry.sh
    deploy_ufm_telemetry.sh
```

 **Note**

All example/deployment scripts should run from the UTM\_DEPLOYMENT\_SCRIPTS folder.

## Hostlist File

Please note the following:

- The `hostlist.txt` file should be set before running any script.
- The hostname and port will be used for communication and HCA for telemetry collection.
- UTM only supports a single fabric for managed TIs, even if different HCAs on the same machine are connected to different fabrics.
- Both local and remote hosts are supported for TI deployments.

```
$ cat hostlist.txt

# List lines in the following format:
# host:port:hca
#
# where:
# - host is IP or hostname. Use localhost or 127.0.0.1 for local deployment
# - port to run telemetry on.
# - hca is the target host device from which telemetry collects. Run `ssh $host ibstat`
#   to find the active device on the target host.

localhost:8123:mlx5_0
localhost:8124:mlx5_0
```

## Main Deployment Script

For a more customizable setup beyond what the example scripts offer, users have the option to manually run `./scripts/deploy_managed_telemetry.sh`. This primary deployment script can deploy multiple TIs and optionally UTM as well.

Use `deploy_managed_telemetry.sh --help` to get help.

```
./deploy_managed_telemetry.sh --help
./deploy_managed_telemetry.sh options:      mandatory:

mandatory:
    --hostlist-file=      Path to a file that lists
hostname:port:hca lines
mandatory run options (use only one at the same time):
    -r, --run            Deploy and run managed telemetry
setup
    -s, --stop          Stop all processes and cleanup
mandatory telemetry deployment options (use only one at the
same time):
    -t=, --ufmt-image=  UFM telemetry docker image or
tgz/tar.gz-image
or:
    --bringup-package=  Bringup tar.gz package
optional:
    -m=, --utm-image=   UTM docker image or tgz/tar.gz-
image. Runs UTM only if it is set. Configures UTM according
hostlist file
    --utm-as-plugin=    if UTM runs as a plugin, set this
flag
    -d=, --data-root=   Root directory for run data |
Default: '/tmp/managed_telemetry/'
    --switch-telem-image= Switch telemetry image (tar.gz-file
or docker image). UTM will be able to deploy it to managed
switches if set
    --common-data-dir=  Common data folder for TIs
-h, --help            Print this message
```

## UFM Plugin Mode

1. Upload the UTM Docker image to the Docker registry on the machine running UFM Enterprise.
2. Navigate to the UFM web UI and click on Settings in the left panel.
3. Go to the "Plugin Management" tab.
4. Right-click on the UTM plugin row and select "Add."

The screenshot shows the UFM Settings interface. At the top, there's a 'Settings' header with a green envelope icon. Below it, several tabs are visible: 'Events Policy', 'Device Access', 'Network Management', 'Subnet Manager', 'Non-Optim', 'Topology Compare', 'Access Tokens', and 'Plugin Management'. The 'Plugin Management' tab is highlighted with a red box. Below the tabs, the 'Plugin Management' section is titled. It shows 'Showing 1 out of 3, Click to reset all filters'. Below this is a table with columns: 'Name', 'Enabled', and 'Tags'. The first row has 'utm' in the 'Name' column, a 'Filter' button, 'LATEST' in the 'Tags' column, and 'NA' in the 'Enabled' column. A context menu is open over the 'utm' row, with options: 'Copy Cell', 'Add', and 'Remove Image'. The 'Add' option is highlighted with a red box.

5. Go to the option on the left called "Telemetry Status" to see the UTM UI page.
6. Prepare TI setup using `utm_deployment_scripts` example scripts:
  1. Change directory:

```
cd $UTM_DEPLOYMENT_SCRIPTS
```

2. Open and configure `hostlist.txt`
3. Deploy and run TIs according to `hostlist.txt` and set these TIs to be monitored by UTM:

```
sudo ./examples/run_with_plugin.sh
```

4. To stop and cleanup TIs setup and unset TIs to be monitored by UTM:

```
sudo ./examples/stop_with_plugin.sh
```

**i Note**

This script does not stop UTM plugin!

To stop the UTM plugin, go to "Plugin Management", right-click on the UTM plugin line and click on disable.

**i Note**

If non-default UFM credentials are used, UTM may fail to access the UFM REST API. To resolve this, configure the `ufm` section of the `utm_config.ini` file with `ufm_user=` and `ufm_pass=` to restore the connection between UTM and UFM.

## Default UFM Telemetry Monitoring

UFM Telemetry has high and low-frequency (Primary and Secondary, respectively) TIs that are running by default.

To enable meaningful monitoring:

1. Set `plugin_env_CLX_EXPORT_API_SHOW_STATISTICS=1` in the config files:

```
/opt/ufm/files/conf/telemetry_defaults/launch_ibdiagnet_config  
/opt/ufm/files/conf/secondary_telemetry_defaults/launch_ibdiag
```

2. Restart telemetry instances with the new config. If UFM Enterprise runs as a docker container, this command should be executed inside the container.

```
/etc/init.d/ufmd ufm_telemetry_restart
```

3. Give TIs some time to update performance metrics. The time depends on the update interval of default TIs.

## Standalone Mode

In standalone mode, UTM periodically tracks fabric changes by itself and does not require UFM Enterprise.

Deploy via example scripts:

1. Change directory

```
cd $UTM_DEPLOYMENT_SCRIPTS
```

2. Open and configure `hostlist.txt`

3. Deploy and run TIs according to `hostlist.txt` and run UTM:

```
sudo ./examples/run_standalone.sh
```

4. To stop and cleanup TIs setup and UTM, run:

```
sudo ./examples/stop_standalone.sh
```

## Manual Deployment

This section provides detailed instructions for manually deploying UTM and managed TIs to ensure coverage of all potential corner cases where the convenience script may not be effective.

### UTM Deployment

UTM can be started with two docker run commands.

1. Set `utm_config`, `utm_data`, `utm_log`, and `utm_image` variables.
2. Initialize UTM config:

```
docker run -v $utm_config:/config \  
           -v $utm_data:/data \  
           --rm --name utm-init \  
           --device=/dev/infiniband/ \  
           $utm_image /init.sh
```

3. Run UTM

```
docker run -d --net=host \  
           \
```

```
        --security-opt seccomp=unconfined --cap-  
add=SYS_ADMIN \  
        --device=/dev/infiniband/ \  
-v $utm_config:/config \  
-v $utm_data:/data \  
-v $utm_log:/log \  
--rm --name utm $utm_image
```

## Managed/Standalone TIs Manual deployment

TI can be represented either as a UFM Telemetry docker container or as a UFM Telemetry Bring-up package.

To run the docker container in managed mode, `launch_ibdiagnet_config.ini` should have the following flags enabled:

```
plugin_env_CLX_EXPORT_API_SHOW_STATISTICS=1  
plugin_env_UFM_TELEMETRY_MANAGED_MODE=1
```

To run UFM Telemetry with Distributed Telemetry, enable its receiver and specify HCA to work on:

```
plugin_env_CLX_EXPORT_API_RUN_DT_RECEIVER=1  
plugin_env_CLX_EXPORT_API_DT_RECEIVER_HCA=$HCA
```

To run bringup in managed mode, create `enable_managed.ini` file with the same flags and use `custom_config` option of `collection_start`:

```
collection_start custom_config=./enable_managed.ini
```

## UTM Configuration File

The UTM configuration file `utm_config.ini` is placed under the configuration folder (which is referred to as `UTM_CONFIG` later on this document).

In the case of UFM plugin mode, `UTM_CONFIG= /opt/ufm/files/conf/plugins/utm/`.

In the case of standalone mode, the default value is `UTM_CONFIG =/tmp/managed_telemetry/utm/config` and can be changed via `--data-root` argument of deployment script.

When changes are made to the configuration file, UTM initiates a restart of its main process to apply the updated configuration.

Users may wish to adjust timeout and update rate configurations based on their specific setups. However, it is important to note that the remaining configurations are tailored to enable UTM to function as a UFM plugin and should not be modified.

## Distributed Telemetry

To enable distributed telemetry set `dt_enable=1` in the corresponding section.

### Note

Distributed Telemetry requires Switch Telemetry docker image tagged as `switch-telemetry:{version}` and placed under `$UTM_CONFIG/telem_files/` as `switch-telemetry_{version}.tar.gz`

UTM scans this file at its start.

Example deployment scripts handle it for both UFM plugin and standalone modes.

For more details refer to [NVIDIA UFM Telemetry Documentation](#) → Distributed Telemetry - Switch Telemetry Agent

# GUI

To access the GUI within the UFM web UI, navigate to the Telemetry status section in the left panel.

The UI is accessible whether it is running as a part of UFM Enterprise or standalone via the endpoint: `http://127.0.0.1:8888/files/index.html`.

The GUI comprises several zones:

- The top pane displays general information and provides options to add a server name/IP and port for monitoring. Users can set the GUI refresh interval in the top right corner.
- The middle panes showcase TI groups, with the default group being basic. Unmanaged (standalone) TIs can be monitored and are placed in the "Unmanaged" group.
- Each group pane presents monitoring information for each TI.
- The bottom pane exhibits system events. Utilize the bottom right menu to navigate through the events history.

**Telemetry Status**

UFM Telemetry Manager Up Time: 2 mins, 4 secs  
Fabric Source: `http://127.0.0.1:8000` Refresh interval: 1 second

[Add Server](#)

---

**Group name: unmanaged**

URL ↑	Mode	DT receiver	Status	Uptime	Collected host/switch ports	Configured host/switch ports	Enabled/Discovered ports	Iteration time (sec)	Export time (sec)	Port counters time (sec)	Ports/sec
<code>http://127.0.0.1:9001</code>	standalone/host	0	Running	2 hours, 28 mins, 21 secs	0+35/-		30/173	0.000723	1e-05	0.000391	
<code>http://127.0.0.1:9002</code>	standalone/host	0	Running	2 days, 21 hours, 11 mins, 45 secs	173/-		30/173	0.38699	0.001255	0.037979	4555.15

---

**Group name: default**  
Number of Discovered Ports: 30  
Status Message: Sampled 29/30 ports. Cluster is sampled at max rate of 280.5 Hz.

URL ↑	Mode	DT receiver	Status	Uptime	Collected host/switch ports	Configured host/switch ports	Enabled/Discovered ports	Iteration time (sec)	Export time (sec)	Port counters time (sec)	Ports/sec
<code>http://localhost:8123</code>	managed/host	1	Running	50 secs	9/-	9/-	30/173	0.003565	8.2e-05	0.002276	3954.31
<code>http://localhost:8124</code>	managed/host	1	Running	50 secs	20/-	20/-	30/173	0.005695	9.7e-05	0.004665	4287.25

---

**Events**

Severity	Time	Source	Group	Description
info	2024-05-05 11:33:18.655627	<code>http://localhost:8124</code>	default	Updated Telemetry Instance with 20 ports
info	2024-05-05 11:33:18.652747	<code>http://localhost:8123</code>	default	Updated Telemetry Instance with 9 ports
info	2024-05-05 11:33:18.257047	<code>http://localhost:8124</code>	default	Host TI config updated. New config_hash=1dc7e0a8aedf520c0940219c45200549c30b6dbd690856b12a9e5aa8fed0788
info	2024-05-05 11:33:18.256252	<code>http://localhost:8124</code>	default	Host TI qp updated. New qp_info={qp_id: 7, qp_port: 1, qp_num: 5776-5777, total_qps: 2, timestamp: 1714908793139835}
info	2024-05-05 11:33:18.249813	<code>http://localhost:8123</code>	default	Host TI config updated. New config_hash=8723213085d6a4e1b913b798471eb1e6ae5863bb69e905b8fda33f0fb147e952

Viewing 1-5 of 85 ⏪ ⏩ ⏴ ⏵

# TI Management

In managed mode, UTM can dispatch commands to TIs. By right-clicking on the TI line, users can:

- Pause a currently running TI. This action redistributes fabric sharding among the active TIs.
- Resume a paused TI.
- Exclude a TI from monitoring. Although the TI remains on the machine, it enters a paused state and is removed from its group. It's important to note that empty TI groups are automatically removed.

## Telemetry Status Fields

The table below lists each column of a Telemetry Group panel:

Field Name	Description
URL	TI URL in format <code>http://{hostname}:{port}</code> or <code>http://{IP}:{port}</code>
Mode	standalone or managed / platform
DT receiver	With or without a Distributed Telemetry receiver. If 0, cannot receive DT data from a switch TI
Status	Down, Running, Initializing, Paused, or Restarting
Uptime	TI uptime in human-readable format
Collected host/switch ports	Ports collected from the host/switch. By default data that did not change from the last sample is not being re-exported. Such data is shown in the host part as <code>+num_old_ports</code> . In the screenshot above, first TI of the "unmanaged" group sampled 0 new data samples and found 35 old ones. Nothing is being sampled from Distributed Telemetry, because this TI runs without DT receiver. The resulting format is: <code>0+35/-</code>
Configured host/switch ports	Ports configured to be sampled from a host and corresponding switches in total. For more details refer to <a href="#">Distributed Telemetry documentation</a> .

Field Name	Description
Enabled/discovered ports	Enabled and discovered ports of the Fabric.
Iteration time	Total iteration time of UFM Telemetry data collection
Export time	Export time in the last iteration of UFM Telemetry data collection. Included to Iteration time
Port counters time	Time spent only on port counters telemetry collection. Included to Iteration time
Ports/sec	Speed of new port counters data collection during the last iteration of UFM Telemetry.

## REST API

All the GUI features including TI management and monitoring can be accessed via REST API.

## Accessing UTM API Commands Based on Operating Mode

The method to access UTM API commands varies depending on the mode:

- **In UFM Plugin Mode:** Use the UFM REST API proxy:

```
curl -s -k https://{UFM_HOST_IP}/ufmRest/plugin/utm/{COMMAND} -u {user}:{pass}
```

- **In Standalone Mode:** Access the UTM HTTPS endpoint on the default port 8888:

```
curl -s -k https://{UTM_HOST_API}:8888/{COMMAND}
```

## Command List

For simplicity, the following commands are provided for standalone mode.

- Get the list of supported user endpoints:

```
curl -s -k https://127.0.0.1:8888/help
```

- Get the status of the monitored TIs in JSON format:

```
curl -k https://127.0.0.1:8888/status
```

- Add TI <http://127.0.0.1:8123> to the my\_group monitoring group:

```
curl -k 'https://127.0.0.1:8888/add_server?url=http://127.0.0.1:8123&group=my_group'
```

- Add TI <http://127.0.0.1:8123> to default monitoring group:

```
curl -k https://127.0.0.1:8888/add_server?  
url=http://127.0.0.1:8123
```

- Remove TI from monitoring (running TI will be paused):

```
curl -k https://127.0.0.1:8888/remove_server?  
url=http://127.0.0.1:8123
```

- Pause running TI:

```
curl -k https://127.0.0.1:8888/pause_server?  
url=http://127.0.0.1:8123
```

- Resume paused TI:

```
curl -k https://127.0.0.1:8888/start_server?  
url=http://127.0.0.1:8123
```

## Overview


The UFM consumer plugin is a self-contained Docker container with REST API support, under UFM management. It serves as a Multi-Subnet consumer within UFM, offering all the functionalities available for Multi-Subnet UFM.

The Multi-Subnet UFM feature allows the management of large fabrics spanning multiple sites within a single product, specifically Multi-Subnet UFM.


This feature comprises two layers: UFM Multi-Subnet Provider and UFM Multi-Subnet Consumer (UFM consumer plugin).

The UFM Provider acts as a Multi-Subnet Provider, exposing all local InfiniBand fabric information to the UFM consumer plugin. On the other hand, the UFM consumer plugin functions as a Multi-Subnet Consumer, gathering and consolidating data from configured UFM Providers. This enables users to manage multiple sites conveniently in one location. While the UFM Consumer offers similar functionality to regular UFM, there are behavioral differences concerning aggregation.

Upon deployment of the UFM consumer plugin, an additional tab is incorporated into the UFM interface.



After clicking on UFM consumer plugin UI, a new browser tab with UFM Multi-Subnet consumer functionality options is presented. Upon the initial launch of the UFM consumer plugin UI and in case there are no configured providers, a screen for adding providers (Provider Management) will be displayed.



The functionality of the UFM consumer plugin is similar to that of Multi-Subnet UFM. For further details, refer to [Multi-Subnet UFM](#).

## Fast-API Plugin

### Overview

The Fast-API plugin is a new component that runs in parallel to the UFM model and provides a more scalable and efficient way to manage the inventory and topology of the fabric. It uses a Redis database to store the data it receives from the SM client consumer and the ibdiagnet collector. It also exposes REST APIs for querying the ports, systems, links, switches, and sharp reservations. The Fast-API plugin also supports persistent inventory, which means it keeps track of all the devices, ports, and links the UFM ever encountered, even if they are disabled or removed. The Fast-API plugin is designed to be backward compatible with the UFM model, except for some minor differences in the API parameters and the handling of generic node names.

## Deployment

- As a first step, get the Fast API image:

```
docker pull mellanox/ufm-plugin-fast_api
```


- Load the downloaded image onto the UFM server. This can be done either by using the UFM GUI by navigating to the Settings -> Plugins Management tab or by loading the image via the following instructions:

1. Log in to the UFM server terminal.
2. Run:


```
docker load -I <path_to_image>
```

- After successfully loading the plugin image, the plugin should become visible in the plugin management table within the UFM GUI. To initiate the plugin's execution, simply right-click on the respective in the table.

## SequencDiagrm



## Sequence Diagram



## Supported APIs

The following APIs are supported:

Ports API - Retrieve all the ports in the cluster or filter by the system name. The following attributes are retrieved:

- GET [https://<UFM\\_IP>/ufmRestV2/plugin/fast\\_api/resources/ports](https://<UFM_IP>/ufmRestV2/plugin/fast_api/resources/ports)
- GET /resources/ports/ - deviceId referred as sys\_guid for switches and hostname for hosts
  - name: The name of the port.
  - lid: The local ID of the port.

- `logical_state`: The logical state of the port.
- `physical_state`: The physical state of the port.
- `number`: The number of the port.
- `decimal_guid`: The decimal GUID of the port.
- `mtu`: The maximum transmission unit of the port.
- `active_speed`: The active speed of the port.
- `active_width`: The active width of the port.
- `peer_address`: The peer address of the port.
- `peer_port`: The peer port of the port.
- `tier`: The tier of the port.
- `label`: The label of the port.

This API retrieves all the ports in the cluster, including cable information. The following attributes are supported for cable information:

- GET [https://<UFM\\_IP>/ufmRestV2/plugin/fast\\_api/resources/ports/?cable\\_info=true](https://<UFM_IP>/ufmRestV2/plugin/fast_api/resources/ports/?cable_info=true)
  - `part_number`: The part number of the cable.
  - `serial_number`: The serial number of the cable.
  - `revision`: The revision of the cable.
  - `identifier`: The identifier of the cable.
  - `length`: The length of the cable.
  - `technology`: The technology of the cable.
  - `fw_version`: The firmware version of the cable.

Links API - Retrieve all the links in the cluster. The following attributes are retrieved:

- GET [https://<UFM\\_IP>/ufmRestV2/plugin/fast\\_api/resources/links](https://<UFM_IP>/ufmRestV2/plugin/fast_api/resources/links)

- source\_guid: The GUID of the source port.
- source\_port: The source port.
- destination\_guid: The GUID of the destination port.
- destination\_port: The destination port.
- source\_port\_dname: The display name of the source port.
- source\_port\_name: The name of the source port.
- destination\_port\_dname: The display name of the destination port.
- destination\_port\_name: The name of the destination port.
- width: The width of the link.
- severity: The severity of the link.
- source\_port\_node\_description: The description of the node connected to the source port.
- destination\_port\_node\_description: The description of the node connected to the destination port.
- name: The name of the link.
- active: The status of the link.

This API retrieves information about the systems in the cluster. It can retrieve all the systems or filter by the system name. The following attributes are retrieved:

- GET [https://<UFM\\_IP>/ufmRestV2/plugin/fast\\_api/resources/systems](https://<UFM_IP>/ufmRestV2/plugin/fast_api/resources/systems)
- GET [https://<UFM\\_IP>/ufmRestV2/plugin/fast\\_api/resources/systems/<system\\_name>](https://<UFM_IP>/ufmRestV2/plugin/fast_api/resources/systems/<system_name>)
- GET [https://<UFM\\_IP>/ufmRestV2/plugin/fast\\_api/resources/switches](https://<UFM_IP>/ufmRestV2/plugin/fast_api/resources/switches)
  - name: The display name of the system.
  - system\_name: The name of the system.
  - guid: The GUID of the system.

- `sys_guid`: The system GUID.
- `ports`: A list of ports associated with the system.
- `hostname`: The hostname of the system.
- `vendor`: The vendor of the system.
- `temperature`: The temperature of the system.
- `fw_version`: The firmware version of the system.
- `technology`: The technology used by the system.
- `level`: The level of the system.
- `uptime`: The uptime of the system.
- `sw_version`: The software version of the system.
- `system_type`: The type of the system.
- `description`: The description of the system.
- `psid`: The PSID of the system.
- `active`: The status of the system.
- `state`: The state of the system.
- `is_managed`: Indicates whether the system is managed.

# UFM Light Plugin

## Overview

UFM Light is a C++ UFM plugin designed to create a reduced UFM model and deliver a high-performance REST API. While it builds a model similar to the legacy UFM, there are notable differences:

- The model in UFM Light is streamlined to meet the specific requirements of the UFM Light REST API functionality.

- UFM Light builds its model more quickly.

UFM Light offers the same REST API as the legacy UFM, but with enhanced performance.

## Deployment

### Prerequisites

1. UFM is running
2. Fast-API plugin is running

UFM Light builds its model from the Redis inventory and requires the Fast-API plugin as the inventory provider. Writing to Redis must be enabled in UFM.

### Installation

1. Get UFM Light image:

```
docker pull mellanox/ufm-plugin-ufm-light
```

2. Load UFM Light plugin:

```
sudo /opt/ufm/scripts/manage_ufm_plugins.sh add -p ufm-light  
-t <version>
```

3. Configure the UFM Light plugin if needed (see "Configuration" section).

**Note:** it is recommended to configure parameter `--http.threads` to "4" for 16-Core systems, "16" for 64-Core systems.

## Configuration

UFM Light runs with its default configuration. To update the configuration, edit:

```
sudo vim /opt/ufm/files/conf/plugins/ufm-light/ufm-light.cfg
```

If `ufm-light.cfg` is updated, the UFM Light plugin must be stopped and started again manually to apply the changes:

```
sudo /opt/ufm/scripts/manage_ufm_plugins.sh stop -p ufm-light
```

```
sudo /opt/ufm/scripts/manage_ufm_plugins.sh start -p ufm-light
```

## Configuration Options:

```
--model.srcmode arg (=redis:invnt)    base source of model:  
redis:invnt, redis:full, grpc  
--model.period arg (=30)              set farbric request  
period in seconds  
--redis.address arg (=localhost)      set Redis address  
--redis.port arg (=6379)              set Redis port  
--grpc.address arg (=localhost)       set gRPC address  
--grpc.port arg (=2510)               set gRPC port  
--telemetry.address arg (=localhost)  set Telemetry address  
--telemetry.port arg (=9001)          set Telemetry port  
--telemetry.url arg (=csv/cset/converted_enterprise) set  
Telemetry url  
--http.address arg (=127.0.0.1)       set http address  
--http.port arg (=8950)               set http port  
--http.threads arg (=1)               set number of http server  
threads, min 1  
--logging.level arg (=INFO)           set logging level:  
CRITICAL, ERROR, WARNING, INFO, DEBUG, TRACE
```

```
--logging.log_dir arg (= /log)          set logging directory
--logging.file.max_size_MB arg (=10)    set MAX log file size
limit in MBs, min 1
--logging.file.backups arg (=10)        set number of log file
backups
```

For normal operation, keep the parameter `model.srcmode = redis:invnt` at its default value. Other values (`redis:full`, `grpc`) can be set, but the model will not be fully built. This feature is not part of the current release. Parameters `grpc.address` and `grpc.port` will have no effect.

**Note:** it is recommended to configure parameter `--http.threads` to “4” for 16-Core systems, “16” for 64-Core systems.

## Supported REST API

Telemetry API:

- GET `monitoring/session/0/data`

### Access methods:

- 

- **Direct access:**

```
curl http://127.0.0.1:8950/monitoring/session/0/data
```

- **Over plugins API:**

```
curl -k https://<lab_ip>/ufmRest/plugin/ufm-light/monitoring/session/0/data -u
<user>:<password>
```

## Troubleshooting

If the response to `GET monitoring/session/0/data` contains an empty dictionary, ensure that the Fast-API plugin is running.

UFM Light logs are located in:

```
/opt/ufm/files/log/plugins/ufm-light/
```

The default log level is `INFO`. To change the log level to `DEBUG`, edit:

```
sudo vim /opt/ufm/files/conf/plugins/ufm-light/ufm-light.cfg

logging.level = DEBUG
```

After config update, `ufm-light` plugin must be stopped and started again manually in order to obtain config changes.

## Key Performance Indexes (KPI) Plugin

The KPI plugin periodically collects telemetry metrics and topology data from one or multiple UFM Telemetry and UFM clusters to calculate high-level Key Performance Indicators (KPIs). It can operate as a standalone Docker container or as a UFM plugin.

The calculated KPIs and collected telemetry metrics are stored in a Prometheus time-series database using the remote-write Prometheus protocol.

### KPIs

#### NICs Connectivity

- **Name:** `connected_endpoints`
- **Description:** This KPI shows the percentage of NICs connectivity, namely, from all NICs available, how many are connected. The desired value is 100%, meaning all NICs are connected.

The default threshold for "bad" values is  $\leq 95\%$ .

### **Note**

The complete list of NICs includes all those detected at least once since the plugin is started.

## Topology Correctness

- **Name:** topology\_correctness
- **Description:** This KPI reports the number of wrongly connected links. The ability to spread traffic over multiple minimal-distance paths is critical in utilizing the bandwidth provided by the network.

Therefore, a pass/fail criteria for the topology not being broken by miss-connections is key for the network to provide reasonable bandwidth to running applications. The threshold for failure is  $> 0$ .

## Link Stability

- **Name:** stability
- **Description:** For each UID (Unique Identifier), the KPI checks for changes in the link down counter. A change may indicate a link recovery, suggesting there was a period with no link. The statistics are tracked per UID, and the ideal value for link down errors is 0, indicating no problematic links.

## Overheated Components

- **Name:** operating\_conditions
- **Description:** This KPI displays the total number of elements (ports and devices) experiencing operating condition violations. Each hardware element has a predefined normal operating temperature range, with a common default threshold set at 70°C (158°F) or higher.

## Bandwidth Loss due to Congestion


- **Name:** `bw_loss_by_congestion`
- **Description:** An Infiniband (IB) network is lossless and can therefore experience loss congestion spread. Features like congestion control aim to minimize this issue. This KPI reports the percentage of bandwidth loss due to congestion for each layer and direction, as measured by the `port-xmit-wait` counter.

The reported percentage is calculated by averaging the `xmit-wait` equivalent time with the time between samples across all links in the specified layer-direction group.


## Fat Tree (Single Root) to Tree Conversion

- **Name:** `tree_over_subscription`
- **Description:** Fat Trees were constructed by Leiserson in order to enable building a tree structure using fixed radix  $K$  and capacity switches  $T$ . Consider a regular  $K-1$  tree (each switch has one parent and  $K-1$  children), which have a single root switch service and after  $H-1$  levels  $(K-1)^{(H-1)}$  leaf switches connecting  $(K-1)^H$  hosts each with bandwidth  $B$ . Consider the worst case traffic pattern where each leaf switch send traffic to other leaf switches that must cross the top. The connection from each leaf switch up should carry  $B(K-1)$  traffic and the capacity of that switch is bi-directional  $B(K-1)$  too. One level up the capacity and up link capacity required is  $B(K-1)^2$ , etc. But that requires exponentially growing capacity from links and switches.

For example, the below diagram is of a three level fat tree:



The Single Root Tree:



The solution to that problem was to split each single switch in the original Single Root Tree (SRT) into Multi Rooted Tree - which is a Fat Tree. In each level there are exactly same number of switches connected up and down except for the top level which carry half the number of switches - connecting only down.

The Fat Tree formulations define which switches connect to which other switches but it does not break the basic concept that a Fat Tree can be collapsed back into a simple tree by merging switches into much larger ones. A pair of leaf switches can still be classified by their distance - or the level of their common parents - just like in the original SRT.

When we want to evaluate the damage to the perfect tree structure due to link faults, it is very hard to get an exact maximum flow bandwidth without lengthy  $N^2$  complex algorithm. However, if we examine the SRT obtained by collapsing the Fat Tree back into a tree, we can get an upper bound to the available bandwidth between different branches of the SRT.

This metric evaluates Fat Tree clusters topology and extracts their original Tree structure. Then it evaluates the over-subscription of each sub-tree. This way, the impact of the exact set of missing links can be evaluated in terms of the bandwidth taken out between sub-trees of the topology.

## Top-of-rack (ToR) to ToR Max Flow (Bandwidth) Matrix

- **Name:** `tor_to_tor_bw`
- **Description:** This KPI provides a simple metric for the impact of link failures. One such network property is the available bandwidth for pairs of ToRs. This provides a meaningful yet traffic independent metric. So no prior knowledge of the exact set of instantaneous traffic patterns is required.

It is most important to look at the TOR up-ports since on Fat Trees the number of possible paths grows exponentially when going up the topology towards the roots. So the impact of link faults is decaying exponentially with their level towards the roots.

It would have been nice if we could just count the number of missing up links on each of the TORs in the pair and claim that TOR X lost  $x$  uplinks and TOR Y lost  $y$  uplinks, the lost bandwidth is  $\text{linkBW} * \min(x,y)$ . But in reality the worst case lost bandwidth is  $\text{linkBW} * (x+y)$ . This is an artifact of the specific links lost and the network structure.


The code we provide performs a Fat Tree specific computation of the exact available bandwidth for each TOR's pair.

The algorithm provides unique identifiers for sub-trees and consider the subtree each link of the TORs connect to. Then it sums the min number of links connected from each of the TORs to each of the subtrees.


A more straight forward approach utilizing networkx or direct implementation of Dinic's max-flow algorithm yielded much higher runtime, yielding this metric impractical to use.

### **We use an example to demonstrate these concepts:**

Consider the Fat Tree GFT(3;4,4,4;1,4,4) depicted in the diagram below:



We re-arrange the top row of switches (cores) such that the full-bipartites between switch levels 2 and 3 are close together:



The re-ordered picture highlights that if we imagine the red links as missing links, then:

1. TORs 200 and 210 missing links are connected to the same bipartite and thus they only lose 1 out of the 4 paths between them.
2. However, TORs 200 and 220, missing links connect to 2 different L2-L3 bipartites and thus 2 different paths out of the 4 possible are lost.

The resulting TOR to TOR max-flow matrix, providing the maximal bandwidth between each pair, in units of single link bandwidth is provided below:

	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
	00	01	02	03	10	11	12	13	20	21	22	23	30	31	32	33		
100		3	3	3	3	3	3	3	2	3	3	3	3	3	3	3	3	
101	3		4	4	3	4	4	4	3	4	4	4	4	4	4	4	4	
102	3	4		4	3	4	4	4	3	4	4	4	4	4	4	4	4	
103	3	4	4		3	4	4	4	3	4	4	4	4	4	4	4	4	
110	3	3	3	3		3	3	3	2	3	3	3	3	3	3	3	3	
111	3	4	4	4	3		4	4	3	4	4	4	4	4	4	4	4	
112	3	4	4	4	3	4		4	3	4	4	4	4	4	4	4	4	
113	3	4	4	4	3	4	4		3	4	4	4	4	4	4	4	4	
120	2	3	3	3	2	3	3	3		3	3	3	3	3	3	3	3	
121	3	4	4	4	3	4	4	4	3		4	4	4	4	4	4	4	
122	3	4	4	4	3	4	4	4	3	4		4	4	4	4	4	4	
123	3	4	4	4	3	4	4	4	3	4	4		4	4	4	4	4	
130	3	4	4	4	3	4	4	4	3	4	4	4		4	4	4	4	
131	3	4	4	4	3	4	4	4	3	4	4	4	4		4	4	4	
132	3	4	4	4	3	4	4	4	3	4	4	4	4	4		4	4	
133	3	4	4	4	3	4	4	4	3	4	4	4	4	4	4		4	

## The Algorithm

The following steps are conducted in order to provide that table:

1. DFS from top to bottom collecting the list of parents for each switch. We require all TORs be accessed so we try all top level switches until we find one that is connected to all TORs. After we are done we can ask for every TORs pair what is the level of the lowest common parent. This is required since routing will only use shortest paths, and thus go up to that level only.
2. Establish for each TOR and up the unique bottom-up subtree it is part of. The same sub-tree number should be used for all parents of each switch that are on the same level. Since the topology may be missing some links, it is not simple to check if there was previous allocation of such number, so first all parents are scanned, and then a consolidation step decides which levels are missing a number. If any needs to be set then another step applies the consolidated value.
3. For TOR switch, we sum the total number of links that connect to switches with same bottom-up tree (recognized by their assigned number). We do that for every parent level.
4. Now that we have that data for every TOR, we compute the TOR to TOR max-flow by first looking up the level of their common parent and then computing the the minimal number of flows they connect to each bottom-up tree they connect to.

## Deployment

The plugin could be deployed as a standalone application or as a UFM plugin.

## Deploy the KPI as a UFM plugin

1. Pull/load the latest image of the plugin:

```
docker pull mellanox/ufm-plugin-kpi
```

2. Pull/load the latest image of the plugin:

```
/opt/ufm/scripts/manage_ufm_plugins.sh add -p kpi -t <TAG>
```

## Deploy the KPI as a Standalone application

1. Pull/load the latest image of the plugin:

```
docker pull mellanox/ufm-plugin-kpi
```

2. Pull/load the latest image of the plugin:

```
docker run --network host -v  
/opt/ufm/files/conf/plugins/kpi:/config -v  
/opt/ufm/files/logs/plugins/kpi:/logs --rm -dit $IMAGE
```

## Configurations

The configurations can be managed through a configuration file.

- **Within the container**, the configurations file can be found under `/config/kpi_plugin.conf`
- **On the host**, the shared volume location of the `/config` is `/opt/ufm/files/conf/plugins/kpi/kpi_plugin.conf`

## Clusters Configurations

The default KPI configurations KPI include one default cluster called `unknown`, once the plugin starts, the default cluster is configured to collect the secondary telemetry endpoint <http://localhost:9002/csv/metrics> and the local UFM topology data.

To change the parameters of the default cluster, or to add additional clusters, please refer to the following configuration under the `kpi_plugin.conf`:

```
### Set name to "cluster-config-$cluster_name". Add section per each cluster
[cluster-config-unknown]

### uncomment and set 2 following options:
#host_list = host_name[1-1024],another_host_name[1-100]
### threshold to distinguish between hosts and switches
(inclusive)
#host_max_ports = 4

### OR

### If hostlist format is not possible, another option is per-
level regular expressions
### That is a list of regular expressions to detect nodes level
in topology (0 is lowest - hosts)
### Key structure is 'level.<level number>.<per-level running index>'
#level.0.0=some-host-pattern-\d+
#level.0.1=another-host-pattern-\d+
#level.1.0=leaf-pattern-l\d+
#level.2.0=spine-pattern-s\d+
#level.3.0=core-pattern-c\d+
```

```

### If running as standalone app please uncomment and set next 3
lines
#ufm_ip=0.0.0.0
#ufm_access_token=1234567890abcdefghijklmnopqrst
#telemetry_url=http://0.0.0.0:9100

### If running as UFM plugin and UFM port has changed
#ufm_port=1234

```

Property	Description	Default Value
cluster.host_list	Set of hosts in <a href="#">hostlist format</a> . Used to detect the topology leafs.	None
cluster.host_max_ports	The maximal number of ports in a server. Used as threshold to classify a node as server / switch.	4
cluster.level.X.Y	Regular Expression to capture topology levels. The first index (X) is the level and the following index (Y) is a running index for level X	None
cluster.ufm_ip	UFM IP that used to collect the topology data	'127.0.0.1'
cluster.ufm_port	UFM port that used to collect the topology data in case the cluster is local	'8000'
cluster.ufm_access_token	The UFM access token that should be provided in case the cluster is collecting data from a remote UFM	None
cluster.telemetry_url	UFM telemetry endpoint URL that used to collect the telemetry metrics.	' <a href="http://127.0.0.1:9002">http://127.0.0.1:9002</a> '
cluster.telemetry_metrics_push_delta_only	If True, only changed telemetry metrics are pushed to Prometheus after each pulling interval, with a fallback to push unchanged metrics if they remain static for over an hour. Otherwise, all fetched metrics will be pushed to the Prometheus after each pulling interval	True

## KPI Configurations

The configurations are related to the KPI plugin itself. please refer to the below configuration section in order to manage the KPI generic configurations:

```
[kpi-config]
### Optional Comma separated list that contains list of the
disabled KPIs that we don't want to store them in Prometheus DB
### Available KPIs:
###
connected_endpoints, topology_correctness, stability, operating_condi
disabled_kpis=telemetry_metrics
```

Property	Description	Default Value
disabled_kpis	Optional Comma-separated list that contains the list of the disabled KPIs that we don't want to store in Prometheus DB. The available KPIs are: connected_endpoints, topology_correctness, stability, operating_conditions, bw_loss_by_congestion, tree_over_subscription, tor_to_tor_bw, general, telemetry_metrics	telemetry_metrics

## Prometheus Configurations

The plugin includes a local Prometheus server instance that is used by default, the following parameters are used to manage the Prometheus configurations:

```
[prometheus-config]
prometheus_ip=0.0.0.0
prometheus_port=9090
prometheus_db_data_retention_size=120GB
prometheus_db_data_retention_time=15d
```

Property	Description	Default Value
prometheus_ip	IP of Prometheus server	0.0.0.0
prometheus_port	Port of Prometheus server	9090
prometheus_db_data_retention_size	Data retention policy by size (used only for the local Prometheus server)	120GB
prometheus_db_data_retention_time	Data retention policy by time (used only for the local Prometheus server)	15d

The data storage path of the local Prometheus DB is under `/opt/ufm/files/conf/plugins/kpi/prometheus_data`.

## Global Time Interval Configurations

The following is used by all clusters globally, each property could be overridden by adding it under the cluster's section.

```
[time-interval-config]
telemetry_interval=300
ufm_interval=60
```

Property	Description	Default Value
telemetry_interval	Polling interval for the telemetry metrics data in seconds	300
ufm_interval	Polling interval for the UFM APIs in seconds	60
disabled_kpis	Polling interval for the connected_endpoints KPI specifically	60

## Logs Configurations


The below configurations are to manage the kpi\_plugin.log file

```
[logs-config]
logs_level = INFO
logs_file_name = /log/kpi_plugin.log
log_file_max_size = 10485760
log_file_backup_count = 5
```

## Grafana Dashboard Templates

The KPI plugin provides several Grafana dashboard templates that the Grafana users can import, these dashboards display the KPIs panels and graphs. The main dashboard is a cluster view that shows the cluster's KPIs. The dashboard should be connected to the KPI Prometheus server.

The dashboard JSON template can be found under `/opt/ufm/files/conf/plugins/kpi/grafana/`:



## Logs

The following logs are exposed under `/opt/ufm/files/logs/plugins/kpi/` in case of UFM plugin mode, and under `/log` inside the container in case of Standalone mode.

- `kpi_plugin.log` - The application logs.
- `kpi_plugin_stderr/stdout` - The application service logs

- prometheus.log - The local Prometheus logs.

## REST APIs

### Get List of Configured Clusters

- URL:
  - UFM Plugin: [https://<IP>/ufmRest/plugin/kpi/api/cluster/\\_\\_names\\_\\_](https://<IP>/ufmRest/plugin/kpi/api/cluster/__names__)
  - Standalone: [http://<IP>:8686/api/cluster/\\_\\_names\\_\\_](http://<IP>:8686/api/cluster/__names__)
- Method: GET
- Response: List of cluster names strings

### Get KPIs Information

- URL:
  - UFM Plugin: [https://<IP>/ufmRest/plugin/kpi/files/kpi\\_info](https://<IP>/ufmRest/plugin/kpi/files/kpi_info)
  - Standalone: [http://<IP>:8686/files/kpi\\_info](http://<IP>:8686/files/kpi_info)
- Method: GET
- Response: List of KPI names and HTML descriptions.

### Get KPIs Values

- URL:
  - UFM Plugin: [https://<IP>/ufmRest/plugin/kpi/api/cluster/<cluster\\_name>](https://<IP>/ufmRest/plugin/kpi/api/cluster/<cluster_name>)
  - Standalone: [http://<IP>:8686/api/cluster/<cluster\\_name>](http://<IP>:8686/api/cluster/<cluster_name>)
- Method: GET

Response: A list of KPIs with the relative calculates graph values to be used in the UI. Generally, 2 main components are expected: the table data (key “2d\_matrix\_data”) and the graph data (key “graph\_data”). Each value corresponds to rules expected by the UI:

- display name – KPI display name
- 2d\_matrix\_data – Latest data in a table-like format. Every list item is a dict that makes a table row - corresponding to the columns of that row.
  - data – List of dict, each dict is a column in the row. May contain:
    - percentage – Value in percentage.
    - value – Raw value.
    - name – Column header
  - direction – For arrows icon (up / down)
  - name – Row header
- graph\_data – dictionary with the following items:
  - multi\_line\_graph – time series graph for one or more series.
    - title – Graph title.
    - x\_label – X axis label.
    - x\_values – X axis values.
    - y\_labels – Y axis labels.
    - y\_values – Y axis values.
  - info – string with information of the graph data.

## Get KPI Plugin Overview

- URL:

- UFM Plugin: `https://<IP>/ufmRest/plugin/kpi/overview?time_window=<value>` (in hours)
  - Standalone: `http://<IP>:8686/overview?time_window=<value>` (in hours)
- Method: GET

Response:

```
{
  "clusters_telemetry_info": [
    {
      "cluster_name": "unknown",
      "interval": 60,
      "url": "http://pjazz:9002/csv/metrics"
    }
  ],
  "prometheus_info": {
    "db_statistics": {
      "appended_samples_rate_per_sec": 11.46,
      "bytes_rate_per_sample": 9.227,
      "total_compressed_blocks_size_bytes": 272329313.0,
      "total_head_chunks_size_bytes": 1937238.0,
      "total_wal_size_bytes": 2989807.0
    },
    "url": "http://pjazz:9191"
  }
}
```

Where:

`clusters_telemetry_info`: contains a list of the configured clusters' information, each cluster has the following properties:

Property	Description	Default Value
<code>cluster_name</code>	Cluster's name	One cluster with name 'unknown'

interval	Cluster's telemetry pulling time interval	60
url	The cluster's URL telemetry	<a href="http://0.0.0.0:9002/csv/metrics">http://0.0.0.0:9002/csv/metrics</a>

**prometheus\_info:** Contains the general Prometheus configurations (e.g. the URL) and statistics about the collected samples (for the local Prometheus mode)

Property	Description
db_statistics.appended_sample_s_rate_per_sec	Prometheus rate of the total appended samples per second, calculated by the following Prometheus expression: <b><i>rate(prometheus_tsdb_head_samples_appended_total[{rate_window_time}h])</i></b>
db_statistics.bytes_rate_per_sample	Prometheus rate of ingested bytes per sample, calculated by the following Prometheus expression: <b><i>rate(prometheus_tsdb_compaction_chunk_size_bytes_sum[{rate_window_time}h]) / rate(prometheus_tsdb_compaction_chunk_samples_sum[{rate_window_time}h])</i></b>
db_statistics.total_compressed_blocks_size_bytes	Total compressed blocks size in bytes that the Prometheus was stored, calculating by the following Prometheus expression: <b><i>prometheus_tsdb_storage_blocks_bytes</i></b>
db_statistics.total_head_chunks_size_bytes	Total HEAD chunks blocks size in bytes that the Prometheus was stored, calculating by the following Prometheus expression: <b><i>prometheus_tsdb_head_chunks_storage_size_bytes</i></b>
db_statistics.total_wal_size_bytes	Total WAL size bytes, calculating by the following Prometheus expression: <b><i>prometheus_tsdb_wal_storage_size_bytes</i></b>
prometheus_info.url	The promethues's URL telemetry

## UI Views

## KPI Overview

**Clusters Telemetry Information**

Cluster Name	Telemetry URL	Scraping Interval
unknown	http://pjazz:9002/ovs/metrics	60

Viewing 1-1 of 1

---

**Prometheus Server Information** Rate Time Window: Last 24 hours

Prometheus Address	http://pjazz:9191
Ingested Samples/sec	11,774 samples/s
Stored Bytes/Sample	9,228 B/sample
WAL Directory Size	1.81 MB
HEAD CHUNKS Directory Size	128 KB
Compressed Blocks Size	253.1 MB

## Cluster KPIs Data

**Cluster Data** Local Time (Asia/Hebron)

Clusters: unknown

Show Trend Line

KPI	Summary	Trend																																										
Bandwidth Loss due to Congestion	<table border="1"> <thead> <tr> <th></th> <th>2-5%</th> <th>5-10%</th> <th>10-20%</th> <th>20-40%</th> <th>40-80%</th> <th>80-100%</th> </tr> </thead> <tbody> <tr> <td>L1/Up</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>L2/Up</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>L3/D-</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>L2/D-</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>L1/D-</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> </tr> </tbody> </table>		2-5%	5-10%	10-20%	20-40%	40-80%	80-100%	L1/Up	0	0	0	0	0	0	L2/Up	0	0	0	0	0	0	L3/D-	0	0	0	0	0	0	L2/D-	0	0	0	0	0	0	L1/D-	0	0	0	0	0	0	<p>Trend line chart showing P1, P10, P50, P90 values over time.</p>
	2-5%	5-10%	10-20%	20-40%	40-80%	80-100%																																						
L1/Up	0	0	0	0	0	0																																						
L2/Up	0	0	0	0	0	0																																						
L3/D-	0	0	0	0	0	0																																						
L2/D-	0	0	0	0	0	0																																						
L1/D-	0	0	0	0	0	0																																						
NICs connectivity	100% (31)	<p>Trend line chart showing Connected NICs at 100%.</p>																																										
General	Total Components: Switches: 2 NICs: 38 Links: 39	<p>Trend line chart showing Switches Overheat (3%) and NICs Overheat (2%).</p>																																										

---

# Troubleshooting

## Split-Brain Recovery in HA Installation

The split-brain problem is a DRBD synchronization issue (HA status shows DUnknown in the DRBD disk state), which occurs when both HA nodes are rebooted. For example, in cases of electricity shut-down. To recover, please follow the below steps:

- **Step 1:** Manually choose a node where data modifications will be discarded.

It is called the split-brain victim. Choose wisely; all modifications will be lost! When in doubt, run a backup of the victim's data before you continue.

When running a Pacemaker cluster, you can enable maintenance mode. If the split-brain victim is in the Primary role, bring down all applications using this resource. Now switch the victim to the Secondary role:

```
victim# drbdadm secondary ha_data
```

- **Step 2:** Disconnect the resource if it's in connection state **WFConnection**:

```
victim# drbdadm disconnect ha_data
```

- **Step 3:** Force discard of all modifications on the split-brain victim:

```
victim# drbdadm -- --discard-my-data connect ha_data
```

For DRBD 8.4.x:

```
victim# drbdadm connect --discard-my-data ha_data
```

- **Step 4:** Resync starts automatically if the survivor is in a WFConnection network state. If the split-brain survivor is still in a Standalone connection state, reconnect it:

```
survivor# drbdadm connect ha_data
```

Now the resynchronization from the survivor (SyncSource) to the victim (SyncTarget) starts immediately. There is no full sync initiated, but all modifications on the victim will be overwritten by the survivor's data, and modifications on the survivor will be applied to the victim.

## Performing Failover on Non-Master Node

The `ufm_ha_cluster` failover action fails with the following error: "Cannot perform failover on non-master node". To fix, follow the below action:

- **Step 1:** Verify that `/etc/hosts` file on both the master and standby UFM hosts contains the correct host names and IP addresses mapping.
- **Step 2:** If necessary, fix the mapping and retry the failover command.

## Restoring UFM Data Upon In-Service Upgrade Failure

### Note

These instructions apply in high availability scenario only.

In the event of an in-service upgrade failure, the previous version of UFM's data will be safeguarded as a backup in the `/opt/ufm/BACKUP` directory, formatted as `"ufm_upgrade_backup_<prev_version>-<new_version>_<date>.zip"`.

To restore the data on the unupgraded node, follow these steps:

1. Copy the backup file from the upgraded node to the unupgraded node using the following command:

```
scp /opt/ufm/BACKUP/ufm_upgrade_backup_<prev_version>-  
<new_version<_<date>.zip  
root@<unupgraded_node_ip>:/opt/ufm/BACKUP/
```

2. Perform a failover of UFM to the master node, which is mandatory for data mount migration (including '/opt/ufm/files') to the master node: On the Master node, execute:

```
ufm_ha_cluster takeover
```

3. Stop UFM on the unupgraded node:

```
ufm_ha_cluster stop
```

4. Restore UFM configuration files from the backup:

```
/opt/ufm/scripts/ufm_restore.sh -f  
/opt/ufm/BACKUP/ufm_upgrade_backup_<prev_version>-  
<new_version<_<date>.zip
```

5. Start UFM on the unupgraded node (Note: Only the upgraded node can function until the upgrade issue is resolved, and failovers will not work).

Now, the issue that caused the upgrade failure can be addressed. If the problem is resolved, you can attempt the in-service upgrade again by failing UFM over to the upgraded node.

Alternatively, if needed, you can revert the changes made by reinstalling the old UFM version on the upgraded node.

---

# Appendixes

- [SM Configurations](#)
- [Appendix – Diagnostic Utilities](#)
- [Appendix - Supported Port Counters and Events](#)
- [Appendix – Used Ports](#)
- [Appendix – Configuration Files Auditing](#)
- [Appendix – IB Router](#)
- [Appendix – NVIDIA SHARP Integration](#)
- [Appendix - UFM SLURM Integration](#)
- [Appendix - Switch Grouping](#)
- [Appendix – Device Management Feature Support](#)

## SM Configurations

- [Appendix – SM Default Files](#)
- [Appendix – UFM Subnet Manager Default Properties](#)
- [Appendix – Partitioning](#)
- [Appendix – Enhanced Quality of Service](#)
- [Appendix - OpenSM Configuration Files for Congestion Control](#)
- [Appendix – Routing Chains](#)
- [Appendix – Adaptive Routing](#)
- [Appendix – Security Features](#)

- [Appendix – SM Activity Report](#)

## Appendix – SM Default Files

The SM default files are located under the following paths:

- Default SM configuration file – /opt/ufm/files/conf/opensm/opensm.conf
- Default node name map file – /opt/ufm/files/conf/opensm/ib-node-name-map
- Default partition configuration file – /opt/ufm/files/conf/opensm/partitions.conf
- Default QOS policy configuration file – /opt/ufm/files/conf/opensm/qos-policy.conf
- Default prefix routes file – /opt/ufm/files/conf/opensm/prefix-routes.conf

## Appendix – UFM Subnet Manager Default Properties

The following table provides a comprehensive list of UFM SM default properties.

Category	Property	Config File Attribute	Default	Mode/Field	Description
<b>Generic</b>	Subnet Prefix	subnet_prefix	0xfe80000000000000	RW	Subnet prefix used on the subnet 0xfe80000000000000
	LMC	lmc	0	RW	The LMC value used on the subnet: 0-7 Changes to the LMC parameter require a UFM restart.
	SM LID	master_sm_lid	0		Force LID for local SM when in MASTER state Selected LID must match configured LMC 0 disables the feature

Category	Property	Config File Attribute	Default	Mode/Field	Description
Keys	M_Key	m_key	0x0000000000000000	RW	M_Key value sent to all ports -used to qualify the set(PortInfo)
	M_Key Lease Period	m_key_lease_period	0	RW	The lease period used for the M_Key on the subnet in [sec]
	SM_Key	sm_key	0x0000000000000001	RO	SM_Key value of the SM used for SM authentication
	SA_Key	sa_key	0x0000000000000001	RO	SM_Key value to qualify rcv SA queries as 'trusted'
	Partition enforcement	part_enforce	<ul style="list-style-type: none"> <li>• Out</li> <li>• In</li> <li>• Both (default-outbound and inbound enforcement enabled)</li> </ul>	RO	Partition enforcement type (for switches)
	MKEY lookup	m_key_lookup	FALSE	RW	If FALSE, SM will not try to determine the m_key of unknown ports.
	M_Key Per Port	m_key_per_port	FALSE	RW	When m_key_per_port is enabled, OpenSM will generate an M_Key for each port
Limits	Packet Life Time	packet_life_time	0x12	RW	The maximum lifetime of a packet in a switch. The actual time is 4.096usec * 2^<packet_life_time> The value 0x14 disables the mechanism

Category	Property	Config File Attribute	Default	Mode/Field	Description
	VL Stall Count	vl_stall_count	0x07	RO	The number of sequential packets dropped that cause the port to enter the VL Stalled state. The result of setting the count to zero is undefined.
	Leaf VL Stall Count	leaf_vl_stall_count	0x07	RO	The number of sequential packets dropped that causes the port to enter the leaf VL Stalled state. The count is for switch ports driving a CA or gateway port. The result of setting the count to zero is undefined.
	Head Of Queue Lifetime	head_of_queue_lifetime	0x12	RW	The maximum time a packet can wait at the head of the transmission queue. The actual time is $4.096\text{usec} * 2^{\langle \text{head\_of\_queue\_lifetime} \rangle}$ The value 0x14 disables the mechanism
	Leaf Head Of Queue Lifetime	leaf_head_of_queue_lifetime	0x10	RW	The maximum time a packet can wait at the head of queue on a switch port connected to a CA or gateway port.
	Maximal Operational VL	max_op_vls	2	RW	Limit of the maximum operational VLs
	Force Link Speed	force_link_speed	15 (Do NOT change)	RO	Force PortInfo: LinkSpeedEnabled on switch ports.

Category	Property	Config File Attribute	Default	Mode/Field	Description
					If 0, do not modify. Values are: 1: 2.5 Gbps 3: 2.5 or 5.0 Gbps 5: 2.5 or 10.0 Gbps 7: 2.5 or 5.0 or 10.0 Gbps 2,4,6,8-14 Reserved 15: set to PortInfo: LinkSpeedSupported
Limits	Subnet Timeout	subnet_timeout	18 (1second)	RW	The subnet_timeout code that will be set for all the ports. The actual timeout is 4.096usec * 2^<subnet_timeout>
	Local PHY Error Threshold	local_phy_errors_threshold	0x08	RW	Threshold of local phy errors for sending Trap 129
	Overrun Errors Threshold	overrun_errors_threshold	0x08	RW	Threshold of credit overrun errors for sending Trap 130
Sweep	Sweep Interval	sweep_interval	10	RW	The time in seconds between subnet sweeps (Disabled if 0)
	Reassign Lids	reassign_lids	FALSE (disabled)	RW	If TRUE (enabled), all LIDs are reassigned
	Force Heavy Sweep	force_heavy_sweep_window	-1	RW	Forces heavy sweep after number of light sweeps (-1 disables this option and 0 will cause every sweep to be heavy)

Category	Property	Config File Attribute	Default	Mode/Field	Description
	Sweep On trap	sweep_on_trap	TRUE (enabled)	RW	If TRUE every trap 128 and 144 will cause a heavy sweep
	Alternative Route Calculation	max_alt_dr_path_retries	4	RW	Maximum number of attempts to find an alternative direct route towards unresponsive ports
	Fabric Rediscovery	max_seq_redisc	2	RW	Max Failed Sequential Discovery Loops
	Offsweep Rebalancing Enable	offsweep_balancing_enabled	FALSE	RW	Enable/Disable idle time routing rebalancing
	Offsweep Rebalancing Window	offsweep_balancing_window	180	RW	Set the time window in seconds after sweep to start rebalancing
Handover	SM Priority	sm_priority	15	RO	SM (enabled). The priority used for deciding which is the master. Range is 0 (lowest priority) to 15 (highest)
	Ignore Other SMs	ignore_other_sm	FALSE (disabled)	RO	If TRUE other SMs on the subnet should be ignored
	Polling Timeout	sminfo_polling_timeout	10	RO	Timeout in seconds between two active master SM polls
	Polling Retries	polling_retry_number	4	RO	Number of failing remote SM polls that declares it

Category	Property	Config File Attribute	Default	Mode/Field	Description
					non-operational
	Honor GUID-to-LID File	honor_guid2lid_file	FALSE (disabled)	RO	If TRUE, honor the guid2lid file when coming out of standby state, if the guid2lid file exists and is valid
	Allowed SM GUID list	allowed_sm_guids	(null) (disabled)		List of Host GUIDs where SM is allowed to run when specified. OpenSM ignores SM running on port that is not in this list. If 0, does not allow any other SM. If null, the feature is disabled.
Threading	Max Wire SMPs	max_wire_smps	8	RW	Maximum number of SMPs sent in parallel
	Transaction Timeout	transaction_timeout	200	RO	The maximum time in [msec] allowed for a transaction to complete
	Max Message FIFO Timeout	max_msg_fifo_timeout	10000	RO	Maximum time in [msec] a message can stay in the incoming message queue
	Routing Threads	routing_threads_num	0	RW	Number of threads to be used for parallel minhop/updn calculations. If 0, number of threads will be equal to number of processors.
	Routing Thread	max_threads_per_core	0	RW	Max number of threads that are allowed to run on

Category	Property	Config File Attribute	Default	Mode/Field	Description
	Threads Per Core				the same processor during parallel computing. If 0, threads assignment per processor is up to operating system initial assignment.
Logging	Log File	log_file	/opt/ufm/files/log/opensm.log	RO	Path of Log file to be used
	Log Flags	log_flags	Error and Info 0x03	RW	The log flags, or debug level being used.
	Force Log Flush	force_log_flush	FALSE (disabled)	RO	Force flush of the log file after each log message
	Log Max Size	log_max_size	4096	RW	Limit the size of the log file in MB. If overrun, log is restarted
	Accumulate Log File	accum_log_file	TRUE (enabled)	RO	If TRUE, will accumulate the log over multiple OpenSM sessions
	Dump Files Directory	dump_files_dir	/opt/ufm/files/log	RO	The directory to hold the file SM dumps (for multicast forwarding tables for example). The file is used collects information.
	Syslog log	syslog_log	0x0	RW	Sets a verbosity of messages to be printed in syslog
Misc	Node Names Map File	node_name_map_name	Null	RW	Node name map for mapping node's to more descriptive node descriptions
	SA database File	sa_db_file	Null	RO	SA database file name

Category	Property	Config File Attribute	Default	Mode/Field	Description
	No Clients Reregistration	no_clients_rereg	FALSE (disabled)	RO	If TRUE, disables client reregistration
	Exit On Fatal Event	exit_on_fatal	TRUE (enabled)	RO	If TRUE (enabled), the SM exits for fatal initialization issues
	Switch Isolation From Routing	held_back_sw_file	Null	RW	File that contains GUIDs of switches isolated from routing
	Enable NVIDIA SHARP support	sharp_enabled	Enabled	RW	Defines whether to enable/disable NVIDIA SHARP on supporting ports.
Multicast	Disable Multicast	disable_multicast	FALSE (disabled)	RO	If TRUE, OpenSM should disable multicast support and no multicast routing is performed
	Multicast Group Parameters	default_mcg_mtu	0	RW	Default MC group MTU for dynamic group creation. 0 disables this feature, otherwise, the value is a valid IB encoded MTU
Multicast	Multicast Group Parameters	default_mcg_rate	0	RW	Default MC group rate for dynamic group creation. 0 disables this feature, otherwise, the value is a valid IB encoded rate
Multicast	Enable incremental multicast routing	enable_inc_mc_routing	FALSE	RW	Enable incremental multicast routing

Category	Property	Config File Attribute	Default	Mode/Field	Description
Multicast	MC root file	mc_roots_file	null	RW	Specify predefined MC groups root guides
QoS	Settings	qos	FALSE (disabled) *From UFM v3.7 and on	RW	If FALSE (disabled), SM will not apply QoS settings
Unhealthy Ports	Enabling Unhealthy Ports	hm_unhealthy_ports_checks	TRUE	RW	Enables Unhealthy Ports configuration
	Configuration file	hm_ports_health_policy_file	null	RW	Specifies configuration file for health policy
	Unhealthy actions	hm_sw_manual_action	no_discover	RW	Specifies what to do with switch ports which were manually added to health policy file
	MADs validation	validate_smp	TRUE	RW	If set to TRUE, opensm will ignore nodes sending non-spec compliant MADs. When set to FALSE, opensm will log the warning in the opensm log file about non-compliant node
Routing	Unicast Routing engine	routing_engine	(null)	RW	By default, ar_updn routing engine is used by the SM. Supported routing engines are minhop, updn, dnup, ftree, dor, torus-2QoS, kdor-hc, kdor-ghc, dfp, dfp2, ar_updn, ar_ftree and ar_dor.

Category	Property	Config File Attribute	Default	Mode/Field	Description
	Randomization	scatter_ports	8	RW	Assigns ports in a random order instead of round-robin. If 0, the feature is disabled, otherwise use the value as a random seed. Applicable to the MINHOP/UPDN routing algorithms
	Randomization	guid_routing_order_no_scatter	TRUE	RO	Do not use scatter for ports defined in guid_routing_order file
	Unicast Routing Caching	use_ucast_cache	TRUE	RW	Use unicast routing cache for routing computation time improvement
	GUID Ordering During Routing	guid_routing_order_file	NULL	RW	The file holding guid routing order of particular guides (for MinHop, Up/Down)
	Torus Routing	torus_config	/opt/ufm/files/conf/opensm/torus-2QoS.conf	RW	Torus-2QoS configuration file name
	Routing Chains	pgrp_policy_file	NULL	RW	The file holding the port groups policy
		topo_policy_file	NULL	RW	The file holding the topology policy
		rch_policy_file	NULL	RW	The file holding the routing chains policy
		max_topologies_per_sw	1	RO	Defines maximal number of topologies to which a single switch may be assigned during routing

Category	Property	Config File Attribute	Default	Mode/Field	Description
					engine chain configuration.
	Incremental Multicast Routing (IMR)	enable_inc_mc_routing	TRUE	RW	If TRUE, MC nodes will be added to the MC tree incrementally. When set to FALSE, the tree will be recalculated per each change.
	MC Global root	mc_primary_root_guid/mc_secondary_root_guid	0x0000000000000000 (for both)	RW	Primary and Secondary global mc root guid
	Scatter ports	use_scatter_for_switch_lid	FALSE	RW	Use scatter when routing to the switch's LIDs
	updn lid tracking mode	updn_lid_tracking_mode	FALSE	RW	Controls whether SM will use LID tracking or not when updn or ar_updn routing engine is used
Events	Event Subscription Handling	drop_subscr_on_report_fail	FALSE	RW	Drop subscription on report failure (o13-17.2.1)
	Event Subscription Handling	drop_event_subscriptions	TRUE	RW	Drop event subscriptions (InformInfo and ServiceRecords) on port removal and SM coming out of STANDBY
Virtualization	Virtualization enabled	virt_enabled	Enabled	RW	Enables/disables virtualization support
	Maximum ports in virtualiz	virt_max_ports_in_process	64	RW	Sets a number of ports to be handled on each virtualization process cycle

Category	Property	Config File Attribute	Default	Mode/Field	Description
	ation process				
Router	Router aguid enable	rtr_aguid_enable	0 (Disabled)	RW	Defines whether the SM should create alias GUIDs required for router support for each HCA port
	Router path record flow label	rtr_pr_flow_label	0	RW	Defines flow label value to use in multi-subnet path query responses
	Router path record tclass	rtr_pr_tclass	0	RW	Defines tclass value to use in multi-subnet path query responses.
	Router path record sl	rtr_pr_sl	0	RW	Defines sl value to use in multi-subnet path query responses
	Router path record MTU	rtr_pr_mtu	4 (IB_MTU_LEN_2048)	RW	Define MTU value to use in multi-subnet path query responses
	Router path record rate	rtr_pr_rate	16 (IB_PATH_RECORD_RATE_100_GBS)	RW	Defines rate value to use in multi-subnet path query responses
SA Security	SA Enhanced Trust Model (SAETM)	sa_enhanced_trust_model	FALSE	RW	Controls whether SAETM is enabled.

Category	Property	Config File Attribute	Default	Mode/Field	Description
	Untrusted GuidInfo records	sa_etm_allow_untrusted_guidinfo_rec	FALSE	RW	Controls whether to allow Untrusted Guidinfo record requests in SAETM.
	Guidinfo record requests by VF	sa_etm_allow_guidinfo_rec_by_vf	FALSE	RW	Controls whether to allow Guidinfo record requests by vf in SAETM.
	Untrusted proxy requests	sa_etm_allow_untrusted_proxy_requests	FALSE	RW	Controls whether to allow Untrusted proxy requests in SAETM.
	Max number of multicast groups	sa_etm_max_num_mcgs	128	RW	Max number of multicast groups per port/vport that can be registered.
	Max number of service records	sa_etm_max_num_srvcs	32	RW	Max number of service records per port/vport that can be registered.
	Max number of event subscriptions	sa_etm_max_num_event_subs	32	RW	Max number of event subscriptions (InformInfo) per port/vport that can be registered.
	SGID spoofing	sa_check_sgid_spoofing	TRUE	RW	If enabled, the SA checks for SGID spoofing in every request with GRH included, unless the SLID

Category	Property	Config File Attribute	Default	Mode/Field	Description
					is from a router port at that request.

## Configuring UFM for SR-IOV

Single-root I/O virtualization (SR-IOV) enables a PCI Express (PCIe) device to appear to be multiple separate physical PCIe devices.

UFM is ready to work with SR-IOV devices by default. You can fine-tune the configuration using the SM configuration.

The following arguments are available for ConnectX-5 and later devices:

Argument	Value	Description
virt_enabled	<ul style="list-style-type: none"> <li>0 – no virtualization support</li> <li>1 – disable virtualization on all virtualization supporting ports</li> <li>2 – enable virtualization on all virtualization supporting ports (default)</li> </ul>	Virtualization support
virt_max_ports_in_process	Possible values: 0-65535; where 0 processes all pending ports Default: 64	Maximum number of ports to be processed simultaneously by the virtualization manager
virt_default_hop_limit	Possible values: 0-255 Default: 2	Default value for hop limit to be returned in path records where either the source or destination are virtual ports

## Isolating Switch From Routing

UFM can isolate particular switches from routing in order to perform maintenance of the switches with minimal interruption to the existing traffic in the fabric.

Isolating a switch from routing is done via UFM Subnet Manager as follows:

1. Create a file that includes either the node GUIDs or system GUID of the switches under maintenance. For example:

```
0x1234566  
0x1234567
```

2. Set the filename of the parameter `held_back_sw_file` in the `/conf/opensm.conf` file (the same as the file created in Step 1).
3. Run:

```
kill -s HUP `pidof opensm`
```

Once SM completes rerouting, the traffic does not go through the ports of isolated switches.

To attach the switch to the routing:

1. Remove the GUID of the switch from the list of isolated switches defined in Step 1 of the isolation process.
2. Run:

```
kill -s HUP `pidof opensm`
```

Once SM completes rerouting, traffic will go through the switch.

## Appendix – Partitioning

Partitioning enforces isolation of the fabric. The default partition is created on all managed devices. Devices that are running an SM, all switches, routers, and gateways are added to the default partition with full membership. By default, all the HCA ports are also added to the default partition with FULL membership.

Partitioning is provisioned to the Subnet Manager via the `partitions.conf` configuration file, which cannot be removed or manually modified.

**Note**

For those who use NVIDIA gateway systems, for proper system functionality, disable the automatic partitioning by changing the attribute `gateway_port_partitioning = none` in the `/opt/ufm/files/conf/gv.cfg` configuration. Restart UFM for the change to take effect.

If required, you can add an extension to the `partitions.conf` file that is generated by UFM. You can edit the file, `/opt/ufm/files/conf/partitions.conf.user_ext`, and the content of this extension file will be added to the `partitions.conf` file. Files synchronization is done by UFM on every logical model change. However, it can also be triggered manually by running the `/opt/ufm/scripts/sync_partitions_conf.sh` script. The script validates and merges the `/opt/ufm/files/conf/partitions.conf.user_ext` file into the `/opt/ufm/files/conf/opensm/partitions.conf` file and starts the heavy sweep on the Subnet Manager.

**Note**

The maximum length of the line in the `partitions.conf` file is 4096 characters. However, to enable long PKeys, it is possible to split the pkey membership to multiple lines:

```
IOPartition=0x4, ipoib, sl=0, defmember=full : <port-guid1> , <port-guid2> ;
```

```
IOPartition=0x4, ipoib, sl=0, defmember=full : <port-guid3> , <port-guid4> ;
```

The `partitions.conf.user_ext` uses the same format as the `partitions.conf` file. See [SM Partitions.conf File Format](#) for the format of the `partitions.conf` file.

For example, to add server ports to PKey 4:

```
IOPartition=0x4, ipoib, sl=0, defmember=full : 0x8f10001072a41;
```

## SM Partitions.conf File Format

This appendix presents the content and format of the SM *partitions.conf* file.

```
OpenSM Partition configuration
=====
```

The default partition will be created by OpenSM unconditionally even when partition configuration file does not exist or cannot be accessed.

The default partition has P\_Key value 0x7fff. OpenSM's port will always have full membership in default partition. All other end ports will have full membership if the partition configuration file is not found or cannot be accessed, or limited membership if the file exists and can be accessed but there is no rule for the Default partition.

Effectively, this amounts to the same as if one of the following rules

below appear in the partition configuration file:

In the case of no rule for the Default partition:

```
Default=0x7fff : ALL=limited, SELF=full ;
```

In the case of no partition configuration file or file cannot be accessed:

```
Default=0x7fff : ALL=full ;
```

## File Format

=====

### Comments:

Line content followed after '#' character is comment and ignored by parser.

### General file format:

```
<Partition Definition>:[<newline>]<Partition Properties>;
```

#### Partition Definition:

```
[PartitionName][=PKey][, ipoib_bc_flags]  
[, defmember=full|limited]
```

PartitionName - string, will be used with logging. When omitted

empty string will be used.

PKey - P\_Key value for this partition. Only low 15 bits will

be used. When omitted will be autogenerated.

ipoib\_bc\_flags - used to indicate/specify IPoIB capability of this partition.

defmember=full|limited - specifies default membership for port guid

list. Default is limited.

#### ipoib\_bc\_flags:

```
ipoib_flag|[mgroup_flag]*
```

ipoib\_flag - indicates that this partition may be used for IPoIB, as a result the IPoIB broadcast group will be created with the flags given, if any.

Partition Properties:

[<Port list>|<MCast Group>]\* | <Port list>

Port list:

<Port Specifier>[,<Port Specifier>]

Port Specifier:

<PortGUID>[=[full|limited]]

PortGUID - GUID of partition member EndPort.  
Hexadecimal numbers should start from 0x, decimal numbers are accepted too.  
full or limited - indicates full or limited membership for this port. When omitted (or unrecognized) limited membership is assumed.

MCast Group:

mgid=gid[,mgroup\_flag]\*<newline>

- gid specified is verified to be a Multicast address  
IP groups are verified to match the rate and mtu of the broadcast group. The P\_Key bits of the mgid for IP

P\_Key specified groups are verified to either match the in by "Partition Definition" or if they are 0x0000 the P\_Key will be copied into those bits.

- mgroup\_flag:
  - rate=<val> - specifies rate for this MC group (default is 3 (10GBps))
  - mtu=<val> - specifies MTU for this MC group (default is 4 (2048))
  - sl=<val> - specifies SL for this MC group (default is 0)
  - scope=<val> - specifies scope for this MC group (default is 2 (link local)). Multiple

scope settings are permitted for a partition.

NOTE: This overwrites the scope nibble of the specified mgid. Furthermore specifying multiple scope settings will result in multiple MC groups being created.

- qkey=<val> - specifies the Q\_Key for this MC group (default: 0x0b1b for IP groups, 0 for other groups)

WARNING: changing this for the broadcast group may break IPoIB on client nodes!!!

- tclass=<val> - specifies tclass for this MC group (default is 0)
- FlowLabel=<val> - specifies FlowLabel for this MC group (default is 0)

newline: '\n'

Note that values for rate, mtu, and scope, for both partitions and multicast groups, should be specified as defined in the IBTA specification (for example, mtu=4 for 2048).

There are several useful keywords for PortGUID definition:

- 'ALL' means all end ports in this subnet.
- 'ALL\_CAS' means all Channel Adapter end ports in this subnet.
- 'ALL\_SWITCHES' means all Switch end ports in this subnet.
- 'ALL\_ROUTERS' means all Router end ports in this subnet.
- 'SELF' means subnet manager's port.

Empty list means no ports in this partition.

Notes:

-----

White space is permitted between delimiters ('=', ',', ':', ';').

PartitionName does not need to be unique, PKey does need to be unique.

If PKey is repeated then those partition configurations will be merged

and first PartitionName will be used (see also next note).

It is possible to split partition configuration in more than one definition, but then PKey should be explicitly specified

(otherwise

different PKey values will be generated for those definitions).

Examples:

-----

```
Default=0x7fff : ALL, SELF=full ;
```

```
Default=0x7fff : ALL, ALL_SWITCHES=full, SELF=full ;
```

```
NewPartition , ipoib : 0x123456=full, 0x3456789034=limited,  
0x2134af2306 ;
```

```
YetAnotherOne = 0x300 : SELF=full ;
```

```
YetAnotherOne = 0x300 : ALL=limited ;
```

```
ShareIO = 0x80 , defmember=full : 0x123451, 0x123452;
```

```
# 0x123453, 0x123454 will be limited
```

```
ShareIO = 0x80 : 0x123453, 0x123454, 0x123455=full;
```

```
# 0x123456, 0x123457 will be limited
```

```
ShareIO = 0x80 : defmember=limited : 0x123456, 0x123457,  
0x123458=full;
```

```
ShareIO = 0x80 , defmember=full : 0x123459, 0x12345a;
```

```
ShareIO = 0x80 , defmember=full : 0x12345b, 0x12345c=limited,  
0x12345d;
```

```
# multicast groups added to default
```

```
Default=0x7fff, ipoib:
```

```
    mgid=ff12:401b::0707, sl=1 # random IPv4 group
```

```
    mgid=ff12:601b::16      # MLDv2-capable routers
```

```
    mgid=ff12:401b::16      # IGMP
```

```
    mgid=ff12:601b::2       # All routers
```

```
    mgid=ff12::1, sl=1, Q_Key=0xDEADBEEF, rate=3, mtu=2 # random
```

```
group
```

```
    ALL=full;
```

Note:

----

The following rule is equivalent to how OpenSM used to run prior to the partition manager:

```
Default=0x7fff, ipoib:ALL=full;
```

## Appendix – Enhanced Quality of Service

Enhanced QoS provides a higher resolution of QoS at the service level (SL). Users can configure rate limit values per SL for physical ports, virtual ports, and port groups, using `enhanced_qos_policy_file` configuration parameter.

Valid values of this parameter:

- Full path to the policy file through which Enhanced QoS Manager is configured
- “null” – to disable the Enhanced QoS Manager (default value)

### Note

To enable Enhanced QoS Manager, QoS must be enabled in SM configuration file.

## Enhanced QoS Policy File

The policy file is comprised of two sections:

- **BW\_NAMES:** Used to define bandwidth setting and name (currently, rate limit is the only setting). Bandwidth names are defined using the syntax:

```
<name> = <rate limit in 1Mbps units>
```

**Example:**

```
My_bandwidth = 50
```

- **BW\_RULES:** Used to define the rules that map the bandwidth setting to a specific SL of a specific GUID. Bandwidth rules are defined using the syntax:

```
<guid>|<port group name> = <sl id>:<bandwidth name>, <sl id>:  
<bandwidth name>...
```

**Examples:**

```
0x2c90000000025 = 5:My_bandwidth, 7:My_bandwidth  
Port_grp1 = 3:My_bandwidth, 9:My_bandwidth
```

## Notes

- **Rate limit = 0** represents unlimited rate limit.
- Any unspecified SL in a rule will be set to 0 (unlimited) rate limit automatically.
- “default” is a well-known name which can be used to define a default rule used for any GUID with no defined rule (If no default rule is defined, any GUID without a specific rule will be configured with unlimited rate limit for all SLs).
- Failure to complete policy file parsing leads to an undefined behavior. User must confirm no relevant error messages in SM log in order to ensure Enhanced QoS Manager is configured properly.

- An empty file with only 'BW\_NAMES' and 'BW\_RULES' keywords configures the network with an unlimited rate limit.
- The VPORT\_BW\_RULES section is optional and includes virtual port GUIDs only (including the vport0 GUID). Physical port GUIDs added to this section are treated as vport0 GUIDs.

## Policy File Example

The below is an example of configuring all ports in the fabric with rate limit of 50Mbps on SL1, except for GUID 0x2c90000000025, which is configured with rate limit of 100Mbps on SL1. In this example, all SLs (other than SL1) are unlimited.

```

-----
-----
BW_NAMES
bw1 = 50
bw2 = 100
BW_RULES
default: 1:bw1
0x2c90000000025: 1:bw2
-----
-----
VPORT_BW_RULES
default = all:DEF_BW_2

```

# OpenSM Configuration

## Enabling Congestion Control

In order to enable congestion control, set the parameter `mlnx_congestion_control` in the OpenSM configuration file to 2. For example:

```
mlnx_congestion_control 2
```

To disable congestion control, set the parameter value to 1. For example:

```
mlnx_congestion_control 1
```

## Defining a Congestion Control Policy File

To define a congestion control policy file, set the parameter `congestion_control_file` in OpenSM configuration file to point to congestion control policy file. For example:

```
congestion_control_policy_file  
/opt/ufm/files/conf/opensm/conf/congestion_control_policy_file
```

The file includes a reference to an active algorithm file name. The algorithm file has to be inside the `ppcc_algo_dir`.

For Example:

```
ca_algo_import_start  
  algo_start  
    algo_id:1  
    algo_file_name: active_algo_file_name  
    # PPCC parameter by name, as defined in algo profile  
    parameters: (BW_G,400), (ALPHA,3932), (MAX_DEC,63569),  
(MAX_INC,69468), (AI,36), (HAI,1200)  
  algo_end  
ca_algo_import_end
```

The `ca_algo_import` block contains all the `algo` blocks that map an `algo_id` to an algorithm profile file. The `algo_id` field of the `algo` blocks must be unique and start from 1. This block is used to import the various PCC algorithms into the configuration and associate them with their `algo_id` values.

## Defining a directory for PPCC algorithm profiles

To define a directory for the programmable congestion control algorithm profiles, set the parameter `ppcc_algo_dir` in OpenSM configuration file. For Example:

```
ppcc_algo_dir /opt/ufm/files/conf/opensm/conf/ppcc_algo_dir
```

## Appendix – Routing Chains

The routing chains feature is offering a solution that enables one to configure different parts of the fabric and define a different routing engine to route each of them. The routings are done in a sequence (hence the name "chains") and any node in the fabric that is configured in more than one part is left with the last routing engine updated for it.

### Configuring Routing Chains

The configuration for the routing chains feature consists of the following steps:

1. Define the port groups.
2. Define topologies based on previously defined port groups.
3. Define configuration files for each routing engine.
4. Define routing engine chains over defined topologies.

### Defining Port Groups

The basic idea behind the port groups is the ability to divide the fabric into sub-groups and give each group an identifier that can be used to relate to all nodes in this group. The port groups are used to define the participants in each of the routing algorithms.

## Defining Port Group Policy File

In order to define a port group policy file, set the parameter 'pgrp\_policy\_file' in the opensm configuration file, as follows:

```
/opt/ufm/files/conf/opensm/port_groups_policy_file.conf
```

## Configuring Port Group Policy

The port groups policy file details the port groups in the fabric. The policy file should be composed of one or more paragraphs that define a group. Each paragraph should begin with the line 'port-group' and end with the line 'end-port-group'.

For example:

```
port-group  
...port group qualifiers...  
end-port-group
```

## Port Group Qualifiers

### Note

Unlike the port group's beginning and ending which do not require a colon, all qualifiers must end with a colon (':'). Also – a colon is a predefined mark that must not be used inside qualifier values. An inclusion of a colon in the name or the use of a port group, will result in the policy's failure.

### Table 62: Port Group Qualifiers

Parameter	Description	Example
name	Each group must have a name. Without a name qualifier, the policy fails.	name: grp1
use	'use' is an optional qualifier that one can define in order to describe the usage of this port group (if undefined, an empty string is used as a default).	use: first port group

## Rule Qualifiers

There are several qualifiers used to describe a rule that determines which ports will be added to the group. Each port group may contain one or more rules of the rule qualifiers in Table 63 (at least one rule shall be defined for each port group).

**Table 63: Rule Qualifiers**

Parameter	Description	Example
guid list	<p>Comma separated list of guides to include in the group. If no specific physical ports were configured, all physical ports of the guid are chosen. However, for each guid, one can detail specific physical ports to be included in the group. This can be done using the following syntax:</p> <ul style="list-style-type: none"> <li>Specify a specific port in a guid to be chosen port-guid: 0x283@3</li> <li>Specify a specific list of ports in a guid to be chosen port-guid: 0x286@1/5/7</li> <li>Specify a specific range of ports in a guid to be chosen port-guid: 0x289@2-5</li> <li>Specify a list of specific ports and ports ranges in a guid to be chosen</li> </ul>	port-guid: 0x283, 0x286, 0x289

Parameter	Description	Example
	<p>port-guid: 0x289@2-5/7/9-13/18</p> <ul style="list-style-type: none"> <li>• Complex rule</li> </ul> <p>port-guid: 0x283@5-8/12/14, 0x286, 0x289/6/8/12</p>	
port-guid-range	<p>It is possible to configure a range of guides to be chosen to the group. However, while using the range qualifier, it is impossible to detail specific physical ports.</p> <p>Note: A list of ranges cannot be specified. The below example is invalid and will cause the policy to fail:</p> <p>port-guid-range: 0x283-0x289, 0x290-0x295</p>	<p>port-guid-range: 0x283-0x289</p>
port-name	<p>One can configure a list of hostnames as a rule. Hosts with a node description that is built out of these hostnames will be chosen. Since the node description contains the network card index as well, one might also specify a network card index and a physical port to be chosen. For example, the given configuration will cause only physical port 2 of a host with the node description 'kuku HCA-1' to be chosen.</p> <p>port and hca_idx parameters are optional. If the port is unspecified, all physical ports are chosen. If hca_idx is unspecified, all card numbers are chosen. Specifying a hostname is mandatory.</p> <p>One can configure a list of hostname/port/hca_idx sets in the same qualifier as follows:</p> <p>port-name: hostname=kuku; port=2; hca_idx=1 , hostname=host1; port=3, hostname=host2</p> <p>Note: port-name qualifier is not relevant for switches, but for HCA's only.</p>	<p>port-name: hostname=kuku; port=2; hca_idx=1</p>
port-regexp	<p>One can define a regular expression so that only nodes with a matching node description will be chosen to the group</p>	<p>port-regexp: SW.*</p>
	<p>It is possible to specify one physical port to be chosen for matching nodes (there is no option to define a list or a range of ports). The given example will cause only nodes that match physical port 3 to be added to the group.</p>	<p>port-regexp: SW.*:3</p>
union-rule	<p>It is possible to define a rule that unites two different port groups. This means that all ports from both groups will be included in the united group.</p>	<p>union-rule: grp1, grp2</p>

Parameter	Description	Example
subtract rule	<p>One can define a rule that subtracts one port group from another. The given rule, for example, will cause all the ports which are a part of grp1, but not included in grp2, to be chosen.</p> <p>In subtraction (unlike union), the order does matter, since the purpose is to subtract the second group from the first one.</p> <p>There is no option to define more than two groups for union/subtraction. However, one can unite/subtract groups which are a union or a subtraction themselves, as shown in the port groups policy file example.</p>	<p>subtract-rule: grp1, grp2</p>

## Predefined Port Groups

There are 3 predefined port groups that are available for use, yet cannot be defined in the policy file (if a group in the policy is configured with the name of one of these predefined groups, the policy fails) –

- ALL – a group that includes all nodes in the fabric
- ALL\_SWITCHES – a group that includes all switches in the fabric.
- ALL\_CAS – a group that includes all HCA's in the fabric.

## Port Groups Policy Examples

```
port-group
name: grp3
use: Subtract of groups grp1 and grp2
subtract-rule: grp1, grp2
end-port-group
```

```
port-group
name: grp1
```

```
port-guid: 0x281, 0x282, 0x283
end-port-group

port-group
name: grp2
port-guid-range: 0x282-0x286
port-name: hostname=server1 port=1
end-port-group

port-group
name: grp4
port-name: hostname=kika port=1 hca_idx=1
end-port-group

port-group
name: grp3
union-rule: grp3, grp4
end-port-group
```

## Defining Topologies Policy File

In order to define a port group policy file, set the parameter 'topo\_policy\_file' in the opensm configuration file.

```
/opt/ufm/files/conf/opensm/topo_policy_file.conf
```

## Configuring Topology Policy

The topologies policy file details a list of topologies. The policy file should be composed of one or more paragraphs which define a topology. Each paragraph should begin with the line 'topology' and end with the line 'end-topology'.

For example:

```
topology
...topology qualifiers...
end-topology
```

## Topology Qualifiers

### Note

Unlike topology and end-topology which do not require a colon, all qualifiers must end with a colon (:). Also – a colon is a predefined mark that must not be used inside qualifier values. An inclusion of a column in the qualifier values will result in the policy's failure.

All topology qualifiers are mandatory. Absence of any of the below qualifiers will cause the policy parsing to fail.

Parameter	Description	Example
id	Topology ID. Legal Values – any positive value. Must be unique.	id: 1
sw-grp	Name of the port group that includes all switches and switch ports to be used in this topology.	sw-grp: some_switches
hca-grp	Name of the port group that includes all HCA's to be used in this topology.	hca-grp: some_hosts

## Configuration File per Routing Engine

Each engine in the routing chain can be provided by its own configuration file. Routing engine configuration file is the fraction of parameters defined in the main opensm

configuration file.

Some rules should be applied when defining a particular configuration file for a routing engine:

- Parameters that are not specified in specific routing engine configuration file are inherited from the main opensm configuration file.
- The following configuration parameters are taking effect only in the main opensm configuration file:
  - qos and qos\_\* settings like (vl\_arb, sl2vl, etc.)
  - lmc
  - routing\_engine

## Defining Routing Chain Policy File

In order to define a port group policy file, set the parameter 'rch\_policy\_file' in the opensm configuration file, as follows:

```
/opt/ufm/files/conf/opensm/routing_chains_policy.conf
```

## First Routing Engine in Chain

The first unicast engine in a routing chain must include all switches and HCA's in the fabric (topology id must be 0). The path-bit parameter value is path-bit 0 and it cannot be changed.

## Configuring Routing Chains Policy

The routing chains policy file details the routing engines (and their fallback engines) used for the fabric's routing. The policy file should be composed of one or more paragraphs which defines an engine (or a fallback engine). Each paragraph should begin with the line 'unicast-step' and end with the line 'end-unicast-step'.

For example:

```
unicast-step
...routing engine qualifiers...
end-unicast-step
```

## Routing Engine Qualifiers

### Note

Unlike unicast-step and end-unicast-step which do not require a colon, all qualifiers must end with a colon (':'). Also – a colon is a predefined mark that must not be used inside qualifier values. An inclusion of a colon in the qualifier values will result in the policy's failure.

Parameter	Description	Example
id	<p>'id' is mandatory. Without an id qualifier for each engine, the policy fails.</p> <ul style="list-style-type: none"><li>• Legal values – size_t value (0 is illegal).</li><li>• The engines in the policy chain are set according to an ascending id order, so it is highly crucial to verify that the id that is given to the engines match the order in which you would like the engines to be set.</li></ul>	is: 1
engine	<p>This is a mandatory qualifier that describes the routing algorithm used within this unicast step.</p> <p>Currently, on the first phase of routing chains, legal values are minhop/ftree/updn.</p>	engine: minhop

Parameter	Description	Example
use	This is an optional qualifier that enables one to describe the usage of this unicast step. If undefined, an empty string is used as a default.	use: ftree routing for cluster 1
config	This is an optional qualifier that enables one to define a separate opensm config file for a specific unicast step. If undefined, all parameters are taken from main opensm configuration file.	config: /etc/confi g/opensm 2.cfg
topology	<p>Define the topology that this engine uses.</p> <ul style="list-style-type: none"> <li>• Legal value – id of an existing topology that is defined in topologies policy (or zero that represents the entire fabric and not a specific topology).</li> <li>• Default value – If unspecified, a routing engine will relate to the entire fabric (as if topology zero was defined).</li> <li>• Notice: The first routing engine (the engine with the lowest id) MUST be configured with topology: 0 (entire fabric) or else, the routing chain algorithm will fail.</li> </ul>	topology: 1
fallback-to	<p>This is an optional qualifier that enables one to define the current unicast step as a fallback to another unicast step. This can be done by defining the id of the unicast step that this step is a fallback to.</p> <ul style="list-style-type: none"> <li>• If undefined, the current unicast step is not a fallback.</li> <li>• If the value of this qualifier is a non-existent engine id, this step will be ignored.</li> <li>• A fallback step is meaningless if the step it is a fallback to did not fail.</li> <li>• It is impossible to define a fallback to a fallback step (such definition will be ignored)</li> </ul>	-
path-bit	<p>This is an optional qualifier that enables one to define a specific lid offset to be used by the current unicast step. Setting lmc &gt; 0 in main opensm configuration file is a prerequisite for assigning specific path-bit for the routing engine.</p> <p>Default value is 0 (if path-bit is not specified)</p>	Path-bit: 1

## Dump Files per Routing Engine

Each routing engine on the chain will dump its own data files if the appropriate `log_flags` is set (for instance `0x43`).

- The files that are dumped by each engine are:
  - `opensm-lid-matrix.dump`
  - `opensm-lfts.dump`
  - `opensm.fdb`
  - `opensm-subnet.lst`

These files should contain the relevant data for each engine topology.

### **Note**

`sl2vl` and `mcfdb` files are dumped only once for the entire fabric and NOT by every routing engine.

- Each engine concatenates its ID and routing algorithm name in its dump file names, as follows:
  - `opensm-lid-matrix.2.minhop.dump`
  - `opensm.fdb.3.ftree`
  - `opensm-subnet.4.updn.lst`
- If a fallback routing engine is used, both the routing engine that failed and the fallback engine that replaces it, dump their data.

If, for example, engine 2 runs `ftree` and it has a fallback engine with 3 as its id that runs `minhop`, one should expect to find 2 sets of dump files, one for each engine:

- `opensm-lid-matrix.2.ftree.dump`
- `opensm-lid-matrix.3.minhop.dump`
- `opensm.fdb.2.ftree`

- opensm.fdfs.3.munhop

## Appendix – Adaptive Routing

### Note

As of UFM v6.4, Adaptive Routing plugin is no longer required for Adaptive Routing and SHIELD configuration. AR is now part of the core Subnet Manager implementation. However, upgrading UFM to v6.4 from an earlier version using the AR plugin will remain possible.

For information on how to set up AR and SHIELD, please refer to [How-To Configure Adaptive Routing and Self Healing Networking](#).

## Appendix – Security Features

### SA Enhanced Trust Model (SAETM)

Standard SA has a concept of trust-based requests on the SA\_Key that is part of each SA MAD. A **trusted request** is when the SA\_Key value is not equal to zero but equals the SA configured value, while an **untrusted request** is when the SA\_Key value equals zero in the request. If a request has a non-zero SA\_Key value that is different from the configured SA key, it will be dropped and reported.

When SAETM is enabled, the SA limits the set of untrusted requests allowed. Untrusted requests that are not allowed according to SAETM will be silently dropped (for the set of untrusted requests allowed, see [the following section](#) below).

SAETM feature is disabled by default. To enable it, set the sa\_enhanced\_trust\_model parameter to TRUE.

#### ***Additional SAETM Configuration Parameters***

Parameter	Description
sa_etm_allow_untrusted_guidinfo_rec	Defines whether to allow GUIDInfoRecord as part of the SAETM set of untrusted requests allowed (see <a href="#">section below</a> )
sa_etm_allow_guidinfo_rec_by_vf	Defines whether to drop GUIDInfoRecord from non-physical ports (see <a href="#">section below</a> )
sa_etm_allow_untrusted_proxy_requests	Defines the behavior for proxy requests (see <a href="#">section below</a> )
sa_etm_max_num_mcs/ sa_etm_max_num_srvcs/ sa_etm_max_num_event_subs	Defines the registration limits in SAETM (see <a href="#">section below</a> )

## Set of Untrusted SA Requests Allowed

The following table lists the untrusted requests allowed when SAETM is enabled:

Request	Request Type
MCMemberRecord	Get/Set/Delete
PathRecord	Get
PathRecord	GetTable (only if both destination and source are specified (e.g. only point to point))
ServiceRecord	Get/Set/Delete
ClassPortInfo	Get
InformInfo	Set (for non-SM security traps)
GUIDInfoRecord	Set/Delete – this request can only be part of this set depending on the values of sa_etm_allow_untrusted_guidinfo_rec and sa_etm_allow_guidinfo_rec_by_vf – see elaboration below.

When `sa_etm_allow_untrusted_guidinfo_rec` is set to `FALSE` (and SAETM is enabled), the SA will drop GUIDInfoRecord Set/Delete untrusted requests.

When `sa_etm_allow_guidinfo_rec_by_vf` is set to `FALSE` (and SAETM is enabled), the SA will drop GUIDInfoRecord Set/Delete requests from non-physical ports.

If `sa_etm_allow_untrusted_guidinfo_rec=FALSE`, GUIDInfoRecord Set/Delete requests will become part of the SAETM set of untrusted requests allowed. Note that if `sa_etm_allow_guidinfo_rec_by_vf=FALSE`, the requests will only be allowed from physical ports.

## Proxy SA Requests

SA modification request (SET/DELETE) is identified as a proxy operation when the port corresponding with the requester source address (SLID from LRH/SGID from GRH) is different than the port for which the request applies:

- For MCMemberRecord, when the MCMemberRecord.PortGID field does not match the requester address
- For ServiceRecord, when the ServiceRecord.ServiceGID field does not match requester address
- For the GUIDInfoRecord, when the LID field in the RID of the record does not match the requester address

When `sa_etm_allow_untrusted_proxy_requests` is set to `FALSE` and SAETM is enabled, untrusted proxy requests will be dropped.

## Registration Limits

When any of `sa_etm_max_num_mcgs`, `sa_etm_max_num_srvcs` or `sa_etm_max_num_event_subs` parameters is set to 0, the number of this parameter's registrations can be unlimited. When the parameter's value is different than 0, attempting to exceed the maximum number of registrations will result in the request being silently dropped. Consequently, the requester and request info will be logged, and an event will be generated for the Activity Manager.

The following parameters control the maximum number of registrations:

Parameter	Description
sa_etm_max_num_m cgs	Maximum number of multicast groups per port/vport that can be registered.
sa_etm_max_num_sr vcs	Maximum number of service records per port/vport that can be registered.
sa_etm_max_num_ev ent_subs	Maximum number of event subscriptions (InformInfo) per port/vport that can be registered.

## SAETM Logging

When requesting an operation that is not part of the SAETM set of untrusted requests, it will be silently dropped and eventually written to the SM log.

The logging of the dropped MADs is repressed to not overload the OpenSM log. If the request that needs to be dropped was received from the same requester many times consecutively, OpenSM logs it only if the request number is part of the following sequence:

0, 1, 2, 5, 10, 20, 50, 100, 200... (similar to the trap log repression).

## SGID Spoofing

SA can validate requester addresses by comparing the SLID and SGID of the incoming request. SA determines the requester port by the SLID and SGID field of the request. SGID spoofing is when the SGID and SLID do not match.

When sa\_check\_sgid\_spoofing parameter is enabled, SA checks for SGID spoofing in every request that includes GRH, unless the SLID belongs to a router port in that same request. In case the request SGID does not match its SLID, the request will be dropped. The default value of this parameter is TRUE.

## M\_Key Authentication

### M\_Key Per Port

This feature increases protection on the fabric as a unique M\_Key is generated and set for each HCA, router, or switch port.

OpenSM calculates an M\_Key per port by performing a hash function on the port GUID of the device and the M\_Key configured in opensm.conf.

To enable M\_Key per port, set the parameter below in addition to the parameters listed in the [previous section](#):

```
m_key_per_port TRUE
```

## Appendix – SM Activity Report

SM can produce an activity report in a form of a dump file that details the different activities done in the SM. Activities are divided into subjects. The table below specifies the different activities currently supported in the SM activity report.

Reporting of each subject can be enabled individually using the configuration parameter `activity_report_subjects`:

- Valid values:

Comma-separated list of subjects to dump. The current supported subjects are:

- - "mc" – activity IDs 1, 2 and 8
  - "prtn" – activity IDs 3, 4, and 5
  - "virt" – activity IDs 6 and 7
  - "routing" – activity IDs 8-12

Two predefined values can be configured as well:

- "all" – dump all subjects
- "none" – disable the feature by dumping none of the subjects

- Default value: "none"

## SM Supported Activities

Activity ID	Activity Name	Additional Fields	Comments	Description
1	mcm_member	- MLid - MGid - Port Guid - Join State	Join state: 1 - Join -1 - Leave	Member joined/left MC group
2	mcg_change	- MLid - MGid - Change	Change: 0 - Create 1 - Delete	MC group created/deleted
3	prtn_guid_add	- Port Guid - PKey - Block index - Pkey Index		Guid added to partition
4	prtn_create	-PKey - Prtn Name		Partition created
5	prtn_delete	- PKey - Delete Reason	Delete Reason: 0 - empty prtn 1 - duplicate prtn 2 - sm shutdown	Partition deleted
6	port_virt_discover	- Port Guid - Top Index		Port virtualization discovered
7	vport_state_change	- Port Guid - VPort Guid - VPort Index - VNode Guid - VPort State	VPort State: 1 - Down 2 - Init 3 - ARMED 4 - Active	Vport state changed
8	mcg_tree_calc	- mlid		MCast group tree calculated
9	routing_succeed	routing engine name		Routing done successfully

Activity ID	Activity Name	Additional Fields	Comments	Description
10	routing_failed	routing engine name		Routing failed
11	ucast_cache_invalidated			ucast cache invalidated
12	ucast_cache_routing_done			ucast cache routing done

## Appendix – Diagnostic Utilities

### Note

For UFM-SDN Appliance, all the below diagnostics commands have ib prefix.

For example, for UFM-SDN Appliance, the command `ibstat` is `ib ibstat`.

### InfiniBand Diagnostics Commands

Command	Description
<code>ibstat</code>	Shows the host adapters status.
<code>ibstatus</code>	Similar to <code>ibstat</code> but implemented as a script.
<code>ibnetdiscover</code>	Scans the topology.
<code>ibaddr</code>	Shows the LID range and default GID of the target (default is the local port).
<code>ibroute</code>	Displays unicast and multicast forwarding tables of the switches.
<code>ibroutetracer</code>	Displays unicast or multicast route from source to destination.
<code>ibping</code>	Uses vendor MADs to validate connectivity between InfiniBand nodes. On exit, (IP) ping-like output is shown.

Command	Description
ibsysstat	Obtains basic information for the specific node which may be remote. This information includes: hostname, CPUs, memory utilization.
sminfo	Queries the SMInfo attribute on a node.
smpdump	A general purpose SMP utility which gets SM attributes from a specified SMA. The result is dumped in hex by default.
smpquery	Enables a basic subset of standard SMP queries including the following: node info, node description, switch info, port info. Fields are displayed in human readable format.
perfquery	Dumps (and optionally clears) the performance counters of the destination port (including error counters).
ibswitches	Scans the net or uses existing net topology file and lists all switches.
ibhosts	Scans the net or uses existing net topology file and lists all hosts.
ibnodes	Scans the net or uses existing net topology file and lists all nodes.
ibportstate	Gets the logical and physical port states of an InfiniBand port or disables or enables the port (only on a switch). Note: This tool can change port settings. Should be used with caution.
saquery	Issues SA queries.
ibdiagnet	ibdiagnet scans the fabric using directed route packets and extracts all the available information regarding its connectivity and devices.
ibnetsplit	Automatically groups hosts and creates scripts that can be run to split the network into sub-networks each containing one group of hosts.
lbqueryerrors	Queries IB spec-defined errors from all fabric ports. Note: This tool can change reset port counters Should be used with caution.
smparquery	Queries adaptive-routing related settings from a particular switch. Note: This tool can change reset port counters Should be used with caution.

## Diagnostic Tools

Model of operation: All utilities use direct MAD access to operate. Operations that require QP 0 mads only, may use direct routed mads, and therefore may work even in subnets that are not configured. Almost all utilities can operate without accessing the SM, unless GUID to lid translation is required.

# Dependencies

## Multiple port/Multiple CA support:

When no InfiniBand device or port is specified (as shown in the following example for "Local umad parameters"), the tools select the interface port to use by the following criteria:

1. The first InfiniBand ACTIVE port.
2. If not found, the first InfiniBand port that is UP (physical link up).

If a port and/or CA name is specified, the **tool** attempts to fulfill the user's request and will fail if it is not possible.

For example:

```
ibaddr          # use the 'best port'
ibaddr -C mthca1      # pick the best port from mthca1 only.
ibaddr -P 2          # use the second (active/up) port from
the first available IB device.
ibaddr -C mthca0 -P 2 # use the specified port only.
```

## Common Options & Flags

Most diagnostics take the following flags. The exact list of supported flags per utility can be found in the usage message and can be shown using `util_name -h` syntax.

```
# Debugging flags
-d  raise the IB debugging level. May be used several times (-
ddd or -d -d -d).
-e  show umad send receive errors (timeouts and others)
-h  show the usage message
-v  increase the application verbosity level.
    May be used several times (-vv or -v -v -v)
-V  show the internal version info.
```

```

# Addressing flags
-D          use directed path address arguments.
           The path is a comma separated list of out ports.
           Examples:
           "0"    # self port
           "0,1,2,1,4"  # out via port 1, then 2, ...
-G          use GUID address arguments.
           In most cases, it is the Port GUID.
           Examples:
           "0x08f1040023"
-s <smlid>  use 'smlid' as the target lid for SA queries.

```

```

# Local umad parameters:
-C <ca_name>    use the specified ca_name.
-P <ca_port>    use the specified ca_port.
-t <timeout_ms> override the default timeout for the
                solicited mads.

```

**CLI notation:** all utilities use the POSIX style notation, meaning that all options (flags) must precede all arguments (parameters).

## Utilities Descriptions

### ibstatus

A script that displays basic information obtained from the local InfiniBand driver. Output includes LID, SMLID, port state, link width active, and port physical state.

Syntax

```
ibstatus [-h] [devname[:port]]
```

Examples:

```
ibstatus                # display status of all IB ports
ibstatus mthca1         # status of mthca1 ports
ibstatus mthca1:1 mthca0:2 # show status of specified ports
```

See also: `ibstat`

## **ibstat**

Similar to the `ibstatus` utility but implemented as a binary and not as a script. Includes options to list CAs and/or ports.

Syntax

```
ibstat [-d(ebug) -l(ist_of_cas) -p(ort_list) -s(hort)] <ca_name>
[portnum]
```

Examples:

```
ibstat                # display status of all IB ports
ibstat mthca1         # status of mthca1 ports
ibstat mthca1 2       # show status of specified ports
ibstat -p mthca0     # list the port guids of mthca0
ibstat -l             # list all CA names
```

See also: `ibstatus`

## **ibroute**

Uses SMPs to display the forwarding tables (unicast (LinearForwardingTable or LFT) or multicast (MulticastForwardingTable or MFT)) for the specified switch LID and the optional lid (mlid) range. The default range is all valid entries in the range 1...FDBTop.

## Syntax

```
ibroute [options] <switch_addr> [<startlid> [<endlid>]]
```

## Nonstandard flags:

```
-a          show all lids in range, even invalid entries.
-n          do not try to resolve destinations.
-M          show multicast forwarding tables. In this case
the range  parameters are specifying mlid range.
node-name-map  node name map file
```

## Examples:

```
ibroute 2          # dump all valid entries of switch lid 2
ibroute 2 15       # dump entries in the range 15...FDBTop.
ibroute -a 2 10 20 # dump all entries in the range 10..20
ibroute -n 2       # simple format
ibroute -M 2       # show multicast tables
```

See also: `ibtracert`

## **ibtracert**

Uses SMPs to trace the path from a source GID/LID to a destination GID/LID. Each hop along the path is displayed until the destination is reached or a hop does not respond. By using the `-m` option, multicast path tracing can be performed between source and destination nodes.

## Syntax

```
ibtracert [options] <src-addr> <dest-addr>
```

Nonstandard flags:

```
-n                simple format; don't show additional information.  
-m <mlid>        show the multicast trace of the specified mlid.  
-f <force>       force  
node-name-map    node name map file
```

Examples:

```
ibtracert 2 23          # show trace between lid 2 and 23  
ibtracert -m 0xc000 3 5 # show multicast trace between lid 3  
and 5 for mcast lid 0xc000.
```

## **smpquery**

Enables a basic subset of standard SMP queries including the following node info, node description, switch info, port info. Fields are displayed in human readable format.

Syntax

```
smpquery [options] <op> <dest_addr> [op_params]
```

Currently supported operations and their parameters:

```
nodeinfo <addr>  
nodedesc <addr>  
portinfo <addr> [<portnum>] # default port is zero
```

```
switchinfo <addr>
pkeys <addr> [<portnum>]
sl2vl <addr> [<portnum>]
vlarb <addr> [<portnum>]
GUIDInfo (GI) <addr>
MlnxExtPortInfo (MEPI) <addr> [<portnum>]
Combined (-c) : use Combined route address argument
node-name-map : node name map file
extended (-x) : use extended speeds
```

Examples:

```
smpquery nodeinfo 2          # show nodeinfo for lid 2
smpquery portinfo 2 5       # show portinfo for lid 2 port 5
```

## **smpdump**

A general purpose SMP utility that gets SM attributes from a specified SMA. The result is dumped in hex by default.

Syntax

```
smpdump [options] <dest_addr> <attr> [mod]
```

Nonstandard flags:

```
-s          show output as string
```

Examples:

```
smpdump -D 0,1,2 0x15 2      # port info, port 2
smpdump 3 0x15 2            # port info, lid 3 port 2
```

## **ibaddr**

Can be used to show the LID and GUID addresses of the specified port or the local port by default. This utility can be used as simple address resolver.

Syntax

```
ibaddr [options] [<dest_addr>]
```

Nonstandard flags:

```
gid_show (-g) : show gid address only
lid_show (-l) : show lid range only
Lid_show (-L) : show lid range (in decimal) only
```

Examples:

```
ibaddr          # show local address
ibaddr 2        # show address of the specified port lid
ibaddr -G 0x8f1040023 # show address of the specified port guid
```

## **sminfo**

Issues and dumps the output of an sminfo query in human readable format. The target SM is the one listed in the local port info or the SM specified by the optional SM LID or by the SM direct routed path.

## **Warning**

CAUTION: Using `sminfo` for any purpose other than a simple query might result in a malfunction of the target SM.

### Syntax

```
sminfo [options] <sm_lid|sm_dr_path> [sminfo_modifier]
```

### Nonstandard flags:

```
-s <state>           # use the specified state in sminfo mad  
-p <priority>        # use the specified priority in sminfo mad  
-a <activity>        # use the specified activity in sminfo mad
```

### Examples:

```
sminfo                # show sminfo of SM listed in local portinfo  
sminfo 2              # query SM on port lid 2
```

## **perfquery**

Uses PerfMgt GMPs to obtain the PortCounters (basic performance and error counters) from the Performance Management Agent (PMA) at the node specified. Optionally show aggregated counters for all ports of node. Also, optionally, reset after read, or only reset counters.

```
perfquery [options] [<lid|guid> [[port] [reset_mask]]]
```

## Nonstandard flags:

```
-a                Shows aggregated counters for all ports
of the destination lid.
-r                Resets counters after read.
-R                Resets only counters.
Extended (-x)    Shows extended port counters
Xmtsl (-X)       Shows Xmt SL port counters
Rcvsl ,(-S)      Shows Rcv SL port counters
Xmtdisc (-D)     Shows Xmt Discard Details
rcvrr, (-E)      Shows Rcv Error Details
extended_speeds (-T) Shows port extended speeds counters
oprvcvcounters  Shows Rcv Counters per Op code
flowctlcounters Shows flow control counters
vloppackets     Shows packets received per Op code per VL
vlopdata        Shows data received per Op code per VL
vlxmitflowctlerrors Shows flow control update errors per VL
vlxmitcounters  Shows ticks waiting to transmit counters per VL
swportvlcong    Shows sw port VL congestion
rcvcc           Shows Rcv congestion control counters
slrcvfecn       Shows SL Rcv FECN counters
slrcvbecn       Shows SL Rcv BECN counters
xmitcc          Shows Xmit congestion control counters
vlxmittimecc    Shows VL Xmit Time congestion control counters
smpctl (-c)     Shows samples control
loop_ports (-l) Iterates through each port
```

## Examples:

```
perfquery        # read local port's performance counters
perfquery 32 1   # read performance counters from lid 32,
port 1
```

```
perfquery -a 32          # read from lid 32 aggregated performance
counters
perfquery -r 32 1       # read performance counters from lid 32
port 1 and reset
perfquery -R 32 1      # reset performance counters of lid 32 port
1 only
perfquery -R -a 32     # reset performance counters of all lid 32
ports
perfquery -R 32 2 0xf000 # reset only non-error counters of lid
32 port 2
```

## ibping

Uses vendor mads to validate connectivity between InfiniBand nodes. On exit, (IP) ping like output is show. `ibping` is run as client/server. The default is to run as client. Note also that a default ping server is implemented within the kernel.

Syntax

```
ibping [options] <dest lid|guid>
```

Nonstandard flags:

```
-c <count>          stop after count packets
-f                  flood destination: send packets back to back w/o
delay
-o <oui>           use specified OUI number to multiplex vendor MADs
-S                 start in server mode (do not return)
```

## ibnetdiscover

Performs InfiniBand subnet discovery and outputs a human readable topology file. GUIDs, node types, and port numbers are displayed as well as port LIDs and node descriptions. All nodes (and links) are displayed (full topology). This utility can also be used to list the

current connected nodes. The output is printed to the standard output unless a topology file is specified.

#### Syntax

```
ibnetdiscover [options] [<topology-filename>]
```

#### Nonstandard flags:

```
l      Lists connected nodes
H      Lists connected HCAs
S      Lists connected switches
g      Groups
full (-f)      Shows full information (ports' speed and width,
               vlcaps)
show (-s)      Shows more information
Router_list (-R) Lists connected routers
node-name-map  Nodes name map file
cache filename to cache ibnetdiscover data to
load-cache filename of ibnetdiscover cache to load
diff filename of ibnetdiscover cache to diff
diffcheck     Specifies checks to execute for --diff
ports : (-p)  Obtains a ports report
max_hops (-m) Reports max hops discovered by the library
outstanding_smps (-o) Specifies the number of outstanding SMP's
               which should be issued during the scan
```

#### **ibhosts**

Traces the InfiniBand subnet topology or uses an already saved topology file to extract the CA nodes.

#### Syntax

```
ibhosts [-h] [<topology-file>]
```

Dependencies: ibnetdiscover, ibnetdiscover format

### **ibswitches**

Traces the InfiniBand subnet topology or uses an already saved topology file to extract the InfiniBand switches.

Syntax

```
ibswitches [-h] [<topology-file>]
```

Dependencies: ibnetdiscover, ibnetdiscover format

### **ibportstate**

Enables the port state and port physical state of an InfiniBand port to be queried or a switch port to be disabled or enabled.

Syntax

```
ibportstate [-d(ebug) -e(rr_show) -v(erbose) -D(irect) -G(uid) -s  
smlid -V(ersion) -C ca_name -P ca_port -t timeout_ms] <dest  
dr_path|lid|guid> <portnum> [<op>]
```

Supported ops: enable, disable, query, on, off, reset, speed, espeed, fdr10, width, down, arm, active, vls, mtu, lid, smlid, lmc, mkey, mkeylease, mkeyprot

Examples:

```
ibportstate 3 1 disable # by lid  
ibportstate -G 0x2C9000100D051 1 enable # by guid
```

```
ibportstate -D 0 1 # by direct route
```

## ibnodes

Uses the current InfiniBand subnet topology or an already saved topology file and extracts the InfiniBand nodes (CAs and switches).

Syntax

```
ibnodes [<topology-file>]
```

Dependencies: ibnetdiscover, ibnetdiscover format

## ibqueryerrors

Queries or clears the PMA error counters in PortCounters by walking the InfiniBand subnet topology.

```
ibqueryerrors [options]
```

Syntax

Options:

```
--suppress, -s <err1,err2,...>  suppress errors listed
--suppress-common, -c            suppress some of the common counters
--node-name-map <file>          node name map file
--port-guid, -G <port_guid>     report the node containing the
port
                                specified by <port_guid>
--, -S <port_guid>              Same as "-G" for backward compatibility
--Direct, -D <dr_path>         report the node containing the port
specified
                                by <dr_path>
```

```

--skip-sl          don't obtain SL to all destinations
--report-port, -r  report port link information
--threshold-file <val> specify an alternate threshold file,
default: /etc/infiniband-diags/error_thresholds
--GNDN, -R        (This option is obsolete and does
nothing)
--data            include data counters for ports with
errors
--switch          print data for switches only
--ca              print data for CA's only
--router          print data for routers only
--details         include transmit discard details
--counters        print data counters only
--clear-errors, -k Clear error counters after read
--clear-counts, -K Clear data counters after read
--load-cache <file> filename of ibnetdiscover cache to load
--outstanding_smps, -o <val> specify the number of outstanding
SMP's
                                which should be issued during the
scan
--config, -z <config> use config file, default:
/etc/infiniband-diags/ibdiag.conf
--Ca, -C <ca>      Ca name to use
--Port, -P <port>  Ca port number to use
--timeout, -t <ms> timeout in ms
--m_key, -y <key>  M_Key to use in request
--errors, -e       show send and receive errors
--verbose, -v      increase verbosity level
--debug, -d        raise debug level
--help, -h         help message
--version, -V      show version

```

## **smparquery**

Issues Adaptive routing-related queries to the fabric switch.

## Syntax

Supported ops (and aliases, [case](#) insensitive):

```
ARInfo (ARI) <addr>
ARGroupTable (ARGT) <addr> [<plft>] [<group_table>]
[<blocknum>]
ARLFTTable (ARLT) <addr> [<plft>] [<blocknum>]
PLFTInfo (PLFTI) <addr>
PLFTDef (PLFTD) <addr> [<blocknum>]
PLFTMap (PLFTM) <addr> [<plft>] [<control_map>]
PortSLToPLFTMap (PLFTP) <addr> [<blocknum>]
RNSubGroupDirectionTable (DIRT) <addr> [<blocknum>]
RNGenStringTable (GSTR) <addr> [<plft>] [<blocknum>]
RNGenBySubGroupPriority (GSGP) <addr>
RNRcvString (RSTR) <addr> [<blocknum>]
RNXmitPortMask (RNXM) <addr> [<blocknum>]
PortRNCounters (RNPC) <addr>
```

Options:

Main

```
-C|--Ca <ca>           : Ca name to use
-P|--Port <port>       : Ca port number to use
-D|--Direct            : use Direct address
```

argument

```
-L|--Lid               : use LID address argument
-h|--help              : help message
-V|--version           : show version
-d|--debug             : Print debug logs
```

### **saquery**

Issues SA queries.

## Syntax

```
saquery [-h -d -P -N -L -G -s -g] [<name>]
```

Queries node records by default.

d	Enables debugging
P	Gets PathRecord info
N	Gets NodeRecord info
L (-L)	Returns just the Lid of the name specified
G (-G)	Returns just the Guid of the name specified
S (-S)	Returns the PortInfoRecords with isSM capability mask bit on
G (-g)	Gets multicast group info
L (-l)	Returns the unique Lid of the name specified
O (-O)	Returns name for the Lid specified
m( -m)	Gets multicast member info (if multicast group specified, list member GIDs only for group specified for example 'saquery -m 0xC000')
x (-x)	Gets LinkRecord info"
c (-c)	Gets the SA's class port info
S (-S)	Gets ServiceRecord info
l (-l)	Gets InformInfoRecord (subscription) info
list (-D)	the node desc of the CA's
src-to-dst (<src:dst>)	Gets a PathRecord for <src:dst> where src and dst are either node names or LIDs
sgid-to-dgid (<sgid-dgid>)	Gets a PathRecord for <sgid-dgid> where sgid and dgid are addresses in IPv6 format
node-name-map	Specifies a node name map file
smkey <val>	SA SM_Key value for the query. If non-numeric value (like 'x') is specified then saquery will prompt for a value. Default (when not specified here or in ibdiag.conf) is to use SM_Key == 0 (or \"untrusted\")
slid <lid>	Source LID (PathRecord)
dlid <lid>	Destination LID (PathRecord)
mild <lid>	Multicast LID (MCMemberRecord)
sgid <gid>	Source GID (IPv6 format) (PathRecord)
dgid <gid>	Destination GID (IPv6 format) (PathRecord)
gid <gid>	Port GID (MCMemberRecord)
mgid <gid>	Multicast GID (MCMemberRecord)
Reversible", 'r', 1, NULL"	Reversible path (PathRecord)
numb_path ", 'n', 1, NULL"	Number of paths (PathRecord)
pkey: P_Key (PathRecord, MCMemberRecord).	QoS Class (PathRecord)
qos_class (-Q)	Service level (PathRecord, MCMemberRecord)
sl	MTU and selector (PathRecord, MCMemberRecord)
mtu : (-M)	Rate and selector (PathRecord, MCMemberRecord)
rate (-R)	Packet lifetime and selector (PathRecord, MCMemberRecord)
pkt_lifetime	If non-numeric value (like 'x') is specified then saquery will prompt for a value.
	Traffic Class (PathRecord, MCMemberRecord)
	Flow Label (PathRecord, MCMemberRecord)

qkey (-q) (PathRecord, MCMemberRecord).	Hop limit (PathRecord, MCMemberRecord) Scope (MCMemberRecord) Join state (MCMemberRecord)
tclass (-T)	Proxy join (MCMemberRecord)
flow_label : (-F)	ServiceID (PathRecord)
hop_limit : (-H)	
scope	
join_state (-J)	
proxy_join (-X)	
service_id	

Dependencies: OpenSM libvendor, OpenSM libopensm, libibumad

## ibsysstat

```
ibsysstat [options] <dest lid|guid> [<op>]
```

Nonstandard flags:

Current supported operations:

```
ping - verify connectivity to server (default)
host - obtain host information from server
cpu - obtain cpu information from server
-o <oui>    use specified OUI number to multiplex vendor mads
-S         start in server mode (do not return)
```

## ibnetsplit

Automatically groups hosts and creates scripts that can be run in order to split the network into sub-networks containing one group of hosts.

Syntax

- Group:

```
ibnetsplit [-v][-h][-g grp-file] -s <.lst|.net|.topo> <-r
```

```
head-ports|-d max-dist>
```

- Split:

```
ibnetsplit [-v][-h][-g grp-file] -s <.lst|.net|.topo>  
-o out-dir
```

- Combined:

```
ibnetsplit [-v][-h][-g grp-file] -s <.lst|.net|.topo> <-r  
head-ports|-d max-dist> -o out-dir
```

## Usage

- Grouping:

The grouping is performed if the -r or -d options are provided.

- If the -r is provided with a file containing group head ports, the algorithm examines the hosts distance from the set of node ports provided in the head-ports file (these are expected to be the ports running standby SM's).
- If the -d is provided with a maximum distance of the hosts in each group, the algorithm partition the hosts by that distance.

### **Note**

This method of analyzation may not be suitable for some topologies.

The results of the identified groups are printed into the file defined by the -g option (default ibnetsplit.groups) and can be manually edited. For groups where the head

port is a switch, the group file uses the FIRST host port as the port to run the isolation script from.

- Splitting:
  - If the -o flag is included, this algorithm analyzes the MinHop table of the topology and identifies the set of links and switches that may potentially be used for routing each group ports. The cross-switch links between switches of the group to other switches are declared as split-links and the commands to turn them off using Directed Routes from the original Group Head ports are written into the out-dir provided by the -o flag.

Both stages require a subnet definition file to be provided by the -s flag. The supported formats for subnet definition are:

- \*.net - for ibnetdiscover
- \*.lst - for opensm-subnet.lst or ibiagnet.lst
- \*.topo - for a topology file

#### HEAD PORTS FILE

This file is provided by the user and defines the ports by which grouping of the other host ports is defined.

#### **Format:**

Each line should contain either the name or the GUID of a single port. For switches the port number shall be 0.

```
<node-name>/P<port-num> | <PGUID>
```

#### GROUPS FILE

This file is generated by the program if the head-ports file is provided to it. Alternatively it can be provided (or edited) by the user if different grouping is desired. The generated script for isolating or connecting the group should be run from the first node in each group.

Format:

Each line may be either:

```
GROUP: <group name>  
<node-name>/P<port-num> | <PGUID>
```

## **ibdiagnet**

ibdiagnet scans the fabric using directed route packets and extracts all the available information regarding its connectivity and devices.

It then produces the following files in the output directory (see below):

- "ibdiagnet2.log" - A log file with detailed information.
- "ibdiagnet2.db\_csv" - A dump of the internal tool database.
- "ibdiagnet2.lst" - A list of all the nodes, ports and links in the fabric.
- "[ibdiagnet2.pm](#)" - A dump of all the nodes PM counters.
- "ibdiagnet2.mlnx\_cntrs" - A dump of all the nodes Mellanox diagnostic counters.
- "ibdiagnet2.net\_dump" - A dump of all the links and their features.
- "ibdiagnet2.pkey" - A list of all pkeys found in the fabric.
- "ibdiagnet2.aguid" - A list of all alias GUIDs found in the fabric.
- "[ibdiagnet2.sm](#)" - A dump of all the SM (state and priority) in the fabric.
- "ibdiagnet2.fdfs" - A dump of unicast forwarding tables of the fabric switches.
- "ibdiagnet2.mcfdfs" - A dump of multicast forwarding tables of the fabric switches.
- "ibdiagnet2.slvl" - A dump of SLVL tables of the fabric switches.
- "ibdiagnet2.nodes\_info" - A dump of all the nodes vendor specific general information for nodes who supports it.
- "ibdiagnet2.plft" - A dump of Private LFT Mapping of the fabric switches.
- "[ibdiagnet2.ar](#)" - A dump of Adaptive Routing configuration of the fabric switches.

- "ibdiagnet2.vl2vl" - A dump of VL to VL configuration of the fabric switches.

### Load plugins from:

**/tmp/ibutils2/share/ibdiagnet2.1.1/plugins/**

**You can specify additional paths to be looked in with "IBDIAGNET\_PLUGINS\_PATH" env variable.**

Plugin Name	Result	Comment
libibdiagnet_cable_diag_plugin-2.1.1	Succeeded	Plugin loaded
libibdiagnet_phy_diag_plugin-2.1.1	Succeeded	Plugin loaded

### Syntax

```
[-i|--device <dev-name>] [-p|--port <port-num>]
[-g|--guid <GUID in hex>] [--skip <stage>]
[--skip_plugin <library name>] [--sc]
[--scr] [--pc] [-P|--counter <<PM>=<value>>]
[--pm_pause_time <seconds>] [--ber_test]
[--ber_thresh <value>] [--llr_active_cell <64|128>]
[--extended_speeds <dev-type>] [--pm_per_lane]
[--ls <2.5|5|10|14|25|FDR10|EDR20>]
[--lw <1x|4x|8x|12x>] [--screen_num_errs <num>]
[--smp_window <num>] [--gmp_window <num>]
[--max_hops <max-hops>] [--read_capability <file name>]
[--write_capability <file name>]
[--back_compat_db <version.sub_version>]
[-V|--version] [-h|--help] [-H|--deep_help]
[--virtual] [--mads_timeout <mads-timeout>]
[--mads_retries <mads-retries>] [-m|--map <map-file>]
[--vlr <file>] [-r|--routing] [--r_opt <[vs,][mcast,]>]
[--sa_dump <file>] [-u|--fat_tree]
[--scope <file.guid>] [--exclude_scope <file.guid>]
[-w|--write_topo_file <file name>]
```

```

[-t|--topo_file <file>] [--out_ibnl_dir <directory>]
[-o|--output_path <directory>]
Cable Diagnostic (Plugin)
[--get_cable_info] [--cable_info_disconnected]
Phy Diagnostic (Plugin)
[--get_phy_info] [--reset_phy_info]

```

## Options

```

-i|--device <dev-name>           : Specifies the name of the device
of the port                       used to connect to the IB fabric
                                   (in case
                                   of multiple devices on he local
                                   system).
-p|--port <port-num>             : Specifies the local device's port
number                             used to connect to the IB fabric.
-g|--guid <GUID in hex>          : Specifies the local port GUID
value of the                       port used to connect to the IB
fabric. If                          GUID given is 0 than ibdiagnet
displays                            a list of possible port GUIDs and
waits                               for user input.
--skip <stage>                   : Skip the executions of the given
stage.                               Applicable skip stages
(vs_cap_smp                       vs_cap_gmp | links | pm |
                                   speed_width_check | all).

```

```

--skip_plugin <library name> : Skip the load of the given
library name.

Applicable skip plugins:
(libibdiagnet_cable_diag_plugin-
2.1.1 |
libibdiagnet_phy_diag_plugin-
2.1.1).
--sc : Provides a report of Mellanox
counters
--scr : Reset all the Mellanox
counters (if -sc
option selected).
--pc : Reset all the fabric PM
counters.
-P|--counter <<PM>=<value>> : If any of the provided PM is
greater than
its provided value than print
it.
--pm_pause_time <seconds> : Specifies the seconds to wait
between
first counters sample and
second counters
sample. If seconds given is 0
than no
second counters sample will be
done.
(default=1).
--ber_test :Provides a BER test for each
port.
Calculate BER for each port
and check no
BER value has exceeds the BER
threshold.
(default threshold="10^-12").
--ber_thresh <value> :Specifies the threshold value
for the

```

number of the

Example: for

0 than all

be

--llr\_active\_cell <64|128>  
cell size

active in the

--extended\_speeds <dev-type>  
extended speeds

all).

--pm\_per\_lane  
(when

--ls <0|2.5|5|10|14|25|50|100|FDR10>  
link speed.

--lw <1x|4x|8x|12x>  
link width.

--screen\_num\_errs <num>  
for printing

(default=5).

--smp\_window <num>  
(default=8).

--gmp\_window <num>  
(default=128).

BER test. The reciprocal

BER should be provided.

$10^{-12}$  than value need to be  
1000000000000 or 0xe8d4a51000  
( $10^{12}$ ). If threshold given is

BER values for all ports will

reported.

: Specifies the LLR active

for BER test, when LLR is

fabric.

: Collect and test port

counters. dev-type: (sw |

: List all counters per lane

available).

: Specifies the expected

: Specifies the expected

: Specifies the threshold

errors to screen.

: Max smp MADs on wire.

: Max gmp MADs on wire.

<p>--max_hops &lt;max-hops&gt; for the  (default=64). --read_capability &lt;file name&gt;  capability  fabric.  mapping for  sending. --write_capability &lt;file name&gt; for  configuration,  capability  --back_compat_db &lt;version.sub_version&gt;  according to  version 2.0. -V --version tool. -h --help (without  -H --deep_help information  --virtual discovery</p>	<p>: Specifies the maximum hops discovery process.  : Specifies capability masks configuration file, giving mask configuration for the ibdiagnet will use this Vendor Specific MADs  : Write out an example file capability masks and also the default masks for some devices.  : Show ports section in "ibdiagnet2.db_csv" given version. Default  : Prints the version of the tool. : Prints help information plugins help if exists). : Prints deep help (including plugins help). : Discover VPorts during stage.</p>
---	---

```

--mads_timeout <mads-timeout> : Specifies the timeout (in
and received                    milliseconds) for sent
                                mads. (default=500).
--mads_retries <mads-retries> : Specifies the number of
retries for                      every timeout mad.
                                (default=2).
-m|--map <map-file> : Specifies mapping file,
that maps                        node guid to name
                                (format: 0x[0-9a-fA-F]+
"node").
                                Mapping file can also be
specified by                      Environment variable
                                "IBUTILS_NODE_NAME_MAP_FILE_PATH".
--src_lid <src-lid> : source lid
--dest_lid <dest-lid> : destination lid
--dr_path <dr-path> : direct route path
-o|--output_path <directory> : Specifies the directory
where the                        Output files will be
placed.
                                (default="/var/tmp/ibdiagpath/").
Cable Diagnostic (Plugin)
--get_cable_info : Indicates to query all
QSFP cables                    for cable information.
                                information will be
Cable                            stored
                                in "ibdiagnet2.cables".
stored

```

```

--cable_info_disconnected      : Get cable info on
disconnected                    ports.

Phy Diagnostic (Plugin)
--get_phy_info                  : Indicates to query all
ports for phy                    information.

--reset_phy_info                : Indicates to clear all
ports phy                          information.

```

### Cable Diagnostic (Plugin):

This plugin performs cable diagnostic. It can collect cable info (vendor, PN, OUI etc..) on each valid QSFP cable, if specified.

It produces the following files in the output directory (see below):

- "ibdiagnet2.cables" - In case specified to collect cable info, this file will contain all collected cable info.

### Phy Diagnostic (Plugin)

This plugin performs phy diagnostic.

### Load Plugins from:

```
/tmp/ibutils2/share/ibdiagnet2.1.1/plugins/
```

You can specify additional paths to be looked in with "IBDIAGNET\_PLUGINS\_PATH" env variableLoad plugins from:

Plugin Name	Result	Comment
libibdiagnet_cable_diag_plugin-2.1.1 loaded	Succeeded	Plugin

libibdiagnet\_phy\_diag\_plugin-2.1.1  
loaded

Succeeded Plugin

## Syntax

```
[-i|--device <dev-name>] [-p|--port <port-num>]
[-g|--guid <GUID in hex>] [--skip <stage>]
[--skip_plugin <library name>] [--sc]
[--scr] [--pc] [-P|--counter <<PM>=<value>>]
[--pm_pause_time <seconds>] [--ber_test]
[--ber_thresh <value>] [--llr_active_cell <64|128>]
[--extended_speeds <dev-type>] [--pm_per_lane]
[--ls <2.5|5|10|14|25|FDR10|EDR20>]
[--lw <1x|4x|8x|12x>] [--screen_num_errs <num>]
[--smp_window <num>] [--gmp_window <num>]
[--max_hops <max-hops>] [--read_capability <file name>]
[--write_capability <file name>]
[--back_compat_db <version.sub_version>]
[-V|--version] [-h|--help] [-H|--deep_help]
[--virtual] [--mads_timeout <mads-timeout>]
[--mads_retries <mads-retries>] [-m|--map <map-file>]
[--src_lid <src-lid>] [--dest_lid <dest-lid>]
[--dr_path <dr-path>] [-o|--output_path <directory>]
Cable Diagnostic (Plugin)
[--get_cable_info] [--cable_info_disconnected]
Phy Diagnostic (Plugin)
[--get_phy_info] [--reset_phy_info]
```

## Options

-i --device <dev-name>	:Specifies the name of the device of the port used to connect to the IB fabric (in case of multiple devices on the local system).
-p --port <port-num>	:Specifies the local device's port number used to connect to the IB fabric. :Specifies the local port GUID value of the port used to connect to the IB fabric. If GUID given is 0 than ibdiagnet displays a list of possible port GUIDs and waits for user input.

<code>-g --guid &lt;GUID in hex&gt;</code>	:Skip the executions of the given stage. Applicable skip stages: (vs_cap_smp   vs_cap_gmp   links   pm   speed_width_check   all).
<code>--skip &lt;stage&gt;</code>	:Skip the load of the given library name. Applicable skip plugins:
<code>--skip_plugin &lt;library name&gt;</code>	(libibdiagnet_cable_diag_plugin-2.1.1   libibdiagnet_phy_diag_plugin-2.1.1).
<code>--sc</code>	:Provides a report of Mellanox counters
<code>--scr</code>	:Reset all the Mellanox counters (if -sc option selected).
<code>--pc</code>	:Reset all the fabric PM counters.
<code>-P --counter &lt;&lt;PM&gt;=&lt;value&gt;&gt;</code>	:If any of the provided PM is greater then its provided value than print it.
<code>--</code>	:Specifies the seconds to wait between first counters sample and second counters sample. If seconds given is 0 than no second counters sample will be done. (default=1).
<code>pm_pause_time &lt;seconds&gt;</code>	:Provides a BER test for each port. Calculate BER for each port and check no BER value has exceeds the BER threshold.(default threshold="10^-12").
<code>--ber_test</code>	:Specifies the threshold value for the BER test. The reciprocal number of the BER should be provided. Example: for 10^-12 than value need to be 1000000000000 or 0xe8d4a51000(10^12).If threshold given is 0 than all BER values for all ports will be reported.
<code>--ber_thresh &lt;value&gt;</code>	:Specifies the LLR active cell size for BER test, when LLR is active in the fabric.
<code>--llr_active_cell &lt;64 128&gt;</code>	:Collect and test port extended speeds counters. dev-type: (sw   all).
<code>--</code>	:Specifies the expected link speed.
<code>extended_speeds &lt;dev-type&gt;</code>	:Specifies the expected link width.
<code>--pm_per_lane</code>	:Specifies the threshold for printing errors to screen. (default=5).
<code>--ls &lt;2.5 5 10 14 25 FDR10 EDR20&gt;</code>	:Max smp MADs on wire. (default=8).
<code>--</code>	:Max gmp MADs on wire. (default=128).
<code>per_lane (when available).</code>	:Specifies the maximum hops for the discovery process.(default=64).
<code>--</code>	:Specifies capability masks configuration file, giving capability mask configuration for the fabric. ibdiagnet will use this mapping for Vendor Specific MADs sending.
<code>--lw &lt;1x 4x 8x 12x&gt;</code>	:Write out an example file for capability masks configuration, and also the default capability masks for some devices.
<code>--</code>	:Show ports section in "ibdiagnet2.db_csv" according to given version. Default version 2.0.
<code>screen_num_errs &lt;num&gt;</code>	:Prints the version of the tool.
<code>--smp_window &lt;num&gt;</code>	:Prints help information (without plugins help if exists).
<code>--gmp_window &lt;num&gt;</code>	:Prints deep help information (including plugins help).
<code>--max_hops &lt;max-hops&gt;</code>	:Discover VPorts during discovery stage.
<code>--read_capability &lt;file name&gt;</code>	:Specifies the timeout (in milliseconds) for sent and received mads.(default=500).
<code>--</code>	:Specifies the number of retries for every timeout mad.(default=2).
<code>write_capability &lt;file name&gt;</code>	:Specifies mapping file, that maps node guid to name (format: 0x[0-9a-fA-F]+ "name"). Mapping file can also be specified by environment variable "IBUTILS_NODE_NAME_MAP_FILE_PATH".
<code>--</code>	:source lid
<code>back_compat_d b</code>	:destination lid
	:direct route path
	:Specifies the directory where the output files will be placed. (default="/var/tmp/ibdiagpath/").
	:Indicates to query all QSFP cables for cable information. Cable information will be stored in "ibdiagnet2.cables".
	:Get cable info on disconnected ports.
	:Indicates to query all ports for phy information.
	:Indicates to clear all ports phy information.

```

<version.sub_ve
rsion>
-V|--version
-h|--help
-H|--deep_help
--virtual
--mads_timeout
<mads-
timeout>
--mads_retries
<mads-retries>
-m|--map
<map-file>
--src_lid <src-
lid>
--dest_lid <dest-
lid>
--dr_path <dr-
path>
-o|--
output_path
<directory>
Cable
Diagnostic
(Plugin)
--get_cable_info
--
cable_info_disco
nnected
Phy Diagnostic
(Plugin)
--get_phy_info
--reset_phy_info

```

## Appendix - Supported Port Counters and Events

Port counters and events are available in the following views:

- Events and Port Counters area, at the bottom of the UFM window
- Error window (Error tab) in the Manage Devices tab
- In the New Monitoring Session window, in the Monitor tab, when clicking Create New Session

- Event Log in the Log tab (click Show Event Log)

## InfiniBand Port Counters

The following tables list and describe the port counters and events currently supported:

- InfiniBand Port Counters
- Calculated Port Counters

<i>InfiniBand Port Counters</i>	
Counter	Description
Xmit Data (in bytes)	Total number of data octets, divided by 4, transmitted on all VLs from the port, including all octets between (and not including) the start of packet delimiter and the VCRC, and may include packets containing errors. All link packets are excluded. Results are reported as a multiple of four octets.
Rcv Data (in bytes)	Total number of data octets, divided by 4, received on all VLs at the port. All octets between (and not including) the start of packet delimiter and the VCRC are excluded and may include packets containing errors. All link packets are excluded. When the received packet length exceeds the maximum allowed packet length specified in C7-45: the counter may include all data octets exceeding this limit. Results are reported as a multiple of four octets.
Xmit Packets	Total number of packets transmitted on all VLs from the port, including packets with errors and excluding link packets.
Rcv Packets	Total number of packets, including packets containing errors and excluding link packets, received from all VLs on the port.
Rcv Errors	Total number of packets containing errors that were received on the port including: <ul style="list-style-type: none"> <li>• Local physical errors (ICRC, VCRC, LPCRC, and all physical errors that cause entry into the BAD PACKET or BAD PACKET DISCARD states of the packet receiver state machine)</li> <li>• Malformed data packet errors (LVer, length, VL)</li> <li>• Malformed link packet errors (operand, length, VL)</li> <li>• Packets discarded due to buffer overrun (overflow)</li> </ul>

*InfiniBand Port Counters*

Xmit Discards	<p>Total number of outbound packets discarded by the port when the port is down or congested for the following reasons:</p> <ul style="list-style-type: none"> <li>• Output port is not in the active state</li> <li>• Packet length has exceeded NeighborMTU</li> <li>• Switch Lifetime Limit exceeded</li> <li>• Switch HOQ Lifetime Limit exceeded, including packets discarded while in VLStalled State.</li> </ul>
Symbol Errors	<p>Total number of minor link errors detected on one or more physical lanes.</p>
Link Error Recovery	<p>Total number of times the Port Training state machine has successfully completed the link error recovery process.</p>
Link Error Downed	<p>Total number of times the Port Training state machine has failed the link error recovery process and downed the link.</p>
Local Integrity Error	<p>The number of times that the count of local physical errors exceeded the threshold specified by LocalPhyErrors</p>
Rcv Remote Physical Error	<p>Total number of packets marked with the EBP delimiter received on the port.</p>
Xmit Constraint Error	<p>Total number of packets not transmitted from the switch physical port for the following reasons:</p> <ul style="list-style-type: none"> <li>• FilterRawOutbound is true and packet is raw</li> <li>• PartitionEnforcementOutbound is true and packet fails partition key check or IP version check</li> </ul>
Rcv Constraint Error	<p>Total number of packets received on the switch physical port that are discarded for the following reasons:</p> <ul style="list-style-type: none"> <li>• FilterRawInbound is true and packet is raw</li> <li>• PartitionEnforcementInbound is true and packet fails partition key check or IP version check</li> </ul>

<i>InfiniBand Port Counters</i>	
Excess Buffer Overrun Error	The number of times that OverrunErrors consecutive flow control update periods occurred, each having at least one overrun error
Rcv Switch Relay Error	Total number of packets received on the port that were discarded when they could not be forwarded by the switch relay for the following reasons: <ul style="list-style-type: none"> <li>• DLID mapping</li> <li>• VL mapping</li> <li>• Looping (output port = input port)</li> </ul>
VL15 Dropped	Number of incoming VL15 packets dropped because of resource limitations (e.g., lack of buffers) in the port
XmitWait	The number of ticks during which the port selected by PortSelect had data to transmit but no data was sent during the entire tick because of insufficient credits or of lack of arbitration.

<i>InfiniBand Calculated Port Counters</i>	
Counter	Description
Normalized XmitData	Effective port bandwidth utilization in % XmitData incremental/ Link Capacity
Normalized Congested Bandwidth	Amount of bandwidth that was suppressed due to congestion (XmitWait incremental/ Time) * Link Capacity Separate counters are used for Tier 4 ports and for the rest of the ports.

## Supported Traps and Events

Device events are listed as VDM or CDM in the Source column of the Events table in the UFM GUI. For information about defining event policy, see [Configuring Event Management](#).

Alarm ID	Alarm Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
64	GID Address In Service	1	0	Info	1	0	Port	Fabric Notification	SM
65	GID Address Out of Service	1	0	Warning	1	0	Port	Fabric Notification	SM
66	New MCast Group Created	1	0	Info	1	0	Port	Fabric Notification	SM
67	MCast Group Deleted	1	0	Info	1	0	Port	Fabric Notification	SM
110	Symbol Error	1	1	Warning	200	0	Port	Hardware	Telemetry
111	Link Error Recovery	1	1	Minor	1	0	Port	Hardware	Telemetry
112	Link Downed	1	1	Critical	0	0	Port	Hardware	Telemetry
113	Port Receive Errors	1	1	Minor	5	0	Port	Hardware	Telemetry
114	Port Receive Remote Physical Errors	0	0	Minor	5	0	Port	Hardware	Telemetry
115	Port Receive Switch Relay Errors	1	1	Minor	50	0	Port	Fabric Configuration	Telemetry
116	Port Xmit Discards	1	1	Minor	200	0	Port	Communication Error	Telemetry
117	Port Xmit Constraint Errors	1	1	Minor	1	0	Port	Communication Error	Telemetry
118	Port Receive Constraint Errors	1	1	Minor	1	0	Port	Communication	Telemetry

Alarm ID	Alarm Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
								Error	
119	Local Link Integrity Errors	1	1	Minor	5	0	Port	Hardware	Telemetry
120	Excessive Buffer Overrun Errors	1	1	Minor	1	0	Port	Communication Error	Telemetry
121	VL15 Dropped	1	1	Minor	500	0	Port	Communication Error	Telemetry
122	Congested Bandwidth (%) Threshold Reached	1	1	Minor	10	0	Port	Hardware	Telemetry
123	Port Bandwidth (%) Threshold Reached	1	1	Minor	95	0	Port	Communication Error	Telemetry
130	Non-optimal link width	1	1	Minor	1	0	Port	Hardware	SM
134	T4 Port Congested Bandwidth	1	1	Warning	10	0	Port	Communication Error	Telemetry
141	Flow Control Update Watchdog Timer Expired	1	0	Warning	1	0	Port	Hardware	SM
144	Capability Mask Modified	1	0	Info	1	0	Port	Fabric Notification	SM
145	System Image GUID changed	1	0	Info	1	0	Port	Communication Error	SM
156	Link Speed Enforcement Disabled	1	0	Critical	0	0	Site	Fabric Notification	SM
250	Running in Limited	1	1	Critical	1	0	Grid	Mainten	Licensin

Alarm ID	Alarm Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
	Mode			l				ance	g
251	Switching to Limited Mode	1	1	Critical	1	0	Grid	Maintenance	Licensing
252	License Expired	1	1	Warning	1	0	Grid	Maintenance	Licensing
253	Duplicated licenses	1	0	Critical	1	0	Grid	Maintenance	Licensing
254	License Limit Exceeded	1	0	Critical	1	0	Grid	Maintenance	Licensing
255	License is About to Expire	1	0	Warning	1	0	Grid	Maintenance	Licensing
256	Bad M_Key	1	0	Minor	1	0	Port	Security	SM
257	Bad P_Key	1	0	Minor	1	0	Port	Security	SM
258	Bad Q_Key	1	0	Minor	1	0	Port	Security	SM
259	Bad P_Key Switch External Port	1	0	Critical	1	0	Port	Security	SM
328	Link is Up	1	1	Info	1	10	Link	Fabric Topology	SM
329	Link is Down	1	1	Warning	1	10	Site	Fabric Topology	SM
331	Node is Down	1	0	Warning	1	0	Site	Fabric Topology	SM
332	Node is Up	1	0	Info	1	0	Site	Fabric Topology	SM
336	Port Action Succeeded	1	0	Info	1	0	Port	Maintenance	UFM
337	Port Action Failed	1	0	Minor	1	0	Port	Maintenance	UFM

Alarm ID	Alarm Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
338	Device Action Succeeded	1	0	Info	1	0	Port	Maintenance	UFM
339	Device Action Failed	1	0	Minor	1	0	Port	Maintenance	UFM
344	Partial Switch ASIC Failure	1	1	Critical	1	0	Switch	Maintenance	UFM
352	Network Added	1	0	Info	1	0	Network	Logical Model	UFM
353	Network Removed	1	0	Info	1	0	Network	Logical Model	UFM
380	Switch Upgrade Error	1	1	Critical	1	0	Switch	Maintenance	UFM
381	Switch Upgrade Failed	1	0	Info	1	0	Switch	Maintenance	UFM
382	Module status NOT PRESENT	1	1	Warning	1	0	Switch	Module Status	UFM
383	Host Upgrade Failed	1	0	Info	1	0	Computer	Maintenance	UFM
384	Switch Module Powered Off	1	1	Info	1	0	Switch	Module Status	UFM
385	Switch FW Upgrade Started	1	0	Info	1	0	Switch	Maintenance	UFM
386	Switch SW Upgrade Started	1	0	Info	1	0	Switch	Maintenance	UFM
387	Switch Upgrade Finished	1	0	Info	1	0	Switch	Maintenance	UFM
388	Host FW Upgrade Started	1	0	Info	1	0	Computer	Maintenance	UFM
389	Host OFED Upgrade Started	1	0	Info	1	0	Computer	Maintenance	UFM

Alarm ID	Alarm Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
391	Switch Module Removed	1	0	Info	1	0	Switch	Fabric Notification	Switch
392	Module Temperature Threshold Reached	1	0	Info	60	0	Module	Hardware	Switch
393	Switch Module Added	1	0	Info	1	0	Switch	Fabric Notification	Switch
394	Module Status FAULT	1	1	Critical	1	0	Switch	Module Status	Switch
395	Device Action Started	1	0	Info	1	0	Port	Maintenance	UFM
396	Site Action Started	1	0	Info	1	0	Port	Maintenance	UFM
397	Site Action Failed	1	0	Minor	1	0	Port	Maintenance	UFM
398	Switch Chip Added	1	0	Info	1	0	Switch	Fabric Notification	Switch
399	Switch Chip Removed	1	0	Critical	1	0	Switch	Fabric Notification	Switch
403	Device Pending Reboot	1	1	Warning	0	0	Device	Maintenance	UFM
404	System Information is missing	1	1	Warning	1	0	Switch	Communication Error	UFM
405	Switch Identity Validation Failed	1	1	Warning	1	0	Switch	Communication Error	UFM
406	Switch System Information is missing	1	1	Warning	1	0	Switch	Communication Error	UFM

Alarm ID	Alarm Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
407	COMEX Ambient Temperature Threshold Reached	1	1	Minor	60	0	Switch	Hardware	Switch
408	Switch is Unresponsive	1	1	Critical	1	0	Switch	Communication Error	UFM
502	Device Upgrade Finished	1	0	Info	1	0	Device	Maintenance	UFM
506	Device Upgrade Finished	1	0	Info	1	0	Device	Maintenance	UFM
508	Core Dump Created	1	1	Info	1	0	Grid	Maintenance	UFM
510	SM Failover	0	1	Critical	1	0	Grid	Fabric Notification	SM
511	SM State Change	0	1	Info	1	0	Grid	Fabric Notification	SM
512	SM UP	0	1	Info	1	0	Grid	Fabric Notification	SM
513	SM System Log Message	0	1	Minor	1	0	Grid	Fabric Notification	SM
514	SM LID Change	0	1	Warning	1	0	Grid	Fabric Notification	SM
515	Fabric Health Report Info	1	1	Info	1	0	Grid	Fabric Notification	UFM
516	Fabric Health Report Warning	1	1	Warning	1	0	Grid	Fabric Notification	UFM

Alarm ID	Alarm Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
517	Fabric Health Report Error	1	1	Critical	1	0	Grid	Fabric Notification	UFM
518	UFM-related process is down	1	1	Critical	1	0	Grid	Maintenance	UFM
519	Logs purge failure	1	1	Minor	1	0	Grid	Maintenance	UFM
520	Restart of UFM-related process succeeded	1	1	Info	1	0	Grid	Maintenance	UFM
521	UFM is being stopped	1	1	Critical	1	0	Grid	Maintenance	UFM
522	UFM is being restarted	1	1	Critical	1	0	Grid	Maintenance	UFM
523	UFM failover is being attempted	1	1	Info	1	0	Grid	Maintenance	UFM
524	UFM cannot connect to DB	1	1	Critical	1	0	Grid	Maintenance	UFM
525	Disk utilization threshold reached	1	1	Critical	1	0	Grid	Maintenance	UFM
526	Memory utilization threshold reached	1	1	Critical	1	0	Grid	Maintenance	UFM
527	CPU utilization threshold reached	1	1	Critical	1	0	Grid	Maintenance	UFM
528	Fabric interface is down	1	1	Critical	1	0	Grid	Maintenance	UFM
529	UFM standby server problem	1	1	Critical	1	0	Grid	Maintenance	UFM
530	SM is down	1	1	Critical	1	0	Grid	Maintenance	UFM
531	DRBD Bad Condition	1	1	Critical	1	0	Grid	Maintenance	UFM

Alarm ID	Alarm Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
532	Remote UFM-SM Sync	1	1	Info	1	0	Grid	Maintenance	UFM
533	Remote UFM-SM problem	1	1	Critical	1	0	Site	Maintenance	UFM
536	UFM Health Watchdog Info	1	1	Info	1	0	Grid	Maintenance	UFM
537	UFM Health Watchdog Critical	1	1	Critical	1	0	Grid	Maintenance	UFM
538	Time Diff Between HA Servers	1	1	Warning	1	0	Grid	Maintenance	UFM
539	DRBD TCP Connection Performance	1	1	Warning	1	0	Grid	Maintenance	UFM
540	Daily Report Completed successfully	1	0	Info	1	0	Grid	Maintenance	UFM
541	Daily Report Completed with Error	1	0	Minor	1	0	Grid	Maintenance	UFM
542	Daily Report Failed	1	0	Critical	1	0	Grid	Maintenance	UFM
543	Daily Report Mail Sent successfully	1	0	Info	1	0	Grid	Maintenance	UFM
544	Daily Report Mail Sent Failed	1	0	Minor	1	0	Grid	Maintenance	UFM
545	SM is not responding	1	1	Critical	1	0	Grid	Maintenance	UFM
546	Management interface is down	1	1	Critical	1	0	Grid	Maintenance	UFM
547	UFM stopped polling SM for updates	1	1	Critical	1	0	Grid	Maintenance	UFM

Alarm ID	Alarm Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
548	Failed to run generic script test	1	1	Critical	1	0	Grid	Maintenance	UFM
551	General External Event Notification	1	0	Info	0	0	Grid	Maintenance	UFM
552	General External Event Notice	1	0	Minor	0	0	Grid	Maintenance	UFM
553	General External Event Alert	1	0	Warning	0	0	Grid	Maintenance	UFM
554	General External Event Error	1	0	Critical	0	0	Grid	Maintenance	UFM
560	User Connected	1	0	Info	1	0	Grid	Security	UFM
561	User Disconnected	1	0	Info	1	0	Grid	Security	UFM
602	UFM Server Failover	1	1	Critical	1	0	Site	Fabric Notification	UFM
603	Events Suppression	1	0	Critical	0	0	Site	Maintenance	UFM
604	Report Succeeded	1	1	Info	1	0	Grid	Maintenance	UFM
605	Report Failed	1	1	Critical	1	0	Grid	Maintenance	UFM
606	Correction Attempts Paused	1	0	Warning	1	0	Site	Fabric Notification	UFM
610	Monitoring History Enabled	1	0	Info	1	0	Grid	Maintenance	UFM
611	Monitoring History Disabled	1	0	Info	1	0	Grid	Maintenance	UFM
612	Monitoring History Bad Connection	1	1	Critical	1	0	Grid	Maintenance	UFM

Alarm ID	Alarm Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
613	Monitoring History Connection Established	1	0	Info	1	0	Grid	Maintenance	UFM
614	Monitoring History Inconsistent Version	1	1	Critical	1	0	Grid	Maintenance	UFM
615	Monitoring History Failed save metadata	1	1	Critical	1	0	Grid	Maintenance	UFM
616	Monitoring History Failed update metadata	1	1	Critical	1	0	Grid	Maintenance	UFM
617	Monitoring History Failed save data	1	1	Critical	1	0	Grid	Maintenance	UFM
618	Monitoring History Failed get metadata	1	1	Critical	1	0	Grid	Maintenance	UFM
619	Monitoring History Failed get data	1	1	Critical	1	0	Grid	Maintenance	UFM
620	Monitoring History Failed remove file	1	1	Critical	1	0	Grid	Maintenance	UFM
621	Monitoring History version not matches UFM version	1	1	Critical	1	0	Grid	Maintenance	UFM
622	Monitoring History Purge DB Occurred	1	1	Warning	1	0	Grid	Maintenance	UFM
623	Monitoring History Migration is not completed	1	1	Warning	1	0	Grid	Maintenance	UFM
624	Monitoring History partition utilization threshold reached	1	1	Critical	1	0	Grid	Maintenance	UFM
625	Monitoring History local report files are about to be cleaned	1	0	Info	1	0	Grid	Maintenance	UFM

Alarm ID	Alarm Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
626	Monitoring History oldest DB table is about to be removed	1	0	Info	1	0	Grid	Maintenance	UFM
627	Monitoring History partition is not mounted	1	0	Critical	1	0	Grid	Maintenance	UFM
701	Non-optimal Link Speed	1	1	Minor	1	0	Port	Hardware	UFM
702	Unhealthy IB Port	1	1	Warning	1	0	Port	Hardware	SM
703	Fabric Collector Connected	1	0	Info	1	0	Grid	Maintenance	UFM
704	Fabric Collector Disconnected	1	1	Critical	1	0	Grid	Maintenance	UFM
750	High data retransmission count on port	1	1	Warning	500	0	Port	Hardware	SM
901	Fabric Configuration Started	0	1	Info	1	0	Grid	Fabric Notification	UFM
902	Fabric Configuration Completed	0	1	Info	1	0	Grid	Fabric Notification	UFM
903	Fabric Configuration Failed	0	1	Critical	1	0	Grid	Fabric Notification	UFM
904	Device Configuration Failure	0	1	Critical	1	0	Device	Fabric Notification	UFM
905	Device Configuration Timeout	0	1	Critical	1	0	Device	Fabric Notification	UFM

Alarm ID	Alarm Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
906	Provisioning Validation Failure	0	1	Critical	1	0	Grid	Fabric Notification	UFM
907	Switch is Down	1	1	Critical	1	0	Site	Fabric Topology	UFM
908	Switch is Up	1	1	Info	1	0	Site	Fabric Topology	UFM
909	Director Switch is Down	1	1	Critical	1	0	Site	Fabric Topology	UFM
910	Director Switch is Up	1	1	Info	1	0	Site	Fabric Topology	UFM
911	Module Temperature Low Threshold Reached (Unmanaged IB switches only)	1	1	Warning	0	0	Module	Hardware	Telemetry
912	Module Temperature High Threshold Reached (Unmanaged IB switches only)	1	1	Critical	60	0	Module	Hardware	Telemetry
913	Module High Voltage	1	1	Warning	15	0	Switch	Module Status	Telemetry
914	Module High Current	1	1	Warning	10	0	Switch	Module Status	Telemetry
915	Critical BER reported	1	1	Critical	10	0	Port	Hardware	Telemetry
916	High BER reported	1	1	Warning	10	0	Port	Hardware	Telemetry

Alarm ID	Alarm Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
917	Critical Symbol BER reported	1	1	Critical	10	0	Port	Hardware	Telemetry
918	High Symbol BER reported	1	1	Warning	10	0	Port	Hardware	Telemetry
919	Cable Temperature High	1	1	Critical	1	0	Port	Hardware	UFM
920	Cable Temperature Low	1	1	Critical	1	0	Port	Hardware	UFM
1300	SA Key violation	1	1	Warning	5	0	Port	Security	SM
1301	SGID Spoofed	1	1	Warning	5	0	Port	Security	SM
1302	SA High Rate detected	1	1	Warning	5	0	Port	Security	SM
1303	Multicast subscriptions over limit	1	1	Warning	5	0	Port	Security	SM
1304	Service Record subscriptions over limit	1	1	Warning	5	0	Port	Security	SM
1305	Event subscriptions over limit	1	1	Warning	5	0	Port	Security	SM
1306	Unallowed SM was detected in the fabric	1	1	Warning	0	0	Port	Fabric Notification	SM
1307	SMInfo SET request was received from unallowed SM	1	1	Warning	0	0	Port	Fabric Notification	SM
1309	SM was detected with non-matching SMKey	1	1	Warning	0	0	Port	Fabric Notification	SM
1310	Duplicated node GUID was detected	1	1	Critical	1	0	Device	Fabric Notification	SM

Alarm ID	Alarm Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
								tion	
1311	Duplicated port GUID was detected	1	1	Critical	1	0	Port	Fabric Notification	SM
1312	Switch was Rebooted	1	1	Info	1	0	Device	Fabric Notification	UFM
1315	Topo Config File Error	1	1	Critical	1	0	Grid	Fabric Notification	UFM
1316	Topo Config Subnet Mismatch	1	1	Critical	1	0	Grid	Fabric Notification	Topodiff
1400	High Ambient Temperature	1	1	Warning	0	0	Switch	Hardware	Switch
1401	High Fluid Temperature	1	1	Warning	0	0	Switch	Hardware	Switch
1402	Low Fluid Level	1	1	Warning	0	0	Switch	Hardware	Switch
1403	Low Supply Pressure	1	1	Warning	0	0	Switch	Hardware	Switch
1404	High Supply Pressure	1	1	Warning	0	0	Switch	Hardware	Switch
1405	Low Return Pressure	1	1	Warning	0	0	Switch	Hardware	Switch
1406	High Return Pressure	1	1	Warning	0	0	Switch	Hardware	Switch
1407	High Differential Pressure	1	1	Warning	0	0	Switch	Hardware	Switch
1408	Low Differential Pressure	1	1	Warning	0	0	Switch	Hardware	Switch
140	System Fail Safe	1	1	Warning	0	0	Switch	Hardware	Switch

Alarm ID	Alarm Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
9				Warning			Switch	Hardware	
1410	Fault Critical	1	1	Critical	0	0	Switch	Hardware	Switch
1411	Fault Pump1	1	1	Critical	0	0	Switch	Hardware	Switch
1412	Fault Pump2	1	1	Critical	0	0	Switch	Hardware	Switch
1413	Fault Fluid Level Critical	1	1	Critical	0	0	Switch	Hardware	Switch
1414	Fault Fluid Over Temperature	1	1	Critical	0	0	Switch	Hardware	Switch
1415	Fault Primary DC	1	1	Critical	0	0	Switch	Hardware	Switch
1416	Fault Redundant DC	1	1	Critical	0	0	Switch	Hardware	Switch
1417	Fault Fluid Leak	1	1	Critical	0	0	Switch	Hardware	Switch
1418	Fault Sensor Failure	1	1	Critical	0	0	Switch	Hardware	Switch
1419	Cooling Device Monitoring Error	1	0	Critical	0	0	Grid	Hardware	Switch
1420	Cooling Device Communication Error	1	1	Critical	0	0	Switch	Hardware	Switch
1500	New cable detected	1	0	Info	1	0	Link	Security	UFM
1502	Cable detected in a new location	1	0	Warning	1	0	Link	Security	UFM
1503	Duplicate Cable Detected	1	0	Critical	1	0	Link	Security	UFM
1504	SHARP Allocation Succeeded	1	1	Info	1	0	Grid	SHARP	SHARP

Alarm ID	Alarm Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
1505	SHARP Allocation Failed	1	0	Warning	1	0	Grid	SHARP	SHARP
1506	SHARP Deallocation Succeeded	1	0	Info	1	0	Grid	SHARP	SHARP
1507	SHARP Deallocation Failed	1	0	Warning	1	0	Grid	SHARP	SHARP
1508	Device Collect System Dump Started	1	0	Info	1	0	Device	Maintenance	UFM
1509	Device Collect System Dump Finished	1	0	Info	1	0	Device	Maintenance	UFM
1510	Device Collect System Dump Error	1	0	Critical	1	0	Device	Maintenance	UFM
1511	Virtual Port Added	1	0	Info	1	0	Port	Fabric Notification	SM
1512	Virtual Port Removed	1	0	Warning	1	0	Port	Fabric Notification	SM
1513	Burn Cables Transceivers Started	1	0	Info	1	0	Device	Maintenance	UFM
1514	Burn Cables Transceivers Finished	1	0	Info	1	0	Device	Maintenance	UFM
1515	Burn Cables Transceivers Failed	1	0	Warning	1	0	Device	Maintenance	UFM
1516	Activate Cables Transceivers FW Finished	1	0	Info	1	0	Device	Maintenance	UFM
1517	Activate Cables Transceivers FW Failed	1	0	Warning	1	0	Device	Maintenance	UFM

Alarm ID	Alarm Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
1520	Aggregation Node Discovery Failed	1	0	Critical	1	0	SHARP AM	SHARP	SHARP
1521	Job Started	1	0	Info	1	0	SHARP AM	SHARP	SHARP
1522	Job Ended	1	0	Info	1	0	SHARP AM	SHARP	SHARP
1523	Job Start Failed	1	0	Critical	1	0	SHARP AM	SHARP	SHARP
1524	Job Error	1	0	Critical	1	0	SHARP AM	SHARP	SHARP
1525	Trap QP Error	1	0	Critical	1	0	SHARP AM	SHARP	SHARP
1526	Trap Invalid Request	1	0	Critical	1	0	SHARP AM	SHARP	SHARP
1527	Trap Sharp Error	1	0	Critical	1	0	SHARP AM	SHARP	SHARP
1528	Trap QP Alloc timeout	1	0	Critical	1	0	SHARP AM	SHARP	SHARP
1529	Trap AMKey Violation	1	0	Critical	1	0	SHARP AM	SHARP	SHARP
1530	Unsupported Trap	1	0	Critical	1	0	SHARP AM	SHARP	SHARP
1531	Reservation Updated	1	0	Info	1	0	SHARP AM	SHARP	SHARP
1532	Sharp is not Responding	1	0	Critical	1	0	SHARP AM	SHARP	SHARP
1533	Agg Node Active	1	0	Info	1	0	SHARP AM	SHARP	SHARP
1534	Agg Node Inactive	1	0	Warning	1	0	SHARP AM	SHARP	SHARP

Alarm ID	Alarm Name	To Log	Alarm	Default Severity	Default Threshold	Default TTL	Related Object	Category	Source
1535	Trap AMKey Violation Triggered by AM	1	0	Warning	1	0	SHARP AM	SHARP	SHARP
1550	GUIDs Were Added to Pkey	1	0	Info	1	0	Port	Fabric Notification	UFM
1551	GUIDs Were Removed from Pkey	1	0	Info	1	0	Port	Fabric Notification	UFM
1600	VS/CC Classes Key Violation	1	0	Warning	1	0	Port	Security	SM
1601	Tenant Access Violation	1	0	Warning	1	0	Port	Security	SM
1602	PCI Speed Degradation Warning	1	1	Critical	1	0	Port	Fabric Notification	UFM
1603	PCI Width Degradation Warning	1	1	Critical	1	0	Port	Fabric Notification	UFM
1604	Non-optimal aggregated port bandwidth	1	1	Warning	1	0	Port	Hardware	UFM
1605	Routing Engine Action Remove	1	1	Warning	1	0	Switch	Fabric Notification	UFM
1606	Routing Engine Action Recover	1	1	Info	1	0	Switch	Fabric Notification	UFM

## Appendix – Used Ports

The following is the list of ports used by the UFM Server for internal and external communication:

Port	Purpose
80(tcp), 443(tcp)	Used by WS clients (Apache Web Server)
8000(udp)	Used for UFM server listening for REST API requests (redirected by Apache web server)
6306(udp)	Used for Multicast requests – communication with latest UFM Agents
8005(udp)	Used as UFM monitoring listening port
8089(tcp)	Used for internal communication between UFM server and MonitoringHistoryEngine
8888(tcp)	Used by DRBD – communication between UFM Primary and Standby server
15800(tcp)	Used for communication with legacy UFM Agents on Mellanox Grid Director DDR switches
8081(tcp), 8082(tcp)	Used for internal communication with Subnet Manager

## Appendix – Configuration Files Auditing

The main purpose of this feature is to allow users to track changes made to selected configuration files. When activating the feature, all the changes are reflected in specific log files which contain information about the changes and when they took place.

### To activate this feature:

In *TrackConfig* section in *gv.cfg*, file value of *track\_config* key should be set to **true** and value of *track\_conf\_files* key should contain a comma-separated list of defined conf files to be tracked.

By default – ALL conf-files are tracked. To activate the feature, after *track\_config* key is set to true, the UFM server should be restarted.

Example:

```
[TrackConfig]
# track config files changes
```

```

track_config = true
# Could be selected options (comaseparated) UFM, SM, SHARP,
Telemetry. Or ALL for all the files.
track_conf_files = ALL

```

The below lists the configuration files that can be tracked:

Conf File Alias	Configuration Files
UFM	/opt/ufm/files/conf/gv.cfg
SM	/opt/ufm/files/conf/opensm/opensm.conf
SHARP	/opt/ufm/files/conf/sharp2/sharp_am.cfg
Telemetry	/opt/ufm/files/conf/telemetry/launch_ibdiagnet_config.ini
ALL	All the above configuration files.

Once the feature is activated and the UFM server is restarted, the UFM generates file which list the changes made in each of the tracked conf files. These files are located in */opt/ufm/files/auditing/* directory and the file naming convention is as follows: original conf file name with audit.log suffix.

Example: For gv.cfg, the name of the changes-tracking file is gv.cfg.audit.log. Changes are stored in auditing files in “linux diff”-like format.

Example:

```

cat /opt/ufm/files/auditing/gv.cfg.audit.log
=== Change occurred at 2022-07-24 07:31:48.679247 ===
---
+++
@@ -45,7 +45,7 @@
mon_mode_discovery_period = 60
check_interface_retry = 5
# The number of times to try if the InfiniBand fabric interface is
down. The duration of each retry is 1 second.
-ibport_check_retries = 90
+ibport_check_retries = 92

```

```
ws_address = UNDEFINED
ws_port = 8088
ws_protocol = https
```

## Appendix – IB Router


IB router provides the ability to send traffic between two or more IB subnets thereby potentially expanding the size of the network to over 40k end-ports, enabling separation and fault resilience between islands and IB subnets, and enabling connection to different topologies used by different subnets.

The forwarding between the IB subnets is performed using GRH lookup. The IB router's basic functionality includes:

- Removal of current L2 LRH (local routing header)
- Routing table lookup – using GID from GRH
- Building new LRH according to the destination according to the routing table


The DLID in the new LRH is built using simplified GID-to-LID mapping (where LID = 16 LSB bits of GID) thereby not requiring to send for ARP query/lookup.

### **Site-Local Unicast GID Format**



For this to work, the SM allocates an alias GID for each host in the fabric where the alias GID = {subnet prefix[127:64], reserved[63:16], LID[15:0]}. Hosts should use alias GIDs in order to transmit traffic to peers on remote subnets.

### **Host-to-Host IB Router Unicast Flow**



## IB Router Scripts

The following scripts are supplied as part of UFM installation package.

### set\_num\_of\_subnets.sh

- **Arguments**

```
/opt/ufm/scripts/ib_router/set_num_of_subnets.sh --hostname
<hostname> --username <username> --password <password> --num-
of-subnets <num-of-subnets>
```

- **Description** – Configures system profile to InfiniBand allowing multiple switch IDs
- **Syntax Description**

hostname	IB router hostname or IP address
username	IB router username
password	IB router user password

num-of-subnets	Specified number of subnets (AKA SWIDs) to be initialized by the system. Value range: 2-6
----------------	---

- **Example**

```
/opt/ufm/scripts/ib_router/set_num_of_subnets.sh --hostname  
10.6.204.12 --username admin --password admin --num-of-  
subnets 6
```

**i Note**

As a result of running this script, reboot is performed and all configuration is removed

## add\_interfaces\_to\_subnet.sh

- **Arguments**

```
/opt/ufm/scripts/ib_router/add_interfaces_to_subnet.sh --  
hostname <hostname> --username <username> --password  
<password> --interface <interface | interface-range> --subnet  
<subnet>
```

- **Description**

Maps an interface to a subnet and enables it

- **SyntaxDescription**

hostname	IB router hostname or IP address
username	IB router username
password	IB router user password
interface   interface-range	Single IB interface or range of IB interfaces. Single IB interface: 1/<interface> Range of IB interfaces: 1/<interface>-1/<interface>
subnet	Name of IB subnet (AKA SWID): infiniband-default, infiniband-1...infiniband-5

- **Example**

```
/opt/ufm/scripts/ib_router/add_interfaces_to_subnet.sh --
hostname 10.6.204.12 --username admin --password admin --
interface 1/1-1/6 --subnet infiniband-1
```

## remove\_interfaces\_from\_subnet.sh

- **Arguments**

```
/opt/ufm/scripts/ib_router/remove_interfaces_from_subnet.sh
--hostname <hostname> --username <username> --password
<password> --interface <interface | interface-range>
```

- **Description**

Un-maps an interface from a subnet after it has been disabled

- **Syntax Description**

hostname	IB router hostname or IP address
username	IB router username

password	IB router user password
interface   interface-range	Single IB interface or range of IB interfaces. Single IB interface: 1/<interface> Range of IB interfaces: 1/<interface>-1/<interface>

- **Example**

```
/opt/ufm/scripts/ib_router/remove_interfaces_from_subnet.sh
--hostname 10.6.204.12 --username admin --password admin --
interface 1/6Example
```

## add\_subnet\_to\_router.sh

- **Arguments**

```
/opt/ufm/scripts/ib_router/add_subnet_to_router.sh --hostname
<hostname> --username <username> --password <password> --
subnet <subnet>
```

- **Description**

Creates routing on IB subnet interface and enables routing on that interface

- **Syntax Description**

hostname	IB router hostname or IP address
username	IB router username
password	IB router user password
subnet	Name of IB subnet (AKA SWID): infiniband-default, infiniband-1... infiniband-5

- **Example**

```
/opt/ufm/scripts/ib_router/add_subnet_to_router.sh --hostname  
10.6.204.12 --username admin --password admin --subnet  
infiniband-3Example
```

**i Note**

As a result of running this script, the set of commands that allow control of IB router functionality is being enabled

## remove\_subnet\_from\_router.sh

- **Arguments**

```
/opt/ufm/scripts/ib_router/remove_subnet_from_router.sh --  
hostname <hostname> --username <username> --password  
<password> --subnet <subnet>
```

- **Description**

Destroys routing on IB subnet interface after routing on that interface has been disabled

- **Syntax Description**

hostname	IB router hostname or IP address
username	IB router username

password	IB router user password
subnet	Name of IB subnet (AKA SWID): infiniband-default, infiniband-1... infiniband-5

- **Example**

```
/opt/ufm/scripts/ib_router/remove_subnet_from_router.sh --
hostname 10.6.204.12 --username admin --password admin --
subnet infiniband-defaultExample
```

## set\_ufm\_sm\_router\_support.sh

- **Arguments**

```
/opt/ufm/scripts/ib_router/set_ufm_sm_router_support.sh [-c
<subnet prefix>] [-r][-h]
```

- **Description**

[-c <subnet prefix>]: Used for updating OpenSM configuration file with new subnet prefix and forces OpenSM to re-read configuration.

[-r]: Used for resetting OpenSM configuration to default value and canceling IB routing.

- **Syntax Description**

-c	Configure new IB subnet prefix. Should be followed by new IB router subnet prefix value
-r	Reset to default
-h	Show help

- **Example**

```
/opt/ufm/scripts/ib_router/set_ufm_sm_router_support.sh -c  
0xfec0000000001234Examples
```

```
/opt/ufm/scripts/ib_router/set_ufm_sm_router_support.sh -r
```

## IB Router Configuration

**Step 1:** Configure multi-switch. Run:

```
/opt/ufm/scripts/set_num_of_subnets.sh --hostname 10.6.204.12 --  
username admin --password admin --num-of-subnets 6
```

**Step 2:** Map interface to a subnet. Run:

```
/opt/ufm/scripts/add_ports_to_subnet.sh --hostname 10.6.204.12 --  
username admin --password admin --interface 1/1 --subnet  
infiniband-default
```

**Step 3:** Create routing on IB subnet interface. Run:

```
/opt/ufm/scripts/add_subnet_to_router.sh --hostname 10.6.204.12  
--username admin --password admin --subnet infiniband-default
```

# Appendix – NVIDIA SHARP Integration

# NVIDIA Scalable Hierarchical Aggregation and Reduction Protocol (SHARP)<sup>™</sup>

NVIDIA SHARP is a technology that improves the performance of MPI operation by offloading collective operations from the CPU and dispatching to the switch network, and eliminating the need to send data multiple times between endpoints. This approach decreases the amount of data traversing the network as aggregation nodes are reached, and dramatically reduces the MPI operation time.

NVIDIA SHARP software is based on:

- Hardware capabilities in Switch-IB<sup>™</sup> 2
- Hierarchical communication algorithms (HCOL) library into which NVIDIA SHARP capabilities are integrated
- NVIDIA SHARP daemons, running on the compute nodes
- NVIDIA SHARP Aggregation Manager, running on UFM

1. These components should be installed from HPCX or MLNX\_OFED packages on compute nodes. Installation details can be found in SHARP Deployment Guide.

## NVIDIA SHARP Aggregation Manager

Aggregation Manager (AM) is a system management component used for system level configuration and management of the switch-based reduction capabilities. It is used to set up the NVIDIA SHARP trees, and to manage the use of these entities.

AM is responsible for:

- NVIDIA SHARP resource discovery
- Creating topology aware NVIDIA SHARP trees
- Configuring NVIDIA SHARP switch capabilities
- Managing NVIDIA SHARP resources
- Assigning NVIDIA SHARP resource upon request
- Freeing NVIDIA SHARP resources upon job termination

AM is configured by a topology file created by Subnet Manager (SM): subnet.lst. The file includes information about switches and HCAs.

## NVIDIA SHARP AM Prerequisites

In order for UFM to run NVIDIA SHARP AM, the following conditions should be met:

- Managed InfiniBand fabric must include at least one of the following Switch-IB 2 switches with minimal firmware version of 15.1300.0126:
  - CS7500
  - CS7510
  - CS7520
  - MSB7790
  - MSB7800
- NVIDIA SHARP software capability should be enabled for all Switch-IB 2 switches in the fabric (a dedicated logical port #37, for NVIDIA SHARP packets transmission, should be enabled and should be visible via UFM).
- UFM OpenSM should be running to discover the fabric topology.

NVIDIA SHARP AM is tightly dependent on OpenSM as it uses the topology discovered by OpenSM.

- NVIDIA SHARP AM should be enabled in UFM configuration by running:

```
[Sharp]
sharp_enabled = true
```

## NVIDIA SHARP AM Configuration

By default, when running NVIDIA SHARP AM by UFM, there is no need to run further configuration. To modify the configuration of NVIDIA SHARP AM, you can edit the following NVIDIA SHARP AM configuration file: /opt/ufm/files/conf/sharp/sharp\_am.cfg.

## Running NVIDIA SHARP AM in UFM

➤ *To run NVIDIA SHARP AM within UFM, do the following:*

1. Make sure that the root GUID configuration file (root\_guid.conf) exists in conf/opensm. This file is required for activating NVIDIA SHARP AM.
2. Enable NVIDIA SHARP in conf/opensm/opensm.conf OpenSM configuration file by running "ib sm sharp enable" or by setting the sharp\_enabled parameter to 2:

```
# SHArP support
# 0: Ignore SHArP - No SHArP support
# 1: Disable SHArP - Disable SHArP on all supporting switches
# 2: Enable SHArP - Enable SHArP on all supporting switches
sharp_enabled 2
```

3. Make sure that port #6126 (on which NVIDIA SHARP AM is communicating with NVIDIA SHARP daemons) is not being used by any other application. If the port is being used, you can change it by modifying **smx\_sock\_port** parameter in the NVIDIA SHARP AM configuration file: conf/sharp2/sharp\_am.cfg or via the command "ib sharp port".
4. Enable NVIDIA SHARP AM in conf/gv.cfg UFM configuration file by running the command "ib sharp enable" or by setting the sharp\_enabled parameter to true (it is false by default):

```
[Sharp]
sharp_enabled = true
```

5. (Optional) Enable NVIDIA SHARP allocation in conf/gv.cfg UFM configuration file by setting the sharp\_allocation\_enabled parameter to true (it is false by default):

```
[Sharp]
```

```
sharp_allocation_enabled = true
```

### **Note**

If the field `sharp_enabled`, and `sharp_allocation_enabled` are both set as `true` in `gv.cfg`, UFM sends an allocation (reservation) request to NVIDIA SHARP Aggregation Manager (AM) to allocate a list of GUIDs to the specified PKey when a new “Set GUIDs for PKey” REST API is called. If an empty list of GUIDs is sent, a PKEY deallocation request is sent to the SHARP AM.

NVIDIA SHARP allocations (reservations) allow SHARP users to run jobs on top of these resource (port GUID) allocations for the specified PKey. For more information, please refer to the *UFM REST API Guide* under Actions REST API → PKey GUIDs → Set/Update PKey GUIDs.

## Operating NVIDIA SHARP AM with UFM

If NVIDIA SHARP AM is enabled, running UFM will run NVIDIA SHARP AM, and stopping UFM will stop NVIDIA SHARP AM.

### To

#### **start UFM with NVIDIA SHARP AM (enabled):**

```
/etc/init.d/ufmd start
```

The same command applies to HA, using `/etc/init.d/ufmha`.

Upon startup of UFM or SHARP Aggregation Manager, UFM will resend all existing persistent allocation to SHARP AM.

#### **To stop UFM with NVIDIA SHARP AM (enabled):**

```
/etc/init.d/ufmd stop
```

➤ **To stop only NVIDIA SHARP AM while leaving UFM running:**

```
/etc/init.d/ufmd sharp_stop
```

➤ **To start only NVIDIA SHARP AM while UFM is already running:**

```
/etc/init.d/ufmd sharp_start
```

Upon startup of UFM or SHARP Aggregation Manager, UFM will resend all existing persistent allocation to SHARP AM.

**To restart only NVIDIA SHARP AM while UFM is running:**

```
/etc/init.d/ufmd sharp_restart
```

Upon startup of UFM or SHARP Aggregation Manager, UFM will resend all existing persistent allocation to SHARP AM.

**To display NVIDIA SHARP AM status while UFM is running:**

```
/etc/init.d/ufmd sharp_status
```

## Monitoring NVIDIA SHARP AM by UFMHealth

UFMHealth monitors SHARP AM and verifies that NVIDIA SHARP AM is always running. When UFMHealth detects that NVIDIA SHARP AM is down, it will try to re-start it, and will trigger an event to the UFM to notify it that NVIDIA SHARP AM is down.

# Managing NVIDIA SHARP AM by UFM High Availability (HA)

In case of a UFM HA failover or takeover, NVIDIA SHARP AM will be started on the new master node using the same configuration that was used prior to the failover/takeover.

## NVIDIA SHARP AM Logs

NVIDIA SHARP AM log file (sharp\_am.log) at /opt/ufm/files/log.

NVIDIA SHARP AM log files are rotated by UFM logrotate mechanism.

## NVIDIA SHARP AM Version

NVIDIA SHARP AM version can be found at /opt/ufm/sharp/share/doc/SHARP\_VERSION.

# Appendix - UFM SLURM Integration

Simple Linux Utility for Resource Management (SLURM) is a job scheduler for Linux and Unix-like kernels.

By integrating SLURM with UFM, you can:

- Assign partition keys (PKeys) to SLURM nodes that are assigned for specific SLURM jobs.
- Create SHARP reservations based on SLURM nodes assigned for specific SLURM jobs.

## Prerequisites

- UFM 6.9.0 (or newer)
- Python 3.0 on SLURM controller
- UFM-SLURM integration files (provided independently)

## Automatic Installation

A script is provided to install the UFM-SLURM integration automatically.

1. Using the SLURM controller, extract the UFM-SLURM integration tar file:

```
tar -xf ufm_slurm_integration.tar.gz
```

2. Run the installation script using root privileges.

```
sudo ./install.sh
```

## Manual Installation

To install the UFM-SLURM integration manually:

1. Extract the UFM-SLURM integration tar file:

```
tar -xf ufm_slurm_integration.tar.gz
```

2. Copy the UFM-SLURM integration files to the SLURM controller folder.
3. Change the permissions of the UFM-SLURM integration files to 755.
4. Modify the SLURM configuration file on the SLURM controller, `/etc/slurm/slurm.conf`, and add/modify the following two parameters:

```
PrologSlurmctld=/etc/slurm/ufm-prolog.sh  
EpilogSlurmctld=/etc/slurm/ufm-epilog.sh
```

## UFM SLURM Config File

The integration process uses a configuration file located at `/etc/slurm/ufm_slurm.conf`. This file is used to configure settings and attributes for UFM-SLURM integration.

Here are the contents:

<b>Attribute Name</b>	<b>Description</b>	<b>Optionality</b>
ufm_server	IP of UFM server to connect to	Mandatory
auth_type	Should be token_auth, or basic_auth If you select basic_auth, you need to set ufm_server_user and ufm_server_pass If you select token_auth, you need to set token_auth	Mandatory
ufm_server_user	Username of UFM server used to connect to UFM, if you set auth_type=basic_auth	Mandatory, depends on the auth_type
ufm_server_pass	UFM server user password	Mandatory, depends on the auth_type
token	Generated token when you set auth_type to token_auth	Mandatory, depends on the auth_type
pkey_allocation	By setting pkey_allocation to true, UFM SLURM Integration will use static Pkey assignment to create new Pkey, otherwise it will use the default management Pkey 0x7fff	Mandatory, default is True.
pkey	Hexadecimal string between "0x0001"- "0x7ffe" exclusive	Optional, default is "0x7fff" (This is the default management pkey)
ip_over_ib	PKey is a member in a multicast group that uses IP over InfiniBand	Hidden param, default is True
index0	If true, the API will store the PKey at index 0 of the PKey table of the GUID	Hidden param, default is False
sharp_allocation	By setting sharp_allocation to true, UFM SLURM Integration will create new SHARP allocation with all SLURM job IDs allocated to hosts	Mandatory, default is False
partially_alloc	By setting this to false, UFM will fail the SHARP allocation request if at least one node does not exist in the fabric	Optional, default is False
app_resources_limit	Application resources limitation	Hidden param, default is -1

Attribute Name	Description	Optionality
log_file_name	Name of integration logging file	Optional

## Configuring UFM for NVIDIA SHARP Allocation

To configure UFM for NVIDIA SHARP allocation/deallocation you must set `sharp_enabled` and `enable_sharp_allocation` to `true` in `gv.cfg` file.

## Generate token\_auth

If you set `auth_type=token_auth` in UFM SLURM's config file, you must generate a new token by logging into the UFM server and running the following `curl` command:

```
curl -H "X-Remote-User:admin" -XPOST
http://127.0.0.1:8000/app/tokens
```

Then you must copy the generated token and paste it into the config file beside the `token_auth` parameter.

## Prolog and Epilog

After submitting jobs on SLURM, there are two scripts that are automatically executed:

- `ufm-prolog.sh` – the prolog script is executed when a job is submitted and before running the job itself. It creates the partition key (pkey) assignment and/or NVIDIA SHARP reservation and assigns the SLURM job hosts for them.
- `ufm-epilog.sh` – the epilog script is executed when a job is complete. It removes the partition key (PKey) assignment and/or NVIDIA SHARP reservation and free the associated SLURM job hosts.

## Integration Files

The integration use scripts and configuration files to work, which should be copied to SLURM controller `/etc/slurm`. Here is a list of these files:

File Name	Description
<code>ufm-prolog.sh</code>	Bash file which executes jobs related to UFM after the SLURM job is completed
<code>ufm-epilog.sh</code>	Bash file which executes jobs related to UFM before the SLURM job is executed
<code>ufm_slurm.conf</code>	UFM-SLURM integration configuration file
<code>ufm_slurm_prolog.py</code>	Python script file which creates the partition key (pkey) assignment and/or SHARP reservation when the prolog bash script is running
<code>ufm_slurm_epilog.py</code>	Python script file which removes partition key (pkey) assignment and/or SHARP reservation based on the SLURM job hosts.
<code>ufm_slurm_util.py</code>	Utility Python file containing functions and utilities used by the integration process

## Running UFM-SLURM Integration

Using the SLURM controller, execute the following commands to run your batch job:

```
$ sbatch -N4 slurm_demo.sh
Submitted batch job 1
```

### Note

N4 is the number of compute nodes used to run the jobs. `slurm_demo.sh` is the job batch file to be run.

The output and result are stored on the working directory `slurm-{id}.out` where `{id}` is the ID of the submitted job.

In the above example, after executing `sbatch` command, you can see that the submitted job ID is 1. Therefore, the output file would be stored in `slurm-1.out`.

Execute the following command to see the output:

```
$cat slurm-1.out
```

On the UFM side, a partition key (PKey) is created in case the `pkey_allocation` parameter is set to true in the configuration file, and the user provided the PKey name including the SLURM job IDs allocated to the hosts. Otherwise it will use the default management PKey.

In addition, the UFM-SLURM will create SHARM AM reservation in case the `sharp_allocation` parameter is set to true in the `ufm_slurm.conf` file.

After the SLURM job is completed, the UFM removes the job-related partition key (PKey) assignment and SHARP reservation, if they were created.

From the moment a job is submitted by the SLURM server until its completion, a log file named `/tmp/ufm_slurm.log` logs all of the actions and errors that occurred during the execution.

This log file can be changed by modifying the `log_file_name` parameter in `/etc/slurm/ufm_slurm.conf`.

## Appendix - Switch Grouping

To facilitate the logical grouping of 1U switches into a "director-like switch" group, the UFM implements a special dedicated group of interconnected 1U switches based on a YAML configuration file. This group, which is of type "superswitch", only includes 1U switches connected to each other, with some functioning as lines and others as spines.

To access the configuration file for superswitches, users can define the path in the [SubnetManager] section of the `gv.cfg` file, using the variable name "super\_switch\_config\_file\_path". For instance, the path can be specified as follows:  
`super_switch_config_file_path=/opt/ufm/files/conf/super_switches_configuration.cfg.`

It is important to note that the file must be located in the `/opt/ufm/files` file tree, as it should be replicated between master and slave UFM servers in a high-availability configuration.

The structure of the superswitch definition should be as follows, based on the following example:

```
superswitch:
  - name: "Marlin01" # Director switch name
    description: "primary dc switch" # Free text with the customer
facing description
    location: "US,NC,DC01" # Director switch location (global
location, includes all racks/switches)
    racks: # Director switch Racks definitions
      #Rack definition
      - name: "rack A" # Director switch rack name
        location:
          dc-grid-row: "A" # formalized rack location in DC
          dc-grid-column: "1" # formalized
          comments: "left-most rack in the line" #Cutomer facing comment on
the rack
        leafs: # List of Director switch leafs (for the rack
specified)
          - guid: "0x043f720300922a00" #required filed. Switch GUID.
            location-u: 1 # required field. Device location in
rack: "U#"
            description: "MF0;gorilla-01:MQM9700/U1" # optional field.
          - guid: "0x043f720300899cc0" #required filed. Switch GUID.
            location-u: XX # required field. Device location in
rack: "U#"
            description: "MF0;gorilla-01:MQM9700/U2" # optional field.
        spines: # List of Director switch spines (for the rack
specified)
          - guid: "0x043f720900922a00" #required filed. Switch GUID.
            location-u: 10 # required field. Device location in
rack: "U#"
            description: "MF0;gorilla-02:MQM9700/U1" # optional field.
          - guid: "0x043f720900899cc0" #required filed. Switch GUID.
```

```

        location-u: XX # required field. Device location in
rack: "U#"
        description: "MF0;gorilla-02:MQM9700/U2" # optional field.
- name: "Marlin02" # Director switch name
        description: "primary dc switch" # Free text with the customer
facing description
        location: "US,NC,DC01" # Director switch location (global
location, includes all racks/switches)
        racks: # Director switch Racks definitions
        #Rack definition
- name: "rack B" # Director switch rack name
        location:
        dc-grid-row: "B" # formalized rack location in DC
        dc-grid-column: "1" # formalized
        comments: "left-most rack in the line" #Cutomer facing comment on
the rack
        leafs: # List of Director switch leafs (for the rack
specified)
- guid: "0x093f720300922a00" #required filed. Switch GUID.
        location-u: 1 # required field. Device location in
rack: "U#"
        description: "MF0;gorilla-03:MQM9700/U1" # optional field.
- guid: "0x093f720300899cc0" #required filed. Switch GUID.
        location-u: XX # required field. Device location in
rack: "U#"
        description: "MF0;gorilla-03:MQM9700/U2" # optional field.
        spines: # List of Director switch spines (for the rack
specified)
- guid: "0x093f720900922a00" #required filed. Switch GUID.
        location-u: 10 # required field. Device location in
rack: "U#"
        description: "MF0;gorilla-04:MQM9700/U1" # optional field.
- guid: "0x093f720900899cc0" #required filed. Switch GUID.
        location-u: XX # required field. Device location in
rack: "U#"
        description: "MF0;gorilla-04:MQM9700/U2" # optional field

```

# UI Presentation

The logical grouping can be accessed under the "Groups" view, specifically listed as "SuperSwitch group" type.

Severity	Name ↑	Description	Type
Info	1U Switches	Includes all 1U Switches that exist in the fabric	General
Info	Alarmed Devices	Devices with alarms	General
Info	Devices Pending FW Transceivers Reset	Includes all Devices that pending FW transceivers reset t...	General
Info	Gateway Devices	Includes all Gateway Devices that exist in the fabric	General
Info	Marlin01	SuperSwitch group	SuperSwitch
Info	Marlin02	SuperSwitch group	SuperSwitch
Info	Modular Switches	Includes all Modular Switches that exist in the fabric	General
Info	Routers	Includes all Router Devices that exist in the fabric	General
Info	Servers	Includes all Hosts that exist in the fabric	General
Info	Servers With DPU	Includes all Devices that has DPU that exist in the fabric	General
Info	Suppressed Devices	No event notifications issued	General
Info	Switches	Includes all Switches that exist in the fabric	General


Upon selecting the group type SuperSwitch, additional columns containing information related to the SuperSwitch are added to the details view.

Severity	Name ↑	Description	Type
Info	1U Switches	Includes all 1U Switche...	General
Info	Alarmed Devices	Devices with alarms	General
Info	Devices Pending FW Tr...	Includes all Devices tha...	General
Info	Gateway Devices	Includes all Gateway D...	General
Info	Marlin01	SuperSwitch group	SuperSwitch
Info	Marlin02	SuperSwitch group	SuperSwitch
Info	Modular Switches	Includes all Modular S...	General
Info	Routers	Includes all Router Dev...	General
Info	Servers	Includes all Hosts that ...	General
Info	Servers With DPU	Includes all Devices tha...	General
Info	Suppressed Devices	No event notifications i...	General
Info	Switches	Includes all Switches t...	General

Name ↑	GUID	IP	Type	Descri...	Locati...	Rack
gorilla-01	0x043f72...	0.0.0.0	leaf	MF0:gori...	1	rack A
gorilla-01	0x043f72...	0.0.0.0	leaf	MF0:gori...	XX	rack A
gorilla-07	0x073f72...	0.0.0.0	spine	MF0:gori...	10	rack A
gorilla-07	0x073f72...	0.0.0.0	spine	MF0:gori...	XX	rack A

An icon for the SuperSwitch group in its collapsed view exists on the network map.



Upon selecting the SuperSwitch group, all of its properties can be viewed in the details view.

Network Map

Layout: Hierarchical Graph Views: Default Regex Filters: Starts With: Enter filter

View Zoom In Filters: Select nodes to highlight and display in Zoom In tab

View Properties

Super Switch Properties

Property	Value
Name	Marlin01
Severity	Info
Description	primary dc switch
Location	US, NC, DC01
Rack	rack A
Rack Location	dc-grid-row= A, dc-grid-column= 1, comments= left-most rack in the line

Leaves

Description	Location	Rack
MF0.gorilla-01.MQM9700/U1	1	rack A
MF0.gorilla-01.MQM9700/U2	XX	rack A

Spines

Description	Location	Rack
MF0.gorilla-02.MQM9700/U1	10	rack A
MF0.gorilla-02.MQM9700/U2	XX	rack A

Expanding the SuperSwitch group icon displays all the switches included in the group as separate 1U switches, along with their respective properties.

Network Map

Layout: Hierarchical Graph Views: Default Regex Filters: Starts With: Enter filter

View Zoom In Filters: Select nodes to highlight and display in Zoom In tab

View Properties

Super Switch Properties

Property	Value
Name	Marlin01
Severity	Info
Description	primary dc switch
Location	US, NC, DC01
Rack	rack A
Rack Location	dc-grid-row= A, dc-grid-column= 1, comments= left-most rack in the line

Leaves

Description	Location	Rack
MF0.gorilla-01.MQM9700/U1	1	rack A
MF0.gorilla-01.MQM9700/U2	XX	rack A

Spines

Description	Location	Rack
MF0.gorilla-02.MQM9700/U1	10	rack A
MF0.gorilla-02.MQM9700/U2	XX	rack A

Network Map

Layout: Hierarchical Graph Views: Default Regex Filters: Starts With: Enter filter

View: Zoom In Filters: Select nodes to highlight and display in Zoom In tab

System Properties

Property	Value
Name	gorilla-07
IP	0.0.0.0
GUID	0x073f720300922a00
Type	switch
Model	MQM9700
Severity	Info
FW Version	N/A
PSID	N/A
Total Alarms	0
Temperature	N/A
Description	MQM9700
SW Version	N/A

System Ports

Port Name
gorilla-07:1
gorilla-07:13
gorilla-07:14

On the devices view, switches that are part of the SuperSwitch group are marked with an additional icon that indicates their role in the group. The "S" icon denotes spines, while the "L" icon denotes lines.

Devices

Local Time Last Update admin

All Types All Groups Displayed Columns CSV

Severity	Name	GUID	Type	Model	IP	Firmware Version
Info	gorilla-01	0x043f720300922a00	switch	MQM9700	0.0.0.0	
Info	gorilla-07	0x073f720300922a00	switch	MQM9700	0.0.0.0	
Info	gorilla-08	0x083f720300922a00	switch	MQM9700	0.0.0.0	
Info	gorilla-02	0x093f720300922a00	switch	MQM9700	0.0.0.0	
Info	gorilla-01	0x043f720300899cc0	switch	MQM9700	0.0.0.0	
Info	gorilla-07	0x073f720300899cc0	switch	MQM9700	0.0.0.0	
Info	gorilla-08	0x083f720300899cc0	switch	MQM9700	0.0.0.0	
Info	gorilla-02	0x093f720300899cc0	switch	MQM9700	0.0.0.0	
Info	r-ufm50	0x248a0703008fa050	host		0.0.0.0	

Viewing 1-9 of 9

Selecting a switch that belongs to the SuperSwitch group in the properties view allows you to view all the switch properties related to the SuperSwitch group.

Devices Local Time Last Update [redacted] ? admin

---

All Types All Groups Refresh Displayed Columns CSV

Name	GUID	Type	Model	IP	Firmwa...
gorilla-01	0x043f720...	switch	MQM97	0.0.0.0	
gorilla-07	0x073f720...	switch	MQM97	0.0.0.0	
gorilla-08	0x083f720...	switch	MQM97	0.0.0.0	
gorilla-02	0x093f720...	switch	MQM97	0.0.0.0	
gorilla-01	0x043f720...	switch	MQM97	0.0.0.0	
gorilla-07	0x073f720...	switch	MQM97	0.0.0.0	
gorilla-08	0x083f720...	switch	MQM97	0.0.0.0	
gorilla-02	0x093f720...	switch	MQM97	0.0.0.0	
r-ufm50	0x248a07...	host		0.0.0.0	

Viewing 1-9 of 9

0x073f720300922a00 - Device Information

General Ports Cables Groups Alarms Events Inventory

Device Access Super Switch

Property	Value
Description	MF0:gorilla-02:MQM9700/U1
Location	10
Type	spine
Rack Name	rack A
Rack Location	dc-grid-row=A, dc-grid-column=1, comment...
Super Switch Name	Marlin01

**Note**

Each SuperSwitch definition can include one or more racks where each embedded rack can include multiple leafs and spines switches.

# Appendix – Device Management Feature Support

The following table describes the management features available on supported devices.

Feature	10 Gb Ethernet Gateway Module	Grid Director 4700/4200/4036/4036E v3.5	Managed IS5000 Switches	Managed SX6000 Switches	Externally Managed IS5000 / SX6000 Switches	Gateway BX5020	HP C-Class	Linux Hosts	Windows Hosts
Discovery									

Feature	10 Gb Ethernet Gateway Module	Grid Director 4700/4200/4036/4036E v3.5	Managed IS5000 Switches	Managed SX6000 Switches	Externally Managed IS5000 / SX6000 Switches	Gateway BX5020	HP C-Class	Linux Hosts	Windows Hosts
IB L2 Discovery	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Advanced Discovery (IP, hostname, Hosts: CPU, memory, FW version)	Yes	Yes	No	Yes	No	No	No	Yes with UFM Host Agent	No
Ethernet access Management interface	Yes	Yes	Yes	Yes	No	No	No	Yes	Yes
Provisioning/ Configuration									
IB Partitioning (pkey)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
QoS: SL (SM configuration)	N/A	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
QoS: Rate Limit (SM configuration)	N/A	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes

Feature	10 Gb Ethernet Gateway Module	Grid Director 4700/4200/4036/4036E v3.5	Managed IS5000 Switchesv	Managed SX6000 Switches	Externally Managed IS5000 / SX6000 Switches	Gateway BX5020	HP C-Class	Linux Hosts	Windows Hosts
Interface/VIF Configuration (IP, hostname, mtu, Bonding)	N/A	N/A	N/A	N/A	N/A	No	N/A	Yes with UFM Host Agent	No
Device Monitoring									
Device Resources : CPU, Memory, Disk	No	Yes	No	No	No	No	No	Yes with UFM Host Agent	No
Get device alerts (Temperature, PS, Fan) <b>Note:</b> This feature is not supported on Switch-X switches.	Yes	Yes	No	Yes	Yes	No	No	No	No
L1 (Physical Port) – Monitoring	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
L2-3 (Interface/	No	No	No	No	No	No	No	Yes with	No

Feature	10 Gb Ethernet Gateway Module	Grid Director 4700/4200/4036/4036E v3.5	Managed IS5000 Switchesv	Managed SX6000 Switches	Externally Managed IS5000 / SX6000 Switches	Gateway BX5020	HP C-Class	Linux Hosts	Windows Hosts
VIF) – Monitoring								UFM Host Agent	
Congestion Monitoring per port (enables congestion map)	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Congestion Monitoring per flow (Advanced Package)	No	Yes	No	No	No	No	No	No	No
Device Management									
Add/remove to/from Rack	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Add/remove to/from Logical Server	N/A	N/A	N/A	N/A	N/A	N/A	N/A	Yes	Yes
View/clear Alarms	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
SSH terminal to device	Yes	Yes	Yes	Yes	No	No	No	Yes	Yes
Power On	No	No	No	No	No	No	No	Yes with	No

Feature	10 Gb Ethernet Gateway Module	Grid Director 4700/4200/4036/4036E v3.5	Managed IS5000 Switchesv	Managed SX6000 Switches	Externally Managed IS5000 / SX6000 Switches	Gateway BX5020	HP C-Class	Linux Hosts	Windows Hosts
								IPMI	
Reboot	No	No	No	Yes (SX3606 only)	No	No	No	Yes with IPMI	No
Shutdown	No	No	No	No	No	No	No	Yes with IPMI	No
Port Enable/Disable	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Firmware Upgrade (HCA & switch)	No	Yes	No	Yes (Upon SW upgrade – SX6036 only)	No	No	No	Yes	No
Inband Firmware Upgrade (over InfiniBand connection)	No	No	No	No	Yes	No	No	Yes	Yes
Software Upgrade (OFED & switch)	No	Yes	No	Yes (SX3606 only)	No	No	No	Yes with UFM Host Agent	No
Protocols									

Feature	10 Gb Ethernet Gateway Module	Grid Director 4700/4200/4036/4036E v3.5	Managed IS5000 Switchesv	Managed SX6000 Switches	Externally Managed IS5000 / SX6000 Switches	Gateway BX5020	HP C-Class	Linux Hosts	Windows Hosts
Communication UFM Server – Device	IB/SNMP	IB/UDP/SSH	IB	IB/HTTP/SSH	IB	IB	IB	IB, SSH, IPMI, UDP	IB

1. For a full list of supported IS5000 switches, see [Supported IS5000 Switches](#).
2. QoS Rate Limit (SM configuration): On ConnectX HCAs-only, for hosts.
3. XmitWait counter monitoring requires ConnectX HCAs with firmware version 2.6 and above.
4. This feature requires that the IP address is configured.

---

# Document Revision History

Release	Date	Description
6.1 8.2	Sep 25, 2024	Updated <a href="#">Bug Fixes in This Release</a>

Release	Date	Description
6.1 8.0	Aug 14, 2024	<p>Updated:</p> <ul style="list-style-type: none"> <li>• <a href="#">Changes and New Features</a></li> <li>• <a href="#">Bug Fixes in This Release</a></li> <li>• <a href="#">Known Issues in This Release</a></li> <li>• <a href="#">Installation Notes</a></li> <li>• <a href="#">Installing UFM Server Software</a> - Added a note on Docker installation via SNAP on Ubuntu OSs</li> <li>• <a href="#">Data Streaming</a></li> <li>• <a href="#">Installing UFM on Docker Container - High Availability Mode</a> - Added two pre-deployment requirements</li> <li>• <a href="#">REST-RDMA Plugin</a> - Updated "Authenticated Remote ibdiagnet Request"</li> <li>• <a href="#">Topology Compare Tab and Events &amp; Alarms</a> - Updated screenshots</li> <li>• <a href="#">Appendix - Supported Port Counters and Events</a> - Added 1605 and 1606 alarm IDs</li> <li>• <a href="#">Autonomous Link Maintenance (ALM) Plugin</a> - Added "Data Filter" and "Metric Filter" ALM jobs</li> <li>• <a href="#">UFM Telemetry Manager (UTM) Plugin</a> - Added an important note on UFM credentials, added instructions on accessing UTM API commands and "Command List"</li> <li>• <a href="#">GNMI-Telemetry Plugin</a></li> </ul> <p>Added:</p> <ul style="list-style-type: none"> <li>• Excluding Unhealthy Ports from Fabric Health Report</li> <li>• UFM Configuration Files Based on Fabric Size</li> <li>• <a href="#">Exposing Performance Histogram Counters</a></li> <li>• <a href="#">Plugins Bundle</a></li> <li>• <a href="#">UFM Plugins Management</a></li> <li>• <a href="#">Key Performance Indexes (KPI) Plugin</a></li> <li>• <a href="#">UFM Light Plugin</a></li> </ul>
6.1 7.2	Jun 24, 2024	Added bug fix (Ref #3912416) to <a href="#">Bug Fixes in This Release</a>
	Jun 26, 2024	<p>Updated:</p> <ul style="list-style-type: none"> <li>• <a href="#">Upgrading UFM on Bare Metal Server</a></li> <li>• <a href="#">Upgrading UFM on Docker Container</a></li> <li>• <a href="#">GNMI-Telemetry Plugin</a></li> </ul>

Release	Date	Description
		<ul style="list-style-type: none"> <li>• <a href="#">Fast-API Plugin</a></li> </ul>
6.1 7.1	May 28, 2024	<p>Updated:</p> <ul style="list-style-type: none"> <li>• <a href="#">Bug Fixes in This Release</a></li> <li>• <a href="#">Known Issues in This Release</a></li> </ul> <p>Added <a href="#">Fast-API Plugin</a></p>
	Jun 17, 2024	<ul style="list-style-type: none"> <li>• Updated the <a href="#">Fast-API Plugin</a> name</li> <li>• Updated <a href="#">Enabling UFM Authentication Server</a></li> </ul>
6.1 7.0	May 7, 2024	<p>Introduced a minor reorganization of the document.</p> <p>Updated:</p> <ul style="list-style-type: none"> <li>• <a href="#">Changes and New Features</a></li> <li>• <a href="#">Bug Fixes in This Release</a></li> <li>• <a href="#">GNMI-Telemetry Plugin</a></li> <li>• <a href="#">Events Policy</a> - Updated event policy parameters</li> <li>• <a href="#">Inventory Window</a></li> <li>• <a href="#">Devices Window</a></li> <li>• <a href="#">UFM Health Tab</a></li> <li>• <a href="#">UFM System Dump Tab</a></li> <li>• <a href="#">Device Access</a> - Updated screenshot and parameters</li> <li>• <a href="#">Configurations of the UFM Authentication Server</a> - Updated that it is turned on by default</li> <li>• <a href="#">Autonomous Link Maintenance (ALM) Plugin</a></li> <li>• <a href="#">PDR Deterministic Plugin</a> - updated the configuration table</li> <li>• <a href="#">Low-Frequency (Secondary) Telemetry Fields</a></li> <li>• <a href="#">Appendix - Supported Port Counters and Events</a> - Added and removed alarm IDs</li> </ul> <p>Added:</p> <ul style="list-style-type: none"> <li>• <a href="#">Events and Alarms</a></li> <li>• <a href="#">Reports</a></li> <li>• <a href="#">Telemetry</a></li> <li>• <a href="#">Events Policy Simulation</a></li> <li>• <a href="#">UFM Telemetry Manager (UTM) Plugin</a></li> <li>• <a href="#">UFM Consumer Plugin</a></li> </ul>

Release	Date	Description
	May 13, 2024	<p>Updated:</p> <ul style="list-style-type: none"> <li>• <a href="#">Known Issues in This Release</a> - Added issue # 3862847</li> <li>• <a href="#">Installation Notes</a> - Updated the latest tested FW versions in Supported NVIDIA Externally/Internally Managed Switches</li> <li>• <a href="#">PDR Deterministic Plugin</a></li> </ul>
	May 24, 2024	<p>Updated:</p> <ul style="list-style-type: none"> <li>• <a href="#">Known Issues in This Release</a> - Added issue #3872303</li> <li>• <a href="#">UFM Telemetry Fluentd Streaming (TFS) Plugin</a></li> <li>• <a href="#">GNMI-Telemetry Plugin</a></li> <li>• <a href="#">PDR Deterministic Plugin</a></li> </ul>
6.1 6.0	Feb 8, 2024	<p>Updated:</p> <ul style="list-style-type: none"> <li>• <a href="#">Changes and New Features</a></li> <li>• <a href="#">Bug Fixes in This Release</a></li> <li>• <a href="#">Installation Notes</a></li> <li>• <a href="#">Secondary Telemetry</a> - Added the secondary_slvl_support flag and information on the default counters and added <a href="#">Secondary Telemetry Exposing IPv6 Counters</a></li> <li>• <a href="#">PDR Deterministic Plugin</a> - Updated instructions</li> <li>• <a href="#">Link Analysis</a> - Updated GUI screenshots</li> <li>• <a href="#">Device Cable Tab</a> - Updated GUI screenshots</li> <li>• <a href="#">Cables Window</a> - Updated GUI screenshots</li> <li>• <a href="#">Packet Level Monitoring Collector (PMC) Plugin</a> - Updated overview and GUI screenshots</li> <li>• <a href="#">General Tab, Inventory Tab and Inventory Window</a> - Updated GUI screenshots</li> <li>• <a href="#">SM Congestion Control Configuration</a> - Updated GUI screenshot</li> <li>• <a href="#">Autonomous Link Maintenance (ALM) Plugin</a> - Added GUI screenshots in <a href="#">ALM UI</a></li> <li>• <a href="#">Appendix – UFM Subnet Manager Default Properties</a> - Updated the max_op_vls from 3 to 2.</li> </ul> <p>Added:</p> <ul style="list-style-type: none"> <li>• <a href="#">Kerberos Authentication and Enabling Kerberos Authentication</a></li> <li>• <a href="#">Secondary Telemetry Exposing IPv6 Counters</a></li> <li>• <a href="#">Dynamic Telemetry</a></li> </ul>

Release	Date	Description
		<ul style="list-style-type: none"> <li>• <a href="#">Configuring Syslog</a></li> <li>• <a href="#">Configuring UFM Logging</a></li> <li>• <a href="#">Appendix - OpenSM Configuration Files for Congestion Control</a></li> </ul>
	Mar 6, 2024	<p>Updated:</p> <ul style="list-style-type: none"> <li>• <a href="#">Troubleshooting</a></li> <li>• <a href="#">Known Issues in This Release</a></li> <li>• <a href="#">Installation Notes</a></li> </ul>
6.1 5.2	Jan 4, 2024	<p>Updated:</p> <ul style="list-style-type: none"> <li>• <a href="#">Changes and New Features</a></li> <li>• <a href="#">Known Issues in This Release</a></li> </ul>
	Jan 23, 2024	Added a note to <a href="#">Installation Notes</a> about the UFM SM version
6.1 5.1	Dec 14, 2023	<p>Updated:</p> <ul style="list-style-type: none"> <li>• <a href="#">Bug Fixes in This Release</a></li> <li>• <a href="#">Known Issues in This Release</a></li> <li>• <a href="#">Supported NVIDIA Internally Managed Switches</a> - Removed MTX6100, MTX6240 and MTX6280 switches and the SX6036G (FDR) gateway</li> <li>• <a href="#">Installation Notes</a> - Updated with the new MFT package version</li> <li>• <a href="#">System Requirements</a> - Added MLNX_OFED23.x</li> <li>• <a href="#">Unsupported Functionalities/Features</a></li> </ul> <p>Added: <a href="#">Cable Validation Report in Subnet Merger</a></p>
	Dec 19, 2023	<ul style="list-style-type: none"> <li>• Updated <a href="#">Changes and New Features</a></li> <li>• Added a Known issue to <a href="#">Bug Fixes in This Release</a></li> </ul>
6.1 5.0	Nov 5, 2023	<p>Updated:</p> <ul style="list-style-type: none"> <li>• <a href="#">Changes and New Features</a></li> <li>• <a href="#">Bug Fixes in This Release</a></li> <li>• <a href="#">Azure Authentication Login Page</a> - Introduced new Azure authentication login page</li> </ul>

Release	Date	Description
		<ul style="list-style-type: none"> <li>• <a href="#">Enabling Azure AD Authentication</a> - Added further instructions</li> <li>• <a href="#">UFM Logs Tab</a> - Added log occurrences display</li> </ul> <p>Added</p> <ul style="list-style-type: none"> <li>• <a href="#">Events History</a></li> <li>• <a href="#">Device Status Events</a></li> <li>• <a href="#">Link Status Events</a></li> <li>• <a href="#">GNMI-Telemetry Plugin</a></li> <li>• In <a href="#">Secondary Telemetry</a>, added instructions on <a href="#">Exposing Switch Aggregation Nodes Telemetry</a> and <a href="#">Stopping Telemetry Endpoint Using CLI Command</a></li> <li>• <a href="#">UFM Authentication Server</a></li> <li>• <a href="#">Enabling UFM Authentication Server</a></li> <li>• <a href="#">Low-Frequency (Secondary) Telemetry Fields</a></li> </ul>
6.1 4.1	Aug 31, 2023	<p>Updated:</p> <ul style="list-style-type: none"> <li>• <a href="#">Changes and New Features</a></li> <li>• <a href="#">Bug Fixes in This Release</a></li> </ul>
	Oct 17, 2023	<p>Updated:</p> <ul style="list-style-type: none"> <li>• <a href="#">System Requirements</a></li> </ul>
6.1 4.0	Aug 10, 2023	<p>Updated:</p> <ul style="list-style-type: none"> <li>• <a href="#">Changes and New Features</a></li> <li>• <a href="#">Bug Fixes in This Release</a></li> <li>• <a href="#">Known Issues in This Release</a></li> <li>• <a href="#">Plugin Management</a></li> <li>• <a href="#">Secondary Telemetry</a></li> <li>• <a href="#">PDR Deterministic Plugin</a> - Updated step 3 in "Deployment".</li> <li>• <a href="#">REST-RDMA Plugin</a></li> <li>• <a href="#">NDT Plugin</a></li> <li>• <a href="#">Autonomous Link Maintenance (ALM) Plugin</a></li> <li>• <a href="#">Appendix - Supported Port Counters and Events</a> - Added alarm ID #134, 1602 and 1603 and status column for all alarm IDs.</li> </ul> <p>Added:</p> <ul style="list-style-type: none"> <li>• <a href="#">Disabling Rest Roles Access Control</a></li> </ul>

Release	Date	Description
		<ul style="list-style-type: none"> <li>• <a href="#">Enabling Azure AD Authentication</a></li> <li>• <a href="#">Azure AD Authentication</a></li> <li>• <a href="#">Health Policy Management</a></li> <li>• <a href="#">Rest Roles Access Control</a></li> <li>• <a href="#">UFM Factory Reset</a></li> </ul>
6.1 3.1	May 18, 2023	<p>Updated:</p> <ul style="list-style-type: none"> <li>• <a href="#">Changes and New Features</a></li> <li>• <a href="#">Bug Fixes in This Release</a></li> </ul>
6.1 3.0	May 5, 2023	<p>Updated:</p> <ul style="list-style-type: none"> <li>• <a href="#">Changes and New Features</a></li> <li>• <a href="#">Bug Fixes in This Release</a></li> <li>• <a href="#">Known Issues in This Release</a></li> <li>• <a href="#">Email</a> - Added time zone preference</li> <li>• <a href="#">NDT Plugin</a></li> <li>• <a href="#">UFM Telemetry Fluentd Streaming (TFS) Plugin</a> - Updated REST API</li> <li>• <a href="#">UFM System Dump Tab</a></li> <li>• <a href="#">Appendix - Supported Port Counters and Events</a></li> </ul> <p>Added:</p> <ul style="list-style-type: none"> <li>• <a href="#">Multi-Subnet UFM</a></li> <li>• <a href="#">Enable Network Fast Recovery</a></li> <li>• <a href="#">NDT Format Merger</a></li> <li>• <a href="#">Subnet Merger UI</a></li> <li>• Added the following Plugins: <ul style="list-style-type: none"> <li>◦ <a href="#">UFM Bright Cluster Integration Plugin</a></li> <li>◦ <a href="#">UFM Cyber-AI Plugin</a></li> <li>◦ <a href="#">Autonomous Link Maintenance (ALM) Plugin</a></li> <li>◦ <a href="#">ClusterMinder Plugin</a></li> <li>◦ <a href="#">Sysinfo Plugin</a></li> <li>◦ <a href="#">SNMP Plugin</a></li> <li>◦ <a href="#">Packet Level Monitoring Collector (PMC) Plugin</a></li> <li>◦ <a href="#">PDR Deterministic Plugin</a></li> </ul> </li> </ul>
	May 9, 2023	<p>Updated</p> <ul style="list-style-type: none"> <li>• <a href="#">Known Issues in This Release</a></li> </ul>

Release	Date	Description
		<ul style="list-style-type: none"> <li>• <a href="#">Appendix – Enhanced Quality of Service</a> - Updated notes and example</li> </ul>
6.1 2.1	Feb 19, 2023	<p>Updated</p> <ul style="list-style-type: none"> <li>• <a href="#">Changes and New Features</a></li> <li>• <a href="#">Bug Fixes in This Release</a></li> <li>• <a href="#">Known Issues in This Release</a></li> </ul>
	Mar 1, 2023	Updated <a href="#">Changes and New Features</a>
	Mar 16, 2023	Updated <a href="#">Changes and New Features</a> - Added MFT package integration details
	Mar 27, 2023	Updated <a href="#">UFM Server Communication with Externally Managed Switches</a>
6.1 2.0	Feb 2, 2023	<p>Updated:</p> <ul style="list-style-type: none"> <li>• <a href="#">Changes and New Features</a></li> <li>• <a href="#">Bug Fixes in This Release</a></li> <li>• <a href="#">Known Issues in This Release</a></li> <li>• <a href="#">Configuring Partial Switch ASIC Failure Events</a></li> <li>• Updated example in <a href="#">Multi-port SM</a></li> <li>• <a href="#">UFM System Dump Tab</a></li> <li>• <a href="#">Appendix – Used Ports</a></li> <li>• <a href="#">Appendix - UFM SLURM Integration</a></li> </ul> <p>Added:</p> <ul style="list-style-type: none"> <li>• Added a note under <a href="#">Ports Window</a></li> <li>• Added a note under <a href="#">Unhealthy Ports Window</a></li> <li>• <a href="#">Delegate Authentication to a Proxy</a></li> </ul> <p>Removed:</p> <ul style="list-style-type: none"> <li>• UFM Logical Elements tab from the Web UI</li> </ul>
	Feb 6, 2023	Updated <a href="#">Troubleshooting</a>

Release	Date	Description
6.1 1.1	Dec 1, 2022	Updated: <ul style="list-style-type: none"> <li>• <a href="#">Changes and New Features</a> to include the upgrade of NVIDIA SHARP SW version</li> <li>• <a href="#">Installation Notes</a></li> <li>• <a href="#">Known Issues in This Release</a></li> <li>• <a href="#">Troubleshooting</a></li> </ul>
	Dec 19, 2022	Updated <a href="#">Changes and New Features</a>

---

# EULA, Legal Notices and 3rd Party Licenses

## Legal Notice

## Third-Party Licenses

## License Agreement

This license is a legal agreement (“Agreement”) between you and Mellanox Technologies, Ltd. (“NVIDIA”) and governs the use of the NVIDIA UFM software and materials provided hereunder (“SOFTWARE”). If you are entering into this Agreement on behalf of a company or other legal entity, you represent that you have the legal authority to bind the entity to this Agreement, in which case “you” will mean the entity you represent.

You agree to use the SOFTWARE only for purposes that are permitted by (a) this license, and (b) any applicable law, regulation, or generally accepted practices or guidelines in the relevant jurisdictions.

1. License. Subject to the terms and conditions of this Agreement and payment of applicable subscription fee, NVIDIA MELLANOX grants you a personal, non-exclusive, non-sublicensable (except as provided in this Agreement), non-transferable, non-commercial license to install and use the Software for your internal business purposes for configuring, operating, and managing your InfiniBand network and not for further distribution.
2. Authorized Users. You may allow access and use of the Software to: (i) employees and contractors of your entity provided that the access and use of the Software is made from your secure network to perform work on your behalf and (ii) If you are an academic institution you may allow users enrolled or employed by the academic institution to access and use the Software from your secure network (“Authorized Users”). You hereby undertake to be responsible and liable for any non-compliance with the terms of this Agreement by your Authorized Users. You further agree to immediately resolve any non-compliance by your Authorized Users of which you become aware and endeavor take necessary steps to prevent any new occurrences.
3. Limitations Your license to use the SOFTWARE is restricted as follows:

3.1 The SOFTWARE is licensed for your use in systems with the registered NVIDIA Host Channel Adapter (HCA) Products or related adapter products.

3.2 Each copy of the SOFTWARE shall be limited to the number of HCAs indicated in the applicable purchase order.

3.3 You may use software back-up utilities to make one back-up copy of the Software Product. You may use the back-up copy solely for archival purposes

3.4 You may not use the SOFTWARE in conjunction with a number of managed nodes or managed devices which is beyond the allowable limit or copy the SOFTWARE on additional hardware. You shall not use any features which are not included in the scope of this Agreement as described in the accompanying documentation.

3.5 You may not reverse engineer, decompile or disassemble, or remove copyright or other proprietary notices from any portion of the SOFTWARE or copies of the SOFTWARE.

3.6 You may not disclose the results of benchmarking, competitive analysis, regression, or performance data relating to the SOFTWARE without the prior written permission from NVIDIA Mellanox.

3.7 Except as expressly provided in this license, you may not copy, sell, rent, sublicense, transfer, distribute, modify, or create derivative works of any portion of the SOFTWARE. For clarity, unless, you have an agreement with NVIDIA Mellanox for this purpose you may not distribute or sublicense the SOFTWARE as a stand-alone product.

3.8 You may not bypass, disable, or circumvent any technical limitation, encryption, security, digital rights management, or authentication mechanism in the SOFTWARE.

3.9 You may not use the Software in any manner that would cause it to become subject to an open source software license. As examples, licenses that require as a condition of use, modification, and/or distribution that the Software be: (i) disclosed or distributed in source code form; (ii) licensed for the purpose of making derivative works; or (iii) redistributable at no charge.

3.10 Unless you have an agreement with NVIDIA Mellanox for this purpose, you may not use the Software with any system or application where the use or failure of the system or application can reasonably be expected to threaten or result in personal injury, death, or catastrophic loss. Examples include use in avionics, navigation, military, medical, life support or other life critical applications. NVIDIA Mellanox does not design, test, or manufacture the Software for these critical uses and NVIDIA

Mellanox shall not be liable to you or any third party, in whole or in part, for any claims or damages arising from such uses.

3.11 You agree to defend, indemnify and hold harmless NVIDIA Mellanox and its affiliates, and their respective employees, contractors, agents, officers and directors, from and against any and all claims, damages, obligations, losses, liabilities, costs or debt, fines, restitutions and expenses (including but not limited to attorney's fees and costs incident to establishing the right of indemnification) arising out of or related to your use of the Software outside of the scope of this license, or not in compliance with its terms.

4. Updates. NVIDIA Mellanox may, at its option, make available patches, workarounds, or other updates to this Software. Unless the updates are provided with their separate governing terms, they are deemed part of the Software licensed to you as provided in this license. You agree that the form and content of the Software that NVIDIA Mellanox provides may change without prior notice to you. While NVIDIA Mellanox generally maintains compatibility between versions, NVIDIA Mellanox may in some cases make changes that introduce incompatibilities in future versions of the SOFTWARE.
5. Pre-Release Versions. Software versions identified as alpha, beta, preview, early access or otherwise as pre-release may not be fully functional, may contain errors or design flaws, and may have reduced or different security, privacy, availability, and reliability standards relative to commercial versions of NVIDIA Mellanox software and materials. You may use a pre-release Software version at your own risk, understanding that these versions are not intended for use in production or business-critical systems. NVIDIA Mellanox may choose not to make available a commercial version of any pre-release Software. NVIDIA Mellanox may also choose to abandon development and terminate the availability of a pre-release Software at any time without liability.
6. Third-Party Components. The Software may include third-party components with separate legal notices or terms as may be described in proprietary notices accompanying the Software or as provided in an Exhibit to this Agreement. If and to the extent there is a conflict between the terms in this license and the third-party license terms, the third-party terms control only to the extent necessary to resolve the conflict. For details regarding the third party components, please review Exhibit A.

## 7. OWNERSHIP

7.1 NVIDIA Mellanox or its licensors reserves all rights, title, and interest in and to the Software not expressly granted to you under this license NVIDIA Mellanox and its suppliers hold all rights, title, and interest in and to the Software, including their respective intellectual property rights. The Software is copyrighted and protected by

the laws of the United States and other countries, and international treaty provisions.

7.2 Subject to the rights of NVIDIA Mellanox and its suppliers in the Software, you hold all rights, title, and interest in and to your applications and your derivative works of the sample source code delivered in the Software including their respective intellectual property rights.

8. You may, but are not obligated to, provide to NVIDIA Mellanox Feedback. “Feedback” means suggestions, fixes, modifications, feature requests or other feedback regarding the Software. Feedback, even if designated as confidential by you, shall not create any confidentiality obligation for NVIDIA Mellanox. NVIDIA Mellanox and its designees have a perpetual, non-exclusive, worldwide, irrevocable license to use, reproduce, publicly display, modify, create derivative works of, license, sublicense, and otherwise distribute and exploit Feedback as NVIDIA Mellanox sees fit without payment and without obligation or restriction of any kind on account of intellectual property rights or otherwise.
9. No Warranties. THE SOFTWARE IS PROVIDED AS-IS. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW NVIDIA MELLANOX AND ITS AFFILIATES EXPRESSLY DISCLAIM ALL WARRANTIES OF ANY KIND OR NATURE, WHETHER EXPRESS, IMPLIED OR STATUTORY, INCLUDING, BUT NOT LIMITED TO, WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT, OR FITNESS FOR A PARTICULAR PURPOSE. NVIDIA MELLANOX DOES NOT WARRANT THAT THE SOFTWARE WILL MEET YOUR REQUIREMENTS OR THAT THE OPERATION THEREOF WILL BE UNINTERRUPTED OR ERROR-FREE, OR THAT ALL ERRORS WILL BE CORRECTED.
10. Limitations of Liability. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW NVIDIA MELLANOX AND ITS AFFILIATES SHALL NOT BE LIABLE FOR ANY SPECIAL, INCIDENTAL, PUNITIVE OR CONSEQUENTIAL DAMAGES, OR FOR ANY LOST PROFITS, PROJECT DELAYS, LOSS OF USE, LOSS OF DATA OR LOSS OF GOODWILL, OR THE COSTS OF PROCURING SUBSTITUTE PRODUCTS, ARISING OUT OF OR IN CONNECTION WITH THIS LICENSE OR THE USE OR PERFORMANCE OF THE SOFTWARE, WHETHER SUCH LIABILITY ARISES FROM ANY CLAIM BASED UPON BREACH OF CONTRACT, BREACH OF WARRANTY, TORT (INCLUDING NEGLIGENCE), PRODUCT LIABILITY OR ANY OTHER CAUSE OF ACTION OR THEORY OF LIABILITY, EVEN IF NVIDIA MELLANOX HAS PREVIOUSLY BEEN ADVISED OF, OR COULD REASONABLY HAVE FORESEEN, THE POSSIBILITY OF SUCH DAMAGES. IN NO EVENT WILL NVIDIA MELLANOX AND ITS AFFILIATES TOTAL CUMULATIVE LIABILITY UNDER OR ARISING OUT OF THIS LICENSE EXCEED US\$10.00. THE NATURE OF THE LIABILITY OR THE NUMBER OF CLAIMS OR SUITS SHALL NOT ENLARGE OR EXTEND THIS LIMIT.
11. Your rights under this license will terminate automatically without notice from NVIDIA Mellanox (a) upon expiration of your subscription, (b) if you fail to comply with

any term and condition of this license including non-payment of applicable fees, or (c) if you commence or participate in any legal proceeding against NVIDIA Mellanox with respect to the Software. NVIDIA Mellanox may terminate this license with advance written notice to you, if NVIDIA Mellanox decides to no longer provide the Software in a country or, in NVIDIA Mellanox's sole discretion, the continued use of it is no longer commercially viable. Upon any termination of this license, you agree to promptly discontinue use of the Software and destroy all copies in your possession or control. All provisions of this license will survive termination, except for the license granted to you.

12. **Product Support.** Product support for the Software Product is provided by NVIDIA Mellanox or its authorized agents under the applicable subscription license, in accordance with NVIDIA Mellanox's standard support and maintenance terms and conditions. For product support, please refer to NVIDIA Mellanox support number provided in the documentation.
13. **Applicable Law.** This license will be governed in all respects by the laws of the United States and of the State of Delaware, without regard to the conflicts of laws principles. The United Nations Convention on Contracts for the International Sale of Goods is specifically disclaimed. You agree to all terms of this license in the English language. The state or federal courts residing in Santa Clara County, California shall have exclusive jurisdiction over any dispute or claim arising out of this license. Notwithstanding this, you agree that NVIDIA Mellanox shall still be allowed to apply for injunctive remedies or urgent legal relief in any jurisdiction.
14. **No Assignment.** This license and your rights and obligations thereunder may not be assigned by you by any means or operation of law without NVIDIA Mellanox's permission. Any attempted assignment not approved by NVIDIA MELLANOX in writing shall be void and of no effect. NVIDIA Mellanox may assign, delegate, or transfer this license and its rights and obligations, and if to a non-affiliate you will be notified.
15. **E The Software is subject to United States export laws and regulations.** You agree to comply with all applicable U.S. and international export laws, including the Export Administration Regulations (EAR) administered by the U.S. Department of Commerce and economic sanctions administered by the U.S. Department of Treasury's Office of Foreign Assets Control (OFAC). These laws include restrictions on destinations, end-users and end-use. By accepting this license, you confirm that you are not currently residing in a country or region currently embargoed by the U.S. and that you are not otherwise prohibited from receiving the Software.
16. **Government Use.** The Software is, and shall be treated as being, "Commercial Items" as that term is defined at 48 CFR § 2.101, consisting of "commercial computer software" and "commercial computer software documentation", respectively, as such terms are used in, respectively, 48 CFR § 12.212 and 48 CFR §§ 227.7202 & 252.227-

7014(a)(1). Use, duplication or disclosure by the U.S. Government or a U.S. Government subcontractor is subject to the restrictions in this license pursuant to 48 CFR § 12.212 or 48 CFR § 227.7202. In no event shall the US Government user acquire rights in the Software beyond those specified in 48 C.F.R. 52.227-19(b)(1)-(2).

17. Please direct your legal notices or other correspondence to NVIDIA Corporation, 2788 San Tomas Expressway, Santa Clara, CA, 95051 United States of America, Attention: Legal Department and to: [NBU-Legal\\_Notices@exchange.nvidia.com](mailto:NBU-Legal_Notices@exchange.nvidia.com)

18. Entire Agreement. This license is the final, complete, and exclusive agreement between the parties relating to the subject matter of this license and supersedes all prior or contemporaneous understandings and agreements relating to this subject matter, whether oral or written. If any court of competent jurisdiction determines that any provision of this license is illegal, invalid, or unenforceable, the remaining provisions will remain in full force and effect. Any amendment or waiver under this license shall be in writing and signed by representatives of both parties.

(v APR. 28, 2022)

## Exhibit A

SOFTWARE includes the following open source/ freeware that are subject to specific license conditions listed in the table below, which may be updated from time to time by NVIDIA Mellanox or the Open Source provider. The below table is current as of December 2021. To obtain source code for software provided under licenses that require redistribution of source code, including the GNU General Public License or for update queries contact: [http://www.mellanox.com/page/gnu\\_code\\_request](http://www.mellanox.com/page/gnu_code_request). This offer is valid for a period of three (3) years from the date of the distribution of this product by NVIDIA Mellanox.

Component name	Version	Home Page	License
@candlefw/wick	0.8.12	<a href="https://github.com/galactrax/cfw-wick#readme">https://github.com/galactrax/cfw-wick#readme</a>	MIT License
ABSender	master-20121122	<a href="https://github.com/100Continue/ABSender">https://github.com/100Continue/ABSender</a>	Apache License 2.0
APBS	apbs-0.3.1	<a href="https://sourceforge.net/projects/apbs">https://sourceforge.net/projects/apbs</a>	GNU General Public License v2.0 or later
Amazon Kindle Source Code	6.2	<a href="http://www.amazon.com/gp/help/customer/display.html?nodeId=200203720">http://www.amazon.com/gp/help/customer/display.html?nodeId=200203720</a>	Apache License 2.0

<b>Component name</b>	<b>Version</b>	<b>Home Page</b>	<b>License</b>
Amiga Research OS	20120217	<a href="https://aros.sourceforge.io/licenses.html">https://aros.sourceforge.io/licenses.html</a>	Aros Public License V 1.1
Apache ActiveMQ	2.2.2	<a href="http://activemq.apache.org/">http://activemq.apache.org/</a>	Apache License 2.0
Apache HTTP Server	1.3.7, 1.3.8	<a href="http://httpd.apache.org/">http://httpd.apache.org/</a>	Apache License 1.0
Apache HTTP Server	2, 2.0.11, 2.0.23, 2.0.25, 2.0.26, 2.0.30, 2.0.33, 2.0.35, 2.0.36, 2.0.38, 2.0.39, 2.0.40, 2.0.41, 2.0.43, 2.1.0	<a href="http://httpd.apache.org/">http://httpd.apache.org/</a>	Apache License 1.1
Apache HTTP Server	2.0.59, 2.1.1, 2.1.10, 2.1.2, 2.1.3, 2.1.4, 2.1.5, 2.1.6, 2.1.7, 2.1.8, 2.1.9, 2.2.1, 2.2.2, 2.2.12, 2.2.13, 2.2.14, 2.2.15, 2.2.16, 2.2.17, 2.2.22, 2.2.26, 2.2.3, 2.2.4, 2.2.5, 2.2.6, 2.2.7, 2.2.9, 2.3.0, 2.3.1, 2.3.4	<a href="http://httpd.apache.org/">http://httpd.apache.org/</a>	Apache License 2.0
Apache HTTP Server	STRIKER_2_1_0_RC1	<a href="http://httpd.apache.org/">http://httpd.apache.org/</a>	Apache License 2.0
Apache Portable Runtime	0.9.13, 0.9.15, 1.2.0, 1.2.10, 1.2.11, 1.2.12, 1.2.7, 1.2.8, 1.2.9, 1.3.0, 1.3.1, 1.3.10, 1.3.12, 1.3.2, 1.3.3, 1.3.4, 1.3.5, 1.3.7, 1.3.8, 1.3.9, 1.4.7, 1.5.1, 1.5.2; APR_1_0_RC2; JCW_0_9_5_PRE1	<a href="http://apr.apache.org/">http://apr.apache.org/</a>	Apache License 2.0

Component name	Version	Home Page	License
Apache Portable Runtime	0.9.4 APACHE_2_0_37 APACHE_2_0_40 APACHE_2_0_44 APACHE_2_0_48	<a href="http://apr.apache.org/">http://apr.apache.org/</a>	Apache License 1.1
Apache Portable Runtime	APU_1_0_RC1	<a href="http://apr.apache.org/">http://apr.apache.org/</a>	(MIT License AND RSA Message-Digest License AND Apache License 2.0 AND Beerware License AND RSA MD4 or MD5 Message-Digest Algorithm License AND Christian Michelsen Research License AND Apache License 1.1)
Apache Tomcat	1.1.0, 6.0.24	<a href="http://tomcat.apache.org/">http://tomcat.apache.org/</a>	Apache License 2.0
BIND9 (Berkeley Internet Name Domain)	9.9.11	<a href="https://www.isc.org/wordpress/software/bind/">https://www.isc.org/wordpress/software/bind/</a>	Mozilla Public License 2.0
Berkeley DB	4.5.20	<a href="http://www.oracle.com/technology/products/berkeley-db/db/index.html">http://www.oracle.com/technology/products/berkeley-db/db/index.html</a>	BSD 3-clause "New" or "Revised" License
Chromium (Google Chrome)	32.0.1700.102	<a href="http://code.google.com/chromium/">http://code.google.com/chromium/</a>	BSD 3-clause "New" or "Revised" License
Cinder	v0.8.0	<a href="http://libcinder.org">http://libcinder.org</a>	BSD 3-clause "New" or

Component name	Version	Home Page	License
			"Revised" License
Clonezilla	1.2.10	<a href="http://clonezilla.org/">http://clonezilla.org/</a>	GNU General Public License v3.0 or later
Cron	3.0pl1	<a href="https://alioth.debian.org/projects/pkg-cron/">https://alioth.debian.org/projects/pkg-cron/</a>	Cron License
CyanogenMod - android_external_busybox	cm-10.1-M1, cm-10.1-M2	<a href="https://github.com/CyanogenMod/android_external_busybox/blob/cm-12.0/LICENSE">https://github.com/CyanogenMod/android_external_busybox/blob/cm-12.0/LICENSE</a>	GNU General Public License v2.0 or later
D-Bus	1.2.6	<a href="http://www.freedesktop.org/wiki/Software/dbus">http://www.freedesktop.org/wiki/Software/dbus</a>	Academic Free License v2.1
DHCP (ISC)	4.3.6	<a href="http://www.isc.org/downloads/dhcp/">http://www.isc.org/downloads/dhcp/</a>	ISC License
Darik's Boot and Nuke	dban-2.0.0	<a href="http://sourceforge.net/projects/dban">http://sourceforge.net/projects/dban</a>	(GNU Lesser General Public License v3.0 or later AND GNU General Public License v3.0 or later)
Debian Games	11.04.1+repack	<a href="http://wiki.debian.org/Games">http://wiki.debian.org/Games</a>	BSD 3-clause "New" or "Revised" License
FLAC - Free Lossless Audio Codec	flac-1.1.1-beta1-src	<a href="http://flac.sourceforge.net">http://flac.sourceforge.net</a>	BSD 3-clause "New" or "Revised" License
FarGroup/FarManager	builds/3.0.2890	<a href="https://github.com/FarGroup/FarManager/blob/master/LICENSE">https://github.com/FarGroup/FarManager/blob/master/LICENSE</a>	BSD 3-clause "New" or "Revised" License
FreeBSD	5.5, 6, 9.0-BETA1, release/11.2.0,12.2,	<a href="https://github.com/truoeos/truoeos">s</a>	BSD 2-clause "Simplified" License

Component name	Version	Home Page	License
	2.2.0, 2.2.6, 5.0.0cvs		
FreeBSD	bsd_44_lite	<a href="https://github.com/truEOS/truEOS">https://github.com/truEOS/truEOS</a>	BSD 4-clause "Original" or "Old" License
FreeBSD Ports	RELEASE_4_5_0 RELEASE_4_6_0	<a href="https://www.freebsd.org/ports/">https://www.freebsd.org/ports/</a>	BSD 2-clause FreeBSD License
FreeNAS	0.7	<a href="https://www.freenas.org/">https://www.freenas.org/</a>	BSD 3-clause "New" or "Revised" License
GD	2.0.1beta, 2.0.32, 2.0.33, 2.0.34RC1, 2.0.35, 2.0.35RC5	<a href="http://www.libgd.org">http://www.libgd.org</a>	GD License
GD	2.0.36_rc1	<a href="http://www.libgd.org">http://www.libgd.org</a>	(X11 License OR MIT License)
GLib	1.2.3, 2.14.6, 2.19.5	<a href="http://library.gnome.org/devel/glib/">http://library.gnome.org/devel/glib/</a>	Apache License 2.0
GNU Compiler Collection	4.7.0	<a href="http://gcc.gnu.org/">http://gcc.gnu.org/</a>	(GD License OR Unknown License)
GNU Libtool	1.4.1	<a href="http://www.gnu.org/software/libtool/">http://www.gnu.org/software/libtool/</a>	BSD 3-clause "New" or "Revised" License
GNU Parted	1.8.1, 2.4	<a href="http://www.gnu.org/software/parted">http://www.gnu.org/software/parted</a>	GNU General Public License v2.0 or later
GNU Parted	2.4	<a href="http://www.gnu.org/software/parted">http://www.gnu.org/software/parted</a>	GNU General Public License v3.0 or later
Gentoo Linux	release_1_3_17	<a href="https://www.gentoo.org/">https://www.gentoo.org/</a>	GNU General Public License v2.0 or later

<b>Component name</b>	<b>Version</b>	<b>Home Page</b>	<b>License</b>
Heimdal Kerberos	heimdal-0.0n	<a href="http://www.h5l.org/">http://www.h5l.org/</a>	BSD 3-clause "New" or "Revised" License
HipHop Virtual Machine for PHP	HHVM-3.1.0	<a href="https://github.com/facebook/hhvm">https://github.com/facebook/hhvm</a>	(PHP License v3.01 AND Zend License v2.0)
Kablank	1.1 Alpha1	<a href="https://www.kablank.org/">https://www.kablank.org/</a>	Apache License 2.0
Less	374	<a href="http://www.greenwoodsoftware.com/less/">http://www.greenwoodsoftware.com/less/</a>	BSD 2-clause "Simplified" License
Less	429	<a href="http://www.greenwoodsoftware.com/less/">http://www.greenwoodsoftware.com/less/</a>	GNU General Public License v2.0 or later OR Less License
LineageOS	cm-10.1.0-RC1	<a href="https://lineageos.org/">https://lineageos.org/</a>	(FSF Unlimited License AND BSD 3-clause "New" or "Revised" License)
Linux Test Project	2004	<a href="https://github.com/linux-test-project/ltp">https://github.com/linux-test-project/ltp</a>	GNU General Public License v2.0 or later
Linux-Pam	0.59, 0.72, 0.74, 0.76, 0.99.1.0, 0.99.2.0, 0.99.4.0, 0.99.5.0, 0.99.6.1, 0.99.6.2, 1.0.0	<a href="http://www.linux-pam.org">http://www.linux-pam.org</a>	BSD 3-clause "New" or "Revised" License
Linux-Pam	1.0.1	<a href="http://www.linux-pam.org">http://www.linux-pam.org</a>	(X11 License AND FSF Unlimited License)
MapServer	rel-1-0-0	<a href="http://mapserver.org">http://mapserver.org</a>	(X11 License AND MIT

Component name	Version	Home Page	License
			License)
Merruk-Technology	2.0-20121113	<a href="http://www.merruk.ma">http://www.merruk.ma</a>	GNU General Public License v2.0 only
MinGW - Minimalist GNU for Windows	binutils-2.20	<a href="http://mingw.sourceforge.net/">http://mingw.sourceforge.net/</a>	Public Domain
MythTV	v0.13	<a href="http://www.mythtv.org">http://www.mythtv.org</a>	GNU General Public License v2.0 or later
NFS	1.0.6	<a href="http://linux-nfs.org/">http://linux-nfs.org/</a>	GNU General Public License v2.0 or later
Net-SNMP	5.0.9, 5.4.2.1, 5.5.2.pre1, 5.7.3, END-UCD-SNMP, Ext-5-3-cvs20050331, JBPN-CBL-1, 5.0.11.1, 5.2.2	<a href="http://www.net-snmp.org">http://www.net-snmp.org</a>	(CMU License AND BSD 3-clause "New" or "Revised" License)
Net-SNMP	5.1.2, Ext-5-0, Ext-5-0-2, Ext-5-0-4, Ext-5-4-1-1, V4-2-patches-merge2	<a href="http://www.net-snmp.org">http://www.net-snmp.org</a>	(Diffstat License OR BSD 3-clause "New" or "Revised" License)
Net-SNMP	Ext-5-0, Ext-5-0-4	<a href="http://www.net-snmp.org">http://www.net-snmp.org</a>	(Diffstat License AND BSD 3-clause "New" or "Revised" License AND Christian Michelsen Research License)
Net-SNMP	Ext-5-4-1-1	<a href="http://www.net-snmp.org">http://www.net-snmp.org</a>	(Diffstat License AND

Component name	Version	Home Page	License
			BSD 3-clause "New" or "Revised" License AND Christian Michelsen Research License AND Bzip2 License)
Net-SNMP	V4-2-patches-merge2	<a href="http://www.net-snmp.org">http://www.net-snmp.org</a>	Diffstat License AND Christian Michelsen Research License)
Net-SNMP	5.2.4 source code, 5.2.5 pre-releases, 5.3.1, 5.3.2 pre-releases, 5.4.2 pre-releases, 5.5, Ext-4-0-pre5, Ext-4-1-pre1, Ext-5-0-2-pre1, Ext-5-0-7-pre1, Ext-5-0-8-pre1, Ext-5-2-2rc6, Ext-5-2-pre2, Ext-5-2-pre3, Ext-5-3-pre1, Ext-5-3-pre3, Ext-5-3-pre4, Ext-5-4-1-pre1, Ext-5-4-1-pre3, Ext-5-4-pre1, Ext-5-4-pre4, Ext-5-5-pre1, Ext-5-5-pre2, Ext-5-5-pre3, Ext-5-5-rc1, Ext-5-5-rc3, 5.3.0.1, 5.8.1.pre1, 5.8.1.pre2	<a href="http://www.net-snmp.org">http://www.net-snmp.org</a>	BSD 3-clause "New" or "Revised" License

<b>Component name</b>	<b>Version</b>	<b>Home Page</b>	<b>License</b>
NetBSD	1.1, 1.5, 2	<a href="http://www.netbsd.org">http://www.netbsd.org</a>	BSD 3-clause "New" or "Revised" License
OpenFabrics Enterprise Distribution - OFED	1.2, 1.5, 3.3.2018	<a href="https://www.openfabrics.org/downloads/rdmacm/">https://www.openfabrics.org/downloads/rdmacm/</a>	BSD 2-clause "Simplified" License
OpenFabrics Enterprise Distribution - OFED	3.1.8	<a href="https://www.openfabrics.org/downloads/rdmacm/">https://www.openfabrics.org/downloads/rdmacm/</a>	BSD 3-clause "New" or "Revised" License
OpenLDAP	2.4.44	<a href="http://www.openldap.org/">http://www.openldap.org/</a>	Open LDAP Public License v2.8
OpenSSH	5.3p1, 7.4p1, 7.7, 7.7p1, 7.8, 7.8p1, 7.9, 7.9p1, 8.0p1, pre-reorder	<a href="http://www.openssh.com/">http://www.openssh.com/</a>	BSD 3-clause "New" or "Revised" License
OpenSSH	7.2p2, 7.6p1	<a href="http://www.openssh.com/">http://www.openssh.com/</a>	X11 License
OpenWrt	12.09, 14.07	<a href="http://openwrt.org/">http://openwrt.org/</a>	GNU General Public License v2.0 or later
PCRE	7.1, 7.4, 7.6	<a href="http://www.pcre.org/">http://www.pcre.org/</a>	PCRE License
PCRE	4, 7.6, 7.7, 7.8	<a href="http://www.pcre.org/">http://www.pcre.org/</a>	BSD 3-clause "New" or "Revised" License
PHP	MERGE_FROM_NEW_LOOK_2001_TAG_1	<a href="http://svn.php.net">http://svn.php.net</a>	BSD 2-clause "Simplified" License
<a href="http://portableapps.com">PortableApps.com</a>	WinMerge 2.10.0 , 2.6.12Source	<a href="http://portableapps.com/">http://portableapps.com/</a>	Apache License 2.0
Python programming language	v2.4a2	<a href="https://www.python.org">https://www.python.org</a>	Python Software

<b>Component name</b>	<b>Version</b>	<b>Home Page</b>	<b>License</b>
			Foundation License 2.0
Qualcomm Kernel Tree for MSM/QSD family and Android 4.4	ath-201808291719	<a href="https://www.codeaurora.org/projects/all-active-projects/linux-msm">https://www.codeaurora.org/projects/all-active-projects/linux-msm</a>	ISC License
TACACS+ client library and PAM module	1.2.10, 1.2.9	<a href="https://sourceforge.net/projects/tacplus">https://sourceforge.net/projects/tacplus</a>	BSD 3-clause "New" or "Revised" License
Stephane-D/SGDK	V1.62	<a href="https://github.com/Stephane-D/SGDK/blob/master/license.txt">https://github.com/Stephane-D/SGDK/blob/master/license.txt</a>	MIT License
TACACS+ client library and PAM module	1.3.2	<a href="https://sourceforge.net/projects/tacplus">https://sourceforge.net/projects/tacplus</a>	GNU General Public License v2.0 or later
Tarifa	Tarifa019.tar	<a href="http://sourceforge.net/projects/tarifa">http://sourceforge.net/projects/tarifa</a>	GNU General Public License v2.0 or later
Tcl/Tk	8.1.1	<a href="http://www.tcl.tk/">http://www.tcl.tk/</a>	TCL/TK License
Tecla Library	1.2.3, 1.4.0, 1.4.1, 1.5.0, 1.6.0, 1.6.2	<a href="http://www.astro.caltech.edu/~mcs/tecla/index.html">http://www.astro.caltech.edu/~mcs/tecla/index.html</a>	MIT License
The GWARE Project	2.10.2	<a href="http://sourceforge.net/projects/gware">http://sourceforge.net/projects/gware</a>	GNU Lesser General Public License v2.1 or later
TizenRT	1.1_Public_Release	<a href="https://github.com/Samsung/TizenRT">https://github.com/Samsung/TizenRT</a>	Apache License 2.0
UC-7402.7408.7410.7420-LX Plus Source	20100210	<a href="http://www.moxa.com/product/UC-7408.htm">http://www.moxa.com/product/UC-7408.htm</a>	GNU General Public License v2.0 only
WinMerge	2.11.1.7	<a href="https://winmerge.org/">https://winmerge.org/</a>	Apache License 2.0

<b>Component name</b>	<b>Version</b>	<b>Home Page</b>	<b>License</b>
XAMPP	1.4.5, 1.6.4	<a href="https://www.apachefriends.org/index.html">https://www.apachefriends.org/index.html</a>	BSD 3-clause "New" or "Revised" License
XAMPP	1.6.4	<a href="https://www.apachefriends.org/index.html">https://www.apachefriends.org/index.html</a>	GNU General Public License v2.0 or later
XQilla	1.1.0	<a href="http://xqilla.sourceforge.net">http://xqilla.sourceforge.net</a>	BSD 3-clause "New" or "Revised" License
YaST	broken/svn/openSUSE-9_3	<a href="http://opensuse.org/YaST">http://opensuse.org/YaST</a>	MIT License
Zile (Zile is Lossy Emacs)	1.4, 1.5, 1.5.2, 1.5.3, 1.6, 1.6.1, 1.6.2	<a href="http://zile.sourceforge.net">http://zile.sourceforge.net</a>	GNU General Public License v2.0 or later
afwall	V2.6.0.1, v2.8.0, v2.9.0, v2.9.1, v2.9.4	<a href="https://github.com/ukanth/afwall">https://github.com/ukanth/afwall</a>	MIT License
alcatel	20	<a href="http://www.alcatel-mobilephones.com/">http://www.alcatel-mobilephones.com/</a>	Apache License 2.0
alcatel	4/18/2012, 20120601, 918	<a href="http://www.alcatel-mobilephones.com/">http://www.alcatel-mobilephones.com/</a>	GNU General Public License v2.0 or later
appweb	3.0B.0-0	<a href="http://code.google.com/p/appweb">http://code.google.com/p/appweb</a>	Apache License 2.0
asuswrt-merlin	376.48, 376.48, 380.62	<a href="https://github.com/RMerl/asuswrt-merlin">https://github.com/RMerl/asuswrt-merlin</a>	Artistic License 1.0
asuswrt-merlin	378.51, 380.62	<a href="https://github.com/RMerl/asuswrt-merlin">https://github.com/RMerl/asuswrt-merlin</a>	GNU General Public License v2.0 or later
avahi	v0.6	<a href="http://avahi.org">http://avahi.org</a>	GNU Lesser General Public License v2.1 or later

<b>Component name</b>	<b>Version</b>	<b>Home Page</b>	<b>License</b>
awokengazebo-lfi	lfi-20080723	<a href="http://www.awokengazebo.com/software/lfi/">http://www.awokengazebo.com/software/lfi/</a>	BSD 4-clause "Original" or "Old" License
beefproject	beef-0.4.3.1	<a href="http://beefproject.com">http://beefproject.com</a>	Apache License 2.0
bitswitcher	0.2.0, 0.3.0, 0.3.3	<a href="http://sourceforge.net/projects/bitswitcher">http://sourceforge.net/projects/bitswitcher</a>	GNU General Public License v2.0 or later
buildroot-kindle	master-20130206	<a href="https://github.com/twobob/buildroot-kindle">https://github.com/twobob/buildroot-kindle</a>	GNU General Public License v2.0 or later
busybox	1.10.0, 1.12.0, 1.2.0, 1.4.0, 1.5.0, 1.8.0, 1_11_0, 1_13_0, 1_14_1, 1_16_0, 1_17_1 17 1, 1_17_2, 1_18_0, 1_18_2, 1_19_0, 1_19_1, 1_19_4, 1_20_2, 1_21_0, 1_24_0, 1_29_0, 1_3_0, 1_7_0	<a href="https://github.com/mirror/busybox">https://github.com/mirror/busybox</a>	GNU General Public License v2.0 only
busybox	1_14_0, 1_15_0, 1_17_0, 1_19_2, 1_19_3, 1_20_0, 1_20_1, 1_28_0,	<a href="https://github.com/mirror/busybox">https://github.com/mirror/busybox</a>	GNU General Public License v2.0 or later
catboost/catboost	v0.2	<a href="https://catboost.ai">https://catboost.ai</a>	Apache License 2.0
curl	7.16.0	<a href="https://curl.se/">https://curl.se/</a>	curl License
decorator-ko	26, 28	<a href="http://jinsell.tistory.com/372">http://jinsell.tistory.com/372</a>	Public Domain
file	5.22	<a href="http://www.darwinsys.com/file/">http://www.darwinsys.com/file/</a>	Fine Free File Command License
fluxcapacitor	0	<a href="https://github.com/majek/fluxcapacitor">https://github.com/majek/fluxcapacitor</a>	MIT License

<b>Component name</b>	<b>Version</b>	<b>Home Page</b>	<b>License</b>
fvpatwds : fvpat Webdev Server	fvpatwds v0.1.4	<a href="http://sourceforge.net/projects/fvpatwds">http://sourceforge.net/projects/fvpatwds</a>	Apache License 2.0
generator-minxing	1.0.2	<a href="https://github.com/yeoman/generator-minxing#readme">https://github.com/yeoman/generator-minxing#readme</a>	Apache License 2.0
geonkick	2.3.6	<a href="https://github.com/iurie-sw/geonkick">https://github.com/iurie-sw/geonkick</a>	GNU General Public License v3.0 or later
hostap-ct	If-5.1.7, If-5.3.3, If-5.3.3b, If-5.3.4, If-5.3.5	<a href="https://github.com/greearb/hostap-ct">https://github.com/greearb/hostap-ct</a>	BSD 3-clause "New" or "Revised" License
hostapd	hostap_0_5_2, hostap_0_5_3, hostap_0_5_6,	<a href="http://w1.fi/hostapd/">http://w1.fi/hostapd/</a>	GNU General Public License v2.0 or later
howl	0.9.4, 0.9.6, 0.9.7, 0.9.9, 1.0.0,0.9.3, 0.9.1	<a href="https://howl.io">https://howl.io</a>	BSD 3-clause "New" or "Revised" License
illumos-joyent	20121101	<a href="http://www.illumos.org/projects/illumos-gate">http://www.illumos.org/projects/illumos-gate</a>	Common Development and Distribution License 1.0
krb5/krb5	1.0-alpha3, 1.0-beta2, 1.0-beta5	<a href="https://github.com/krb5/krb5">https://github.com/krb5/krb5</a>	Krb5-MIT License
libevent - an event notification library	0.1, 1.0d, 1.0e,1.4.1-beta	<a href="http://libevent.org/">http://libevent.org/</a>	BSD 3-clause "New" or "Revised" License
libexpat	1.95.0, 1.95.1, 1.95.2, 2.0.0, v19991013	<a href="http://www.libexpat.org/">http://www.libexpat.org/</a>	Expat License
libexpat	V19991013	<a href="http://www.libexpat.org/">http://www.libexpat.org/</a>	Mozilla Public License 1.1

<b>Component name</b>	<b>Version</b>	<b>Home Page</b>	<b>License</b>
linux-yocto-dev	v2.6.12	<a href="http://git.yoctoproject.org/cgi/cgit.cgi/linux-yocto-dev/">http://git.yoctoproject.org/cgi/cgit/cgit.cgi/linux-yocto-dev/</a>	GNU General Public License v2.0 with Linux Syscall Note
littlekernel-m900-eclair	master-20110326	<a href="http://github.com/LouZiffer/littlekernel-m900-eclair">http://github.com/LouZiffer/littlekernel-m900-eclair</a>	GNU General Public License v2.0 only
lmbd	0.9.18	<a href="http://symas.com/mdb/">http://symas.com/mdb/</a>	Open LDAP Public License
math-linux	0.0.1	<a href="http://sourceforge.net/projects/math-linux">http://sourceforge.net/projects/math-linux</a>	GNU General Public License v3.0 or later
mod_dup	2.5.0	<a href="http://github.com/Orange-OpenSource/mod_dup/">http://github.com/Orange-OpenSource/mod_dup/</a>	Apache License 2.0
ngx_pagespeed	1.9.32.4-dbg-ssl-crash	<a href="https://github.com/pagespeed/nginx_pagespeed">https://github.com/pagespeed/nginx_pagespeed</a>	Apache License 2.0
nss_ldap	253	<a href="https://github.com/PADL/nss_ldap">https://github.com/PADL/nss_ldap</a>	GNU Library General Public License v2 or later
opensm	3.3.17	<a href="http://www.openfabrics.org/">http://www.openfabrics.org/</a>	BSD 2-clause "Simplified" License
pGina	Plugin Bundle 05-11-2006	<a href="http://pgina.org/">http://pgina.org/</a>	MIT License
pam_radius	release_2_0_0	<a href="http://freeradius.org/pam_radius_auth/">http://freeradius.org/pam_radius_auth/</a>	GNU General Public License v2.0 only
protovis	3.3.1	<a href="http://mbostock.github.io/protovis/">http://mbostock.github.io/protovis/</a>	BSD 3-clause "New" or "Revised" License
root-project	5-13-04e	<a href="https://root.cern">https://root.cern</a>	(GNU Lesser General Public License v2.1 or later AND MIT

Component name	Version	Home Page	License
			License AND GNU General Public License v2.0 or later)
rsyslog	sysklogd-141-import	<a href="https://www.rsyslog.com/">https://www.rsyslog.com/</a>	GNU General Public License v2.0 or later
rtems-libbsd	5.1	<a href="http://git.rtems.org/rtems-libbsd.git/">http://git.rtems.org/rtems-libbsd.git/</a>	Apache License 2.0
rtl8186 - toolchain	0.5.5_src	<a href="http://rtl8186.sourceforge.net">http://rtl8186.sourceforge.net</a>	GNU General Public License v2.0 or later
snake-os	0.9	<a href="http://code.google.com/p/snake-os/">http://code.google.com/p/snake-os/</a>	GNU General Public License v2.0 or later
ssmtp	2.61	<a href="http://packages.qa.debian.org/s/ssmtp.html">http://packages.qa.debian.org/s/ssmtp.html</a>	GNU General Public License v2.0 or later
<a href="svn://svn.tug.org/g/texlive/trunk">svn://svn.tug.org/g/texlive/trunk</a>	texlive-2009.0	<a href="http://www.tug.org/texlive/">http://www.tug.org/texlive/</a>	LaTeX Project Public License - Version Unspecified
util-linux	2.11q, 2.11w, 2.12a, 2.13-pre1	<a href="https://en.wikipedia.org/wiki/Util-linux">https://en.wikipedia.org/wiki/Util-linux</a>	GNU General Public License v2.0 or later
videolan/vlc	0.5.0	<a href="https://github.com/videlalib/vlc">https://github.com/videlalib/vlc</a>	(GNU Lesser General Public License v2.1 or later AND GNU General Public License v2.0 or later)
wakame-vdc	v13.06.0	<a href="http://wakame.axsh.jp/">http://wakame.axsh.jp/</a>	Unknown License
wpa_supplicant - IEEE 802.1X, WPA, WPA2,	0.5.0, 0.5.3, 0.5.5, 0.5.	<a href="http://w1.fi/wpa_supplicant/">http://w1.fi/wpa_supplicant/</a>	BSD 3-clause "New" or

Component name	Version	Home Page	License
RSN, IEEE 802.11i	6, 0.5.8, 0.6.0, 0.6.10, 0.6.2, 0.6.3, 0.6.4, 0.6.8, 0.7.0, 0.7.1, 0.7.2, 0.7.3, 1, 2, 2.1, 2.2, 2.3, 2.4, 2.5, 2.6, 2.7, 2.7+git20190108+11ce7a1, , 2.7~git20180504+60a5737, 2.7~git20180606+b915f2c, 2.7~git20180706+420b5dd		"Revised" License
xorp.ct	1.5, xorp-1-7	<a href="http://www.candelatech.com/xorp.ct">http://www.candelatech.com/xorp.ct</a>	MIT License
zeroconf	0.9	<a href="https://files.pythonhosted.org/packages/20/d7/418ff6c684ace0f5855ec56c66cfa99ec50443c41693b91e9abcccfa096c/zeroconf-0.20.0.tar.gz">https://files.pythonhosted.org/packages/20/d7/418ff6c684ace0f5855ec56c66cfa99ec50443c41693b91e9abcccfa096c/zeroconf-0.20.0.tar.gz</a>	GNU General Public License v2.0 or later

## Notice

This document is provided for information purposes only and shall not be regarded as a warranty of a certain functionality, condition, or quality of a product. NVIDIA Corporation (“NVIDIA”) makes no representations or warranties, expressed or implied, as to the accuracy or completeness of the information contained in this document and assumes no responsibility for any errors contained herein. NVIDIA shall have no liability for the consequences or use of such information or for any infringement of patents or other rights of third parties that may result from its use. This document is not a commitment to develop, release, or deliver any Material (defined below), code, or functionality.

NVIDIA reserves the right to make corrections, modifications, enhancements, improvements, and any other changes to this document, at any time without notice.

Customer should obtain the latest relevant information before placing orders and should verify that such information is current and complete.

NVIDIA products are sold subject to the NVIDIA standard terms and conditions of sale supplied at the time of order acknowledgement, unless otherwise agreed in an individual sales agreement signed by authorized representatives of NVIDIA and customer (“Terms of Sale”). NVIDIA hereby expressly objects to applying any customer general terms and conditions with regards to the purchase of the NVIDIA product referenced in this document. No contractual obligations are formed either directly or indirectly by this document.

NVIDIA products are not designed, authorized, or warranted to be suitable for use in medical, military, aircraft, space, or life support equipment, nor in applications where failure or malfunction of the NVIDIA product can reasonably be expected to result in personal injury, death, or property or environmental damage. NVIDIA accepts no liability for inclusion and/or use of NVIDIA products in such equipment or applications and therefore such inclusion and/or use is at customer’s own risk.

NVIDIA makes no representation or warranty that products based on this document will be suitable for any specified use. Testing of all parameters of each product is not necessarily performed by NVIDIA. It is customer’s sole responsibility to evaluate and determine the applicability of any information contained in this document, ensure the product is suitable and fit for the application planned by customer, and perform the necessary testing for the application in order to avoid a default of the application or the product. Weaknesses in customer’s product designs may affect the quality and reliability of the NVIDIA product and may result in additional or different conditions and/or requirements beyond those contained in this document. NVIDIA accepts no liability related to any default, damage, costs, or problem which may be based on or attributable to: (i) the use of the NVIDIA product in any manner that is contrary to this document or (ii) customer product designs.

No license, either expressed or implied, is granted under any NVIDIA patent right, copyright, or other NVIDIA intellectual property right under this document. Information published by NVIDIA regarding third-party products or services does not constitute a license from NVIDIA to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property rights of the third party, or a license from NVIDIA under the patents or other intellectual property rights of NVIDIA.

Reproduction of information in this document is permissible only if approved in advance by NVIDIA in writing, reproduced without alteration and in full compliance with all applicable export laws and regulations, and accompanied by all associated conditions, limitations, and notices.

THIS DOCUMENT AND ALL NVIDIA DESIGN SPECIFICATIONS, REFERENCE BOARDS, FILES, DRAWINGS, DIAGNOSTICS, LISTS, AND OTHER DOCUMENTS (TOGETHER AND SEPARATELY, “MATERIALS”) ARE BEING PROVIDED “AS IS.” NVIDIA MAKES NO WARRANTIES, EXPRESSED, IMPLIED, STATUTORY, OR OTHERWISE WITH RESPECT TO THE MATERIALS, AND EXPRESSLY DISCLAIMS ALL IMPLIED WARRANTIES OF NONINFRINGEMENT, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE. TO THE EXTENT NOT PROHIBITED BY LAW, IN NO EVENT WILL NVIDIA BE LIABLE FOR ANY DAMAGES, INCLUDING WITHOUT LIMITATION ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES, HOWEVER CAUSED AND REGARDLESS OF THE THEORY OF LIABILITY, ARISING OUT OF

ANY USE OF THIS DOCUMENT, EVEN IF NVIDIA HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Notwithstanding any damages that customer might incur for any reason whatsoever, NVIDIA's aggregate and cumulative liability towards customer for the products described herein shall be limited in accordance with the Terms of Sale for the product.

## **Trademarks**

NVIDIA and the NVIDIA logo are trademarks and/or registered trademarks of NVIDIA Corporation in the U.S. and other countries. Other company and product names may be trademarks of the respective companies with which they are associated.

© Copyright 2024, NVIDIA. PDF Generated on 10/07/2024