



# **NVIDIA Firmware Tools (MFT) Documentation v4.36.0-147**

# Table of Contents

<b>1</b>	<b>Overview</b> .....	<b>12</b>
1.1	Intended Audience.....	12
1.2	Software Download.....	12
1.3	Document Revision History.....	12
<b>2</b>	<b>Release Notes</b> .....	<b>13</b>
2.1	Release Notes Update History.....	13
2.2	General Information.....	13
2.2.1	Package Tools.....	13
2.2.2	Software Dependencies.....	15
2.2.3	Dependencies.....	16
2.2.3.1	3rd Part MFT Dependencies.....	16
2.2.4	Supported Operating Systems and Platforms.....	16
2.2.5	Supported Flash Types.....	22
2.2.6	Supported NVIDIA Devices.....	22
2.2.7	Supported Adapter Cards Firmware Versions.....	23
2.2.8	Supported Switch Systems Software.....	24
2.3	Changes and New Features.....	24
2.3.1	Customer Affecting Changes.....	25
2.3.1.1	Changes in This Release.....	25
2.3.1.2	Changes Planned for Future Releases.....	25
2.3.1.3	Changes in Earlier Releases.....	25
2.3.1.4	Discontinued Features.....	26
2.3.2	Declared Unsupported Features.....	26
2.4	MFT Bug Fixes in this Version.....	26
2.5	MFT Known Issues.....	26
<b>3</b>	<b>User Manual</b> .....	<b>37</b>
3.1	Supported Operating Systems.....	37
3.2	MFTshell.....	38
3.3	Access to Hardware Devices.....	38
3.4	Compilation and Installation.....	41
3.5	Firmware Generation, Configuration, and Update Tools.....	41
3.5.1	mst Service.....	42
3.5.1.1	Linux.....	42

3.5.1.1.1	mst Synopsis - Linux.....	42
3.5.1.1.2	Using mst.conf File in Linux .....	44
3.5.1.1.3	Examples of mst Usage - Linux .....	44
3.5.1.2	Running mst in an Environment without a Kernel .....	45
3.5.1.3	Windows .....	46
3.5.1.3.1	mst Synopsis - Windows .....	46
3.5.1.4	FreeBSD .....	47
3.5.1.4.1	mst Synopsis - FreeBSD .....	47
3.5.1.5	VMware ESXi.....	48
3.5.1.5.1	mst Synopsis - VMware .....	48
3.5.2	MFT Configuration.....	49
3.5.2.1	MKey Configuration .....	49
3.5.3	mlxfwmanager - Firmware Update and Query Tool .....	50
3.5.3.1	mlxfwmanager Synopsis .....	50
3.5.3.2	Querying the Device .....	51
3.5.3.3	Archived Images Content.....	53
3.5.3.4	Parallel Query and Firmware Update Using fwctl .....	54
3.5.3.5	Updating the Device .....	54
3.5.3.5.1	Updating the Device Online.....	55
3.5.3.6	UPMF .....	57
3.5.3.7	UPMF Generation Flow .....	57
3.5.3.7.1	mlx_fwsfx_gen Usage .....	57
3.5.3.8	Updating Firmware Using an UPMF .....	59
3.5.4	mlxarchive - Binary Files Compression Tool.....	60
3.5.4.1	mlxarchive Synopsis.....	60
3.5.5	mlxconfig - Changing Device Configuration Tool .....	61
3.5.5.1	Tool Requirements.....	61
3.5.5.2	mlxconfig Synopsis .....	61
3.5.5.3	Bifurcation Configuration .....	63
3.5.5.4	Examples of mlxconfig Usage.....	65
3.5.5.4.1	Querying the Device Configuration .....	65
3.5.5.4.2	Setting Device Configuration .....	66
3.5.5.4.3	Resetting Device Configuration to Default .....	66
3.5.5.4.4	Setting Missing Parameters with Default Values .....	67
3.5.5.4.5	Configuring Per-Host TLV Parameters: Host ID and PF Index .....	67
3.5.5.5	Using mlxconfig .....	67
3.5.5.5.1	Using mlxconfig with PCI Device in Bus Device Function (BDF) Format .....	67
3.5.5.5.2	Using mlxconfig to Set IB/ETH Parameters.....	68
3.5.5.5.3	Using mlxconfig to Set PHY Parameters.....	68
3.5.5.5.4	Using mlxconfig to Set SR-IOV Parameters .....	70

3.5.5.5.5	Using mlxconfig to Set Preboot Settings .....	70
3.5.5.5.6	Using mlxconfig to Split a Port in a Remotely Managed Switch .....	71
3.5.5.5.7	mlxconfig Raw Configuration Files.....	73
3.5.5.5.8	Setting Pre-defined Configuration .....	74
3.5.5.6	mlxconfig Commands .....	75
3.5.5.6.1	mlxconfig Backup Command .....	75
3.5.5.6.2	Generating an XML Template for the Configurations.....	76
3.5.5.6.3	mlxconfig xml2raw Command .....	76
3.5.5.6.4	mlxconfig xml2bin Command .....	77
3.5.5.6.5	mlxconfig create_conf Command .....	77
3.5.5.6.6	mlxconfig apply Command .....	78
3.5.5.7	MFT Supported Configurations and Parameters.....	78
3.5.6	flint - Firmware Burning Tool.....	78
3.5.6.1	flint Synopsis .....	79
3.5.6.2	Tool Options .....	79
3.5.6.3	Command Parameters .....	82
3.5.6.4	Burning a Firmware Image .....	84
3.5.6.4.1	Burning the MFA2 Images.....	86
3.5.6.4.2	Burning PLDM Images .....	86
3.5.6.4.3	Cable Firmware Update (In-Field-Firmware-Update).....	86
3.5.6.5	Querying the Firmware Image.....	92
3.5.6.6	Verifying the Firmware Image .....	93
3.5.6.6.1	Comparing the Binary Image.....	93
3.5.6.6.2	The Verify Command on Encrypted Flash/Image .....	93
3.5.6.7	Performing Checksum Calculation on Image/Device .....	94
3.5.6.8	Managing an Expansion ROM Image .....	94
3.5.6.9	Setting GUIDs and MACs .....	95
3.5.6.9.1	4th Generation (Group I) Devices.....	95
3.5.6.9.2	5th Generation (Group II) Devices .....	97
3.5.6.9.3	Preparing a Binary Firmware Image for Pre-assembly Burning .....	100
3.5.6.10	Setting the VSD .....	102
3.5.6.11	Disabling/Enabling Access to the Hardware.....	102
3.5.6.11.1	5th Generation Devices.....	102
3.5.6.12	Flash Operations.....	103
3.5.6.12.1	Reading a Word from Flash.....	103
3.5.6.12.2	Writing a dword to Flash .....	103
3.5.6.12.3	Writing a dword to Flash Without Sector Erase .....	103
3.5.6.12.4	Erasing a Sector.....	104
3.5.6.12.5	Querying Flash Parameters.....	104
3.5.6.13	Firmware Timestamping for Multi-Host Environment .....	104
3.5.6.13.1	Setting a Timestamp on Image .....	105

3.5.6.13.2	Querying a Timestamp on Image .....	105
3.5.6.13.3	Resetting a Timestamp on Device.....	105
3.5.6.13.4	Setting a Timestamp on Device .....	105
3.5.6.13.5	Querying a Timestamp on Device .....	105
3.5.6.13.6	Resetting a Timestamp on Device.....	106
3.5.6.13.7	Important Notes .....	106
3.5.6.14	flint/mlxburn Limitations .....	106
3.5.6.15	Secure Host.....	106
3.5.6.15.1	Using Secure Host .....	107
3.5.6.15.2	Enabling Hardware Access .....	108
3.5.6.15.3	Key Loss Recovery .....	108
3.5.6.16	Secure Firmware Update.....	109
3.5.6.16.1	Secure Firmware Implications on Burning Tools .....	111
3.5.6.17	Burning/Querying a Component.....	111
3.5.6.17.1	Burning a Component Firmware Image .....	111
3.5.6.17.2	Querying the Component Firmware Image .....	111
3.5.7	mlxburn - Firmware Image Generator and Burner .....	112
3.5.7.1	mlxburn Synopsis .....	112
3.5.7.1.1	Connect-IB, Switch-IB, Switch-IB 2, NVIDIA Spectrum, ConnectX-4, and ConnectX-4 Lx Initial Burning Options.....	113
3.5.7.1.2	Additional mlxburn Options.....	113
3.5.7.2	Examples of mlxburn Usage.....	114
3.5.7.2.1	Query for firmware attributes (e.g., firmware version, GUIDs, etc.): .....	114
3.5.7.2.2	VPD read: .....	114
3.5.7.2.3	Burning bin file using mlxburn: .....	114
3.5.7.2.4	Detecting and burning the suitable bin file from a dir of several bin files: .....	114
3.5.7.2.5	To Query fw version of the given device:.....	115
3.5.7.2.6	Exit Return Values .....	115
3.5.8	mlxfwreset - Loading Firmware on 5th Generation Devices Tool.....	115
3.5.8.1	Tool Requirements.....	115
3.5.8.2	Query Command .....	115
3.5.8.3	Reset Command.....	115
3.5.8.4	mlxfwreset Synopsis .....	115
3.5.8.5	Reset Levels and Types .....	116
3.5.8.6	Reset Sync .....	117
3.5.8.7	Reset Method.....	117
3.5.8.8	PCIe Switch Reset via Hot Reset .....	117
3.5.8.9	Driver Detection Assistance.....	117
3.5.8.10	mlxfwreset for Switch Devices .....	118
3.5.8.11	mlxfwreset for Multi-Host NICs.....	119

3.5.8.12	mlxfwreset for SmartNICs (Bluefield) .....	119
3.5.8.13	mlxfwreset after Changing Configurations using mlxconfig .....	119
3.5.8.14	Examples of mlxfwreset Usage .....	119
3.5.8.15	mlxfwreset Status .....	120
3.5.8.16	mlxfwreset Limitations .....	120
3.5.9	mlxphyburn - Burning Tool for Externally Managed PHY .....	121
3.5.9.1	Tool Requirements.....	121
3.5.9.2	mlxphyburn Synopsis .....	121
3.5.9.3	Examples of mlxphyburn Usage .....	121
3.5.10	mlx_fpga - Burning and Debugging Tool for NVIDIA Devices with FPGA. 122	
3.5.10.1	Tool Requirements.....	122
3.5.10.2	mlx_fpga Synopsis .....	122
3.5.10.3	Examples of mlx_fpga Usage .....	123
3.5.10.3.1	Adding FPGA mst Device Interface.....	123
3.5.10.3.2	Burning the FPGA's Flash Device using the mlx_fpga Burning Tool ..	124
3.5.10.3.3	Loading the Tool .....	124
3.5.10.3.4	Debugging the Tool .....	124
3.5.10.3.5	Updating the FPGA Image .....	124
3.5.11	cpldupdate - Tool for Programming On-Board CPLDs on NVIDIA Devices .....	125
3.5.11.1	Tool Requirements.....	125
3.5.11.2	cpldupdate Synopsis .....	126
3.5.11.3	Burn Example .....	126
3.5.12	mlxprivhost - NIC Configuration by the Host Restriction Tool (Zero Trust Mode) .....	126
3.5.12.1	mlxprivhost Synopsis .....	126
3.5.13	mlxtokengenerator - Token Creation Tool .....	128
3.5.13.1	mlxtokengenerator Synopsis .....	128
3.5.13.1.1	Token Generation Process .....	129
3.5.14	mlxdpa - DPA Applications Sign Tool .....	129
3.5.15	mlxcableimgen - Cable Firmware Image Wrapper Generation Tool .....	132
3.5.16	nvredfish .....	132
3.5.16.1	BMC/HMC Dumps .....	133
3.6	Debug Utilities .....	133
3.6.1	fwtrace Utility .....	134
3.6.1.1	fwtrace Usage.....	134
3.6.2	mlxtrace Utility .....	136
3.6.2.1	mlxtrace Usage .....	136
3.6.3	mlxprtrace Utility .....	138

3.6.3.1	mlxptrace Usage .....	138
3.6.4	mstdump Utility .....	139
3.6.4.1	mstdump Usage .....	139
3.6.5	mlxi2c Utility .....	140
3.6.5.1	mlxi2c Usage .....	140
3.6.6	i2c Utility.....	141
3.6.6.1	i2c Usage (Advanced Users).....	141
3.6.6.2	Exit Return Values .....	142
3.6.7	mget_temp Utility .....	142
3.6.7.1	mget_temp Usage .....	142
3.6.8	mlxdump Utility .....	143
3.6.8.1	mlxdump Usage .....	143
3.6.9	mlxmcg Utility .....	144
3.6.9.1	mlxmcg Usage.....	144
3.6.10	pckt_drop Utility .....	145
3.6.10.1	pckt_drop Usage.....	145
3.6.11	mlxuptime Utility .....	145
3.6.11.1	mlxuptime Usage .....	146
3.6.12	wqdump Utility .....	146
3.6.12.1	wqdump Usage.....	146
3.6.13	mlxmdio Utility .....	149
3.6.13.1	mlxmdio Usage.....	149
3.6.14	mlxreg Utility .....	150
3.6.14.1	mlxreg Usage.....	151
3.6.15	mlxlink Utility .....	154
3.6.15.1	mlxlink Usage .....	155
3.6.15.2	Margin Scan Tool.....	163
3.6.15.3	RX Error Injection .....	163
3.6.15.3.1	Flags Usage .....	163
3.6.15.4	Rx-to-Tx Loopback Mode Activation .....	164
3.6.15.4.1	Prerequisite .....	164
3.6.15.5	Module PRBS Test Mode.....	165
3.6.15.5.1	Enabling\Disabling The Module PRBS Test Mode .....	165
3.6.15.5.2	Getting Module Information .....	165
3.6.15.5.3	PRBS Diagnostic Counters Information .....	166
3.6.15.6	Module Control Parameters.....	166
3.6.15.6.1	Querying and Configuring The Module Control Parameters .....	167
3.6.15.7	Tool Usage with NIC vs. Switch (-p Flag).....	167

3.6.15.8	Tool Usage on NVIDIA Quantum HDR Switch Systems with Split Ports .....	168
3.6.15.9	Tool Usage on NVIDIA Quantum-2 NDR Switch Systems .....	168
3.6.15.10	PCIe.....	168
3.6.15.10.1	Link Speed and Width.....	168
3.6.15.10.2	PCIe Switch.....	169
3.6.15.10.3	Link Counters .....	169
3.6.15.10.4	Link Eye Opening and Grade.....	170
3.6.15.10.5	Pass/Fail Criteria .....	170
3.6.16	mlxfwstress Utility .....	176
3.6.16.1	mlxfwstress Synopsis.....	177
3.6.16.2	Stress Types .....	178
3.6.16.2.1	ConnectX-4/ConnectX-4 Lx/ConnectX-5 Adapter Cards Stress Types .....	178
3.6.16.2.2	ConnectX-3 Pro Adapter Cards Stress Types .....	178
3.6.16.2.3	Turning On Stress Types.....	179
3.6.16.2.4	Turning Off Stress Types .....	180
3.6.16.2.5	Querying the Stress Types .....	180
3.6.16.3	Hang Types .....	180
3.6.16.3.1	ConnectX-4/ConnectX-4 Lx/ConnectX-5 Adapter Cards Hang Types.....	180
3.6.16.3.2	Turning On Hang Types.....	181
3.6.16.3.3	Turning Off Hang Types .....	181
3.6.16.3.4	Querying the Hang Types.....	181
3.6.16.4	Clearing all Stress/Hang Types .....	182
3.6.16.5	Clearing the Semaphore .....	182
3.6.16.6	Random Operation .....	182
3.6.16.6.1	Setting the Random Mode for the Stress Types .....	182
3.6.16.6.2	ConnectX-3/ConnectX-3 Pro Adapter Cards Hang Types.....	184
3.6.17	resourcedump Utility .....	184
3.6.17.1	resourcedump Usage .....	185
3.6.17.1.1	resourcedump query Usage .....	185
3.6.17.1.2	resourcedump dump Usage .....	186
3.6.18	resourceparse Utility .....	187
3.6.18.1	resourceparse Usage .....	187
3.6.19	stedump Utility .....	189
3.6.19.1	Prerequisites .....	190
3.6.19.2	stedump Usage.....	190
3.6.19.2.1	stedump live Usage .....	190
3.6.19.2.2	stedump live egress Usage .....	191
3.7	Cable Utilities .....	193
3.7.1	Cable Discovery .....	193

3.7.1.1	How to Discover the Cables.....	193
3.7.1.2	Representing the Cables in mst Status.....	193
3.7.1.2.1	Local Cables.....	193
3.7.1.2.2	Remote Cables.....	194
3.7.2	Working with Cables.....	194
3.7.3	mlx cables - Cables Tool.....	194
3.7.3.1	mlx cables Synopsis.....	195
3.7.3.2	MTUSB Cable Board.....	198
3.7.3.3	Cable Firmware Upgrade with Live-Patch.....	199
3.8	Troubleshooting.....	200
3.8.1	General Related Issues.....	200
3.8.2	mlxconfig Related Issues.....	200
3.8.3	Installation Related Issues.....	201
3.8.4	Firmware Burning Related Issues.....	201
3.8.5	Secure Firmware Related Issues.....	203
3.9	Appendixes.....	204
3.9.1	Assigning PSID.....	204
3.9.1.1	PSID Field Structure.....	204
3.9.1.2	Assigning PSID and Integrating Flow.....	204
3.9.2	Remote Access to NVIDIA Devices.....	205
3.9.2.1	Burning a Switch In-band Device Using mlxburn.....	205
3.9.2.2	In-Band Access to Multiple IB Subnets.....	206
3.9.2.3	MTUSB-1 USB to I2C Adapter.....	207
3.9.2.3.1	MTUSB-1 Package Contents.....	208
3.9.2.3.2	System Requirements.....	208
3.9.2.3.3	Supported Platforms.....	208
3.9.2.3.4	Hardware Installation.....	208
3.9.2.3.5	Software Installation.....	209
3.9.2.3.6	Switch Reprogramming through I2C Port.....	209
3.9.2.4	Remote Access to Device by Sockets.....	210
3.9.2.5	Accessing Remote InfiniBand Device by Direct Route MADs.....	211
3.9.3	Bootting HCA Device in Livefish Mode.....	212
3.9.3.1	Bootting Card in Livefish Mode.....	212
3.9.3.2	Bootting Card in Normal Mode.....	212
3.9.3.3	Common Locations of Flash Present Pins.....	212
3.9.4	Burning a New Device.....	213
3.9.4.1	Connect-IB Adapter Card.....	214
3.9.4.1.1	GUIDs and MACs.....	214
3.9.4.1.2	PCI Vital Product Data (VPD).....	214

3.9.4.1.3	Burning a New Connect-IB Device .....	214
3.9.4.2	ConnectX-4 onwards Adapter Cards Family .....	216
3.9.4.2.1	Burning the ConnectX-4 onwards Adapter Cards Family.....	216
3.9.4.3	Spectrum or Switch-IB 2 Switch Systems .....	218
3.9.4.3.1	Burning the Spectrum/Switch-IB 2 Device.....	218
3.9.4.4	Switch-IB Switch System .....	219
3.9.4.4.1	Burning the Switch-IB Device .....	220
3.9.5	Generating Firmware Secure and NV LifeCycle Configurations Files....	221
3.9.5.1	Create Forbidden Versions Binary File .....	221
3.9.5.2	Create Tokens for Secure Firmware and NV LifeCycle.....	222
3.9.6	Updating Firmware Using ethtool/devlink and .mfa2 File.....	222
3.9.7	Using MFT tools on Secured GPU Devices.....	224
3.10	ESXi .....	224
3.10.1	Supported plugin commands: .....	225
<b>4</b>	<b>Document Revision History.....</b>	<b>228</b>
4.1	Release Notes Revision History .....	228
4.1.1	MFT Release Notes Change Log History .....	228
4.1.2	MFT Bug Fixes History .....	234
4.2	User Manual Revision History.....	238
<b>5</b>	<b>Document Conventions and Related Documents.....</b>	<b>241</b>
5.1	Abbreviations and Acronyms .....	241
5.2	Reference Documents and Downloads .....	241
<b>6</b>	<b>Legal Notices and 3rd Party Licenses.....</b>	<b>242</b>



This version is not intended for GB/B customers. GB/B customers should use the designated release package to ensure full compatibility, qualification, and support alignment.

---

# 1 Overview

The NVIDIA<sup>®</sup> Firmware Tools (MFT) package is a set of firmware management and debug tools for NVIDIA devices. The document describes MFT features, tools content and configuration.

The documentation here relates to:

- [Release Notes](#)
- [User Manual](#)

## 1.1 Intended Audience

This manual is intended for system administrators responsible for managing and debugging firmware for NVIDIA devices.

See also [Document Conventions and Related Documents](#).

## 1.2 Software Download

To download product software, please refer to the [Firmware Tools \(MFT\)](#) product page.

## 1.3 Document Revision History

A list of the changes made to the user manual are provided in [User Manual Revision History](#).

## 2 Release Notes

These are the release notes for NVIDIA<sup>®</sup> Firmware Tools (MFT). MFT supports the following operating systems: Linux, Windows, VMware ESXi and FreeBSD. Please see the supported platform table for further details.

The tools functionality is identical in all operating systems unless otherwise noted.

### 2.1 Release Notes Update History

Revision	Date	Description
4.36.0-147	June 03, 2026	Initial release of this Release Notes version.

## 2.2 General Information

### 2.2.1 Package Tools

The following is a list of the available tools in the package, together with a brief description of each tool. The tools apply to single switch systems or adapter cards.



Please note that running MFT tools in parallel or simultaneously on the same device is not supported and might cause unexpected behavior.

The MFT tools do not provide cluster wide functionality.

Category	Tool	Description	Operating System
MST Service	mst	<ul style="list-style-type: none"><li>Lists the available mst devices</li><li>Start/stop the register access driver for Linux and VMware ESXi OSs.</li></ul>	All
Firmware Update and Configuration	mlxburn	This tool provides the following functions: <ul style="list-style-type: none"><li>Generating a standard or customized firmware image for burning in .bin format</li><li>Burning an image to the Flash attached to an HCA or switch device</li><li>Querying the firmware version loaded on a device</li><li>Displaying the Vital Product Data (VPD) of a network adapter</li></ul>	All
	flint	This tool burns a firmware binary image or an expansion ROM image to the Flash of a network adapter/ switch device. It includes query functions to the burnt firmware image and to the binary image file.	All
	mlxconfig	Allows the user to change some of the device configurations without having to create and burn a new firmware.	All

Category	Tool	Description	Operating System
	mlxfwmanager	The mlxfwmanager is a firmware update and query utility. It provides a simple 'single click' firmware update functionality. <b>Note:</b> The same tool with embedded firmware binaries is released separately and is named mlxup.	All
	mlxarchive	The mlxarchive tool allows the user to create a file with the mfa2 extension. The new file contains several binary files of a given firmware for different adapter cards.	Linux Windows FreeBSD
	mlxphyburn	A tool for burning externally managed PHY	Linux
	mlx_fpga	A tool for burning and debugging devices with FPGA. It allows the user to burn their own hardware code on an FPGA integrated with HCA board. It also provides the user with read/write registers in the QDR memory of the FPGA.	Linux
	cplupdate	A tool for programming on board CPLDs for NVIDIA devices for the OEM packages only.	Linux
Debug and Diagnostic Utilities	itrace	Extracts and prints trace messages generated by the firmware of a ConnectX-3 adapter cards.	All
	fwtrace	Extracts and prints trace messages generated by the firmware of 5th generation devices	Linux Windows FreeBSD
	mlxtrace	Dumps trace messages generated by the device hardware.	All
	mlxdump	Dumps device internal configuration registers. The dump file can be used by the Support team for hardware troubleshooting.	All
	mlxmcg	Displays the current multicast groups and flow steering rules configured in the device. Target users: Developers of Flow Steering aware applications.	All
	wqdump	Dumps the current QP contexts and Work Queues of ConnectX family network adapter cards and Connect-IB adapter cards.	All
	i2c	Generates an i2c transaction using an mtusb usb to i2c adapter or using the device internal i2c compatible master	Linux Windows FreeBSD
	mlx_i2c	Scans the i2c bus Routes the i2c bus of an externally managed InfiniscaleIV/ SwitchX system to connect to the switch silicon.	Linux Windows
	mget_temp	Reads the hardware temperature from NVIDIA devices internal sensors and prints the reading in Celsius degrees.	All
	pckt_drop	Corrupts the next transmitted packet from the ConnectX family network adapter cards and Connect-IB adapter cards.	All
	mlxuptime	Prints NVIDIA devices' up time and measured/configured core clock frequency	All
	mlxfwreset	Loads the firmware after firmware update on ISFU capable devices. (5th generation devices)	Linux Windows FreeBSD
	mlxmdio	Reads/writes MDIO registers (Clause 45) on boards with externally managed PHY	All
	mlxreg	Exposes supported access registers, and allows users to obtain information regarding the registers fields and attributes, and to set and get data with specific register.	All
	mstdump	Dumps device internal configuration data.	All

Category	Tool	Description	Operating System
	mcra	Reads/writes a single word from/to a device configuration register space	All
	mlxcables	Reads/writes NVIDIA cable registers and queries the cables info	All
	mlxlink	Displays and configures port related data at the physical layer.	All
	mlxvpd	Reads PCI device VPD	All
	mlxprivhost	Enables the user to restrict the hosts from configuring the NIC.	Linux
	resourcedump	Extracts and prints data segments generated by the firmware.	Linux Windows
	resourceparse	Parses and prints data segments content.	Linux Windows
	stedump	A packet simulator for host NIC steering solutions.	Linux

Detailed installation instructions along with complete descriptions of the various tools in the package can be found in the Firmware Tools User Manual.

## 2.2.2 Software Dependencies

Software Package	Required Version
<b>Linux</b>	
Kernel sources	Machine's kernel version
DOCA-Host <sup>1, 2</sup>	1.5.0 or later
Perl	5.24 or later
Python <sup>3</sup>	3.6 or later
lsusb <sup>4</sup>	
rpmbuild	
xz <sup>5</sup>	
<b>Windows</b>	
NVIDIA WinOF <sup>6</sup>	3.0.0 or later
<b>VMware ESXi</b>	
Python	3.6 or later

### Notes:

- DOCA-Host can be downloaded from <http://www.openfabrics.org>. Note that installing DOCA-Host is *not* required if you wish to install MFT without In-Band capabilities.

2. For the ‘mst ib add’ command to run, one of the DOCA-Host packages “ibutils” or “ibutils2” or “infiniband-diags” should be installed and available in the PATH. (For details on DOCA-Host installation, visit <https://docs.nvidia.com/networking/category/mlnxofedib>.)
3. Required for the mlxmcg tool only.
4. Required for the mtusb device usage.
5. For creating UPMF (update package for NVIDIA firmware).
6. WinOF is required only for In-Band access. The package can be downloaded from the [WinOF](#) page..
7. Python 2.x is now end-of-life and no longer supported by MFT. To use the latest and up-to-date MFT tools, we recommend you use Python 3.x.

## 2.2.3 Dependencies

### 2.2.3.1 3<sup>rd</sup> Part MFT Dependencies

Component name	Component version name	Home Page	License names
JSON-CPP	0.6.0	<a href="https://github.com/open-source-parsers/jsoncpp">https://github.com/open-source-parsers/jsoncpp</a>	MIT License
OpenSSL	1.1.1l	<a href="http://www.openssl.org/">http://www.openssl.org/</a>	The Open SSL License
Perl	v5.32.0	<a href="http://www.perl.org/">http://www.perl.org/</a>	Artistic License 1.0 (Perl)
SQLite	3.33.0	<a href="http://sqlite.org/">http://sqlite.org/</a>	Public Domain
XZ Utils	5.0.4	<a href="http://tukaani.org/xz/">http://tukaani.org/xz/</a>	Public Domain
Curl	7.79.1	<a href="https://curl.se/">https://curl.se/</a>	curl License
Iniparser	4.1	<a href="http://ndevilla.free.fr/iniparser">http://ndevilla.free.fr/iniparser</a>	MIT License
Libexpat	2.4.1	<a href="http://www.libexpat.org/">http://www.libexpat.org/</a>	MIT License
libxml2	2.9.10	<a href="http://www.xmlsoft.org/">http://www.xmlsoft.org/</a>	MIT License
Zlib	1.2.11	<a href="http://www.zlib.net/">http://www.zlib.net/</a>	zlib License

## 2.2.4 Supported Operating Systems and Platforms

MFT is supported on the following platforms:

Table Legend:

+ (Green)	Supported and tested
** (Orange)	Supported but not tested
*** Blue	Partially tested

Supported Operating Systems and Platforms

OS	Platform	Status
RH/CentOS 8.8	x86_64	+
RH/CentOS 8.8	PPC64LE	**
RH/CentOS 8.8	ARM64	+
RH/CentOS 8.10	x86_64	+
RH/CentOS 8.10	PPC64LE	+
RH/CentOS 8.10	ARM64	+
RH/Rocky 9.0	x86_64	+
RH/Rocky 9.0	PPC64LE	+
RH/Rocky 9.1	x86_64	+
RH/Rocky 9.1	PPC64LE	+
RH/Rocky 9.2	x86_64	+
RH/Rocky 9.2	PPC64LE	+
RH/Rocky 9.2	ARM64	+
RH/Rocky 9.3	x86_64	+
RH/Rocky 9.3	PPC64LE	+
RH/Rocky 9.3	ARM64	+
RH/Rocky 9.4	x86_64	+
RH/Rocky 9.4	PPC64LE	+
RH/Rocky 9.4	ARM64	+
RH/Rocky 9.5	x86_64	+
RH/Rocky 9.5	PPC64LE	+
RH/Rocky 9.5	ARM64	+
RH/Rocky 9.6	x86_64	+
RH/Rocky 9.6	PPC64LE	+
RH/Rocky 9.6	ARM64	+
RH/Rocky 9.7	x86_64	+
RH/Rocky 9.7	PPC64LE	+
RH/Rocky 9.7	ARM64	+
RH/Rocky 10	x86_64	+
RH/Rocky 10	PPC64LE	+
RH/Rocky 10	ARM64	+
RH/Rocky 10.1	x86_64	+
RH/Rocky 10.1	PPC64LE	+
RH/Rocky 10.1	ARM64	+
Centos Stream v8 - Community	x86_64	**
Centos Stream v8 - Community	PPC64LE	**

OS	Platform	Status
Centos Stream v9 - Community	x86_64	+
Centos Stream v9 - Community	ARM64	+
Centos Stream v9 - Community	PPC64LE	**
OEL 8.4	x86_64	+
OEL 8.6	x86_64	+
OEL 8.7	x86_64	+
OEL 8.8	x86_64	+
OEL 9.0	x86_64	+
OEL 9.1	x86_64	+
OEL 9.2	x86_64	+
OEL 9.5	x86_64	+
OEL 9.6	x86_64	+
OEL 9.7	x86_64	+
Fedora 32 - Community	x86_64	+
Fedora 35 - Community	x86_64	**
Sles15 SP2	x86_64	+
Sles15 SP2	PPC64LE	+
Sles15 SP3	PPC64LE	+
Sles15 SP3	x86_64	+
Sles15 SP4	PPC64LE	+
Sles15 SP4	x86_64	+
Sles15 SP5	PPC64LE	+
Sles15 SP5	x86_64	+
Sles15 SP6	PPC64LE	+
Sles15 SP6	x86_64	+
Sles15 SP7	x86_64	+
Sles15 SP7	PPC64LE	+
Sles15 SP7	ARM64	+
EulerOS V2.0 SP12	x86_64	+
EulerOS V2.0 SP12	ARM64	+
EulerOS V2.0 SP13	x86_64	+
EulerOS V2.0 SP13	ARM64	+
OpenEuler 20.3 SP1 - Community	x86_64	**
OpenEuler 20.3 SP3	x86_64	+
OpenEuler 22.3 LTS	x86_64	+
OpenEuler 22.03 SP4	x86_64	+

OS	Platform	Status
OpenEuler 22.3 SP1	x86_64	+
OpenEuler 24.3 SP0	x86_64	+
Ubuntu 20.04	x86_64	+
Ubuntu 20.04	ARM64	+
Ubuntu 20.04	PPC64LE	+
Ubuntu 22.04	x86_64	+
Ubuntu 23.10	x86_64	+
Ubuntu 24.04	x86_64	+
Ubuntu 24.04	ARM64	+
Ubuntu 24.04	PPC64LE	**
Ubuntu 25.04	x86_64	+
BCLinux 21.10 SP2	x86_64	+
BCLinux 21.10 SP2	ARM64	**
BCLinux 22.10 SP2	x86_64	+
BCLinux 22.10 SP2	ARM64	+
Debian 10.13	x86_64	+
Debian 10.13	ARM64	+
Debian 12.1	x86_64	+
Debian 12.1	ARM64	+
Debian 12.5	x86_64	+
Debian 12.5	ARM64	+
Debian 12.11	x86_64	+
Debian 13.0	x86_64	+
Debian 13.0	ARM64	+
Debian 13.1	x86_64	+
Debian 13.1	ARM64	+
Citrix server 8.2	x86_64	+
Anolis 8.4 - Community	x86_64	**
Anolis 8.6	x86_64	+
Anolis 8.6	ARM64	+
Korg 6.8	x86_64	+
Korg 6.8	ARM64	+
TencentOS 3.3	ARM64	+
TKLinux 3.3	x86_64	+
TKLinux 3.3	ARM64	**
OpenSUSE 15.3 - Community	x86_64	**

OS	Platform	Status
Photon 3.0 - Community	x86_64	**
CTYunOS2	x86_64	+
CTYunOS2	ppc64le	**
CTYunOS3	x86_64	+
CTYunOS3	ARM64	+
Mariner 2.0	x86_64	+
Alma 8.5	x86_64	**
KylinOS v10 SP3	x86_64	+
KylinOS v10 SP3	ARM64	+
Allinux 3.12	x86_64	+
Allinux 3.12	ARM64	+
Allinux 3.2	x86_64	+
Allinux 3.2	ppc64le	+
DriveOS 6.0.5.0	x86_64	+
DriveOS 6.0.5.0	ARM64	+
UOS v20 1040d -Community	x86_64	+
UOS v20 1060a	x86_64	+
UOS v20 1060a	ARM64	**
UOS v20 1060e	x86_64	+
UOS v20 1060e	ARM64	**
UOS v20 1021e	x86_64	+
UOS v20 1021e	ARM64	**
Windows Server 2016	64 Bit	+
Windows Server 2019	64 Bit	+
Windows Server 2022	64 Bit	+
Windows Server 2025	x86_64	+
Windows Server AH2023	64 Bit	+
Windows Server AH2022	64 Bit	+
Windows Server AH2021	64 Bit	+
Windows Server AH2020	64 Bit	+
Windows 10 21H2	64 Bit	+
Windows 10 22H2	64 Bit	+
Windows 10 1809	64 Bit	+
Windows 11 21H2	64 Bit	+
Windows 11 22H2	64 Bit	+
Windows 11 23H2	64 Bit	+

OS	Platform	Status
Windows 11 24H2	64 Bit	+
Windows 11 25H2	64 Bit	+
WinPE 4.0	32 Bit	+
WinPE 4.0	64 Bit	+
WinPE 5.0	32 Bit	+
WinPE 5.0	64 Bit	+
WinPE 5.1	32 Bit	+
WinPE 5.1	64 Bit	+
WinPE 10	32 Bit	+
WinPE 10	64 Bit	+
VeLinux 2.1	x86_64	+
VMware ESXi 8.0 Native (Vsphere 2022)	64 Bit	+
VMware ESXi 8.0 Native (Vsphere 2022)	ARM	+
VMware ESXi 8.0 u1 Native (Vsphere 2022)	64 Bit	+
VMware ESXi 8.0 u1 Native (Vsphere 2022)	ARM64	+
VMware ESXi 8.0 u2 Native (Vsphere 2022)	x86_64	+
VMware ESXi 8.0 u2 Native (Vsphere 2022)	ARM64	+
VMware ESXi 8.0 u3 Native	64 Bit	+
VMware ESXi 8.0 u3 Native	ARM64	+
VMware ESXi 9.0 Native	64 Bit	+
VMware ESXi 9.0 Native	ARM64	+
VMware ESXi 9.1 Native	64 Bit	+
VMware ESXi 9.1 Native	ARM64	+
FreeBSD 14.0-STABLE	x86_64	+
FreeBSD 15-CURRENT	x86_64	+
MLNX-OS 3.12.1000	64 Bit	+
SONiC 202511	64 Bit	+
Cumulus 5.9	64 Bit	+
NV-OS 25.02.1000	64 Bit	**
DVS 4.7.1000	64 Bit	+
FreeBSD 14.0-STABLE	ARM64	+
FreeBSD 15.0-CURRENT	ARM64	+
Korg6.16	X86_64	+
Mariner 3.0	X86_64	+
Xenserver 8.2	X86_64	+

## 2.2.5 Supported Flash Types

MFT supports the following Flash types.

Vendor	Flash Family	Tested P/N
Winbond	W25QxxBV	W25Q32FVSSIG
		W25Q32FVSSIGS
		W25Q32FVSSIGT
		W25Q128FVSSIGS
	W25Qxxx	W25Q256JVBIMT
		W25Q128JVSIQ
Macronix	MX25L16xxx	MX25L12845GM2I-08G
	MX25Lxxx	MX25L25645GXDI-08G
Micron	N25Q0xxx	MT25QL128ABA1ESE-0SIT
ISSI	IS25LPxxx	IS25LP128-JBLE SPA# U1323A
	IS25WPxxx	IS25WP256E-RHLE
Cypress	S25FL256L	S25FL256LDPBHV023
		S25FL128SAGMFGV00
Gigadevice		GD25LB256EBFRY
		GD25B256DFIGR

## 2.2.6 Supported NVIDIA Devices

The supported NVIDIA devices are listed in the following table:

IC Group	IC Device
Group II/5th Generation	<ul style="list-style-type: none"> <li>• Adapter Cards: <ul style="list-style-type: none"> <li>• NVIDIA ConnectX-9</li> <li>• NVIDIA ConnectX-8</li> <li>• NVIDIA ConnectX-8 - PCIe Switch</li> <li>• NVIDIA BlueField-3</li> <li>• NVIDIA BlueField-2</li> <li>• NVIDIA ConnectX-7</li> <li>• NVIDIA ConnectX-7 - PCIe Switch</li> <li>• NVIDIA ConnectX-6 Lx</li> <li>• NVIDIA ConnectX-6 Dx</li> <li>• NVIDIA ConnectX-6</li> <li>• NVIDIA ConnectX-5</li> <li>• NVIDIA ConnectX-4 Lx</li> <li>• NVIDIA ConnectX-4</li> </ul> </li> <li>• Switch Systems: <ul style="list-style-type: none"> <li>• NVIDIA NVLink5 Switch ASIC</li> <li>• NVIDIA Quantum-2</li> <li>• NVIDIA Quantum</li> <li>• NVIDIA Spectrum-5</li> <li>• NVIDIA Spectrum-4</li> <li>• NVIDIA Spectrum-3</li> <li>• NVIDIA Spectrum-2</li> <li>• NVIDIA Switch-IB 2</li> <li>• NVIDIA Switch-IB</li> </ul> </li> <li>• GPU <ul style="list-style-type: none"> <li>• NVIDIA GB300 NVL72 (Blackwell)</li> <li>• NVIDIA GB200 NVL72 (Blackwell)</li> </ul> </li> <li>• Retimer <ul style="list-style-type: none"> <li>• Arcus-E</li> <li>• Arcus-2</li> </ul> </li> </ul>

## 2.2.7 Supported Adapter Cards Firmware Versions

The following NVIDIA® network adapter cards are supported:

Adapter Card	Bundled Firmware Version
ConnectX-9	82.49.1014
ConnectX-8	40.49.1014
BlueField®-3	32.49.1014
BlueField®-2	24.49.1014
ConnectX-7	28.49.1014
ConnectX-6 Lx	26.49.1014
ConnectX-6 Dx	22.49.1014
ConnectX-6	20.43.8004
ConnectX-5	16.35.8008

ConnectX-4 Lx	14.32.1912
ConnectX-4	12.28.4706

To download the firmware binaries, please visit [Firmware Downloads](#).

## 2.2.8 Supported Switch Systems Software

The following are the Supported Switch Systems Software.

Switch Software	Version
MLNX-OS	3.12.3000
SONIC	202511
Cumulus	5.16.0.0087
DVS	4.8.3086
NVOS	25.02.7000

## 2.3 Changes and New Features

Component/ Tool	Description	Operating System
<b>Rev. 4.36.0-147</b>		
flint	Added support for firmware updates which change the minor portion of a device's PSID on supported hardware.	All
mlxfwmanager	Added support for MFA2 for Parallel Burn.	All
	Added support for Parallel DMA Firmware Update.	All
mlxfwreset	<b>[Beta Feature]</b> Added support for mlxfwreset Status.	All
mlxlink	Added support for <code>--smpci</code> flag, presenting the OE\ELS mappings.	All
	Added support for NVLink6 Switch ASIC.	All
	Added support for ELS operations (Laser On, Laser Off, Laser Up, Laser Down, Laser Tuning, Laser Wave Length Tuning).	All
	Added support for configuring pre-coding (RX\TX).	All
	Added support for port information for CPO devices.	All
mlxreg	Added support for using the <code>--get</code> and <code>--set</code> commands with the <code>--detailed</code> option. This feature enables users to view and modify register values with extended field-level information.	All
	Added support for using the <code>show_reg</code> command with the <code>--advanced</code> option in <code>mlxreg</code> . This feature enables users to view command templates and detailed descriptions for specific register fields.	All

Component/ Tool	Description	Operating System
<b>Rev. 4.36.0-147</b>		
mlxtokengenerator	Added support for: <ul style="list-style-type: none"> <li>• <code>--debug_fw_dir &lt;path&gt;</code></li> <li>• <code>--output_zip &lt;path&gt;</code></li> <li>• <code>--output_dir</code></li> </ul>	All
mget_temp Utility	Added support for reporting temperatures from on-board module sensors on supported devices. Added support for the following options: <ul style="list-style-type: none"> <li>• display precision ( <code>-precision</code> )</li> <li>• exclude module readings ( <code>--no-modules</code> )</li> </ul>	All
resourcedump	Added support for Resource Dump segment to dump the CR space, which lead to improvement in SysInfoSnapshot runtime.	All
Bug Fixes	See <a href="#">MFT Bug Fixes in this Version</a> .	All

## 2.3.1 Customer Affecting Changes

### 2.3.1.1 Changes in This Release

This section provides a list of changes that took place in the current version and break compatibility/interface, discontinue support for features and/or OS versions, etc.

Planned for Version	Description
N/A	N/A

### 2.3.1.2 Changes Planned for Future Releases

This section provides a list of changes that will take place in a future version of the product and will break compatibility/interface, discontinue support for features and/or OS versions, etc.

Planned for Version	Description
N/A	N/A

### 2.3.1.3 Changes in Earlier Releases

This section provides a list of changes that took place throughout the past two major releases that broke compatibility/interface, discontinued support for features and/or OS versions, etc.

For an archive of all changes, please refer to the Release Notes History section.

Planned for Version	Description
N/A	N/A

### 2.3.1.4 Discontinued Features

List of features which are supported in previous generations of hardware devices.

N/A

### 2.3.2 Declared Unsupported Features

This section provides a list of features that are not supported by the software.

N/A

## 2.4 MFT Bug Fixes in this Version

For a list of old Bug Fixes, please see [MFT Bug Fixes History](#).

Internal Ref.	Description
4981230	<b>Description:</b> Fixed initialization order issue to ensure device callbacks are set before registration. In addition, added NULL pointer checks in ioctl paths to prevent invalid access.
	<b>Keywords:</b> NULL, ioctl paths
	<b>Discovered in Version:</b> 4.30.1-8
	<b>Fixed in Release:</b> 4.36.0-147
4745544	<b>Description:</b> Changed the algorithm for determining the default reset level (new behavior). As a result, if only Sync 2 is supported, the tool falls back to system reboot.
	<b>Keywords:</b> Sync 2
	<b>Discovered in Version:</b> 4.34.1-10
	<b>Fixed in Release:</b> 4.35.0-159

## 2.5 MFT Known Issues

The following table provides a list of known issues and limitations.

Internal Ref. No.	Issue
5046217	<b>Description:</b> Working with cables on Ubuntu 26 may display “double free” messages, but this does not affect the functionality.
	<b>Workaround:</b> Ignore the double free messages.

Internal Ref • No •	Issue
	<p><b>Keywords:</b> cable device, core dump</p> <p><b>Discovered in Version:</b> 4.36.0-147</p>
5040 399	<p><b>Description:</b> On Debian, installing kernel-mft-dkms from a local apt repository while a linux-image-* package is being installed or upgraded at the same <code>apt install</code> invocation, causes the linux-image-* postinst to abort with:</p> <pre>Module /lib/modules/&lt;kver&gt;/updates/dkms/&lt;mod&gt;.ko.xz already installed (unversioned module), override by specifying --force.</pre> <p><b>Workaround:</b> First, install or upgrade the Kernel as a separate step, then install kernel-mft-dkms (or doca-) in a second apt transaction:</p> <ul style="list-style-type: none"> <li>• <code>apt install linux-image-&lt;ver&gt;</code></li> <li>• <code>apt install kernel-mft-dkms # or doca</code></li> </ul> <p><b>Keywords:</b> Kernel, kernel-mft-dkms</p> <p><b>Discovered in Version:</b> 4.36.0-147</p>
4979 539	<p><b>Description:</b> Running commands in parallel on a remote MTUSB device may cause undefined behavior.</p> <p><b>Workaround:</b> Avoid running commands in parallel on the remote MTUSB device.</p> <p><b>Keywords:</b> remote, MTUSB</p> <p><b>Discovered in Version:</b> 4.35.0-159</p>
4889 151	<p><b>Description:</b> Running IB discovery to access the NVSwitches (<code>mst ib add</code>) in B200/300 systems, results in getting MADs errors.</p> <p><b>Workaround:</b> Run <code>mst ib add mlx5_0</code></p> <p><b>Keywords:</b> mst ib add</p> <p><b>Discovered in Version:</b> 4.35.0-159</p>
4802 159	<p><b>Description:</b> Some addresses may be blocked in firmware when accessing via interfaces with low privileges such as PCIe BAR0 (<code>pci_cr</code>).</p> <p><b>Workaround:</b> Use the privileged path (<code>pciconf device</code>).</p> <p><b>Keywords:</b> PCIe BAR0, pciconf device</p> <p><b>Discovered in Version:</b> 4.35.0-159</p>
4661 761	<p><b>Description:</b> mlx cables DDM query is not supported for new generation modules.</p> <p><b>Workaround:</b> mlxlink provides DDM information which contains all mlx cables DDM query fields.</p> <ul style="list-style-type: none"> <li>• mlxlink command for HCA: <code>mlxlink -d &lt;dev&gt; --cable --ddm</code></li> <li>• mlxlink command for Switch: <code>mlxlink -d &lt;dev&gt; -p &lt;port number&gt; --cable --ddm</code></li> </ul>

Internal Ref · No ·	Issue
	<p><b>Keywords:</b> mlx cables, DDM, mlxlink</p> <p><b>Discovered in Version:</b> 4.35.0-159</p>
4682 265	<p><b>Description:</b> When running FWtrace on Python 3.6 with remote device, the tool might crash with segmentation fault due to a problem with shared object imports.</p> <p><b>Workaround:</b> Upgrade Python version to 3.8 and above.</p> <p><b>Keywords:</b> FWtrace, Python</p> <p><b>Discovered in Version:</b> 4.34.0-145</p>
4414 021	<p><b>Description:</b> In PCIe Switch-only product, if all PCIe Links are down, the device might enter power-save mode. In this case, MFT tools will not be able to access the device.</p> <p><b>Workaround:</b> Remove the device from the power-save mode in order to be able to use MFT tools on it.</p> <p><b>Keywords:</b> PCIe</p> <p><b>Discovered in Version:</b> 4.34.0-145</p>
-	<p><b>Description:</b> mlxptrace does not run on Spectrum-5 switch systems due to missing firmware support.</p> <p><b>Workaround:</b> Use mlxtrace instead of mlxptrace.</p> <p><b>Keywords:</b> mlxptrace, mlxtrace, tracer tools, Spectrum-5 switch systems</p> <p><b>Discovered in Version:</b> 4.34.0-145</p>
4524 862	<p><b>Description:</b> Running mlxfwreset over BlueField-2 and BlueField-3 devices when driver is down, results with wrong error message.</p> <p><b>Workaround:</b> Use the needed flags for the sync and not rely on the defaults.</p> <p><b>Keywords:</b> mlxfwreset, BlueField-2, BlueField-3</p> <p><b>Discovered in Version:</b> 4.33.0-3002</p>
4296 168	<p><b>Description:</b> The default reset level is not executed in hot plug systems when the host CPU is in the DPU root complex.</p> <p><b>Workaround:</b> Using explicitly reset method 1 parameter in CLI. Execute the following command: <code>mlxfwreset --device &lt;dev&gt; reset --method 1</code></p> <p><b>Keywords:</b> BlueField-3, DPU Mode</p> <p><b>Discovered in Version:</b> 4.32.0-120</p>

Internal Ref • No •	Issue
4294 588/ 4799 744	<p><b>Description:</b> In some cases, BlueField-3 users might experience a misleading error message following mlxfwreset command with sync 1 and method 1 (hot reset), even though the reset was completed successfully. The error message is: "-E- The PCI link is still up even after the expected time (360.0) seconds has passed. Exiting the process."</p> <p><b>Workaround:</b> Ignore the misleading error message.</p> <p><b>Keywords:</b> mlxfwreset, hot reset</p> <p><b>Discovered in Version:</b> 4.31.0-149</p>
4258 362	<p><b>Description:</b> When testing the tools using RDMA as the device, they do not work when mst is stopped/ started.</p> <p><b>Workaround:</b> RDMA rename feature is supported only after running the mst start command.</p> <p><b>Keywords:</b> tools, mst, RDMA</p> <p><b>Discovered in Version:</b> 4.31.0-149</p>
4129 306	<p><b>Description:</b> Autocomplete feature is not working as expected for Ubuntu 24.10. Error messages might appear (for example: /etc/bash_completion.d/mft/mft_base_autocomplete: No such file or directory). MFT functionalities are all working as expected, only autocomplete on Ubuntu 24.10 is affected.</p> <p><b>Workaround:</b> Execute the following cmd: <code>ln -snf /usr/etc/bash_completion.d/* /etc/bash_completion.d/</code></p> <p><b>Keywords:</b> Autocomplete, Ubuntu</p> <p><b>Discovered in Version:</b> 4.30.0-139</p>
4089 179	<p><b>Description:</b> When using mlxlink with --show_module(-m) flag, Rx/TX Power Current [dBm] fields show the same output for all lanes.</p> <p><b>Workaround:</b> To get the Power Current values, use mlxreg with PDDR register indexes: page_select=3, module_info_ext=1, local_port=&lt;local_port&gt; and read rx_power_lane&lt;lane_num&gt;/ tx_power_lane&lt;lane_num&gt; to get the data for each lane. For example:</p> <pre data-bbox="276 1559 1393 1671">mlxreg -d /dev/mst/hgx-isr1-020:23108,@dev@mst@mt41692_pciconf1 --get --reg_name PDDR --indexes "port_type=0,plane_ind=0,lp_msb=0,pnat=0,local_port=1,page_select=3,group_opcode=0,tracer_mode=0,pre_trigger_buff_mode=0,trigger_cond_fsm=0,trigger_cond_state_or_event=0,trigger_cond_state_event_val=0,pport=0,fsn_mask=0,isr_access_enums=0,tracer_sel=0" --op "module_info_ext=1"</pre> <p><b>Keywords:</b> mlxlink, Rx/TX Power Current</p> <p><b>Discovered in Version:</b> 4.29.0-131</p>

Internal Ref · No ·	Issue
3262 855	<p><b>Description:</b> The mlxfwreset tool might fail when using PPC64LE on the RH 8.7 operating system.</p> <p><b>Workaround:</b> N/A</p> <p><b>Keywords:</b> mlxfwreset, PPC64LE</p> <p><b>Discovered in Version:</b> 4.29.0-131</p>
3926 386	<p><b>Description:</b> Secure boot devices, such as ConnectX7 and above, does not expose the PXE/UEFI ROM data version by running flint on IMG file.</p> <p><b>Workaround:</b> N/A</p> <p><b>Keywords:</b> ConnectX7, PXE/UEFI ROM data, IMG file</p> <p><b>Discovered in Version:</b> 4.29.0-131</p>
3886 315	<p><b>Description:</b> '--sync 0' argument must be specified when resetting or shutting down the Arm.</p> <p><b>Workaround:</b> N/A</p> <p><b>Keywords:</b> mlxfwreset, sync 0, ARM</p> <p><b>Discovered in Version:</b> 4.28.0-92</p>
3872 303	<p><b>Description:</b> Activation of MMS4X00-NS transceivers may fail with rc=8 following multiple "Activating burned FW image..." prints.</p> <p><b>Workaround:</b> Reset the Switch/HCA to activate the new firmware on the cable.</p> <p><b>Keywords:</b> MMS4X00-NS</p> <p><b>Discovered in Version:</b> 4.28.0-92</p>
3743 317	<p><b>Description:</b> Reset flow is not supported when Hotplug is enabled. The NIC driver reports an error state using the 'negotiation dis-acknowledgment' MFRL register</p> <p><b>Workaround:</b> N/A</p> <p><b>Keywords:</b> Reset flow, Hotplug</p> <p><b>Discovered in Version:</b> 4.26.1</p>
3738 146	<p><b>Description:</b> mlxfwreset does not support MRSR-6 when using Quantum-3 and Spectrum-4 based switch systems.</p> <p><b>Workaround:</b> N/A</p> <p><b>Keywords:</b> mlxfwreset, MRSR-6</p> <p><b>Discovered in Version:</b> 4.26.1</p>
3641 618	<p><b>Description:</b> Running a command triggers the following error message:</p> <pre data-bbox="277 1865 1385 1933">/lib/ libgcc_s.so .1: version GCC_4.5.0 required by /usr/local/lib/gcc12/libstdc++.so.6 not found</pre>

Internal Ref · No ·	Issue
	<p><b>Workaround:</b> Run the following command:</p> <pre>export LD_LIBRARY_PATH=/usr/local/lib/gcc12:\$LD_LIBRARY_PATH</pre> <p><b>Keywords:</b> libstd, gcc, mft, libgcc</p> <p><b>Discovered in Version:</b> 4.26.0</p>
3549 141	<p><b>Description:</b> mlxfwreset usage by the Prometheus PCIe switch is currently not supported.</p> <p><b>Workaround:</b> N/A</p> <p><b>Keywords:</b> mlxfwreset, Prometheus PCIe switch</p> <p><b>Discovered in Version:</b> 4.25.0</p>
3262 855	<p><b>Description:</b> The mlxfwreset tool might fail when using PPC64LE on the RH 8.7 operating system.</p> <p><b>Workaround:</b> N/A</p> <p><b>Keywords:</b> mlxfwreset, PPC64LE, RH 8.7</p> <p><b>Discovered in Version:</b> 4.25.0</p>
3090 162	<p><b>Description:</b> The PCIe Error Injection feature is not supported due to a security limitation.</p> <p><b>Workaround:</b> N/A</p> <p><b>Keywords:</b> PCI Error Injection</p> <p><b>Discovered in Version:</b> 4.22.0</p>
3446 066	<p><b>Description:</b> When using ConnectX-7 and later cards, the link should be fully down (not in polling state) for the loopback configuration can be applied.</p> <p><b>Workaround:</b> N/A</p> <p><b>Keywords:</b> mxlink</p> <p><b>Discovered in Version:</b> 4.23.0</p>
3352 983	<p><b>Description:</b> mlxfwreset does not work on mlnx-os/sonic/cumulus.</p> <p><b>Workaround:</b> N/A</p> <p><b>Keywords:</b> mlxfwreset</p> <p><b>Discovered in Version:</b> 4.23.0</p>
3418 112	<p><b>Description:</b> Loading a new firmware may require running <code>mlxfwreset</code>, and in some cases rebooting or initiating a power-cycle.</p> <p><b>Workaround:</b> N/A</p> <p><b>Keywords:</b> mlxfwreset</p> <p><b>Discovered in Version:</b> 4.24.0</p>

Internal Ref · No ·	Issue
3314 750	<p><b>Description:</b> When entering link speed values, you can specify a single value (i.e "HDR") or a list of values separated by commas (i.e "HDR, FDR, SDE"). In the current MFTshell version, the autocomplete feature suggesting possible values, only works for the first value in a list of values separated by commas.</p> <p>Additionally, the autocompletion list includes all possible speeds. Some of them may not be supported by the device. Once the command is fired, you will be notified in case the selected speed is not supported.</p> <p>Affected shell commands are:</p> <pre>port speed port autonegotiation on speed port autonegotiation off speed</pre> <p>Any inconvenience caused by these limitations will be addressed in future MFTshell updates.</p> <p><b>Workaround:</b> When entering a link speed, you may press the &lt;TAB&gt; key first. This will provide you with all possible values. You can then select the desired link speed value, copy and paste it into the command prompt, and type a comma (,) to select the next speed. Repeat the process to form a list of all desired link speed values separated by commas.</p> <p>Once the command is fired, the underlying MFT tool will inform you if the selected speed is not supported by the device.</p> <p>In addition, the <code>help</code> context for the affected shell commands includes detailed explanations of the available options.</p> <p><b>Keywords:</b> mft-shell, link-speed</p> <p><b>Discovered in Version:</b> 4.23.0</p>
3188 577	<p><b>Description:</b> Some firmware scratchpad registers have been moved to a different location. Therefore, if you use your own utility to dump mstdumps, you must update your CSV file with the latest CSV, CSV2 files that are included in the MFT package.</p> <p>Otherwise, the mstdumps device will not retrieve the firmware version, and the FAEs will not be able to use NVIDIA internal tools to debug the error.</p> <p><b>Workaround:</b> N/A</p> <p><b>Keywords:</b> CSV, mstdump</p> <p><b>Discovered in Version:</b> 4.22.0</p>
2787 479	<p><b>Description:</b> mlxcables shows the wrong firmware version for OSFP cables.</p> <p><b>Workaround:</b> N/A</p> <p><b>Keywords:</b> mlxcables, OSFP, firmware version</p> <p><b>Discovered in Version:</b> 4.18.0</p>
2823 492	<p><b>Description:</b> mlxfwreset is not supported on DPU with GPU boards.</p> <p><b>Workaround:</b> N/A</p> <p><b>Keywords:</b> mlxfwreset</p>

Internal Ref · No ·	Issue
	<b>Discovered in Version:</b> 4.18.0
2715 716	<b>Description:</b> mlxfwreset is not supported on secure-boot host devices.
	<b>Workaround:</b> N/A
	<b>Keywords:</b> mlxfwreset
	<b>Discovered in Version:</b> 4.18.0
2752 916	<b>Description:</b> The information of the IB/ETH protocols should not be stored on the same CSV file. Doing so will result in a mismatch on the columns of CSV file.
	<b>Workaround:</b> N/A
	<b>Keywords:</b> mlxlink
	<b>Discovered in Version:</b> 4.18.0
2838 222	<b>Description:</b> mlxfwreset is not supported on kernel 3.10.0-1062.el7.x86_64 due to a kernel bug that leads to 'rescan' PCI operation to take a few minutes.
	<b>Workaround:</b> N/A
	<b>Keywords:</b> mlxfwreset
	<b>Discovered in Version:</b> 4.18.0
2703 663	<b>Description:</b> Running flint commands on the hypervisor while a Virtual Machine is running with the same device (pass-through), may cause kernel panic.
	<b>Workaround:</b> N/A
	<b>Keywords:</b> flint, kernel, VM
	<b>Discovered in Version:</b> 4.17.0
2670 833	<b>Description:</b> Burning firmware using DMA might fail on virtual FreeBSD machines.
	<b>Workaround:</b> N/A
	<b>Keywords:</b> Firmware burning, DMA, FreeBS, VM
	<b>Discovered in Version:</b> 4.17.0
2484 780	<b>Description:</b> Configuring TX/RX_rate to 200GbE in test mode fails.
	<b>Workaround:</b> To work with the new speeds specify the number of lanes as shown below: <ul style="list-style-type: none"> <li>• 100G_1X/200G_2X/400G_4X/800G_8X for NDR speeds</li> <li>• 50G_1X/100G_2X/200G_4X/400G_4X for HDR speeds</li> </ul>
	<b>Keywords:</b> 200GbE, Tx/Rx
	<b>Discovered in Version:</b> 4.17.0

Internal Ref · No ·	Issue
2392 334	<p><b>Description:</b> Using the MFT with the --with-pcap option to install stedump utility requires the following third-party dependencies:</p> <ul style="list-style-type: none"> <li>• Libraries and header files for the libpcap library</li> <li>• Libraries and header files for Python development library</li> <li>• Package Installer for Python (PIP) available</li> </ul> <p><b>Workaround:</b> To install the third-party dependencies, perform the following:</p> <ol style="list-style-type: none"> <li>1. Install <code>libpcap-devel</code> or <code>libpcap-dev</code> on Debian-based distributions.</li> <li>2. Install <code>python3-devel</code> or <code>python3-dev</code> on Debian-based distributions.</li> <li>3. Bootstrap the PIP installer in one of the following ways: <ul style="list-style-type: none"> <li>• On Python 3.4 or newer bootstrap it from the standard library by running the <code>"python -m ensurepip"</code> command.</li> <li>• Install PIP with Linux Package Manager, for more details see: <a href="https://packaging.python.org/guides/installing-using-linux-tools/">https://packaging.python.org/guides/installing-using-linux-tools/</a></li> </ul> </li> </ol> <p><b>Keywords:</b> stedump utility</p> <p><b>Discovered in Version:</b> 4.16.0</p>
2376 425	<p><b>Description:</b> Direct Device Assignment (DDA, ak.a. pass-through) facility is not supported in MFT, its usage may cause the host to reboot.</p> <p><b>Workaround:</b> Burn the firmware in PF and then attach the HCA to the VM.</p> <p><b>Keywords:</b> DDA</p> <p><b>Discovered in Version:</b> 4.16.0</p>
2208 845/ 2099 263	<p><b>Description:</b> mlxlink does not support test mode for 50GE-KR4 speed.</p> <p><b>Workaround:</b> N/A</p> <p><b>Keywords:</b> mlxlink</p> <p><b>Discovered in Version:</b> 4.16.0</p>
-	<p><b>Description:</b> Port toggling with Inband devices using mlxlink fails and the following error is presented: "Unknown MAD error".</p> <p><b>Workaround:</b> To avoid this issue, perform one of the following options:</p> <ul style="list-style-type: none"> <li>• Use OpenSM (with or without -o)</li> <li>• Use only active ports</li> </ul> <p><b>Keywords:</b> Port toggling, mlxlink, Inband devices</p> <p><b>Discovered in Version:</b> 4.14.0-105</p>
2234 589	<p><b>Description:</b> For Multi-Host systems, enabling the PRBS test mode causes network connectivity disconnection.</p> <p><b>Workaround:</b> Maintain another interface for enabling the link back.</p> <p><b>Keywords:</b> mlxlink</p>

Internal Ref · No ·	Issue
	<b>Discovered in Version:</b> 4.15.0
2167 841	<p data-bbox="272 499 1393 566"><b>Description:</b> "mlxfwmanager --download" and "mlxfwmanager --online" commands are currently not functional on ESXi 7.0.</p> <p data-bbox="272 577 1393 611"><b>Workaround:</b> N/A</p> <p data-bbox="272 622 1393 656"><b>Keywords:</b> mlxup/mlxfwmanager</p> <p data-bbox="272 667 1393 723"><b>Discovered in Version:</b> 4.14.3</p>
2149 437	<p data-bbox="272 745 1393 813"><b>Description:</b> When the SLTP configuration is wrongly set, the “Bad status” explanation will not be presented (only error indication) to the user.</p> <p data-bbox="272 824 1393 857"><b>Workaround:</b> N/A</p> <p data-bbox="272 869 1393 902"><b>Keywords:</b> SLTP configuration</p> <p data-bbox="272 913 1393 969"><b>Discovered in Version:</b> 4.14.2</p>
1780 276	<p data-bbox="272 992 1393 1059"><b>Description:</b> "mst server start" runs at foreground instead of the background on FreeBSD and VMWare ESXi OSes.</p> <p data-bbox="272 1070 1393 1104"><b>Workaround:</b> Use '&amp;' --&gt; 'mst server start &amp;'</p> <p data-bbox="272 1115 1393 1149"><b>Keywords:</b> 'mst server start', FreeBSD, VMWare ESXi</p> <p data-bbox="272 1160 1393 1216"><b>Discovered in Version:</b> 4.14.0-105</p>
2001 890	<p data-bbox="272 1238 1393 1328"><b>Description:</b> The argparse module is installed by default in Python versions =&gt;2.7 and &gt;=3.2. In case an older Python version is used, the argparse module is not installed by default and therefore must be manually installed.</p> <p data-bbox="272 1339 1393 1373"><b>Workaround:</b> N/A</p> <p data-bbox="272 1384 1393 1417"><b>Keywords:</b> Python, argparse module</p> <p data-bbox="272 1429 1393 1462"><b>Discovered in Version:</b> 4.13.3</p>
1923 665 / 1939 791	<p data-bbox="272 1485 1393 1518"><b>Description:</b> Force Mode does not work when using mlxlink in ConnectX-6 InfiniBand adapter cards.</p> <p data-bbox="272 1529 1393 1563"><b>Workaround:</b> N/A</p> <p data-bbox="272 1574 1393 1608"><b>Keywords:</b> mlxlink, Force Mode, ConnectX-6 IB</p> <p data-bbox="272 1619 1393 1653"><b>Discovered in Version:</b> 4.13.3</p>
1802 662	<p data-bbox="272 1709 1393 1742"><b>Description:</b> Due to mst signing process, some executions might be slower than expected.</p> <p data-bbox="272 1753 1393 1787"><b>Workaround:</b> N/A</p> <p data-bbox="272 1798 1393 1832"><b>Keywords:</b> mst</p> <p data-bbox="272 1843 1393 1877"><b>Discovered in Version:</b> 4.13.0</p>
1431 471	<p data-bbox="272 1888 1393 1955"><b>Description:</b> In ConnectX-5 adapter cards, the time-stamp capability using flint, is supported only on the device using the "-d" flag, and not on the binary using the "-i" flag.</p>

Internal Ref · No ·	Issue
	<b>Workaround:</b> Use the “-d” flag to set the time-stamp.
	<b>Keywords:</b> flint
	<b>Discovered in Version:</b> 4.11.0


# 3 User Manual

MFT package is a set of firmware management and debug tools for NVIDIA<sup>®</sup> devices. MFT can be used for:

- Generating a standard or customized NVIDIA firmware image
- Querying for firmware information
- Burning a firmware image to a single NVIDIA device

The list of the available tools in the package can be found in the [Release Notes](#) document.

## MFT - A Scheme of Operation



## 3.1 Supported Operating Systems

Please refer to the release notes of your version for supported operating systems and platforms.

**⚠** Unless explicitly specified, the usage of the tools is identical for all operating systems.

## 3.2 MFTshell



This is an early alpha release of MFTshell with limited capabilities.

The MFTshell is a frontend for a variety of MFT tools. It is designed to be a starting point for entry-level users to become familiar with the functionality of the tools. In general, commands entered in the shell, result in the execution of the corresponding tool.

You can use the autocompletion feature of MFTshell by pressing the tab key. You may access helpful information by typing ".help" followed by the command on which you wish to receive helpful information.

## 3.3 Access to Hardware Devices

The table below lists the NVIDIA<sup>®</sup> devices supported by MFT, the supporting tools, and the access methods to these devices.

Device Type	Product Name	HW Access Method			NVIDIA Driver
		PCI	I2C	In-Band	
IB/ETH Network Adapter	NVIDIA ConnectX-9				
	NVIDIA ConnectX-8	V	V	V	
	NVIDIA ConnectX-4	V	V	V	
	NVIDIA ConnectX-5	V	V	V	
	NVIDIA ConnectX-5 Ex	V	V	V	
	NVIDIA ConnectX-6	V	V	V	
	NVIDIA ConnectX-6 Dx	V	V	V	
	NVIDIA ConnectX-7	V	V	V	
	NVIDIA BlueField-2	V	V	V	
	NVIDIA BlueField-3	V	V	V	
Ethernet Adapter (NIC)	ConnectX-9				
	NVIDIA ConnectX-8	V	V		
	NVIDIA ConnectX-4 Lx	V	V		
	NVIDIA ConnectX-6 Dx	V	V		
	NVIDIA ConnectX-6 Lx	V	V		
	NVIDIA ConnectX-7	V	V		
	NVIDIA BlueField-2	V	V		

Device Type	Product Name	HW Access Method			
		PCI	I2C	In-Band	NVIDIA Driver
Switch	NVIDIA Switch-IB®	v <sup>1</sup>	V	V	
	NVIDIA Switch-IB 2	v <sup>1</sup>	V	V	
	NVIDIA Spectrum™	V	V		
	NVIDIA Spectrum-2	V	V		
	NVIDIA Spectrum-3	V	V		
	NVIDIA Spectrum-4	V	V		
	NVIDIA Spectrum-5	V	V		
	NVIDIA Quantum	V	V	V	
	NVIDIA Quantum-2	V	V	V	
	NVIDIA NVLink5	V	V	V	
GPU	NVIDIA Blackwell				V

Note. V<sup>1</sup> indicates managed switch products only. MFT tools access NVIDIA devices via the PCI Express interface, via a USB to I2C adapter (P/N: MTUSB-1), or via vendor-specific MADs over the InfiniBand fabric (In-Band).



In-Band device access requires the local IB port to be in the ACTIVE state and connected to an IB fabric.

All MFT tools address the target hardware device using an *mst device name*. This name is assigned by running the command 'mst start' (in Windows, it is not required to run the "mst start" command) for PCI and I2C access. In-Band devices can be assigned by running the 'mst ib add' command.

To list the available mst device names on the local machine, run 'mst status'. Local PCI devices may also be accessed using device aliases. Supported aliases are:

- PCI device "bus:dev.fn" (e.g. 03:00.0)
- OFED RDMA device (e.g. mlx4\_0)
- Network interface with "net-" prefix (e.g. net-eth2)
- FWCTL device (e.g. - /dev/fwctl/fwctl10)

Run `mst status -v` to list the devices and their available aliases. The format of an mst device name is as follows:

Via PCI:

```
# mt4099_pci_crX
```

```
# mt4099_pciconf0
```

Where:

*X* is the index of the adapter on the machine.

`_crX` devices access the adapter directly (recommended if possible).

`_pciconfX` devices use configuration cycles to access the adapter.

For example:

```
# mt25418_pci_cr0
```

Via USB to I2C adapter: For example, `mtusb-1`.

Via Remote device:

```
/dev/mst/mft:23108,@dev@mst@mt4103_pci_cr0
```

Via `ibdr` device: For example, `/dev/mst/CA_MT4113_server1_HCA-3_ibdr-0,mxlx- 5_0,1` or `ibdr-0,mxlx5_0,1`.

Via In-Band: `<string>lid-<lid_number>`.

For example:

```
/dev/mst/CA_MT4099_mft_HCA-1_lid-0x0002 or simply "lid-2"
```

The “`mst ib add`” command adds devices in the format:

- For adapters:

```
CA_<device id >_<ib node description>_lid-<lid number>
```

- For switches:

```
SW_<device id >_lid-<lid number>
```

See Step 3 in [Remote Access to NVIDIA Devices](#) for instructions on how to obtain the device LID.

Via PCI user level: `<bus:dev.fn>`

For example, if you run `lspci -d 15b3`: NVIDIA devices and PCI Device IDs will be displayed.

```
# /sbin/lspci -d 15b3:
02:00.0 Ethernet controller: Mellanox Technologies Unknown device 6368 (rev a0)
```

VFIO Access:

The purpose of this access is to work in a Kernel lockdown mode, since user space access to the Kernel is not allowed in that environment.

To use it:

1. Load the VFIO driver by running: `modprobe vfio`.
2. Access the device using its DBDF.

FWCTL Access:

Available only in Linux OS.

Can be used with PRM-based tools (flint, mlxlink, mlxconfig etc). Direct cr-space access tools (mcra, mstdump etc) are not supported for this interface.

## 3.4 Compilation and Installation

Download the relevant MFT package for your OS from the [MFT](#) webpage and continue as described in table below according your OS.

OS	Install	Uninstall
Linux	<ol style="list-style-type: none"><li>1. Untar the downloaded package</li><li>2. Allow packaging of bins to a self-executing file.</li><li>3. Run 'install.sh' <b>For OEM only:</b> 'install.sh --oem'</li><li>4. Start the mst driver by running: mst start</li></ol> <p>NOTE: It is possible to customize some installation parameters (such as the target installation path). Run 'install.sh --help' for details.</p>	Uninstall MFT on Linux by running the following command: mft_uninstall.sh
Windows	The installation is EXE based: <ol style="list-style-type: none"><li>1. Double click the EXE file and follow the instructions presented by the installation wizard.</li></ol>	<ol style="list-style-type: none"><li>1. Go to Add or remove programs.</li><li>2. Remove WinMFT64 depending on the platform type.</li></ol>
FreeBSD	<ol style="list-style-type: none"><li>1. Untar the downloaded package.</li><li>2. Run "install.sh"</li></ol>	Uninstall MFT on FreeBSD, run the following command: mft_uninstall.sh
VMware	<ol style="list-style-type: none"><li>1. Install the package. Run: # esxcli software vib install -v &lt;MST Vib&gt; # esxcli software vib install -v &lt;MFT Vib&gt; NOTE: For VIBs installation examples, please see below.</li><li>2. Reboot system.</li><li>3. Start the mst driver. Run: # /opt/mellanox/bin/mst start</li></ol>	<ol style="list-style-type: none"><li>1. Uninstall the package. Run: # esxcli software vib remove -n mft</li><li>2. Uninstall the mst:<ul style="list-style-type: none"><li>• VMKlinux: # esxcli software vib remove -n net-mft</li><li>• Native: # esxcli software vib remove -n nmst</li></ul></li><li>3. Reboot system.</li></ol>

Example (VIBs installation):

VMK:

```
esxcli software vib install -v /tmp/net-mst-4.6.0.22-10EM.600.0.0.2295424.vib
esxcli software vib install -v /tmp/mft-4.6.0.22-10EM-600.0.0.2295424.x86_64.vib
```

Native:

```
esxcli software vib install -v /tmp/nmst-4.6.0.22-10EM.600.0.0.2295424.x86_64.vib
esxcli software vib install -v /tmp/mft-4.6.0.22-10EM-600.0.0.2295424.x86_64.vib
```

## 3.5 Firmware Generation, Configuration, and Update Tools

This chapter contains the following sections:

- [mst Service](#)
- [MFT Configuration](#)
- [mlxfwmanager - Firmware Update and Query Tool](#)
- [mlxarchive - Binary Files Compression Tool](#)
- [mlxconfig - Changing Device Configuration Tool](#)
- [flint - Firmware Burning Tool](#)
- [mlxburn - Firmware Image Generator and Burner](#)
- [mlxwreset - Loading Firmware on 5th Generation Devices Tool](#)
- [mlxphyburn - Burning Tool for Externally Managed PHY](#)
- [mlx\\_fpga - Burning and Debugging Tool for NVIDIA Devices with FPGA](#)
- [cpldupdate - Tool for Programming On-Board CPLDs on NVIDIA Devices](#)
- [mlxprivhost - NIC Configuration by the Host Restriction Tool \(Zero Trust Mode\)](#)
- [mlxtokengenerator - Token Creation Tool](#)
- [mlxdpa - DPA Applications Sign Tool](#)
- [mlx cableimgen - Cable Firmware Image Wrapper Generation Tool](#)
- [nvredfish](#)

## 3.5.1 mst Service

This section contains:

- [Linux](#)
- [Running mst in an Environment without a Kernel](#)
- [Windows](#)
- [FreeBSD](#)
- [VMware ESXi](#)

### 3.5.1.1 Linux

This script is used to start mst service and to stop it. It is also used in other operations with NVIDIA devices, such as in resetting or enabling remote access.

#### 3.5.1.1.1 mst Synopsis - Linux

```
mst <command> [switches]
```

mst Commands and Switches Description - Linux

mst start [--with_msix] [--with_unknown] [--with_i2cdev] [--with_lpcdev] [--with_fpga] [--with_fpga_fw_access]	<p>Create special files that represent NVIDIA devices in directory /dev/mst. Load appropriate kernel modules and saves PCI configuration headers in directory /var/mst_pci. After successfully completion of this command the MST driver is ready to work. You can configure the start command by editing the configuration file: /etc/mft/mst.conf, for example you can rename you devices.</p> <p>Options:</p> <ul style="list-style-type: none"> <li>• --with_msix: Create the msix device.</li> <li>• --with_unknown: Do not check if the device ID is supported.</li> <li>• --with_i2cdev: Create Embedded I2C master</li> <li>• --with_fpga: Create MST device for the attached FPGA card (Access via Driver)</li> <li>• --with_fpga_fw_access: Create an extended MST device for the attached FPGA (Access via Firmware)</li> </ul>
mst stop [--force]	<p>Stop the MST driver service, remove all special files/ directories and unload kernel modules.</p> <p>Options:</p> <ul style="list-style-type: none"> <li>• --force: Force try to stop mst driver even if it's in use.</li> </ul>
mst restart [--with_msix] [--with_unknown] [--with_i2cdev] [--with_lpcdev] [--with_fpga] [--with_fpga_fw_access]	<p>Just like "mst stop" followed by "mst start [--with_msix] [--with_unknown] [--with_i2cdev] [--with_lpcdev] [--with_fpga] [--with_fpga_fw_access]"</p>
mst server start [port-p <port> [-s <passphrase>]	<p>Start mst MST server to allow incoming connection. The default port is 23108. Use the '-s' flag to define the passphrase used by the server. If no passphrase is provided, a random one will be generated.</p>
mst server stop	<p>Stop the mst server.</p>
mst remote add <hostname>[:port] [-s <passphrase>]	<p>Establish a connection with a specified host on a specified port. The default port is 23108. Add devices on a remote peer to a local devices list. &lt;hostname&gt; may be the host name as well as an IP address. Use the '-s' flag to provide the host's passphrase. If no passphrase is provided, you will be prompted to insert one.</p>
mst remote del <hostname>[:port]	<p>Remove all remote devices on specified hostname. &lt;hostname&gt;[:port] should be specified exactly as in the "mst remote add" command.</p>
mst ib add [OPTIONS] [local_hca_id] [local_hca_port]	<p>Add devices found in the IB fabric for inband access. Requires OFED installation and an active IB link. If local_hca_id and local_hca_port are given, the IB subnet connected to the given port is scanned. Otherwise, the default subnet is scanned.</p> <p>Options:</p> <ul style="list-style-type: none"> <li>• --discover-tool &lt;discover-tool&gt;: The tool that is used to discover the fabric Supported tools: ibnetdiscover, ibdiagnet. default: ibdiagnet</li> <li>• --add-non-mlnx: Add non NVIDIA nodes</li> <li>• --topo-file &lt;topology-file&gt;: A prepared topology file which describes the fabric. For ibnetdiscover: provide an output of the tool. For ibdiagnet: provide LST file that ibdiagnet generates</li> <li>• --use-ibdr: Access by direct route MADs. Available only when using ibnetdiscover tool, for SwitchX and ConnectIB devices</li> </ul> <p>NOTE: If a topology file is specified, device are taken from it. Otherwise, a discover tool is run to discover the fabric.</p> <ul style="list-style-type: none"> <li>• --planarized : Add planarized device</li> </ul> <p>NOTE: this device is only supported by mlxlink tool.</p>
mst ib del	<p>Remove all inband devices.</p>

mst cable add [OPTIONS] [params]	Add the cables that are connected to 5th generation devices. There is an option to add the cables found in the IB fabric for Cable Info access, requires WinOF-2 installation and active IB links. If local_hca_id and local_hca_port are given, the IB subnet connected to the given port is scanned. Otherwise, all the devices will be scanned. Options: <ul style="list-style-type: none"> <li>• --with_ib: Add the inband cables in addition to the local PCI devices</li> <li>• --with_retimer: Add the retimer devices of the added cables</li> <li>• --cdb_discovery: Discover retimer devices using CDB commands</li> </ul> params: [local_hca_id] [local_hca_port]
mst cable del	Remove all cable devices.
mst i2c add [--with_retimer] [--with_chipset]	Add I2C devices for each i2c secondary address.
mst gpu add	Add GPU device via NVIDIA Driver.
mst gpu del	Remove all GPU devices.
mst status	Print current status of NVIDIA devices Options: <ul style="list-style-type: none"> <li>• -v run with high verbosity level (print more info on each device)</li> </ul>
mst save	Save PCI configuration headers in directory /var/mst_pci.
mst load	Load PCI configuration headers from directory /var/mst_pci.
mst version	Print the version info

### 3.5.1.1.2 Using mst.conf File in Linux

Edit the /etc/mft/mst.conf configuration file to configure the start operation in Linux (only).

The configuration file consists of lines of rules. Every line will be a rule for mst start. It must be valid, and the rules should be unique. There should also be no duplication of new names and/or serials.

The rule general format is the following:

```
$OPCODE $PARAMS
```

mst start Supported OPCODES

OPCODE	Definition	Description
RENAME	renames mst devices	<ul style="list-style-type: none"> <li>• Rule format: RENAME \$TYPE \$NEW_NAME \$ID</li> <li>• Supported types: # MTUSB (where \$ID is the iSerial)</li> <li>• Example: RENAME USB my 0x2A4C.</li> <li>• Effect: MTUSB with serial 0x2A4C will be renamed to /dev/mst/mymtusb-1 (always mtusb-1 will be concatenated to the new name).</li> </ul>

### 3.5.1.1.3 Examples of mst Usage - Linux

To start the mst driver service:

```
# mst start
```

```
Starting MST (Mellanox Software Tools) driver set
Loading MST PCI module - Success
Loading MST PCI configuration module - Success
Create devices
MTUSB-1 USB to I2C Bridge - Success
```

To stop the service:

```
Success# mst stop
Stopping MST (Mellanox Software Tools) driver set
Unloading MST PCI module - Success
```

To print the current status of NVIDIA devices:

```
# mst status
MST modules:
-----
MST PCI module loaded
MST PCI configuration module loaded

MST devices:
-----
/dev/mst/mt4099_pciconf0      - PCI configuration cycles access.
                             domain:bus:dev.fn=0000:0b:00.0 addr.reg=88 data.reg=92
                             Chip revision is: 01
/dev/mst/mt4099_pci_cr0      - PCI direct access.
                             domain:bus:dev.fn=0000:0b:00.0 bar=0xd2600000 size=0x100000
                             Chip revision is: 01
/dev/mst/mtusb-1             - USB to I2C adapter as I2C master
                             iSerial = 0x1683
```

To show the devices status with detailed information

```
# mst status -v
PCI devices:
DEVICE_TYPE      MST                PCI                RDMA               NET                NUMA
ConnectX4 (rev:0) /dev/mst/mt4115_pciconf0 08:00.0            mlx5_0            net-ib2            -1
ConnectX4 (rev:0) /dev/mst/mt4115_pciconf0.1 08:00.1            mlx5_1            net-ib3            -1
ConnectIB (rev:0) /dev/mst/mt4113_pciconf0 0b:00.0            mlx5_2            net-ib4,           -1
                                                           net-ib5
ConnectX3 (rev:1) /dev/mst/mt4099_pciconf0 0e:00.0            mlx4_0            net-ib0,           -1
ConnectX3 (rev:1) /dev/mst/mt4099_pci_cr0
                                                           net-ib1

I2C devices:
-----
MST
/dev/mst/mtusb-1 0x1B5C
```

In case the device has Function Per Port (FPP) enabled on it, a new device will appear in the `mst status -v` output with information about the second physical function. Example:

```
DEVICE_TYPE      MST                PCI                RDMA               NET                NUMA
ConnectX4 (rev:0) /dev/mst/mt4115_pciconf0 07:00.0            mlx5_4            net-ib4            -1
ConnectX4 (rev:0) /dev/mst/mt4115_pciconf0.1 07:00.1            mlx5_5            net-ib5            -1
```

### 3.5.1.2 Running mst in an Environment without a Kernel

mst can work even without kernel module being installed on the machine or if the kernel is down. In this case, the devices' names will be the PCI address of the devices.

Example:

```
> mst status
MST modules:
-----
MST PCI module is not loaded
MST PCI configuration module is not loaded

PCI Devices:
-----
05:00.0
08:00.0
82:00.0


> mst status -v
MST modules:
```

```

-----
MST PCI module is not loaded
MST PCI configuration module is not loaded

PCI devices:
-----
DEVICE_TYPE      MST  PCI      RDMA  NET      NUMA
ConnectX3Pro(rev:0) NA  05:00.0  mlx4_0 net-ib0,net-ib1
ConnectX4(rev:0)  NA  08:00.0  mlx5_0 net-ib2
ConnectX4(rev:0)  NA  08:00.1  mlx5_1 net-ib3
ConnectIB(rev:0)  NA  82:00.0  mlx5_2 net-ib4,net-ib5

```

 The MST interface will be NA in mst status -v[v] output.

Run commands with these devices:

```

> flint -d 08:00.0 q
Image type:      FS3
FW Version:      12.16.0048
FW Release Date: 14.3.2016
Description:     UID                               GuidNumber
Base GUID:       7cfe90030029205e                4
Base MAC:        00007cfe9029205e          4
Image VSD:
Device VSD:
PSID:           MT_2190110032


```

### 3.5.1.3 Windows

#### 3.5.1.3.1 mst Synopsis - Windows

mst status [-v] | help | server <start|stop> | ib <add|del> | version | remote <add|del> <hostname>

##### 3.5.1.3.1.1 mst Commands and Switches Description - Windows

 There are no mst start or stop operations in Windows.

mst server start [port]	Start mst server to allow incoming connection. Default port is 23108.
mst server stop	Stop mst server.
mst remote add <hostname>: [port] [-s <passphrase>]	Establish a connection with a specified host on a specified port (the default port is 23108). Add devices on a remote peer to a local devices list. <hostname> may be host name as well as an IP address. Use the '-s' flag to provide the host's passphrase. If no passphrase is provided, you will be prompted to insert one. <b>Note:</b> [-s <passphrase>] is applicable when the host server OS is not windows.
mst remote del <hostname>[:port]	Remove all remote devices on a specified hostname <hostname>:<port> should be specified exactly as in the "mst remote add" command.
mst ib del	Remove all inband devices.
mst cable add [OPTIONS] [params]	Add the cables that are connected to 5th generation devices. There are an option to add the cables found in the IB fabric for Cable Info access, requires OFED installation and active IB links. If local_hca_id and local_hca_port are given, the IB subnet connected to the given port is scanned. Otherwise, all the devices will be scanned. <b>OPTIONS:</b> --with_ib: Add the inband cables in addition to the local PCI devices. params: [local_hca_id] [local_hca_port]

mst cable del	Remove all cable devices.
mst status	Print current status of NVIDIA devices.
mst version	Print the version info.
mst ib add [OPTIONS] [local_hca_id] [local_hca_port] [lst-file]	<p>Add devices found in the IB fabric for inband access. Requires MLNX_WinOF installation and an active IB link. If local_hca_id and local_hca_port are given, the IB subnet connected to the given port is scanned. Otherwise, the default subnet is scanned. If an lst-file is specified, devices are taken from this file. Otherwise, ibnetdiscover tool is run to discover the fabric.</p> <p>Options:</p> <ul style="list-style-type: none"> <li>• --discover-tool &lt;discover-tool&gt;: The tool used to discover the fabric. Supported tools: ibnetdiscover, ibdiagnet. default: ibnetdiscover</li> </ul> <p>NOTE: The discover tool argument is intended only for parsing purposes, thus you need to specify an lst-file with it.</p> <ul style="list-style-type: none"> <li>• --add-non-mlnx: Add non NVIDIA nodes.</li> <li>• --use-ibdr: Access by direct route MADs. Available only when using ibnetdiscover tool, for SwitchX and ConnectIB devices.</li> <li>• --no-format-check: Do not check the format of the given local_hca_id. The expected format of the local_hca_id is: ibv_device[0-9]+.</li> <li>• --topo-file &lt;topology-file&gt;: A prepared topology file which describes the fabric. For ibnetdiscover: provide an output of the tool. For ibdiagnet: provide and lst-file that ibdiagnet generates.</li> </ul> <p>NOTE: If a topology file is specified, the devices are taken from it. Otherwise, a discover tool is run to discover the fabric.</p>
mst help	Print this help information.

### 3.5.1.3.1.2 Examples of mst Usage - Windows

To print the current status of NVIDIA devices:

```
# mst status
MST devices:
-----
mt4115_pciconf0
mtusb-1
mtusb-2
```

To show the devices status with detailed information:


```
# mst status -v
MST devices:
-----
mt4115_pciconf0    bus:dev.fn=13:00.0
mt4115_pciconf0.1 bus:dev.fn=13:00.1
mtusb-1           iSerial=0x1ccc
mtusb-2           iSerial=0x1cd5
```

## 3.5.1.4 FreeBSD

### 3.5.1.4.1 mst Synopsis - FreeBSD

```
mst <command> [switches]
```

### 3.5.1.4.1.1 Commands and Switches Description - FreeBSD


 There are no mst start or stop operations in FreeBSD.

mst status	Print current status of NVIDIA devices.
mst help	Print this help information.
mst version	Print mst version information.
mst server start [port]	Start mst server to allow incoming connection. Default port is 23108.
mst server stop	Stop mst server.
mst cable add	Add the cables that are connected to the device
mst cable del	Delete the added cables

### 3.5.1.4.1.2 Examples of mst Usage - FreeBSD

To print the current status of NVIDIA devices:

```
VMwareMST devices:
-----
pci0:3:0:0 - MT27500 Family [ConnectX-3]
```

 The mst status output is taken from parsing the `pciconf` output.

To show the devices status with detailed information:

```
# mst status -v
PCI devices:
-----
DEVICE_TYPE      MST  PCI          RDMA      NET        NUMA
ConnectX4LX(rev:0) pci0:2:0:0  02:00.0  mlx5_0
ConnectX4LX(rev:0) pci0:2:0:1  02:00.1  mlx5_1
ConnectX4(rev:0)   pci0:3:0:0  03:00.0  mlx5_2
```

## 3.5.1.5 VMware ESXi

### 3.5.1.5.1 mst Synopsis - VMware

```
mst <command> [switches]
```

#### 3.5.1.5.1.1 Commands and Switches Description - VMwareMST

mst start	Create special files that represent NVIDIA devices in directory/dev. Load appropriate modules. After successfully completing this command, the mst driver will be ready to work.
mst stop	Stop NVIDIA mst driver service and unload the kernel modules.
mst restart	"mst stop" followed by "mst start"

mst server start [-p --port portport] [-s <passphrase>]	Start the MST server to allow incoming connection. The default port is 23108. Use the '-s' flag to define the passphrase used by the server. If no passphrase is provided, a random one will be generated.
mst server stop	Stop the mst server.
mst status	Print current status of NVIDIA devices Options: -v run with a high verbosity level (print more info on each device)
mst version	Print the version info

### 3.5.1.5.1.2 Examples of mst Usage - VMware

To print the current status of NVIDIA devices:

Native

```
# /opt/mellanox/bin/mst status
MST devices:
-----
mt4099_pciconf0
mt4099_pci_cr0
```

VMK Linux

```
# /opt/mellanox/bin/mst status
MST Devices:
/dev/mt4099_pciconf0
/dev/mt4099_pci_cr0
```


To show the devices status with detailed information:

```
# /opt/mellanox/bin/mst status -vv
PCI devices:
DEVICE_TYPE      MST          PCI          RDMA         NET          NUMA
ConnectX4 (rev:0) mt4115_pciconf0 03:00.0      net-vmnic4
ConnectX4 (rev:0) mt4115_pciconf0.1 03:00.1      net-vmnic5
ConnectX3Pro (rev:0) mt4103_pci_cr0 05:00.0      net-vmnic1,netvmnic1000102
ConnectX3Pro (rev:0) mt4103_pciconf0 05:00.0      net-vmnic1,netvmnic1000102
```

For further information on In-Band and Remote Access, please refer to [In-Band Access to Multiple IB Subnets](#), [Accessing Remote InfiniBand Device by Direct Route MADs](#), and [Remote Access to Device by Sockets](#).

## 3.5.2 MFT Configuration

MFT configuration file resides in `/etc/mft/mft.conf`. It includes a list of defines and their values in the following syntax: `<DEF> = <value>`.

 This capability is available in Linux only.

### 3.5.2.1 MKey Configuration

In order to use the mft tools when the MKEY is configured, please edit the `/etc/mft.conf` file as shown below:

- mkey\_enable=yes (default: no)
- sm\_config\_dir= (if empty, the SM config directory will be: `/var/cache/opensm/`)
- sm\_conf\_file\_path=<opensm configuration file full path> (default `/etc/opensm/opensm.conf`)

### 3.5.3 mlxfwmanager - Firmware Update and Query Tool

The mlxfwmanager is a firmware update and query utility which scans the system for available NVIDIA devices (only mst PCI devices) and performs the necessary firmware updates. For further information on firmware update, please refer to [Bootting HCA Device in Livefish Mode](#).

mlxfwmanager supports MFA and MFA2.



The examples throughout the document use pci “bus.dev.fn” format. However, all the examples are inter-changeable with the mlxfwmanager `-d /dev/mst/<device>` format.

#### 3.5.3.1 mlxfwmanager Synopsis

```
# [-d|--dev DeviceName] [-h|--help] [-v|--version] [--query] [--query-format Format] [-u|--update] [-i|--image-file
FileName] [-D|--image-dir DirectoryName] [-f|--force] [-y|--yes] [--no] [--clear-semaphore] [--exe-rel-path] [-l|--
list-content] [--archive-names] [--nofs] [--log] [-L|--log-file LogFileName] [--no-progress] [-o|--outfile
OutputFileName] [--online] [--online-query-psid PSIDs] [--key key] [--download DirectoryName] [--download-default]
[--get-download-opt OPT] [--download-device Device] [--download-os OS] [--download-type Type] [--ssl-certificate
Certificate] [--no_fw_ctrl] [--component_type componentName] [--skip_if_same]
```

where:

<code>-d --dev DeviceName</code>	Perform operation for specified mst device(s). Run 'mst status' command to list the available devices. Multiple devices can be specified delimited by semicolons. A device list containing semicolons must be quoted.
<code>-h --help</code>	Show this message and exit.
<code>-v --version</code>	Show the executable version and exit.
<code>--query</code>	Query device(s) info
<code>--query-format Format</code>	(Query Onlinequery)outputformat,XML Text-defaultText
<code>-u --update</code>	Update firmware image(s) on the device(s).
<code>-i --image-file FileName</code>	Specified image file to use.
<code>-D --image-dir DirectoryName</code>	Specified directory instead of default to locate image files.
<code>-f --force</code>	Force image update
<code>-y --yes</code>	Answer is yes in prompts
<code>--no</code>	Answer is no in prompts
<code>--clear-semaphore</code>	Force clear the flash semaphore on the device, No command is allowed when this flag is used. NOTE: May result in system instability or flash corruption if the device or another application is currently using the flash. Exercise caution.
<code>--exe-rel-path</code>	Use paths relative to the location of the executable
<code>-l --list-content</code>	List file/Directory content, used with <code>--image-dir</code> and <code>--image-file</code> flags
<code>--archive-names</code>	Display archive names in listing

--nofs	Burn image in a non failsafe manner
--log	Create log file
-L --log-file LogFileName	Use specified log file
--no_fw_ctrl	Do not use firmware Ctrl update
--no-progress	Do not show progress
-o --outfile OutputFileName	Write to specified output file
--online	Fetch required FW images online from NVIDIA server
--online-query-psid PSIDs	Query FW info, PSID(s) are comma separated
--key key	Key for custom download/update
--download DirectoryName	Download files from server to a specified directory
--download-default	Use Default values for download
--get-download-opt OPT	Get download options for OS or Device Options are: OS, Device
--download-device Device	Use '--get-download-opt Device' option to view available devices for device specific downloads
--download-os OS	Only for self_extractor download: Use '--get-download-opt OS' option to view available OS for sfx download
--download-type Type	MFA   self_extractor - default All
--ssl-certificate Certificate	SSL certificate for secure connection
--component_type componentName	Specify the PLDM component type to extract
--skip_if_same	Skip firmware update if current and new versions match

### 3.5.3.2 Querying the Device

To query a specific device, use the following command line:

```
# mlxfwmanager -d <device> --query
```

To query all the devices on the machine, use the following command line:

```
# mlxfwmanager --query
```

Examples:

Query the device.

```
mlxfwmanager -d 18:00:0 --query
Querying Mellanox devices firmware ...

Device #1:
-----

Device Type:      ConnectX7
Part Number:     CX713106AE-HEA_QP1_Ax
Description:     NVIDIA ConnectX-7 HHHH adapter Card; 200GbE (default mode) / NDR200 IB; Dual-port QSFP112; PCIe
5.0 x16 with x16 PCIe extension option; Crypto Enabled; Secure Boot Capable; IPN for internal use
```

```

PSID: MT_0000000894
PCI Device Name: 18:00.0
Base MAC: 1070fd875230
Versions: Current Available
FW 28.43.0180 28.45.1008
PXE N/A 3.7.0500
UEFI N/A 14.38.0016

```

```

Status: Update required

```

```

-----
Found 1 device(s) requiring firmware update. Please use -u flag to perform the update.

```

## Query all the devices.

```

Querying Mellanox devices firmware ...

```

```

Device #1:
-----

```

```

Device Type: ConnectX6
Part Number: MCX653106A-ECA_Ax
Description: ConnectX-6 VPI adapter card; H100Gb/s (HDR100; EDR IB and 100GbE); dual-port QSFP56; PCIe3.0
x16; tall bracket; ROHS R6
PSID: MT_0000000224
PCI Device Name: 0000:04:00.0
Base GUID: b8599f030023f954
Versions: Current Available
FW 20.43.1014 20.43.1014
PXE 3.7.0500 3.7.0500
UEFI 14.36.0016 14.36.0016

```

```

Status: Up to date

```

```

Device #2:
-----

```

```

Device Type: ConnectX6LX
Part Number: MCX631102AN-ADA_Ax
Description: ConnectX-6 Lx EN adapter card; 25GbE ; Dual-port SFP28; PCIe 4.0 x8; No Crypto
PSID: MT_0000000531
PCI Device Name: 0000:07:00.0
Base GUID: 0c42a1030060614c
Base MAC: 0c42a160614c
Versions: Current Available
FW 26.45.0386 26.45.1008
PXE 3.7.0500 3.7.0500
UEFI 14.38.0014 14.38.0016

```

```

Status: Update required

```

```

Device #3:
-----

```

```

Device Type: ConnectX5
Part Number: MCX556A-ECA_Ax
Description: ConnectX-5 VPI adapter card; EDR IB (100Gb/s) and 100GbE; dual-port QSFP28; PCIe3.0 x16; tall
bracket; ROHS R6
PSID: MT_0000000008
PCI Device Name: 0000:21:00.0
Base GUID: 248a0703008db026
Versions: Current Available
FW 16.35.3004 16.35.3004
PXE N/A 3.6.0902
UEFI N/A 14.29.0015

```

```

Status: Up to date

```

```

Device #4:
-----

```

```

Device Type: ConnectX4
Part Number: MCX455A-FCA_Ax
Description: ConnectX-4 VPI adapter card; FDR IB (56Gb/s) and 40GbE; single-port QSFP28; PCIe3.0 x16; ROHS
R6
PSID: MT_2160111021
PCI Device Name: 0000:24:00.0
Base GUID: 8e0b01e681d98270

```

```

Versions:      Current      Available
FW            12.28.2006   12.28.2006
PXE          3.6.0102    3.6.0102
UEFI         14.21.0017   14.21.0017

```

```
Status:        Up to date
```

```
Device #5:
-----
```

```

Device Type:   ConnectX6LX
Part Number:   MCX631102AN-ADA_Ax
Description:    ConnectX-6 Lx EN adapter card; 25GbE ; Dual-port SFP28; PCIe 4.0 x8; No Crypto
PSID:          MT_0000000531
PCI Device Name: 0000:0a:00.0
Base GUID:     0c42a10300a981fe
Base MAC:      0c42a1a981fe
Versions:      Current      Available
FW            26.45.0386   26.45.1008
PXE          3.7.0500   3.7.0500
UEFI         14.38.0014   14.38.0016

```

```
Status:        Update required
```

```
-----
Found 2 device(s) requiring firmware update. Please use -u flag to perform the update.
```

### Query XML:

```

mlxfwmanager --query-format xml
<Devices>
  <Device pciName="0000:04:00.0" type="ConnectX6" psid="MT_0000000224" partNumber="MCX653106A-ECA_Ax">
    <Versions>
      <FW current="20.43.1014" available="20.43.1014"/>
      <PXE current="3.7.0500" available="3.7.0500"/>
      <UEFI current="14.36.0016" available="14.36.0016"/>
    </Versions>
    <GUIDs Base_Guid="b8599f030023f954" />
    <Status>Up to date</Status>
    <Description>ConnectX-6 VPI adapter card; H100Gb/s (HDR100; EDR IB and 100GbE); dual-port QSFP56; PCIe3.0
x16; tall bracket; ROHS R6</Description>
  </Device>
  <Device pciName="0000:07:00.0" type="ConnectX6LX" psid="MT_0000000531" partNumber="MCX631102AN-ADA_Ax">
    <Versions>
      <FW current="26.45.0386" available="26.45.1008"/>
      <PXE current="3.7.0500" available="3.7.0500"/>
      <UEFI current="14.38.0014" available="14.38.0016"/>
    </Versions>
    <MACs Base_Mac="0c42a160614c" />
    <GUIDs Base_Guid="0c42a1030060614c" />
    <Status>Update required</Status>
    <Description>ConnectX-6 Lx EN adapter card; 25GbE ; Dual-port SFP28; PCIe 4.0 x8; No Crypto</Description>
  </Device>
  <Device pciName="0000:21:00.0" type="ConnectX5" psid="MT_0000000008" partNumber="MCX556A-ECA_Ax">
    <Versions>
      <FW current="16.35.3004" available="16.35.3004"/>
      <PXE current="N/A" available="3.6.0902"/>
      <UEFI current="N/A" available="14.29.0015"/>
    </Versions>
    <GUIDs Base_Guid="248a0703008db026" />
    <Status>Up to date</Status>
    <Description>ConnectX-5 VPI adapter card; EDR IB (100Gb/s) and 100GbE; dual-port QSFP28; PCIe3.0 x16; tall
bracket; ROHS R6</Description>
  </Device>
  <Device pciName="0000:21:00.0" type="ConnectX5" psid="MT_0000000008" partNumber="MCX556A-ECA_Ax">
    <Versions>
      <FW current="16.35.3004" available="16.35.3004"/>
      <PXE current="N/A" available="3.6.0902"/>
      <UEFI current="N/A" available="14.29.0015"/>
    </Versions>
    <GUIDs Base_Guid="248a0703008db026" />
    <Status>Up to date</Status>
    <Description>ConnectX-5 VPI adapter card; EDR IB (100Gb/s) and 100GbE; dual-port QSFP28; PCIe3.0 x16; tall
bracket; ROHS R6</Description>
  </Device>
</Devices>

```

### 3.5.3.3 Archived Images Content

Supports listing the contents of images archive.

- When running this command, the tool will list all firmware images within this PLDM package for each image it displays.

Usage:

```
mlxfwmanager -i <pldm-path> --list-content
```

- When running this command, the tool will list all firmware images within this mfa package.

Usage:

```
mlxfwmanager -i <mfa-file> --list-content
```

For each image, it displays the following: PSID, Part Number, firmware version, and device description.

### 3.5.3.4 Parallel Query and Firmware Update Using fwctl

In case of multiple devices, the tool will execute query or firmware update over fwctl device.

Please make sure that the fwctl driver is loaded on the Kernel space (using lsmod). The fwctl driver was introduced in Upstream Kernel v6.15, and it can also be installed with DOCA.

### 3.5.3.5 Updating the Device

To update a device on the machine, use the following command line: (Note: If only PXE rom needs update, please add -f to the command line.)

```
# mlxfwmanager -u -d <device> -i <existingMFAFile>
```

Update the device using PLDM:

```
mlxfwmanager -d <device> -i <pldm_package>
```

Example:

```
mlxfwmanager -u -d 18:00.0 -i /tmp/fw-ConnectX7-rel-28.45.1008.mfa
Querying Mellanox devices firmware ...

Device #1:
-----
Device Type:      ConnectX7
Part Number:     CX713106AE-HEA_QP1_Ax
Description:     NVIDIA ConnectX-7 HHHH adapter Card; 200GbE (default mode) / NDR200 IB; Dual-port QSFP112; PCIe
5.0 x16 with x16 PCIe extension option; Crypto Enabled; Secure Boot Capable; IPN for internal use
PSID:           MT_0000000894
PCI Device Name: 18:00.0
Base MAC:       1070fd875230
Versions:
  Current      Available
  FW          28.43.0180 28.45.1008
  PXE         N/A      3.7.0500
  UEFI        N/A      14.38.0016

Status:         Update required
-----
Found 1 device(s) requiring firmware update..
```

### 3.5.3.5.1 Updating the Device Online

To update the device online on the machine from website, use the following command line:

```
mlxfwmanager --online -u -d <device>
```

Example:

```
mlxfwmanager --online -u -d 21:00.0 -y
Querying Mellanox devices firmware ...

Device #1:
-----
Device Type:      ConnectX7
Part Number:     MCX75210AAS-NEA_Ax
Description:     NVIDIA ConnectX-7 HHHH Adapter Card; NDR IB; Single-port OSFP; PCIe 5.0 2x8 in a row (Socket
Direct); Crypto Disabled; Secure Boot Enabled
PSID:            MT_0000000851
PCI Device Name: /dev/mst/mt4129_pciconf0
Base GUID:       N/A
Base MAC:        N/A
Versions:
FW              Current      Available
FW              28.43.1014   28.43.1014
PXE             3.7.0500     N/A
UEFI            14.36.0016   N/A

Status:         Forced update required
-----
Found 1 device(s) requiring firmware update...

Please wait while downloading MFA(s) 100%
Device #1: Updating FW ...
FSMST_INITIALIZE - OK
Writing Boot image component - OK
Done

Restart needed for updates to take effect.
```

#### 3.5.3.5.1.1 Downloading Firmware Images and Firmware Update Packages

To download firmware images/firmware update packages, use the following command line:

```
mlxfwmanager --download <DownloadDir> --download-device <DeviceType> --download-os <OS> --download-type
<DownloadType>
```

To get the list of the supported devices or OSEs, use the flag "--get-download-opt OPT"

```
mlxfwmanager --get-download-opt OS
esxi_6_5_native
esxi_6_native
fbsd10_64
linux
linux_arm64
linux_ppc64
linux_ppc64le
linux_x64
windows
windows_x64

mlxfwmanager --get-download-opt Device
All
```

Examples:

Downloading Firmware Images/Firmware Update Packages:

```
mlxfwmanager --download /tmp/DownloadDir --download-device All --download-os All --download-type self_extractor
----- Files To Be Downloaded -----

All :
-----
```

```

<Files>:
0 - linux_x64/mlxup
1 - windows/mlxup.exe
2 - esxi_6_native/mlxup
3 - windows_x64/mlxup.exe
4 - linux_ppc64/mlxup
5 - linux_arm64/mlxup
6 - linux_ppc64le/mlxup
7 - linux/mlxup
8 - fbsd10_64/mlxup
9 - esxi_6_5_native/mlxup
<Release Notes>:
For more details, please refer to the following FW release notes:
1- ConnectX3 (2.42.5000): http://www.mellanox.com/pdf/firmware/ConnectX3-FW-2_42_5000-release_notes.pdf
2- ConnectX3Pro (2.42.5000): http://www.mellanox.com/pdf/firmware/ConnectX3-Pro-FW-2_42_5000-release_notes.pdf
3- Connect-IB (10.16.1200): http://www.mellanox.com/pdf/firmware/ConnectIBFW-10_16_1200-release_notes.pdf
4- ConnectX4 (12.28.2008): https://docs.mellanox.com/display/ConnectX4Firmwarev12282006
5- ConnectX4Lx (14.30.1004): https://docs.mellanox.com/display/ConnectX6LxFirmwarev14301004
6- ConnectX5 (16.30.1004): https://docs.mellanox.com/display/ConnectX5Firmwarev16301004
7- ConnectX6 (20.30.1004): https://docs.mellanox.com/display/ConnectX6Firmwarev20301004
8- ConnectX6Dx (22.30.1004): https://docs.mellanox.com/display/ConnectX6DxFirmwarev22301004
9- ConnectX6Lx (26.30.1004): https://docs.mellanox.com/display/ConnectX6LxFirmwarev26301004
10- BlueField (18.30.1004): N/A
11- BlueField2 (24.30.1004): N/A

Perform Download? [y/N]: y
Please wait while downloading Files to : '/tmp/DownloadDir'
0 - linux_x64/mlxup : Done
1 - windows/mlxup.exe : Done
2 - esxi_6_native/mlxup : Done
3 - windows_x64/mlxup.exe : Done
4 - linux_ppc64/mlxup : Done
5 - linux_arm64/mlxup : Done
6 - linux_ppc64le/mlxup : Done
7 - linux/mlxup : Done
8 - fbsd10_64/mlxup : Done
9 - esxi_6_5_native/mlxup : Done

Downloading file(s) to : '/tmp/DownloadDir' is done successfully

```

## Downloading firmware images/firmware update packages using custom key:

```

mlxfwmanager --download /tmp/DownloadDir --download-device All --download-os All --download-type All --key
last_release

----- Files To Be Downloaded -----

All :
-----

<Files>:
0 - Mellanox_Firmware_20210407.mfa
1 - linux_x64/mlxup
2 - windows/mlxup.exe
3 - esxi_6_native/mlxup
4 - windows_x64/mlxup.exe
5 - linux_ppc64/mlxup
6 - linux_arm64/mlxup
7 - linux_ppc64le/mlxup
8 - linux/mlxup
9 - fbsd10_64/mlxup
10 - esxi_6_5_native/mlxup

<Release Notes>:
For more details, please refer to the following FW release notes:
For more details, please refer to the following FW release notes:
1- ConnectX3 (2.42.5000): http://www.mellanox.com/pdf/firmware/ConnectX3-FW-2_42_5000-release_notes.pdf
2- ConnectX3Pro (2.42.5000): http://www.mellanox.com/pdf/firmware/ConnectX3-Pro-FW-2_42_5000-release_notes.pdf
3- Connect-IB (10.16.1200): http://www.mellanox.com/pdf/firmware/ConnectIBFW-10_16_1200-release_notes.pdf
4- ConnectX4 (12.28.2008): https://docs.mellanox.com/display/ConnectX4Firmwarev12282006
5- ConnectX4Lx (14.30.1004): https://docs.mellanox.com/display/ConnectX6LxFirmwarev14301004
6- ConnectX5 (16.30.1004): https://docs.mellanox.com/display/ConnectX5Firmwarev16301004
7- ConnectX6 (20.30.1004): https://docs.mellanox.com/display/ConnectX6Firmwarev20301004
8- ConnectX6Dx (22.30.1004): https://docs.mellanox.com/display/ConnectX6DxFirmwarev22301004
9- ConnectX6Lx (26.30.1004): https://docs.mellanox.com/display/ConnectX6LxFirmwarev26301004
10- BlueField (18.30.1004): N/A
11- BlueField2 (24.30.1004): N/A

Perform Download? [y/N]: y
Please wait while downloading Files to : '/tmp/DownloadDir'
0 - Mellanox_Firmware_20210407.mfa : Done
1 - linux_x64/mlxup : Done
2 - windows/mlxup.exe : Done
3 - esxi_6_native/mlxup : Done
4 - windows_x64/mlxup.exe : Done
5 - linux_ppc64/mlxup : Done
6 - linux_arm64/mlxup : Done
7 - linux_ppc64le/mlxup : Done
8 - linux/mlxup : Done
9 - fbsd10_64/mlxup : Done
10 - esxi_6_5_native/mlxup : Done

Downloading file(s) to : '/tmp/DownloadDir' is done successfully

```

### 3.5.3.6 UPMF

Update Package for NVIDIA Firmware (UPMF) is a new method used to distribute firmware to end users. Instead of providing multiple binary files (one for each board type) and burning them using the flint tool, the UPMF method requires only a single standalone file.

The UPMF is a self-extracting executable that contains a set of firmware binary images, and the mlxfwmanager firmware update tool.

UPMF provides:

- Single file per firmware release
- Simple 'one click' firmware update
- Compact size (achieved by efficient compression of the firmware images)
- No installation required

When executed, the UPMF:

- Extracts its content into a temporary location
- Scans the locally installed NVIDIA devices firmware versions
- Performs firmware updates if needed
- Cleans up temporary files

### 3.5.3.7 UPMF Generation Flow

The mlx\_fwsfx\_gen tool is used for OEMs that wish to create their own UPMFs that contain their own customized firmware images.

To install the mlx\_fwsfx\_gen tool, the installation script should be run with the "--oem" command line option.

#### 3.5.3.7.1 mlx\_fwsfx\_gen Usage

This tool packs the firmware images provided in the input directory and the mlxfwmanager update tool into a single standalone self-extracting executable.

The UPMF generation is supported on Linux and Windows. Being an executable file, the UPMF should be prepared for Linux and Windows separately.

Usage:


```
# mlx_fwsfx_gen --source-dir <FW images directory> --out-dir <output directory> [--sfx-name <sfx file name>] [--phy-support --phy-img <phy-img>] [--extra-args <args>]
```

where:

--source-dir	Directory containing NVIDIA firmware images to be included in the package. This option may be used more than once to specify more than one source directory.
--out-dir	Specifies the output directory.

--certific ate	SSL certificate.
--phy- support	Generate extractor with mlxphyburn support.
--phy- img	PHY firmware image.
--sfx- name	The self-extracting executable filename. The default name is mlxfwmanager-YYYYMMDD-<build number>, where build number is the previous maximum build number existing in the output directory incremented by one.
--extra- args	Extra args passed to mlxfwmanager default arguments. In the case of multiple args, the args are separated by commas. For example: [--extra-args --ret-lvim,--online]

### UPMF Package Generation Flow



#### 3.5.3.7.1.1 UPMF Generation Example

The below example packs 3 firmware binaries (named fw-ConnectX-3-1.bin, fw-ConnectX-3-2.bin, fw-ConnectX-3-3.bin) located in the directory '/tmp/fw-ConnectX-3-dir/' into a Linux UPMF package named /tmp/mlxfwmanager-20171004-1.

```
mlx_fwfsx_gen --source-dir /tmp/fw-ConnectX-3Pro-dir/ --out-dir /tmp/
Package name: /tmp/mlxfwmanager-20171004-1
Contents:
Source dirs: /tmp/fw-ConnectX-3Pro-dir
Adding file: /etc/mft/ca-bundle.crt
sfx_stub file: /usr/bin/mlx_sfx_stub
Creating intermediate MFA archive from binary files:
4779-314A-X00_Ax-ATT1090111023.bin
Huawei_TD70VMVA_VA_CX3Pro_2P_40G_Ax-HUA0020010017.bin
Inventec_U50_CX3Pro_10GE_A1~INV0010110023.bin
MCX342A-XCQ_Ax-MT_1680116023.bin
MCX353A-FCC_Ax-MT_1100111019.bin
mfa tool: /usr/bin/mlx_mfa_gen
mfa cmd: /usr/bin/mlx_mfa_gen -p /tmp/OMS1D5PvHq/srcs.mfa -s /tmp/fw-ConnectX-3Pro-dir
Adding bins from /tmp/fw-ConnectX-3Pro-dir
Files copied: 5
Querying images ...
Files queried: 5
Compressing ... (this may take a minute)
Archive: /tmp/OMS1D5PvHq/srcs.mfa
Total time: 0m3s
Adding file: /tmp/OMS1D5PvHq/srcs.mfa
```

```

Adding file: /usr/bin/mlxfwmanager
Creating zip /tmp/OMs1D5PvHg/zippackage.zip
adding: srcs.mfa (deflated 0%)
adding: mlxfwmanager (deflated 52%)
adding: ca-bundle.crt (deflated 45%)
sfx auto-run command:
mlxfwmanager -u --log-on-update --ssl-certificate %ca-bundle.crt% %current-dir% %argv%
Log name: /tmp/mlxfwmanager-20171004-1.log

```

## UPMF Generation with PHY Binary Example

The below example packs 3 firmware binaries (named fw-ConnectX-3-1.bin, fw-ConnectX-3-2.bin, fw-ConnectX-3-3.bin) located in the directory '/tmp/fw-ConnectX-3-dir/' and a PHY image '/tmp/Firmware\_1.37.10\_N32722.cld' into a Linux UPMF package named /tmp/mlxfwmanager-20141126-2.

```

mlx_fwsfx_gen --source-dir /tmp/fw-ConnectX-3-dir --out-dir /tmp --phy-support --phy-img /tmp/
Firmware_1.37.10_N32722.cld

Creating /tmp/C04TldeQhr/phy_mfa direcotry
Package name: /tmp/mlxfwmanager-20141126-2
Contents:
Source dirs: /tmp/fw-ConnectX-3-dir
Adding file: /etc/mft/ca-bundle.crt
sfx_stub file: /usr/bin/mlx_sfx_stub
Creating intermediate MFA archive from binary files:
fw-ConnectX-3-1.bin
fw-ConnectX-3-2.bin
fw-ConnectX-3-3.bin
mfa tool: /usr/bin/mlx_mfa_gen
mfa cmd: /usr/bin/mlx_mfa_gen -p /tmp/YaH5BAoQ8q/srcs.mfa -s /tmp/fw-ConnectX-3-dir
Adding bins from /tmp/fw-ConnectX-3-dir

Files copied: 3

Querying images ...
Files queried: 3
Compressing ... (this may take a minute)

Archive: /tmp/YaH5BAoQ8q/srcs.mfa
Total time: 0m1s
Adding file: /tmp/YaH5BAoQ8q/srcs.mfa
Adding file: /usr/bin/mlxfwmanager
Copying /tmp/Firmware_1.37.10_N32722.cld to /tmp/C04TldeQhr/phy_mfa
Adding file: /tmp/Firmware_1.37.10_N32722.cld
Adding file: /usr/bin/mlxphyburn
Creating zip /tmp/YaH5BAoQ8q/zippackage.zip
adding: srcs.mfa (deflated 0%)
adding: ca-bundle.crt (deflated 45%)
adding: phy_mfa/ (stored 0%)
adding: phy_mfa/Firmware_1.37.10_N32722.cld (deflated 44%)
adding: mlxfwmanager (deflated 57%)
adding: mlxphyburn (deflated 60%)
sfx auto-run command:
mlxfwmanager -u --log-on-update --ssl-certificate %ca-bundle.crt% %current-dir% %argv%
mlxphyburn auto-run command:
mlxphyburn %device% -i ./phy_mfa/Firmware_1.37.10_N32722.cld b
Log name: /tmp/mlxfwmanager-20141126-2.log

```

### 3.5.3.8 Updating Firmware Using an UPMF

Updating the firmware is done by simply executing the UPMF. Most of the command line options of the mlxfwmanager tool apply also for the UPMF.

For further detail, please refer to [mlxfwreset - Loading Firmware on 5th Generation Devices Tool](#).

Some of the most commonly used command line options are:

--force	Force firmware update even if the firmware in the UPMF is not newer than the one on the device.
--yes	Non-interactive mode - assume 'yes' to all questions.

In addition to the mlxfwmanager tool command line options, the UPMF has 2 additional options:

Additional UPMF self extractor options:

--sfx-extract-dir <dir>	Use <dir> for temporary files during execution
--sfx-no-pause	Do not wait for user keypress after completion. Note: This flag is used in Windows OSs.

## Extraction Example

```
# mlxfwmanager-20130717-1 --sfx-extract-dir ./mydir --sfx-extract-only
Extracting to mydir/mlxfwmanager-20130717-1 ... Done
```

Run the firmware update command:

```
# ./mydir/mlxfwmanager-20130717-1/mlxfwmanager -u
```

## 3.5.4 mlxarchive - Binary Files Compression Tool



mlxarchive is not installed by default, and requires installing MFT with the `--oem` option.

The mlxarchive tool allows the user to create a file with the MFA2 extension. The new file contains several binary files of a given firmware for different adapter cards.

mlxarchive accepts the following attributes as its input:

- `--bins-dir` - The path to a folder with the binary files that will be included in the MFA2 file
- `--version` - The MFA2 file's version
- `--out-file` - The output of the mlxarchive file (MFA2 file)
- `-m|--mfa2-file mfa2_file` - MFA2 file to parse

Example:

```
mlxarchive --bins-dir /full/path/to/bin/directory/ --version 1.1.1 --out-file out.mfa2 mlxarchive --mfa2-file
out.mfa2
Creation Time : 2019-09-18 08:35:43
Devices 2
PSID : <...>
Num of Images 1
Index 0
Version : 10.16.1200
Date : 2019-09-18 08:35:43 PSID : <...>
Num of Images 1
Index 1
Version : 10.16.1200
Date : 2019-09-18 08:35:43
```

### 3.5.4.1 mlxarchive Synopsis

```
[--help] [--version version] [--out-file out_file] [--bins-dir bins_dir] [-m|--mfa2-file mfa2_file]
```

where:

<code>--help</code>	Shows the help message and exit
<code>--version version</code>	MFA2's version in the following format: x.x.x
<code>--out-file out_file</code>	The output file
<code>-bins-dir bins_dir</code>	The directory with the binaries files
<code>-m --mfa2-file mfa2_file</code>	Mfa2 file to parse



The .mfa2 file can be used with ethtool to burn adapter cards firmware. The procedure is described in [Updating Firmware Using ethtool/devlink and .mfa2 File](#) section.

## 3.5.5 mlxconfig - Changing Device Configuration Tool

The mlxconfig tool allows the user to change some of the device configurations without reburning the firmware. The configuration is kept after reset.

By default, mlxconfig shows the configurations that will be loaded in the next boot. For 5th generation devices, it is also possible to query the default configurations and the configurations that are used by the current running firmware.

### 3.5.5.1 Tool Requirements

- mst driver loaded
- OFED/WinOF driver to be installed and enabled
- Access to the device through the PCI interface (pciconf/pci\_cr)
- Changing device configurations enabled



For changes after a successful configuration to take effect, reboot the system.

### 3.5.5.2 mlxconfig Synopsis

```
# mlxconfig [Options] <commands> [Parameters]
```

where:

-d --dev <device>	Performs operation for a specified mst device.
-b --db <filename>	Use a specific database file.
-f --file <conf.file>	Raw configuration file.
-h --help	Displays help message.
-v --version	Displays version info.
-e --enable_verbosity	Show default and current configurations. Note: For 5th generation (Group II) devices, the --enable_verbosity option works with ConnectX-4 firmware v12.14.0016 and above for querying the default configurations, and with ConnectX-4 firmware v12.17.1010 and above for querying the current configurations.
-j --json_format <file>	Save the query output to file in JSON format, only usable with Query command.
-y --yes	Answers yes in prompt.
--with_default	Set command will fill any missing parameters with default values. If the final configurations matches the current, no set will be done.

-a --all_attrs	Show all attributes in the XML template.
--host_id	Specify host id for Per-Host TLV (class 3).
--pf_index	Specify PF index for Per-Host TLV (class 3).
-p --private_key	pem file for private key.
-u --key_uuid	keypair uuid.
-eng --openssl_engine	OpenSSL engine name.
-k --open_ssl_key_id	OpenSSL key identifier
--aws_hsm	Sign in 3S environment.
-l --private_key_label	Private key label to use for 3S HSM sign.
-t --device_type <switch/hca/linkx>	Specify the device type.
--i2c_secondary	Specify I2C secondary address.
-s --session_id	Specify the session id for token keep alive session.
-st --session_time	Specify session time for token keep alive session.
-tkn --token_type	Specify token type.
--sign_algorithm	Specify a signature algorithm from the following: RSA4k, RSA3k or ECDSA256.
--nested_token	Include challenge response for ArcusE.
clear_semaphore	Clear the tool's semaphore.
i[show_confs]	Display information about all configurations.
q[query]	Queries the supported configurations. Note: Query command will query a single device if a device is specified. Otherwise, it will query all devices on the machine.
r[reset]	Resets configurations to their default value.
s[et]	Sets configurations to a specific device.
set_raw	Sets raw configuration file (5th generation/Group II devices only).
get_raw	Gets raw configuration file (5th generation/Group II devices only).

backup	Backs up configurations to a file (only 5th generation (Group II) devices). Use set_raw command to restore file.
gen_tlvs_file	Generate a List of all TLVs. TLVs output file name must be specified.
g[en_xml_template]	Generate an XML template. TLVs input file name and XML output file name must be specified.
xml2raw	Generate a Raw file from an XML file. XML input file name and raw output file name must be specified.
raw2xml	Generate an XML file from a Raw file. raw input file name and XML output file name must be specified.
xml2bin	Generate binary configuration dump file from XML file. XML input file name and bin output file name must be specified.
create_conf	Generate configuration file from XML file. XML input file name and bin output file name must be specified.
apply	Apply a configuration file, that was created with create_conf command. bin input file name must be specified.
challenge_request	Send a token challenge request to the device. Token type must be specified.
remote_token_keep_alive	Start a remote token session for a specified time. session id must be specified.
token_supported	Query which tokens are supported.
query_token_session	Query the status of a token session.
end_token_session	End an active token session.
show_system_conf	Show available system configurations.
set_system_conf	Apply a system configuration to the device.
validate_system_conf	Validate a system configuration against the device.

### 3.5.5.3 Bifurcation Configuration

Before working with the Lego Softbank CG1 and Lego C2 flavors, make sure that the device is set to NIC mode (CPU as a RC). Please use the following commands, as specified in the "CPU as RC" column.

Lego Configuration

Configuration of Lego Systems	CPU as RC	DPU as RC
<p>Configuration to bifurcation mode</p>	<p>To configure a BlueField-3 card as a "CPU is RC" of NVMe (DPU as PCIe switch):</p> <pre> mlxconfig -d /dev/mst/ mt41692_pciconf0 -y reset mlxconfig -d /dev/mst/ mt41692_pciconf0 -y s PCI_SWITCH0_UPSTRAEM_PORT_BUS=0 mlxconfig -d /dev/mst/ mt41692_pciconf0 -y s PCI_SWITCH0_UPSTRAEM_PORT_PEX=0 mlxconfig -d /dev/mst/ mt41692_pciconf0 -y s PCI_BUS00_HIERARCHY_TYPE=1 mlxconfig -d /dev/mst/ mt41692_pciconf0 -y s PCI_BUS00_WIDTH=5 mlxconfig -d /dev/mst/ mt41692_pciconf0 -y s PCI_BUS00_SPEED=4 mlxconfig -d /dev/mst/ mt41692_pciconf0 -y s PCI_BUS10_HIERARCHY_TYPE=1 mlxconfig -d /dev/mst/ mt41692_pciconf0 -y s PCI_BUS10_WIDTH=3 mlxconfig -d /dev/mst/ mt41692_pciconf0 -y s PCI_BUS10_SPEED=4 mlxconfig -d /dev/mst/ mt41692_pciconf0 -y s PCI_BUS12_HIERARCHY_TYPE=1 mlxconfig -d /dev/mst/ mt41692_pciconf0 -y s PCI_BUS12_WIDTH=3 mlxconfig -d /dev/mst/ mt41692_pciconf0 -y s PCI_BUS12_SPEED=4 mlxconfig -d /dev/mst/ mt41692_pciconf0 -y s PCI_BUS14_HIERARCHY_TYPE=1 mlxconfig -d /dev/mst/ mt41692_pciconf0 -y s PCI_BUS14_WIDTH=3 </pre>	<p>To configure a BlueField-3 card as a "DPU is RC" of NVMe (using SNAP towards the CPU):</p> <pre> mlxconfig -d /dev/mst/ mt41692_pciconf0 -y reset mlxconfig -d /dev/mst/ mt41692_pciconf0 -y s PCI_BUS00_HIERARCHY_TYPE=0 mlxconfig -d /dev/mst/ mt41692_pciconf0 -y s PCI_BUS00_WIDTH=5 mlxconfig -d /dev/mst/ mt41692_pciconf0 -y s PCI_BUS00_SPEED=4 mlxconfig -d /dev/mst/ mt41692_pciconf0 -y s PCI_BUS10_HIERARCHY_TYPE=2 mlxconfig -d /dev/mst/ mt41692_pciconf0 -y s PCI_BUS10_WIDTH=3 mlxconfig -d /dev/mst/ mt41692_pciconf0 -y s PCI_BUS10_SPEED=4 mlxconfig -d /dev/mst/ mt41692_pciconf0 -y s PCI_BUS12_HIERARCHY_TYPE=2 mlxconfig -d /dev/mst/ mt41692_pciconf0 -y s PCI_BUS12_WIDTH=3 mlxconfig -d /dev/mst/ mt41692_pciconf0 -y s PCI_BUS12_SPEED=4 mlxconfig -d /dev/mst/ mt41692_pciconf0 -y s PCI_BUS14_HIERARCHY_TYPE=2 mlxconfig -d /dev/mst/ mt41692_pciconf0 -y s PCI_BUS14_WIDTH=3 mlxconfig -d /dev/mst/ mt41692_pciconf0 -y s PCI_BUS14_SPEED=4 mlxconfig -d /dev/mst/ mt41692_pciconf0 -y s PCI_BUS16_HIERARCHY_TYPE=2 </pre>

Configuration of Lego Systems	CPU as RC	DPU as RC
	<pre>mlxconfig -d /dev/mst/ mt41692_pciconf0 -y s PCI_BUS14_SPEED=4 mlxconfig -d /dev/mst/ mt41692_pciconf0 -y s PCI_BUS16_HIERARCHY_TYPE=1 mlxconfig -d /dev/mst/ mt41692_pciconf0 -y s PCI_BUS16_WIDTH=3 mlxconfig -d /dev/mst/ mt41692_pciconf0 -y s PCI_BUS16_SPEED=4</pre>	<pre>mlxconfig -d /dev/mst/ mt41692_pciconf0 -y s PCI_BUS16_WIDTH=3 mlxconfig -d /dev/mst/ mt41692_pciconf0 -y s PCI_BUS16_SPEED=4</pre>
Configuring the card in NIC mode	<pre># mlxconfig -d /dev/mst/ mt41692_pciconf0 s INTERNAL_CPU_OFFLOAD_ENGINE=1</pre>	<pre># mlxconfig -d /dev/mst/ mt41692_pciconf0 s INTERNAL_CPU_OFFLOAD_ENGINE=1</pre>

### 3.5.5.4 Examples of mlxconfig Usage

#### 3.5.5.4.1 Querying the Device Configuration


To query the device's configuration, use the following command line:


```
# mlxconfig -d <device> query
```

ConnectX-3 Example:

```
# mlxconfig -d /dev/mst/mt4099_pciconf0 q
Device type: ConnectX-3
PCI device: /dev/mst/
/dev/mst/mt4099_pciconf0

Device 1:
-----
Configurations:      Next Boot
SRIOV_EN             True(1)
NUM_OF_VFS           16
WOL_MAGIC_EN_P1     False(0)
WOL_MAGIC_EN_P2     False(0)
```

 N/A means that the device default configuration is set.

 For Array type parameters, the query command will not show a value for it. It will only show you the word "Array" and the range of the array.

- For example: HOST\_CHAINING\_DESCRIPTOR Array[0..7]
- To query the fifth element in the array, run: `mlxconfig -d <device> query HOST_CHAINING_DESCRIPTOR[5]`
- To specify a range: `mlxconfig -d <device> query HOST_CHAINING_DESCRIPTOR[3..7]`

- To set the fifth element in the array, run: `mlxconfig -d <device> set HOST_CHAINING_DESCRIPTOR[5]=3`
- Or you can set value for more than one element: `mlxconfig -d <device> set HOST_CHAINING_DESCRIPTOR[3..7]=3`

### ConnectX-4 Lx Example:

```
# mlxconfig -d /dev/mst/mt4117_pciconf0 --enable_verbosity q
Device #1:
-----
Device type: ConnectX4LX
PCI device: /dev/mst/mt4117_pciconf0

Configurations:      Default      Current      Next Boot
* NUM_OF_VFS         8          5            5
  SRIOV_EN           True(1)    True(1)     True(1)
The '*' shows parameters with next value different from default/current value.
```

### 3.5.5.4.2 Setting Device Configuration

To set the device configuration, use the following command line:

```
# mlxconfig -d <device> set [Parameters...]
```

#### Example:

```
# mlxconfig -d /dev/mst/mt4099_pciconf0 set WOL_MAGIC_EN_P2=1 NUM_OF_VFS=24
Device type: ConnectX-3
PCI device: /dev/mst/mt4099_pciconf0
Configurations:      Next Boot      New
NUM_OF_VFS           16             24
WOL_MAGIC_EN_P2     False(0)       True(1)

Apply new Configuration?(y/n) [n]: y
Applying... Done!

-I- Please reboot the system to load new configurations.
```

### 3.5.5.4.3 Resetting Device Configuration to Default

To reset the device configuration to default, use the following command line:

```
# mlxconfig -d <device> reset
```

#### Example:

```
# mlxconfig -d /dev/mst/mt4099_pciconf0 reset
Reset configuration for device /dev/mst/mt4099_pciconf0? (y/n) [n] : y
Applying... Done!

-I- Please power-cycle device to load new configurations.
>mlxconfig -d /dev/mst/mt4099_pciconf0 query

Device 1:
-----
Device type: ConnectX-3
PCI Device: /dev/mst/mt4099_pciconf0
Configurations:      Next Boot
SRIOV_EN             True(1)
NUM_OF_VFS           8
WOL_MAGIC_EN_P1     False(0)
WOL_MAGIC_EN_P2     False(0)
```

### 3.5.5.4.4 Setting Missing Parameters with Default Values

Set of commands that will fill any missing parameters with default values. If the final configurations matches the current, no set will be done.

```
# mlxconfig -d <device> --with_default set BOOT_LACP_DIS=False
```

Example:

```
# mlxconfig -d /dev/mst/mt41692_pciconf0 --with_default set BOOT_LACP_DIS=False
Found a difference, first difference on the list is VIRTIO_BLK_EMULATION_NUM_MSIX from val 0 to 2
continue to reset and set

Apply reset and set? (y/n) [n] : y

Device #1:
-----
Device type:      BlueField3
Name:             900-9D3B6-00CV-AAB_Ax
Description:      Nvidia BlueField-3 BF3220 P-Series DPU 200GbE/NDR200 dual-port QSFP112; PCIe Gen5.0 x16 FHHL
with x16 PCIe extension option; Crypto Enabled; SB Disabled 32GB on-board DDR; integrated BMC; Tall Bracket; IPN QP
Device:           /dev/mst/mt41692_pciconf0

Configurations:
      BOOT_LACP_DIS                               Next Boot      New
      True(1)                                       True(1)        False(0)
Applying... Done!
-I- Please reboot machine to load new configurations.
```

### 3.5.5.4.5 Configuring Per-Host TLV Parameters: Host ID and PF Index

Used to define the target host and physical function for Class 3 Per-Host TLV operations.

```
# mlxconfig -d /dev/mst/mt41692_pciconf0 --host_id 1 --pf_index 1 set ROCE_CONTROL=2
```

Example:

```
# mlxconfig -d /dev/mst/mt41692_pciconf0 --host_id 1 --pf_index 1 set ROCE_CONTROL=2

Device #1:
-----
Device type:      BlueField3
Name:             900-9D3B6-00CV-AAB_Ax
Description:      Nvidia BlueField-3 BF3220 P-Series DPU 200GbE/NDR200 dual-port QSFP112; PCIe Gen5.0 x16 FHHL
with x16 PCIe extension option; Crypto Enabled; SB Disabled 32GB on-board DDR; integrated BMC; Tall Bracket; IPN QP
Device:           /dev/mst/mt41692_pciconf0

Configurations:
      ROCE_CONTROL                               Next Boot      New
      ROCE_ENABLE(2)                            ROCE_ENABLE(2) ROCE_ENABLE(2)

Apply new Configuration? (y/n) [n] : y
Applying... Done!
-I- Please reboot machine to load new configurations.
```

## 3.5.5.5 Using mlxconfig

### 3.5.5.5.1 Using mlxconfig with PCI Device in Bus Device Function (BDF) Format

In order to access device in BDF format via configuration cycles, use "pciconf-" as prefix to the device.

Example:

```
# mlxconfig -d 0000:86:00.0 q
```

```

Device #1:
-----
Device type:   ConnectX5
Name:         MCX556A-ECA_Ax
Description:   ConnectX-5 VPI adapter card; EDR IB (100Gb/s) and 100GbE; dual-port QSFP28; PCIe3.0 x16; tall
bracket; ROHS R6
Device:       0000:86:00.0

Configurations:
MEMIC_BAR_SIZE           0
MEMIC_SIZE_LIMIT        _256KB(1)
HOST_CHAINING_MODE       DISABLED(0)
HOST_CHAINING_CACHE_DISABLE  False(0)
HOST_CHAINING_DESCRIPTOR Array[0..7]
HOST_CHAINING_TOTAL_BUFFER_SIZE Array[0..7]
FLEX_PARSER_PROFILE_ENABLE 0
FLEX_IPV4_OVER_VXLAN_PORT 0
ROCE_NEXT_PROTOCOL       254
ESWITCH_HAIRPIN_DESCRIPTOR Array[0..7]
ESWITCH_HAIRPIN_TOT_BUFFER_SIZE Array[0..7]
PF_BAR2_SIZE             0
NON_PREFETCHABLE_PF_BAR  False(0)
VF_VPD_ENABLE            False(0)
STRICT_VF_MSIX_NUM       False(0)
VF_NODNIC_ENABLE         False(0)
NUM_OF_VFS               0
PARTIAL_WRITE_CACHE_MODE DEVICE_DEFAULT(0)
PF_BAR2_ENABLE           False(0)
SRIOV_EN                 False(0)
PF_LOG_BAR_SIZE          5
.....

```

### 3.5.5.5.2 Using mlxconfig to Set IB/ETH Parameters

In order to set IB/ETH parameters through mlxconfig, use the following command line:

```
# mlxconfig -d <device> set [LINK_TYPE_P1=<link_type>] [LINK_TYPE_P2=<link_type>]
```

Example: Configuring both ports as InfiniBand:

```

# mlxconfig -d /dev/mst/mt4119_pciconf0 set LINK_TYPE_P1=1 LINK_TYPE_P2=1

Device #1:
-----
Device type:   ConnectX5
Name:         MCX556A-ECA_Ax
Description:   ConnectX-5 VPI adapter card; EDR IB (100Gb/s) and 100GbE; dual-port QSFP28; PCIe3.0 x16; tall
bracket; ROHS R6
Device:       /dev/mst/mt4119_pciconf0

Configurations:
LINK_TYPE_P1           Next Boot   New
LINK_TYPE_P2           ETH(2)     IB(1)
                       ETH(2)     IB(1)

Apply new Configuration? (y/n) [n] : y
Applying... Done!
-I- Please reboot machine to load new configurations.

```

### 3.5.5.5.3 Using mlxconfig to Set PHY Parameters

#### 3.5.5.5.3.1 Setting Auto Negotiation

Auto negotiation modes is displayed at mlxconfig available configuration menu (Using <i> command).

In order to set non-volatile auto negotiation mode through mlxconfig, use the following command line:

```
# mlxconfig -d <device> set [PHY_AUTO_NEG_P1=<auto_negotiation_mode>] [PHY_AUTO_NEG_P2=<auto_negotiation_mode>]
```

Example: Configuring both ports with auto negotiation enabled:

```
# mlxconfig -d /dev/mst/mt4129_pciconf0 set PHY_AUTO_NEG_P1=1 PHY_AUTO_NEG_P2=1
```

```

Device #1:
-----

Device type:    ConnectX7
Name:          CX713106AE-HEA_QP1_Ax
Description:   NVIDIA ConnectX-7 HHHHL adapter Card; 200GbE (default mode) / NDR200 IB; Dual-port QSFP112; PCIe 5.0
               x16 with x16 PCIe extension option; Crypto Enabled; Secure Boot Capable; IPN for internal use
Device:       /dev/mst/mt4129_pciconf0

Configurations:
PHY_AUTO_NEG_P1
PHY_AUTO_NEG_P2

Next Boot      New
DEVICE_DEFAULT(0) AUTO_NEG_ENABLED(1)
DEVICE_DEFAULT(0) AUTO_NEG_ENABLED(1)

Apply new Configuration? (y/n) [n] : y
Applying... Done!
-I- Please reboot machine to load new configurations.

```

### 3.5.5.5.3.2 Setting Speed Rate Mask

Speed rate mask enables masking device's available speeds in all link operational modes. Speed masking requires defining the speed rate mask and enabling speed override configuration.

In order to set non-volatile speed rate mask through mlxconfig, verify first that override mask is enabled using the following command:

```
# mlxconfig -d <device> set [PHY_RATE_MASK_OVERRIDE_P1=<True|False>] [PHY_RATE_MASK_OVERRIDE_P2=<True|False>]
```

Example: Enabling both ports' speed mask override:

```

# mlxconfig -d /dev/mst/mt4129_pciconf0 set PHY_RATE_MASK_OVERRIDE_P1=1 PHY_RATE_MASK_OVERRIDE_P2=1

Device #1:
-----

Device type:    ConnectX7
Name:          CX713106AE-HEA_QP1_Ax
Description:   NVIDIA ConnectX-7 HHHHL adapter Card; 200GbE (default mode) / NDR200 IB; Dual-port QSFP112; PCIe 5.0
               x16 with x16 PCIe extension option; Crypto Enabled; Secure Boot Capable; IPN for internal use
Device:       /dev/mst/mt4129_pciconf0

Configurations:
PHY_RATE_MASK_OVERRIDE_P1
PHY_RATE_MASK_OVERRIDE_P2

Next Boot      New
False(0)       True(1)
False(0)       True(1)

Apply new Configuration? (y/n) [n] : y
Applying... Done!
-I- Please reboot machine to load new configurations.

```

Configure the wanted speed mask using the following command:

```
# mlxconfig -d <device> set [PHY_RATE_MASK_P1=<rate_mask>] [PHY_RATE_MASK_P2=<rate_mask>]
```

The rate mask mapping is displayed at mlxconfig available configuration menu (Using <i> command).

Example: Enabling both ports to support CAUI-4 / 100GBASE-CR4 only:

```

# mlxconfig -d /dev/mst/mt4129_pciconf0 set PHY_RATE_MASK_P1=0x200 PHY_RATE_MASK_P2=0x200

Device #1:
-----

Device type:    ConnectX7
Name:          CX713106AE-HEA_QP1_Ax
Description:   NVIDIA ConnectX-7 HHHHL adapter Card; 200GbE (default mode) / NDR200 IB; Dual-port QSFP112; PCIe 5.0
               x16 with x16 PCIe extension option; Crypto Enabled; Secure Boot Capable; IPN for internal use
Device:       /dev/mst/mt4129_pciconf0

Configurations:
PHY_RATE_MASK_P1
PHY_RATE_MASK_P2

Next Boot      New
0              0x200 (512)
0              0x200 (512)

Apply new Configuration? (y/n) [n] : y
Applying... Done!
-I- Please reboot machine to load new configurations.

```

### 3.5.5.5.3 Setting FEC Mode

Customizes FEC configuration of the port.

Detailed information on FEC modes is displayed at mlxconfig available configuration menu (Using <i> command).

In order to set non-volatile FEC mode through mlxconfig, use the following command line:

```
# mlxconfig -d <device> set [PHY_FEC_OVERRIDE_P1=<fec_mode>] [PHY_FEC_OVERRIDE_P2=<fec_mode>]
```

Example: Setting FEC mode disabled DME, RS FEC for 25G/50G/100G for both port:

```
# mlxconfig -d /dev/mst/mt4129_pciconf0 set PHY_FEC_OVERRIDE_P1=0x2 PHY_FEC_OVERRIDE_P2=0x2
Device #1:
-----
Device type:    ConnectX7
Name:          CX713106AE-HEA_QP1_Ax
Description:   NVIDIA ConnectX-7 HHHH adapter Card; 200GbE (default mode) / NDR200 IB; Dual-port QSFP112; PCIe 5.0
               x16 with x16 PCIe extension option; Crypto Enabled; Secure Boot Capable; IPN for internal use
Device:       /dev/mst/mt4129_pciconf0

Configurations:
PHY_FEC_OVERRIDE_P1      Next Boot      New
PHY_FEC_OVERRIDE_P2      DEVICE_DEFAULT(0) MODE_2 (2)
                           DEVICE_DEFAULT(0) MODE_2 (2)

Apply new Configuration? (y/n) [n] : y
Applying... Done!
-I- Please reboot machine to load new configurations.
```

### 3.5.5.5.4 Using mlxconfig to Set SR-IOV Parameters

In order to set SR-IOV parameters through mlxconfig, use the following command line:

```
# mlxconfig -d <device> set [SRIOV_EN=<0|1>] [NUM_OF_VFS=<NUM>]
```

Example: Turning on SR-IOV and enabling 8 Virtual Functions per Physical Function:

```
# mlxconfig -d /dev/mst/mt4115_pciconf0 set SRIOV_EN=1 NUM_OF_VFS=8
Device #1:
-----
Device type:    ConnectX4
PCI device:    /dev/mst/mt4115_pciconf0
Configurations:
SRIOV_EN      Next Boot      New
SRIOV_EN      0              1
NUM_OF_VFS    0              8

Apply new Configuration? ? (y/n) [n] : y Applying... Done!
-I- Please reboot machine to load new configurations.
```

### 3.5.5.5.5 Using mlxconfig to Set Preboot Settings

For a full description of the preboot configurable parameters, refer to [Supported Configurations and their Parameters](#) under "Preboot Settings".

Example: Enable boot option ROM on port 1, set boot retries to 3 and set the boot protocol to PXE (on ConnectX-3 Pro cards only).

```
# mlxconfig -d /dev/mst/mt4103_pciconf0 set BOOT_OPTION_ROM_EN_P1=1 BOOT_RETRY_CNT_P1=3 LEGACY_BOOT_PROTOCOL_P1=1
Device #1:
-----
Device type:    ConnectX3Pro
PCI device:    /dev/mst/mt4103_pciconf0
Configurations:
BOOT_OPTION_ROM_EN_P1      Next Boot      New
                           False(0)        True(1)
```

```

BOOT_RETRY_CNT_P1          0          3
LEGACY_BOOT_PROTOCOL_P1   2          1

Apply new Configuration? ? (y/n) [n] : y
Applying... Done!
-I- Please reboot machine to load new configurations.

```

### Example: Configure VLAN ID to 3 on port 2

```

# mlxconfig -d /dev/mst/mt4119_pciconf0 set BOOT_VLAN=3

Device #1:
-----
Device type:   ConnectX5
Name:         MCX556A-ECA_Ax
Description:  ConnectX-5 VPI adapter card; EDR IB (100Gb/s) and 100GbE; dual-port QSFP28; PCIe3.0 x16; tall
              bracket; ROHS R6
Device:       /dev/mst/mt4119_pciconf0

Configurations:
BOOT_VLAN          Next Boot      New
                  1                  3

Apply new Configuration? (y/n) [n] : y
Applying... Done!
-I- Please reboot machine to load new configurations.

```

### 3.5.5.5.6 Using mlxconfig to Split a Port in a Remotely Managed Switch

The break-out cable is a unique NVIDIA capability, where a single physical quad-lane HDR or NDR port is divided into 2 dual-lane ports. It maximizes the flexibility of the end user to use the NVIDIA switch with a combination of dual-lane and quad-lane interfaces according to the specific requirements of its network. All system ports may be split into 2-lane ports. Splitting a port changes the notation of that port -

- In HDR ports:  
From x/y to x/y/z, with “x/y” indicating the previous notation of the port prior to the split, and “z” indicating the number of the resulting sub-physical port (1,2). Each sub-physical port is then handled as an individual port. For example, splitting port 5 into 2 lanes gives the following new ports: 1/5/1 & 1/5/2.
- In NDR ports:  
From x/y/z to x/y/z/i, with “x/y/z” indicating the previous notation of the port prior to the split, and “i” indicating the number of the resulting single-lane port (1,2). Each sub-physical port is then handled as an individual port. For example, splitting port 1/5/1 into 2 lanes results in ports 1/5/1/1 and 1/5/1/2.



To enable the port split, the following actions are required:

**Step 1. Set the Split Mode in a Remotely Managed Switch.**

```
# mlxconfig -d <device>set SPLIT_MODE=1
```

**Example:**

```
# mlxconfig -d /dev/mst/mt54000_pciconf0 set SPLIT_MODE=1
Device #1:
-----
Device type:   Quantum
Name:          N/A
Description:   N/A
Device:        /dev/mst/mt54000_pciconf0
Configurations:  Next Boot          New
                  SPLIT_MODE       NO_SPLIT_SUPPORT(0)          SPLIT_2X(1)
```

To create a query for the Split Mode parameter using mlxconfig:

```
# mlxconfig -d <device> q SPLIT_MODE
```

**Example:**

```
# mlxconfig -d /dev/mst/mt54000_pciconf0 q SPLIT_MODE
Device #1:
-----
Device type:   Quantum
Name:          N/A
Description:   N/A
Device:        /dev/mst/mt54000_pciconf0
Configurations:  Next Boot
                  SPLIT_MODE       SPLIT_2X(1)
```

**Step 2. Split a Port in a Remotely Managed Switch.**

- To split a specific port for one or more ports of (1-64) using mlxconfig:

```
# mlxconfig -d <device> set SPLIT_PORT[<port_num>/<port_range>]=1
```



Please note that although the command, is “set SPLIT\_PORT[33..64]”, it splits a specific port for one or more ports of the higher ports (33-40).

Please note that the first port is set as 1, e.g., [1], [1..64].

- How to turn on the split port for the first port only:

```
mlxconfig -d /dev/mst/SW_MT54000_EVB-SX-1_L00_lid-0x0001 set SPLIT_PORT[1]=1
```

- How to turn on the split port for the first 32 ports (range of ports):

```
mlxconfig -d /dev/mst/SW_MT54000_EVB-SX-1_L00_lid-0x0001 set SPLIT_PORT[1..32]=1
```

- How to turn on the split port for the last 8 ports:

```
mlxconfig -d /dev/mst/SW_MT54000_EVB-SX-1_L00_lid-0x0001 set SPLIT_PORT[57..64]=1
```

- How to turn off the split port for port 40:

```
mlxconfig -d /dev/mst/SW_MT54000_EVB-SX-1_L00_lid-0x0001 set SPLIT_PORT[40]=0
```

- How to query the split port for the first 32 ports:

```
mlxconfig -d /dev/mst/SW_MT54000_EVB-SX-1_L00_lid-0x0001 query SPLIT_PORT[1..32]
```

Step 3. Reboot the switch, or run:

```
flint -d <device> swreset
```

To disable the port split, the following actions are required:

Step 1. Disable the Split Ports in a Remotely Managed Switch:

- To unsplit a specific port for one or more ports (1-32) using mlxconfig:

```
# mlxconfig -d <device> set SPLIT_PORT[<port_num>/<port_range>]=0
```

Step 2. Disable the Split Mode in a Remotely Managed Switch.

```
# mlxconfig -d <device> set SPLIT_MODE=0
```

### 3.5.5.5.7 mlxconfig Raw Configuration Files

mlxconfig allows applying raw configuration file for a pre-set configuration. Raw configuration files are intended for advanced users. This document does not cover the generation of such files.

Set the raw configuration file:

```
# mlxconfig -f ./tlv_file.conf -d /dev/mst/mt4115_pciconfl set_raw

Raw TLV #1 Info:
Length: 0xc
Version: 0
OverrideEn: 1
Type: 0x00000080
Data: 0xa0000000 0xa0020010 0x00000000

Raw TLV #2 Info:
Length: 0x4
Version: 0
OverrideEn: 1
Type: 0x01020012
Data: 0x0000000b

Raw TLV #3 Info:
Length: 0x8
Version: 0
OverrideEn: 1
Type: 0x00000190
Data: 0x00000010 0x00007d00

Raw TLV #4 Info:
Length: 0x4
Version: 0
OverrideEn: 1
Type: 0x00000082
Data: 0x0000000c
Operation intended for advanced users.

Are you sure you want to apply raw TLV file? ? (y/n) [n] : y
Applying... Done!
-I- Please reboot machine to load new configurations.
```



Never apply files from an unreliable source.

### 3.5.5.5.8 Setting Pre-defined Configuration

Use `show_system_conf` to get a list of supported configurations for the required device.



Currently, supported for ConnectX-9 only.

```
# mlxconfig -d <device> show_system_conf
System configurations available for ConnectX9 devices:

Configuration name: conf1 - Dual_Asic_Single_OSFP_PB_1P_ETH
Description:      2 CX9 over a single OSFP 800GR4 each asic
-----
      ASIC[0] Description:
                BOARD_CONFIGURATION_MODE=0 MODULE_SPLIT_M0[0..3]=1 MODULE_SPLIT_M0[4..15]=FF
MODULE_SPLIT_M1[0..15]=FF LINK_TYPE_P1=2 NUM_OF_PLANES_P1=0 NUM_OF_PF=1
      ASIC[1] Description:
                BOARD_CONFIGURATION_MODE=0 MODULE_SPLIT_M0[0..3]=FF MODULE_SPLIT_M0[4..7]=1
MODULE_SPLIT_M0[8..15]=FF MODULE_SPLIT_M1[0..15]=FF LINK_TYPE_P1=2 NUM_OF_PLANES_P1=0 NUM_OF_PF=1

Configuration name: conf2 - Dual_Asic_Single_OSFP_PB_MP_IB
Description:      2 CX9 over a single OSFP XDR x4 (multiplane) each asic
-----
      ASIC[0] Description:
      ...
      ...
      ...
```

- Configuration can be set to asics
- Use "mst aggregare add" to create aggregated device that contains several devices based on their serial number and geographical address
- Configure multiple devices by running single `set_system_conf` command
- Use `mlxconfig -d <aggregated_device> set_system_conf <conf_number>`

```
#example: mlxconfig -d /dev/mst/mt4133_pciconf_agg_0 set_system_conf conf2
```

Configuration of specific asic, can be set in the following format: `set_system_conf`  
`<conf_number>[<asic_number>]`

```
#example: mlxconfig -d </dev/mst/mt4133_pciconf0> set_system_conf conf2[0]
Applying configuration 'conf2' (asic 0) to device /dev/mst/mt4133_pciconf0...
Device #1:
-----
Device type:      ConnectX9
...
Configurations:      Next Boot      New
...
```

After reboot, users can use the `validate_system_conf` to check if the devices were correctly set to a specific configuration.

```
#example: mlxconfig -d </dev/mst/mt4133_pciconf0> validate_system_conf conf3[0]
Validating system configuration 'conf3[0]' on device /dev/mst/mt4133_pciconf0
-----
...
...
-----
Result: Device configuration does NOT match the system configuration.
```

## 3.5.5.6 mlxconfig Commands

### 3.5.5.6.1 mlxconfig Backup Command

The backup command is used to save the current non-volatile configurations (TLV) in the device into a file in raw TLV syntax so it can be restored anytime using the `set_raw` command.

`mlxconfig` backup command allows backing up the all of the configurations which are related only to the PCI Physical Function associated with the given MST device. To back up all of the device configurations, perform the operation from every PCI Physical Function the device exposes. Restoring the configurations must be made from the matching PCI Physical Function.



In a MultiHost environment, these operations are required to be executed per host.

```
# mlxconfig -d /dev/mst/mt4117_pciconf0 -f /tmp/backup.conf backup
Collecting...
Saving output...
Done!
# cat /tmp/backup.conf
MLNX_RAW_TLV_FILE
% TLV Type: 0x00000400, Writer ID: ICMD MLXCONFIG(0x09), Writer Host ID: 0x00 0x00000014 0x00000400 0x00000000
0x00000000 0x000e0000 0x001000f6 0x20160526 0x11250000
# mlxconfig -d /dev/mst/mt4117_pciconf0 -f /tmp/backup.conf set_raw
Raw TLV #1 Info:
Length: 0x14
```

```

Version: 0
OverrideEn: 0
Type: 0x00000400
Data: 0x00000000 0x000e0000 0x001000f6 0x20160526 0x11250000
Operation intended for advanced users.
Are you sure you want to apply raw TLV file? ? (y/n) [n] : y
Applying... Done!
-I- Please reboot machine to load new configurations.

```

### 3.5.5.6.2 Generating an XML Template for the Configurations

Users can generate an XML file that contains a template for the configurations. The template describes the configurations and their parameters. No values are included in the template.

To generate such a template, run the `gen_tlvs_file` command. This command will generate a file containing a list of all supported configurations by `mlxconfig`, with a zero appearing in the end of each configuration. To choose a configuration, change the 0 to 1, then save the file and run the `gen_xml_template` command. An XML file containing the required configurations will be generated.

Example:

```

# mlxconfig gen_tlvs_file /tmp/confs.txt
Saving output...
Done!
# cat /tmp/confs.txt
nv_host_to_bmc          0
nv_kdnet_data           0
nv_fpga_data            0
nv_packet_pacing        0
nv_debug_mode           0
nv_global_pci_conf      0

```

In order to include the `nv_kdnet_data` configuration in the template, change the 0 to 1, as demonstrated in the following example.

Example:

```

nv_kdnet_data           1

#mlxconfig gen_xml_template /tmp/confs.txt /tmp/template.xml
Saving output...
Done!

#cat /tmp/template.xml
<?xml version="1.0" encoding="UTF-8"?>
<config xmlns="http://www.mellanox.com/config">
<nv_kdnet_data>

    <!-- Legal Values: False/True -->
    <kdnet_en></kdnet_en>

</nv_kdnet_data>
</config>

```

#### 3.5.5.6.2.1 Advance Options

Add the `-a` flag in order to allow advance options in the XML generated file. When using this flag, each TLV in the XML file has additional attributes that must be filled.

by default, all TLVs will be at MLNX priority. Other possible values are OEM and USER.

### 3.5.5.6.3 mlxconfig xml2raw Command

The `xml2raw` command is an easy way to generate a flawless raw configuration file that can be used in the `set_raw` command. The input for the command is an XML file that contains the data of the required configurations. To generate an XML file and fill it with the desired values, run

the commands from [Generating an XML Template for the Configurations](#), and then use the `xml2raw` command to generate a raw file.

Example:

```
# cat /tmp/template.xml
<?xml version="1.0" encoding="UTF-8"?>
<config xmlns="http://www.mellanox.com/config">
<nv_kdnet_data>

    <!-- Legal Values: False/True -->
    <kdnet_en>True</kdnet_en>

</nv_kdnet_data>
</config>

#mlxconfig xml2raw /tmp/template.xml /tmp/confs.raw
Saving output...
Done!

#cat /tmp/confs.raw
MLNX_RAW_TLV_FILE
0x03000004 0x00000085 0x00000000 0x80000000
```

### 3.5.5.6.4 `mlxconfig xml2bin` Command

The `xml2bin` command is an easy way to generate a binary file that contains a binary dump of configurations. The input for the command is an XML file that contains the data of the required configurations. To generate an XML file and fill it with the desired values, run the commands from Section 2.4.10, and then use the `xml2bin` command to generate a binary file.

Example:

```
#mlxconfig xml2bin /tmp/template.xml /tmp/confs.bin
Saving output...
Done!
# hexdump -C /tmp/confs.bin
00000000 80 00 00 00          |....|
00000004
```

### 3.5.5.6.5 `mlxconfig create_conf` Command

The `create_conf` command assists in creating an NV configuration file that can be used for LifeCycle and Secure Firmware Updates purposes. The flow for creating a configuration file is the same as the flow for `xml2bin`. The user must provide the command with an XML file containing the required configurations and their values. The command can sign the configuration file, if the user provides a private key and UUID. The sign result will be appended to the end of the configuration file. If no private key and UUID are provided, the tool will compute an SHA256/SHA512 digest and append it to the file. The generated signature will be used by the firmware for authentication purposes.



Currently the only supported NV configurations types are CS tokens, Debug tokens, BTC tokens, and MLNX ID which are used for Secure Firmware Updates. Additionally, it supports two RSA keys of 2048 or 4096 bits length for all tokens except BTC which supports only 4096 bits.



The NV configurations files must have the `applicable_to` configuration.

Examples:

```
# mlxconfig create_conf --private_key privatekey.pem --key_uuid "29ee36ee-13b7-11e7-83de-0cc47a6d39d2" /tmp/
template.xml /tmp/nvconf.bin
```

```
Saving output...
Done!
```

```
# mlxconfig create_conf --private_key privatekey.pem --key_uuid "29ee36ee-13b7-11e7-83de-0cc47a6d39d2" /tmp/
template.xml /tmp/nvconf.bin --openssl_engine pkcs11 --openssl_key_id
"pkcs11:serial=0123456789abcdef;token=My%20token%201;type=private;object=example_pkey;id=%12%34%56%78" --key_uuid
"e0129552-13ba-11e7-a990-0cc47a6d39d2" /tmp/template.xml /tmp/nvconf.bin
Saving output...
Done!
```

### 3.5.5.6.6 mlxconfig apply Command

The apply command can be used to apply the NV configurations files to the firmware using the apply command. Only Firmware that supports applying configurations files can be used.

Example:

```
# mlxconfig -d /dev/mst/mt4115_pciconf0 apply /tmp/nvconf.bin
Applying...
Done!
```

### 3.5.5.7 MFT Supported Configurations and Parameters



The list of MFT Supported Configurations and Parameters is available by running the “`mlxconfig -d <device> show_confs`” command.



Before setting the number of VFs in SR-IOV, make sure your system can support that number of VFs. If your hardware and software cannot support that number, this may cause your system to cease working. Therefore, mlxconfig protects the user by making sure that when setting SR-IOV parameters, for ConnectX-3 and ConnectX-3 Pro, the value of `NUM_OF_VFS*PCI_BAR_SIZE`<sup>(1)</sup> must not exceed 512. For 5th generation devices (Group II devices), however, the value is dependent on the firmware. Also, `NUM_OF_VFS` must not exceed the limit defined by the firmware (127 VFs upper bound). The same calculation applies to BAR size settings.

(1). `PCI_BAR_SIZE` refers to the PCI BAR size per function, either physical or virtual.



In case there were no server booting after enabling SR-IOV, please refer to [Troubleshooting](#).



Support was added to set some of the parameters in mlxconfig in textual values in addition to the numerical values that are still supported. For example: `LINK_TYPE_P1` can be set as follows: `LINK_TYPE_P1=ETH`, instead of: `LINK_TYPE_P1=2`  
Note that the textual values are case insensitive (either “True” or “true” are accepted).

## 3.5.6 flint - Firmware Burning Tool

The flint (Flash interface) utility performs the following functions:

- Burns a binary firmware image to the Flash device attached to an adapter or a switch device.
- Burns an Expansion ROM image to the Flash device attached to adapters.


- Queries for firmware attributes (version, GUIDs, UIDs, MACs, PSID, etc.)
- Enables executing various operations on the Flash memory from the command line (for debug/production).
- Disables/enables the access to the device's hardware registers, and changes the key used for enabling. This feature is functional only if the burnt firmware supports it.

### 3.5.6.1 flint Synopsis

```
flint [OPTIONS] <command> [parameters...]
```

### 3.5.6.2 Tool Options

--allow_rom_change	Allows burning/removing a ROM to/from Firmware image when product version is present.
-banks <banks>	Set the number of attached flash devices (banks)
-blank_guids	Burn the image with blank GUIDs and MACs (where applicable). These values can be set later using the "sg" command (see details below). Commands affected: burn
-clear_semaphore	Force clear the flash semaphore on the device. No command is allowed when this flag is used. NOTE: May result in system instability or flash corruption if the device or another application is currently using the flash. Exercise caution.
--cpu_util <CPU_UTIL>	Use this flag to reduce CPU utilization while burning, Windows only. Legal values are from 1 (lowest CPU) to 5 (highest CPU)
-d[evice] <device>	Device flash is connected to. Commands affected: all
-dual_image	Make the burn process burn two images on flash (previously default algorithm). Current default failsafe burn process burns a single image (in alternating locations). Commands affected: burn
-flash_params <type,log2size,num_of_flash es>	Use the given parameters to access the flash instead of reading them from the flash. Supported parameters: <ul style="list-style-type: none"> <li>• Type: The type of the flash, such as: M25PXxx, M25Pxx, SST25VFxx, W25QxxBV, W25Xxx, AT25DFxxx, S25FLXXXP</li> <li>• log2size: The log2 of the flash size</li> <li>• num_of_flash: the number of the flashes connected to the device</li> </ul>
--flashed_version	When specified, only flashed fw version is fetched Commands affected: query
-guid <GUID>	GUID base value. 4 GUIDs are automatically assigned to the following values: guid -> node GUID guid+1 -> port1 guid+2 -> port2 guid+3 -> system image GUID NOTE: port2 guid will be assigned even for a single port HCA - The HCA ignores this value. Commands affected: burn, sg

-guids <GUIDs...>	4 GUIDs must be specified here. The specified GUIDs are assigned to the following fields, respectively: node, port1, port2 and system image GUID. NOTE: port2 guid must be specified even for a single port HCA. The HCA ignores this value. It can be set to 0x0. Commands affected: burn, sg
-h[elp]	Prints this message and exits
-hh	Prints extended command help
--hmac_key <hmac_key>	Path to the file containing the HMAC key (For FS4 image only).
--hsm	Flag to use with sign command. Will use HSM HW for encryption operations.
-i[image] <image>	Binary image file. Commands affected: burn, verify
--ignore_dev_data	Do not attempt to take device data sections from device (sections will be taken from the image. FS3 image only). Commands affected: burn
--key_uuid <uuid_file>	UUID matching the given private key to be used by the sign command
--key_uuid2 <uuid_file>	UUID matching the given private key to be used by the sign command
-log <log_file>	Prints the burning status to the specified log file
--low_cpu	When specified, cpu usage will be reduced. Run time might be increased Commands affected: query
-mac <MAC>1	MAC address base value. 2 MACs are automatically assigned to the following values: mac -> port1 mac+1 -> port2 Commands affected: burn, sg
-macs <MACs...>1	2 MACs must be specified here. The specified MACs are assigned to port1, port2, respectively. Commands affected: burn, sg NOTE: -mac/-macs flags are applicable only for NVIDIA Ethernet products.
-no	Non-interactive mode - assume answer "no" to all questions. Commands affected: all
-no_flash_verify	Do not verify each write on the flash.
--no_fw_ctrl	Do not attempt to work with the firmware Ctrl update commands.
-nofs	Burns image in a non failsafe manner.
--openssl_engine <engine name>	Name of the OpenSSL engine to be used by the sign/rsa_sign commands to work with the HSM hardware via OpenSSL API <div style="border: 1px solid red; padding: 5px; margin-top: 10px;"> Please be aware that OpenSSL engine will be deprecated in the next release.</div>
--openssl_key_id <key>	Key identification string to be used by the sign/rsa_sign commands to work with the HSM hardware via OpenSSL API
--output_file <string>	Output file name for exporting the public key from PEM/BIN.
-override_cache_replacement 2	Allow accessing the flash even if the cache replacement mode is enabled. NOTE: This flag is often referred to as -ocr NOTE: This flag is intended for advanced users only. Running in this mode may cause the firmware to hang.
--private_key <key_file>	Path to PEM formatted private key to be used by the sign command

--private_key_label <string>	Flag to use with sign/import_hsm_key commands.
--private_key2 <key_file>	Path to PEM formatted private key to be used by the sign command
-qq	Run a quick query. When specified, flint will not perform full image integrity checks during the query operation. This may shorten execution time when running over slow interfaces (e.g., I2C, MTUSB-1). Commands affected: query
-s[ilent]	Do not print burn progress flyer. Commands affected: burn
-striped_image	Use this flag to indicate that the given image file is in a "striped image" format. Commands affected: query verify
-uid <UID>	5th Generation (Group II) devices only. Derive and set the device's base UID. GUIDs and MACs are derived from the given base UID according to NVIDIA Methodologies. Commands affected: burn, sg
-use_dev_rom	Save the ROM which exists in the device (FS3 and FS4 image only). Commands affected: burn
--use_fw	Access to flash using FW (ConnectX-3/ConnectX-3 Pro device only). Commands affected: all
-use_image_guids	Burn (guids/uids/macs) as appears in the given image. Commands affected: burn
-use_image_ps	Burn vsd as appears in the given image - do not keep existing VSD on flash. Commands affected: burn
-use_image_rom	Do not save the ROM which exists in the device. Commands affected: burn
--user_password <string>	Flag to use with HSM HW for encryption operations.
-v	Version info.
-vsd <string>	Write this string, of up to 208 characters, to VSD when burn.
-y[es]	Non interactive mode - assume answer "yes" to all questions. Commands affected: all
--linkx	Burn or query the cable device connected to the host.
--aws_hsm	Flag for the <code>rsa_sign</code> command
--cert_chain_index	Use this flag to specify the certificate location. The acceptable values are 0-7 (default - 0).
--i2c_secondary <address>	Change the I <sup>2</sup> C secondary address.
--run_module_image	Use this flag to switch FW banks on the module. By default, the command is not performed.
--commit_module_image	Use this flag to switch committed bank on the module. By default, the command is not performed.



The -mac and -macs options are applicable only to NVIDIA Ethernet adapter and switch devices.



When accessing SwitchX via I<sup>2</sup>C or PCI, the -override\_cache\_replacement flag must be set.

### 3.5.6.3 Command Parameters

The flint utility commands are:

#### Common Firmware Update and Query

b[urn]	Burn flash
q[uey] [full]	Query misc. flash/firmware characteristics, use "full" to get more information.
v[erify]	Verify entire flash
swreset	SW reset the target unmanaged switch device. This command is supported only in the In-Band access method.
sign_with_h mac	Sign image with HMAC.
component_ type	Queries components on a given device via FW
skip_if_sam e	Skip burning if the firmware version matches the current version on the device

#### Expansion ROM Update:

brom <ROM-file>	Burn the specified ROM file on the flash.
drom	Remove the ROM section from the flash.
rrom <out-file>	Read the ROM section from the flash.
qrom	Query ROM in a given image.

#### Initial Burn, Production:

bb	Burn Block - Burns the given image as is. No checks are done. Note: The MFT 'bb' option is an advanced flag used ONLY for production flows. It is NOT recommend to use it, as it can cause unrecoverable firmware burning failures. <b>Note:</b> FwBurnBlock is not supported any longer in FS3 and up images.
sg [guids_num=<num> step_size=<size>]   [nocrc]	Set GUIDs.
set_vpd [vpd file]	Set read-only VPD (For FS3 image only).
smg [guids_num=<num> step_size=<size>]	Set manufacture GUIDs (For FS3 image only).
sv	Set the VSD.

#### Misc Firmware Image Operations

ri <out-file>	Read the fw image on the flash.
dc [out-file]	Dump Configuration: print fw configuration file for the given image.

dh [out-file]	Dump Hash: print hash file for the given image.
checksum cs	Perform MD5 checksum on firmware.
timestamp ts <set query reset> [timestamp] [FW version]	Set/query/reset firmware timestamp.
cache_image ci	Cache FW image (Windows only).
sign	Sign firmware image file
rsa_sign	Sign firmware image file with RSA
set_public_keys [public key binary file]	Set Public Keys (For FS3/FS4 image only).
set_forbidden_versions [forbidden versions]	Set Forbidden Versions (For FS3/FS4 image only).
import_hsm_key	This command allows to import the private and public key to the HSM HW.
export_public_key	This command extracts the public key from given BIN file or from PEM file.

#### Hardware Access Key:


set_key [key]	Set/Update the HW access key which is used to enable/disable access to HW. The key can be provided in the command line or interactively typed after the command is given. NOTE: The new key is activated only after the device is reset.
hw_access <enable  disable> [key]	Enable/disable the access to the HW. The key can be provided in the command line or interactively typed after the command is given.


#### Low Level Flash Operations:

hw query	Query HW info and flash attributes.
e[rase] <addr>	Erase sector
rw <addr>	Read one dword from flash
ww <addr> < data>	Write one dword to flash
wwne <addr>	Write one dword to flash without sector erase
wb <data-file> <addr>	Write a data block to flash
wbne <addr> <size> <data ...>	Write a data block to flash without sector erase
rb <addr> <size> [out-file]	Read a data block from flash

#### Return Values:

Value	Description
0	Successful completion
1	An error has occurred
7	For the <code>burn</code> command - The option of burning new firmware was not chosen by the user when prompted. Thus, the firmware burning process was aborted.

 The following commands are non-failsafe when performed on a 5th generation (Group II) device: `sg`, `smg`, `sv` and `set_vpd`.

 Manufacture GUIDs are similar to GUIDs. However, they are located in the protected area of the flash and set during production. By default, firmware will use GUIDs unless specified otherwise during production.

### 3.5.6.4 Burning a Firmware Image

The flint utility enables you to burn the Flash from a binary image. To burn the entire Flash from a raw binary image, use the following command line:

```
# flint -d <device> -i <fw-file> [-guid <GUID> | -guids <4 GUIDS> | -mac <MAC> | -macs <2 MACs>] burn
```

where:

device	Device on which the flash is burned.
fw-file	Binary firmware file.
GUID(s)	Optional, for InfiniBand adapters and 4th generation (Group I) switches. One or four GUIDs. <ul style="list-style-type: none"><li>• If 4 GUIDS are provided (-guids flag), they will be assigned as node, Port 1, Port 2 and system image GUIDs, respectively.</li><li>• If only one GUID is provided (-guid flag), it will be assigned as node GUID. Its values +1, +2 and +3 will be assigned as Port 1, Port 2 and system image GUID, respectively.</li><li>• If no -guid/-guids flag is provided, the current GUIDs will be preserved on the device.</li></ul> NOTE: For 4th generation (Group I), four GUIDs must be specified but Ports 1 and 2 GUIDs are ignored and should be set to 0. NOTE: A GUID is a 16-digit hexadecimal number. If less than 16 digits are provided, leading zeros will be inserted.
MAC(s)	Optional, for Ethernet and InfiniBand adapters and switches. <ul style="list-style-type: none"><li>• If 2 MACs are provided (-macs flag), they will be assigned to Port 1 and Port 2, respectively.</li><li>• If only one MAC is provided (-mac flag), it will be assigned to Port 1; MAC+1 will be assigned to Port 2.</li><li>• If no -mac/-macs flag is provided, the current LIDs will be preserved on the device.</li></ul> NOTE: A MAC is a 12-digit hexadecimal number. If less than 12 digits are provided, leading zeros will be inserted.

To burn a firmware image:

1. Update the firmware on the device, keeping the current GUIDs and VSD. (Note: This is the common way to use the tool.)

```
# flint -d /dev/mst/mt4131_pciconf0 -i fw_900-9X81Q-00CN-STA_Ax-MT_0000001223.bin burn
```

2. Update the firmware on the device, specifying the GUIDs to burn.

```
# flint -d /dev/mst/mt4131_pciconf0 -i fw_900-9X81Q-00CN-STA_Ax-MT_0000001223.bin -guid 1234567deadbeef burn
```

3. Update the firmware on the device, specifying the MACs to burn.

```
# flint -d /dev/mst/mt4131_pciconf0 -i fw_900-9X81Q-00CN-STA_Ax-MT_0000001223.bin -mac 1234567deadbeef burn
```

4. Burn the image on a blank Flash device. This means that no GUIDs are currently burnt on the device, therefore they must be supplied (with `-guid/-guids`) by the burning command. Moreover, the burn process cannot be failsafe when burning a blank Flash, therefore the `-nofs` flag must be specified.

```
burn# flint -d /dev/mst/mt4131_pciconf0 -i fw_900-9X81Q-00CN-STA_Ax-MT_0000001223.bin -nofs -guid 12345678  
burn
```

5. Read FW from the device and save it as an image file.

```
# flint -d /dev/mst/mt4131_pciconf0 ri Flash_Image_Copy.bin
```

6. MT58100 SwitchX switch:

Burn the image on a blank Flash device. Meaning, no GUIDs/MACs are currently burnt on the device, therefore they must be supplied (with `-guid/-guids` and `-mac/-macs`) by the burning command. Moreover, the burn process cannot be failsafe when burning a blank Flash, therefore the `-nofs` flag must be specified.

```
# flint -d /dev/mst/mtusb-1 -i /tmp/fw-sx.bin -nofs -guids 000002c900002100 0 0 000002c900002100 -macs  
0002c9002100 0002c9002101 b
```

7. MT58100 SwitchX switch inband firmware update:

```
# flint -d lid-0x18 -i /tmp/fw-sx.bin b
```

## Burning Firmware with Different Minor PSID

On new generation devices (ConnectX-9 and above) that support the Unified SKU feature, it is possible to burn a firmware image of which the PSID differs from the device's current PSID only in the minor portion. The PSID is interpreted as three components:

- Header (e.g., `MT_00` ),
- Two-character minor (e.g., `AB` )
- Six-character major (e.g., `000129` )

Forming a full PSID, such as: `MT_00AB000129`

A firmware burn is allowed when all of the following conditions are met:


- The device firmware advertises support for the PSID major-minor split feature
- Both the device and image PSIDs share the same header and major values
- The image minor does not begin with a reserved character ( `X` , `Y` , or `Z` )
- The device's minor PSID has not been locked to a previously-burned value

After a successful burn with a changed minor PSID, a device reset (e.g., via `mlxfwreset` ) is required for the new PSID to take effect. Once reset, the new minor PSID is automatically locked; subsequent attempts to change it to another minor value will be rejected with a descriptive error message indicating the locked PSID.

If the device does not support the feature, standard behavior applies: the device PSID and image PSID must match exactly, or the `--allow_psid_change` flag must be used to override.

### 3.5.6.4.1 Burning the MFA2 Images

Burning the MFA2 images enables the user to extract (i.e. unzip) 4MB images from MFA2 archive that matches the device type and device PSID. If there are more than one matching images, the user may use the `--latest_fw` flag and burn the latest firmware, or choose the required image from the user menu.

 The device flash MUST have all relevant device information (signatures, PSID, VPD, DEV\_INFO, MFG\_INFO, etc.) valid since MFA2 format does not have that information and without the burn process will fail.

```
flint -d <device> -i <mfa2 file> --psid <PSID string> (optionally) --latest_fw (optionally) -silent (optionally) b (or burn)
```

- Burning the MFA2 Images when the Device Includes a Valid Image  
In this scenario, the user *may* (optional) provide a `--psid` flag and extract from the MFA2 archive the image that matches this flag, and this way actually change the PSID on the device.
- Burning the MFA2 Images when in Live Fish Mode  
In this scenario, the user *must* provide a `--psid` flag and extract from the MFA2 archive the image that matches this flag, and this way actually change the PSID on the device.


### 3.5.6.4.2 Burning PLDM Images

```
flint -d <device> -i <pldm_package> --component_type FW -y b
```

Options:

<code>--component_type</code>	Component type to burn from the package of the supported components (currently only FW)
-------------------------------	---

### 3.5.6.4.3 Cable Firmware Update (In-Field-Firmware-Update)

 This capability is supported only in NVIDIA Quantum switch systems and hosts with NVIDIA ConnectX-6 adapter cards.

The In-Field-Firmware-Update (IFFU) tool works via the switches/NICs in the datacenters and is intended for remote control. The tool is used to update cables transceivers' firmware.


Optical Cables and Transceivers are active network components which run firmware, and as any component running firmware, the ability to update firmware is mandatory. Transceiver firmware update is a system flow which requires the following elements:

- Tool/Manager which will perform the firmware update

- Switch/NIC firmware management used as a middleman between the Manager and the cable transceiver
- Transceiver firmware: target for upgrade

The figure below shows the tool/manager which runs on a remotely controlled host or (in case of managed switches) on a switch, shown as 'Device'.

The manager can query the transceivers type and the current running firmware to understand if an update is required. When an update is required, the manager can apply a set of commands that will send the remote host device a new firmware images for the specific transceiver(s) and activate a firmware update flow. The set of commands is defined with low level primitives to support full flexibility for the user. High level script can be applied on top of the manager and allow system wide update.



The update of modules/AOCs connected to switches is done over InfiniBand (inband) PRM registries. Whereas, the update of modules connected to NICs is done over MCC (RegAccess) on the host.  
 Inband connection implies that unmanaged switches like QM8790 support IFFU.  
 Each device (NIC, Switch) can update only the modules connected directly to it, not the far end. Updating the far end transceiver/end of the AOC requires the same operation to be done at the far end switch(es).

The Tool/Manager host must have MST rev. 4.16.00 or later installed.  
 Remote control from outside the cluster (data center) requires access to the host being used as Tool/Manager. When the cluster has many switches, multiple hosts may be engaged in the upgrade process. The host(s) can be remotely controlled via VNC access.

### 3.5.6.4.3.1 Firmware Burning Across a Cluster (Data Center)

The IFFU function described below works on one switch. Cluster-wide firmware updating is done by use of a script which initiates the update procedure in multiple switches in parallel by initiating an instance of the flint command for each switch. In large clusters the script can be executed on multiple hosts, each handling a different part of the cluster.

### 3.5.6.4.3.2 Cable Burn Command

```
# flint -d <device> --linkx <flags> <commands>
```

where:

Flags:

<device>	The name of the target switch (one only).
--downstream_device_id_start_index <downstream_device_id_start_index>	The port number of the first LinkX cable/transceiver. (min. port number = 1)
--num_of_downstream_devices <num_of_downstream_devices>	the number of cables/transceivers to burn. They are burnt sequentially.
--linkx_auto_update	Use this flag to burn all supported cables/transceivers connected to the switch.
--download_transfer	Use this flag to perform download and transfer of all cable data for cables. Download and transfer are not performed by default. This flag is only relevant for cable components.
--activate	Use this flag to apply the activation of the new firmware in the updated devices. Activation is not performed by default.
--activate_delay_sec <timeout in seconds>	Use this flag to activate all cable devices connected to host with delay, acceptable values are between 0 and 255 (default - 1, immediately). Important: 'activate' flag must be set. This flag is relevant only for cable components.
--i <image>	'i' indicates 'binary Image' followed by the path and file name of the bin file to download into the cable/transceiver.
--downstream_device_ids <list of ports>	Use this flag to specify the LNKX ports to perform query. List must be only comma-separated numbers, without spaces

Commands:

b[urn]	Burn flash
q[uey]	Query misc. flash/firmware characteristics.

### 3.5.6.4.3.3 Updating the Firmware

Burning a firmware cable transceiver connected to the host (NIC or switch) is done using the "flint" tool. To do so, the user should use the "-linkx" flag.

Firmware can be burnt in follow one of the methods:

- Burn with Auto-update:

1. Transfer the data from the host.

```
# flint -d <device> --linkx --linkx_auto_update --download_transfer -i <image> b
```

Example:

```
# flint -d lid-2 --linkx --linkx_auto_update --download_transfer -i image.bin b
```

## 2. Activate the firmware.

```
# flint -d <device> --linkx --linkx_auto_update --activate b
```



The flint "--activate" flag behavior is changed to include a minimal delay of 1 second to avoid disconnections if the connected port is being activated. To use the "legacy" activation flow, use the "--activate\_delay\_sec 0" command.

Example:

```
# flint -d lid-2 --linkx --linkx_auto_update --activate b
```

Activate with delay Example:

```
# flint -d lid-2 --linkx --linkx_auto_update --activate --activate_delay_sec 10 b
```

Transfer and Activate Example:

```
# flint -d lid-2 --linkx --linkx_auto_update --download_transfer --activate -i image.bin b
```



Burning all cables in an unmanaged switch in one operation is risky. If the cables do not link up after the update, you lose connection to the switch - permanently. Burn half of the cables, check that they come up after burning, then burn the other half.

- Burning multiple cables in the switch using the 'Range':

### 1. Transfer the data from the host.

```
# flint -d <device> --linkx --downstream_device_id_start_index <index> --num_of_downstream_devices <number> --download_transfer -i <image> b
```

### 2. Activate the firmware.

```
# flint -d <device> --linkx --downstream_device_id_start_index <index> --num_of_downstream_devices <number> --activate b
```

Example of Download Transfer with Activation, range indices is 10 to 16:

```
# flint -d lid-2 --linkx --downstream_device_id_start_index 10 --num_of_downstream_devices 6 download_transfer --activate -i image.bin b
```

This will update 6 AOCs/Transceivers starting from port 10, i.e. all ports in the range 10..15.



You cannot ‘overburn’ the same firmware version into a transceiver/AOC as the one already installed. This is to prevent wasting time re-burning transceivers in a large cluster. If you try to burn the existing FW version, the command responds:

```
Cable burn failed, error is LinkX downstream transfer failed for
device index i
```

Example of successful update of 1 AOC:

```
-I- Downloading FW ...
FSMST_INITIALIZE - OK
Writing COMPID_LINKX component - OK
FSMST_LOCKED - OK
FSMST_DOWNSTREAM_DEVICE_TRANSFER - OK
FSMST_LOCKED - OK
Please wait while activating the transceiver(s) FW ...
FSMST_ACTIVATE - OK..]
-I- Cable burn finished successfully.
```



Downloading and burning takes approx. 1½ minute + activation ½ minute for one cable. The time for multiple cables depends on which ports they are plugged into.

### Cable Burn Command Running CMIS Firmware Upgrade Flow for Supported Cables

The flint tool is able to burn firmware packages on CMIS compliant cables that support the CDB firmware update procedure.

```
# flint --device <mst cable device> [--image <image>] [flags] burn
```

Where:

Where:

--module_password	Optional, module password to enable locked operations.
--module_vendor_data	Optional, path to vendor data file in case it is not a part of the firmware image file.
--activate	Optional, run and commit the burned image. Use without the "--image" flag to try to perform run and commit commands if possible.

#### 3.5.6.4.3.4 Querying Firmware Version from an Image

Querying a cable image for firmware version is done using the "flint" tool.

```
# flint -i <fw file> q
```

#### 3.5.6.4.3.5 Querying Vendor Specific Firmware Information from a NVIDIA AOC / Transceiver

Querying a firmware cable transceiver is done using the "flint" tool.



In case the Vendor Specific query command is not support by the firmware, it will run the CMIS standard query implemented by the firmware.

```
# flint -d <cable device> q
```

### 3.5.6.4.3.6 Querying Firmware Information from an AOC / Transceiver

Querying a firmware cable transceiver connected to the host (NIC or switch) is done using the "flint" tool. To do so, the user should use the "-linkx" flag.

```
# flint -d <device> --linkx --downstream_device_ids <ids> [--output_file <file_name>] q
```

Query ports 1,2,5 Example:

```
# flint -d <device> --linkx --downstream_device_ids 1,2,5 q
```

The system responds with information about the firmware version loaded into the transceivers.

The firmware version of all cables plugged into ports 1...40 of a switch with lid #nn can alternatively be checked with the mlxlink command:

```
# for i in {1..40}; do echo $i; mlxlink -d lid- $nn$  -p $i -m | grep 'Part\|FW'; done
```

Checking successful burning and operation - Example:

It is essential to check that the links come up AFTER the cable FW is updated and reactivated. This can be done as follows:

```
# for i in {36..40}; do echo $i; mlxlink -d lid- $nn$  -p $i -m | grep 'Part\|FW\|State'; done
```

The 'State' parameter was added to the query. The response has the following format (example):

```
# 36
State                : Active
Vendor Part Number   : MFS1S00-H010
FW Version           : 38.100.59
37
State                : Active
Vendor Part Number   : MFS1S00-H010
FW Version           : 38.100.59
38
State                : Active
Vendor Part Number   : MFS1S00-H010
FW Version           : 38.100.59
39
State                : Active
Vendor Part Number   : MFS1S00-H010
FW Version           : 38.100.59
40
```

State	: Active
Vendor Part Number	: MFS1S00-H010
FW Version	: 38.100.59

### 3.5.6.5 Querying the Firmware Image

To query the FW image on a device, use the following command line:

```
# flint -d <device> q
```

To query the FW image in a file, use the following command line:

```
# flint -i <image file> q
```

where:

device	Device on which the query is run.
image file	Image file on which the query is run.

Examples:

- Query the FW on the device.
 

```
# flint -d /dev/mst/mt4133_pciconf0 query
```
- Query the FW image file.
 

```
# flint -i 25408-2_42_5000-MCX354A-FCB_A2.bin query
```
- Security Attributes field in Query output:
 

This field lists the security attributes of the device’s firmware, where:

  - Secure-fw: This attribute indicates that this binary/device supports secure-firmware-updates. It means that only officially signed binaries can be loaded to the device from the host, and that the current binary is signed.
  - Signed-fw: This attribute indicates that that this binary is signed and that the device can verify digital signatures of new updates. However, unlike, secure-fw, there might still be methods to upload unsigned binaries to the device from the host.
  - debug: This attribute indicate that this binary is (or this device runs) a debug-version. Debug versions are custom made for specific data-centers or labs, and can only be installed after a corresponding debug-fw token is pushed to the device. The debug-fw-token, which is digitally signed, includes a list of the target devices MAC addresses.
  - dev: This attribute indicates that the firmware is signed with development (test) key.
- Default Update Method" field in Query Full output: {This field reflect the method which flint will use in order to update the device. The user can enforce a different method using the --no\_fw\_ctrl or the --ocr flags. The default methods are:
  - Legacy: flint will use the low level flash access registers.
  - fw\_ctrl: flint will operate the ‘firmware component update’ state machine.
- Secure-boot attributes
  - Secure-boot : This attribute indicates if the device supports secure-boot
  - Life-cycle : This attribute indicates the current status of secure-boot

- Security-version:
  - For query on image: This attribute indicates the security-version of the image.
  - For query on device:
    - “EFUSE security version”: Indicates the security version of the device
    - “Image security version”: Indicates the security version of the image on the flash
    - Programming method: Indicates when the boot will program the “EFUSE security version” to be aligned with the “image security version”.

### 3.5.6.6 Verifying the Firmware Image

To verify the FW image on the Flash, use the following command line:

```
# flint -d <device> verify
```

To verify the FW image in a file, use the following command line:

```
# flint -i <image file> v
```

where:

device	Flash device to verify.
image file	Image file to verify.

Examples:

```
# flint -d /dev/mst/mt4115_pciconf0 v
```

```
# flint -i ./image_file.bin verify
```

#### 3.5.6.6.1 Comparing the Binary Image

Binary comparison of the firmware image enables the user to verify that a given firmware image contains the image that matches the given device.



Since ConnectX-4/ConnectX-4 Lx devices have iTOC (image specific) and dTOC (device specific) sections at the beginning of the device flash, and the MFA2 archive does not have the dTOC information by its definition, the binary comparison will ignore the device specific sections on the device.

```
#flint -d <device> -i <fw image> --silent (optional) bc (or binary_compare)
```

#### 3.5.6.6.2 The Verify Command on Encrypted Flash/Image



The `verify` command on encrypted flash/image is applicable on adapter cards starting from ConnectX-7.

The flint tool supports the `verify` command on encrypted flash/image, as follows:

- When both the device and the image are given the verify command: verifying encrypted flash, the flint tool will execute binary-compare between the flash and the given image (the

image is expected to be the one burnt on the device). In case of a device in recovery mode, the verify action is applicable before transcoding.

- When an encrypted device/image is given the verify command: only DTOC CRCs will be verified. In case a device is given, the verify is applicable in recovery mode only.

### 3.5.6.7 Performing Checksum Calculation on Image/Device

The flint utility allows performing an MD5 checksum on the non-persistent sections of the firmware image. For example: the sections that are changed when performing a firmware upgrade.

To perform a checksum on the flash, run the following command line:

# flint -d <mst device> checksum To perform a checksum on a firmware image, run the following command line:

# flint -i <image file> checksum where:

device	Flash device to verify.
image file	Image file to verify.

Examples:

```
flint -i fw-ConnectX4Lx.bin checksum -l- Calculating Checksum ... Checksum:
68ddae6bfe42f87f09084f3f468a35c6
flint -d /dev/mst/mt4117_pciconf0 cs
-l- Calculating Checksum ...
Checksum: 68ddae6bfe42f87f09084f3f468a35c6
```

### 3.5.6.8 Managing an Expansion ROM Image

To burn an Expansion ROM image, run the following command:

```
# flint -d <mst device> brom <image name>.mrom
```

The “brom” command installs the ROM image on the flash device or replaces an already existing one.

Example:

```
# flint -d /dev/mst/mt4099_pci_cr0 brom example.mrom
Current ROM info on flash: N/A
```

```
New ROM info: type=PXE version=3.5.305 cpu=AMD64
Burning ROM image - OK
Restoring signature - OK
#
```

To read an expansion ROM image to a file, run the following command:

```
# flint -d <mst device> rrom <image name>.rom
```

Example:

```
# flint -d /dev/mst/mt4099_pci_cr0 rromexample.mrom
# flint -d /dev/mst/mt4099_pci_cr0 q
Image type: FS2
FW Version: 2.42.5000
FW Release Date: 4.5.2017
Rom Info: type=PXE version=3.5.305 cpu=AMD64
Device ID: 4099
```

```
Description: Node      Port1      Port2      Sys image
GUIDs:      f45214030001b8a0 f45214030001b8a1 f45214030001b8a2
f45214030001b8a3
MACs:              f4521401b8a1  f4521401b8a2
VSD:
PSID:      MT_1090120019
#
```

To remove the expansion ROM, run the following command:

```
# flint -d <mst device> drom
```

Examples:

```
# flint -d /dev/mst/mt4099_pci_cr0 drom
Removing ROM image - OK
Restoring signature - OK
```

### 3.5.6.9 Setting GUIDs and MACs

To set GUIDs/MACs/UID for the given device, use the 'sg' (set guides) command with the -guid(s), -uid and/or -mac(s) flags.

#### 3.5.6.9.1 4th Generation (Group I) Devices

On 4th generation/Group I devices, the "sg" command can operate on both the image file and the image on the flash. When running the "sg" command on an image on the flash, if the GUIDs/MACs/UIDs in the image are non-blank, the flint will re-burn the current image using the given GUIDs/MACs/UIDs.

1. Change the GUIDs/MACs on a device:

```
# flint -d /dev/mst/mt4099_pci_cr0 q
-W- Running quick query - Skipping full image integrity checks.
Image type: FS2
FW Version: 2.42.5000
FW Release Date: 4.5.2017
Device ID: 4099
Description: Node      Port1      Port2      Sys image
```

GUIDs: f45214030001b8a0 f45214030001b8a1 f45214030001b8a2 f45214030001b8a3  
MACs: f4521401b8a1 f4521401b8a2  
VSD:  
PSID: MT\_1090120019

```
# flint -d /dev/mst/mt4099_pci_cr0 -guid 0x452140300abadaba -mac 0x300abadaba sg  
-W- GUIDs are already set, re-burning image with the new GUIDs ...  
You are about to change the Guids/Macs/Uids on the device:
```

	New Values	Current Values
Node GUID:	452140300abadaba	f45214030001b8a0
Port1 GUID:	452140300abadabb	f45214030001b8a1
Port2 GUID:	452140300abadabc	f45214030001b8a2
Sys.Image GUID:	452140300abadabd	f45214030001b8a3
Port1 MAC:	00300abadaba	f4521401b8a1
Port2 MAC:	00300abadabb	f4521401b8a2

Do you want to continue ? (y/n) [n] : y  
Burning FS2 FW image without signatures - OK  
Restoring signature - OK

```
# flint -d /dev/mst/mt4099_pci_cr0 q  
Image type: FS2  
FW Version: 2.31.5050  
FW Release Date: 4.5.2014  
Device ID: 4099  
Description: Node Port1 Port2 Sys image  
GUIDs: 452140300abadaba 452140300abadabb 452140300abadabc 452140300abadabd  
MACs: 00300abadaba 00300abadabb  
VSD:  
PSID: MT_1090120019
```

2. Change the GUIDs/MACs on an image file:

```
# flint -i /tmp/image.bin q  
Image type: fs2  
FW Version: 2.31.5050  
FW Release Date: 4.5.2014  
Device ID: 4099  
Description: Node Port1 Port2 Sys image  
GUIDs: f45214030001b8a0 f45214030001b8a1 f45214030001b8a2 f45214030001b8a3  
MACs: 00300abadaba 00300abadabb  
VSD:  
PSID: MT_1090120019
```

```
# flint -i /tmp/image.bin -guid 0002c9000abcdef0 -mac 02c90abcdef0 sg  
You are about to change the Guids/Macs/Uids on the device:
```

	New Values	Current Values
Node GUID:	0002c9000abcdef0	f45214030001b8a0

```

Port1 GUID: 0002c9000abcdef1 f45214030001b8a1
Port2 GUID: 0002c9000abcdef2 f45214030001b8a2
Sys.Image GUID: 0002c9000abcdef3 f45214030001b8a3
Port1 MAC: 02c90abcdef0 00300abadaba
Port2 MAC: 02c90abcdef1 00300abadabb

```

Do you want to continue ? (y/n) [n] : y

Restoring signature - OK# flint -i /tmp/image.bin q

Image type: FS2

FW Version: 2.31.5050

FW Release Date: 4.5.2014

Device ID: 4099

Description: Node Port1 Port2 Sys image

GUIDs: 0002c9000abcdef0 0002c9000abcdef1 0002c9000abcdef2 0002c9000abcdef3

MACs: 02c90abcdef0 02c90abcdef1

VSD:

PSID: MT\_1090120019

### 3.5.6.9.2 5th Generation (Group II) Devices

On 5th Generation (Group II) devices, the “sg” command can operate on both the image file and the image on the flash. When running the “sg” command on an image on the flash, -uid flag must be specified. For ConnectX-4, -guid/-mac flags can be specified. By default, 8 GUIDs will be assigned for each port starting from base, base+1 up until base+7 for port 1 and base+8 up until base+15 for port 2.

To change the step size and the number of GUIDs per port, specify `guids_num=<num> step_size=<size>` to the sg command.

1. Change GUIDs for device:

```
# flint -d /dev/mst/mt4113_pciconf0 q
```

Image type: FS3

FW Version: 10.10.3000

FW Release Date: 29.4.2014

Description: UID GuidsNumber Step

Base GUID1: 0002c903002ef500 8 1

Base GUID2: 0002c903002ef508 8 1

Base MAC1: 0002c92ef500 8 1

Base MAC2: 0002c92ef508 8 1

Image VSD:

Device VSD: VSD

PSID: MT\_1240110019

```
# flint -d /dev/mst/mt4113_pciconf0 -uid 0002c123456abcd -ocr sg
```

-W- Firmware flash cache access is enabled. Running in this mode may cause the firmware to hang.

Updating GUID section - OK

Updating ITOC section - OK

Restoring signature - OK

```
# flint -d /dev/mst/mt4113_pciconf0 q
Image type:   FS3
FW Version:   10.10.3000
FW Release Date: 29.4.2014
Description:  UID          GuidsNumber  Step
Base GUID1:  00002c123456abcd 8          1
Orig Base GUID1: 0002c903002ef500 8          1
Base GUID2:  00002c123456abd5 8          1
Orig Base GUID2: 0002c903002ef508 8          1
Base MAC1:   00002c56abcd    8          1
Orig Base MAC1: 0002c92ef500    8          1
Base MAC2:   00002c56abd5    8          1
Orig Base MAC2: 0002c92ef508    8          1
Image VSD:
Device VSD:  VSD
PSID:       MT_1240110019
```



Orig Base GUID/MAC refers to the GUIDs/MACs located in the MFG(manufacture guids) section of the flash/image.

2. Change GUIDS for device (specifying guids\_num and step\_size):

```
# flint -d /dev/mst/mt4113_pciconf0 q
Image type:   FS3
FW Version:   10.10.3000
FW Release Date: 29.4.2014
Description:  UID          GuidsNumber  Step
Base GUID1:  0002c903002ef500 8          1
Base GUID2:  0002c903002ef508 8          1
Base MAC1:   0002c92ef500    8          1
Base MAC2:   0002c92ef508    8          1
Image VSD:
Device VSD:  VSD
PSID:       MT_1240110019
```

```
# flint -d /dev/mst/mt4113_pciconf0 -uid 0000000000000001 -ocr sg guids_num=2 step_size=1
-W- Firmware flash cache access is enabled. Running in this mode may cause the firmware to hang.
```

```
Updating GUID section - OK
Updating ITOC section - OK
Restoring signature  - OK
```

```
# flint -d /dev/mst/mt4113_pciconf0 q
Image type:   FS3
FW Version:   10.10.3000
FW Release Date: 29.4.2014
```

```

Description:  UID          GuidNumber Step
Base GUID1:  0000000000000001 2      1
Orig Base GUID1: 0002c903002ef500 8      1
Base GUID2:  0000000000000003 2      1
Orig Base GUID2: 0002c903002ef508 8      1
Base MAC1:   000000000001      2      1
Orig Base MAC1: 0002c92ef500    8      1
Base MAC2:   000000000003      2      1
Orig Base MAC2: 0002c92ef508    8      1
Image VSD:
Device VSD:  VSD
PSID:       MT_1240110019

```

3. Change GUIDs for image:

```
# flint -i /tmp/connect-ib.bin q
```

```
Image type:  FS3
```

```
FW Version:  10.10.3000
```

```
FW Release Date: 29.4.2014
```

```

Description:  UID          GuidNumber Step
Base GUID1:  0002c903002ef500 8      1
Base GUID2:  0002c903002ef508 8      1
Base MAC1:   0002c92ef500      8      1
Base MAC2:   0002c92ef508      8      1
Image VSD:
Device VSD:  VSD
PSID:       MT_1240110019

```

```
# flint -i /tmp/connect-ib.bin -uid 000123456abcd sg
```

```
Updating GUID section - OK
```

```
Updating ITOC section - OK
```

```
Restoring signature - OK
```

```
# flint -i /tmp/connect-ib.bin q
```

```
Image type:  FS3
```

```
FW Version:  10.10.3000
```

```
FW Release Date: 29.4.2014
```

```

Description:  UID          GuidNumber Step
Base GUID1:  000000123456abcd 8      1
Orig Base GUID1: 0002c903002ef500 8      1
Base GUID2:  000000123456abd5 8      1
Orig Base GUID2: 0002c903002ef508 8      1
Base MAC1:   00000056abcd      8      1
Orig Base MAC1: 0002c92ef500    8      1
Base MAC2:   00000056abd5      8      1
Orig Base MAC2: 0002c92ef508    8      1
Image VSD:
Device VSD:  VSD
PSID:       MT_1240110019

```

#### 4. Change GUIDs and MACs for the ConnectX-4 device:

```
# flint -d /dev/mst/mt4115_pciconf0 -guid e41d2d0300570fc0 -mac 0000e41d2d570fc0 -ocr sg  
-W- Firmware flash cache access is enabled. Running in this mode may cause the firmware to  
hang.
```

```
Updating GUID section - OK
```

```
Updating ITOC section - OK
```

```
Restoring signature - OK
```

```
# flint -d /dev/mst/mt4115_pciconf0 q
```

```
Image type: FS3
```

```
FW Version: 12.0100.5630
```

```
FW Release Date: 23.3.2015
```

```
Description: UID          GuidsNumber
```

```
Base GUID: e41d2d0300570fc0 4
```

```
Base MAC: e41d2d570fc0 4
```

```
Image VSD:
```

```
Device VSD:
```

```
PSID: MT_2190110032
```



GUIDs and MACs can be changed separately on ConnectX-4.

### 3.5.6.9.3 Preparing a Binary Firmware Image for Pre-assembly Burning

In some cases, OEMs may prefer to pre-burn the flash before it is assembled on board. To generate an image for pre-burning for 4th generation (Group I) devices, use the `mlxburn "- striped_image"` flag. The "striped image" file layout is identical to the image layout on the flash, hence making it suitable for burning verbatim. When pre-burning, the GUIDs/MACs inside the image should be unique per device. The following are two methods to pre-burn an image. You can choose the best method suitable for your needs.

#### 3.5.6.9.3.1 Method 1: Pre-burn an Image with Blank GUIDs/MACs

In this method, the image is generated with blank GUIDs and CRCs. The GUIDs are set after the device is assembled using the `flint "sg"` command. To set GUIDs take less than 1 second when running on an image with blank GUIDs (through a PCI device).



A device that is burnt with blank GUIDs/MACs will not boot as a functional network device as long as the GUIDs/MACs are not set.

To pre-burn an image with blank GUIDs/MACs:

1. Generate a striped image with blank GUIDs.

```
# mlxburn -fw ./fw-ConnectX3-rel.mlx -./MCX354A-FCB_A2-A5.ini -wimage./fw-ConnectX3-rel.bin -striped_image  
-blank_guids  
-I- Generating image ...  
-I- Image generation completed successfully.
```

- Burn the image to a flash using an external burner.
- (Optional) After assembly, query the image on flash to verify there are no GUIDs on the device.

```
# flint -d /dev/mst/mt4099_pci_cr0 q
Image type:      FS2
FW Version:      2.31.5050
FW Release Date: 4.5.2014
Device ID:       4099
Description:     Node          Port1          Port2          Sys image
GUIDs:          ffffffff         ffffffff         ffffffff         ffffffff
MACs:           ffffffff         ffffffff         ffffffff
VSD:           n/a
PSID:           MT_1090120019

-W- GUIDs/MACs values and their CRC are not set.
```

- Set the correct GUIDs. Since the image is with blank GUIDs, this operation takes less than 1 second.

```
# flint -d /dev/mst/mt4099_pci_cr0 -guid 0x0002c9030abcdef0 -mac 0x0002c9bcdef1 sg
```

- Query the image on flash to verify that the GUIDs are set correctly.

```
sg# flint -d /dev/mst/mt4099_pci_cr0 q
Image type:      FS2
FW Version:      2.31.5050
FW Release Date: 4.5.2014
Device ID:       4099
Description:     Node          Port1          Port2          Sys image
GUIDs:          0002c9030abcdef0 0002c9030abcdef1 0002c9030abcdef2 0002c9030abcdef3
MACs:           0002c9bcdef1          0002c9bcdef2
VSD:           n/a
PSID:           MT_1090120019
```

### 3.5.6.9.3.2 Method 2: Pre-burn an Image with Specific GUIDs/MACs for Each Device

In this method, a “base” image is generated with arbitrary default GUIDs and then updated with the correct GUIDs for each device.

To pre-burn an image with specific GUIDs/MACs for each device:

- Generate the base image with arbitrary default GUIDs.

```
# mlxburn -fw./fw-ConnectX3-rel.mlx -c ./MCX354A-FCB_A2-A5.ini -wrimage ./fw-ConnectX3-rel.bin
-striped_image
```

- Per device, set the device specific GUIDs in the image.

```
flint -i ./fw-ConnectX3-rel.bin -guid 0x0002c9030abcdef0 -mac 0x0002c9bcdef1 -striped_image sg
```

- (Optional) After assembly, query the image on flash to verify there are no GUIDs on the device.

```
sg# flint -i ./fw-ConnectX3-rel.bin -striped_image q
Image type:      FS2
FW Version:      2.31.5050
FW Release Date: 4.5.2014
Device ID:       4099
Description:     Node          Port1          Port2          Sys image
GUIDs:          0002c9030abcdef0 0002c9030abcdef1 0002c9030abcdef2 0002c9030abcdef3
MACs:           0002c9bcdef1          0002c9bcdef2
VSD:           n/a
PSID:           MT_1090120019
```

Now the fw-ConnectX3-rel.bin image can be pre-burned to the flash. After the assembly, the device would be fully functional.

### 3.5.6.10 Setting the VSD

To set the vsd for the given image/device (4th generation/Group I), use the sv command with -vsd flag.

Example:

```
# flint -d /dev/mst/mt4099_pci_cr0 -vsd "MELLANOX" sv
Setting the VSD - OK
Restoring signature - OK

# flint -d /dev/mst/mt4099_pci_cr0 q
Image type:      FS2
FW Version:     2.31.5050
FW Release Date: 4.5.2014
Device ID:      4099
Description:    Node          Port1          Port2          Sys image
GUIDs:         f45214030001b8a0 f45214030001b8a1 f45214030001b8a2 f45214030001b8a3
MACs:         00300abadaba 00300abadabb
VSD:          MELLANOX
PSID:         MT_1090120019
```

### 3.5.6.11 Disabling/Enabling Access to the Hardware

The secure host feature enables ConnectX family devices to block access to its internal hardware registers. The hardware access in this mode is allowed only if a correct 64 bits key is provided.



The secure host feature requires a DOCA\_OFED driver installed on the machine.

#### 3.5.6.11.1 5th Generation Devices

Secure Host can be enabled on 5th generation devices in one of the following manners:

1. Set the key:

```
# flint -d /dev/mst/mt4115_pciconf0 set_key 18022018
-I- Secure Host was enabled successfully on the device.
```

2. Disable HW access:

```
# flint -d /dev/mst/mt4115_pciconf0 hw_access disable 18022018
-I- Secure Host was enabled successfully on the device.
```

If the key was not provided in the command line, an interactive shell will ask for it, and verifying it:

```
# flint -d /dev/mst/mt4115_pciconf0 set_key
Enter Key : *****
Verify Key : *****
-I- Secure Host was enabled successfully on the device.
```

Or

1. Disable the Secure Host (Enable HW access):

```
# flint -d /dev/mst/mt4115_pciconf0 hw_access enable 18022018
-I- The Secure Host was disabled successfully on the device.
And the same as previous, providing the key can be done in interactive shell:
# flint -d /dev/mst/mt4115_pciconf0 hw_access enable
Enter Key : *****
```

```
-I- The Secure Host was disabled successfully on the device.
```

## 3.5.6.12 Flash Operations

### 3.5.6.12.1 Reading a Word from Flash

To read one dword from Flash memory, use the following command line:

```
# flint -d <device> rw addr
```

where:

device	The device the dword is read from.
addr	The address of the word to read.

Example:

```
# flint -d /dev/mst/mt4099_pci_cr0 rw 0x20
```

### 3.5.6.12.2 Writing a dword to Flash

To write one dword to Flash memory, use the following command line:

```
# flint -d <device> ww addr data
```

where:

device	The device the dword is written to.
addr	The address of the word to write.
data	The value of the word.

Example:

```
# flint -d /dev/mst/mt4099_pci_cr0 ww 0x10008 0x5a445a44
```

### 3.5.6.12.3 Writing a dword to Flash Without Sector Erase

To write one dword to Flash memory without sector erase , use the following command line:

```
# flint -d <device> wwne addr data
```

where:

device	The device the dword is written to..
addr	The address of the word to write.

data	The value of the word.
------	------------------------

Example:

```
# flint -d /dev/mst/mt4099_pci_cr0 wme 0x10008 0x5a445a44
```

Note that the result may be dependent on the Flash type. Usually, bitwise and between the specified word and the previous Flash contents will be written to the specified address.

### 3.5.6.12.4 Erasing a Sector

To erase a sector that contains a specified address, use the following command line:

```
# flint -d <device> e addr
```

where:

device	The device the dword is erased from.
addr	The address of a word in the sector that you want to erase.

Example:

```
# flint -d /dev/mst/mtusb-1 e 0x1000
```

### 3.5.6.12.5 Querying Flash Parameters

To query flash parameters use the following command line:

```
# flint -d <device> [-ocr] hw query
```

where:

device	The device to query.
--------	----------------------

Example:

```
# flint -d /dev/mst/mt4115_pciconf0 hw query
```

### 3.5.6.13 Firmware Timestamping for Multi-Host Environment

In a multi-host environment, every host can upgrade the NIC firmware. All hosts are treated equally and there is no designated host. Hence, there can be situations where one host will try to upgrade the firmware and another will try to downgrade; which may lead to two or more unnecessary server reboots. In order to avoid such situations, the administrator can add a timestamp to the firmware they want to upgrade to. Attempts to burn a firmware image with a timestamp value that is lower than the current firmware timestamp will fail.



Firmware timestamping can be used on Connect-IB/ConnectX-4/ConnectX-4 Lx HCAs for controlling the firmware upgrade/downgrade flow.

### 3.5.6.13.1 Setting a Timestamp on Image

In order to set a timestamp on an image, run:

```
# flint -i ./fw-4115.bin timestamp set [UTC time]
```



The user can either specify a combined date and time timestamp in UTC which conforms to ISO 8601, or let the tool use the machine's time for the timestamp.

### 3.5.6.13.2 Querying a Timestamp on Image

To view the timestamp that was set on the device, run:

```
# flint -d /dev/mst/mt4115_pciconf0 timestamp query
Current timestamp : N/A. No valid timestamp found
Next timestamp   : 2015-12-21T10:58:23Z 12.15.0005
```

- “Current timestamp” represents the current running firmware timestamp. If “N/A” is visible, then the timestamp entry is invalid (example: first use of the feature or after resetting the timestamp).
- “Next timestamp” represents the next firmware that is allowed to be burnt on the HCA. Updating the “Next timestamp” requires an equal or newer timestamp to be provided.

### 3.5.6.13.3 Resetting a Timestamp on Device

To reset the timestamp that was set on the device, run:

```
# flint -d /dev/mst/mt4115_pciconf0 timestamp reset
```

Resetting the timestamp on device causes invalidation of both “Current timestamp” and “Next timestamp” fields.

### 3.5.6.13.4 Setting a Timestamp on Device

In case it is not possible to modify the firmware image, it is possible to set the timestamp directly on the device by specifying the timestamp and firmware version tied to it.

```
# flint -d /dev/mst/mt4115_pciconf0 timestamp set <UTC time> <Firmware version>
```

### 3.5.6.13.5 Querying a Timestamp on Device

To view the timestamp that was set on the device, run:

```
# flint -d /dev/mst/mt4115_pciconf0 timestamp query
```

```
Current timestamp : N/A. No valid timestamp found
Next timestamp : 2015-12-21T10:58:23Z 12.15.0005
```

- “Current timestamp” represents the current running firmware timestamp. If N/A is visible, then the timestamp entry is invalid (example: first use of the feature or after resetting the timestamp).
- “Next timestamp” represents the next firmware that is allowed to be burnt on the HCA. Updating the “Next timestamp” requires an equal or newer timestamp to be provided.

### 3.5.6.13.6 Resetting a Timestamp on Device

To reset the timestamp that were set on the device, run:

```
# flint -d /dev/mst/mt4115_pciconf0 timestamp reset
```

Resetting the timestamp on device causes invalidation of both “Current timestamp” and “Next timestamp” fields.

### 3.5.6.13.7 Important Notes

Please note the following:

- If a firmware image contains a timestamp, the burning tool will automatically attempt to set it on the device. If the operation succeeds, the firmware will be burnt.
- If a timestamp was only set on the device, the burning tool will prevent the burning of any firmware version different than the one set in the timestamp set operation.
- Lack of timestamp in both image and device will cause no checks to be performed.

### 3.5.6.14 flint/mlxburn Limitations

- When running flint/mlxburn via an MTUSB-1 device, a burn/query command may take up to 45 minutes to complete.
  - To accelerate the burn process add the flag `-no_flash_verify` to the command line which skips the flash verification step. This flag, however, does not verify if the image is burnt correctly.
- Burning an image to a ConnectX-3 adapter in Flash recovery mode may fail on some server types (that use PCIe spread spectrum). The tool may not be able to recognize the device’s PCI CONF0 or the image burn may not complete successfully.
  - To burn the device, use the MTUSB-1 connection.
- To load the newly burnt firmware image, a driver restart is required for ConnectX-3/ConnectX-3 Pro cards.
  - For fifth generation (Group II) devices, run the `mlxfwreset` tool or reboot the system.


### 3.5.6.15 Secure Host

Secure host is the general term for the capability of a device to protect itself and the subnet from malicious software through mechanisms such as blocking access of untrusted entities to


the device configuration registers, directly (through `pci_cr` or `pci_conf`) and indirectly (through MADs).

When Secure Host is enabled, host is blocked from performing firmware updates and setting non-volatile configurations.

 The supported opcodes of `secure_host` register by flint tool is setting/unsettling the lock.

 **WARNING:**

- Once a hardware access key is set, the hardware can be accessed only after the correct key is provided.
- If a key is lost, please refer to [Key Loss Recovery](#).




- The hardware access in this mode is allowed only if a correct 64 bits key is provided.
- The secure host feature for ConnectX-3/ConnectX-3 Pro HCAs requires a `MLNX_OFED` driver installed on the machine.

### 3.5.6.15.1 Using Secure Host

Secure Host feature is supported for all NVIDIA® network adapters (listed in Group 1 and group 2). For group 1 network adapters, the user is required to generate and burn a firmware image that supports the feature (see “Generating/Burning a Firmware Supporting Secure Host” below).

For Group 2 network adapters, the feature is supported on firmware version 1x.22.1002 or newer.

#### 3.5.6.15.1.1 Generating/Burning a Firmware Supporting Secure Host

 This is not applicable for ConnectX-4 devices and above. No burning of a specific firmware is needed.

1. Make sure you have INI and `mlx` files suitable for the device.
  - a. Add `cr_protection_en=true` under `[HCA]` section in the INI file.
  - b. Generate an image using `mlxburn`, for example run:

```
# mlxburn -fw ./fw-4099-rel.mlx -conf ./edited_conf.ini -wimage fw-4099.bin
```

2. Burn the image on the device using flint:

```
# flint -d /dev/mst/mt4099_pci_cr0 -i fw-4099.secure.bin b
```

3. For changes to take effect, reboot is required.

#### 3.5.6.15.1.2 Setting the Secure Host Key (for all NIC cards)

To set the key, run:

```
# flint -d <dev> set_key 22062011
Setting the HW Key - OK
Restoring signature - OK
```



A driver restart is required to activate the new key.

Accessing the device after hardware access is disabled should show the following:

```
# flint -d <dev> q
E- Cannot open <dev>: HW access is disabled on the device.
E- Run "flint -d <dev> hw_access enable" in order to enable HW access.
```

### 3.5.6.15.2 Enabling Hardware Access

Back user should run the following:

For ConnectX-4 and above devices:

run:

```
# flint -d <device> hw_access enable
Enter Key: *****
```

For ConnectX-3 and ConnectX-3 Pro devices:

1. Make sure you have INI and MLX file suitable for the device.
  - a. Remove `cr_protection_en=true` from the INI (if present)
  - b. Generate the image using `mlxburn`, for example run:

```
# mlxburn -fw ./fw-4099-rel.mlx -conf ./unsecure_host.ini -wrimage fw-4099.unsecure.bin
```

2. Burn the firmware on the device (make sure hardware access is enabled prior to burning):

```
# flint -d /dev/mst/mt4099_pci_cr0 -i fw-4099.unsecure.bin b
```

3. Execute a driver restart in order to load the unsecure firmware:

```
# service openibd restart
```

### 3.5.6.15.3 Key Loss Recovery

If a key is lost, there is no way to recover it using the tool. The only way to recover is to:

1. Connect the flash-not-present jumper on the card.
2. Reboot the machine.
3. Re-burn firmware (for Group 2 network adapters re-burn the firmware following the process in [Burning a New Device.](#))
4. Remove the flash-not-present jumper.

5. Reboot the machine
6. Re-set the hardware access key

### 3.5.6.16 Secure Firmware Update



Secure Firmware Update is supported only on ConnectX-4 onwards adapter cards.

A “Secure firmware update” is the ability of a device to verify digital signatures of new firmware binaries, in order to assure that only officially approved versions can be installed from the host, the network[1] or a Board Management Controller (BMC).

The firmware of devices with “secure firmware up date” functionality (secure FW), restricts access to specific commands and registers that can be used to modify the firmware binary image on the flash, as well as commands that can jeopardize security in general. Most notably, the commands and registers for random flash access are disabled.

Secure FW verifies new binaries before activating them, compared to legacy devices where this task is done by the update tool using direct flash access commands. In addition to signature verification, secure FW also checks that the binary is designated to the same device model, that the new firmware is also secured, and that the new FW version is not included in a forbidden versions blacklist. The firmware rejects binaries that do not match the verification criteria.

Secure FW utilizes the same ‘fail safe’ upgrade procedures, so events like power failure during update should not leave the device in an unstable state. The table below lists the impact of secure FW update on MFT tools.

Tool	Flow	Secure FW	With CS Token	Blocked Commands
flint / mlxburn	Burn FW	Working with controlled fw update	Working with controlled fw update	
	Query	Working with controlled fw update	Working with controlled fw update	
	Set GUIDs	Working with controlled fw update	Working with controlled fw update	
	Verify	Working partially (BOOT image)	Working partially (BOOT image)	
	Set DV INFO: SET MFG, SET VSD, VPD	Not supported in Secure FW	Not supported in Secure FW	MFBA
	ROM OPS: BROM, DROM	Not supported, BOOT image modification is not supported (MFBA)	Not supported, BOOT image modification is not supported (MFBA)	MFBA
	"-ocr" override cache replacement (Direct flash GW access)	Not supported in Secure FW	Not supported in Secure FW	Flash GW is blocked
	HW SET (Set flash parameters)	Flash GW is blocked	Flash GW is blocked	Flash GW is blocked
	"--no_fw_ctrl" (Legacy Flow)	Not supported in Secure FW	Not supported in Secure FW	MFBA

Tool	Flow	Secure FW	With CS Token	Blocked Commands
mlxfwmnager / mlxup	Burn FW	Working with controlled fw update	Working with controlled fw update	
mlxfwmnager	with --no_fw_ctrl	Not supported in Secure FW	Not supported in Secure FW	MFBA
mlxdump	fsdump	Blocked icmds	Working	gcif_get_ft_info, gcif_get_ft_list, gcif_get_fg, gcif_get_fg_list, gcif_get_fte, gcif_get_fte_list
	phyUc	Blocked icmds	working	gcif_phy_uc_get_array_prop_px, gcif_phy_uc_set_get_data, gcif_phy_uc_get_array_prop_EDR, gcif_phy_uc_get_array_prop_HDR
	rxdump	CR-Space is locked & Blocked icmds	working	gcif_read_rx_slice_desc, gcif_read_rx_slice_packet
	sxdump	CR-Space is locked & Blocked icmds	working	gcif_read_wq_buffer
wqdump	Dump QP contexts	Blocked icmds	working	gcif_read_context
	Dump WQs	Blocked icmds	working	gcif_read_host_memory, gcif_read_qentry, gcif_qp_get_pi_ci
	ICM	Blocked icmds	working	gcif_read_icm
	WRITE QP (Devmon)		working	gcif_write_context
mget_temp	hw_access	Read Only CR- Space	working	Read Only CR- Space
mcra	Read	working	working	working
	Write	Read Only CR- Space	working	Read Only CR- Space
mstdump	Read	working	working	working
mlxtrace / fwtrace	MEM & FIFO	Only fwtrace is supported and only in Linux	working	Read Only CR- Space
pckt_drop	uses write to CR-Space to work	Read Only CR- Space	working	Read Only CR- Space
mlxlink	working	working	working	working
mlxreg	working	working	working	working
mlxcables	working	working	working	working
mlxconfig	working	working	working	working

Tool	Flow	Secure FW	With CS Token	Blocked Commands
mlxfwreset	working	working	working	working
i2c/mlxi2c	Not relevant when not in livefish			
	With Force flag (ENV VAR)	Read Only CR- Space	working	Read Only CR- Space

### 3.5.6.16.1 Secure Firmware Implications on Burning Tools

When Secure Firmware is enabled, the flint output slightly changes due to the differences in the underlying NIC accessing methods. Some functionalities may be restricted according to the device security level.

flint query under secure mode:

```
# flint -d /dev/mst/mt4115_pciconf0 q
Image type:      FS3
FW Version:     12.19.2278
FW Release Date: 7.6.2017
Description:    UID           GuidNumber
Base GUID:     7cfe90030029205e 4
Base MAC:     00007cfe9029205e 4
Image VSD:
Device VSD:
PSID:         MT_2190110032
Security Attributes: secure-fw, dev
```



Unavailable information is reported as N/A.

### 3.5.6.17 Burning/Querying a Component

#### 3.5.6.17.1 Burning a Component Firmware Image

##### 3.5.6.17.1.1 Clock Synchronizer Images

The flint utility enables the user to burn the Clock Synchronizer firmware from a binary image.

```
# flint --device <mst device> --image <clock synchronizer image> burn
```

Where:

-d --device	mst device
-i --image	Specified component firmwared image file to use.

#### 3.5.6.17.2 Querying the Component Firmware Image

##### 3.5.6.17.2.1 Clock Synchronizer Images

To query the Clock Synchronizer image on a device, use the following command line:

```
# flint --device <mst device> --component_type sync_clock query_components
```

To query the Clock Synchronizer image in a file, use the following command line:

```
# flint --image <image file> query
```

## 3.5.7 mlxburn - Firmware Image Generator and Burner

mlxburn is a tool for firmware (FW) image burning to the Flash/EEPROM attached to an NVIDIA device. It can also query for firmware attributes (e.g., firmware version, GUIDs, etc.) and VPD info of adapter cards and switch systems.

### 3.5.7.1 mlxburn Synopsis

```
#mlxburn [-h][-v] <-dev mst-device> <-img_dir img_directory> [-force][-fwver][-vpd][-vpd_rw][-vpd_prog_rw [-query]
```

where:

-dev <mst-dev>	Burn the image using the given mst device
-fwver	When a device is given: Display current loaded firmware version. When a FW file is given (-fw flag): Display the file FW version. Note: The “-fwver” flag is not supported in Connect-IB devices.
-h	Display a short help text
-image <fw-image-file>	Do not generate image. Use the given fw image instead
-striped_image	When specified, generated image will be in striped format, and will indicate that the image is in striped format when queried.
-query	Query the HCA/Switch device for firmware details, e.g. Firmware Version, GUIDs, etc. In addition to the above flags, Mlxburn can also accept the following flags/options, which are passed to the underlying burning tool: -banks    -use_image_ps -skip_is -mac(s)    -guid(s)    -sysguid -vsd       -ndesc       -bsn -pe_i2c    -se_i2c       -is3_i2c -no        -uid(s) -log       -blank_guids -flash_params -allow_psid_change       -no_flash_verify -use_image_rom           -override_cache_replacement -use_image_guids See the flint tool documentation for HCA/4th gen switches/Bridge burning options.
-v	Print version info and exit
-V <INFORM WARNING DEBUG>	Set verbosity level. Default is WARNING
-vpd 1,2	Display the read only section of the PCI VPD (Vital Product Data) of the given device
-vpd_rw1,2	<b>(on Linux only):</b> Display also the read/write section of the PCI VPD of the given device.

Note 1. The VPD query may not be enabled on certain board types. Also, VPD operations are available only for devices with a PCI interface.

Note 2. Running multiple VPD access commands in parallel on the same device, by mlxburn or any other VPD access tool, may cause the commands to fail. VPD access commands should be run one at a time.

### 3.5.7.1.1 Connect-IB, Switch-IB, Switch-IB 2, NVIDIA Spectrum, ConnectX-4, and ConnectX-4 Lx Initial Burning Options

The following options are relevant when generating an image for initial burning. The image contains the VPD and the GUIDs that are in a read-only area on flash.

```
[ -vpd_r_file <vpd_r_file>] [ -base_guid <GUID>]
```

where:

-vpd_r_file <vpd_r_file>	Embed the given VPD Read-Only section in the generated image. The vpd_r_file should contain the vpd read only section and the first dword of the vpd writeable section. The file is in binary format, and its size must be a multiple of 4 bytes. Please refer to PCI base spec for VPD structure info.
-base_guid <GUID>	Set the given GUID as the image base GUID. The base GUID is used to derive GUIDs and MACs for the HCA ports. It is assumed that 16 GUIDs (base_guid to base_guid + 15) are reserved for the card. Note: On ConnectX-4/ConnectX-4 Lx/ConnectX-5/ConnectX-5 Ex, only GUIDs will be derived according to the HCA configuration.
-base_mac <MAC>	Set the given MAC as the image base MAC. The base MAC is used to derive MACs for the HCA ports according to the device configuration (ConnectX-4/ConnectX-4 Lx/ConnectX-5/ConnectX-5 Ex).
-vsd <string>	Write this string, of up to 208 characters, to VSD section.

### 3.5.7.1.2 Additional mlxburn Options

The following is a list of additional options. Please see [mlxfwmanager - Firmware Update and Query Tool](#) for the HCA options.

```
-banks -use_image_ps -skip_is -mac(s) -guid(s) -sysguid -ndesc -bsn -use_image_guids -pe_i2c -se_i2c  
-is3_i2c -no -qq -uid(s) -log -blank_guids -flash_params -allow_psid_change -no_flash_verify  
-use_image_rom  
-override_cache_replacement -ocr -ignore_dev_data -use_dev_rom -no_fw_ctrl
```



The arguments of the -guids and -macs flags must be provided within quotation marks; for example, mlxburn -macs "0002c900001 0002c900002".

## 3.5.7.2 Examples of mlxburn Usage

### 3.5.7.2.1 Query for firmware attributes (e.g., firmware version, GUIDs, etc.):

```
# mlxburn -d /dev/mst/mt4129_pciconf0 query
-I- Image type:      FS4
-I- FW Version:      28.45.0376
-I- FW Release Date: 15.4.2025
-I- Product Version: 28.45.0376
-I- Rom Info:        type=UEFI version=14.38.14 cpu=AMD64,AARCH64
                    type=FXE version=3.7.500 cpu=AMD64
-I- Description:    UID                      GuidNumber
-I- Base GUID:      N/A                      8
-I- Base MAC:       N/A                      8
-I- Image VSD:      N/A
-I- Device VSD:    N/A
-I- PSID:           MT_00000000851
-I- Security Attributes: secure-fw
```

### 3.5.7.2.2 VPD read:

```
# mlxburn -d /dev/mst/mt4123_pciconf0 -vpd_rw

VPD-KEYWORD  DESCRIPTION          VALUE
-----
Read Only Section:

PN           Part Number          MCX653106A-HDAT
EC           Revision             A1
V2           N/A                  MCX653106A-HDAT
SN           Serial Number        MT1836X04719
V3           N/A                  0
VA           N/A                  MLX:MN=MLNX:CSKU=V2:UUID=V3:PCI=V0:MODL=CX653106A
V0           Misc Info            PCIeGen4 x16
VU           N/A                  MT1836X04719MLNXS0D0F0
RV           Checksum Complement  0xc0
IDTAG       Board Id             CX653106A - ConnectX-6 QSFP56

Read Write Section:
```

```
# mlxburn vpd -d /dev/mst/mt4123_pciconf0

VPD-KEYWORD  DESCRIPTION          VALUE
-----
Read Only Section:

PN           Part Number          MCX653106A-HDAT
EC           Revision             A1
V2           N/A                  MCX653106A-HDAT
SN           Serial Number        MT1836X04719
V3           N/A                  0
VA           N/A                  MLX:MN=MLNX:CSKU=V2:UUID=V3:PCI=V0:MODL=CX653106A
V0           Misc Info            PCIeGen4 x16
VU           N/A                  MT1836X04719MLNXS0D0F0
RV           Checksum Complement  0xc0
IDTAG       Board Id             CX653106A - ConnectX-6 QSFP56
```

### 3.5.7.2.3 Burning bin file using mlxburn:

```
# mlxburn -d /dev/mst/mt4131_pciconf0 -i cx8.bin -y
```

### 3.5.7.2.4 Detecting and burning the suitable bin file from a dir of several bin files:

```
# mlxburn -d /dev/mst/mt4131_pciconf0 -img_dir /tmp/s -y
```

### 3.5.7.2.5 To Query fw version of the given device:

```
# mlxburn -d /dev/mst/mt4115_pciconf0 -fwver  
-I- FW Version: 12.28.2006
```

### 3.5.7.2.6 Exit Return Values

The following exit values are returned:

- 0 - successful completion
- >0 - an error occurred

## 3.5.8 mlxfwreset - Loading Firmware on 5th Generation Devices Tool

The mlxfwreset tool enables the user to load updated firmware on a NIC/switch without having to reboot the machine. The mlxfwreset tool supports 5<sup>th</sup> Generation (Group II) HCAs and allows a smooth firmware upgrade.



This feature is supported if either reset type 3 (ARM RESET), which is the default starting from this version, or 4 (ARM SHUT DOWN), and reset level 1 (IMMEDIATE RESET) are supported.

### 3.5.8.1 Tool Requirements

- Access to device through PCI configuration cycles
- Supported OSs: FreeBSD, Linux, Windows

### 3.5.8.2 Query Command

```
mlxfwreset -d <device> query
```

### 3.5.8.3 Reset Command

```
mlxfwreset -d <device> reset-[y] [--level <0,3,4>] [--type <0..2>] [--sync <0,1,2>] [-s] [-m] [--method <0,1>]  
[status <--json>]
```

### 3.5.8.4 mlxfwreset Synopsis

Where:

q query	Query supported reset level/type/sync.	N/A for switch devices.
r reset	Execute reset.	-
reset_fsm_register	Reset the multi-host synchronization register.	-

-d --device <device>	Device to work with.	-
-l --level <0,1,3,4>	Run reset with the specified reset-level.	N/A for switch devices.
-t --type <0..4>	Run reset with the specified reset-type.	N/A for switch devices.
--sync <0,1,2>	Run reset with the specified reset-sync.	N/A for switch devices.
--method <0,1>	Run reset with the specified request method (relevant only for reset-level 3)	-
-y --yes	Answer “yes” on prompt.	-
-m --mst_flags MST_FLAGS	Provide mst flags to be used when invoking mst restart step. For example: --mst_flags="-with_fpga".	<ul style="list-style-type: none"> <li>• This option is supported in Linux OSes only.</li> <li>• N/A for switch devices.</li> </ul>
-s --skip_driver	Skip driver start/stop stage (driver must be stopped manually).	N/A for switch devices.
-v --version	Print tool version.	-
-h --help	Show help message and exit.	-
status <--json>	Determines the required reset type after firmware or configuration changes, and presents the result in a clear and unified format.	-

### 3.5.8.5 Reset Levels and Types

Reset levels and types depend on the extent of the changes introduced when updating the device's firmware. The tool will display the supported reset levels and types that will ensure the loading of the new firmware. Those reset levels and types are:

- Reset-levels:
  - 0: Driver, PCI link, network link will remain up ("live-Patch")
  - 1: Only ARM side will not remain up ("Immediate reset")
  - 3: Driver restart and PCI reset
  - 4: Warm Reboot
- Reset-types (relevant only for reset-levels 1, 3, 4):
  - 0: Full chip reset
  - 1: Phy-less reset ("port-alive" - network link will remain up) - Not Supported
  - 2: NIC only reset (for SoC devices)
  - 3: ARM only reset
  - 4: ARM OS shut down



The exact reset-level and reset-types needed to load new the firmware may differ as they depend on the difference between the running firmware and the firmware we are upgrading to.

### 3.5.8.6 Reset Sync

- Reset-sync indicates who is responsible for the synchronization mechanism between the hosts on the Multi-Host setup (relevant only for reset-level 3):
  - 0: Tool is the owner
  - 1: Driver is the owner
  - 2: FW is the owner

### 3.5.8.7 Reset Method

- Reset request method (relevant only for reset-level 3):
  - 0: Link Disable method
  - 1: Hot reset (SBR)

### 3.5.8.8 PCIe Switch Reset via Hot Reset

- We provide a mechanism to reset a PCIe switch using a hot reset, eliminating the need to reboot the entire setup.  
This is achieved using sync 2 and method 1 arguments, which together define the hot reset flow.  
This feature currently supports ConnectX-7 and BlueField devices.  
To trigger the reset, users can either run the tool with: --sync 2 --method 1 arguments or simply run it without any parameters and the tool will apply the default values automatically.
- Important:  
Before executing the reset, the user should stop any driver bound or associated with devices downstream to the PCIe Switch. The tool may also prompt the user to unload specific drivers or terminate some processes that it is aware of, but it is not necessarily aware of all the bounded drivers.  
It is the user responsibility to ensure these steps are completed to guarantee a successful reset.

### 3.5.8.9 Driver Detection Assistance

- When performing a hot reset on a PCIe switch, if drivers are still bound to devices downstream of the switch, the tool exits with an error and displays the identified drivers that must be unbound.  
For each detected driver, the corresponding DBDF (Domain:Bus:Device.Function) of the bound device is also shown.
- This information is provided as a recommendation to assist the user in identifying affected devices and drivers.  
Final responsibility and discretion remain with the user, as the tool may not detect all possible bindings or dependencies.

#### Ignore Options

The tool supports `--ignore_list` / `--ignore_file` , which allow users to bypass specific detected drivers and continue the hot-reset flow without explicitly unbinding them.

- These options are intended for advanced use cases only, for example when the user knows that certain drivers are reset-resilient and safe to ignore

Option	Description
<code>--ignore_list</code> " <code>&lt;driver1&gt;</code> , <code>&lt;driver2&gt;</code> ,..."	<ul style="list-style-type: none"> <li>• Specifies a comma-separated list of driver names to ignore during driver detection.</li> <li>• Drivers listed here will not block the reset flow, even if they are bound to devices downstream of the PCIe switch.</li> <li>• This allows the reset to proceed without explicitly unbinding those drivers.</li> </ul>
<code>--ignore_file &lt;path&gt;</code>	<ul style="list-style-type: none"> <li>• Provides a file containing driver names to ignore (one per line).</li> <li>• Useful for maintaining a persistent or shared ignore configuration across systems.</li> <li>• If <code>--ignore_list</code> or <code>--ignore_file</code> is provided, drivers appearing in those lists are skipped and the reset flow continues.</li> </ul>



Please note that ignoring drives, might cause unexpected behavior:

- Using `ignore_list` / `ignore_file` may allow the reset to proceed while some drivers remain bound to devices downstream of the PCIe switch
- If an ignored driver is not reset-resilient, continuing the flow may result in undefined behavior, device instability, or incomplete recovery after reset

Therefore, these options should be used only when the user fully understands the implications and confirms that the ignored drivers are safe across reset.

Example:

```
mlxfwreset -d <device> --level 3 --sync 2 --method 1 r
The reset level for device, <device> is:
3: Driver restart and PCI reset
Please be aware that resetting the Bluefield may take several minutes. Exiting the process in the middle of the
waiting period will not halt the reset.
The ARM side will shut down.
=====
ERROR: The following drivers are currently bound to PCI devices on the switch:
=====
PCI          | Driver
-----|-----
0000:02:00.0 | pcieport

Please unbind the drivers or add them to the ignore file/list.
* Driver that is resilient to device reset can be added to ignore list, for example:
  --ignore_list "pcieport"

Exit on error..
```

### 3.5.8.10 mlxfwreset for Switch Devices

Running `mlxfwreset` on a switch device is done in the same form as running `mlxfwreset` on a NIC. The only difference is that there are no level, types or sync parameters.

### 3.5.8.11 mlxfwreset for Multi-Host NICs

Running mlxfwreset on a Multi-Host setup enables you to choose one of the supported reset-sync. To check which reset-sync are supported on your device, run the query command prior to the reset command.

- When running reset with reset-sync "0" ("tool is the owner"), the tool must be ran simultaneously on all the hosts. Note that a time-out of 3 minutes is expected for all the hosts until they join the reset process.
- When running reset with reset-sync "1" ("driver is the owner"), the tool must be ran on a single host.



reset-sync "1" ("driver is the owner") is supported only when the firmware and all the drivers on all the hosts support it.

### 3.5.8.12 mlxfwreset for SmartNICs (Bluefield)

After upgrading the FW , you can run mlxfwreset with level 3 and sync 1.

If you use Level 4 standalone (without shutting down the ARM), you need to execute mlxfwreset on both the integrated ARM and the host.

To update the FW using Level 4, the ARM must be shut down first.



Depending on the reset-type, the integrated Arm might get reset. In case Arm is reset, the mlxfwreset on the host will wait for the Arm to complete the reboot process.

### 3.5.8.13 mlxfwreset after Changing Configurations using mlxconfig

Some configuration changes require PCI rescan by the user, in this case, mlxfwreset will print the following warning message:

```
"-W- PCI rescan is required after device reset."
```

### 3.5.8.14 Examples of mlxfwreset Usage

To query the default and supported options to reset a device, run:

```
# mlxfwreset -d /dev/mst/mt4113_pciconf0 query
```

Example:

```
Reset-levels:
0: Driver, PCI link, network link will remain up ("live-Patch") -Not Supported
1: Only ARM side will not remain up ("Immediate reset").         -Not Supported
3: Driver restart and PCI reset                                  -Supported      (default)
4: Warm Reboot                                                  -Supported

Reset-types (relevant only for reset-levels 1,3,4):
0: Full chip reset                                             -Supported      (default)
```

```

1: Phy-less reset ("port-alive" - network link will remain up) -Not Supported
2: NIC only reset (for SoC devices) -Not Supported
3: ARM only reset -Not Supported
4: ARM OS shut down -Not Supported

Reset-sync (relevant only for reset-level 3):
0: Tool is the owner -Supported (default)
1: Driver is the owner -Supported
In the new mlxfwreset for BF2 and BF3, sync1 is the default. Sync0 is not supported.

```

To reset the device in order to load the new firmware, run:

```
# mlxfwreset -d /dev/mst/mt4113_pciconf0 reset
```

Or:

```
mlxfwreset -d /dev/mst/mt53100_pciconf0 reset -y
```

Example

```

3: Driver restart and PCI reset
Continue with reset?[y/N] y
-I- Stopping Driver -Done
-I- Sending Reset Command To Fw -Done
-I- Resetting PCI -Done
-I- Starting Driver -Done
-I- Restarting MST -Done
-I- FW was loaded successfully.

```

To reset a device with a specific reset level to load new firmware, run:

```
# mlxfwreset -d /dev/mst/mt4113_pciconf0 -l 4 reset
```


Example

```

Requested reset level for device, /dev/mst/mt4113_pciconf0:
4: Warm Reboot
Continue with reset?[y/N] y
-I- Sending reboot command to machine

```

### 3.5.8.15 mlxfwreset Status

 Beta Feature: This feature is under active development and may be unstable. We recommend using it with caution.

mlxfwreset Status checks if a reset is required after a firmware update or configuration change. The tool informs the user which type of reset is needed (Level 3, warm reboot, or power cycle). The result is shown in a simple and clear format for easy understanding.

### 3.5.8.16 mlxfwreset Limitations

The following are the limitations of mlxfwreset:

- Executing a reset-level or reset-type or reset-sync that is not supported (as shown in the query command) will yield an error
- When burning firmware with flint/mlxburn at the end of the burn the following message is displayed:

-I- To load new FW run mlxfwreset or reboot machine

If this message is not displayed, a reboot is required to load a new firmware

- On an old firmware, after a successful reset execution, attempting to query or reset again will yield an error as the load new firmware command was already sent to the firmware
- In case mlxfwreset exits with error after the “Stopping driver” step and before the “Starting driver” step, the driver will remain down. The user should start the driver manually in this case
- mlxfwreset for switch devices does not work over InfiniBand or remote connection

## 3.5.9 mlxphyburn - Burning Tool for Externally Managed PHY

Mlxphyburn tool allows the user to burn firmware of an externally managed PHY. The tool burns and verifies a pre-compiled binary PHY firmware image on the PHY’s flash. It is supported only on Linux.

### 3.5.9.1 Tool Requirements

- ConnectX-3/ConnectX-3 Pro with an externally managed PHY
- A device that has access to the PHY flash module
- MLNX\_OFED driver (if installed) must be down
- Access to the device through the PCI interface (pciconf/pci\_cr)
- Firmware version that supports access to an externally managed PHY
  - Version 2\_33\_5000 and above

### 3.5.9.2 mlxphyburn Synopsis

```
# mlxphyburn [-d <device>] [-i Phy_fw_image] b[urn]|q[uey]
```

where:

-d --dev <device>	Device which has access to the PHY.
-i --img <PHY_fw_image>	PHY firmware image.
-v --version	Display version info.
-h --help	Display help message.
b[urn]	Burn given PHY image on the device's PHY.
q[uey]	Query PHY FW on device.



If no device is specified, mlxphyburn will attempt to burn the PHY firmware image on all mst devices on the machine.

### 3.5.9.3 Examples of mlxphyburn Usage

Burn Example


```
# mlxphyburn -d /dev/mst/mt4099_pciconf0 -i Firmware_1.37.10_N32722.cld burn
```

```
-I- attempting to burn PHY Fw on device: /dev/mst/mt4099_pciconf0
-I- Burning...(Process might take a few minutes)
-I- Device burned and verified.
```

## Query Example

```
# mlxphyburn -d /dev/mst/mt4099_pciconf0 q
-I- Querying device: /dev/mst/mt4099_pciconf0
Flash Type : Atmel AT25DF041A
FW version : 1.37
Image ID : 1.37.10 InterfaceMasters N32722 Apr 14, 2014 12:21:00
Image ROM ID : 0
```

## 3.5.10 mlx\_fpga - Burning and Debugging Tool for NVIDIA Devices with FPGA

 The mlx\_fpga utility will be deprecated as of MFT v4.18.0.

mlx\_fpga tool allows the user to burn and update a new FPGA image on NVIDIA Innova™ adapter cards. For instructions on how to burn, please refer to [Burning the FPGA's Flash Device using the mlx\\_fpga Burning Tool](#).

The tool also enables the user to read/write individual registers in the FPGA configuration space.

### 3.5.10.1 Tool Requirements

- An Innova IPsec 4 Lx EN / Innova Flex 4 Lx EN adapter card with an FPGA device
- For Innova IPsec 4 Lx EN: Load the mlx5\_fpga\_tools module
- For Innova Flex 4 Lx EN: Load the mlx\_accel\_tools module

Note: The module is included in the Innova driver which is supplied for this product line only, and available through the [Support](#).

- Start mst service with the fpga lookup flag (mst start --with\_fpga)

### 3.5.10.2 mlx\_fpga Synopsis

where:

-d --device <device>	FPGA mst device interface
-v --version	Display version info
-h --help	Display help message
-f --force	Non-interactive mode, answer yes to all questions
r  read <addr>	Read debug register in address
w  write <addr> <data>	Write data to debug register in address
b  burn <image file/s>	Burn the image on the flash
l  load	Load image from flash (--factory - load image from factory flash)
clear_semaphore	Unlock flash controller semaphore
reset	Reset flash controller (--gw) or FPGA (--fpga)

q  query	Query general FPGA information
set_fw_mgmt <disable enable>	Disable/Enable FPGA management by the Firmware

### 3.5.10.3 Examples of mlx\_fpga Usage

#### 3.5.10.3.1 Adding FPGA mst Device Interface

For Innova IPsec 4 Lx EN: Load the mlx5\_fpga\_tools module.

```
# modprobe mlx5_fpga_tools
# mst start --with_fpga
# mst status
MST modules:
-----
MST PCI module is not loaded
MST PCI configuration module is not loaded
MST devices:
-----
No MST devices were found nor MST modules were loaded.
You may need to run 'mst start' to load MST modules.
FPGA devices:
-----
/dev/mst/mt4117_pciconf0_fpga_i2c
/dev/mst/mt4117_pciconf1_fpga_rdma1
```

**Note:** In the last line, it is recommended to use the RDMA device as it is faster. I2C is used for recovery purposes when RDMA is not functional.

For Innova Flex 4 Lx EN: Load the mlx\_accel\_tools module.

```
# modprobe mlx_accel_tools
# mst start --with_fpga
# mst status
MST modules:
-----
MST PCI module is not loaded
MST PCI configuration module is not loaded
MST devices:
-----
No MST devices were found nor MST modules were loaded.
You may need to run 'mst start' to load MST modules.
FPGA devices:
-----
/dev/mst/mt4117_pciconf0_fpga_i2c
/dev/mst/mt4117_pciconf1_fpga_rdma
```

**Note:** In the last line, it is recommended to use the RDMA device as it is faster. I2C is used for recovery purposes when RDMA is not functional.

For recovery only, where modules are broken or missing.

```
# mst start --with_fpga_fw_access
Starting MST (Mellanox Software Tools) driver set
Loading MST PCI module - Success
Loading MST PCI configuration module - Success
Create devices
Unloading MST PCI module (unused) - Success
# mst status
MST modules:
-----
MST PCI module is not loaded
MST PCI configuration module loaded
MST devices:
-----
/dev/mst/mt4117_pciconf0          - PCI configuration cycles access.
                                domain:bus:dev.fn=0000:01:00.0 addr.reg=88 data.reg=92
                                Chip revision is: 00
FPGA devices:
-----
/dev/mst/mt4117_pciconf0_fpga
```



The `mlx5_fpga_tools` and the `mlx_accel_tools` modules must be down before trying to recover the FPGA mst Device Interface.

### 3.5.10.3.2 Burning the FPGA’s Flash Device using the `mlx_fpga` Burning Tool

`mlx_fpga` tool burns a `.bin` file onto the FPGA flash device.

The Innova Flex `.bin` file must be generated according to the instructions listed in the *Innova Flex Adapter Card User Manual*.



It is recommended to burn the FPGA device using an RDMA device as it faster and it shortens the burning time.

1. Burn the image.

```
# mlx_fpga -d <device> burn image.bin
```

2. Load the FPGA image from flash according to “Loading the Tool” below or power cycle the machine for change to take effect.

### 3.5.10.3.3 Loading the Tool

Load an FPGA image from user configurable flash:

```
# mlx_fpga -d <device> l/load <optional: load options>
```

where `<optional: load options>` is:

<code>--factory</code>	Load FPGA image from factory flash
<code>--user</code>	Load FPGA image from user flash [Default option]

### 3.5.10.3.4 Debugging the Tool

Reading One Debug Register:

```
# mlx_fpga -d <device> read 0x0
```

Writing One Debug Register:

```
# mlx_fpga -d <device> write 0x0 0x0
```

### 3.5.10.3.5 Updating the FPGA Image

In order to verify the new image burned to the FPGA, the user can use `mlx_fpga` tool and read the following registers:

Name	Address	Range	Default	RW	Description
image_version	0x900000	31:00:00	0x0	RO	Version of the image increased on every synthesis.
image_date	0x900004	31:00:00	0x0	RO	Image date of creation. The hex number is actually the decimal value, i.e. 0x12011995 means 12/01/ 1995 in DD/MM/YY: bits [31:24] = day of creation bits [23:16] = month of creation bits [15:0] = year of creation
image_time	0x900008	31:00:00	0x0	RO	Image time of creation. The hex number is actually the decimal value, i.e. 0x00015324 means 01:53:24 in HH:MM:SS: bits [23:16] = hour (00..23) bits [15:8] = minutes (00..59) bits [7:0] = seconds (00..59)



Innova Flex users should refer to the Innova User Manual for more information.

### 3.5.11 cpldupdate - Tool for Programming On-Board CPLDs on NVIDIA Devices

cpldupdate tool allows the user to program on-board CPLDs on supporting NVIDIA products. The on-board CPLDs, as well as the core engine for programming them, are provided by Lattice Semiconductors.

cpldupdate accepts VME files as input and programs the appropriate CPLD on the device. The CPLD ID is embedded in the VME file. The user need not be aware of the board composition.

A VME file is the data file for use with the ispVM Embedded programming software. The file is essentially a binary version of an SVF file. SVF commands and data are stored in a binary format (with optional compression) for efficient storage and processing by embedded microprocessors. The ispVM Embedded software, provided as source code in C, interprets the VME data to manipulate the JTAG signals of connected target devices.

cpldupdate tool was provided by Lattice Semiconductors and was modified to fit NVIDIA needs.

For NVIDIA Quantum and Spectrum-2 and newer switch families, the CPLD update can be performed via GPIO instead using the firmware interface. By default, cpldupdate will use GPIO for Quantum and Spectrum-2 switches (if `--dev` option is specified), However, the user can use the `--fw` option to run cpldupdate via the firmware. Alternatively, the user can dismiss the `--dev` flag and use the `--gpio`.

For NVIDIA Spectrum-1 switches (SN2201), the CPLD update must be performed via GPIO. The user must use the `--uncustomized` option in addition to the `--gpio` option in this case.

#### 3.5.11.1 Tool Requirements

- CPLD bearing board

### 3.5.11.2 cpldupdate Synopsis

```
# cpldupdate [option] vme_file [vme_file]
```

where:

--dev <device>	<device> (e.g. lid-N, /dev/mst/mt4115_pciconf0).
--gpio	Update CPLD using GPIO.
--fw	Update CPLD using FW.
--idcode <num_of_bits>	Run IDCODE command and exits.
--print-progress	Print progress indication.
--uncustomized	Update CPLD via GPIO on NVIDIA Spectrum-1 (SN2201) switches.
--cpld_chain	Provides an option to select which chain to burn, possible chains are CPLD, FPGA and full chain.

### 3.5.11.3 Burn Example

```
# cpldupdate --dev /dev/mst/mt52000_pciconf0 ./cpld000039_v0100.vme
Lattice Semiconductor Corp.
ispVME(tm) V12.2 Copyright 1998-2012.
Customized for Mellanox products.
Processing virtual machine file (./cpld000039_v0100.vme).....
+++++++
| PASS! |
+++++++
```

## 3.5.12 mlxprivhost - NIC Configuration by the Host Restriction Tool (Zero Trust Mode)

mlxprivhost enables the user to restrict the hosts from managing the device in case the BlueField DPU is in a Zero Trust environment, and the host cannot be considered “trusted”.



mlxprivhost is supported in Linux only.



mlxprivhost is not supported in ESXi 7.0.



This utility is supported in BlueField devices only.

### 3.5.12.1 mlxprivhost Synopsis

```
mlxprivhost [OPTIONS] <command> [parameters...]
```

- Restrict configuration takes effect immediately, but disabling/enabling RShim requires power cycle

- A zero-trust (restricted) host will not be able to perform operations that can compromise the DPU, such as:
  - Port ownership - the host cannot assign itself as port owner
  - Hardware counters - the host does not have access to hardware counters
  - Tracer functionality is blocked
  - RShim interface is blocked
  - FW flash is restricted
- For Multi-host systems, the tool is compatible with firmware versions starting from xx.31.10xx and later

where:

-h, --help	Shows this help message and exit
-v, --version	Shows program's version number and exit
-d <dev>, --device <dev>	Device to work with.
--disable_rshim	When TRUE, the host does not have an RSHIM function to access the embedded CPU registers (power cycle is required to apply changes)
--disable_tracer	When TRUE, the host will not be allowed to own the Tracer (requires FW reset to be applied)
--disable_counter_r d	When TRUE, the host will not be allowed to read Physical port counters (requires FW reset to be applied)
--disable_port_owne r	When TRUE, the host will not be allowed to be Port Owner (requires FW reset to be applied)
r,restrict	Set all external hosts as zero-trust (restricted) except of the one that called the command
p,privilege	Set all external hosts privileged except the one that called the command
q,query	From external HOST: query the status of the host From Embedded ARM CPU: query the status of all external hosts.
-f, --full	Run with query command for high verbosity level - valid from embedded ARM CPU only.

Example of mlxprivhost:

- Enabling Zero-Trust host (Full Host Restriction - Embedded ARM CPU Only):

```
mlxprivhost -d /dev/mst/mt41682_pciconf0 r --disable_rshim --disable_tracer --disable_counter_rd --
disable_port_owner
```

- Disabling Zero-Trust host restriction (Embedded ARM CPU Only):

```
mlxprivhost -d /dev/mst/mt41682_pciconf0 p
```

- Query the status of the host\hosts (the full flag valid for embedded ARM CPU Only):

```
mlxprivhost -d /dev/mst/mt41682_pciconf0 q --full
Host configurations
-----
host index      : 0          1          2          3
level           : PRIVILEGED PRIVILEGED PRIVILEGED PRIVILEGED
```

```

Port functions status:
-----
disable_rshim      : FALSE      FALSE      FALSE      FALSE
disable_tracer     : FALSE      FALSE      FALSE      FALSE
disable_port_owner : FALSE      FALSE      FALSE      FALSE
disable_counter_rd : FALSE      FALSE      FALSE      FALSE

```

## 3.5.13 mlxtokengenerator - Token Creation Tool

The mlxtokengenerator tool allows the user to create Token XML files automatically. The Token XML file will be filled with all the required data. The generated Token XML file is ready to be used for sign and installation commands.

### 3.5.13.1 mlxtokengenerator Synopsis

```
# mlxtokengenerator [Options] <commands>
```

where:

-d --dev <device>	Performs operation for a specified mst device
-t --device_type <Switch/HCA/LinkX>	Mst device type
-k --token_type <CS/ DBG/CRCS/CRDT/RMCS/ RMDT>	Token type
-o --output_file <Path>	Path to output Token XML file
-f --debug_fw <Path>	Path to debug fw file
-n --nested_token	Get nested token for Retimer
-e --nested_debug_fw	Path to debug fw file for Retimer nested token
-p --tokens_dir <Path>	Path to a directory of tokens for aggregation
-v --version	Displays version info
-h --help	Displays help message
-s --i2c_secondary <i2c_secondary>	I2C secondary address
--b --blob	Path to challenge blob file (relevant for CRCS/CRDT token types)
--debug_fw_dir <path>	Path to a directory with debug firmware files
--output_zip <path>	Path to zip output file
--output_dir	Path to output directory

Examples:

To create a CS token:

```
# mlxtokengenerator -d /dev/mst/mt4123_pciconf0 -k CS -t HCA -o /tmp/cs_token.xml generate_token
```

To create a DBG token:

```
# mlxtokengenerator -d /dev/mst/mt4123_pciconf0 -k DBG -t HCA -f /tmp/dbg_fw.bin -o /tmp/dbg_token.xml
generate_token
```

To create a CRDT token with nested Retimer:

```
# mlxtokengenerator -d mt54004_pciconf0_cable_1 -k CRDT -t LinkX -debug_fw /tmp/dbg_fw.bin --nested_debug_fw /tmp/
retimer_dbg_fw.bin --nested_token -o /tmp/dbg_token.xml generate_token
```

To create challenge based tokens with blob option:

```
# mlxtokengenerator -b <blob_file> -k CRCS -t HCA -o <out.xml> generate_token
```

### 3.5.13.1.1 Token Generation Process

The token generation process consists of three main stages:

1. Generating a token XML.
2. Signing the token on a dedicated signing server.
3. Applying the signed token to the device.

The mlxtokengenerator tool will streamline this flow by enabling batch token generation either into a directory or a zip file. It operates on all applicable MST devices discoverable from the host, while filtering by device type (HCA or Switch only) and token type (CRCS or CRDT only). If the specified output directory already exists, the generated files are simply added to it.

Generate in a directory:

```
mlxtokengenerator -t <Switch/HCA> -k <CRCS/CRDT> -o <directory path> auto_generate_tokens
```

Generate in a zip file:

```
mlxtokengenerator -t <Switch/HCA> -k <CRCS/CRDT> --zip_output -o <zip path> auto_generate_tokens
```

Generate CRDT tokens:

```
mlxtokengenerator -t <Switch/HCA> -k CRDT -o <directory path> --debug_fw_dir <path> auto_generate_tokens
```

Once tokens are signed and converted to binary, the mlxconfig tool supports automatically applying them from a given directory or a zip file, attempting to match and apply the appropriate token to all discoverable MST devices on the host.

Apply tokens automatically:

```
mlxconfig -t <Switch/HCA> auto_apply <zip/directory>
```

## 3.5.14 mlxdpa - DPA Applications Sign Tool

The mlxdpa tool allows the user to sign DPA applications, which are given to the tool as part of a Host ELF file.

It also supports creation, signing, and removal of single applications.

In addition, mlxdpa allows the user to add or remove certificates from the DPA device – this is done by creating certificate containers and signing them.

The tool generates the signatures using a provided private key PEM file.

Tool Requirements:

- Supported operating systems: Linux
- Supported platforms: x86-64, arm64

## mlxdpa Synopsis

### Sign Host ELF using PEM file

```
# mlxdpa --host_elf <ELF file> --cert_chain <certificate chain> --private_key <key .pem file> --output_file <output file path> sign_dpa_apps
```

### Create upload container for single app

```
mlxdpa -s /tmp/singleApp.elf --life_cycle_priority OEM -m /tmp/appmetadata.yaml --manifest /tmp/manifest.bin -o /tmp/single_app.bin create_single_dpa_app
```

### Sign upload container for single app using PEM file

```
mlxdpa -s /tmp/single_app.bin -c /tmp/chain.cert -p /tmp/p_key.pem [--cert_chain_count 5] --life_cycle_priority OEM -o /tmp/signed_single_app.bin sign_single_dpa_app
```

### Query manifest from single elf

```
mlxdpa -s /tmp/singleApp.elf -o /tmp/manifest.bin query_manifest
```

### Create Dpa app removal container

```
mlxdpa --dpa_app_uuid 7c0ab0fc-082e-11ee-bd9d-e43d1a1f06ae -o /tmp/dpa_app_removal_container.bin --life_cycle_priority OEM create_dpa_app_removal
```

### Sign Dpa app removal container

```
mlxdpa --dpa_app_removal_container /tmp/dpa_app_removal_container.bin --keypair_uuid 3c8f46b2-159f-11ee-9ac4-e43d1a1f06ae -p /tmp/p_key.pem -o /tmp/signed_dpa_app_removal_container.bin --life_cycle_priority OEM sign_dpa_app_removal
```

Where:

-e --host_elf	Path to the Host ELF file containing DPA applications
-c --cert_chain	Path to a certificate chain file to embed in the crypto data
-p --private_key	Path to a private key PEM file for signature generation
-o --output_file	Path to output signed Host ELF
-h --help	Show help message
-v --version	Show tool version
--cert_chain_count <Hex number>	Number of certificates in the provided certificate chain
--dpa_app_removal_container <Path>	Path to a dpa app removal container to sign

<code>--manifest &lt;Manifest&gt;</code>	Path to the manifest file
<code>-m --app_metadata &lt;App Metadata&gt;</code>	Path to the app metadata yaml file
<code>-s --single_app &lt;Single App&gt;</code>	Path to the single app file

## Creating a Certificate Container

Container for adding a certificate:

```
mlxdpa --cert_container_type add -c <.DER formatted certificate> -o <output path> --life_cycle_priority <Nvidia,OEM,User> create_cert_container
```

Container for removing a certificate:

```
mlxdpa --cert_container_type remove [--cert_uid <uuid of the certificate for removal>] [--remove_all_certs] -o <output path> --life_cycle_priority <Nvidia,OEM,User> create_cert_container
```

Create a certificate upload container with the keep\_sig flag

```
mlxdpa --cert_container_type add -c /tmp/cert.der -o /tmp/cert_container.bin --life_cycle_priority OEM --keep_sig create_cert_container
```

Create certificate upload container with nvidia\_signed\_oem flag

```
mlxdpa --cert_container_type add -c /tmp/cert.der -o /tmp/cert_container.bin --nvidia_signed_oem create_cert_container
```

## Signing a Certificate Container

Container for adding a certificate:

```
mlxdpa --cert_container <container> -p <private key pem file> --keypair_uuid <uuid> --cert_uid <uuid> --life_cycle_priority <Nvidia,OEM,User> -o <output path> sign_cert_container
```

Container for removing a certificate:

```
mlxdpa --cert_container <container> -p <private key pem file> --keypair_uuid <uuid> --life_cycle_priority <Nvidia,OEM,User> -o <output path> sign_cert_container
```

Where:

<code>--cert_container</code>	Path to a certificate container to sign
<code>--cert_container_type &lt;Add/Remove&gt;</code>	Type of a certificate container to create
<code>-c --certificate</code>	Path to a .DER formatted certificate
<code>--keypair_uuid</code>	Key-pair UUID of the private key used for signing
<code>--cert_uid</code>	Time base UUID generated right before signing
<code>--remove_all_certs</code>	Remove all CA Certificates, provide with the sign_cert_remove command
<code>--life_cycle_priority &lt;Nvidia, OEM, User&gt;</code>	Life-cycle priority of a requested certificate container
<code>-o --output_file</code>	Path to an output file

-p --private_key	Path to a private key PEM file for signature generation
--nvidia_signed_oem	NVIDIA signed OEM certificate
-k --keep_sig	The whole certificate container will be kept

### 3.5.15 mlx cableimngen - Cable Firmware Image Wrapper Generation Tool

The specifications of a compatible cable hardware must be passed to the tool to create the image wrapper.

#### mlx cableimngen Synopsis

```
mlx cableimngen -d <OUI> -p <vendor pn> -r <vendor rev> -w <vendor hw major> -m <vendor fw major> -n <vendor fw minor> -b <vendor fw build> -i <fw image> [-j <vendor data>] -o <output path> generate_image
```


Where:


-d --vendor_ieee_id	Vendor IEEE ID in Hex (6 characters)
-p --vendor_pn	Part number provided by vendor in ASCII (16 characters)
-r --vendor_rev	Revision level for part number provided by vendor in ASCII (2 characters)
-w --vendor_hw_major	Module hardware major revision in Hex (2 characters)
-m --vendor_fw_major	Module firmware major revision in Hex (2 characters)
-n --vendor_fw_minor	Module firmware minor revision in Hex (2 characters)
-b --vendor_fw_build	Module firmware build revision in Hex (4 characters)
-i --image_path	Path to FW image file
-j --vendor_data_path	Path to vendor data file (optional)
-o --output_path	Path to output image file


### 3.5.16 nvredfish

The nvredfish tool enables the user to query the BMC firmware and update the BMC firmware.

Users can perform firmware update to BMC (for the update to take effect, a full AC cycle of the board is needed).

 For the update to take effect, a full AC cycle of the board is needed.

 Initial FW burn is outside the scope of this feature.

 For the nvredfish tool to be installed as part of the MFT package, the user must provide `--with-nvredfish` argument to the install script.

#### User Flow

1. Generate token (not MFT related)
2. Generate mst device representing the BMC:  

```
mst redfish add <bmc ip> <token>
```
3. Query:  

```
nvredfish -d <> query
```
4. Burn the image:  

```
nvredfish -d <> -p <.fwpkg> burn
```

After the burn command, for the firmware update to take effect, an AC cycle (physically disconnecting and then reconnecting the system's main power) of the board is needed.

### 3.5.16.1 BMC/HMC Dumps

#### User Flow

1. To view all available dumps in the system, please run the following command:  

```
nvredfish -d <redfish_device> query_dump
```

The command will display a list of available device diagnostic dumps.
2. Choose the desired dump type and run the following command to start the dump process:  

```
nvredfish -d <redfish_device> -t <type> -o <output_file> dump
```



This command can take up to several minutes. The progress will be displayed while the tool is running. The output file will contain a dump file in mstdump format.

## 3.6 Debug Utilities

This section contains:

- [fwtrace Utility](#)
- [mlxtrace Utility](#)
- [mlxptrace Utility](#)
- [mstdump Utility](#)
- [mlxix2c Utility](#)
- [i2c Utility](#)
- [mget\\_temp Utility](#)
- [mstdump Utility](#)
- [mlxmcp Utility](#)
- [pckt\\_drop Utility](#)
- [mlxuptime Utility](#)
- [wqdump Utility](#)


- [mlxmdio Utility](#)
- [mlxreg Utility](#)
- [mlxlink Utility](#)
- [mlxfwstress Utility](#)
- [resourcedump Utility](#)
- [resourceparse Utility](#)
- [stedump Utility](#)

### 3.6.1 fwtrace Utility


The fwtrace utility extracts and prints trace messages generated by the firmware running on 5th generation (Group II) devices iRISCs.


These trace messages inform developers of software drivers about internal status, events, critical errors, etc. Trace messages generated by iRISCs are stored in the trace buffer. The trace buffer is located in host memory. The tool also supports mem free mode where it uses a device internal small buffer.

By default, the firmware does not print trace messages. Please contact your FAE for more details on how to enable firmware tracing.

 When using secure firmware, the user needs to validate that the value "1" is set to `/sys/kernel/debug/tracing/events/mlx5/fw_tracer/enable`.

As of MFT v4.30.0, fwtrace can extract events from secure devices (for supported Firmware versions) using `mlxprtrace` utility and without the need of `mlx5` driver. `fwtrace` will automatically use the new capabilities if the device supports it.

 Memory mode on 5th generation (Group II) devices is supported only by PCI mst devices.

 For the tool to properly work with Inband devices, both the MFT and the Firmware must be updated to the latest (MFT version 4.18.0 and above, and Firmware version XX.32.1xxx and above).

#### 3.6.1.1 fwtrace Usage

1. Start the mst driver (`mst start` or `mst restart`)
2. Enter the following command:

```
# fwtrace [options...]
```

where

<code>-h --help</code>	Print this help message and exit
<code>-d --device</code>	mst device name
<code>-f --fw_strings</code>	Fw strings db file containing the FW strings

--tracer_mode	Tracer mode [FIFO   MEM]
--real_ts	Print real timestamps in [hh:mm:ss:nsec] format
-i --irisc	iRISC name (See below for full list of irisc names)
-t --tile	Allow the user to specify which tile events he would like to see. # "1.all" will enable risc1 in all tiles. # "1" will be treated like "1.all" # "all" will be treated like all.all # "all.1" will enable all iriscs in tile 1 # .1 is invalid input.
-a --apu	If enabled, tool will show APU events.
--include_phy_uc	If enabled, tool will also show phy_uc events related to the enabled riscs (main / tiles)
--keep_cfg	If enabled, the FWtrace will not delete the temporary cfg file (if one was created during the current run)
-s --stream	Run in streaming mode
-c --cfg	Hardware tracer events cfg file
-n --snapshot	Take events snapshot - this assumes previous FW configurations
-S --buf_size	Hardware tracer MEM buffer size in [MB]
-p --dump	Dump file name
--raw_dump	Used with --dump flag to inform the tool the dump input type is .dump, which is coming from reasource_dump, and not .trc type that come from tracer tool
-m --mask	Trace class mask, use "+" to enable multiple classes or use integer format, e.g: -m class1+class2+... or 0xff00ff00
-l --level	Trace level
--log_delay	Firmware tracer log delay in uSec
v --version	Print tool's version and exit
--gvmi	Global virtual machine interface
--ignore_old_events	Ignore collecting old events
--mem_access	Memory access method: OB_GW, VMEM, UDRIVER
--keep_running	Keep the hardware tracer unit running after exit
--config_only	Configure tracer and exit
--fw_cfg_only	Skip HW config and only configure FW events (default=off)

#### Device Specific Info:

To view device specific information, run `"fwtrace -d <mst_dev> -h"`.

#### Example:

```

fwtrace -d /dev/mst/mt4123_pciconf0 -i all -s -l 0 -m 0xFFFFFFFF
-I Found FW string db cache file, going to use it
Got ownership successfully!
mlxtrace -d /dev/mst/mt4123_pciconf0 -m MEM --skip_ownership -c /tmp/itrace_2946580.cfg -S
-I Tracer Configuration:
-I =====
-I Mode : Collector
-I Activation Mode : Memory Mode
-I Memory Access Method : NA
-I Configuration File Path : /tmp/itrace_2946580.cfg
-I Output file (Trace File) Path : mlxtrace.trc
-I User Buffer Size : NAMBytes
-I Use Stream Mode : YES
-I Configure Only : NO
-I Only Snapshot (Skip Configuration Stage) : NO
-I Ignore old events : NO
-I Continuous fill : NO
-I Print timestamp in hh:mm:ss:nsec format : NO
-I Output file for streaming : STDOUT
-I Delay between samples : 0usec
-I Stop tracer after exit : YES
-I =====
-I Tracer ownership is already taken or skipped
-I Device is: ConnectX6
-I Configuring Tracer...
-I Invalidating kernel buffer... (Press ^C to skip)
-I Done
-I Tracer was configured successfully
Device frequency: 430MHz
-I Starting event streaming...
#time stamp, unreliable, lost, missing TS, event name
Reading new events...
512458354925 I3 in pll_management_handler. freq_in = 3.
512458355201 I3 in pll_management_handler. set pll 0 in center pll 0 to state 0.
512458355749 I3 in pll_management_handler. freq_in = 3.
512458356030 I3 in pll_management_handler. set pll 1 in center pll 0 to state 0.
512458356583 I3 in pll_management_handler. freq_in = 3.
512458356865 I3 in pll_management_handler. set pll 2 in center pll 0 to state 3. .
.
.

```

## 3.6.2 mlxtrace Utility

The mlxtrace utility is used to configure and extract HW events generated by different units in NVIDIA devices. The utility generates a dump ".trc" file which contains HW events that assist us with debug, troubleshooting and performance analysis. Events can be stored in host memory if driver is up or in a small on-chip buffer (always available) depending on the utility running mode. In order to run the utility it's required to have a configuration file first, this file should be provided by the NVIDIA representative.

A dump file "mlxtrace.trc" will be generated by end of run (file name can be controlled by "-o" flag), this file should be sent to the NVIDIA representative for further diagnostics/troubleshooting.



Memory mode on 5th generation (Group II) devices is supported only by PCI mst devices. Memory mode is supported in Windows, as well as in Linux.



For the tool to properly work with Inband devices, both the MFT and the Firmware must be updated to the latest (MFT version 4.18.0 and above, and Firmware version XX.32.1xxx and above).

### 3.6.2.1 mlxtrace Usage

1. The mst driver must be started prior to running the mlxtrace tool.
2. For MEM buffer mode driver must be "loaded" also.
3. Enter the following command:

```
mlxtrace [options]
```

## Options

-h, --help	Print help and exit
-v, --version	Print version (default=off)
-p, --parse	Move to parser mode (default=off)

## Mode: CollectMode

-d, --device=MstDev	Mst device
-m, --mode=Mode	Activation mode: FIFO - HW BUFFER , MEM - KERNEL BUFFER (possible values="FIFO", "MEM")
-a, --mem_access=MemMethod	Memory access method: OB_GW, VMEM, UDRIVER, PERFMON (possible values="OB_GW"/ "VMEM"/ "UDRIVER" "PERFMON")
--gvmi	Global virtual machine interface
-c, --cfg=CfgFile	Mlxtrace configuration file
-o, --trc_file=TrcPath	Output TRC file path (default=`mlxtrace.trc`)
-C, --config_only	Configure tracer and exit (default=off)
-b, --backpressure	Enable "Allow_backpressure" for all supported hardware events (default=off)
-n, --snapshot	Take events snapshot - This assumes previous run with -- config_only (default=off)
-s, --buf_size=BufSize	User buffer size [MB] (default=`1`)
-S, --stream	Don't save events to file parse it immediately (default=off)
--ignore_old_events	Ignore collecting old events in MEM mode (default=off)
-g, --continuous_fill	Do not stop recording (stopping only with ^C), keep filling user's buffer cyclically (default=off)
--sample_delay=Delay	Delay between samples when polling new events in [usec] (default=`0`)
--keep_running	Keep the HW tracer unit running after exit (default=off)
--enable_limiting_every_chunk	Limit the HW tracer after reading every chunk (default=off)
--fw_cfg_only	Skip HW config and only configure FW events (default=off)
--skip_ownership	Skip taking ownership (default=off)

## Mode: ParseMode

-i, --input=TrcFile	Input file (default=`mlxtrace.trc`)
--csv_mode	Enable csv output format (default=off)
--print_ts	Print timestamp events (default=off)
-r, --real_ts	Print real timestamps in [hh:mm:ss.nsec] format (default=off)
--print_raw	Print event bytes in each line header (default=off)
--ts_format=format	Choose printed TS format hex/dec (possible values="hex", "dec" default=`dec`)
--print_delta	Enable printing delta between events (in cycles) (default=off)
-f, --print_file=FilePath	Print parsed event to the given file and not to stdout

<code>--enable_db_check</code>	Enable events DB checks (default=off)
--------------------------------	---------------------------------------

Examples:

Choose the suitable .cfg file depending on the device you are using, and run the following command to generate a .trc file:

```
# mlxtrace -d /dev/mst/mt4123_pciconf0 -c ConnectX6.cfg -m MEM -o ConnectX6.trc
```

To generate a .trc file with a maximal size of 100 MB, run the following command:

```
# mlxtrace -d /dev/mst/mt4123_pciconf0 -c ConnectX6.cfg -m MEM -s 100 -o ConnectX6.trc
```

### 3.6.3 mlxptrace Utility

The mlxptrace utility is used to configure and extract FW events generated by different units in NVIDIA devices.

This utility was added in MFT v4.30 to provide solutions for supported secured devices with the need of debug token.

- The utility is only supported in Linux environment
- It is recommended to run the tool via fwtrace and not directly from command line
- the tool has similar interface to the mlxtrace and same .cfg files can be used for both tools. (for more information please review the mlxtrace utility)

#### 3.6.3.1 mlxptrace Usage

1. The mst driver must be started prior to running the mlxptrace tool.
2. Enter the following command:

```
mlxptrace [options]
```

Options:

<code>-h, --help</code>	Print help and exit
<code>-p, --parse</code>	Move to parser mode (default=off)
<code>-d, --device=MstDev</code>	Mst device
<code>-m, --mode=Mode</code>	Currently only FIFO mode is supported (possible values are "FIFO", "MEM" for compatibility with mlxtrace).
<code>--gvmi</code>	Global virtual machine interface
<code>-c, --cfg=CfgFile</code>	mlxtrace configuration file
<code>-o, --trc_file=TrcPath</code>	Output TRC file path (default=`mlxtrace.trc`)
<code>-C, --config_only</code>	Configure tracer and exit (default=off)
<code>-n, --snapshot</code>	Take events snapshot - This assumes previous run with -- config_only (default=off)
<code>-s, --buf_size=BufSize</code>	User buffer size [MB] (default=`1`)

-S, --stream	Don't save events to file parse it immediately (default=off)
--ignore_old_events	Ignore collecting old events in MEM mode (default=off)
-g, --continuous_fill	Do not stop recording (stopping only with ^C), keep filling user's buffer cyclically (default=off)
--keep_running	Keep the HW tracer unit running after exit (default=off)
--fw_cfg_only	Skip HW config and only configure FW events (default=off)
--skip_ownership	Skip taking ownership (default=off)
-i, --input=TrcFile	Input file (default=`mlxtrace.trc')
--raw_dump	When set, the parse input file will be considered as raw dump taken from resource dump instead of .trc file. Must be used with --cfg and --parse flags.
--csv_mode	Enable csv output format (default=off)
--print_ts	Print timestamp events (default=off)
--print_raw	Print event bytes in each line header (default=off)
--ts_format	Switch printed TS format to hex, default=dec
--print_delta	Enable printing delta between events (in cycles) (default=off)

## 3.6.4 mstdump Utility

The mstdump utility dumps device internal configuration registers. The dump file is used by the Support team for hardware troubleshooting purposes. It can be applied on all NVIDIA devices.



For the tool to properly work with Inband devices, both the MFT and the Firmware must be updated to the latest (MFT v4.18.0 & firmware vX.X.1014).



If ConnectX-4 adapter card is used as an Inband device, for the tool to work properly, you need to use MFT 4.17.0.

### 3.6.4.1 mstdump Usage

To run mstdump:

```
# mstdump [-full] <mst device> > <dump file>_FW_VERSION
```

where the `-full` flag dumps all internal registers

positional arguments:

device	The device name
--------	-----------------

optional arguments:

-h, --help	show help message and exit
-v, -version, --version	show program's version number and exit
-full, --full	Dump more expanded list of addresses
-ignore_fail, --ignore_fail	Continue dumping, even if some addresses fails
-c CSV, -csv CSV, --csv CSV	Database path
--cause address.offset	Specify address and offset
--i2c_secondary I2C_SECONDARY	I2C secondary [0-127]

Example:

```
[root@myrnach]# mstdump /dev/mst/mt4099_pci_cr0 > mt4099_12_16_2600.dmp
```

This dumps the internal configuration data of the device into the mt4099.dmp file.

## 3.6.5 mlxI2c Utility

The mlxI2c utility provides a way to route the I2C bus to 4th generation (Group I) switches.

### 3.6.5.1 mlxI2c Usage

The mst driver must be started prior to running mlxI2c.

To start mlxI2c:

1. Start the mst driver (mst start or mst restart). Note: This step is not required in Windows.
2. Run mlxI2c with the following command line syntax:

```
# mlxI2c [switches...] <command> [parameters...]
```

#### Switches Options

-d <device>	mst i2c device name default: "/dev/mst/mtusb-1" Affected commands: all
-h	Print this help information
-s, --i2c-secondary <address>	Change the I2C secondary address.
-v	Print version and exit

#### Commands

p <i2c_component>	Route the i2c path to the indicated i2c component
scan	Scan the i2c slave addresses

Example:

Display the addresses of all I2C-accessible devices:

```
# mlxI2c -d /dev/mst/mtusb-1 scan
```

## 3.6.6 i2c Utility

The i2c utility provides low level access to the I2C bus on any NVIDIA switch platform, enabling the user to read or write data.

### 3.6.6.1 i2c Usage (Advanced Users)

The mst driver must be started prior to running i2c tool.

To start i2c:

1. Start the mst driver (mst start or mst restart). Note: This step is not required in Windows.
2. Run i2c with the following command line syntax:

```
# i2c [OPTIONS] <device> <cmd> <i2c_addr> <addr> [<data>]
```

where:

-h	Prints this message.
-a <addr_width>	Sets address width (in bytes) to the specified value. May be 0, 1, 2 or 4. Default: 1.
-d <data_width>	Sets data width (in bytes) to the specified value. May be 1, 2 or 4s. Default is 1.
-x <data_len>	Presents each byte of data as two hexadecimal digits (such as 013C20343B). Note that this option is mutually exclusive with the "-d" option.

The remaining parameters are:

<device>	Valid mst device.
<cmd>	Command. May be "r[ead]" or "w[rite]".
<i2c_addr>	I2C slave address.
<addr>	Address (of length addr_width) inside I2C target device to read/write operation. Note that the <addr> value is ignored if <addr_witdh> = 0.
<data>	Data (bytes of length data_width) to write to target device.



All parameters are interpreted as hexadecimal values.

Examples:

Read two bytes from address 0 of target I2C slave address 0x56:

```
# i2c -a 2 -d 2 /dev/mst/mtusb-1 r 0x56 0x00  
0000
```

Write two bytes to the address above then read them:

```
# i2c -a 2 -d 2 /dev/mst/mtusb-1 w 0x56 0x00 0x1234
# i2c -a 2 -d 2 /dev/mst/mtusb-1 r 0x56 0x00
3412
```

Read (as separate) 16 bytes in hexadecimal format starting from address 0 of the target device above:

```
# i2c -a 2 -x 16 /dev/mst/mtusb-1 r 0x56 0x00
12340000000000000000000000000000
```

### 3.6.6.2 Exit Return Values

The following exit values are returned:

- 0 - successful completion
- >0 - an error occurred

### 3.6.7 mget\_temp Utility

The mstmget\_temp utility reads the hardware temperature from supported NVIDIA devices and prints the result in degrees Celsius.

#### 3.6.7.1 mget\_temp Usage

To run mget\_temp:

```
# mget_temp [OPTIONS]
```

where:

-h	Print the help message.
-d <dev>	mst device name.
--version	Display version info.
-s <i2c-secondary>	I <sup>2</sup> C secondary address
-v	print a table of all thermal diode data
--precision <unit>	Set the temperature display resolution.
--no-modules	Exclude module sensor readings from the output.

Example on how to read a device temperature:

```
# mget_temp -d /dev/mst/SW_MT51000_0002c903007e76a0_lid-0x0002 -v
```



On supported devices, mstmget\_temp reports both the device temperature and the temperature of on-board modules.

## 3.6.8 mlxdump Utility

The mlxdump utility dumps device internal configuration data and other internal data (such as counters, state machines).

The data can be used for hardware troubleshooting. It can be applied to all NVIDIA devices.

The tool has 3 run modes: [fast | normal | full] while the default is "fast", the "full" mode dumps all available data but might run slower than normal and fast modes.

The tool also can dump only flow steering information using the fsdump sub-command (See example below). The fsdump sub-command has the flag --type to specify the type of the flow steering: STE or FT or All.

The tool can dump only mstdump information using the mstdump sub-command (see example below). The mstdump sub-command has multiple flags: --full, i2c\_slave, cause\_addr and cause\_offset which enable the user to run with the needed parameters.

### 3.6.8.1 mlxdump Usage

The mst driver must be started prior to running mlxdump tool.

```
mlxdump OPTION <command> [COMMAND OPTIONS] [-d|--device MstDevice] [-h|--help] [-v|--version]
```

where:

-d --device MstDevice	mst device name
-h --help	Show help message and exit
-v --version	Show version and exit
mstdump	Read mstdump information
fsdump	Read Flow Steering information. <b>Note:</b> Reading flow steering information is supported in ConnectX-4 and above adapter cards.
snapshot	Dump everything



To view <command> related options please run: "mlxdump OPTION <command> -h"

Examples:

To generate "mlxdump.udmp" while running in fast mode:

```
# mlxdump -d /dev/mst/mt4117_pciconf0 snapshot
```

To generate "mlxdump.udmp" while running in full mode:

```
# mlxdump -d /dev/mst/mt4117_pciconf0 snapshot -m full
```

To generate "mlxdump\_13\_1\_2013.udmp" while running in normal mode:

```
# mlxdump -d /dev/mst/mt4117_pciconf0 snapshot -m normal -o mlxdump_13_1_2013.udmp
```

To generate flow steering information:

```
# mlxdump -d /dev/mst/mt4117_pciconf0 fsdump --type=All --gvmi=0
```

To generate mstdump information::

```
# mlxdump -d /dev/mst/mt4119_pciconf0 mstdump
```

## 3.6.9 mlxmcg Utility

The mlxmcg tool displays the current multicast groups and flow steering rules configured in the device. Target users: Developers of Flow Steering aware applications.

This tool dumps the internal steering table which is used by the device to steer Ethernet packets and Multicast IB packets to the correct destination QPs.

Each line in the table shows a single filter and a list of destination QPs. Packets that match the filter are steered to the list of destination QPs.



- mlxmcg is not supported against In-band device.
- mlxmcg is supported in ConnectX-3/ConnectX-3 Pro only.

### 3.6.9.1 mlxmcg Usage

The mst driver must be started prior to running mlxmcg tool. To start mlxmcg:

1. [Optional for Windows OSs] Start the mst driver (mst start or mst restart).
2. Enter an mlxmcg command that complies with the following command syntax:

```
# mlxmcg [OPTIONS]
```

where:

-h, --help	Show this help message and exit
-d DEV, --dev=DEV	mst device to use, required
-f FILE, --file=FILE	MCG dump file to use (for debug). Used as input - no need for a device.
-p PARAMS, --params=PARAMS	Mcg params, (MCG_ENTRY_SIZE, HASH_TABLE_SIZE, MCG_TABLE_SIZE), default is (64, 32768, 65536)
-q, --quiet	Do not print progress messages to stderr
-v, --version	Print tool version
-c, --hopcount	Add hopCount column
-a, --advanced	Show all rules

This will display all the current multicast groups and flow steering rules configured in the device.



### 3.6.11.1 mlxuptime Usage

```
mlxuptime [options]
```

where:

-d <dev> --device	Mst device name
-s <time> --sample	Sampling interval for measuring frequency (default: 1 [sec])
-h --help	Print help and exit
-v --version	Print tool version and exit
-f, --force_sample	Force sampling interval for measuring frequency. Default: Reading up time from device.

Examples:

Print all info:

```
# mlxuptime -d /dev/mst/mt4117_pciconf0
Measured core frequency      : 427.099818 MHz
Device up time               : 10:01:20.456344 [h:m:s.usec]
```

### 3.6.12 wqdump Utility

The wqdump utility dumps device internal work queues. A work queue is an object containing a Queue Pair Context (QPC) which contains control information required by the device to execute I/O operations on that QP, and a work queue buffer which is a virtually-contiguous memory buffer allocated when creating the QP.

The dumped data can be used for hardware troubleshooting. It can be applied on ConnectX adapter cards family and Connect-IB adapter devices.



wqdump on ConnectX-3 and ConnectX-3 Pro is not supported against in-band devices.

#### 3.6.12.1 wqdump Usage

The mst driver must be started prior to running the wqdump utility. To start the wqdump utility:

1. Start the mst driver (mst start or mst restart).
2. Run wqdump:

```
# WQDump <-d|--device DeviceName> <--source ContextType> [--gvmi Gvmi] [--qp ContextNumber]
<--dump DumpType> [--fi StartIndex] [--num NumberOfItems] [--format Format]
[--address Address] [--size Size] [-v|--version] [-h|--help] [--clear_semaphore] [--gw_access]
```

where:

--d --device DeviceName	Device name
----------------------------	-------------

--source ContextType	Type of context to dump. Options are: Snd, Rcv, Cmp, Srq, Eqe, Connect-X3/Pro: MCG, 5th generation devices: MKC, SXDC, FullQp ConnectX-5: CMAS_QP_WQE, CMAS_QP_SWQ, CMAS_SRQ_WQE, CMAS_CQ_BUFF, CMAS_QP_DBR, CMAS_QP_SDB, CMAS_SRQ_DB, CMAS_CQ_DBR, CMAS_CQ_ARM, CMAS_EQ_BUFF, CMAS_TAG_MATCH. CMAS_INLINE
--gvmi Gvmi	Guest VM ID (5th generation devices)
--qp ContextNumber	Context number to dump
--dump DumpType	Dump Type. Options are: WQ, QP, WQ_QP, ALL_QPC, ALL_VALID_QPNS, ICM
--fi StartIndex	Index of first element to dump, (Default:0)
--num NumberOfItems	Number of elements to dump from buffer, (Default: keep reading)
--format Format	Output format: options are : text, raw, dw, (Default: text)
--address Address	Memory Address
--size Size	Memory size in bytes
-v --version	Show tool version and exit
-h --help	Show usage
-- clear_semaphore	Force clear semaphore
--gw_access	Force get QPC by GW access (Connect-X 3/Pro)

#### 4th Generation Device Examples:

##### Print all valid qpns

The example below will dump all valid qpns of type mcg context.

```
# wqdump -d /dev/mst/mt4099_pci_cr0 --source mcg --dump ALL_VALID_QPNS
```

##### Dump mcg qp

The example below will dump mcg context number 0x10.

```
# wqdump -d /dev/mst/mt4099_pci_cr0 --source mcg --dump QP -qp 0x10
```

##### Dump other qpns

The example below will dump snd context number 0x10 in a raw format.

```
# wqdump -d /dev/mst/mt4099_pci_cr0 --source snd --dump QP -qp 0x10 --format raw
```

##### Dump wq

The example below will dump send work queue buffer number 0x42.

```
# wqdump -d /dev/mst/mt4099_pci_cr0 --source snd --dump wq -qp 0x42
```

##### Dump mcg qp by GW access

The example below will dump mcg context number 0x10 by GW access.

```
# wqdump -d /dev/mst/mt4103_pci_cr0 --source mcg --dump QP -qp 0x10 --gw_access
```

## 5th Generation Device Examples:

FullQp: The QP context of the Rcv and Snd with the common part. Note, FullQp does not have dump as WQ.

- Get opened contexts from the first 20 indexes:

```
# wqdump -d /dev/mst/mt4117_pciconf0 --source FullQp --dump ALL_VALID_QPNS --num 20
Numbers of valid contexts (in the range 0x0 - 0x13):
index 0x00000003
index 0x00000006
index 0x00000007
index 0x0000000b
index 0x0000000c
index 0x00000013
-----
Number of valid contexts: 6
-----
```

- Show the QP Context (RAW):

```
# wqdump -d /dev/mst/mt4117_pciconf0 --source FullQp --dump QP --qp 0x0000000b --format raw
== Common Part (Not Connected) ==
0. 80000000 0000001e 05000000 00000000
1. 70000000 00000000 00000000 00000000
2. 0000000b 00ffffff 00000000 00000000
3. 00000000 00000000 00000000 80010000
-----
Send Qpc gvmi 0000 QP Index 0000000b
0. 80000000 0000001e 05000000 00000000
1. 70000000 00000000 00000000 00000000
2. 0000000b 00ffffff 00000000 00000000
3. 00000000 00000000 00000000 80010000
-----
== Responder Part (Not Connected (mac)) ==
Recv Qpc gvmi 0000 QP Index 0000000b
0. b8eccd02 00000000 d8f5cd02 00000000
1. d0010000 00000000 40000000 00000000
2. e0e03903 00000000 f0e03903 00000000
3. 00000000 00000000 00000000 00000000
-----
```

## SRQ

- Opened QPs:

```
# wqdump -d /dev/mst/mt4115_pciconf0 --source Srq --dump all_valid_qpns
Numbers of valid contexts (in the range 0x0 - 0xffffffff):
gvmi 0x0000 index 0x00000060
gvmi 0x0000 index 0x00000061
gvmi 0x0000 index 0x00000066
```

- Dump WQs:

```
0x00000066# wqdump -d /dev/mst/mt4117_pciconf0 --source Srq --dump wq --qp 0x60
[Element Index 0]
----- SRQ Next -----
next_wqe_index : 0x1
signature : 0x0
----- scatter entry (0) -----
byte_count : 0x0
wqe_inline : 0x0
local_key : 0x0
local_address_63_32 : 0x0
local_address_31_0 : 0x0
[Element Index 0x1]
----- SRQ Next -----
next_wqe_index : 0x0
signature : 0x0
----- scatter entry (0) -----
byte_count : 0x0
wqe_inline : 0x0
local_key : 0x0
local_address_63_32 : 0x0
local_address_31_0 : 0x0
```

## CMAS

- Opened contexts from some CMAS type (CMAS\_EQ\_BUFF for ex):

```
#wqdump -d /dev/mst/mt4119_pciconf0 --source CMAS_EQ_BUFF --dump ALL_VALID_QPNS
Numbers of valid contexts (in the range 0x0 - 0xffffffff):
gvmi 0x0000 index 0x00000002
gvmi 0x0000 index 0x00000010
gvmi 0x0000 index 0x00000011
gvmi 0x0000 index 0x00000012
gvmi 0x0000 index 0x00000013
gvmi 0x0000 index 0x00000014
gvmi 0x0000 index 0x00000015
```

- Dump raw data:

```
# wqdump -d /dev/mst/mt4119_pciconf0 --source CMAS_EQ_BUFF --dump QP --qp 0x15 --format raw
CMAS gvmi 0000 CMAS Index 00000015
0. 80000002 00000000 00000000 e4f80000
1. 00000000 00000000 00000000 00000000
2. 00000000 00000000 00000000 00000000
3. 00000000 00000000 00000000 00000000
-----
```

## 3.6.13 mlxmdio Utility

The mlxmdio tool is used to read/write MDIO registers (Clause 45) on Boards with externally managed PHY.

### 3.6.13.1 mlxmdio Usage

To run mlxmdio, use the following line:

```
# mlxmdio -d mst_dev -m phy_addr:dev_addr -g mdio_gw -a addr[:data] [-r size] [-w input_file]
```

where:

-d <device>	mst device
-m <mdio_id>	The mdio id of the target device in phy_addr:dev_addr format.
-a <addr[:data]>	Access a single MDIO reg. If data is specified, the reg is written, Otherwise, it is read. Addr and data should be in hex format.
-g <mdio_gw>	Select which mdio gateway <0..10> to use.
-c <clause>	Select which clause to use: <ul style="list-style-type: none"><li>• 22: clause 22.</li><li>• 45: clause 45 (Default).</li></ul>
-r <size>	Read a block of <size> 16-bit words (max size 64)
-w <input_file>	Write a block from <input_file>. Every line of input file should be addr:data in hex.
-h	Show usage.
-v	Show tool version.

## Methods for Sending MDIO Transactions

mlxmdio will attempt to send the MDIO transaction through a firmware interface if supported (on supported devices only). The mdio gateway values should be in the range of 0..10.



Sending MDIO transactions via FW requires specification of the PCI device.

Example:

To read mlxmdio register, run the following command:

```
# mlxmdio -d /dev/mst/mt4123_pciconf0 -m 0x7:0x1 -a 0x0 -g 6
```

To write mlxmdio register, run the following command:

```
# mlxmdio -d /dev/mst/mt4123_pciconf0 -m 0x7:0x1 -a 0x0:0x0124 -g 6
```

To read block of 5 sequential operations through mlxmdio register, run the following command:

```
# mlxmdio -d /dev/mst/mt4123_pciconf0 -m 0x7:0x1 -a 0x14 -g 6 -r 5
0x0014:0x0010
0x0015:0x0003
0x0016:0x0030
0x0017:0x0040
0x0018:0x0050
```



The address of the beginning of the block should be provided with the "-a" flag (e.g., `-a 0x14`).

To write block of operations through mlxmdio register, run the following command:

```
# mlxmdio -d /dev/mst/mt4123_pciconf0 -m 0x7:0x1 -g 6 -w input.txt
```



Every line of the input file should be formatted as `addr:data` in hex. The address of every line is not necessarily in a sequential order.

An example of the input file:

```
0x0017:0x0040
```

```
0x0014:0x0010
```

```
0x0015:0x0003
```

```
0x0018:0x0050
```

```
0x0016:0x0030
```

## 3.6.14 mlxreg Utility

The `mlxreg` utility allows users to obtain information regarding supported access registers, such as their fields and attributes. It also allows getting access to register data from firmware and setting access register data on firmware.

Registers can be get/set in unknown (RAW) mode by providing register ID and length.



Unknown (RAW) mode is risky as no checks are performed, please consult with [Support](#) before using it.

### 3.6.14.1 mlxreg Usage

mst driver must be started prior to running mlxreg tool.

Some access registers depend on setup configuration such as link up/down. Invalid setup may cause failures.

To run mlxreg, use the following line:

```
mlxreg [options]
```

where:

-h  --help	Displays help message.
-v  --version	Displays version info.
-d  --device <device>	Performs operation for a specified mst device.
-a  --adb_file <adb_file>	An external ADB file
--reg_name <reg_name>	Known access register name
--reg_id <reg_ID>	Access register ID
--reg_len <reg_length>	Access register layout length (bytes)
-i  --indexes <idxs_vals>	Register indexes
-g  --get	Register access GET
-s  --set <reg_dataStr>	Register access SET
--show_reg <reg_name>	Prints the fields of a given reg access (must have reg_name)
--show_regs	Prints all available access registers
--yes	Non-interactive mode, answer yes to all questions
--i2c_secondary <i2c_secondary>	I <sup>2</sup> C secondary address
-w  --overwrite	Set only specified fields, set unspecified fields to zero (only valid for SET command)
--full_path	Show field names with full hierarchical path. (Recommended to use it always to avoid field ambiguity)
--detailed	Show detailed output including enum names and decimal values
--advanced	Show field descriptions (truncated by default, use with --show_reg)
--full_desc	Show full wrapped descriptions instead of truncated (use with --advanced)
--field <field_name>	Filter to show specific field only (use with --advanced)

Examples:

Show all available access registers (the example below shows a sample of the whole list):

```
mlxreg -d /dev/mst/mt4115_pciconf0 --show_regs
```

```
Available Access Registers
=====
CWTP
CWTPM
MCIA
MLCR
MPCNT
MPEIN
NCFG
PAOS
PDDR
PMDR
PMLP
PPAOS
PPCNT
PPLM
PPLR
PPRT
PPTT
PTAS
PTYS
ROCE_ACCL
SBCM
SBDCR
SBPM
SBPR
SBSR
SLRG
SLRP
SLTP
.....
```

Query a single access register (PAOS):

```
mlxreg -d /dev/mst/mt4115_pciconf0 --show_reg PAOS
Field Name | Address (Bytes) | Offset (Bits) | Size (Bits) | Access
=====
oper_status | 0x00000000 | 0 | 4 | RO
admin_status | 0x00000000 | 8 | 4 | RW
local_port | 0x00000000 | 16 | 8 | INDEX
swid | 0x00000000 | 24 | 8 | INDEX
e | 0x00000004 | 0 | 2 | RW
ee | 0x00000004 | 30 | 1 | WO
ase | 0x00000004 | 31 | 1 | WO
=====
```

Note: There might be indexes in access register fields that must be provided when setting or getting data.

Get access register data (PAOS with indexes: local port 1, swid 0):

```
mlxreg -d /dev/mst/mt4115_pciconf0 --reg_name PAOS --get --indexes "local_port=0x1,swid=0x0"
Field Name | Data
=====
oper_status | 0x00000001
admin_status | 0x00000001
local_port | 0x00000001
swid | 0x00000000
e | 0x00000000
ee | 0x00000000
ase | 0x00000000
=====
```

Set access register data (PAOS with indexes: local\_port 1 swid 0x0 and data: e 1):

```
mlxreg -d /dev/mst/mt4115_pciconf0 --reg_name PAOS --indexes "local_port=0x1,swid=0x0" --yes --set "e=0x1"
You are about to send access register: PAOS with the following data:
Field Name | Data
=====
oper_status | 0x00000002
admin_status | 0x00000001
local_port | 0x00000001
swid | 0x00000000
e | 0x00000001
ee | 0x00000000
ase | 0x00000000
=====
Do you want to continue ? (y/n) [n] : y
Sending access register...
```

Get access register data (PAOS (0x5006) in unknown mode (RAW) with indexes: local\_port=0x1 swid=0x0):

```

mlxreg -d /dev/mst/mt4115_pciconf0 --reg_id 0x5006 --reg_len 0x10 --indexes "0x0.16:8=0x1,0x0.24:8=0x0" --get
Address | Data
=====
0x00000000 | 0x00010101
0x00000004 | 0x00000000
0x00000008 | 0x00000000
0x0000000c | 0x00000000
=====

```

Set access register data (PAOS in unknown mode (RAW) with indexes: local\_port=0x1 swid=0x0 and data e 1):

```

mlxreg -d /dev/mst/mt4115_pciconf0 --reg_id 0x5006 --reg_len 0x10 --indexes "0x0.16:8=0x1,0x0.24:8=0x0" --yes --set
"0x4.0:2=0x1"
You are about to send access register id: 0x5006 with the following data:
Address | Data
=====
0x00000000 | 0x00010102
0x00000004 | 0x00000001
0x00000008 | 0x00000000
0x0000000c | 0x00000000
=====
Do you want to continue ? (y/n) [n] : y
Sending access register...

```

Get access register data (PAOS with indexes: local port 1, swid 0) with --detailed:

```

mlxreg -d /dev/mst/mt4115_pciconf0 --get --reg_name PAOS --indexes "local_port=0x1,swid=0x0" --detailed
Sending access register...

```

Field Name	Hex Value	Decimal	Enum/Type
oper_status	0x00000002	2	down
plane_ind	0x00000000	0	
admin_status	0x00000001	1	up
lp_msb	0x00000000	0	
pnat	0x00000000	0	
local_port	0x00000001	1	
swid	0x00000000	0	
e	0x00000000	0	Do_not_generate_event

Query a single access register (PAOS) with --advanced:

```

mlxreg -d /dev/mst/mt4115_pciconf0 --show_reg PAOS --advanced

```

Field Name	Address	Offset	Size	Access	Description
oper_status	0x00000000	0	4	RO	Port operational state: 1: up 2: down 4:
down_by_port_failure - (transitione...					Possible values (oper_status): 1 (0x1): up 2 (0x2): down 4 (0x4): down_by_port_failure
plane_ind	0x00000000	4	4	INDEX	Reserved for non-planarized port. Plane port index of the aggregated port. A...
admin_status	0x00000000	8	4	RW	Port administrative state (the desired state of the interface): 1: up 2: dow...
					Possible values (admin_status): 1 (0x1): up 2 (0x2): down_by_configuration 3 (0x3): up_once 4 (0x4): disabled_by_system 6 (0x6): sleep
lp_msb	0x00000000	12	2	INDEX	Local port number [9:8]
.					
.					
phy_force_linkup_mode	0x00000008	31	1	RO	Indicates physical link entered forced linkup debug mode

```

Suggested 'get' command:
    mlxreg -d /dev/mst/apps-95:23108,@dev@mst@mt4115_pciconf0.1 --reg_name PAOS --indexes
"plane_ind=0,lp_msb=0,pnat=0,local_port=0,swid=0" --get

```

Query a single access register (PAOS) with --advanced --full\_desc:

```

mlxreg -d /dev/mst/mt4115_pciconf0 --show_reg PAOS --advanced --full_desc
Field Name | Address | Offset | Size | Access | Description
=====
oper_status | 0x00000000 | 0 | 4 | RO | Port operational state: 1: up 2: down 4:
down_by_port_failure - (transitioned by | the hardware)
| Possible values (oper_status):
| 1 (0x1): up
| 2 (0x2): down
| 4 (0x4): down_by_port_failure
-----
plane_ind | 0x00000000 | 4 | 4 | INDEX | Reserved for non-planarized port. Plane port index
of the aggregated port. A
| value of 0 refers to the aggregated port only.
-----
admin_status | 0x00000000 | 8 | 4 | RW | Port administrative state (the desired state of the
interface): 1: up 2: | down_by_configuration 3: up_once - if the port goes
up and then down, the | operational status should go to "down by port
failure" and can only go back up | upon explicit command 4: disabled_by_system - this
mode cannot be set by the | software, only by the hardware. 6: sleep - can be
configured only if sleep_cap | is set. Note that a sleep setting will cause the
port to transition immediately | into sleep state regardless of previous
admin_status. [Internal] - up_once shall | not be used for GPU case. In order to define link
down state set PLDS register |
| Possible values (admin_status):
| 1 (0x1): up
| 2 (0x2): down_by_configuration
| 3 (0x3): up_once
| 4 (0x4): disabled_by_system
| 6 (0x6): sleep
-----
lp_msb | 0x00000000 | 12 | 2 | INDEX | Local port number [9:8]
.
.
.
-----
phy_force_linkup_mode | 0x00000008 | 31 | 1 | RO | Indicates physical link entered forced linkup debug
mode
=====
Suggested 'get' command:
mlxreg -d /dev/mst/apps-95:23108,@dev@mst@mt4115_pciconf0.1 --reg_name PAOS --indexes
"plane_ind=0,lp_msb=0,pnat=0,local_port=0,swid=0" --get

```

Query a single access register (PAOS) with --advanced --field admin\_status:


```

mlxreg -d /dev/mst/mt4115_pciconf0 --show_reg PAOS --advanced --field admin_status
Field Name | Address | Offset | Size | Access | Description
=====
admin_status | 0x00000000 | 8 | 4 | RW | Port administrative state (the desired state of the
interface): 1: up 2: dow... | Possible values (admin_status):
| 1 (0x1): up
| 2 (0x2): down_by_configuration
| 3 (0x3): up_once
| 4 (0x4): disabled_by_system
| 6 (0x6): sleep
=====

```

### 3.6.15 mlxlink Utility

The mlxlink tool is used to check and debug link status and related issues. The tool can be used on different links and cables (passive, active, transceiver and backplane).

 • In order for mlxlink to function properly, make sure to update the firmware version to the latest version

• mlxlink is intended for advanced users with appropriate technical background

- When using mlxlink to disable the port state (“--port\_state dn” flag) on a NIC connected through a Socket-Direct connection, the port must be disabled on both mst devices representing the physical port
- Do not use mlxlink to disable the port connecting between the host and the unmanaged switch using (“--port\_state dn”) flag
- When running mlxlink to show SLTP for 16nm technology, the “--advanced” flag should be added to the run command
- mlxlink errors, warnings and notes are printed on stderr console
- Setting the speeds (50GbE, 100GbE and 200GbE) for the new devices (NVIDIA ConnectX-6 and above, NVIDIA Quantum switches and above) requires specifying the number of lanes for the speed: mlxlink -d <dev> --speeds [50G\_2X | 50G\_1X | 100G\_2X | 100G\_4X | 200G\_4X]
- In ConnectX-7 and later cards, configuring the loopback can be applied when the link is fully down (not in polling state)
- mlxlink is a diagnostic tool and is not intended for continuous polling or background monitoring

### 3.6.15.1 mlxlink Usage

To run mlxlink:

```
mlxlink [OPTIONS]
```

where:

Options:

-h   --help	Display help message.
-v   --version	Display version info.
-d   --device <device>	Perform operation for a specified mst device
-p   --port <port_number>	Port Number
--port_type <port_type>	Port Type [NETWORK(Default)/PCIE/OOB]
--depth <depth>	Depth level of the DUT of some hierarchy (valid for PCIe port type only)
--pcie_index <pcie_index>	PCIe index number (Internal domain index) (valid for PCIe port type only)
--node <node>	The node within each depth (valid for PCIe port type only)
--json	Print the output in JSON format

Queries:

--show_links	Show valid PCIe links (valid for PCIe port type only) and the link status
-m   --show_module	Show Module Info
-c   --show_counters	Show Physical Counters and BER Info
-e   --show_eye	Show Eye Opening Info
--show_fec	Show FEC Capabilities
--show_serdes_tx	Show Transmitter Info

--show_tx_group_map <group_num>	Display all label ports mapped to group <group_num> (for NVIDIA Spectrum-2 and NVIDIA Quantum devices).
--show_device	General Device Info
--show_ber_monitor	Show BER Monitor Info. <b>Note:</b> The flag is not supported in HCAs.
--show_external_phy	Show External PHY Info <b>Note:</b> The flag is supported in NVIDIA Spectrum switch systems only.
--show_plr	Show Physical Layer Retransmission (PLR) Info <b>Note:</b> The flag is supported in NVL5 (and above) switch systems only.
--show_kr	Show Link Training Optimization (KR) Info <b>Note:</b> The flag is supported in NVL5 (and above) switch systems only.
--show_rx_recovery_counters	Show Rx Recovery Counters <b>Note:</b> The flag is supported in NVL5 (and above) switch systems only.
--show_peq	Show Link Periodic Equalization (PEQ) Info <b>Note:</b> The flag is supported in NVL5 (and above) switch systems only.
--show_multi_port_info   --smpi	Show Multi Port Info Table
--show_multi_port_module_info   --smpmi	Show Multi Port Module Info Table
--show_multi_port_cpo_info   --smpci	Show Multi Port Module CPO Info Table
--show_bkv_groups	Show BKV Groups Info (requires --lane parameter)
--show_bkv_group <group_id>	Show BKV Group Info (requires --lane parameter)

#### Commands:

-a   --port_state <port_state>	Configure Port State [UP(up)/DN(down)/TG(toggle)]
-s   --speeds <speeds>	Configure Speeds [speed1,speed2,...]
--link_mode_force	Configure Link Mode Force (Disable AN)
-l   --loopback <loopback>	Configure Loopback Mode [NO(no loopback)/RM(phy remote Rx-to-Tx loopback)/PH(internal phy Tx-to-Rx loopback)/EX(external loopback connector needed)/LL(link layer local loopback)]
-k   --fec <fec_override>	Configure FEC [AU(Auto)/NF(No-FEC)/FC(FireCode FEC)/ RS(RS-FEC)/ LL(LL-RS-FEC)/DF-RS(Interleaved_RS-FEC)/DF-LL(Interleaved_LL_RS-FEC)]
--fec_speed <fec_speed>	Speed to Configure FEC [100G/50G/25G/...] (Default is Active Speed)
--serdes_tx <params>	Configure Transmitter Parameters [polarity,ob_tap0,...]
--serdes_tx_lane <transmitter_lane>	Transmitter Lane to Set (Optional - Default All Lanes)
--database	Save Transmitter Configuration for Current Speed Permanently (Optional)
--tx_params_override	Set the parameters according to Data Base only, otherwise it will be set according to the best possible configuration chosen by the system (e.g. KR-startup) (Optional)

--tx_group_map <group_num>	Map ports to group <group_num> (for NVIDIA Spectrum-2 and NVIDIA Quantum devices)
--ports <ports>	Ports to be mapped [1,2,3,4..]
--test_mode <prbs_mode>	Physical Test Mode Configuration [EN(enable)/DS(disable)/TU(perform tuning)]
--rx_prbs <rx_prbs_mode>	RX PRBS Mode [PRBS31(Default)/PRBS7/...] (Optional - Default PRBS31)
--tx_prbs <tx_prbs_mode>	TX PRBS Mode [PRBS31(Default)/PRBS7/...] (Optional - Default PRBS31)
--rx_rate <rx_lane_rate>	RX Lane Rate [EDR(Default)/25G/10G/...] (Optional - Default 25G)
--tx_rate <tx_lane_rate>	TX Lane Rate [EDR(Default)/25G/10G/...] (Optional - Default 25G)
--invert_tx_polarity	PRBS TX polarity inversion (Optional - Default No Inversion)
--invert_rx_polarity	PRBS RX polarity inversion (Optional - Default No Inversion)
--force_tx_allowed	Force TX allowed for PRBS test mode
--skip_power_good_check	Skip power good check for PRBS test mode
--sysfs_path <path>	Full path to sysfs files (for SW controlled module)
--lanes	PRBS lanes to set (one or more lane separated by comma)[0,1,2,...] <b>Optional:</b> Default all lanes
--rx_modulation	RX Modulation [NRZ/PAM4/PAM4_PRECODING/PAM4_NO_GRAY] (Optional - Default based on lane rate)
--tx_modulation	TX Modulation [NRZ/PAM4/PAM4_PRECODING/PAM4_NO_GRAY] (Optional - Default based on lane rate)
-b   --ber_collect <csv_file>	Port Extended Information Collection [CSV File]
--amber_collect <csv_file>	AmBER Port Extended Information Collection For 16nm Products and Later [CSV File]
--ber_limit <limit_criteria>	BER Limit Criteria [Nominal(Default)/Corner/Drift] (Optional - Default Nominal)
--iteration <iteration>	Iteration Number of BER Collection
--pc	Clear Counters
--set_external_phy	Set External PHY <b>Note:</b> The flag is supported in NVIDIA Spectrum switch systems only.
--twisted_pair_force_mode <twisted_pair_force_mode>	Twisted Pair Force Mode [MA(Master)/SL(Slave)]
--cable	Perform operations on the cables
--dump	Dump cable pages in raw format
--ddm	Get cable Digital Diagnostic Monitoring information
--read	Perform read operation from specific page
--length <length>	Length of data to read in bytes (Optional - Default 1 byte)
--page <pageNum>	Specific page number to read/write

	--offset <offset>	Specific page offset to read/write
	--write <bytes>	Perform write operation with specific data (list of bytes, separated by ';')
	--prbs_select <side>	Module PRBS test mode side selector [MEDIA, HOST]
	--prbs_mode <cmd>	Perform PRBS test mode on the Module [EN(Enable),DS(Disable)]
	--generator_pattern <pattern>	Set PRBS generator pattern [PRBS31(default),PRBS23,PRBS7,PRBS11,PRBS9,PRBS13,SSPR,SSPRQ]
	--swap_generator	Enable PAM4 MSB <-> LSB generator swapping (Optional)
	--invert_generator	Enable PRBS generator inversion (Optional)
	--generator_lanes <lanes>	PRBS generator lanes to set (one or more lane separated by comma) [0,1,2,3,4,5,6,7] (Optional - Default all lanes)
	--checker_pattern <pattern>	Set PRBS checker pattern [PRBS31(default),PRBS23,PRBS7,PRBS11,PRBS9,PRBS13,SSPR,SSPRQ]
	--swap_checker	Enable PAM4 MSB <-> LSB checker swapping (Optional)
	--invert_checker	Enable PRBS checker inversion (Optional)
	--checker_lanes <lanes>	PRBS checker lanes to set (one or more lane separated by comma) [0,1,2,3,4,5,6,7] (Optional - Default all lanes)
	--lane_rate <rate>	Set PRBS checker and generator lane rate [HDR(50G) (default),1.25G,SDR(2.5G),10.3125G,FDR(14G),EDR(25G),NDR(100G)]
	--show_diagnostic_info	Show PRBS diagnostic counters information
	--clear_diagnostic_info	Clear PRBS diagnostic counters
	--control_parameters	Show Module Control Parameters
	--tx_equalization <value>	Set Module Tx Input Equalization in dB [NE(No Equalization),1,2,3,4,5,6,7,8, 9,10,11,12]

	--rx_emphasis <value>	Set Module RX Output Emphasis in dB. for CMIS, pre-emphasis value will be set [NE(No Equalization),0.5,1,1.5,2,2.5,3,3.5,4,5,6,7]
	--rx_post_emphasis <value>	Set Module Rx Post Emphasis in dB [NE(No Equalization),1,2,3,4,5,6,7]
	--rx_amplitude <value>	Set Module Rx Output Amplitude [0(100-400mV),1(300-600mV),2(400-800mV),3(600-1200mV)]
--margin		Read the SerDes eye margins per lane
	--measure_time <time>	Measure time in seconds for single eye [10, 30, 60, 90, 120, 240, 480, 600 and 900] (Optional - Default 60 for PCIe and 30 for Network ports)
	--eye_select <eye_sel>	Eye selection for PAM4 [UP, MID, DOWN, ALL] (Default ALL)
	--lane <lane_index>	Run eye for specific lane index (Default all lanes)
--rx_error_injection		Enable the RX link deterioration
	--mixer_offset0 <value>	Fine change to the center of the eye [0x0 to 0x7ff]
	--mixer_offset1 <value>	Coarse change to the center of the eye [0x0 to 0x3ff]
	--show_mixers_offset	Show mixer offset 0 and mixer offset 1
--rx_fec_histogram		Provide histogram of FEC errors. The result is divided to bins. Each bin is holding different number of errored bit within FEC protected block
	--show_histogram	Show FEC errors histogram
	--clear_histogram	Clears FEC errors histograms
--pcie_error_injection		Start/show PCIe error injection
	--error_type <type>	PCIe error type [ABORT(0),BAD_DLLP_LCRC(1),BAD_TLP_LCRC(2),BAD_TLP_ECRC(3),ERR_MSG(4),MALFORMED_TLP(5),POISONED_TLP(6),UNEXPECTED_CPL(7),ACS_VIOLATION(8),SURPRISE_LINK_DOWN(100),RECEIVER_ERROR(101)]
	--error_duration <duration>	Error duration, depend on the error type
	--injection_delay <delay>	Delay in micro-seconds before applying the error (Optional)
	--error_parameters <params>	Comma-separated parameters for selected error type (param0,param1,param2,param3)
	--dbdf <dbdf>	Destination bus device function, e.g af:00.0 (Optional used for specific error type)
--yes		Non-interactive mode, answer yes to all questions
--link_training <link_training_mode>		Link Training Optimization Configuration EN(enable)/DS(disable)/EN_EXT(enable extra)
--phy_recovery <phy_recovery_mode>		Configure PHY Recovery EN(enable)/DS(disable)
	--recovery_type <type>	Configure Recovery Type host_serdes_feq/host_logic_re_lock
--set_link_peq <interval>		Set link Periodic Equalization (PEQ) interval [10-40000] uS. 0 means FW-Default Only multiples of 10 are supported.
--set_tx_precoding		Set Tx Pre-coding (EN[enable]/DS[disable])
--set_rx_precoding		Set Rx Pre-coding (EN[enable]/DS[disable])
--els_module <module_index>		Enable ELS mode and specify the module index to operate on

<code>--els_laser &lt;lasers&gt;</code>	Specify which lasers to operate on (separated by commas)
<code>--els_operation &lt;operation&gt;</code>	Specify the ELS operation to perform: FC(fiber_check) / LT(laser_tuning) / WL(laser_wl_tuning) / UP(laser_up) / [internal]F_UP(force_laser_up) / [internal]OFF(laser_off)
<code>--set_bkv_group &lt;group_id&gt;</code>	Set BKV Group Masks
<code>--lane &lt;lane_index&gt;</code>	lane index (Required)
<code>--bkv_rates</code>	BKV Rates separated by comma: [312.5M,53.125G,106.25G,200G,212.5G] (Optional)
<code>--bkv_roles</code>	BKV Roles [TLM,RLM,TCLM] (Optional)
<code>--bkv_mode_b_roles</code>	BKV Mode B Roles [PRIMARY,SECONDARY] (Optional)
<code>--set_bkv_entry &lt;group_id&gt;</code>	Set BKV Group Entry
<code>--bkv_entry &lt;entry_id&gt;</code>	BKV Entry ID (Required)
<code>--bkv_address &lt;address&gt;</code>	BKV Entry Address (Optional)
<code>--lane &lt;lane_index&gt;</code>	lane index (Required)
<code>--wdata &lt;wdata&gt;</code>	BKV Entry Write Data (Optional)
<code>--wmask &lt;wmask&gt;</code>	BKV Entry Write Mask (Optional)

#### Examples:

Get info of <device>, <port\_number>:

```
mlxlink -d <device> -p <port_number>
```

Get info of <device>, <port\_number> and BER Counters:

```
mlxlink -d <device> -p <port_number> -c
```

Get info of <device>, <port\_number> and Transmitter Parameters:

```
mlxlink -d <device> -p <port_number> --show_serdes_tx
```

Configure Port State:

```
mlxlink -d <device> -p <port_number> --port_state UP
```

Configure Port Speeds:

```
mlxlink -d <device> -p <port_number> --speeds 25G,50G,100G
```

Configure FEC:

```
mlxlink -d <device> -p <port_number> --fec RS
```

Configure Port for Physical Test Mode:

```
mlxlink -d <device> -p <port_number> --test_mode EN (--rx_prbs PRBS31 --rx_rate 25G --tx_prbs PRBS7 --tx_rate 10G --invert_rx_polarity --invert_tx_polarity)
```

### Configure Port for Physical Test Mode over Software Controlled Module:

```
mlxlink -d <device> -p <port_number> --test_mode EN (--rx_prbs PRBS31 --rx_rate 25G --tx_prbs PRBS7 --tx_rate 10G --invert_rx_polarity --invert_tx_polarity --force_tx_allowed --skip_power_good_check --sysfs_path /sys/module/sx_core/asic<asic_number>/module<module_number>)
```



During configuration of the device to enter test mode on software controlled module, mlxink will use the default sysfs path given by the supported OS (/sys/module/sx\_core/asic#/module#). Users can provide their own base path using `--sysfs_path`.  
If users are certain that the module is operating correctly, software controlled checks done by the tool can be skipped and enter test mode similar to standard firmware controlled modules.

### Perform PRBS Tuning:

```
mlxlink -d <device> -p <port_number> --test_mode TU
```



RX and TX lane rates for new devices include the PAM4 speeds (50G\_1X and 100G\_2X).  
eg: `mlxlink -d <device> --test_mode EN --rx_rate [normal speeds | 50G_1X | 100G_2X] --tx_rate [normal speeds | 50G_1X | 100G_2X]`



The PRBS pattern configured in PAM4 rates is PRBSQ.

### Start ELS Operation

```
mlxlink -d <device> --els_module <module_index> --els_laser <lasers> --els_operation FC
```

### Cable operations:

```
mlxlink -d <device> --cable [Options]
```

### Dump cable EEPROM pages:

```
mlxlink -d <device> --cable --dump
```

### Get cable DDM information:

```
mlxlink -d <device> --cable --ddm
```

### Read from cable:

```
mlxlink -d <device> --cable --read --page <page number> --offset <bytes offset> --length <number of bytes>
```

### Write to cable:

```
mlxlink -d <device> --cable --write <bytes separated by comma> --page <page number> --offset <bytes offset>
```

### Configure Transmitter Parameters (on lane, to database):

```
mlxlink -d <device> -p <port_number> --serdes_tx <polarity>,<ob_tap0>,<ob_tap1>,<ob_tap2>,<ob_bias>,<ob_preemp_mode>,<ob_reg>,<ob_leva> (--serdes_tx_lane <lane number>) (--database)
```

### Configure Transmitter Parameters for 16nm devices:

```
mlxlink -d <device> -p <port_number> --serdes_tx <pre_2_tap>,<pre_tap>,<main_tap>,<post_tap>,<ob_m2lp>,<ob_amp>
```

### Getting PCIe links info:

```
mlxlink -d /dev/mst/mt41682_pciconf0 --port_type PCIE --show_links
Valid PCIe Links
-----
Legend          : depth ,pcie_index ,node ,port ,bdf          ,link_status
Link 1          : 0      ,0      ,0      ,0      ,00:01:00.0      ,UP
Link 2          : 3      ,0      ,0      ,16     ,00:05:00.0      ,DOWN
Link 3          : 0      ,1      ,0      ,8      ,08:01:00.0      ,UP
Link 4          : 3      ,1      ,0      ,4      ,08:05:08.0      ,UP
..
```

To query information for a specific link, the depth, pcie\_index and node for the link must be specified:

```
mlxlink -d /dev/mst/mt41682_pciconf0 --port_type PCIE --depth 3 --pcie_index 0 --node 1 --show_serdes_tx --show_eye
PCIe Operational (Enabled) Info
-----
Depth, pcie index, node : 3, 0, 1
Link Speed Active (Enabled) : 8G-Gen 3 (16G-Gen 4)
Link Width Active (Enabled) : 2X (16X)

EYE Opening Info (PCIe)
-----
Physical Grade : 84, 84
Height Eye Opening [mV] : 1194, 1194
Phase Eye Opening [psec] : 84, 84

Serdes Tuning Transmitter Info (PCIe)
-----
Serdes TX parameters          : Pol ,tap0 ,tap1 ,tap2 ,bias ,preemp_mode ,reg ,leva
Lane 0                        : 0   ,21  ,92  ,7   ,15  ,1   ,10  ,9
Lane 1                        : 1   ,21  ,92  ,7   ,15  ,1   ,10  ,9
Lane 2                        : 0   ,21  ,92  ,7   ,15  ,1   ,10  ,9
Lane 3                        : 1   ,21  ,92  ,7   ,15  ,1   ,10  ,9
Lane 4                        : 0   ,21  ,92  ,7   ,15  ,1   ,10  ,9
Lane 5                        : 1   ,21  ,92  ,7   ,15  ,1   ,10  ,9
Lane 6                        : 0   ,21  ,92  ,7   ,15  ,1   ,10  ,9
Lane 7                        : 1   ,21  ,92  ,7   ,15  ,1   ,10  ,9
```

To print the output in JSON format:

```
mlxlink -d <device> --show_module --json
```

To show ports group map (for NVIDIA Quantum and NVIDIA Spectrum-2):

```
mlxlink -d<device> --show_tx_group_map 0
```

To assign ports to a specific group on NVIDIA Quantum and NVIDIA Spectrum-2:

```
mlxlink -d <device> --tx_group_map 1 -ports 1,2,3,5,4,8,7,8,9,10,11
```

To show histogram of FEC errors:


```
mlxlink -d /dev/mst/mt4125_pciconf0 --rx_fec_histogram --show_histogram
```

To clear histogram:

```
mlxlink -d /dev/mst/mt4125_pciconf0 --rx_fec_histogram --clear_histogram
```

### 3.6.15.2 Margin Scan Tool

The margin scan tool is used for scanning PCIe or Network ports (in EDR\25G or HDR\PAM4 speeds).

 If the margin scan fails with an "eye scan not completed" message, perform a reboot and run the scan again.

To enable the margin scan with a measure time of 10 seconds:

```
mlxlink -d <device> --port_type PCIE -margin -measure_time 10
```

To enable the margin scan for Multi-host or Socket Direct systems through:

- depth, pcie\_index and node:

```
mlxlink -d <device> --port_type PCIE -depth 0 -pcie_index 1 -node 0 -margin -measure_time 30
```

- The local port (can be shown by the `-show_links` command):

```
mlxlink -d <device> --port_type PCIE -port 1 -margin -measure_time 10
```

### 3.6.15.3 RX Error Injection

Allows modifying the Eye Center capability by changing the mixer\_offset0 (fine change) and mixer\_offset1 (coarse change) flags for 28nm products to produce RX errors.

#### 3.6.15.3.1 Flags Usage

- To change the mixers values:

```
mlxlink -d /dev/mst/mt4117_pciconf0 --rx_error_injection --mixer_offset0 0x200 --mixer_offset1 0x305
```

 Modifying `mixer_offset0` and `mixer_offset1` flags can change the Eye Center and might cause link degradation.

- To query the mixers values:

```
mlxlink -d /dev/mst/mt4117_pciconf0 --rx_err r_injection --show_mixers_offset
```

## 3.6.15.4 Rx-to-Tx Loopback Mode Activation

This capability enables Rx-to-Tx remote loopback mode.

### 3.6.15.4.1 Prerequisite

- The port should be disabled and configured with Force mode [Disable the Auto-negotiation]
- Remote loopback is supported for 25G/50G per lane speed
- If the NIC has 2 ports, both ports should be configured with the same speed

To enable Rx-to-Tx remote loopback mode:

1. Disable the port.

```
mlxlink -d /dev/mst/mt4123_pciconf0 -port_state DN
```

2. Configure the link mode to Force [Disable the Auto-negotiation].

```
mlxlink -d /dev/mst/mt4123_pciconf0 --speeds 100G --link_mode_force
```

3. Configure loopback with remote loopback [RM].

```
mlxlink -d /dev/mst/mt4123_pciconf0 -loopback RM
```

4. Enable the port.

```
mlxlink -d /dev/mst/mt4123_pciconf0 -port_state UP
```

To return to the normal link operation:

1. Disable the port.

```
mlxlink -d /dev/mst/mt4123_pciconf0 -port_state DN
```



Possible common reasons for failing to bring the port down:

- Multi Host
- Socket Direct (SD)
- Wrong configurations (for example KEEP\_ETH\_LINK\_UP\_Px is enabled)
- Port management is enabled

2. Clear the loopback configuration using the "NO loopback" option.

```
mlxlink -d /dev/mst/mt4123_pciconf0 -loopback NO
```

3. Enable the port.

```
mlxlink -d /dev/mst/mt4123_pciconf0 -port_state UP
```

### 3.6.15.5 Module PRBS Test Mode

The module PRBS test mode can be performed by using the new flags under the `--cable` command.

#### Notes

- This feature supports Active/Optical CMIS modules only
- Either the media or host side can run with PRBS mode
- To enable the PRBS test mode, the module should be plugged in and active

#### 3.6.15.5.1 Enabling\Disabling The Module PRBS Test Mode

To enable the module PRBS test mode, the side of the module should be selected using the `--prbs_select` flag. After providing the `--cable` flag, either the HOST or the MEDIA side should be selected, so the `--prbs_mode <EN\DS>` can be used to enable or disable the PRBS test mode process.

For example, the following command will enable the PRBS test mode on the HOST side of the module:

```
mlxlink -d /dev/mst/mt53104_pciconf0 --port 3 --cable --prbs_select HOST --prbs_mode EN
```

The command above will put the HOST side of the module in PRBS test mode with default Checker and Generator parameters.

The Checker and Generator parameters can be overridden while enabling the PRBS test mode according to their related flags in the help menu:

```
mlxlink -d /dev/mst/mt53104_pciconf0 --port 3 --cable --prbs_select HOST --prbs_mode EN --checker_pattern PRBS13 --invert_checker --generator_pattern PRBS31 --swap_generator --lane_rate HDR
```

To disable the PRBS test mode, the following command can be executed:

```
mlxlink -d /dev/mst/mt53104_pciconf0 --port 3 --cable --prbs_select HOST --prbs_mode DS
```

#### 3.6.15.5.2 Getting Module Information

Some of the module information can be presented using the `--show_module` flag.

For example, the following command will present the module information for the module connected to port 1 on the switch:

```
mlxlink -d /dev/mst/mt53120_pci_cr0 --port 1 --show_module

Module Info
-----
Identifier           : OSFP
Compliance           : IB HDR,200GBASE-SR4
Cable Technology     : 850 nm VCSEL
Cable Type           : Optical Module (separated)
OUI                  : Nvidia
Vendor Name          : NVIDIA
Vendor Part Number   : MMA4U00-HS
Vendor Serial Number : MT2134FT06348
```

```

Rev : A3
Wavelength [nm] : 850
Transfer Distance [m] : 10
Attenuation (5g,7g,12g,25g,53g) [dB] : N/A
FW Version : 40.55.0
Digital Diagnostic Monitoring : Yes
Power Class : 12.0 W max
CDR RX : ON,ON,ON,ON,ON,ON,ON,ON,ON,ON
CDR TX : ON,ON,ON,ON,ON,ON,ON,ON,ON,ON
LOS Alarm : N/A
Temperature [C] : 36 [-10..80]
Voltage [mV] : 3280 [3100..3500]
Bias Current [mA] : 7.460,7.490,7.292,7.348,7.430,7.200,7.392,7.300 [5.492..8.5]
Rx Power Current [dBm] : -40,-40,-40,-40,-40,-40,-40,-40 [-13.372..5.4]
Tx Power Current [dBm] : 0.473,0.477,0.282,0.434,0.766,0.645,0.500,0.500 [-11.427..5.4]
Intra-ASIC Latency [ns] : N/A
Module Datapath Latency [ns] : N/A
Round Trip Latency [ns] : N/A
SNR Media Lanes [dB] : N/A
SNR Host Lanes [dB] : N/A
IB Cable Width : N/A
Memory Map Revision : 64
Linear Direct Drive : 0
Cable Breakout : Unspecified
SMF Length : N/A
MAX Power : 48
Cable Rx AMP : 1
Cable Rx Emphasis (Pre) : 0
Cable Rx Post Emphasis : 0
Cable Tx Equalization : 0
Wavelength Tolerance : 15.0nm
Module State : Ready state
DataPath state [per lane] :
DPActivated,DPActivated,DPActivated,DPActivated,DPActivated,DPActivated,DPActivated,DPActivated
Rx Output Valid [per lane] : 0,0,0,0,0,0,0,0
Nominal bit rate : N/A
Rx Power Type : Average power
Manufacturing Date : 24_08_21
Active Set Host Compliance Code : IB HDR
Active Set Media Compliance Code : 200GBASE-SR4
Error Code Response : ConfigUndefined
Module FW Fault : 0
DataPath FW Fault : 0
Tx Fault [per lane] : 0,0,0,0,0,0,0,0
Tx LOS [per lane] : 0,0,0,0,0,0,0,0
Tx CDR LOL [per lane] : 0,0,0,0,0,0,0,0
Rx LOS [per lane] : 0,0,0,0,0,0,0,0
Rx CDR LOL [per lane] : 1,1,1,1,1,1,1,1
Tx Adaptive EQ Fault [per lane] : 0,0,0,0,0,0,0,0

```

```
mlxlink -d /dev/mst/mt53104_pciconf0 --port 3 --cable --prbs_select HOST --clear_diagnostic_info
```

### 3.6.15.5.3 PRBS Diagnostic Counters Information

After performing the PRBS test mode, the module counters can be queried by using the following command:

```
mlxlink -d /dev/mst/mt53104_pciconf0 --port 3 --cable --prbs_select HOST --show_diagnostic_info
```

The module PRBS test mode counters can be cleared by using the following command, which will clear the diagnostic counters on the HOST side only:

```
mlxlink -d /dev/mst/mt53104_pciconf0 --port 3 --cable --prbs_select HOST --clear_diagnostic_info
```

### 3.6.15.6 Module Control Parameters

Some of the module parameters can be controlled by mlxlink after providing the `--control_parameter` flag, which can be executed under the `--cable` flag.

The possible parameters can be controlled as follows:

- Reading and configuring Tx Equalization
- Reading and configuring Rx Emphasis (PreCursor & PostCursor)
- Reading and configuring Rx Amplitude

### Notes

- To apply the changes, the link should be disabled first
- After configuring a new parameter, the link should be raised again to allow the firmware to load the new configuration
- Cable control parameters are valid for active\optical modules only

### 3.6.15.6.1 Querying and Configuring The Module Control Parameters

To query the currently configured module control parameters, the `--control_parameters` flag can be used under the `--cable` flag as follows:

```
mlxlink -d /dev/mst/mt53104_pciconf0 --cable --control_parameters
...
Module Control Parameters
-----
TX Equalization           : 1dB
RX Emphasis (pre)        : 2.5dB
RX Post Emphasis         : No Equalization
RX Amplitude              : 600-1200 mV (P-P)
```

To configure the module control parameters, the following command can be executed:

```
mlxlink -d /dev/mst/mt53104_pciconf0 --cable --control_parameters --tx_equalization 2 --rx_amplitude 1
```

### 3.6.15.7 Tool Usage with NIC vs. Switch (-p Flag)

When using the `mlxlink` tool with an adapter card, notice that the "label\_port" `-p` flag should not be used. To address different ports, please use different MST devices.

For example:

To address port 1 when using ConnectX-4:

```
mlxlink -d /dev/mst/mt4115_pciconf0
```

To address port 2, use:

```
mlxlink -d /dev/mst/mt4115_pciconf0.1
```



- Any `mlxlink` command for a switch should include the "`-p`" flag to address the specific port in the switch
- When working with an adapter card, if an MTUSB is used for communication with the NVIDIA NIC, to address port 2, use `mlxlink -d /dev/mst/mt4115_pciconf0 --gvmi_address <0xAddress>`

### 3.6.15.8 Tool Usage on NVIDIA Quantum HDR Switch Systems with Split Ports

If the split port number is not provided by the ibdiagnet tool, to use mlxlink on NVIDIA Quantum HDR based switch systems split ports, run:

```
mlxlink -d lid-<LID> -p <formula>
```

Formula:

In case of 2X port:

- 1- port\_num = round\_down[(Iblinkinfo\_port\_num + 1)\*0.5]
- 2- if (Iblinkinfo\_port\_num + 1) modulo 2 =1 then append '/2' to port\_num

In case of 4X port, use only item #1 above.

Example:

```
43 23[ ] == ( 2X 53.125 Gbps Active/ LinkUp) ==> mlxlink -d lid-43 -p 12
43 24[ ] == ( 2X 53.125 Gbps Active/ LinkUp) ==> mlxlink -d lid-43 -p 12/2
```

### 3.6.15.9 Tool Usage on NVIDIA Quantum-2 NDR Switch Systems

In NVIDIA Quantum-2 NDR switch systems, there are 32-OSFP cages (8x), where each one holds 2 (4x) ports instead of 1, and each port can be accessed by providing the cage number and the port in the cage - "Cage/Port".

```
mlxlink -d <mst device> -p <Cage>/<Port>
```

If the split profile is ready, it is possible to access the split ports by providing the number of split to the port flag, e.g.:

- To access the main port of 15/2:

```
mlxlink -d <mst device> -p 15/2
```

- To access the split port of 15/2:

```
mlxlink -d <mst device> -p 15/2/2
```

### 3.6.15.10 PCIe

#### 3.6.15.10.1 Link Speed and Width

For PCIe link speed and width, use the following flag: `--port_type PCIE`.

```
PCIe Operational (Enabled) Info
-----
Depth, pcie index, node      : [Depth, pcie index, node]
Link Speed Active (Enabled) : [Freq - Gen]
```

```
Link Width Active (Enabled) : [Width]
```

### 3.6.15.10.2 PCIe Switch

When using NVIDIA ConnectX-5 and newer devices, the PCIe interface can be configured for a PCIe switch. When the PCIe switch is enabled, the depth, pcie\_index and node parameters are needed in order to specify the PCIe port from which the requested information (such as counters or eye info) is gathered.

Parameters	Description
Depth	This parameter defines the number of layers from the Root Complex to the specific port. <ul style="list-style-type: none"><li>• For NVIDIA ConnectX adapter cards multi-host mode, the depth should be set to 0.</li><li>• For NVIDIA BlueField/BlueField-2 JBoF, the depth should be set to 3.</li></ul>
Pcie_index	This parameter defines the root complex ID or host index. <ul style="list-style-type: none"><li>• For NVIDIA ConnectX adapter cards multi-host mode, the pcie_index is the host index (0-3).</li><li>• For NVIDIA BlueField/BlueField-2 JBoF, the pcie_index is always 0.</li></ul>
Node	This parameter defines the specific PCIe port. <ul style="list-style-type: none"><li>• For NVIDIA ConnectX adapter cards multi-host mode, the node is always 0 for each host_index.</li><li>• For NVIDIA BlueField JBoF mode, this parameter range is 0x0-0xF, which amounts for up to 16 possible ports for BlueField JBoF.</li><li>• For NVIDIA BlueField-2, this parameter's range is 0x0-0x7.</li></ul> <b>Note:</b> For NVIDIA BlueField/BlueField-2 SmartNIC mode, the PCIe link information can only be gathered from the external host. The PCIe interface status cannot be retrieved from the Arm side. When retrieving the PCIe link information from the external host, there is no need to specify the depth, pcie_index and node.

#### Example: NVIDIA BlueField JBoF Mode

```
# mlxlink -d /dev/mst/mt41682_pciconf0 --port_type pcie --depth 3 --pcie_index 0 --node 4 -c

PCIe Operational (Enabled) Info
-----
Depth, pcie index, node      : 3, 0, 4
Link Speed Active (Enabled)  : 8G-Gen 3 (16G-Gen 4)
Link Width Active (Enabled)  : 2X (2X)

Management PCIe Timers Counters Info
-----
dl down                       : 0

Management PCIe Performance Counters Info
-----
RX Errors                     : 0
TX Errors                     : 0
CRC Error dllp                 : 0
CRC Error tlp                  : 0
```

### 3.6.15.10.3 Link Counters

For PCIe counters information, use the `--port_type PCIE -c` flag.

```
Management PCIe Timers Counters Info
-----
dl down                       : [link down counter]

Management PCIe Performance Counters Info
-----
RX Errors                     : [Rx Errors]
TX Errors                     : [Tx Errors]
CRC Error dllp                 : [CRC Errors dllp]
CRC Error tlp                  : [CRC Errors tlp]
```

- RX Errors: indicate the number of transitions to recovery required due to framing errors and CRC (dlp and tlp) errors.
- TX Errors: indicate the number of transitions to recovery required due to EIEOS and TS errors.
- CRC Error dllp: indicate CRC error in Data Link Layer Packets.
- CRC Error tlp: indicate CRC error in Transaction Layer Packet.

Example:

```
# mlxlink -d /dev/mst/mt4123_pciconf0 --port_type PCIE -c
PCIE Operational (Enabled) Info
-----
Depth, pcie index, node      : 0, 0, 0
Link Speed Active (Enabled)  : 16G-Gen 4 (16G-Gen 4)
Link Width Active (Enabled)  : 16X (16X)

Management PCIE Timers Counters Info
-----
dl down                      : 3

Management PCIE Performance Counters Info
-----
RX Errors                    : 0
TX Errors                    : 16
CRC Error dllp               : 0
CRC Error tlp                : 0
```

### 3.6.15.10.4 Link Eye Opening and Grade

For PCIe link physical grade and eye opening information, use the `--port_type PCIE -e` flag.

```
EYE Opening Info (PCIE)
-----
Physical Grade : [Grade0, Grade1, Grade2, Grade3, Grade4, Grade5, Grade6, Grade7, Grade8, Grade9, Grade10, Grade11,
Grade12, Grade13, Grade14, Grade15]
Height Eye Opening [mV] : [Height0, Height1, Height2, Height3, Height4, Height5, Height6, Height7, Height8,
Height9, Height10, Height11, Height12, Height13, Height14, Height15]
Phase Eye Opening [psec] : [Phase0, Phase1, Phase2, Phase3, Phase4, Phase5, Phase6, Phase7, Phase8, Phase9,
Phase10, Phase11, Phase12, Phase13, Phase14, Phase15]
```

Example:

```
# mlxlink -d /dev/mst/mt4123_pciconf0 --port_type PCIE -e
PCIE Operational (Enabled) Info
-----
Depth, pcie index, node      : 0, 0, 0
Link Speed Active (Enabled)  : 16G-Gen 4 (16G-Gen 4)
Link Width Active (Enabled)  : 16X (16X)

EYE Opening Info (PCIE)
-----
Physical Grade                : 57279, 56340, 59340, 61824, 55140, 60501, 61530, 57392, 61573, 58930, 62752,
60421, 57188, 59796, 60066, 60847
Height Eye Opening [mV]      : 292, 288, 314, 325, 278, 310, 319, 299, 316, 318, 343,
323, 310, 311, 335, 318
Phase Eye Opening [psec]     : 30, 30, 30, 30, 30, 30, 30, 30, 30, 30, 28, 28,
28, 28, 30, 28, 30
```

### 3.6.15.10.5 Pass/Fail Criteria

#### 3.6.15.10.5.1 SLRED

```
mlxlink -d [device] --port_type PCIE --margin
```

ConnectX-4/ConnexX-4 Lx/ConnectX-5/Bluefield

Gen3

<b>Gen3</b>	
Eye width	f(Height, Width)
0 < Eye width < 50	FAIL
50 < Eye width < 60	pass external, fail internal
60 < Eye width	PASS

Gen4

<b>Gen4</b>	
Eye Margin	f(Height, Width)
0 < Eye Grade < 1500	FAIL
1500 < Eye Grade < 4500	Pending on BER criteria
4500 < Eye Grade	PASS

ConnectX-6/ConnectX-6 Dx/ConnectX-6 Lx/BlueField-2

Gen3

<b>Gen3</b>	
Eye Grade	FOM(figure of merit)
0 < Eye Grade < 700	FAIL
700 < Eye Grade < 2300	Pending on BER criteria
2300 < Eye Grade	PASS

Gen4

<b>Gen4</b>	
Eye Margin	FOM
0 < Eye Grade < 69	FAIL
70 < Eye Grade < 99	Pending on BER criteria
100 < Eye Grade	PASS

Gen5

<b>Gen4</b>	
Eye Margin	FOM
0 < Eye Grade < 49	FAIL
50 < Eye Grade < 69	Pending on BER criteria
70 < Eye Grade	PASS

ConnectX-7/BlueField-3

### Gen4/Gen3

<b>Gen4</b>	
Last FOM	Eye Margin
0 < Last FOM < 69	FAIL
70 < Last FOM < 99	Pending on BER criteria
100 < Last FOM	PASS

### Gen5

<b>Gen5</b>	
Last FOM (figure of merit)	Eye Margin
0 < Last FOM < 65	FAIL
65 < Last FOM < 95	Pending on BER criteria
95 < Last FOM	PASS

### NVLink5/ConnectX-8/ConnectX-9

#### Gen3

<b>Gen3</b>	
Last FOM (figure of merit)	Eye Margin
0 < Last FOM < 1499	FAIL
1500 < Last FOM < 1881	BER 1e-15
1881 < Last FOM	PASS

#### Gen4

<b>Gen4</b>	
Last FOM (figure of merit)	Eye Margin
0 < Last FOM < 1499	FAIL
1500 < Last FOM < 1881	BER 1e-15
1881 < Last FOM	PASS

#### Gen5

<b>Gen5</b>	
Last FOM (figure of merit)	Eye Margin
0 < Last FOM < 999	FAIL
1000 < Last FOM < 1400	BER 1e-15
1400 < Last FOM	PASS

#### Gen6

Gen6	
Last FOM(figure of merit)	Eye Margin
0 < Last FOM < 200	FAIL
200< Last FOM < 400	FBER 1e-9
400< Last FOM	PASS

## PCIE Error Injection

This test feature allows errors injection over the PCI links. It is used to verify that the system can handle the PCIe errors, which rarely occur in regular usage.

The ConnectX-7 device includes testability features that can be configured to act as an error injection 'exerciser' in order to test other components in the system. This is supported when the ConnectX-7 is used as a PCIe switch.



- This is a PCIe related feature that should be run over PCIe links only ( `--port_type PCIE` ) with specific depth, PCIe index and node (DPN)
- If the DPN is not provided, the tool will take the default values - 0,0 and 0, respectively
- The mapping between the BDF and its DPN can be found by executing the `show_links` command (see example below)

### 3.6.15.10.5.2 Error Types

ID	Error Type	Description	Unit	Additional Parameters ( <code>--errors_parameters</code> )	Advanced Error Reporting Flag Set by This Error
0	ABORT	Cancels the current pending error, if exists.	NA	NA	NA
1	BAD_DLLP_LCRC	Flips a bit in the LCRC of the next " <code>error_duration</code> " DLLPs that are transmitted through the port.	Packets	NA	Bad DLLP Status
2	BAD_TLP_LCRC	Flips a bit in the LCRC of the next " <code>error_duration</code> " TLPs that are transmitted through the port. The packets are VDM TLPs that are sent by the port to the destination BDF - " <code>dbdf</code> ".	Packets	NA	Bad TLP Status

3	BAD_TLP_ECRC	Flips a bit in the ECRC of the next “ <b>error_duration</b> ” TLPs that are transmitted through the port. The packets are VDM TLPs that are sent by the port to the destination BDF - “ <b>dbdf</b> ”.	Packets	NA	ECRC Error Status
4	ERR_MSG	Sends an error signaling message to the RC.	Packets	Parameter 0: message type 0 - Correctable 1 - Nonfatal 2 - Fatal	ERR_COR Received / Non-Fatal Error Messages Received / Fatal Error Messages Received
5	MALFORMED_TLP	Sends an “ <b>error_duration</b> ” PM_ACTIVE_STATE_NACK message to the destination BDF - “ <b>dbdf</b> ” with TC=1 instead of 0.	Packets	NA	Malformed TLP Status
6	POISONED_TLP	Sends an “ <b>error_duration</b> ” VDMs with data to the destination BDF - “ <b>dbdf</b> ” with EP = 1.	Packets	NA	Poisoned TLP Received
7	UNEXPECTED_CPL	Sends “ <b>error_duration</b> ” completions to the destination BDF - “ <b>dbdf</b> ” with 0xff tag.	Packets	NA	Unexpected Completion Status
8	ACS_VIOLATION	Sends “ <b>error_duration</b> ” VDMs to the destination BDF - “ <b>dbdf</b> ” with source_bdf=0.	Packets	NA	ACS Violation Status
100	SURPRISE_LINK_DOWN	Sets a port state to DETECT.	NA	NA	Surprise Down Error Status
101	RECEIVER_ERROR	Sends a clock instead of data for “ <b>error_duration</b> ” usecs. A value of 0 in ‘ <b>error_duration</b> ’ means that this error must be toggled by the firmware as fast as possible.	uSec	NA	Receiver Error Status

### 3.6.15.10.5.3 PCIe Error Injection Inputs

The following values should be provided in the error injection command line. Some values may be optional according to the error type.

Input	Command Line Flag	Description	Obligatoriness	Default
Error Type	-- error_type	Error type according to the table above.	Yes	-

Error Duration	<code>--duration</code>	The minimal number of packets with this error that will be sent, or the minimal amount of time that this error state would be applied.	No	1
Injection Delay	<code>--injection_delay</code>	Delay in microseconds before the error is applied. This allows time for the completion to return to the tool caller correctly. A higher value can be used to allow the system to get to a lower power state.	No	0
Destination BDF	<code>--dbdf</code>	Destination BDF. Relevant for some of the errors that require packet generation. See error table above.	No	0:0 0.0
Additional Parameters	<code>--errors_parameters</code>	Additional parameters according to the error type. See error table above.	No	0

Mlxlink will trigger the firmware to start the error injection process by providing the `--pcie_error_injection` flag with the requested configuration parameters.

Note that the command returns immediately, but the error injection can take longer to complete (according to the error duration and injection delay inputs).

When the tool is run without the parameters above, it will query the error injection state - Whether it is ready to start a new error injection, or it is in the middle of the previous injection.

#### 3.6.15.10.5.4 Usage Example

Start the process by performing error injection with error type UNEXPECTED\_CPL.

This example shows how to start the error injection by sending 5 unexpected completion packets. The packets (of error type UNEXPECTED\_CPL (id 7)) are directed from BDF 05:00.0 to BDF 06:0.0 after 500µs of sending the command in the following environment:

PCIe Component	BDF
Root port	00:01.0
(exerciser) PCIe Switch Upstream port	01:00.0
(exerciser) PCIe Switch Downstream port	05:00.0
Endpoint	06:00.0

To get the related depth, pcie\_index and node for the specific BDF 05:00.0, the `show_links` command should be executed as follows:

```

Show Links

mlxlink -d /dev/mst/mt4129_pciconf0 --port_type PCIE --show_links

Valid PCIe Links
-----
Legend          : depth ,pcie_index ,node ,port ,bdf
Link 1          : 0 ,0 ,0 ,0 ,01:00.0
Link 2          : 3 ,0 ,0 ,60 ,05:00.0

```

In this case, the depth, pcie\_index, and node flags for the downstream port should be 3, 0, and 0, respectively.

Then, the following command can be executed to start the process:

#### Start PCIe Error Injection

```
mlxlink -d /dev/mst/mt4129_pciconf0 --port_type PCIe --depth 3 --pcie_index 0 --node 0 --pcie_error_injection --
error_type UNEXPECTED_CPL --error_duration 5 --dbdf 06:00.0 --injection_delay 500

PCIe Operational (Enabled) Info
-----
Depth, pcie index, node      : 3, 0, 0
Link Speed Active (Enabled)  : 16G-Gen 4 (16G-Gen 4)
Link Width Active (Enabled)  : 16X (16X)

PCIe error injection might cause a PCIe bus failures or a system hang
Do you want to continue? yes
Starting PCIe Error Injection...
```

#### Query Error Injection Status

After sending the configuration command, the progress of the process can be checked by executing the tool with the `pcie_error_injection` flag only:

#### Query PCIe Error Injection Status 1

```
mlxlink -d /dev/mst/mt4129_pciconf0 --port_type PCIe --depth 3 --pcie_index 0 --node 0 --pcie_error_injection

PCIe Operational (Enabled) Info
-----
Depth, pcie index, node      : 3, 0, 0
Link Speed Active (Enabled)  : 16G-Gen 4 (16G-Gen 4)
Link Width Active (Enabled)  : 16X (16X)

PCIe Error Injection Info
-----
Error Injection Status       : In progress
Error Injection Type         : UNEXPECTED_CPL
Error Injection Duration     : 5 Packets
```

Once the process is complete, the output will be changed to "ready". This means that another error injection request can be submitted:

#### Query PCIe Error Injection Status 2

```
mlxlink -d /dev/mst/mt4129_pciconf0 --port_type PCIe --depth 3 --pcie_index 0 --node 0 --pcie_error_injection

PCIe Operational (Enabled) Info
-----
Depth, pcie index, node      : 3, 0, 0
Link Speed Active (Enabled)  : 16G-Gen 4 (16G-Gen 4)
Link Width Active (Enabled)  : 16X (16X)

PCIe Error Injection Info
-----
Error Injection Status       : Ready
Error Injection Type         : N/A
Error Injection Duration     : N/A
```

## 3.6.16 mlxfwstress Utility



The tool can support new devices only once the tool is upgraded to its latest version.

mlxfwstress enables/disables various firmware stress flows. It can work in multiple modes:

- Enable/disable a specific set of stress types
- Clear all stress types
- Random mode:
  - Single mode - choose one stress type in each iteration and enable/disable it
  - Wild-mode- choose multiple stress types in each iteration and enable/disable them

Each time a stress type is chosen in a random iteration, the opposite operation is done on it (e.g., if a stress type is turned on, in the next iteration it will be turned off and vice versa).

- Toggle mode:
  - Turns on and off the list of stress types alternating. Can be used with iterations.



To disable a stressor while in toggling mode, first you must disable the mlxfwstress tool, and only after that disable the stressor.

- Clear semaphore:  
Note: This functionality is supported in ConnectX-3 Pro adapter cards only.

### 3.6.16.1 mlxfwstress Synopsis

```
# mlxfwstress [-d|--dev <DeviceName>] [-h|--help] [-v|--version] [-o|--operation <Operation>] [--rand-mode <Random mode>] [-t|--stress-type <Stress type>] [--iterations <Iterations>] [--stress-delay <Stress delay>] [--max-rand-on <Max rand on>] [--hang-type <Hang type>] [--seed <seed>] [--toggle-time <x,y>]
```

where:

-d --dev <DeviceName>	Perform operation for a specified device
-h --help	Show this message and exit
-v --version	Show the executable version and exit
-o --operation <Operation>	Choose operation: on, off, clear_all, random query, clear_semaphore
--rand-mode <Random mode>	Choose a random mode: single, wild
-t --stress-type <Stress type>	Specify a list of stress types separated by comma. ( <i>See Stress Types.</i> )
--iterations <Iterations>	Specify the number of iterations.
--stress-delay <Stress delay>	Specify the stress delay in seconds (can be float). Note: Some stress flows may take more time. Recommended values: 0-1
--max-rand-on <Max rand on>	Specify the maximal time a stress is allowed to be on in random mode in seconds. Recommended values (0,1] Default is 1
--hang-type <Hang type>	Specify a list of hang types separated by comma. ( <i>See Hang Types.</i> )
--seed <seed>	Specify the seed for the random.
--toggle-time <x,y>	Toggle time after off, both in seconds (can be float). If y is not supplied the tool will use equal values for x and y

## 3.6.16.2 Stress Types

### 3.6.16.2.1 ConnectX-4/ConnectX-4 Lx/ConnectX-5 Adapter Cards Stress Types

The following are the stress types available for ConnectX-4/ConnectX-4 Lx/ConnectX-5 adapter cards:

Category	Stress Type	Description	Notes
Transparent	PAUSE_STORM_GENERATION	Generates pause frames from the device toward the network	
	INVALIDATE_INTERNAL_CACHE_RX_1	Invalidates STE cache	
	INVALIDATE_INTERNAL_CACHE_RX_2	Invalidates qp L0 cache (RX)	
	INVALIDATE_INTERNAL_CACHE_RX_3	Invalidates dct L0 cache (RX)	
	INVALIDATE_INTERNAL_CACHE_RX_4	Invalidates scatter list cache in RX	
	INVALIDATE_INTERNAL_CACHE_CQ	Invalidates CQC cache	
	INVALIDATE_INTERNAL_CACHE_SX1	Invalidates SXDC cache	
	INVALIDATE_INTERNAL_CACHE_RX_5	Invalidates LDB cache	
	INVALIDATE_INTERNAL_CACHE_GENERAL_1	Invalidates RO caches	
	INVALIDATE_INTERNAL_CACHE_SX2	Invalidates pkey cache (SX)	
	INVALIDATE_INTERNAL_CACHE_SX3	Invalidates guid cache (SX)	
	INVALIDATE_INTERNAL_CACHE_QP	Invalidates QPC (main QP cache unit)	
Hang FW/HW	PACKET_DROP	Drops N packets on portx	This type requires the following extra flags: <ul style="list-style-type: none"> <li>num_of_packets - 8 bit (max 15)</li> <li>port_num - 8 bit (should be 1 or 2)</li> </ul>

### 3.6.16.2.2 ConnectX-3 Pro Adapter Cards Stress Types

The following are the stress types available for ConnectX-3 Pro adapter cards:



Stressors in "Transparent" category that are active for more than 100 msec, may cause resiliency.

Category	Stress Type	Description
Transparent	STOP_CE_INSTAGE_EQE	Stops sending EQEs created by the hardware (not the ones created by the firmware).
	STOP_EDBH	Stops the handling of external doorbells.

	STOP_IDBH	Stops the handling of internal doorbells.
	STOP_QPC_MISS_MAC_HINE_0 STOP_QPC_MISS_MAC_HINE_1 STOP_QPC_MISS_MAC_HINE_2 STOP_QPC_MISS_MAC_HINE_3	Spots reading a QPC from the ICM on a miss-blocking hardware/firmware that accesses the QPC
	LOCK_CEGW	Locks the CQE gateway.
	LOCK_OBGW_TPT LOCK_OBGW_TCU LOCK_OBGW_SXD	Locks the OBGW (access to the host memory gateway).
	LOCK_QPCGW_RX	Locks QPCGW.
	LOCK_SEMAPHORE_IPC_RX0 LOCK_SEMAPHORE_IPC_RX1 LOCK_SEMAPHORE_IPC_LDB LOCK_SEMAPHORE_IPC_SX1	Locks the IPC semaphore.
	INVALIDATE_CACHES	Invalidates caches.
Performance	STOP_SXP_VL_ARB_PORT1 STOP_SXP_VL_ARB_PORT2	Stops transmission of packets to the wire. Causes head-of-line packet drop (HLL) if enabled.
	RX_BACKPRESSURE	Stops the RX pipe - back-pressure to wire- sending tx pauses.
	DROP_PACKETS_TX	Drops packets on the TX side.

### 3.6.16.2.3 Turning On Stress Types

To turn on a specific stress type:

```
mlxfwstress -d mt4103_pciconf0 -o on -t STOP_CE_INSTAGE_EQE
-----
Operation: [ON]
-----
Turning ON stress type: stop_ce_instage_eqe -PASSED
```

To turn on a set of stress types:

```
mlxfwstress -d mt4103_pciconf0 -o on -t STOP_CE_INSTAGE_EQE,STOP_QPC_MISS_MACHINE_3,LOCK_SEMAPHORE_IPC_RX1
-----
Operation: [ON]
-----
Turning ON stress type: stop_ce_instage_eqe -PASSED
Turning ON stress type: stop_qpc_miss_machine_3 -PASSED
Turning ON stress type: lock_semaphore_ipc_rx1 -PASSED
```

To turn on all the available stress types:

```
mlxfwstress -d mt4119_pciconf0 -t ALL -o on
Random seed: [1587969653]
-----
Operation: [ON]
```

```

-----
Turning ON stress type: INVALIDATE_INTERNAL_CACHE_CQ -PASSED
Turning ON stress type: INVALIDATE_INTERNAL_CACHE_GENERAL_1 -PASSED
Turning ON stress type: INVALIDATE_INTERNAL_CACHE_QP -PASSED
Turning ON stress type: INVALIDATE_INTERNAL_CACHE_RX_1 -PASSED
Turning ON stress type: INVALIDATE_INTERNAL_CACHE_RX_2 -PASSED
Turning ON stress type: INVALIDATE_INTERNAL_CACHE_RX_3 -PASSED
Turning ON stress type: INVALIDATE_INTERNAL_CACHE_RX_4 -PASSED
Turning ON stress type: INVALIDATE_INTERNAL_CACHE_RX_5 -PASSED
Turning ON stress type: INVALIDATE_INTERNAL_CACHE_SX1 -PASSED
Turning ON stress type: INVALIDATE_INTERNAL_CACHE_SX2 -PASSED
Turning ON stress type: INVALIDATE_INTERNAL_CACHE_SX3 -PASSED

```

### 3.6.16.2.4 Turning Off Stress Types

To turn off a specific stress type:

```

mlxfwstress -d mt4103_pciconf0 -o off -t STOP_CE_INSTAGE_EQE
-----
Operation: [OFF]
-----
Turning OFF stress type: stop_ce_instage_eqe -PASSED

```

To turn off a set of stress types:

```

mlxfwstress -d mt4103_pciconf0 -o off -t STOP_CE_INSTAGE_EQE,STOP_QPC_MISS_MACHINE_3,LOCK_SEMAPHORE_IPC_RX1
-----
Operation: [OFF]
-----
Turning OFF stress type: stop_ce_instage_eqe -PASSED
Turning OFF stress type: stop_qpc_miss_machine_3 -PASSED
Turning OFF stress type: lock_semaphore_ipc_rx1 -PASSED

```

### 3.6.16.2.5 Querying the Stress Types

To query the state of all stress types:

```

mlxfwstress -d mt4117_pciconf0 -o query -t ALL
-----
Operation: [QUERY]
-----
Querying stress type: INVALIDATE_INTERNAL_CACHE_CQ -ENABLED
Querying stress type: INVALIDATE_INTERNAL_CACHE_GENERAL_1 -ENABLED
Querying stress type: INVALIDATE_INTERNAL_CACHE_QP -ENABLED
Querying stress type: INVALIDATE_INTERNAL_CACHE_RX_1 -ENABLED
Querying stress type: INVALIDATE_INTERNAL_CACHE_RX_2 -ENABLED
Querying stress type: INVALIDATE_INTERNAL_CACHE_RX_3 -ENABLED
Querying stress type: INVALIDATE_INTERNAL_CACHE_RX_4 -ENABLED
Querying stress type: INVALIDATE_INTERNAL_CACHE_RX_5 -NOT SUPPORTED
Querying stress type: INVALIDATE_INTERNAL_CACHE_SX1 -ENABLED
Querying stress type: INVALIDATE_INTERNAL_CACHE_SX2 -ENABLED
Querying stress type: INVALIDATE_INTERNAL_CACHE_SX3 -ENABLED

```

## 3.6.16.3 Hang Types

### 3.6.16.3.1 ConnectX-4/ConnectX-4 Lx/ConnectX-5 Adapter Cards Hang Types

The following are the hang types available for ConnectX-4/ConnectX-4 Lx/ConnectX-5 adapter cards:

Category	Stress Type	Description	Notes
Hang FW/ HW	FFSER	Initialize FaultInjector object	<ul style="list-style-type: none"> <li>This hang type is supported in BlueField-2 device only.</li> <li>No extra flag is required.</li> </ul>
	STOP_RX_PER_PR IO <sup>1</sup>		This type requires the following extra flags: <ul style="list-style-type: none"> <li>vl_mask - 16 bit</li> <li>port_num - 8 bit</li> </ul>

```
mlxfwstress -d mt4115_pciconf0 -o on --hang-type STOP_RX_PER_PRIO --extra %STOP_RX_PER_PRIO[0x00100FF]
Random seed: [1588056318]
-----
Operation: [ON]
-----
Turning ON hang type: STOP_RX_PER_PRIO -PASSED
```

To turn this Hang Type, the command must be executed in the following format:

Example:

```
mlxfwstress -d mt4115_pciconf0 -o on --hang-type STOP_RX_PER_PRIO --extra % STOP_RX_PER_PRIO [0x000100FF]
output:
Random seed: [1573642282]
-----
Operation: [ON]
-----
Turning ON hang type: STOP_RX_PER_PRIO-PASSED
```

### 3.6.16.3.2 Turning On Hang Types

To turn on a specific hang type:

```
mlxfwstress -d mt4103_pciconf0 -o on --hang-type HANG_SX1
-----
Operation: [ON]
-----
Turning ON hang type: Sx1 -PASSED
```

To turn on a set of hang types:

```
mlxfwstress -d mt4103_pciconf0 -o on --hang-type HANG_SX1,HANG_RX1
-----
Operation: [ON]
-----
Turning ON hang type: Sx1 -PASSED
Turning ON hang type: Rx1 -PASSED
```

### 3.6.16.3.3 Turning Off Hang Types

To turn off a specific hang type:

```
mlxfwstress -d mt4103_pciconf0 -o off --hang-type HANG_SX1
-----
Operation: [OFF]
-----
Turning OFF hang type: Sx1 -PASSED
```

To turn off a set of hang types:

```
mlxfwstress -d mt4103_pciconf0 -o off --hang-type HANG_SX1,HANG_RX1
-----
Operation: [OFF]
-----
Turning OFF hang type: Sx1 -PASSED
Turning OFF hang type: Rx1 -PASSED
```

### 3.6.16.3.4 Querying the Hang Types

To query the state of all hang types:

```
mlxfwstress -d mt4103_pciconf0 -o query --hang-type ALL
-----
Operation: [QUERY]
-----
Querying hang type: Sx1 -ENABLED
```

```
Querying hang type: Rx1 -ENABLED
Querying hang type: Tx -ENABLED
Querying hang type: Rx -ENABLED
```

### 3.6.16.4 Clearing all Stress/Hang Types

To clear all stress/hang types:

```
mlxfwstress -d mt4103_pciconf0 -o clear_all
-----
Operation: [CLEAR_ALL]
-----
Turning OFF hang type: Sx1 -PASSED
Turning OFF hang type: Rx1 -PASSED
Turning OFF hang type: Tx -PASSED
Turning OFF hang type: Rx -PASSED
Turning OFF stress type: stop_ce_instage_eqe -PASSED
Turning OFF stress type: stop_sxp_vl_arb_port1 -PASSED
Turning OFF stress type: stop_sxp_vl_arb_port2 -PASSED
Turning OFF stress type: stop_edbh -PASSED
Turning OFF stress type: stop_idbh -PASSED
Turning OFF stress type: stop_gpc_miss_machine_0 -PASSED
Turning OFF stress type: stop_gpc_miss_machine_1 -PASSED
Turning OFF stress type: stop_gpc_miss_machine_2 -PASSED
Turning OFF stress type: stop_gpc_miss_machine_3 -PASSED
Turning OFF stress type: lock_cegw -PASSED
Turning OFF stress type: lock_obgw_tpt -PASSED
Turning OFF stress type: lock_obgw_tcu -PASSED
Turning OFF stress type: lock_obgw_sxd -PASSED
Turning OFF stress type: lock_gpcgw_rx -PASSED
Turning OFF stress type: lock_semaphore_ipc_sx1 -PASSED
Turning OFF stress type: lock_semaphore_ipc_rx0 -PASSED
Turning OFF stress type: lock_semaphore_ipc_rx1 -PASSED
Turning OFF stress type: lock_semaphore_ipc_ldb -PASSED
Turning OFF stress type: invalidate_caches -PASSED
```

### 3.6.16.5 Clearing the Semaphore

To clear the semaphore:

```
mlxfwstress -d mt4103_pciconf0 -o clear_semaphore
-----
Operation: [CLEAR_SEMAPHORE]
-----
Semaphore was cleared successfully
```

### 3.6.16.6 Random Operation

There are two random modes you can choose from:

- Single - gives a set of stress types, in each iteration one stress type is chosen and toggled ON/OFF according to his current state
- Wild - gives a set of stress types, in each iteration a random subset of stress types is chosen and toggled ON/OFF according to their current state

#### 3.6.16.6.1 Setting the Random Mode for the Stress Types

To set the Single Mode:

```
mlxfwstress -d mt4103_pciconf0 -o random --rand-mode single -t STOP_CE_INSTAGE_EQE --stress-delay 0.2 --iterations 10
-----
Operation: [RANDOM]
-----
#####
Random:
Iterations delay: 0.2 [sec]
Iterations number: 10
Max on time: 1 [sec]
#####
RANDOM ITERATION: [1]
[stop_ce_instage_eqe]: [ON] , duration since last operation: 0 [ms]
RANDOM ITERATION: [2]
```

```

[stop_ce_instage_ege]: [OFF], duration since last operation: 200 [ms]
RANDOM ITERATION: [3]
[stop_ce_instage_ege]: [ON] , duration since last operation: 201 [ms]
RANDOM ITERATION: [4]
[stop_ce_instage_ege]: [OFF], duration since last operation: 200 [ms]
RANDOM ITERATION: [5]
[stop_ce_instage_ege]: [ON] , duration since last operation: 200 [ms]
RANDOM ITERATION: [6]
[stop_ce_instage_ege]: [OFF], duration since last operation: 201 [ms]
RANDOM ITERATION: [7]
[stop_ce_instage_ege]: [ON] , duration since last operation: 200 [ms]
RANDOM ITERATION: [8]
[stop_ce_instage_ege]: [OFF], duration since last operation: 201 [ms]
RANDOM ITERATION: [9]
[stop_ce_instage_ege]: [ON] , duration since last operation: 200 [ms]
Turning OFF stress type: stop_ce_instage_ege
RANDOM ITERATION: [10]
[stop_ce_instage_ege]: [ON] , duration since last operation: 200 [ms]
=====
Turning off all stress types after random:
Turning OFF stress type: stop_ce_instage_ege

```

- As seen in the example above, after the specified number of iterations, the tool turns off all the stress types.
- The default value for stress-delay is 1 second.
- If no number of iterations was supplied then the user is expected to stop the tool with ctrl+c. The tool turns off all the stress types.

### To set the Wild Mode:

```

mlxfwstress -d mt4103_pciconf0 -o random --rand-mode wild -t ALL --stress-delay 0.2 --max-rand-on 1 --iterations 5
-----
Operation: [RANDOM]
-----
#####
Random:
Iterations delay: 0.2 [sec]
Iterations number: 5
Max on time: 1 [sec]
#####

RANDOM ITERATION: [1]
[stop_ce_instage_ege]: [ON] , duration since last operation: 0 [ms]
[stop_sxp_vl_arb_port2]: [ON] , duration since last operation: 0 [ms]
[stop_edbh]: [ON] , duration since last operation: 0 [ms]
[stop_idbh]: [ON] , duration since last operation: 0 [ms]
[stop_gpc_miss_machine_0]: [ON] , duration since last operation: 0 [ms]
[stop_gpc_miss_machine_3]: [ON] , duration since last operation: 0 [ms]
[lock_cegw]: [ON] , duration since last operation: 0 [ms]
[lock_obgw_tcu]: [ON] , duration since last operation: 0 [ms]
[lock_gpcgw_rx]: [ON] , duration since last operation: 0 [ms]
[lock_semaphore_ipc_sx1]: [ON] , duration since last operation: 0 [ms]

RANDOM ITERATION: [2]
[stop_sxp_vl_arb_port1]: [ON] , duration since last operation: 0 [ms]
[stop_edbh]: [OFF], duration since last operation: 203 [ms]
[stop_idbh]: [OFF], duration since last operation: 203 [ms]
[stop_gpc_miss_machine_3]: [OFF], duration since last operation: 202 [ms]
[lock_cegw]: [OFF], duration since last operation: 202 [ms]
[lock_obgw_tpt]: [ON] , duration since last operation: 0 [ms]
[lock_obgw_tcu]: [OFF], duration since last operation: 203 [ms]
[lock_semaphore_ipc_rx0]: [ON] , duration since last operation: 0 [ms]
[lock_semaphore_ipc_rx1]: [ON] , duration since last operation: 0 [ms]
[lock_semaphore_ipc_ldb]: [ON] , duration since last operation: 0 [ms]

RANDOM ITERATION: [3]
[stop_ce_instage_ege]: [OFF], duration since last operation: 406 [ms]
[stop_sxp_vl_arb_port2]: [OFF], duration since last operation: 406 [ms]
[stop_edbh]: [ON] , duration since last operation: 203 [ms]
[stop_idbh]: [ON] , duration since last operation: 203 [ms]
[stop_gpc_miss_machine_0]: [OFF], duration since last operation: 406 [ms]
[stop_gpc_miss_machine_2]: [ON] , duration since last operation: 0 [ms]
[lock_obgw_tpt]: [OFF], duration since last operation: 203 [ms]
[lock_obgw_sxd]: [ON] , duration since last operation: 0 [ms]
[lock_semaphore_ipc_sx1]: [OFF], duration since last operation: 405 [ms]
[lock_semaphore_ipc_ldb]: [OFF], duration since last operation: 203 [ms]

RANDOM ITERATION: [4]
[stop_sxp_vl_arb_port2]: [ON] , duration since last operation: 203 [ms]
[stop_edbh]: [OFF], duration since last operation: 202 [ms]
[stop_idbh]: [OFF], duration since last operation: 202 [ms]
[stop_gpc_miss_machine_1]: [ON] , duration since last operation: 0 [ms]
[stop_gpc_miss_machine_3]: [ON] , duration since last operation: 406 [ms]
[lock_obgw_tpt]: [ON] , duration since last operation: 202 [ms]
[lock_obgw_tcu]: [ON] , duration since last operation: 406 [ms]
[lock_obgw_sxd]: [OFF], duration since last operation: 203 [ms]
[lock_semaphore_ipc_sx1]: [ON] , duration since last operation: 203 [ms]
[lock_semaphore_ipc_rx1]: [OFF], duration since last operation: 406 [ms]
[invalidate_caches]: [ON] , duration since last operation: 0 [ms]

Turning OFF stress type: stop_sxp_vl_arb_port1
Turning OFF stress type: stop_sxp_vl_arb_port2
Turning OFF stress type: stop_gpc_miss_machine_1
Turning OFF stress type: stop_gpc_miss_machine_2
Turning OFF stress type: stop_gpc_miss_machine_3

```

```

Turning OFF stress type: lock_obgw_tpt
Turning OFF stress type: lock_obgw_tcu
Turning OFF stress type: lock_qpcgw_rx
Turning OFF stress type: lock_semaphore_ipc_sx1
Turning OFF stress type: lock_semaphore_ipc_rx0
Turning OFF stress type: invalidate_caches

RANDOM ITERATION: [5]
[stop_sxp_vl_arb_port2]: [ON] , duration since last operation: 202 [ms]
[stop_idbh]: [ON] , duration since last operation: 322 [ms]
[lock_obgw_tpt]: [ON] , duration since last operation: 202 [ms]
[lock_obgw_tcu]: [ON] , duration since last operation: 202 [ms]
[lock_qpcgw_rx]: [ON] , duration since last operation: 202 [ms]
[invalidate_caches]: [ON] , duration since last operation: 202 [ms]
=====
Turning off all stress types after random:

Turning OFF stress type: stop_sxp_vl_arb_port2
Turning OFF stress type: stop_idbh
Turning OFF stress type: lock_obgw_tpt
Turning OFF stress type: lock_obgw_tcu
Turning OFF stress type: lock_qpcgw_rx
Turning OFF stress type: invalidate_caches

```


### 3.6.16.6.2 ConnectX-3/ConnectX-3 Pro Adapter Cards Hang Types


The following are the hang types available for ConnectX-3/ConnectX-3 Pro adapter cards:


Category	Stress Type	Description	Notes
Hang FW/HW	HANG_SX1		
	HANG_RX1		
	HANG_TX		
	HANG_RX		
	ALL		Hang types that require extra flags are not supported when running with the 'ALL' option.


## 3.6.17 resourcedump Utility

The resourcedump tool extracts and prints data segments generated by the firmware. It is supported in 5th generation NIC's devices. The dump output is used by NVIDIA for debug and troubleshooting.

 Scapy and Pyverbs are no longer resourcedump dependencies. The same functionality has been changed with a C code that is based on the RDMA core included in OFED (v5.7 and up) or Upstream (Kernel v5.14 and up).

 mstresourcedump can be used only if Python 3.x is installed. Using lower versions will result in tool's failure.

 To use the memory mode, the user must install the MLNX\_OFED driver version that includes the rdma-core package, and in addition, must install the scapy package.

 It is important for the user to generate a bin file for debugging and troubleshooting cases when needed by NVIDIA.



If the firmware version used is not supported, the tool will generate the following error message:

```
“Error: Failed to fetch query data with exception: Failed to send Register RESOURCE DUMP with rc: 515. Exiting...”.
```

### 3.6.17.1 resourcedump Usage

```
resourcedump [-h] [-v] {dump,query}
```

where

dump	Dump command
query	Query command
-h, --help	Show help message and exit
-v, --version	Shows tool version and exit

#### 3.6.17.1.1 resourcedump query Usage

```
resourcedump query [-h] [-v VIRTUAL_HCA_ID] [-m [MEM]] -d DEVICE
```

where

-h, --help	Show help message and exit
-v, --virtual-hca-id	The virtual HCA (host channel adapter, NIC) ID
-d, --device	The device name
-m, --mem	Perform the dump through memory (OFED with rdma-core dependency). Optionally accepts: [rdma device (for example "mlx5_4")]

An example of how to run the query command:

```
# resourcedump query --device /dev/mst/mt4119_pciconf0
```

---

```
Segment Type - 0x1300 (FULL_EQC)
```

Dump Params	Applicability	Special Values
index1 (EQN)	Mandatory	N/A
num-of-obj1	N/A	N/A
index2 (N/A)	N/A	N/A
num-of-obj2	N/A	N/A

---

```
Segment Type - 0x1000 (FULL_QPC)
```

Dump Params	Applicability	Special Values
index1 (QPN)	Mandatory	N/A
num-of-obj1	N/A	N/A
index2 (N/A)	N/A	N/A
num-of-obj2	N/A	N/A
...		
...		

### 3.6.17.1.2 resourcedump dump Usage

```
usage: resourcedump dump [-h] -d DEVICE -s SEGMENT [-v VIRTUAL_HCA_ID] [-i1 INDEX1]
[-i2 INDEX2] [-n1 NUM_OF_OBJ1] [-n2 NUM_OF_OBJ2] [-de DEPTH] [-b BIN] [-m [MEM]]
```

where

-h, --help	Show help message and exit
-v, --virtual-hca-id	The virtual HCA (host channel adapter, NIC) ID
-i1, --index1	The first context index to dump (if supported for this segment)
-i2, --index2	The second context index to dump (if supported for this segment)
-n1, --num-of-obj1	The number of objects to be dumped (if supported for this segment). accepts: ["all", "active", number, depends on the capabilities]
-n2, --num-of-obj2	The number of objects to be dumped (if supported for this segment). accepts: ["all", "active", number, depends on the capabilities]
-de, --depth	The depth of walking through reference segments. 0 stands for flat, 1 allows crawling of a single layer down the struct, etc. "inf" for all
-b, --bin	The output to a binary file that replaces the default print in hexadecimal, a readable format
-d, --device	The device name
-s, --segment	The segment to dump
-m, --mem	Perform the dump through memory (OFED with rdma-core dependency). Optionally accepts: [rdma device (for example "mlx5_4")]

Examples of how to:

- Run the dump command:

```
# resourcedump dump --device /dev/mst/mt4119_pciconf0 --segment 0x1200 --index1 0x404 --depth 0
Found 10 segments:
-----
Segment Type: 0xffffe
Segment Size: 16 Bytes
Segment Data:
0x0004FFFE 0x00000000 0x00000000 0x101A0111
-----
Segment Type: 0xffffa
Segment Size: 20 Bytes
Segment Data:
0x0005FFFA 0x12000000 0x00000404 0x00000000
0x00000000
-----
```

- Run the Dump command and save it in bin file:


```
# resourcedump dump --device /dev/mst/mt4119_pciconf0 --segment 0x1200 --index1 0x404 --depth 0 --bin
segment_1200.bin
write to file: segment_1200.bin
```


## 3.6.18 resourceparse Utility

The resourceparse tool parses and prints data segments content. The parser's output is used by NVIDIA representatives for debugging and troubleshooting.

This tool parses the output of the "resourcedump" tool. There are several parsing methods (see --parser):

- **ABD:**  
This parsing method receives an ABD file and parses each segment data according to the ABD layout of the node with the segment\_id attribute corresponding to the segment.
- **Map:**  
This parsing method assumes that the provided resource-segments represent a memory map by DWORD pairs of address-value, and outputs each pair in a new line (similar to mstdump).

 The tool applicable inputs for parsing can be the resourcedump outputs (bin file or the "human readable" format), or the devlink json format output.

 To parse the segments data in the most efficient way, the user must use the most suitable adb file. For the adb file, please contact [Support](#).

### 3.6.18.1 resourceparse Usage

```
resourceparse -d DUMP_FILE [-p RESOURCE_PARSER] [--version] [-o OUT] [-v] -a ADB_FILE [-r]
```

where

-d, --dump-file	Location of the dump file used for parsing
-p, --parser	RESOURCE_PARSER: Available options: ['adb', 'map']. Default: 'adb'. see Parsing Methods.
-a, --adb-file	Location of the ABD file
-h, --help	Shows this help message and exit
--version	Shows the tool's version and exit
-o, --out	Location of the output file
--out-dir	Location of the output directory, a separate file is created for each segment
-r, --raw	Prints the raw data in addition to the parsed data
--hide-segment-header	Hide segment header during printing
-v	Verbosity notice

Examples:

- How to run basic parsing:

```
# resourceparse --dump-file notice.txt --adb-file fw-4119-rel-16_23_2008.adb  
Parse 4 segments:
```

```

-----
                Segment - segment_info (0xffffe)
segment_header.segment_type = 0xffffe
segment_header.length_dw = 0x4
dump_version = 0x0
hw_version = 0x0
fw_version = 0x1063232c
-----

```

```

-----
                Segment - segment_command (0xffffa)
segment_header.segment_type = 0xffffa
segment_header.length_dw = 0x5
vhca_id = 0x0
segment_called = 0x2000
index1 = 0x21
index2 = 0x0
num_of_obj1 = 0x0
num_of_obj2 = 0x0
-----

```

```

-----
                Segment - segment_notice (0xffff9)
segment_header.segment_type = 0xffff9
segment_header.length_dw = 0xc
syndrome_id = 0x211
notice[0] = 0x2000
notice[1] = 0x21
notice[2] = 0x0
notice[3] = 0x0
notice[4] = 0x496e7661
notice[5] = 0x6c696420
notice[6] = 0x52657300
notice[7] = 0x0
notice msg = !Invalid Res
-----

```

```

-----
                Segment - segment_terminate (0xffffb)
segment_header.segment_type = 0xffffb
segment_header.length_dw = 0x1
-----

```

- How to run parsing with 'raw' and 'verbosity' options:

```

# resourceparse --dump-file notice.txt --adb-file fw-4119-rel-16_23_2008.adb -raw -v
Notice - adb fw version 16.23.2008 is used for parsing while dump fw version is 16.99.9004
Parse 4 segments:
-----
                Segment - segment_info (0xffffe)
segment_header.segment_type = 0xffffe
segment_header.length_dw = 0x4
dump_version = 0x0
hw_version = 0x0
fw_version = 0x1063232c
RAW DATA:
DWORD [0-3]      :0x0004FFFE 0x00000000 0x00000000 0x1063232C
-----
                Segment - segment_command (0xffffa)

```

```

segment_header.segment_type = 0xffffa
segment_header.length_dw = 0x5
vhca_id = 0x0
segment_called = 0x2000
index1 = 0x21
index2 = 0x0
num_of_obj1 = 0x0
num_of_obj2 = 0x0
RAW DATA:
DWORD [0-3] :0x0005FFFA 0x20000000 0x00000021 0x00000000
DWORD [4] :0x00000000
-----

Segment - segment_notice (0xffff9)
segment_header.segment_type = 0xffff9
segment_header.length_dw = 0xc
syndrome_id = 0x211
notice[0] = 0x2000
notice[1] = 0x21
notice[2] = 0x0
notice[3] = 0x0
notice[4] = 0x496e7661
notice[5] = 0x6c696420
notice[6] = 0x52657300
notice[7] = 0x0
RAW DATA:
DWORD [0-3] :0x000CFFF9 0x00000211 0x00000000 0x00000000
DWORD [4-7] :0x00002000 0x00000021 0x00000000 0x00000000
DWORD [8-11] :0x496E7661 0x6C696420 0x52657300 0x00000000
notice msg = !Invalid Res
-----

Segment - segment_terminate (0xffffb)
segment_header.segment_type = 0xffffb
segment_header.length_dw = 0x1
RAW DATA:
DWORD [0] :0x0001FFFB
-----

```

- How to run parsing and save it into a file:

```

# resourceparse --dump-file notice.txt --adb-file fw-4119-rel-16_23_2008.adb -out out_flie.txt
write to file: out_flie.txt

```

### 3.6.19 stedump Utility

The stedump tool is a packet simulator for host NIC steering solutions. It is supported in 5th generation NIC devices and only when using Python v3.4 and above. The dump output of HW steering is used for debugging and troubleshooting.

### 3.6.19.1 Prerequisites

Using the MFT with the --with-pcap option to install stedump utility requires the following third-party dependencies:

- Libraries and header files for the libpcap library
- Libraries and header files for Python development library
- Package Installer for Python (PIP) available

### 3.6.19.2 stedump Usage

```
stedump [-h] --read-file <read_file> [--packet-format <packet_format>] [--output-file <output_file>] [--verbosity <verbosity>] [-v] {live,offline}
```

Where

-h, --help	Show help message and exit
--version	Show version information and exit
--packet-format	Specifies the I/O packet file format (default: hex)
--output-file	Redirect the output to specific file (default: stdout)
--verbosity	Increase output verbosity (default: 0)
--read-file	Specifies the packet(s) filename to read from
live	Run in live mode.
offline	Run in offline mode.

There are three kind of packet formats:

1. hex - Represents one or more packets separated by a newline in hexadecimal format.
2. pcap - Represents one or more packets in packet capture format.
3. raw - Represents a single packet in binary data format.



The pcap packet format is not supported by default, and requires installing MFT with the --with-pcap option.



Offline mode is not supported.

#### 3.6.19.2.1 stedump live Usage

```
stedump live [-h] --device <device> --port <physical_port> {egress,ingress}
```

Where

-h, --help	Show help message and exit
-d, --device	Perform operation for a specified MST device

--port	Specifies the physical port number
egress	Specifies the packet source to be egress for TX flows
ingress	Specifies the packet source to be ingress for RX flows

### 3.6.19.2.2 stedump live egress Usage

```
stedump live egress [-h] [--reg-a <reg_a_value>] [--virtual-hca-id <virtual_hca_id>] [--sqn <sqn>] [--force-loopback] [--special-root]
```

#### Where

-h, --help	Show help message and exit
--reg-a	Specifies steering register A value (default: 0)
--virtual-hca-id	Specifies the source virtual HCA ID (default: 0)
--sqn	Specifies the send queue context number (default: 0)
--force-loopback	specifies whether to use QP force loopback
--special-root	specifies whether to use QP special root

An example of how to run the egress (TX) packet flow:

```
# stedump --read-file tcp.hex live --device /dev/mst/mt4119_pciconf0 --port 0 egress
PACKET_DATA
C0 C1 C2 C3 C4 C5 A0 A1 A2 A3 A4 A5 08 00 45 00
00 28 00 00 40 00 40 06 34 CB 01 01 01 01 02 02
02 02 10 E1 22 3D 00 00 BA BA 00 00 DE DA 51 23
FF FF AD 29 00 00

STE_MASKED[1] OUTER: source_qp: 0x40
[HIT] - hit_ix=0x6e polarity

STE_MASKED[2] OUTER: encapsulation_type: ROCE
[HIT] - hit_ix=0x6d polarity

STE_MASKED[3] : Always Hit
[HIT] - hit_ix=0x2000001a

STE_MASKED[4] : Always Hit
[HIT] - hit_ix=0xf0000000

STE_MASKED[5] : Always Hit
[HIT] - hit_ix=0xf0000009

STE_MASKED[6] OUTER: dmac: c0:c1:c2:c3:c4:c5, l3_type: IPV4
[HIT] - hit_ix=0xf000000e

STE_MASKED[7] OUTER: sip: 1.1.1.1
[ACTION] - COUNT { flow_counter_id=0x801199, gvmi=0x0 }
[ACTION] - MODIFY_HEADER { number_of_re_write_actions:11, ix=0x57 }
```

```

[HIT] - hit_ix=0x1a44c

STE_MASKED[8] : Always Hit
[ACTION] - COUNT { flow_counter_id=0x2a, gvmi=0x0 }
[ACTION] - WIRE { }
[HIT] - hit_ix=0x0
[ACTION] - SX TERMINATOR { WIRE }
- STEERING_HOPS - 8

```

### An example of how to run the ingress (RX) packet flow:

```

# stedump --read-file tcp.hex live --device /dev/mst/mt4119_pciconf0 --port 0 ingress
PACKET_DATA
E0 E1 E2 E3 E4 E5 A0 A1 A2 A3 A4 A5 08 00 45 00
00 5E 00 00 40 00 40 11 34 8A 01 01 01 01 02 02
02 02 04 D2 17 C1 00 4A DC C1 01 80 65 58 CC CE
23 00 61 61 61 61 B0 B1 B2 B3 B4 B5 A0 A1 A2 A3
A4 A5 08 00 45 00 00 28 00 00 40 00 40 06 34 CB
01 01 01 01 02 02 02 02 10 E1 22 3D 00 00 BA BA
00 00 DE DA 51 23 FF FF AD 29 00 00

STE_MASKED[1] OUTER: encapsulation_type: ROCE
[ACTION] - COUNT { flow_counter_id=0x29, gvmi=0x0 }
[HIT] - hit_ix=0x2000001a polarity

STE_MASKED[2] : Always Hit
[HIT] - hit_ix=0xf0000000

STE_MASKED[3] : Always Hit
[HIT] - hit_ix=0xf0000009

STE_MASKED[4] OUTER: dmac: e0:e1:e2:e3:e4:e5, l3_type: IPV4
[HIT] - hit_ix=0xf000000f

STE_MASKED[5] OUTER: sip: 1.1.1.1
[ACTION] - COUNT { flow_counter_id=0x801199, gvmi=0x0 }
[ACTION] - DECAP { L2 }
[ACTION] - MODIFY_HEADER { number_of_re_write_actions:1, ix=0xd7 }
[HIT] - hit_ix=0xa00001a5

STE_MASKED[6] : Always Hit
[HIT] - hit_ix=0xa00001a2

STE_MASKED[7] : Always Hit
[ACTION] - QP { gvmi=0x0,qp=0x108d }
[HIT] - hit_ix=0x0
[ACTION] - RX TERMINATOR { }
- STEERING_HOPS - 7

```

## 3.7 Cable Utilities

MFT can work against the cables that are connected to the devices on the machine, or in the InfiniBand fabric in the following scenarios:

- Accessing the cable using the local PCI device. Supported in:
  - ConnectX-4 and newer devices
  - All the platforms
- Accessing the cable using the IB fabric. Supported in:
  - All the devices
  - Linux and Windows since IB driver is required
  - Supported cables are all QSFP and SFP

### 3.7.1 Cable Discovery

#### 3.7.1.1 How to Discover the Cables

To discover the cables that are connected to the local devices:

```
mst cable add
```

This command will scan all the local PCI devices and try to discover cable connected to each port.

To expand the discovery to include also the IB fabric, use the "--with\_ib" flag. This flag by default will scan all the ib devices from the ibstat/ibv\_devices output. To run only a specific interface and port, the interface or the port should be specified after the flag.

Examples:

To scan all the fabric:

```
mst cable add --with_ib
```

To scan a specific interface:

```
mst cable add --with_ib mlx4_0
```

or:

```
mst cable add --with_ib mlx4_0 1
```

#### 3.7.1.2 Representing the Cables in mst Status

##### 3.7.1.2.1 Local Cables

The name of the cable will be the same name as the mst-device/PCI-device with `_cable_<port>`.

Examples:

```

mst cable add
-I- Added 2 cable devices.

mst status
MST modules:
...
Cables:
-----
mt4115_pciconf0_cable_0
mt4115_pciconf0.1_cable_1

```

### 3.7.1.2.2 Remote Cables

When using the '--with\_ib' flag, the name of the cable devices are created the same as the Inband devices with `_cable`.

```

> mst cable add --with_ib
-I- Added 4 cable devices ..
> mst status
Cables:
-----
CA_MT4113_HCA-4_lid-0x0002,mlx5_0,1_cable
CA_MT4115_HCA-2_lid-0x0001,mlx5_0,1_cable
mt4115_pciconf0_cable_0
mt4115_pciconf0_cable_1

```

## 3.7.2 Working with Cables

The following are the tools that can work with cables: `mstdump`, `mlxdump` and `mlxcables`.

The below are examples using the tools mentioned above.

### mstdump

```

mstdump mt4115_pciconf0_cable_0
0x00000000 0x0002060d
0x00000004 0x00000000
0x00000008 0x00000000
0x0000000c 0x00000000
0x00000010 0x00000000
0x00000014 0x4a340000
0x00000018 0x8b7f0000
0x0000001c 0x00000000
0x00000020 0xc0210000
0x00000024 0x901aa61d
0x00000028 0x6dc9521c
0x0000002c 0xe2d12fca
...
...
...

```

### mlxdump

```

# mlxdump -d mt4115_pciconf0_cable_0 snapshot
-I- Dumping crspace...
-I- crspace was dumped successfully
-I- Dump file "mlxdump.udmp" was generated successfully

```

For the `mlxcables` example, refer to section [mlxcables](#).

## 3.7.3 mlxcables - Cables Tool



- `mlxcables` is used for R/W to cable EEPROM
- The information of the devices will be collected by PRM command from switch Asic by `mlxlink` tool only

- mlx cables will continue to support R/W operations to EEPROM, and will not be deprecated currently due to Independent module. Meaning, new features will not be supported in mlx cables

The mlx cables tool allows users to access the cables and do the following:

- Query the cable and get its IDs
- Read specific addresses in the EEPROM
  - Read a specific register by its name. Supported registers are received by the tool (depends on the cable type)
  - Dump all the cable EEPROM bytes in RAW format
  - Upgrade the FW image on the cable uC (Only on cables that support ISSU)

### 3.7.3.1 mlx cables Synopsis

```
[-d|--dev <DeviceName>] [-h|--help] [-v|--version] [-q|--query] [--DDM] [-r|--read] [--print_raw] [--dump] [-b|--bytes_line <bytesPerLine>] [-p|--page <pageNum>] [-o|--offset <pageOffset>] [-l|--length <length>] [-a|--address <address>] [-y|--yes] [--no] [--read_reg <Register>] [--read_all_regs] [--show_all_regs] [--customization <Customization_type>]
```

where:

-d --dev <DeviceName>	Perform operation for specified cable
-h --help	Show this message and exit
-v --version	Show the executable version and exit
-q --query	Query cable info
--DDM	Get cable DDM query
-r --read	Read from cable
--print_raw	Print bytes in raw format
--dump	Dump all cable pages in RAW format
-b --bytes_line <bytesPerLine>	Bytes per line in the raw print (multiples of 4, default: 4)
-p --page <pageNum>	Specific Page number to do the read/write operation
-o --offset <pageOffset>	Specific Page offset
-l --length <length>	Length of the needed data in bytes to read (default: 1 Byte)
-a --address <address>	Address (Replacement for page+offset)
--read_reg <Register>	Read register from cable
--read_all_regs	Read all registers from cable
--show_all_regs	Show all registers in the cable
--customization <customization_type>	Show cable specific customization

Notes:

- For QSFP transceivers, the tool reads the address from I2C address of 0x50. For further information, please see spec SFF8636.
- For SFP transceivers, the tool reads from I2C address 0x50 and names it page 0. When reading from I2C address 0x51 the pages will be read as page <x+1>, for example:

- I2C address 0x51 page 0 will be referred in the tool as page 1.
- I2C address 0x51 page 1 will be referred in the tool as page 2. For further information, please see spec SFF8472.

### Examples:

To read specific byte/s in the cable pages:

```
mlxcables -d mt4115_pciconf0_cable_0 -r -p 0 -o 165 -l 3
Page[0].Byte[165] = 0x00
Page[0].Byte[166] = 0x02
Page[0].Byte[167] = 0xc9
```

Another way to read from a specific page is to use the '--address <ADDR>' flag where ADDR=0x<PAGE><OFFSET>, for example to read the same bytes with -a:

```
mlxcables -d mt4115_pciconf0_cable_0 -r -a 0x00A5 -l 3
Page[0].Byte[165] = 0x00
Page[0].Byte[166] = 0x02
Page[0].Byte[167] = 0xc9
```

To read in raw format:

```
# mlxcables -d mt4115_pciconf0_cable_0 -r -p 0 -o 128 -l 12 --print_raw
128: 0d 8c 23 81
132: 00 00 00 00
136: 00 00 00 05
```

To control Bytes per line, use -b:

```
# mlxcables -d mt4115_pciconf0_cable_0 -r -p 0 -o 128 -l 12 --print_raw -b 8
128: 0d 8c 23 81 00 00 00 00
136: 00 00 00 05
```

To query the cable:

```
mlxcables -d mt4115_pciconf0_cable_0 -q
Cable name      : mt4115_pciconf0_cable_0
FW version     : 2.2.550
FW Dev ID      : 0x21
FW GW version  : Legacy
----- Cable EEPROM -----
Identifier     : QSFP+ (0dh)
Technology     : 1550 nm DFB (50h)
Compliance    : 40G Active Cable (XLPPI), 100G AOC or 25GAUI C2M AOC. Providing a worst BER of 10^(-12) or below
Wavelength    : 1550 nm
OUI           : 0x0002c9
Vendor        : Mellanox
Serial number  : MT1602FT00022
Part number   : MFS1200-E003
Revision      : AB
Temperature   : 54 C
Length        : 3 m
```

Get the DDM query of the cable:

```
# mlxcables -d mt4115_pciconf0_cable_0 --DDM
Cable DDM:
-----
Temperature : 37C
Voltage     : 3.3010V
RX Power    : -0.6712dBm
TX Power    : 0.8877dBm
TX Bias     : 6.7500mA
-----
Flags -----
Temperature:
Alarm high  : 0
Warning high : 0
Warning low  : 0
```

```

Alarm low      : 0
Voltage:
Alarm high    : 0
Warning high  : 0
Warning low   : 0
Alarm low     : 0
RX/TX Power and TX Bias:
RX Power alarm high : 0
RX Power warning high: 0
RX Power warning low : 0
RX Power alarm low  : 0
TX Power alarm high : 0
TX Power warning high: 0
TX Power warning low : 0
TX Power alarm low  : 0
TX Bias alarm high  : 0
TX Bias warning high : 0
TX Bias warning low : 0
TX Bias alarm low   : 0
----- Thresholds -----
Temperature high alarm threshold : 80C
Temperature high warning threshold : 70C
Temperature low warning threshold : 0C
Temperature low alarm threshold  : -10C

Voltage high alarm threshold : 3.5000V
Voltage high warning threshold: 3.4650V
Voltage low warning threshold : 3.1350V
Voltage low alarm threshold  : 3.1000V

RX Power high alarm threshold : 5.3999dBm
RX Power high warn threshold  : 2.4000dBm
RX Power low warn threshold   : -10.3012dBm
RX Power low alarm threshold  : -13.3068dBm

TX Power high alarm threshold : 5.3999dBm
TX Power high warn threshold  : 2.4000dBm
TX Power low warn threshold   : -8.4013dBm
TX Power low alarm threshold  : -11.4026dBm

TX Bias high alarm threshold  : 8.5000mA
TX Bias high warn threshold   : 8.0000mA
TX Bias low warn threshold    : 6.0000mA
TX Bias low alarm threshold   : 5.4920mA

```

To read by register name:

Get the list of the supported registers.

```

mlxables -d mt4115_pciconf0_cable_0 --show_all_regs
Available registers per page:
=====
page00_high registers:
=====
identifier |
ext_identifier |
connector_type |
..
..
..
vendor_oui   |
..

```

Read the register with the register name you choose (e.g. vendor\_oui, identifier).

```

mlxables -d mt4115_pciconf0_cable_0 --read_reg vendor_oui
vendor_oui = 0x0002c9
mlxables -d mt4115_pciconf0_cable_0 --read_reg identifier
identifier = 0x0d

```

To read all the Eeprom of the cable:

```

mlxables -d mt4115_pciconf0_cable_0 --read_all_regs
Available registers per page:
=====
page00_high registers:
=====
identifier | 0x0d
ext_identifier | 0x06
connector_type | 0x02
..
..
..
vendor_oui | 0x0002c9
..

```

This will print the same tables as "--show\_all\_regs" but with the data that was read.

To dump all the cable's pages in raw format:

```
# mlx cables -d mt4115_pciconf0_cable_0 --dump -b 16
+-----+
| Page: 0x00 , Offset: 000, Length: 0x80 |
+-----+
000: 0d 06 00 f0 00 00 00 00 00 00 00 00 00 00 00 00
016: 00 00 00 00 00 00 29 a7 00 00 80 7d 00 00 00 00
032: 00 00 37 fa 26 2a 33 68 1c 0c b3 f9 b2 76 c2 fc
048: c1 3e 00 00 00 00 00 00 00 00 00 00 00 00 00 00
064: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
080: 00 00 00 00 00 00 00 00 00 00 00 00 00 01 00 00
096: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 08 00
112: 00 10 00 00 00 00 00 00 00 00 00 00 00 00 00 00
+-----+
| Page: 0x00 , Offset: 128, Length: 0x80 |
+-----+
128: 0d cc 23 81 00 00 00 00 00 00 00 05 ff 00 00 00
144: 00 00 03 50 4d 65 6c 6c 61 6e 6f 78 20 20 20 20
160: 20 20 20 20 1f 00 02 c9 4d 46 53 31 32 30 30 2d
176: 45 30 30 33 20 20 20 20 41 43 79 18 27 10 46 be
192: 18 07 f5 96 4d 54 31 36 31 33 46 54 30 30 36 39
208: 36 20 20 20 31 36 30 32 32 32 00 00 00 00 67 a9
224: 36 30 33 46 4d 41 32 30 33 47 31 34 32 38 20 20
240: 00 00 00 00 00 00 00 00 00 00 01 00 10 00 00 00
+-----+
| Page: 0x03 , Offset: 128, Length: 0x80 |
+-----+
128: 50 00 f6 00 46 00 00 00 00 00 00 00 00 00 00 00
144: 88 b8 79 18 87 5a 7a 76 00 00 00 00 00 00 00 00
160: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
176: 87 71 01 d3 43 e2 03 a5 00 00 00 00 00 00 00 00
192: 87 71 02 d4 43 e2 05 a5 00 00 00 00 00 00 00 00
208: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
224: a7 03 00 00 00 00 00 00 00 00 00 00 77 77 11 11
240: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
```

### 3.7.3.2 MTUSB Cable Board

The mlx cables tool supports reading cable data directly via i2c when the cable is connected to a dedicated board. The board is connected to the host with an MTUSB adapter.

Examples on a Windows machine:

After adding the cables using 'mst cable add' the following mst status is presented:

```
mst status
MST devices:
-----
  mtusb-1
Cable MST devices:
-----
  mtusb-1_cable
```

Query the cable:

```
mlx cables -d mtusb-1_cable
Querying Cables ....
Cable #1:
-----
Cable name      : mtusb-1_cable
FW version     : 2.0.208
FW Dev ID      : 0x20
FW GW version   : Legacy
----- Cable EEPROM -----
Identifier      : QSFP+ (0dh)
Technology     : 850 nm VCSEL (00h)
Compliance     : 40G Active Cable (XLPPI), 100G AOC (Active Optical Cable) or 25GAUI C2M AOC.
Wavelength     : 850 nm
OUI            : 0x0002c9
Vendor         : Mellanox
Serial number   : MT1707FT01544
Part number    : MPA1A00-E001
Revision       : A1
Temperature    : 31 C
Length         : 1 m
```

Read from a specific address:

```
mlxcables -d mtusb-1_cable -r -p 0 -o 165 -l 3
Page[0].Byte[165] = 0x00
Page[0].Byte[166] = 0x02
Page[0].Byte[167] = 0xc9
```

### 3.7.3.3 Cable Firmware Upgrade with Live-Patch

Live-Patch enables a seamless update of the cable firmware.

#### Prerequisites

The cable firmware gateway version must be set to ISFU (see "FW GW version : ISFU" in the example below).

Burn the cable firmware image binary.

```
# mlxcables -d mt52000_pciconf0_cable_22 -i img.bin -u
```

To get the cable's firmware binary, please contact Mellanox Support ([support@mellanox.com](mailto:support@mellanox.com)).

#### Burning Process Example:

Query the device:

```
# mlxcables -d mt52000_pciconf0_cable_22
Querying Cables ....
Cable #1:
-----
Cable name      : mt52000_pciconf0_cable_22
FW version     : 32.20.121
FW Dev ID      : 0x22
FW GW version   : ISFU
----- Cable EEPROM -----
Identifier      : QSFP28 (11h)
Technology      : 850 nm VCSEL (00h)
Compliance      : Extended Specification Compliance is valid, 100GBASE-SR4 or 25GBASE-SR
Wavelength      : 850 nm
OUI             : 0x0002c9
Vendor          : Mellanox
Serial number    : MT1623FT01610
Part number     : MMA1B00-C100D
Revision        : A2
Temperature     : 31 C
Length          : 50 m
```

Query the image:

```
# mlxcables -i img.bin
Image name      : img.bin
FW version     : 32.30.204
FW Dev ID      : 0x22
FW GW version   : ISFU
```

Upgrade the firmware:

```
# mlxcables -i img.bin -d mt52000_pciconf0_cable_22 -u
Cable FW version : 32.20.121
Image FW version : 32.30.204
The image version is newer than the FW version on the cable, Do you want to proceed (y/N)? y
100%
-I- The FW was updated successfully
```

Query and verify the new firmware version:

```
# mlxcables -d mt52000_pciconf0_cable_22
Querying Cables ....
Cable #1:
-----
Cable name      : mt52000_pciconf0_cable_22
FW version     : 32.30.204
FW Dev ID      : 0x22
FW GW version   : ISFU
```

```

----- Cable EEPROM -----
Identifier      : QSFP28 (11h)
Technology     : 850 nm VCSEL (00h)
Compliance    : Extended Specification Compliance is valid, 100GBASE-SR4 or 25GBASE-SR
Wavelength    : 850 nm
OUI           : 0x0002c9
Vendor        : Mellanox
Serial number  : MT1623FT01610
Part number   : MMA1B00-C100D
Revision      : A2
Temperature   : 31 C
Length        : 50 m

```

## 3.8 Troubleshooting

You may be able to easily resolve the issues described in this section. If a problem persists and you are unable to resolve it yourself please contact your NVIDIA representative or [Support](#).

### 3.8.1 General Related Issues

Issue	Cause	Solution
Adapter is no longer identified by the operating system after firmware upgrade	Happens due to burning the wrong firmware on the adapter, firmware corruption or adapter's hardware failure.	Power cycle the server. If the issue persists, extract the adapter and contact <a href="#">Support</a>
Server is booting in loop/not completing boot after performing adapter firmware upgrade	Happens due to burning the wrong firmware on the adapter, firmware corruption or adapter's hardware failure.	Extract the adapter and contact <a href="#">Support</a>
Some of the 5th generation (Group II) devices are represented with only one mst device (dev/mst/mt4113_pciconfx) in the output of mst status	For 5th generation (Group II) devices, there is only one method available for accessing the hardware. For example, Connect-IB device is represented by dev/mst/mt4113_pciconfx mst device	When querying a 5th generation (Group II) device, use the conf mst device (for example: dev/mst/mt4113_pciconfx)
Enabling hardware access after configuring new secure host key, fails	The new configuration of the secure host key was not loaded by the driver	Restart the driver before enabling the hardware access again
MFT tools fail on PCI device with the following errors: <ul style="list-style-type: none"> <li>• Operation not permitted</li> <li>• Failed to identify device</li> <li>• Failed to detect device ID</li> <li>• Unknown device</li> <li>• No such device</li> <li>• Failed to open device</li> </ul>	Tools PCI semaphore might be locked due to unexpected process shutdown.	Run the following command: # mcra -c <mst_pci_device> *Supported on MFT-4.4.0 and newer versions.

### 3.8.2 mlxconfig Related Issues

Issue	Cause	Solution
Server not booting after enabling SRIOV with high number of VFs	Setting number of VFs larger than what the Hardware and Software can support may cause the system to cease working	To solve this issue: <ol style="list-style-type: none"> <li>1. Disable SRIOV in bios</li> <li>2. Reboot server</li> <li>3. Change num of VFs</li> <li>4. Enable SRIOV in bios</li> </ol>

Issue	Cause	Solution
After resetting configuration using the tool on 5th generation (Group II) devices, the configuration's value does not change	Firmware loads the default configuration only upon reboot	Reboot the server

### 3.8.3 Installation Related Issues

Issue	Cause	Solution
Unable to install the tool package on ESXi platform and the following message is printed on the screen: Got no data from process	Insufficient privileges	<ol style="list-style-type: none"> <li>1. Copy the tool's package to /tmp/vmware and continue with the installation. If the issue persists, reboot the ESX server and try again</li> <li>2. Use full file path of the tool's package</li> </ol> <b>Note:</b> an additional reboot will be required after completing the installation
Unable to install kernel-mft in Linux due to compilation error that contains the following message: 'error: conflicting types for 'compat_sigset_t''	CONFIG_COMPAT might not be enabled in the kernel configuration.	Set the CONFIG_COMPAT to "y" in the kernel .config file, and rebuild the kernel.

### 3.8.4 Firmware Burning Related Issues

Issue	Cause	Solution
The following message is printed on screen when performing firmware update: An update is needed for the flash layout. The operation is not failsafe and terminating the process is not allowed.	A flash alignment operation is required.	Approve the alignment, avoid process interrupt.
Firmware update fails with the following message: -E- Burning FS4 image failed: Bad parameter <b>Note:</b> This is a rare scenario.	Firmware compatibility issue.	Re-run the burn command with --no_fw_ctrl flag.
The following message is printed on screen when performing firmware update: Shifting between different image partition sizes requires current image to be re-programmed on the flash. Once the operation is done, reload FW and run the command again <b>Note:</b> This is a rare scenario.	Firmware compatibility issue.	Re-load firmware and re-run the burn command.
The following message is printed on screen when trying to query/burn a Connect-IB device: -E- Cannot open Device: /dev/mst/mt4113_pciconf0. B14 Operation not permitted MFE_CMDIF_GO_BIT_BUSY	Using an outdated firmware version with the Connect-IB adapter.	<ol style="list-style-type: none"> <li>1. Unload MLNX_OFED driver: /etc/init.d/openibd stop.</li> <li>2. Add "-ocr" option to the 'flint' command.</li> </ol> <b>For example:</b> flint -d /dev/mst/mt4113_pciconf0 -ocr q

Issue	Cause	Solution
<p>The following message is reported on screen when trying to remove the expansion ROM using the 'drom' option:            -E- Remove ROM failed: The device FW contains common FW/ROM Product Version - The ROM cannot be removed separately.B9</p>	<p>Updating only the EXP_ROM (FlexBoot) for recent firmware images which requires adding the 'allow_rom_change' option.</p>	<p>Allow “-allow_rom_change” option to the “flint” command. For example:            flint -d &lt;mst_device&gt; -allow_rom_change drom</p>
<p>Burning command fails and the following message is printed on screen:            -E- Can not open 06:00.0: Can not obtain Flash semaphore (63). You can run "flint -clear_semaphore            - d &lt;device&gt;" to force semaphore unlock. See help for details.</p>	<p>Semaphore can be locked for any of the following reasons:</p> <ul style="list-style-type: none"> <li>• Another process is burning the firmware at the same time</li> <li>• Failure in the firmware boot</li> <li>• Burning process was forcefully killed</li> <li>• In a Multi-Host environment, another Host is currently burning the firmware</li> </ul>	<p>If no other process is taking place at the same time run the following command: flint -d &lt;device&gt; -- clear_semaphore            OR            Reboot the machine.</p>
<p>Burning tool fails with the following message:            -E- Unsupported binary version (2.0) please update to latest MFT package.</p>	<p>The binary version is incompatible with the burning tool.</p>	<p>Update MFT to the latest package.</p>
<p>mlxburn tool fails to generate a firmware image and displays the following message:            -E- Unsupported MLX file version (2.0) please update to latest MFT package.</p>	<p>The MLX file version is incompatible with the image generation tool (mlxburn).</p>	<p>Update MFT to the latest package.</p>
<p>mlxburn tool fails to generate a firmware image and displays the following message            -E- Perl Error: Image generation tool uses mic (tool) version 1.5.0 that is not supported for creating a bin file for this FW version. FW requires mic version 2.0.0 or above. Please update MFT package.</p>	<p>The MLX file version is incompatible with the image generation tool (mlxburn).</p>	<p>Update MFT to the latest package.</p>
<p>Burning tool fails with an error mentioning Firmware time stamping e.g            -E- Burning FS3 image failed: Stamped FW version mismatch: 12.16.0212 differs from 12.16.0230</p>	<p>The device was set with a timestamp for a different firmware version than the one being burnt or the image is stamped with an older timestamp</p>	<p>Either set a newer timestamp on the image than there is on the device, or reset the timestamp completely. flint -d &lt;device&gt; ts reset flint -i &lt;image&gt; ts reset</p>
<p>Burning the image on Controlled FW (default update method: fw_ctrl in 'flint -d &lt;device&gt; query full' output), fails with:            -E- Burning FS3 image failed: The Digest in the signature is wrong.</p>	<p>The image was changed without calculating the new digest on it with 'flint -i &lt;img.bin&gt; sign'.</p>	<p>Run 'flint -i &lt;img.bin&gt; sign', and retry.</p>

### 3.8.5 Secure Firmware Related Issues

Issue	Cause	Solution
Changing device setting such as ROM/ GUIDS using the relevant flint commands result in failure with the following error: -E- <Operation> failed: Unsupported operation under Secure FW	Secure Firmware does not allow changes to the device data unless burning new Secure Firmware image.	N/A
Burning tool fails with the following error: -E- Burning FS3 image failed: The component is not signed.	The image is not signed with an RSA authentication.	Contact <a href="#">Support</a> to receive a signed firmware image.
Burning tool fails with the following error: -E- Burning FS3 image failed: Rejected authentication.	The image authentication is rejected.	Contact <a href="#">Support</a> to receive a signed firmware image.
Burning tool fails with the following error: -E- Burning FS3 image failed: Component is not applicable.	The image does not match the device (Wrong ID).	Contact <a href="#">Support</a> to receive the firmware image for the device.
Burning tool fails with the following error: -E- Burning FS3 image failed: The FW image is not secured.	The image is not secured and is not accepted by the device.	Contact <a href="#">Support</a> to receive a signed firmware image.
Burning tool fails with the following error: -E- Burning FS3 image failed: There is no Debug Token installed.	The debug firmware was burnt before the debug token was installed on the device.	Install the debug token using mlxconfig and then re-burn the firmware.
Burning firmware on a secure device fails with one of the following messages: <ul style="list-style-type: none"> <li>-E- Burning FS3 image failed: Rejected authentication</li> <li>The FW image is not secured</li> <li>The key is not applicable</li> </ul>	The image was not secured in a the proper way.	Ask for a secure image with the right keys that match the device.
Secure Firmware fails when using flint brom and drom commands.	flint brom and drom commands are not supported.	N/A
mlxdump and wqdump debug utilities do not work in Secure Firmware	A customer support token was not applied.	N/A
When the CR space is in read only mode, the tracers may demonstrate an unexpected behavior.	A writing permission is required for them to work properly.	N/A
Applying token on the device fails with one of the following messages: <ul style="list-style-type: none"> <li>Component is not applicable</li> <li>The manufacturing base MAC was not listed</li> <li>Mismatch FW version</li> <li>Mismatch user timestamp</li> <li>Rejected forbidden version</li> </ul>	The token was not generated or signed in the proper way.	N/A
Burning the firmware using the "--use_dev_rom" flag has no effect and the ROM is replaced with the one on the image.	Controlled firmware does not support changing boot image component.	Use "--no_fw_ctrl".

## 3.9 Appendixes

- [Assigning PSID](#)
- [Remote Access to NVIDIA Devices](#)
- [Booting HCA Device in Livefish Mode](#)
- [Burning a New Device](#)
- [Generating Firmware Secure and NV LifeCycle Configurations Files](#)
- [Updating Firmware Using ethtool/devlink and .mfa2 File](#)
- [Using MFT tools on Secured GPU Devices](#)

### 3.9.1 Assigning PSID

In some cases, OEMs or board manufacturers may wish to use a specific FW configuration not supplied by NVIDIA. After setting the new FW parameters in an INI file, the user should assign a unique PSID (Parameter Set ID) to this new configuration. The PSID is kept as part of the FW image on the device NVMEM. The firmware burning tools use this field to retain FW settings while updating FW versions.

This appendix explains how to assign a new PSID for a user customized FW, and how to indicate to the burning tools that a new PSID exists.

**⚠ Please change FW parameters with caution. A faulty setting of FW parameters may result in undefined behavior of the burnt device.**

#### 3.9.1.1 PSID Field Structure

The PSID field is a 16-ascii (byte) character string. If the assigned PSID length is less than 16 characters, the remaining characters are filled with binary 0s by the burning tool.

The table below provides the format of a PSID.

Vendor Symbol	Board Type Symbol	Board Version Symbol	Parameter Set Number	Reserved
3 characters	3 characters	3 characters	4 characters	3 characters (filled with '\0')

Example:

A PSID for NVIDIA MHXL-CF128-T HCA board is MT\_0030000001, where:

MT\_ Vendor symbol  
003 MHXL-CF128-T board symbol  
000 Board version symbol  
0001 Parameter Set Number

#### 3.9.1.2 Assigning PSID and Integrating Flow

To assign and integrate the new PSID to produce the new FW:

1. Write the new FW configuration file (in .INI format).

2. Assign it with a PSID in the format described above. Use your own vendor symbol to ensure PSID uniqueness. If you do not know your vendor symbol, please contact your local NVIDIA FAE.
3. Set the PSID parameter in the new FW configuration file.

## 3.9.2 Remote Access to NVIDIA Devices

### 3.9.2.1 Burning a Switch In-band Device Using mlxburn

In order to update MT52000 Switch-IB device with a specific GUID (for example, 0xe41d2d03001094b0) using In-Band, the following steps are recommended:



For Linux device names should be listed with the /dev/mst prefix. For Windows, no prefix is required.

1. Make sure all subnet ports are in the active state. One way to check this is to run opensm, the Subnet Manager.

```
[root@mymach]> /etc/init.d/opensmd start
opensm start [ OK ]
```

2. Make sure the local ports are active by running 'ibv\_devinfo'.

3. Obtain the device LID. There are two ways to obtain it:

- a. Using the "mst ib add" command:

The "mst ib add" runs the ibdiagnet/ibnetdiscover tool to discover the InfiniBand fabric and then lists the discovered IB nodes as an mst device. These devices can be used for access by other MFT tools.

```
[root@mymach]> mst ib add
-I- Discovering the fabric - Running: /opt/bin/ibdiagnet -skip all
-I- Added 3 in-band devices
```

- b. To list the discovered mst inband devices run "mst status".

```
devices[root@mymach]> mst status
MST modules:
-----
MST PCI module loaded
MST PCI configuration module loaded
...
Inband devices:
-----
/dev/mst/CA_MT4103_sw005_HCA-1_lid-0x0001
/dev/mst/CA_MT4115_sw005_HCA-2_lid-0x0002
/dev/mst/SW_MT52000_lid-0x0010
[root@mymach]>
```

- c. Using the ibnetdiscover tool, run:

```
ibnetdiscover | grep e41d2d03001094b0 | grep -w Switch
Switch 36 "S-e41d2d03001094b0"
# "SwitchIB Mellanox Technologies" enhanced port 0 lid 16 lmc 0
```



The resulting LID is given as a decimal number.

4. Run mlxburn with the LID retrieved in Step 3 above to perform the In-Band burning operation.

Burn the Switch-INB device:

```
# mlxburn -d lid-0x0010 -fw ./fw-SwitchIB.mlx
-I- Querying device ...
-I- Using auto detected configuration file: ./MSB7700-E_Ax.ini (PSID = MT_1870110032)
-I- Generating image ...
Current FW version on flash: 11.0.1250
New FW version: 11.0200.0120
Burning FS3 FW image without signatures - OK
Restoring signature - OK
-I- Image burn completed successfully.
```

### 3.9.2.2 In-Band Access to Multiple IB Subnets

In most cases, an adapter is connected to a single InfiniBand subnet. The LIDs (InfiniBand Local IDs) on this subnet are unique. In this state, the device access MADs are sent (to the target LID) from the first active port on the first adapter on the machine.

In case that the different IB ports are connected to different IB subnets, source IB port on the local host should be specified explicitly.


The device name would be in the format:

```
<any-string>lid-<lid-number>[,source adapter name][,source IB port number]
```

For example:

- On Linux: lid-3,mlx4\_0,1
- On Windows: lid-3,0,1

Say we have the following setup:



H1 host has 2 adapters. Port 1 of the first adapter is connected to Switch 1, and port 2 of the second adapter is connected to Switch 2. Since the 2 adapters on the H1 are not connected to the each other, there are 2 separate IB subnets in this setup.

Subnet1 nodes: H1 Switch 1 and H2 Subnet2 nodes: H1 Switch 2 and H3

Running "ibv\_devinfo" command on H1 would list the 2 adapter names. For ConnectX adapters, the names would be mlx4\_0 and mlx4\_1.

Running "mst ib add" would add ib devices from the default port (first active port on the first adapter) - only Subnet1 nodes would be listed.

To add the nodes of the second subnet, the source adapter and port should be specified to the "mst ib add" command in the following format:

```
# mst ib add <hca_name> <hca_port>
```

Examples:

Add nodes of both subnets, Run:

```
# mst ib add mlx4_0 1  
# mst ib add mlx4_1 2
```

List the devices:

```
# mst status  
...  
/dev/mst/CA_MT25418_H1_HCA-1_lid-0x0001,mlx4_0,1  
/dev/mst/CA_MT25418_H2_HCA-1_lid-0x0005,mlx4_0,1  
/dev/mst/SW_MP51000_Switch1_lid-0x0003,mlx4_0,1  
/dev/mst/CA_MT25418_H1_HCA-1_lid-0x0010,mlx4_1,2  
/dev/mst/CA_MT25418_H3_HCA-1_lid-0x0012,mlx4_1,2  
/dev/mst/SW_MP51000_Switch2_lid-0x0005,mlx4_1,2
```




You can use the above device names with the MFT tools.

### 3.9.2.3 MTUSB-1 USB to I2C Adapter

The MTUSB-1 is a USB to I2C bus adapter. This chapter provides the user with hardware and software installation instructions on machines running Linux or Windows operating systems.

MTUSB-1 Device



### 3.9.2.3.1 MTUSB-1 Package Contents

Please make sure that your package contains the items listed and that they are in good condition.

Item	Quantity	Description
MTUSB-1 device	1	USB to I2C bus adapter
USB cable	1	USB_A to USB_B (1.8m)
I2C cable	1	9-pin male-to-male cable (1.5m)
Converter cable	2	9-pin female to 3-pin (small/large) (0.3m)

### 3.9.2.3.2 System Requirements

The MTUSB-1 is a USB device which may be connected to any Personal Computer with a USB Host Adapter (USB Standard 1.1 or later) and having at least one USB connection port.

### 3.9.2.3.3 Supported Platforms

MTUSB-1 is supported in Linux and Windows only.

### 3.9.2.3.4 Hardware Installation

To install the MTUSB-1 hardware, please execute the following steps in the *exact* order:

1. Connect one end of the USB cable to the MTUSB-1 and the other end to the PC.
2. Connect one end of the I2C cable to the MTUSB-1 and the other end to the system/board you wish to control via the I2C interface. If the system/board uses a 3-pin connector instead of a 9-pin connector, connect the appropriate converter cable as an extension to the I2C cable on the 9-pin end, then connect its 3-pin end to the system/board.

### 3.9.2.3.5 Software Installation

The MTUSB-1 device requires that the MFT package be installed on the machine to which MTUSB-1 is connected; see MFT Installation for installation instructions.

For a Windows machine, it is also required to install the MTUSB-1 driver; visit <http://www.diolan.com> to download this driver. This driver is required for the first use of the MTUSB-1 device.

1. Start the *mst1* driver. Enter: (Note: This step is not required in Windows.)

```
# mst start          (or mst restart if mst start was run earlier)
```

2. To obtain the list of *mst* devices, enter:

```
# mst status -v      (or mst restart if mst start was run earlier)
```

If MTUSB-1 has been correctly installed, “mst status” should include the following device in the device list it generates:

- On Linux: `/dev/mst41:00.0/mtusb-1`
- On Windows: `mtusb-1`

### 3.9.2.3.6 Switch Reprogramming through I2C Port

In order to reprogram the switch through the I2C adapter, follow the steps below:

For MSX1710/MSX67XX Switch systems:

1. Open the bus:

```
i2c -a 1 -d 1 /dev/mst/mtusb-1 w 0x60 0x20 0x10  
i2c -a 1 -d 1 /dev/mst/mtusb-1 w 0x62 0x00 0x01
```

2. Burn the firmware:

```
flint -d /dev/mst/mtusb-1 -i ./fw-SX.bin b
```

3. Power cycle the system by unplugging and re-plugging the power cord to load the new firmware.

For MSX6025/6036 Switch systems:

1. Open the bus:

```
i2c -d /dev/mst/mtusb-1 w 0x22 0x1a 0xfb
```

2. Route the I2C bus to the switch device:

```
i2c -d /dev/mst/mtusb-1 w 0x70 0x0 0x1
```

3. Burn the firmware:

```
flint -d /dev/mst/mtusb-1 -i ./fw-SX.bin b
```

- Power cycle the system by unplugging and re-plugging the power cord to load the new firmware.

### 3.9.2.4 Remote Access to Device by Sockets

The mst device on a machine can be accessed (server side) remotely for debugging purposes using the minimum set of tools from another machine (client side) which may have more tools or faster machine.

To do so:

- The mst server should run on the 'server side machine. Run: 'mst server start'
- The client side should add the mst 'server side'. Run: 'mst remote add <server side machine IP>'

After remote devices are added to the mst list device in the 'client side', you can run any tool that accesses the mst devices of the 'server side' as seen in the example below.

Usage of relevant command:

Command	Description
mst server start [port]	Starts mst server to allow incoming connection. Default port is 23108
mst server stop	Stops mst server.
mst remote add <host-name>[:port]	<ul style="list-style-type: none"> <li>Establishes connection with a specified host on a specified port (default port is 23108).</li> <li>Adds devices on remote peer to local the devices list.</li> <li>&lt;hostname&gt; may be host name as well as an IP address.</li> </ul>
mst remote del <host-name>[:port]	Removes all remote devices on a specified hostname. <host-name>[:port] should be specified exactly as in the "mst remote add" command.

Example:

The example below shows how to query the firmware of a device in the server side (machine: mft) from the client side (machine: mft1):

- Run mst status in the server side:

```
[root@mft ~]# mst status
MST modules:
-----
MST PCI module loaded
MST PCI configuration module loaded

MST devices:
-----
/dev/mst/mt4099_pciconf0 - PCI configuration cycles access.
                        domain:bus:dev.fn=0000:0b:00.0 addr.reg=88 data.reg=92
                        Chip revision is: B0
/dev/mst/mt4099_pci_cr0  - PCI direct access.
                        domain:bus:dev.fn=0000:0b:00.0 bar=0xd2600000 size=0x100000
                        Chip revision is: B0
/dev/mst/mtusb-1:       - USB to I2C adapter as I2C master
```

- Start the mst server in the 'server side':

```
[root@mft ~]# mst server start
```

- Add mst remote device in the client side:

```
[root@mft1 ~]# mst remote add mft
```

4. Show the mst device in the 'client side' which contains remote devices for the 'server side' machine:

```
[root@mft1 ~]# mst status
MST modules:
-----
MST PCI module loaded
MST PCI configuration module loaded

MST devices:
-----
/dev/mst/mt4099_pciconf0 - PCI configuration cycles access.
                        domain:bus:dev.fn=0000:0b:00.0 addr.reg=88 data.reg=92
                        Chip revision is: 01
/dev/mst/mt4099_pci_cr0 - PCI direct access.
                        domain:bus:dev.fn=0000:0b:00.0 bar=0xd2600000 size=0x100000
                        Chip revision is: 01

Remote MST devices:
-----
/dev/mst/mft:23108,@dev@mst@mt4099_pciconf0
                        Chip revision is: B0
/dev/mst/mft:23108,@dev@mst@mt4099_pci_cr0
                        Chip revision is: B0
/dev/mst/mft:23108,@dev@mst@mtusb-1
```

5. Access a remote mst device from the 'client side':

```
[root@mft1 ~]# flint -d
/dev/mst/mft:23108,@dev@mst@mt4099_pci_cr0 q
Image type:      FS2
FW Version:      2.32.1092
FW Release Date: 17.8.2014
Rom Info:        type=PXE version=3.5.305 cpu=AMD64
Device ID:       4099
Description:     Node          Port1          Port2          Sys image
GUIDs:          0002c90300e6e4e0 0002c90300e6e4e1 0002c90300e6e4e2 0002c90300e6e4e3
MACs:           n/a          0002c9e6e4e1   0002c9e6e4e2
VSD:            n/a
PSID:           MT_1090120019
```

### 3.9.2.5 Accessing Remote InfiniBand Device by Direct Route MADs

To access IB devices remotely by direct route MADs (except for ConnectX-3 and ConnectX-3 Pro):

1. Make sure the local ports are connected to a node or more:

```
# ibstat
```

or

```
# ibv_devinfo
```

2. Obtain the device direct route path:

```
# mst ib add --use-ibdr --discover-tool ibnetdiscover mlx5_0 1
-I- Discovering the fabric - Running: ibnetdiscover -s -C mlx5_0 -P 1
-I- Added 2 in-band devices
```

3. List the discovered direct route device:

```
# mst status MST modules:
-----
MST PCI module loaded
MST PCI configuration module loaded
MST devices:
-----
...
Inband devices:
-----
/dev/mst/CA_MT4113_server1_HCA-3_ibdr-0,mlx5_0,1
/dev/mst/SW_MT51000_switch1_ibdr-0.2,mlx5_0,1
```

#### 4. Run any tool against the devices above.

```
#flint -d /dev/mst/CA_MT4113_server1_HCA-3_ibdr-0,mlx5_0,2 v
FS3 failsafe image
/0x00000038-0x0000f4f (0x000f18) / (BOOT2) - OK
/0x00201000-0x0020101f (0x000020) / (ITOC_Header) - OK
/0x00203000-0x0020323f (0x000240) / (FW_MAIN_CFG) - OK
/0x00204000-0x0020437f (0x000380) / (FW_BOOT_CFG) - OK
/0x00205000-0x002057ff (0x000800) / (HW_MAIN_CFG) - OK
/0x00206000-0x002060ff (0x000100) / (HW_BOOT_CFG) - OK
/0x00207000-0x002195e3 (0x0125e4) / (PCT_CODE) - OK
/0x0021a000-0x0021e3a7 (0x0043a8) / (IRON_PREP_CODE) - OK
/0x0021f000-0x00226bab (0x007bac) / (PCIE_LINK_CODE) - OK
/0x00227000-0x002a888f (0x081890) / (MAIN_CODE) - OK
/0x002a9000-0x002a95bf (0x0005c0) / (POST_IRON_BOOT_CODE) - OK
/0x002aa000-0x002aa3ff (0x000400) / (IMAGE_INFO) - OK
/0x002aa400-0x002b3e7b (0x0009a7c) / (FW_ADB) - OK
/0x002b3e7c-0x002b4277 (0x0003fc) / (DBG_LOG_MAP) - OK
/0x002b4278-0x002b427f (0x000008) / (DBG_FW_PARAMS) - OK
/0x003fa000-0x003fbfff (0x002000) / (NV_DATA) - OK
/0x003fd000-0x003fd1ff (0x000200) / (DEV_INFO) - OK
/0x003ff000-0x003ff13f (0x000140) / (MFG_INFO) - OK
/0x003ff140-0x003ff13f (0x000000) / (VPD_R0) - OK
FW image verification succeeded. Image is bootable.
```

### 3.9.3 Booting HCA Device in Livefish Mode

In case a MLNX HCA fails to boot properly, and is not being identified by the system due to a corrupt firmware, the user is able to boot the card in livefish mode, which allows re-burning of the flash device in order to restore the device into functional mode.

The device can also be forced into booting in livefish mode (only when supported on the board). To do so, a direct access to the card is needed. By connecting the two flash present pins using a jumper while the machine is powered off, the card will boot in "flash not present" mode (the firmware will not be loaded from the flash) i.e livefish.

#### 3.9.3.1 Booting Card in Livefish Mode

To boot the card in livefish mode:

1. Power off the machine.
2. Locate the Flash preset pins on the HCA.
3. Close the two pins using a jumper.
4. Power on the machine.

#### 3.9.3.2 Booting Card in Normal Mode

To boot the card in normal mode:



1. Power off the machine.
2. Take off the jumper connected to the Flash Present pins on the HCA.
3. Power on the machine.

#### 3.9.3.3 Common Locations of Flash Present Pins

The following photos show common locations of the Flash Present pins.



Existence and location of Flash Present pins depends on the board manufacture.



### 3.9.4 Burning a New Device

Select the appropriate method depending upon your device model.

- [Connect-IB Adapter Card](#)
- [ConnectX-4 onwards Adapter Cards Family](#)
- [Spectrum or Switch-IB 2 Switch Systems](#)
- [Switch-IB Switch System](#)

### 3.9.4.1 Connect-IB Adapter Card

When burning a flash for the first time, the initial image should contain the correct GUIDs and VPD for the device. Subsequent firmware updates will not change these initial setting.



flint for OEM is required for burning Connect-IB for the first time.

#### 3.9.4.1.1 GUIDs and MACs

The Connect-IB image contains the Node, Port and System GUIDs and Port MACs to be used by the card. To simplify GUIDs assignment, the mlxburn tool can derive the MACs and GUIDs from a single base GUID according to NVIDIA methodology:

```
Description: UID          Number  Step
Port1 GUID:  base        8        1
Port2 GUID:  base + 8    8        1
Port1 MAC:   guid2mac1(base) 8        1
Port2 MAC:   guid2mac(base + 8) 8        1
```

Note: `guid2mac(guid)` is `((guid >> 16) & 0xfffff000000) | (guid & 0xfffff)`. Meaning, remove the 2 middle bytes of an 8 bytes GUID to generate a 6 bytes MAC.

#### 3.9.4.1.2 PCI Vital Product Data (VPD)

The VPD information is returned by the firmware upon VPD access from the PCI configuration header.

- The `vpd_ro` file last 3 bytes are the `vpd_rw` tag-id and length
- The size of the `vpd_r` file (including the above 3 bytes) should be a multiple of 4

#### 3.9.4.1.3 Burning a New Connect-IB Device

The VPD and GUIDs are stored in the last sector on flash that can be set as Write protected after the initial firmware burn.

##### 3.9.4.1.3.1 Method 1: Generating Firmware with Specific GUIDs and Burning on the Flash

1. Generate the initial image with the correct GUIDs and VPD for the specific device, using the `mlxburn` tool. The generated image occupies full flash size.

```
# mlxburn -fw FW/fw-ConnectIB.mlx -c FW/MCB194A-FCA_A1.ini -wimage fw-ConnectIB-MCB194A-FCA_A1.bin
-base_guid 0x0002c903002ef500 -vpd_r_file ./vpd_r_data.bin
```

2. Disable the Write protection.

```
# flint -d /dev/mst/mt511_pciconf0 -ocr hw set Flash0.WriteProtected=Disabled
```

3. Burn the entire flash, using the `flint` tool.

```
# flint -d /dev/mst/mt511_pciconf0 -i ./fw-ConnectIB-MCB194A-FCA_A1.bin -ocr -ignore_dev_data
-allow_psid_change -nofs --yes burn
```

4. Set Write protection on the last sector, using mstflint:

For devices using Winbond flash:

```
# flint -d /dev/mst/mt511_pciconf0 -ocr hw set Flash0.WriteProtected=Top,1-SubSectors
```

5. Enable flash quad SPI IO operations.

```
# flint -d /dev/mst/mt511_pciconf0 -ocr hw set QuadEn=1
```

### 3.9.4.1.3.2 Method 2: Generating Firmware Image with Blank GUIDs, Burning and Setting GUIDs on the Flash

1. Generate the initial image with VPD for the specific device, using the mlxburn tool. The generated image occupies full flash size.

```
# mlxburn -fw FW/fw-ConnectIB.mlx -c FW/MCB194A-FCA_A1.ini -wimage fw-ConnectIB-MCB194A-FCA_A1.bin  
-vpd_r_file ./vpd_r_data.bin
```

2. Disable the Write protection.

```
# flint -d /dev/mst/mt511_pciconf0 -ocr hw set Flash0.WriteProtected=Disabled
```

3. Burn the entire flash.

```
# flint -d /dev/mst/mt511_pciconf0 -i ./fw-ConnectIB-MCB194A-FCA_A1.bin -ocr -ignore_dev_data  
-allow_psid_change -nofs --yes burn
```

4. Set device manufacture GUIDs.

```
# flint -d /dev/mst/mt511_pciconf0 -ocr -uid 0x0002c903002ef500 smg
```

5. Set device GUIDs.

```
# flint -d /dev/mst/mt511_pciconf0 -ocr -uid 0x0002c903002ef500 sg
```

6. Set Write Protection on the last sector, using the mstflint tool.

For devices using Winbond flash:

```
# flint -d /dev/mst/mt511_pciconf0 -ocr hw set Flash0.WriteProtected=Top,1-SubSectors
```

7. Enable flash quad SPI IO operations:

```
# flint -d /dev/mst/mt511_pciconf0 -ocr hw set QuadEn=1
```

a. To view flash settings, run:

```
# flint -d /dev/mst/mt511_pciconf0 -ocr hw query
```

b. To view assigned GUIDs, run:

```
# flint -d /dev/mst/mt511_pciconf0 -ocr q
```

c. To change a GUID after the initial burn, run:

```
# flint -d /dev/mst/mt4113_pciconf0 -ocr -uid 0x0002c903002ef500 sg
```

### 3.9.4.2 ConnectX-4 onwards Adapter Cards Family

Upon first time device burning, the GUIDs, MACs and VPD of the device are required to be set on the flash.

The sections below demonstrate two methods of burning a new ConnectX-4 onwards device in order to set these initial settings. Subsequent firmware updates will not change these settings.



flint for OEM is required for burning ConnectX-4 onwards adapter cards family for the first time.

For information regarding GUIDs, MACs and VPD, please refer to [Accessing Remote InfiniBand Device by Direct Route MADs](#).

#### 3.9.4.2.1 Burning the ConnectX-4 onwards Adapter Cards Family

##### 3.9.4.2.1.1 Method 1: Generating Firmware with Specific GUIDs and MACs and Burning it on the Device

In order to burn a new device, follow the steps below:

1. Disable the Write protection.

```
# flint -d /dev/mst/mt521_pciconf0 -ocr hw set Flash0.WriteProtected=Disabled
```

2. Burn the entire flash.

```
# flint -d /dev/mst/mt521_pciconf0 -i ./ fw-ConnectX4- MCX454_Ax.bin -ocr -ignore_dev_data -allow_psid_change -nofs --yes burn
```

3. Set Write protection

```
# flint -d /dev/mst/mt521_pciconf0 -ocr hw set Flash0.WriteProtected=Top,8-SubSectors
```

4. Enable flash quad SPI IO operations.

```
# flint -d /dev/mst/mt521_pciconf0 -ocr hw set QuadEn=1
```

##### 3.9.4.2.1.2 Method 2: Generating Firmware Image with Blank GUIDs, Burning and Setting GUIDs on the Device

In order to burn a new device, follow the steps below:

1. Disable the Write protection.

```
# flint -d /dev/mst/mt521_pciconf0 -ocr hw set Flash0.WriteProtected=Disabled
```

2. Burn the entire flash.

```
# flint -d /dev/mst/mt521_pciconf0 -i ./ fw- ConnectX4- MCX454_Ax.bin -ocr -ignore_dev_data -
allow_psid_change -nofs --yes burn
```

### 3. Set device manufacture GUIDs and MACs.

```
# flint -d /dev/mst/mt521_pciconf0 -ocr -guid 0xe41d2d0300570fc0 -mac 0x0000e41d2d570fc0 smg
```

### 4. Set device GUIDs and MACs.

```
# flint -d /dev/mst/mt521_pciconf0 -ocr -guid 0xe41d2d0300570fc0 -mac 0x0000e41d2d570fc0 sg
```

### 5. Set Write protection on the last sector using flint:

```
# flint -d /dev/mst/mt521_pciconf0 -ocr hw set Flash0.WriteProtected=Top,8-SubSectors
```



The command may vary based on the Flash type used.

Protection\_type can be :

- 1- Top,8-SubSectors, if it is in [W25QxxBV]
- 2- Top,1-Sectors, if it is in [MX25L16xxx, N25Q0XX, IS25LPxxx, S25FL256L, MX25Lxxx, W25Qxxx, MX25Uxxx]

### 6. Enable flash quad SPI IO operations.

```
# flint -d /dev/mst/mt521_pciconf0 -ocr hw set QuadEn=1
```

#### a. To view flash settings:

```
# flint -d /dev/mst/mt521_pciconf0 -ocr hw query
```

#### b. To view assigned GUIDs:

```
# flint -d /dev/mst/mt521_pciconf0 -ocr
```

#### c. To change a GUID after the initial burn:

```
# flint -d /dev/mst/mt4115_pciconf0 -ocr -guid 0xe41d2d0300570fc0 sg
```

#### d. To change a MAC after the initial burn:

```
# flint -d /dev/mst/mt4115_pciconf0 -ocr -mac 0x0000e41d2d570fc0 sg
```

#### e. To change a GUID and derive MAC from it after the initial burn, run:

```
# flint -d /dev/mst/mt4115_pciconf0 -ocr -uid 0xe41d2d0300570fc0 sg
```

### 3.9.4.3 Spectrum or Switch-IB 2 Switch Systems

Upon first time flash burning, the GUIDs and VPD of the device are required to be set on the flash. The sections below demonstrate two methods of burning a new device in order to set these initial settings. Subsequent firmware updates will not change these settings.



flint for OEM is required for burning Spectrum/Switch-IB 2 for the first time.

For information regarding GUIDs, MACs and VPD, please refer to [Accessing Remote InfiniBand Device by Direct Route MADs](#).

#### 3.9.4.3.1 Burning the Spectrum/Switch-IB 2 Device

##### 3.9.4.3.1.1 Method 1: Generating Firmware with Specific GUIDs and MACs and Burning it on Device

In order to burn a new Spectrum/Switch-IB 2 device, follow the steps below:

1. Generate the initial image with the correct GUIDs and VPD for the specific device using the mlxburn tool. The generated image occupies full flash size.

```
# mlxburn -fw FW/fw-Spectrum.mlx -c FW/MCB194A-FCA_A1.ini -wrimage fw-Spectrum-MCB194A- FCA_A1.bin  
-base_guid 0x0002c903002ef500 -base_mac 0x02c90ef500 -vpd_r_file ./vpd_r_data.bin
```

2. Disable Write protection.

```
# flint -d /dev/mst/mt585_pciconf0 -override_cache_replacement hw set Flash0.WritePro-  
tected=Disabled
```

3. Burn the entire flash.

```
# flint -d /dev/mst/mt585_pciconf0 -i ./fw-Spectrum-MCB194A-FCA_A1.bin -override_cache_re-  
placement -ignore_dev_data -nofs -allow_psid_change -y b
```

4. Set Write protection.

```
# flint -d /dev/mst/mt585_pciconf0 -override_cache_replacement hw set  
Flash0.WriteProtected=Top,8-SubSectors
```

5. Enable flash quad SPI IO operations.

```
# flint -d /dev/mst/mt585_pciconf0 -override_cache_replacement hw set QuadEn=1
```

##### 3.9.4.3.1.2 Method 2: Generating a Firmware Image with Blank GUIDs, Burning and Setting GUIDs on the Device

In order to burn a new Spectrum/Switch-IB 2 device, follow the steps below:

1. Generate the initial image VPD for the specific device using the mlxburn tool. The generated image occupies full flash size.

```
# mlxburn -fw FW/fw-Spectrum.mlx -c FW/MCB194A-FCA_A1.ini -wrimage fw-Spectrum-MCB194A- FCA_A1.bin  
-vpd_r_file ./vpd_r_data.bin
```

## 2. Disable Write protection.

```
# flint -d /dev/mst/mt585_pciconf0 -override_cache_replacement hw set Flash0.WriteProtected=Disabled
```

## 3. Burn the entire flash using the flint tool.

```
# flint -d /dev/mst/mt585_pciconf0 -i ./fw-Spectrum-MCB194A-FCA_A1.bin -ocr -ignore_dev_data -nofs -allow_psid_change -y b
```

## 4. Set device manufacture GUIDs and MACs.

```
# flint -d /dev/mst/mt585_pciconf0 -ocr -guid 0xe41d2d0300570fc0 -mac 0x0000e41d2d570fc0 smg
```

## 5. Set device GUIDs and MACs.

```
# flint -d /dev/mst/mt585_pciconf0 -ocr -guid 0xe41d2d0300570fc0 -mac 0x0000e41d2d570fc0 sg
```

## 6. Set Write protection on the last sector.

```
# flint -d /dev/mst/mt585_pciconf0 -ocr hw set Flash0.WriteProtected=Top,8-SubSectors
```

## 7. Enable flash quad SPI IO operations.

```
# flint -d /dev/mst/mt585_pciconf0 -ocr hw set QuadEn=1
```

### a. To view flash settings:

```
# flint -d /dev/mst/mt53000_pciconf0 -ocr hw query
```

### b. To view assigned GUIDs:

```
# flint -d /dev/mst/mt53000_pciconf0 -ocr q
```

### c. To change a GUID after the initial burn:

```
# flint -d /dev/mst/mt53000_pciconf0 -ocr -guid 0xe41d2d0300570fc0 sg
```

### d. To change a MAC after the initial burn:

```
# flint -d /dev/mst/mt53000_pciconf0 -ocr -mac 0x0000e41d2d570fc0 sg
```

### e. To change a GUID and derive MAC from it after the initial burn, run:

```
# flint -d /dev/mst/mt53000_pciconf0 -ocr -uid 0xe41d2d0300570fc0 sg
```

## 3.9.4.4 Switch-IB Switch System

Upon first time flash burning, the GUIDs and VPD of the device are required to be set on the flash.

The sections below demonstrate two methods of burning a new Switch-IB device in order to set these initial settings. Subsequent firmware updates will not change these settings.



flint for OEM is required for burning Switch-IB for the first time.

For information regarding GUIDs, MACs and VPD, please refer to [Accessing Remote InfiniBand Device by Direct Route MADs](#).

### 3.9.4.4.1 Burning the Switch-IB Device

The examples below are for managed switches. For unmanaged switches, connect an MTUSB adapter (see [MTUSB-1 USB to I2C Adapter](#)) to the device and use the appropriate mst device (/dev/mst/mtusb...).

#### 3.9.4.4.1.1 Method 1: Generating Firmware with Specific GUIDs and Burning it on the Flash

In order to burn a new Switch-IB device, follow the steps below:

1. Generate the initial image with the correct GUIDs and VPD for the specific device using the mlxburn tool. The generated image occupies full flash size.

```
# mlxburn -fw FW/fw-SwitchIB.mlx -c FW/MSB7700-E_Ax.ini -wimage fw-SwitchIB-MSB7700-E_Ax.bin -base_guid 0x0002c903002ef500 -vpd_r_file ./vpd_r_data.bin
```

2. Disable the Write protection.

```
# flint -d /dev/mst/mt583_pciconf0 -ocr hw set Flash0.WriteProtected=Disabled  
# flint -d /dev/mst/mt583_pciconf0 -ocr hw set Flash1.WriteProtected=Disabled
```

3. Burn the entire flash.

```
# flint -d /dev/mst/mt583_pciconf0 -i ./ fw-SwitchIB-MSB7700-E_Ax.bin -ocr -ignore_dev_data -allow_psid_change -nofs --yes burn
```

4. Set Write protection.

```
# flint -d /dev/mst/mt583_pciconf0 -ocr hw set Flash0.WriteProtected=Top,2-SubSectors
```

5. Enable flash quad SPI IO operations.

```
# flint -d /dev/mst/mt583_pciconf0 -ocr hw set QuadEn=1
```

#### 3.9.4.4.1.2 Method 2: Generating Firmware Image with Blank GUIDs, Burning and Setting GUIDs on the Flash

In order to burn a new Switch-IB device, follow the steps below:

1. Generate the initial image VPD for the specific device using the mlxburn tool. The generated image occupies full flash size.

```
# mlxburn -fw FW/fw-SwitchIB.mlx -c FW/MSB7700-E_Ax.ini -wimage fw-SwitchIB-MSB7700-E_Ax.bin -vpd_r_file ./vpd_r_data.bin
```

2. Disable the Write protection.

```
# flint -d /dev/mst/mt583_pciconf0 -ocr hw set Flash0.WriteProtected=Disabled
# flint -d /dev/mst/mt583_pciconf0 -ocr hw set Flash1.WriteProtected=Disabled
```

### 3. Burn the entire flash.

```
# flint -d /dev/mst/mt583_pciconf0 -i ./ fw-SwitchIB-MSB7700-E_Ax.bin - ocr -ignore_dev_data
-allow_psid_change -nofs --yes burn
```

### 4. Set device manufacture GUIDs.

```
# flint -d /dev/mst/mt583_pciconf0 -ocr -uid 0x0002c903002ef500 smg
```

### 5. Set device GUIDs.

```
# flint -d /dev/mst/mt583_pciconf0 -ocr -uid 0x0002c903002ef500 sg
```

### 6. Set Write protection.

```
# flint -d /dev/mst/mt583_pciconf0 -ocr hw set Flash0.WriteProtected=Top,2-SubSectors
# flint -d /dev/mst/mt583_pciconf0 -ocr hw set Flash1.WriteProtected=Top,1-SubSectors
```

### 7. Enable flash quad SPI IO operations.

```
# flint -d /dev/mst/mt583_pciconf0 -ocr hw set QuadEn=1
```

#### a. To view flash settings:

```
# flint -d /dev/mst/mt583_pciconf0 -ocr hw query
```

#### b. To view assigned GUIDs:

```
# flint -d /dev/mst/mt583_pciconf0 -ocr q
```

#### c. To change a GUID after the initial burn:

```
# flint -d /dev/mst/mt52000_pciconf0 -ocr -uid 0x0002c903002ef500 sg
```

## 3.9.5 Generating Firmware Secure and NV LifeCycle Configurations Files

### 3.9.5.1 Create Forbidden Versions Binary File

The flint "set\_forbidden\_versions" command takes as a parameter the binary file that contains the forbidden versions. To create this file easily you can use the mlxconfig "xml2bin" command. The forbidden versions configuration is found in the mlxconfig database.

1. Run mlxconfig "gen\_tlvs\_file".
2. Choose "nv\_forbidden\_versions".
3. Generate XML template using mlxconfig "gen\_xml\_template".
4. Set values for the parameters in the XML template.

You can set up to 32 forbidden versions. mlxconfig requires all the parameters in the XML

template to have values, so in case you want to fill only one forbidden version you have to set the other 31 parameters to zero, you can do that by using index range as follows:

```
<forbidden_fw_version index='1..31' >0x0</forbidden_fw_version>
```

5. Run the `xml2bin` command to generate the binary file.

### 3.9.5.2 Create Tokens for Secure Firmware and NV LifeCycle

`mlxconfig` can be used to generate CS tokens, debug tokens and NV LifeCycle configuration files and apply it on your device.

To create the tokens:

1. Generate XML template that contains the necessary configurations for the token.  
The XML template must have only one token configuration. The current available token configurations are: debug token, challenge based debug token, customer token, challenge based customer token and MLNX ID token.  
The XML must also have the `file_applicable_to` configuration for all devices and an additional configuration which is device dependent:
  - a. For cables include the `file_device_unique` configuration.
  - b. For other devices include the `file_mac_addr_list` configuration.
2. Generate a binary file that can be applied to the device using the `mlxconfig create_conf` command.

### 3.9.6 Updating Firmware Using `ethtool`/`devlink` and `.mfa2` File

In order to flash the firmware on the device using `ethtool`, you need to prepare a `.mfa2` firmware file using the `mlxarchive` tool - see [mlxarchive - Binary Files Compression Tool](#). Note that `mlxarchive` requires installing MFT with `--oem` option.



*To perform firmware upgrade using `ethtool`/`devlink`, follow the steps below:*

1. Run the `mlxarchive` tool to generate the `.mfa2` file (the following example assumes MFA2 v1.1.1).

```
# mlxarchive -v 1.1.1 --bins-dir <source binaries directory> --out-file /lib/firmware/<file_name>.mfa2
```

2. Obtain the interface name of the adapter for which you wish to update firmware. For example, you can use `ifconfig -a`.

```
# ifconfig -a
...
p5p1: flags=4099<UP,BROADCAST,MULTICAST> mtu 1500
    ether ec:0d:9a:48:af:2a txqueuelen 1000 (Ethernet)
    RX packets 0 bytes 0 (0.0 B)
    RX errors 0 dropped 0 overruns 0 frame 0
    TX packets 0 bytes 0 (0.0 B)
    TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0

p5p2: flags=4099<UP,BROADCAST,MULTICAST> mtu 1500
    ether ec:0d:9a:48:af:2b txqueuelen 1000 (Ethernet)
    RX packets 0 bytes 0 (0.0 B)
    RX errors 0 dropped 0 overruns 0 frame 0
    TX packets 0 bytes 0 (0.0 B)
```

```
... TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0
```

3. Burn the firmware using the .mfa2 image with ethtool/devlink. Please use the .mfa2 file path relative to /lib/firmware.

ethtool command:

```
# ethtool -f <interface name> <file_name>.mfa2
```

devlink command:

```
$ devlink dev flash <dev> file <file_name>.mfa2
```

4. Query the adapter to verify that the new firmware version has been loaded following.

```
# mst start
# mst status -v
MST modules:
-----
MST PCI module loaded
MST PCI configuration module loaded
PCI devices:
-----
DEVICE_TYPE          MST                      PCI          RDMA          NET
-----
NUMA
ConnectX5 (rev:0)    /dev/mst/mt4119_pciconf0.1  05:00.1  mlx5_3        net-p5p2          0
ConnectX5 (rev:0)    /dev/mst/mt4119_pciconf0    05:00.0  mlx5_2        net-p5p1          0
...
#
# flint -d /dev/mst/mt4119_pciconf0 q
Image type:          FS4FW Version: 16.25.1042 FW Version(Running): 16.25.1020 FW Release Date: 30.4.2019
Product Version: 16.25.1020 Rom Info: type=UEFI version=14.18.19 cpu=AMD64 type=PXE version=3.5.701
cpu=AMD64 Description: UID GuidNumber Base GUID: ec0d9a030048af2a 4 Base MAC: ec0d9a48af2a 4 Image VSD:
N/A Device VSD: N/A PSID: MT_0000000080 Security Attributes: N/A
```

5. For the firmware update to take effect, you need to either reboot the server or run:

```
# mlxfwreset -d /dev/mst/mt4119_pciconf0 -y r
```

6. Validate the firmware update by a query.

Using mst:

```
# mst start
# flint -d /dev/mst/mt4119_pciconf0 q
Image type:          FS4
FW Version:          16.25.1042
FW Release Date:     15.5.2019
Product Version:     16.25.1042
Rom Info:             type=UEFI version=14.18.19 cpu=AMD64
                    type=PXE version=3.5.701 cpu=AMD64
Description:         UID GuidNumber
Base GUID:           ec0d9a030048af2a 4
Base MAC:            ec0d9a48af2a 4
Image VSD:           N/A
Device VSD:          N/A
PSID:                MT_0000000080
Security Attributes: N/A
#
```

Using devlink:

```
$ devlink dev info <dev>
pci/0000:05:00.0:
driver mlx5_core
versions:
fixed: fw.psid MT_0000000080
running: fw.version 16.23.1000
stored: fw.version 16.25.1042
```

## 3.9.7 Using MFT tools on Secured GPU Devices

In systems with secured FW, GPUs cannot be accessed directly via PCIe, therefore "pci\_cr" devices will become inaccessible.

The only way to send firmware queries is via the NVIDIA GPU Driver.

Please follow these instructions to discover and display GPU devices on your secured system:

1. Make sure the NVIDIA driver is loaded using "modprobe nvidia".
2. Start the mst service by running "mst start" command.
3. Discover GPU devices via the NVIDIA Driver using the "mst gpu add" command.
4. See the newly added devices using "mst status -v" command, they will appear under "GPU Devices".

Run any of the supported tools using the GPU NETIR mst device. For example:

```
mlxlink -d /dev/mst/netir10561_08.1.00_gpu0
```

## 3.10 ESXi

The MFT and MFT-OEM packages in VMware now include a new plugin feature. This plugin can be accessed and managed using the following command within the ESXi shell:

```
esxcli mellanox <package name> <tool name> <command>
```

For example:

```
esxcli mellanox mst status
```

To enable this functionality without requiring additional code for each tool, a wrapper has been implemented. This wrapper encapsulates the tool's command and ensures the output is returned in the correct XML format.

Additionally, a plugin generator has been developed. This generator automatically creates the necessary XML files for each tool during the packaging process, streamlining the integration of new tools into the plugin framework.

There are a few challenges with integrating existing tools into the ESXi plugin:

- Tools that generate output during their execution (e.g., progress indicators like percentage bars in mlxfwmanager) can cause issues with the VMware plugin if not handled properly
  - To address this, some tools might need to provide an option to suppress such progress indicators. For example, mlxfwmanager includes the `--no-progress` flag for this purpose
- If a tool requires user input or prompts during its execution, it must provide clear mechanisms for handling these interactions within the context of the VMware plugin
  - This may include options for non-interactive execution (e.g., `--yes`, `--force`) or clear and well-defined prompts with expected input formats and error handling
- If a tool prints output with colors, the wrapper converts the color output to regular, otherwise the VMware plugin will fail

In summary:

- Each tool might require specific adjustments or workarounds to ensure compatibility with the VMware plugin.
- In some cases, the tool's output format or behavior may be inherently incompatible with the plugin's requirements, preventing successful integration.

By carefully considering these factors and implementing appropriate solutions (such as using suppression flags or modifying tool behavior), we can maximize the number of tools that can be successfully integrated with the VMware plugin.

### 3.10.1 Supported plugin commands:

Description	Original Command	esxcli plugin command
Create special files that represent Nvidia devices in directory /dev/mst. After successfully completion of this command the MST driver is ready to work and you can invoke other Nvidia tools.	/opt/mellanox/bin/ <b>mst start</b>	esxcli mellanox mft <b>mst start</b>
Stop Nvidia MST driver service.	/opt/mellanox/bin/ <b>mst stop</b>	esxcli mellanox mft <b>mst stop</b>
Show all Nvidia devices connected to server	/opt/mellanox/bin/ <b>mst status</b>	esxcli mellanox mft <b>mst status</b>
Show all Nvidia devices connected to server [verbose mode]	/opt/mellanox/bin/ <b>mst status -v</b>	esxcli mellanox mft <b>mst status -v</b> esxcli mellanox mft <b>mst status --verbose</b>
Query all devices connected to server	/opt/mellanox/bin/ <b>mlxfwmanager</b>	esxcli mellanox mft <b>mlxfwmanager query</b>
Query device and look for available online FW for the given device from NVIDIA web-site , if current FW version older than latest one , FW upgrade will be done	/opt/mellanox/bin/ <b>mlxfwmanager --online --update --no-progress --yes</b>	esxcli mellanox mft <b>mlxfwmanager update</b>
Burn FW image to a given device	/opt/mellanox/bin/ <b>flint -d &lt;dev&gt; -i &lt;image&gt; --silent -y b</b>	esxcli mellanox mft <b>flint burn -d &lt;dev&gt; -i &lt;image&gt; --run</b>
start MST server for remote connections	/opt/mellanox/ <b>mst server start -s &lt;pass&gt;</b>	esxcli mellanox mft <b>mst serverStart -s &lt;passphrase&gt; -p &lt;port&gt;</b>
Stop MST server	/opt/mellanox/ <b>mst server stop</b>	esxcli mellanox mft <b>mst serverStop</b>
Query specific device connected to server	/opt/mellanox/bin/ <b>flint -d &lt;dev&gt; q</b>	esxcli mellanox mft <b>flint query -d &lt;dev&gt; --run</b>
Query specific device connected to server with full option	/opt/mellanox/bin/ <b>flint -d &lt;dev&gt; q full</b>	esxcli mellanox mft <b>flint query -d &lt;dev&gt; --run --full</b>
Verify entire device flash	/opt/mellanox/bin/ <b>flint -d &lt;dev&gt; v</b>	esxcli mellanox mft <b>flint verify -d &lt;dev&gt; --run</b>
Show all mlxreg available supported registers for the given device	/opt/mellanox/bin/ <b>mlxreg -d &lt;dev&gt; show_regs</b>	esxcli mellanox mft <b>mlxreg showRegs -d &lt;dev&gt;</b>

The dump file is used by the Support team for hardware troubleshooting purposes. It can be applied on all NVIDIA devices.	<code>/opt/mellanox/bin/mstdump &lt;dev&gt; device_name.dmp</code>	<code>esxcli mellanox mft mstdump dump -d &lt;dev&gt;</code>
Read the hardware temperature from NVIDIA devices with temperature sensors (all NVIDIA devices) and prints the result in Celsius degrees.	<code>/opt/mellanox/bin/mget_temp -d &lt;dev&gt;</code>	<code>esxcli mellanox mft mgettemp read -d &lt;dev&gt;</code>
Show NVIDIA device link status	<code>/opt/mellanox/bin/mlxlink -d &lt;dev&gt;</code>	<code>esxcli mellanox mft mlxlink status -d &lt;dev&gt;</code>



If you're not sure how to run a command or you want to explore the available flag shortcuts in the esxcli plugin, you can check it by writing a partial start of a command and utilizing the output you're getting to figure out what to write next.

Example: flint tool

Write the beginning of the command like this:

```
esxcli mellanox mft flint
```

the output will be the available options for the continuation of the command:

```
[root@apps-35:~] esxcli mellanox mft flint
Usage: esxcli mellanox mft flint {cmd} [cmd options]

Available Commands:
  burn          Burn flash.
  query         Query misc. flash/firmware characteristics, use "full" to get more information.
  verify        Verify entire flash.
  version       Display flint version
[root@apps-35:~] █
```

And you can continue the command with the option you'd like to proceed with, to see which flags are needed for the chosen command.

For example, if you'd like to choose the "verify" command, write:

```
esxcli mellanox mft flint verify
```

the following output will be displayed:

```
[root@apps-35:~] esxcli mellanox mft flint verify
Error: Missing required parameter -r|--run

Usage: esxcli mellanox mft flint verify [cmd options]

Description:
  verify                Verify entire flash.

Cmd options:
  -d|--device=<str>    Device flash is connected to.
  -r|--run              Use "--run" to execute command. (required)
[root@apps-35:~] █
```

Please note that in the flint command the user must use the --run or -r flag to run the command. If the user forgets to use the required command, an informative error message will be displayed:

```
[root@apps-35:~] esxcli mellanox mft flint verify -d mt4119_pciconf0
Error: Missing required parameter -r|--run

Usage: esxcli mellanox mft flint verify [cmd options]


Description:
  verify                Verify entire flash.

Cmd options:
  -d|--device=<str>    Device flash is connected to.
  -r|--run              Use "--run" to execute command. (required)
[root@apps-35:~] █
```

## 4 Document Revision History

### 4.1 Release Notes Revision History

#### 4.1.1 MFT Release Notes Change Log History

Component/Tool	Description	Operating System
<b>Rev. 4.35.0-159</b>		
General	MFT v4.35.0 introduces support for the NVIDIA ConnectX-9 SuperNIC, making it the first GA MFT release to enable ConnectX-9.	All
	Changed payload compression method for DEB and RPM packages to gzip format.	All
fwctl	Added support for fwctl interface. <div style="border: 1px solid orange; padding: 5px; margin-top: 10px;">  fwctl interface is only for PRM based tools.         </div>	Linux Kernel v6.8 and above that has: <ul style="list-style-type: none"> <li>• fwctl subsystem support</li> <li>• mlx5_core driver built/available in Kernel</li> </ul>
MST	Added support to display STATE column when running "mst status -v" command. This column will be used for recovery indication: for devices in recovery mode "recovery" will be printed.	All
DMA	Added support for a new feature which detects when DMA Protection is enabled and avoid using DMA in that case.	Windows
<a href="#">mlxlink</a>	Added a new column to the show_links table to reflect the PCIE link status (UP\DN).	All
	Added support for a new field in show_plr flag to reflect the operational PLR state.	All
	Added support for test mode on switches where the modules are not in firmware control.	All
	Added support for giving dbdf information instead of just bdf when running <code>mlxlink -d &lt;dev&gt; -port_type PCIE -show_links tool</code> .	All
Bug Fixes	See <a href="#">MFT Bug Fixes in this Version</a> .	All
<b>Rev. 4.34.0-145</b>		
nvredfish	Added support for nvredfish tool.	All
mdevices_info	Added <code>--enable-vfio</code> configure flag to make VFIO library optional.	All

mlxconfig	Added support for <code>--with_default</code> flag for mlxconfig tool.	All
	Added support for <code>--host_id</code> and <code>pf_index</code> flags in mlxconfig tool.	All
mlxlink	Added support for <code>--rx_modulation</code> and <code>--tx_modulation</code> flags to the test mode flow. Modulation status is shown in mlxlink output when in test mode.	All
mlxreg	Exposed the syndrome in mlxreg in external MFT package.	All
mlxdpa	Added commands for creating, signing, and removing a single application. Also, added support for <code>keep_sig</code> flag for container creation.	All
Component/ Tool	Description	Operating System
Rev. 4.33.0-169		
mlxfwmanager	Added the ability to skip firmware update when the target image is already burned on the device and the user used the <code>skip_if_same</code> flag. Usage: <ul style="list-style-type: none"> <li><code>mlxfwmanager -d &lt;&gt; -u --skip_if_same -i &lt;.mfa&gt;</code></li> <li><code>flint -d &lt;&gt; -i &lt;.bin&gt; --skip_if_same b</code></li> </ul>	All
flint	Added support for flint to query firmware images contained within PLDM (.fwpkg) package files.	All
mlxlink	Added support for a new field for <code>--show_module</code> flag.	All
	Added support for a new capability to allow the user to configure recovery types using the flag <code>--phy_recovery</code> . The recovery types available are: <ul style="list-style-type: none"> <li><code>host_serdes_feq</code></li> <li><code>host_logic_re_lock</code></li> </ul>	All
mlxfwreset	Added support for sync 2 to reset a PCIe switch using a hot reset using the arguments <code>--sync 2</code> and <code>--method 1</code> .	Linux
Rev. 4.32.0-120		
mlxpttrace	Added support for <code>--raw_dump</code> flag for mlxpttrace utility. This flag allows users to take a raw resource_dump of HW_TRACE segment and translate it to readable traces, as if they were taken from mlxpttrace.	All
flint	Added support for displaying device mode by adding either independent, standalone or unknown mode to the flint hardware query output.	All
	Added support for displaying TB/BP bits as-is and for displaying the SRWD bit for specific flash types.	All
	Added support for Independent module Stand Alone option. IM SA mode on Moose is enabled.	All
mlxlink	Added support for FEC correctable and FEC uncorrectable errors in mlxlink <code>--port_type PCIE -c</code> .	All
	Added support for aggregating module information for all switch ASICs for an aggregated port. This features enables to present a single value for each field instead of presenting for each line separately.	All
	Added support for mlxlink port mapping to FNM.	All
	Added support for <code>-m</code> options in mlxlink.	All

	Added new fields to support the ELS and OE unique characteristics and required telemetry.	All
	Added support for a new flag "module_state" with three states (up, down, tg) to allow the user to change the module state.	All
	Added a feature to PRBS to support dc_cpl_allow flag to run PRBS on DC coupled links. Getting a DC coupled ports into test\PRBS mode will require the user's approval, to avoid HW life shortage.	All
	Added support to display a detailed BER count for each lane.	All
mlxconfig	Rearranged the way BYTE type TLVS are handled in mlxconfig to properly support customization_number.	All
	Added support to output configuration to file as JSON.	All
mlxreg	Removed PRM reg index enforcement from mlxreg tool.	All
mlxfwmanager	Added support for flashing firmware binary image stored in a PLDM package for flint and mlxfwmanager tools.	All
mlxprtrace	Added support for --raw_dump flag for mlxprtrace tool. This feature supports hardware Tracer Dump From Resource Dump.	All
<b>Rev. 4.31.0-149</b>		
flint	SECURITY_LOG section was added to image layout. Added FS5_SECURITY_LOG identifier which will be displayed during the command: <code>flint -i &lt;bin&gt; verify</code>	All
	flint -d <dev> -ocr hw query: Added support for querying BP (Block Protection) and TBS (Top Bottom Selection) in raw, bitwise form. flint -d <dev> -ocr hw set: Added support for performing partial sets for write protection. This allows users to set either the TBS bit or the BP bits individually, instead of requiring both to be set simultaneously.	All
	Added support for displaying flint query if the device is Socket Direct device (If not - nothing new will be printed). For BF-3 devices, will also display if aux card is connected.	All
	Added support for querying if the Aux card is connected by use of MRSV.two_p_core_active. This is meaningful only if the case where the two_p_core_active strap is fed from the AUX card plug.	All
mlxdpa	Added support for host ELF file to appear in a format where each DPA app can contain multiple DPA ELFs for different hardware arch versions. Command: <code>mlxdpa -e &lt;host elf file&gt; -c &lt;certificate path&gt; -p &lt;private key path&gt; -o &lt;output path&gt; sign_dpa_apps</code>	<ul style="list-style-type: none"> <li>• Linux x86_64</li> <li>• Linux ARM64</li> </ul>
mst	Added support for creating a planarized mst device file by providing a SystemImageGUID and the 4 lids that share it. Command: <code>mst ib create_aggregated_device --system_image_guid &lt;&gt; --lids &lt;&gt;</code> In case the IB devices were created with mlx5_1, the command should be as follows: <code>mst ib create_aggregated_device --system_image_guid &lt;&gt; --lids &lt;&gt; --hca_id mlx5_1</code>	All

mlxconfig, mlxtokengenerator	mlxconfig and mlxtokengenerator support ConnectX-7 and BlueField-3 devices with challenge-based tokens.	All
mlxconfig	Added support to output configuration to file as JSON. Command: <code>mlxconfig -d /dev/mst/mt4129_pciconf0 -j /tmp/configuration.json query</code> <code>mlxconfig -d mt4129_pciconf0 --json_format C:\Users\Administrator\Desktop/configuration.json -e query NUM_OF_VFS</code>	All
mgettemp	Added support for get temperature tool to mstflint.	All
mlxreg	The tool no longer enforces indexes, indexes that are not specified will be set to zero.	All
General	Added support for RDMA devices modified names.	All
	Added support to detect ConnectX location using straps (to allow Same INI for both ConnectX).	All
<b>Rev. 4.30.0</b>		
flint	Detect ConnectX location using straps. If a device is multi ASIC system component, display its geographical address to the user. Example (for a ASIC platform device): Geographical Address: ASIC 3 Note that for a device that is not multi ASIC system component, no such data will be displayed.	All
	Added the option to enable the user to query the certificate status after burning the DPA cert. This tool will print a list of all the certificates and their metadata. If the command includes cert uuid, the certificate will be written to the provided file. Command: <code>flint -d &lt;device_name&gt; --component_type digital_cacert [--cert_uuid &lt;cert uuid&gt;] query_components [output file]</code>	All
mlxreg	Added the option <code>--overwrite</code> for sending a SET command without sending an initial GET command that fills the unspecified non-index fields. Example: <code>mlxreg -d &lt;device_name&gt; --reg_name MNVIA --overwrite --set "writer_id=9"</code>	All
resourceparse/ resourcedump	Added the option <code>--out-dir</code> to write each segment into a different file under the supplied directory. Examples: <ul style="list-style-type: none"> <li><code>resourcedump dump -d &lt;device_name&gt; -s &lt;segment&gt; --out-dir &lt;output_directory&gt;</code></li> <li><code>resourceparse -d &lt;dump_file&gt; -p map --out-dir &lt;output_directory&gt;</code></li> </ul>	All
	Added the option <code>--hide-segment-header</code> to hide segment header from ADB parse output.	All
General	Implemented new reset flow for PCIe Switch and Connect-X devices to reset the device using HOT reset mechanism.	All

	Added the option to allow users to burn the QM3 FW on the BMC server using the Redfish interface.	All
	Added support for recovering a device from Zombiefish mode. A device in Zombiefish mode exposes the functional device ID (i.e. it looks like a functional device, though it does not have valid firmware running on it). To recover a device from Zombiefish mode, run the following flint command: <code>flint -ocr -d -i -y b</code>	All
<b>Rev. 4.29.0</b>		
General	Added a warning message before deprecating the support for OpenSSL engine in the next release.	All
flint	Added support to print new INI version field.	All
mlxtokengenerator	Added support for challenge data from blob file instead of device. Example of use: <code>"mlxtokengenerator -b &lt;challenge_blob.bin&gt; -k CRCS -t switch -o /tmp/crcs_token.xml generate_token</code>	All
<b>Rev. 4.28</b>		
General	Added support for flint query to display the port GUID, node GUID, system GUID, and allocated GUID for devices that are part of a multi-asic system.	All
	Expanded the MCC register to include more informative error messages which are relevant for module upgrade flows.	All
	Upgraded full OS.	All
	Added support for new flag "-s" which allows the user to determine which I2C secondary address to use when running mget_temp tool	All
	Added an error message stating that the image/device is encrypting and breaking the flow.	All
	Added support in mlxtrace and fwtrace tools to read events in ArcusE.	All
mlxlink	Disabled physical state in optic cables.	All
mlxfwreset	The mlxfwreset tool might fail when using PPC64LE on the RH 8.7 operating system.	All
	Changed the default firmware reset to level 3 from level 4 for PCIe devices. To load new configurations, either execute mlxfwreset level 4 or initiate a cold boot.	All
<b>Rev. 4.27.0-83</b>		
General	When using the TACACS protocol to check scripts that are being run during login, the MFT auto-completion generation is activated. The auto-complete files are now available in a separate package, which is an optional installation.	All
	Added flint support for querying and upgrading firmware on new modules of part number MMA4Z00-NS.	All
mlxlink	Added mlxlink support for read/write/dump actions via direct EEPROM. This is a Beta level support feature that is currently limited to IEI file-systems.	All
<b>Rev. 4.26.1</b>		
Bug Fixes	See <a href="#">MFT Bug Fixes History</a> .	All

Rev. 4.26		
mlxconfig	Removed the <code>--read_only</code> flag from the mlxconfig tool.	
General	Added support for an additional flash type - Winbond Part No. W25Q256JVFIQ.	All
General	Removed dependency on Boost library.	All
General	Added support for VPATH builds.	All
General	The descriptors for DEB/RPM packages are now configured to include two additional tools: mstreg and mstlink. This results in the addition of build-time dependencies on <code>libexpat1-dev</code> and <code>liblzma-dev</code> .	All
Rev. 4.25.1		
mlxfwreset	Added a query for the last reboot. The " <code>mlxfwreset -d &lt;&gt; q</code> " command now shows the cause for the last reboot, and the number of clock cycles since the last cold reset.	All
mlxconfig	Added a priority field to the XML header of each TLV in the mlxconfig xml file. The priority possible values are "MLNX", "OEM" and "USER".	All
Rev. 4.25.0		
General	Added MFT package for WinPE running on Arm64 (aarch64) processors.	All
	Added Sha256 signature to MFT RPM packages in order to allow installation on FIPS (Federal Information Processing Standard) enabled systems.	All
mlxconfig	Added <code>--read_only</code> as a new flag to the mlxconfig tool. When a query with this flag is enabled, the user is able to see <code>read_only</code> parameters. These parameters are marked with 'RO' in the query.	All
mlxfwreset	Added support for DGX H100 device reset. All DGX H100 devices reset requests are handled by the mlxfwreset tool. When one of the DGX H100 devices is provided, the tool proceeds to reset all the devices accordingly. As the final step in the reset process, a reboot command is executed, resulting in a reboot of the entire setup.	All
mlxlink	Added SNR (signal-noise ratio) for the media and host sides of active\optical NDR modules.	All
mlxdpa	mlxdpa was added the ability to create and sign containers for the addition and removal of certificates.	All
mlxdump	Starting from this release, the fsdump mode of the mlxdump tool is deprecated. Support will be provided by November 2023. Please use resource-dump with the appropriate segment instead	All
Rev. 4.24.0		
mlxlink	Updated the <code>show_module</code> command output to display RX and TX power in a higher resolution.	All
	Updated the <code>show_module</code> command output to display new module information fields - Round Trip Latency, Intra-ASIC Latency and Module Datapath Latency.	All
General	Added support for Microsoft CBL-Mariner Linux Operating System.	All
	Added a new flag, <code>[--skip_driver]</code> , to allow control of the stop/start driver functionality in reset flow.	All

fwtrace	Added fwtrace the ability to detect when a token is applied, and work in relevant mode (instead of constantly working in Secure Mode).	All
---------	--	-----

## 4.1.2 MFT Bug Fixes History

The table below lists the history of bugs fixed. For a list of old Bug Fixes, please see [MFT Archived Bug Fixes](#) file.

Internal Ref. No.	Issue
4745544	<b>Description:</b> Changed the algorithm for determining the default reset level (new behavior). As a result, if only Sync 2 is supported, the tool falls back to system reboot.
	<b>Keywords:</b> Sync 2
	<b>Discovered in Version:</b> 4.34.1-10
	<b>Fixed in Release:</b> 4.35.0-159
4781675/ 5719766	<b>Description:</b> Fixed an issue where running "mst gpu add" caused command failures.
	<b>Keywords:</b> mst gpu add
	<b>Discovered in Version:</b> 4.34.1-10
	<b>Fixed in Release:</b> 4.35.0-159
4855126	<b>Description:</b> Fixed an issue where using mlxconfig to query for split port mode fails. The fix adds back special support for continues array SPLIT_PORT on switches.
	<b>Keywords:</b> MFT-mlxconfig, Diagnostics, SPLIT_PORT
	<b>Discovered in Version:</b> 4.34.1-10
	<b>Fixed in Release:</b> 4.35.0-159
4033666	<b>Description:</b> Fixed an issue where the <code>-a/--port_state</code> TG command did not report errors if configuring the port state to Down failed.
	<b>Keywords:</b> <code>-a/--port_state</code> TG command
	<b>Discovered in Version:</b> 4.34.0-145
	<b>Fixed in Release:</b> 4.35.0-159
4784439	<b>Description:</b> Added <code>--no_dynamic</code> flag to display dynamic arrays and conditional unions.
	<b>Keywords:</b> <code>--no_dynamic</code>
	<b>Discovered in Version:</b> 4.34.0-145
	<b>Fixed in Release:</b> 4.35.0-159
4759365/ 4534863	<b>Description:</b> Fixed an issue where <code>drv_dump</code> field was taken from the wrong field in SLTP register. The fix ensures that the field is taken correctly in SLTP register according to the device technology.
	<b>Keywords:</b> <code>drv_dump</code> field, SLTP
	<b>Discovered in Version:</b> 4.34.0-145
	<b>Fixed in Release:</b> 4.35.0-159

Internal Ref. No.	Issue
4564528	<b>Description:</b> In <code>mlx_fwsfx_gen</code> , removed dependency of <code>/dev/null</code> due to lack of permission in some environments.
	<b>Keywords:</b> <code>mlx_fwsfx_gen</code> , <code>/dev/null</code>
	<b>Discovered in Version:</b> 4.33.0-169
	<b>Fixed in Release:</b> 4.34.0-145
4406754	<b>Description:</b> Fixed an issue with wrong device enumeration.
	<b>Keywords:</b> Enumeration
	<b>Discovered in Version:</b> 4.32.0-120
	<b>Fixed in Release:</b> 4.33.0-169
4398750	<b>Description:</b> Added support for reset level 1 type 3 and 4 when the driver is signed in a UEFI system.
	<b>Keywords:</b> UEFI
	<b>Discovered in Version:</b> 4.32.0-120
	<b>Fixed in Release:</b> 4.33.0-169
4378652	<b>Description:</b> Added support for SIGHUP signal handling in MFT infrastructure to trigger configuration reloads or graceful runtime updates.
	<b>Keywords:</b> SIGHUP
	<b>Discovered in Version:</b> 4.26.0
	<b>Fixed in Release:</b> 4.32.0-120
4337526	<b>Description:</b> Fixed an issue relating to querying the counters for <code>local_port 255</code> in Spectrum4 standalone mode.
	<b>Keywords:</b> <code>local_port 255</code> , Spectrum4
	<b>Discovered in Version:</b> 4.29.0-131
	<b>Fixed in Release:</b> 4.32.0-120
4294588	<b>Description:</b> Changed the polling method to check if BlueField reset is complete.
	<b>Keywords:</b> BlueField
	<b>Discovered in Version:</b> 4.31.0-149
	<b>Fixed in Release:</b> 4.32.0-120
4291685	<b>Description:</b> Removed PSID <code>MT_0000000884</code> from PCIE switch map.
	<b>Keywords:</b> PSID, PCIE
	<b>Discovered in Version:</b> 4.31.0-149
	<b>Fixed in Release:</b> 4.32.0-120
4290640	<b>Description:</b> Fixed the issue of handling bad arguments in <code>mlxreg</code> . The tool will report the error, print the usage message and exit.
	<b>Keywords:</b> <code>mlxreg</code> , bad error code
	<b>Discovered in Version:</b> 4.31.0-149
	<b>Fixed in Release:</b> 4.32.0-120
4258362	<b>Description:</b> Adapted the NIC driver name to support any custom name.

Internal Ref. No.	Issue
	<b>Keywords:</b> NIC driver name
	<b>Discovered in Version:</b> 4.31.0-149
	<b>Fixed in Release:</b> 4.32.0-120
4220920	<b>Description:</b> MFT on FreeBSD OS supports PCI-CORE VSC address spaces separation.
	<b>Keywords:</b> FreeBSD OS, PCI-CORE VSC address
	<b>Discovered in Version:</b> 4.30.0-139
	<b>Fixed in Release:</b> 4.31.0-149
4091646	<b>Description:</b> Changed the field name in code from dp_st_lane0 to dp_st_lane[0].
	<b>Keywords:</b> mlxlink,, DataPath,dp_st_lane0, dp_st_lane[0]
	<b>Discovered in Version:</b> 4.28.0
	<b>Fixed in Release:</b> 4.30.0
4078946	<b>Description:</b> Added handling interrupts between burning chunks to cables.
	<b>Keywords:</b> interrupts, burning chunks
	<b>Discovered in Version:</b> 4.28.0
	<b>Fixed in Release:</b> 4.30.0
3953342	<b>Description:</b> Removed support for OpenSSL engine.
	<b>Keywords:</b> OpenSSL engine
	<b>Discovered in Version:</b> 4.29.0
	<b>Fixed in Release:</b> 4.30.0
3832522	<b>Description:</b> Created VMware domain security policy according to the needs of MFT plugins.
	<b>Keywords:</b> VMware
	<b>Discovered in Version:</b> 4.26.1.102
	<b>Fixed in Release:</b> 4.29.0
3993256	<b>Description:</b> Corrected the order of reading data via I2C from big endian to little endian
	<b>Keywords:</b> I2C
	<b>Discovered in Version:</b> 4.28.0
	<b>Fixed in Release:</b> 4.29.0
3880918	<b>Description:</b> Added a validation that states that the provided path is a file and provided a better error message.
	<b>Keywords:</b> Validation, path
	<b>Discovered in Version:</b> 4.28.0
	<b>Fixed in Release:</b> 4.29.0
3953339	<b>Description:</b> Added a warning message before deprecating the support for OpenSSL engine in the next release.
	<b>Keywords:</b> OpenSSL
	<b>Discovered in Version:</b> 4.28.0

Internal Ref. No.	Issue
	<b>Fixed in Release:</b> 4.29.0
3886315	<b>Description:</b> To reset or shut down the BlueField Arm, it is mandatory to specify the --sync 0 argument with reset level 1 and reset type 3 or 4. For example: 'mlxfwreset -d <device> -l 1 -t 4 --sync 0 r'.
	<b>Keywords:</b> BlueField Arm, shutdown
	<b>Discovered in Version:</b> 4.28.0
	<b>Fixed in Release:</b> 4.29.0
3819004	<b>Description:</b> flint's CMIS burn flow for cables ignores signals (e.g. CTRL+C) during the burn.
	<b>Keywords:</b> CMIS, burn
	<b>Discovered in Version:</b> 4.28.0
	<b>Fixed in Release:</b> 4.29.0
3645548	<b>Description:</b> Fixed an issue that led to wrong M1-M4 measurements calculation when using ConnecX-7.
	<b>Keywords:</b> M1-M4 measurements, ConnecX-7
	<b>Discovered in Version:</b> 4.26.0
	<b>Fixed in Release:</b> 4.26.1
3632765	<b>Description:</b> Fixed an issue that occurred when attempting to unzip the mlxfwmanager self-extractor.
	<b>Keywords:</b> mlxfwmanager, unzipping
	<b>Discovered in Version:</b> 4.25.0
	<b>Fixed in Release:</b> 4.26.0
3582574	<b>Description:</b> Fixed an issue that prevented ConnectX-5 EX reset using the fastfwreset tool.
	<b>Keywords:</b> fastfwreset
	<b>Discovered in Version:</b> 4.25.0
	<b>Fixed in Release:</b> 4.26.0
3582575	<b>Description:</b> Fixed an issue that caused incorrect enumeration in NVIDIA devices.
	<b>Keywords:</b> incorrect enumeration
	<b>Discovered in Version:</b> 4.25.0
	<b>Fixed in Release:</b> 4.26.0
3613010	<b>Description:</b> Fixed an issue where mlxdump did not work with Quantum-2 switches due to the absence of the Quantum2.csv file from the C:\Program Files\Mellanox\WinMFT\mstdump_dbs\ folder.
	<b>Keywords:</b> mlxdump, Quantum-2
	<b>Discovered in Version:</b> 4.25.0
	<b>Fixed in Release:</b> 4.26.0

Internal Ref. No.	Issue
3474570	<b>Description:</b> Fixed an issue that occurred when two MFT tools were running simultaneously, and while one of them loaded the driver, the second tool, which was not supposed to reload it in this case, failed to discover the Mellanox devices.
	<b>Keywords:</b> Driver reload
	<b>Discovered in Version:</b> 4.24.0
	<b>Fixed in Release:</b> 4.25.0
3471307	<b>Description:</b> Fixed an issue where incorrect eye information was displayed for 10G speed over ConnectX-7 devices.
	<b>Keywords:</b> Eye information, ConnectX-7
	<b>Discovered in Version:</b> 4.23.0
	<b>Fixed in Release:</b> 4.25.0

## 4.2 User Manual Revision History

Revision	Date	
4.36.0-147	June 03, 2026	<p>Updated:</p> <ul style="list-style-type: none"> <li>• <a href="#">Burning a Firmware Image</a> - Added Burning Firmware with Different Minor PSID</li> <li>• <a href="#">mlxlink Utility</a></li> <li>• <a href="#">mlxfwmanager - Firmware Update and Query Tool</a></li> <li>• <a href="#">mlxfwreset - Loading Firmware on 5th Generation Devices Tool</a> - Added status</li> <li>• <a href="#">mlxlink Utility</a> - Added: --show_multi_port_cpo_info, --smpci, --set_tx_precoding, --set_rx_precoding, --els_module &lt;module_index&gt;, --els_laser &lt;lasers&gt;, --els_operation &lt;operation&gt;</li> <li>• <a href="#">mlxconfig - Changing Device Configuration Tool</a> - Added: show_system_conf, set_system_conf, validate_system_conf</li> <li>• <a href="#">Using mlxconfig</a> - Added Setting Pre-defined Configuration</li> <li>• <a href="#">mget_temp Utility</a> - Added -precision, --no-modules</li> </ul>
4.35.0-159	February 19, 2026	<p>Updated:</p> <ul style="list-style-type: none"> <li>• <a href="#">cpldupdate - Tool for Programming On-Board CPLDs on NVIDIA Devices</a></li> <li>• <a href="#">mlxlink Utility</a></li> <li>• <a href="#">mlxfwmanager - Firmware Update and Query Tool</a> - Added Driver Detection Assistance</li> <li>• <a href="#">nvredfish</a> - Added BMC/HMC Dumps</li> <li>• <a href="#">Linux</a></li> <li>• <a href="#">Access to Hardware Devices</a> - Added FWCTL</li> </ul>
4.34.0-145	November 10, 2025	<p>Updated:</p> <ul style="list-style-type: none"> <li>• <a href="#">Access to Hardware Devices</a></li> <li>• <a href="#">Supported Operating Systems and Platforms</a></li> <li>• <a href="#">mlxconfig - Changing Device Configuration Tool</a> - Added --with_default, --host_id and --pf_index flags</li> <li>• <a href="#">mlxlink Utility</a> - Added --rx_modulation and --tx_modulation flags</li> <li>• <a href="#">mlxreg Utility</a> - Added recommendation</li> <li>• <a href="#">mlxdpa - DPA Applications Sign Tool</a></li> <li>• <a href="#">Examples of mlxconfig Usage</a></li> <li>• <a href="#">Burning a Firmware Image</a></li> <li>• <a href="#">Verifying the Firmware Image</a></li> <li>• <a href="#">Querying the Firmware Image</a></li> </ul>

Revision	Date	
4.33.0-169	August 08, 2025	Updated: <ul style="list-style-type: none"> <li>• <a href="#">mlxlink Utility</a></li> <li>• <a href="#">mlxconfig - Changing Device Configuration Tool</a> - Added --i2c_secondary</li> <li>• <a href="#">mlxreg Utility</a> - Added --full_path</li> <li>• <a href="#">mlxfwreset - Loading Firmware on 5th Generation Devices Tool</a> - Added PCIe Switch Reset via Hot Reset</li> <li>• <a href="#">flint - Firmware Burning Tool</a> - Added component_type and skip_if_same</li> <li>• <a href="#">mlxfwmanager - Firmware Update and Query Tool</a> - Added --component_type componentName and --skip_if_same</li> </ul>
4.32.0-120	May 08, 2025	Updated: <ul style="list-style-type: none"> <li>• <a href="#">Secure Host</a></li> <li>• <a href="#">mlxptrace Utility</a> - Added --raw_dump flag</li> <li>• <a href="#">fwtrace Utility</a> - Added --raw_dump flag</li> <li>• <a href="#">Burning a Firmware Image</a> - Added Burning PLDM Images</li> <li>• <a href="#">Updating the Device using PLDM</a></li> <li>• <a href="#">mlxburn - Firmware Image Generator and Burner</a></li> <li>• <a href="#">mlxtokengenerator - Token Creation Tool</a></li> <li>• <a href="#">mlxburn - Firmware Image Generator and Burner</a></li> <li>• <a href="#">Linux</a> - Added i2c</li> <li>• <a href="#">mlxfwmanager - Firmware Update and Query Tool</a></li> <li>• <a href="#">mlxcables - Cables Tool</a> - Added note</li> </ul>
4.31.0-149	February 10, 2025	Updated: <ul style="list-style-type: none"> <li>• <a href="#">mget_temp Utility</a></li> <li>• <a href="#">mlxconfig - Changing Device Configuration Tool</a></li> <li>• <a href="#">Linux</a></li> <li>• <a href="#">Using mlxconfig</a></li> <li>• <a href="#">Secure Host</a></li> </ul> Added: <ul style="list-style-type: none"> <li>• <a href="#">ESXi</a></li> </ul>
4.30.0-139	November 11, 2024	Updated: <ul style="list-style-type: none"> <li>• <a href="#">mlxreg Utility</a></li> <li>• <a href="#">resourceparse Utility</a></li> <li>• <a href="#">Supported Operating Systems and Platforms</a></li> <li>• <a href="#">mlxconfig - Changing Device Configuration Tool</a></li> </ul> Added: <ul style="list-style-type: none"> <li>• <a href="#">mlxptrace Utility</a></li> </ul>
4.29.0	August 14, 2024	Updated: <ul style="list-style-type: none"> <li>• <a href="#">flint - Firmware Burning Tool</a></li> <li>• <a href="#">cpldupdate - Tool for Programming On-Board CPLDs on NVIDIA Devices</a></li> <li>• <a href="#">mlxlink Utility</a></li> </ul>
4.28.0	May 7, 2024	Updated: <ul style="list-style-type: none"> <li>• <a href="#">mget_temp Utility</a></li> </ul>
4.27.0	February 8, 2023	Added Bifurcation Configuration under <a href="#">mlxconfig - Changing Device Configuration Tool</a> .
4.26.1	December 14, 2023	No changes to the User Manual.
4.26.0	November 6, 2023	Updated: <ul style="list-style-type: none"> <li>• <a href="#">mlxdpa - DPA Applications Sign Tool</a></li> <li>• <a href="#">mlxconfig - Changing Device Configuration Tool</a></li> </ul>
4.25.1	October 22, 2023	Added: <ul style="list-style-type: none"> <li>• Advance Options to "Generating an XML Template for the Configurations" under <a href="#">mlxconfig Commands</a>.</li> </ul>

Revision	Date	
4.25.0	August 10, 2023	<p>Updated:</p> <ul style="list-style-type: none"> <li>• Cable Burn Command Running CMIS Firmware Upgrade Flow for Supported Cables under <a href="#">Burning a Firmware Image</a>.</li> <li>• <a href="#">mlxcpa - DPA Applications Sign Tool</a></li> <li>• <a href="#">mlxfwreset - Loading Firmware on 5th Generation Devices Tool</a></li> <li>• <a href="#">fwtrace Utility</a></li> <li>• <a href="#">mlxtrace Utility</a></li> <li>• <a href="#">resourcedump Utility</a></li> <li>• <a href="#">resourceparse Utility</a></li> <li>• mst Synopsis - Windows under <a href="#">Windows</a>.</li> <li>• mst Synopsis - VMware under <a href="#">VMware ESXi</a>.</li> <li>• mst Synopsis - FreeBSD under <a href="#">FreeBSD</a>.</li> <li>• mst Synopsis - Linux under <a href="#">Linux</a>.</li> </ul> <p>Added:</p> <ul style="list-style-type: none"> <li>• <a href="#">mlxcableimgen - Cable Firmware Image Wrapper Generation Tool</a> under <a href="#">Firmware Generation, Configuration, and Update Tools</a>.</li> </ul>

## 5 Document Conventions and Related Documents

### 5.1 Abbreviations and Acronyms

Term	Description
MFT	NVIDIA® Firmware tools
MST	Software tools and it is the name of the script that starts/stops the driver used by MFT tools
mlx	Extension of the text firmware file which contains all the firmware content
ini	Extension of the firmware configuration file which is in INI format and contains card specific configurations.
bin	Extension of the binary firmware file which is a combination of INI and mlx file
MFA	Extension of the a firmware file that contains several binary files of firmware for different cards/ boards
4th Generation ICs/ Group I of ICs	Contains the following devices: <ul style="list-style-type: none"><li>• ConnectX-3</li><li>• ConnectX-3 Pro</li></ul>
5th Generation ICs/ Group II of ICs	Contains the following devices and newer: <ul style="list-style-type: none"><li>• Connect-IB</li><li>• Switch-IB</li><li>• Switch-IB 2</li><li>• NVIDIA Spectrum</li><li>• NVIDIA Spectrum-2</li><li>• ConnectX-4</li><li>• ConnectX-4 Lx</li><li>• ConnectX-5</li><li>• ConnectX-5 Ex</li><li>• ConnectX-6</li><li>• ConnectX-6 Dx</li><li>• NVIDIA BlueField</li></ul>

### 5.2 Reference Documents and Downloads

Reference Documents and Downloads	Location
MFT web page	<a href="https://network.nvidia.com/products/adapter-software/firmware-tools/">https://network.nvidia.com/products/adapter-software/firmware-tools/</a>
Firmware Release Notes	<a href="https://docs.nvidia.com/networking/category/adapterfw">https://docs.nvidia.com/networking/category/adapterfw</a>
DOCA-Host	<a href="https://docs.nvidia.com/networking/dpu-doca/index.html#doca">https://docs.nvidia.com/networking/dpu-doca/index.html#doca</a>
WinOF/WinOF-2	<a href="https://docs.nvidia.com/networking/category/winof2">https://docs.nvidia.com/networking/category/winof2</a>
VMware	<a href="https://docs.nvidia.com/networking/category/vmwareesxiasyncdrivers">https://docs.nvidia.com/networking/category/vmwareesxiasyncdrivers</a>
FreeBSD	<a href="https://docs.nvidia.com/networking/category/freebsd">https://docs.nvidia.com/networking/category/freebsd</a>

# 6 Legal Notices and 3rd Party Licenses

The following are the drivers' software, tools and HCA firmware legal notices and 3rd party licenses.

Product	Version	Legal Notices and 3rd Party Licenses
Firmware	xx.49.1014	<ul style="list-style-type: none"> <li>• <a href="#">License</a></li> <li>• <a href="#">3rd Party Notice</a></li> <li>• <a href="#">3rd Party Unify Notice</a></li> <li>• <a href="#">HCA Firmware EULA</a></li> </ul>
DOCA-Host	3.4.0	<ul style="list-style-type: none"> <li>• <a href="#">License</a></li> <li>• <a href="#">3rd Party Notice</a></li> <li>• <a href="#">3rd Party Unify Notice</a></li> </ul>
MFT FreeBSD	4.36.0-147	<ul style="list-style-type: none"> <li>• <a href="#">License</a></li> <li>• <a href="#">3rd Party Notice</a></li> <li>• <a href="#">3rd Party Unify Notice</a></li> </ul>
MFT Linux		<ul style="list-style-type: none"> <li>• <a href="#">License</a></li> <li>• <a href="#">3rd Party Notice</a></li> <li>• <a href="#">3rd Party Unify Notice</a></li> </ul>
MFT VMware		<ul style="list-style-type: none"> <li>• <a href="#">License</a></li> <li>• <a href="#">3rd Party Notice</a></li> <li>• <a href="#">3rd Party Unify Notice</a></li> </ul>
MFT Windows		<ul style="list-style-type: none"> <li>• <a href="#">License</a></li> <li>• <a href="#">3rd Party Notice</a></li> <li>• <a href="#">3rd Party Unify Notice</a></li> </ul>

## Notice

This document is provided for information purposes only and shall not be regarded as a warranty of a certain functionality, condition, or quality of a product. Neither NVIDIA Corporation nor any of its direct or indirect subsidiaries and affiliates (collectively: "NVIDIA") make any representations or warranties, expressed or implied, as to the accuracy or completeness of the information contained in this document and assumes no responsibility for any errors contained herein. NVIDIA shall have no liability for the consequences or use of such information or for any infringement of patents or other rights of third parties that may result from its use. This document is not a commitment to develop, release, or deliver any Material (defined below), code, or functionality.

NVIDIA reserves the right to make corrections, modifications, enhancements, improvements, and any other changes to this document, at any time without notice. Customer should obtain the latest relevant information before placing orders and should verify that such information is current and complete.

NVIDIA products are sold subject to the NVIDIA standard terms and conditions of sale supplied at the time of order acknowledgement, unless otherwise agreed in an individual sales agreement signed by authorized representatives of NVIDIA and customer ("Terms of Sale"). NVIDIA hereby expressly objects to applying any customer general terms and conditions with regards to the purchase of the NVIDIA product referenced in this document. No contractual obligations are formed either directly or indirectly by this document.

NVIDIA products are not designed, authorized, or warranted to be suitable for use in medical, military, aircraft, space, or life support equipment, nor in applications where failure or malfunction of the NVIDIA product can reasonably be expected to result in personal injury, death, or property or environmental damage. NVIDIA accepts no liability for inclusion and/or use of NVIDIA products in such equipment or applications and therefore such inclusion and/or use is at customer's own risk.

NVIDIA makes no representation or warranty that products based on this document will be suitable for any specified use. Testing of all parameters of each product is not necessarily performed by NVIDIA. It is customer's sole responsibility to evaluate and determine the applicability of any information contained in this document, ensure the product is suitable and fit for the application planned by customer, and perform the necessary testing for the application in order to avoid a default of the application or the product. Weaknesses in customer's product designs may affect the quality and reliability of the NVIDIA product and may result in additional or different conditions and/or requirements beyond those contained in this document. NVIDIA accepts no liability related to any default, damage, costs, or problem which may be based on or attributable to: (i) the use of the NVIDIA product in any manner that is contrary to this document or (ii) customer product designs.

No license, either expressed or implied, is granted under any NVIDIA patent right, copyright, or other NVIDIA intellectual property right under this document. Information published by NVIDIA regarding third-party products or services does not constitute a license from NVIDIA to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property rights of the third party, or a license from NVIDIA under the patents or other intellectual property rights of NVIDIA.

Reproduction of information in this document is permissible only if approved in advance by NVIDIA in writing, reproduced without alteration and in full compliance with all applicable export laws and regulations, and accompanied by all associated conditions, limitations, and notices.

THIS DOCUMENT AND ALL NVIDIA DESIGN SPECIFICATIONS, REFERENCE BOARDS, FILES, DRAWINGS, DIAGNOSTICS, LISTS, AND OTHER DOCUMENTS (TOGETHER AND SEPARATELY, "MATERIALS") ARE BEING PROVIDED "AS IS." NVIDIA MAKES NO WARRANTIES, EXPRESSED, IMPLIED, STATUTORY, OR OTHERWISE WITH RESPECT TO THE MATERIALS, AND EXPRESSLY DISCLAIMS ALL IMPLIED WARRANTIES OF NONINFRINGEMENT, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE. TO THE EXTENT NOT PROHIBITED BY LAW, IN NO EVENT WILL NVIDIA BE LIABLE FOR ANY DAMAGES, INCLUDING WITHOUT LIMITATION ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES, HOWEVER CAUSED AND REGARDLESS OF THE THEORY OF LIABILITY, ARISING OUT OF ANY USE OF THIS DOCUMENT, EVEN IF NVIDIA HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Notwithstanding any damages that customer might incur for any reason whatsoever, NVIDIA's aggregate and cumulative liability towards customer for the products described herein shall be limited in accordance with the Terms of Sale for the product.

## Trademarks



NVIDIA, the NVIDIA logo, and Mellanox are trademarks and/or registered trademarks of NVIDIA Corporation and/or its affiliates in the U.S. and in other countries. Other company and product names may be trademarks of the respective companies with which they are associated.

Copyright

© 2026 NVIDIA Corporation & affiliates. All Rights Reserved.

