CUDA Debugger API

API Reference Manual

TRM-06710-001 _vRelease Version | January 2024

Table of Contents

Chapter 1. Release Notes 1
1.2. CUDA 12.9 Release 1
1.3. CUDA 12.8 Release 2
1.4. CUDA 12.7 Release 2
1.5. CUDA 12.6 Release 3
1.6. CUDA 12.5 Release 3
1.7. CUDA 12.4 Release 4
1.8. CUDA 12.3 Release 4
1.9. CUDA 12.2 Release 5
1.10. CUDA 12.1 Release 5
1.11. CUDA 12.0 Release 5
1.12. CUDA 11.8 Release 6
1.13. CUDA 7.0 Release 7
1.14. CUDA 6.5 Release 7
Chapter 2. Introduction 8
2.1. Debugger API 8
2.2. ELF and DWARF 9
2.3. ABI Support 10
2.4. Exception Reporting 11
2.5. Attaching and Detaching 11
Chapter 3. Modules 14
3.1. General 14
CUDBGCudaLogMessage 14
CUDBGCudaLogLevel 14
CUDBGResult 15
3.2. Initialization 17
CUDBGAPI_st::finalize 17
CUDBGAPI_st::getSupportedDebuggerCapabilities 17
CUDBGAPI_st::initialize 18
3.3. Device Execution Control 18
CUDBGAPI_st::resumeDevice 18
CUDBGAPI_st::resumeWarpsUntilPC 18
CUDBGAPI_st::singleStepWarp 19
CUDBGAPI_st::singleStepWarp40 20
CUDBGAPI_st::singleStepWarp41 21

CUDBGAPI_st::suspendDevice.... 22
3.4. Breakpoints.... 22
CUDBGAPI_st::getAdjustedCodeAddress.... 22
CUDBGAPI_st::setBreakpoint.... 23
CUDBGAPI_st::setBreakpoint31.... 23
CUDBGAPI_st::unsetBreakpoint.... 24
CUDBGAPI_st::unsetBreakpoint31.... 24
3.5. Device State Inspection.... 25
CUDBGAPI_st::consumeCudaLogs.... 25
CUDBGAPI_st::generateCoredump.... 26
CUDBGAPI_st::getCbuWarpState.... 26
CUDBGAPI_st::getClusterExceptionTargetBlock.... 27
CUDBGAPI_st::getConstBankAddress.... 27
CUDBGAPI_st::getConstBankAddress123.... 28
CUDBGAPI_st::getCudaExceptionString.... 29
CUDBGAPI_st::getHardwareBarrierInfo.... 30
CUDBGAPI_st::getLoadedFunctionInfo.... 31
CUDBGAPI_st::getLoadedFunctionInfo118.... 31
CUDBGAPI_st::getManagedMemoryRegionInfo.... 32
CUDBGAPI_st::memcheckReadErrorAddress.... 33
CUDBGAPI_st::readActiveLanes.... 33
CUDBGAPI_st::readAllVirtualReturnAddresses.... 34
CUDBGAPI_st::readBlockIdx.... 35
CUDBGAPI_st::readBlockIdx32.... 36
CUDBGAPI_st::readBrokenWarps.... 37
CUDBGAPI_st::readCallDepth.... 37
CUDBGAPI_st::readCallDepth32.... 38
CUDBGAPI_st::readCCRegister.... 39
CUDBGAPI_st::readClusterIdx.... 40
CUDBGAPI_st::readCodeMemory.... 41
CUDBGAPI_st::readConstMemory129.... 41
CUDBGAPI_st::readCPUCallStack.... 42
CUDBGAPI_st::readErrorPC.... 43
CUDBGAPI_st::readGenericMemory.... 44
CUDBGAPI_st::readGlobalMemory.... 45
CUDBGAPI_st::readGlobalMemory31.... 46
CUDBGAPI_st::readGlobalMemory55.... 47
CUDBGAPI_st::readGridId.... 48

CUDBGAPI_st::readGridId50....49
CUDBGAPI_st::readLaneException....50
CUDBGAPI_st::readLaneStatus....50
CUDBGAPI_st::readLocalMemory....51
CUDBGAPI_st::readParamMemory....52
CUDBGAPI_st::readPC....53
CUDBGAPI_st::readPinnedMemory....54
CUDBGAPI_st::readPredicates....55
CUDBGAPI_st::readRegister....56
CUDBGAPI_st::readRegisterRange....57
CUDBGAPI_st::readReturnAddress....58
CUDBGAPI_st::readReturnAddress32....59
CUDBGAPI_st::readSharedMemory....60
CUDBGAPI_st::readSmException....61
CUDBGAPI_st::readSyscallCallDepth....61
CUDBGAPI_st::readTextureMemory....62
CUDBGAPI_st::readTextureMemoryBindless....63
CUDBGAPI_st::readThreadIdx....64
CUDBGAPI_st::readUniformPredicates....65
CUDBGAPI_st::readUniformRegisterRange....66
CUDBGAPI_st::readValidLanes....66
CUDBGAPI_st::readValidWarps....67
CUDBGAPI_st::readVirtualPC....68
CUDBGAPI_st::readVirtualReturnAddress....69
CUDBGAPI_st::readVirtualReturnAddress32....70
CUDBGAPI_st::readWarpResources....71
CUDBGAPI_st::readWarpState....71
CUDBGAPI_st::readWarpState120....72
CUDBGAPI_st::readWarpState127....73
CUDBGAPI_st::readWarpState60....73
CUDBGAPI_st::writePinnedMemory....74
CUDBGAPI_st::writePredicates....75
CUDBGAPI_st::writeUniformPredicates....76
3.6. Device State Alteration....76
CUDBGAPI_st::writeCCRegister....77
CUDBGAPI_st::writeGenericMemory....78
CUDBGAPI_st::writeGlobalMemory....79
CUDBGAPI_st::writeGlobalMemory31....79

CUDBGAPI_st::writeGlobalMemory55....80
CUDBGAPI_st::writeLocalMemory.... 81
CUDBGAPI_st::writeParamMemory.... 82
CUDBGAPI_st::writeRegister....83
CUDBGAPI_st::writeSharedMemory.... 84
CUDBGAPI_st::writeUniformRegister.... 85
3.7. Grid Properties.... 85
CUDBGGridInfo....85
CUDBGGridStatus....85
CUDBGAPI_st::getBlockDim....86
CUDBGAPI_st::getClusterDim....87
CUDBGAPI_st::getClusterDim120....87
CUDBGAPI_st::getElfImage....88
CUDBGAPI_st::getElfImage32....89
CUDBGAPI_st::getGridAttribute....89
CUDBGAPI_st::getGridAttributes.... 90
CUDBGAPI_st::getGridDim.... 91
CUDBGAPI_st::getGridDim32.... 91
CUDBGAPI_st::getGridInfo....92
CUDBGAPI_st::getGridInfo120....93
CUDBGAPI_st::getGridInfo55....93
CUDBGAPI_st::getGridStatus.... 94
CUDBGAPI_st::getGridStatus50.... 94
CUDBGAPI_st::getTID....95
3.8. Device Properties.... 95
CUDBGAPI_st::getDeviceName....95
CUDBGAPI_st::getDeviceType....96
CUDBGAPI_st::getNumDevices....96
CUDBGAPI_st::getNumLanes....97
CUDBGAPI_st::getNumPredicates.... 97
CUDBGAPI_st::getNumRegisters....98
CUDBGAPI_st::getNumSMs.... 99
CUDBGAPI_st::getNumUniformPredicates.... 99
CUDBGAPI_st::getNumUniformRegisters....100
CUDBGAPI_st::getNumWarps.... 100
CUDBGAPI_st::getSmType.... 101
3.9. DWARF Utilities....101
CUDBGAPI_st::disassemble.... 102

CUDBGAPI_st::getElfImageByHandle ... 102
CUDBGAPI_st::getHostAddrFromDeviceAddr ... 103
CUDBGAPI_st::getPhysicalRegister30 ... 104
CUDBGAPI_st::getPhysicalRegister40 ... 105
CUDBGAPI_st::isDeviceCodeAddress ... 106
CUDBGAPI_st::isDeviceCodeAddress55 ... 106
CUDBGAPI_st::lookupDeviceCodeSymbol ... 107
3.10. Events ... 107
CUDBGEvent ... 108
CUDBGEventCallbackData ... 108
CUDBGEventCallbackData40 ... 108
CUDBGEventKind ... 108
CUDBGNotifyNewEventCallback ... 109
CUDBGNotifyNewEventCallback31 ... 109
CUDBGAPI_st::acknowledgeEvent30 ... 109
CUDBGAPI_st::acknowledgeEvents42 ... 110
CUDBGAPI_st::acknowledgeSyncEvents ... 110
CUDBGAPI_st::getErrorStringEx ... 110
CUDBGAPI_st::getNextAsyncEvent50 ... 111
CUDBGAPI_st::getNextAsyncEvent55 ... 112
CUDBGAPI_st::getNextEvent ... 112
CUDBGAPI_st::getNextEvent30 ... 113
CUDBGAPI_st::getNextEvent32 ... 113
CUDBGAPI_st::getNextEvent42 ... 114
CUDBGAPI_st::getNextSyncEvent50 ... 114
CUDBGAPI_st::getNextSyncEvent55 ... 115
CUDBGAPI_st::setNotifyNewEventCallback ... 115
CUDBGAPI_st::setNotifyNewEventCallback31 ... 116
CUDBGAPI_st::setNotifyNewEventCallback40 ... 116
CUDBGAPI_st::setNotifyNewEventCallback41 ... 117
Chapter 4. Data Structures ... 118
CUDBGAPI_st ... 118
acknowledgeEvent30 ... 119
acknowledgeEvents42 ... 119
acknowledgeSyncEvents ... 119
clearAttachState ... 120
consumeCudaLogs ... 120
disassemble ... 120

finalize....121
generateCoredump....121
getAdjustedCodeAddress....122
getBlockDim....122
getCbuWarpState....123
getClusterDim....123
getClusterDim120....124
getClusterExceptionTargetBlock....125
getConstBankAddress....125
getConstBankAddress123....126
getCudaExceptionString....127
getDeviceName....127
getDevicePCIBusInfo....128
getDeviceType....128
getElfImage....129
getElfImage32....130
getElfImageByHandle....130
getErrorStringEx....131
getGridAttribute....132
getGridAttributes....132
getGridDim....133
getGridDim32....133
getGridInfo....134
getGridInfo120....135
getGridInfo55....135
getGridStatus....136
getGridStatus50....136
getHardwareBarrierInfo....137
getHostAddrFromDeviceAddr....137
getLoadedFunctionInfo....138
getLoadedFunctionInfo118....139
getManagedMemoryRegionInfo....139
getNextAsyncEvent50....140
getNextAsyncEvent55....140
getNextEvent....141
getNextEvent30....141
getNextEvent32....142
getNextEvent42....142

getNextSyncEvent50 143
getNextSyncEvent55 143
getNumDevices 144
getNumLanes 144
getNumPredicates 145
getNumRegisters 145
getNumSMs 146
getNumUniformPredicates 146
getNumUniformRegisters 147
getNumWarps 147
getPhysicalRegister30 148
getPhysicalRegister40 149
getSmType 150
getSupportedDebuggerCapabilities 150
getTID 151
initialize 151
initializeAttachStub 151
isDeviceCodeAddress 152
isDeviceCodeAddress55 152
lookupDeviceCodeSymbol 153
memcheckReadErrorAddress 153
readActiveLanes 154
readAllVirtualReturnAddresses 155
readBlockIdx 156
readBlockIdx32 156
readBrokenWarps 157
readCallDepth 158
readCallDepth32 159
readCCRegister 159
readClusterIdx 160
readCodeMemory 161
readConstMemory129 162
readCPUCallStack 163
readDeviceExceptionState 164
readDeviceExceptionState80 164
readErrorPC 165
readGenericMemory 165
readGlobalMemory 166

readGlobalMemory31 167
readGlobalMemory55 168
readGridId 169
readGridId50 170
readLaneException 171
readLaneStatus 172
readLocalMemory 172
readParamMemory 173
readPC 174
readPinnedMemory 175
readPredicates 176
readRegister 177
readRegisterRange 178
readReturnAddress 179
readReturnAddress32 180
readSharedMemory 181
readSmException 182
readSyscallCallDepth 182
readTextureMemory 183
readTextureMemoryBindless 184
readThreadIdx 185
readUniformPredicates 186
readUniformRegisterRange 186
readValidLanes 187
readValidWarps 188
readVirtualPC 189
readVirtualReturnAddress 189
readVirtualReturnAddress32 190
readWarpResources 191
readWarpState 192
readWarpState120 192
readWarpState127 193
readWarpState60 193
requestCleanupOnDetach 194
requestCleanupOnDetach55 194
resumeDevice 195
resumeWarpsUntilPC 195
setBreakpoint 196

setBreakpoint31....196
setKernelLaunchNotificationMode....197
setNotifyNewEventCallback....197
setNotifyNewEventCallback31....198
setNotifyNewEventCallback40....198
setNotifyNewEventCallback41....199
singleStepWarp....199
singleStepWarp40....200
singleStepWarp41....201
suspendDevice....201
unsetBreakpoint....202
unsetBreakpoint31....202
writeCCRegister....203
writeGenericMemory....204
writeGlobalMemory....205
writeGlobalMemory31....205
writeGlobalMemory55....206
writeLocalMemory....207
writeParamMemory....208
writePinnedMemory....209
writePredicates....210
writeRegister....211
writeSharedMemory....212
writeUniformPredicates....213
writeUniformRegister....213
CUDBGCudaLogMessage....214
logLevel....214
message....214
osThreadId....214
unixTimestampNs....214
CUDBGEvent....214
cases....215
kind....215
CUDBGEvent::cases_st....215
contextCreate....216
contextDestroy....216
contextPop....216
contextPush....216

elfImageLoaded....216
internalError....216
kernelFinished....216
kernelReady....216
CUDBGEvent::cases_st::contextCreate_st....217
context....217
dev....217
tid....217
CUDBGEvent::cases_st::contextDestroy_st....217
context....217
dev....217
tid....217
CUDBGEvent::cases_st::contextPop_st....217
context....218
dev....218
tid....218
CUDBGEvent::cases_st::contextPush_st....218
context....218
dev....218
tid....218
CUDBGEvent::cases_st::elfImageLoaded_st....218
context....219
dev....219
handle....219
module....219
properties....219
size....219
CUDBGEvent::cases_st::internalError_st....219
errorType....219
CUDBGEvent::cases_st::kernelFinished_st....219
context....220
dev....220
function....220
functionEntry....220
gridId....220
module....220
tid....220
CUDBGEvent::cases_st::kernelReady_st....220

blockDim....221
context....221
dev....221
function....221
functionEntry....221
gridDim....221
gridId....221
module....221
parentGridId....221
tid....221
type....222
CUDBGEventCallbackData....222
tid....222
CUDBGEventCallbackData40....222
tid....222
CUDBGGridInfo....222
blockDim....223
context....223
dev....223
function....223
functionEntry....223
gridDim....223
gridId64....223
module....223
origin....223
parentGridId....223
tid....223
type....223
Chapter 5. Data Fields....224

Chapter 1. Release Notes

1.2. CUDA 12.9 Release

Major changes

- Suport late attach on WSL.
- Bugfixes and performance improvements.

New APIs

The following APIs were added in this release. Please refer to the Modules documentation for more details about the new methods.

getCbuWarpState(uint32_t dev, uint32_t sm, uint64_t warpMask, CUDBGCbuWarpState* warpStates, uint32_t numWarpStates)

Gets CBU state of a given warp.

consumeCudaLogs(CUDBGCudaLogMessage* logMessages, uint32_t numMessages, uint32_t* numConsumed)

Get CUDA error log entries. This consumes the log entries, so they will not be available in subsequent calls.

readCPUCallStack(uint32_t dev, uint64_t gridId64, uint64_t *addrs, uint32_t numAddrs, uint32_t* totalNumAddrs)

Read CPU call stack captured at the time of kernel launch.

Updated APIs

The following APIs were updated in this release. Please refer to the method documentation for the details. The old code, compiled for the older versions of the API will still work.

- readWarpState(uint32_t dev, uint32_t sm, uint32_t wp, CUDBGWarpState *state)

1.3. CUDA 12.8 Release

Major changes

- Support late attach on Jetson targets.
- Bugfixes and performance improvements.

New APIs

The following APIs were added in this release. Please refer to the Modules documentation for more details about the new methods.

readWarpResources(uint32_t dev, uint32_t sm, uint32_t wp, CUDBGWarpResources *resources)

Get the resources assigned to a given warp.

1.4. CUDA 12.7 Release

Major changes

- Bugfixes and performance improvements.

New APIs

The following APIs were added in this release. Please refer to the Modules documentation for more details about the new methods.

getClusterExceptionTargetBlock(uint32_t dev, uint32_t sm, uint32_t wp, CuDim3 *blockIdx, bool *blockIdxValid)

Retrieves the target block index and validity status for a given device, streaming multiprocessor, and warp for cluster exceptions.

Updated APIs

The following APIs were updated in this release. Please refer to the method documentation for the details. The old code, compiled for the older versions of the API will still work.

- getGridInfo(uint32_t dev, uint64_t gridId64, CUDBGGridInfo *gridInfo)
- getClusterDim(uint32_t dev, uint32_t sm, uint32_t wp, CuDim3 *clusterDim)
- readWarpState(uint32_t dev, uint32_t sm, uint32_t wp, CUDBGWarpState *state)

1.5. CUDA 12.6 Release

Major changes

- Reduced overhead for batch breakpoint updates.
- Moved constbank memory dump control to a separate flag.
- Bugfixes and performance improvements.

New APIs

CUDBG_COREDUMP_SKIP_CONSTBANK_MEMORY flag for coredump generation (generateCoredump).

In the previous API versions the CUDBG_COREDUMP_SKIP_GLOBAL_MEMORY controlled both the global and the constant memory. Since CUDA 12.6 the constbank memory is controlled by a separate flag (the constbank memory is usually smaller than global memory, so it is feasible to dump it by default even if the global memory is skipped).

1.6. CUDA 12.5 Release

Major changes

- Significant performance improvements for memory accessing operations and stepping.
- Bugfixes and stability improvements.

New APIs

The following APIs were added in this release. Please refer to the Modules documentation for more details about the new methods.

readAllVirtualReturnAddresses(uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint64_t *addrs, uint32_t numAddrs, uint32_t* callDepth, uint32_t* syscallCallDepth)

Reads all the virtual return addresses.

getSupportedDebuggerCapabilities(CUDBGCapabilityFlags* capabilities)

Returns debugger capabilities that are supported by this version of the API.

readSmException(uint32_t dev, uint32_t sm, CUDBGException_t *exception, uint64_t *errorPC, bool *errorPCValid)

Get the SM exception status if it exists.

Deprecated APIs

CUDBG_COREDUMP_SKIP_ABORT

The generateCoredump API no longer accepts the CUDBG_COREDUMP_SKIP_ABORT flag. Note that this flag was ignored in the previous versions of the API.

1.7. CUDA 12.4 Release

Major changes

- Made CUDA ELF file handling more robust and performant.
- Bugfixes and performance improvements.

New APIs

The following APIs were added in this release. Please refer to the Modules documentation for more details about the new methods.

getDeviceInfoSizes(uint32_t dev, CUDBGDeviceInfoSizes* sizes)

Returns sizes for device info structs and defined attributes.

getDeviceInfo(uint32_t dev, CUDBGDeviceInfoQueryType_t type, void *buffer, uint32_t length, uint32_t *dataLength)

Returns full or changed device info.

Updated APIs

The following APIs were updated in this release. Please refer to the method documentation for the details. The old code, compiled for the older versions of the API will still work.

- getConstBankAddress(uint32_t dev, uint64_t gridId64, uint32_t bank, uint64_t* address, uint32_t* size)
- singleStepWarp(uint32_t dev, uint32_t sm, uint32_t wp, uint32_t laneHint, uint32_t nsteps, uint32_t flags, uint64_t *warpMask)

1.8. CUDA 12.3 Release

Major changes

- Support generating coredumps after the debugger has attached.
- Bugfixes and performance improvements.

New APIs

getConstBankAddress(uint32_t dev, uint32_t sm, uint32_t wp, uint32_t bank, uint32_t offset, uint64_t* address)

Returns sizes for device info structs and defined attributes.

generateCoredump(const char* filename, CUDBGCoredumpGenerationFlags flags)

Generates a coredump for the current GPU state.

Updated APIs

The following APIs were updated in this release. Please refer to the method documentation for the details. The old code, compiled for the older versions of the API will still work.

- getLoadedFunctionInfo(uint32_t devId, uint64_t handle, CUDBGLoadedFunctionInfo *info, uint32_t startIndex, uint32_t numEntries)

Deprecated APIs

disassemble() deprecation notice

The disassemble() API function is deprecated. It will be dropped in an upcoming release. API consumers should use the nvdisasm utility instead.

1.9. CUDA 12.2 Release

Major changes

- Switch to the new debugger back-end (Unified Debugger) on WSL.
- Switch to the new debugger back-end (Unified Debugger) on Jetson.
- Bugfixes and performance improvements.

New APIs

The following APIs were added in this release. Please refer to the Modules documentation for more details about the new methods.

getErrorStringEx(char *buf, uint32_t bufSz, uint32_t *msgSz)

Fills a user-provided buffer with an error message encoded as a null-terminated ASCII string. The error message is specific to the last failed API call and is invalidated after every API call.

1.10. CUDA 12.1 Release

Major changes

- Improved support for single stepping.
- Bugfixes and performance improvements.

1.11. CUDA 12.0 Release

Major changes

- Debugging support for application using CUDA Dynamic Parallelism V2.

- Improved support for latest GPU architectures.
- Bugfixes and performance improvements.

New APIs

The following APIs were added in this release. Please refer to the Modules documentation for more details about the new methods.

getClusterDim(uint32_t dev, uint64_t gridId64, CuDim3 *clusterDim)
Get the number of blocks in the given cluster.

readClusterIdx(uint32_t dev, uint32_t sm, uint32_t wp, CuDim3 *clusterIdx)
Get the number of blocks in the given cluster.

Updated APIs

The following APIs were updated in this release. Please refer to the method documentation for the details. The old code, compiled for the older versions of the API will still work.

- getGridInfo(uint32_t dev, uint64_t gridId64, CUDBGGridInfo *gridInfo)
- readWarpState(uint32_t dev, uint32_t sm, uint32_t wp, CUDBGWarpState *state)

1.12. CUDA 11.8 Release

New Unified Debugger backend
A new debugger backend named the Unified Debugger (UD) has been introduced on Linux platforms with this release. UD is supported across multiple platforms including both Windows and Linux. The UD should mostly be transparent to existing clients of the API. The previous debugger backend, known as the classic debugger backend, can still be used by setting the environment variable CUDBG_USE_LEGACY_DEBUGGER to 1. UD is not supported on Maxwell GPUs. The clients of the API shall switch to the classic backend if Maxwell support is required.

Device side cudaDeviceSynchronize() undefined behavior
The clients of the API shall prevent the use of SingleStepWarp in the deprecated cudaDeviceSynchronize() function. Instead, revert to stepping over the call with a BP set and resume.

CUDBG_EVENT_KERNEL_READY events are no longer delivered for GPU-launched grids
CUDBG_EVENT_KERNEL_READY events for GPU-launched grids that were delivered over the ASYNC event pipe will no longer be sent. GPU-launched here refers to codes making use of CUDA Dynamic Parallelism. The existing implementation for this use case was imprecise. The callback did not report all GPU-launched grids before execution has begun, only those found on the deivce currently executing that were not previously reported during their launch. This functionality may be reintroduced in a future release. If this functionality is strictly required, the classic debugger backend can be used.

getLoadedFunctionInfo
Added a new getLoadedFunctionInfo call to obtain the section number and address of loaded functions for a given module.

1.13. CUDA 7.0 Release

Stability improvements. No API additions or changes.

1.14. CUDA 6.5 Release

Predicate registers

The per-thread predicate registers can be accessed and modified via the readPredicates() and writePredicates() calls. Each of these calls expects a buffer of sufficient size to cover all predicates for the current GPU architecture. The number of current predicate registers can be read back via the getNumPredicates() API call.

Condition code register

The per-thread condition code register can be accessed and modified via the readCCRegister() and writeCCRegister() calls. The condition code register is a unsigned 32-bit register, whose format may vary by GPU architecture.

Device Name

The getDeviceName() API returns a string containing the publically exposed product name of the GPU.

API Error Reporting Improvement

The symbol CUDBG_REPORT_DRIVER_API_ERROR_FLAGS points to an unsigned 32-bit integer in the application's process space that controls API error reporting. The values that can be written into this flag are specified in the CUDBGReportDriverApiErrorFlags enum. In 6.5, setting the bit corresponding to CUDBG_REPORT_DRIVER_API_ERROR_FLAGS_SUPPRESS_NOT_READY in the variable CUDBG_REPORT_DRIVER_API_ERROR_FLAGS is supported. This will prevent CUDA API calls that return the runtime API error code cudaErrorNotReady or the driver API error code cuErrorNotReady from executing the CUDA API error reporting function.

Chapter 2. Introduction

This document describes the API for the set routines and data structures available in the CUDA library to any debugger.

Starting with 3.0, the CUDA debugger API includes several major changes, of which only few are directly visible to end-users:

- Performance is greatly improved, both with respect to interactions with the debugger and the performance of applications being debugged.
- The format of cubins has changed to ELF and, as a consequence, most restrictions on debug compilations have been lifted. More information about the new object format is included below.

The debugger API has significantly changed, reflected in the CUDA-GDB sources.

2.1. Debugger API

The CUDA Debugger API was developed with the goal of adhering to the following principles:

- Policy free
- Explicit
- Axiomatic
- Extensible
- Machine oriented

Being explicit is another way of saying that we minimize the assumptions we make. As much as possible the API reflects machine state, not internal state.

There are two major "modes" of the devices: stopped or running. We switch between these modes explicitly with suspendDevice and resumeDevice, though the machine may suspend on its own accord, for example when hitting a breakpoint.

Only when stopped, can we query the machine's state. Warp state includes which function is it runnning, which block, which lanes are valid, etc.

As of CUDA 6.0, state collection functions in the debug API will return CUDBG_ERROR_RUNNING_DEVICE if called without first calling the suspendDevice entry point to ensure the device is stopped.

Clients of the debug API should suspend all devices before servicing a CUDBGEvent. A valid CUDBGEvent is only guaranteed to be returned after the notification callback set using CUDBGAPI_st::setNotifyNewEventCallback() is executed. Any debug API entry point will return CUDBG_ERROR_RECURSIVE_API_CALL when the call is made from within the notification callback set using CUDBGAPI_st::setNotifyNewEventCallback().

2.2. ELF and DWARF

CUDA applications are compiled in ELF binary format.

Starting with CUDA 6.0, DWARF device information is obtained through an API call of CUDBGAPI_st::getElfImageByHandle using the handle exposed from CUDBGEvent of type CUDBG_EVENT_ELF_IMAGE_LOADED. This means that the information is not available until runtime, after the CUDA driver has loaded. The DWARF device information lifetime is valid until it is unloaded, which presents a CUDBGEvent of type CUDBG_EVENT_ELF_IMAGE_UNLOADED.

In CUDA 5.5 and earlier, the DWARF device information was returned as part of the `CUDBGEvent` of type CUDBG_EVENT_ELF_IMAGE_LOADED. The pointers presented in CUDBGEvent55 were read-only pointers to memory managed by the debug API. The memory pointed to was implicitly scoped to the lifetime of the loading CUDA context. Accessing the returned pointers after the context was destroyed resulted in undefined behavior.

DWARF device information contains physical addresses for all device memory regions except for code memory. The address class field (DW_AT_address_class) is set for all device variables, and is used to indicate the memory segment type (ptxStorageKind). The physical addresses must be accessed using several segment-specific API calls.

For memory reads, see:

- CUDBGAPI_st::readCodeMemory()
- CUDBGAPI_st::readConstMemory()
- CUDBGAPI_st::readGlobalMemory()
- CUDBGAPI_st::readParamMemory()
- CUDBGAPI_st::readSharedMemory()
- CUDBGAPI_st::readLocalMemory()
- CUDBGAPI_st::readTextureMemory()

For memory writes, see:

- CUDBGAPI_st::writeGlobalMemory()
- CUDBGAPI_st::writeParamMemory()
- CUDBGAPI_st::writeSharedMemory()
- CUDBGAPI_st::writeLocalMemory()

Access to code memory requires a virtual address. This virtual address is embedded for all device code sections in the device ELF image. See the API call:

- CUDBGAPI_st::readVirtualPC()

Here is a typical DWARF entry for a device variable located in memory:

```
<2><321>: Abbrev Number: 18 (DW_TAG_formal_parameter)
     DW_AT_decl_file   : 27
     DW_AT_decl_line   : 5
     DW_AT_name        : res
     DW_AT_type        : <2c6>
     DW_AT_location    : 9 byte block: 3 18 0 0 0 0 0 0 0       (DW_OP_addr: 18)
     DW_AT_address_class: 7
```

The above shows that variable 'res' has an address class of 7 (ptxParamStorage). Its location information shows it is located at address 18 within the parameter memory segment.

Local variables are no longer spilled to local memory by default. The DWARF now contains variable-to-register mapping and liveness information for all variables. It can be the case that variables are spilled to local memory, and this is all contained in the DWARF information which is ULEB128 encoded (as a DW_OP_regx stack operation in the DW_AT_location attribute).

Here is a typical DWARF entry for a variable located in a local register:

```
<3><359>: Abbrev Number: 20 (DW_TAG_variable)
     DW_AT_decl_file   : 27
     DW_AT_decl_line   : 7
     DW_AT_name        : c
     DW_AT_type        : <1aa>
     DW_AT_location    : 7 byte block: 90 b9 e2 90 b3 d6 4      (DW_OP_regx:
 160631632185)
     DW_AT_address_class: 2
```

This shows variable 'c' has address class 2 (ptxRegStorage) and its location can be found by decoding the ULEB128 value, DW_OP_regx: 160631632185. See cuda-tdep.c in the cuda-gdb source drop for information on decoding this value and how to obtain which physical register holds this variable during a specific device PC range.

Access to physical registers liveness information requires a 0-based physical PC. See the API call:

- CUDBGAPI_st::readPC()

2.3. ABI Support

ABI support is handled through the following thread API calls:

- CUDBGAPI_st::readCallDepth()
- CUDBGAPI_st::readReturnAddress()
- CUDBGAPI_st::readVirtualReturnAddress()

The return address is not accessible on the local stack and the API call must be used to access its value.

For more information, please refer to the ABI documentation titled "Fermi ABI: Application Binary Interface".

2.4. Exception Reporting

Some kernel exceptions are reported as device events and accessible via the API call:

- CUDBGAPI_st::readLaneException()

The reported exceptions are listed in the CUDBGException_t enum type. Each prefix, (Device, Warp, Lane), refers to the precision of the exception. That is, the lowest known execution unit that is responsible for the origin of the exception. All lane errors are precise; the exact instruction and lane that caused the error are known. Warp errors are typically within a few instructions of where the actual error occurred, but the exact lane within the warp is not known. On device errors, we *may* know the *kernel* that caused it. Explanations about each exception type can be found in the documentation of the struct.

Exception reporting is only supported on Fermi (sm_20 or greater).

2.5. Attaching and Detaching

The debug client must take the following steps to attach to a running CUDA application:

1. Attach to the CPU process corresponding to the CUDA application. The CPU part of the application will be frozen at this point.
2. Check to see if the `CUDBG_DEBUGGER_INITIALIZED` variable is accessible from the memory space of the application. If not, it implies that the application has not loaded the CUDA driver, and the attaching to the application is complete.
3. If the `CUDBG_DEBUGGER_INITIALIZED` variable is accessible and non-zero, then the attach procedure is finished.
4. Check the existence and value of the global variable `CUDBG_INITIATE_DEBUGGER_ATTACH_PROCEDURE_FD`:
   a). If it doesn't exist, then proceed with Legacy debugger initialization described below.
   b). On Linux, if it's less than zero, then the CUDA driver has not fully initialized yet. The attach process should be retried later, once this variable is greater than or equal to zero.
   c). If it's value is greater than or equal to zero, then proceed with debugger initialization as described below.
5. Legacy debugger initialization: If the `CUDBG_INITIATE_DEBUGGER_ATTACH_PROCEDURE_FD` variable is not present or is less than zero:
   a). Make a dynamic (inferior) function call to the function `cudbgApiAttach()`, e.g. by using `ptrace(2)` on Linux. This causes a helper process to be forked off from the application, which assists in attaching to the CUDA process.
   b). Ensure that the initialization of the CUDA debug API is complete, or wait till API initialization is successful (i.e. call the `initialize()` API method until it succeeds).

c). Make the `initializeAttachStub()` API call to initialize the helper process that was forked off from the application earlier.

6. If the `CUDBG_INITIATE_DEBUGGER_ATTACH_PROCEDURE_FD` variable is greater than or equal to zero:

   a). Insert a breakpoint in the `CUDBG_REPORT_ATTACH_PROCEDURE_FINISHED` function.

   b). Open the application's file descriptor whose number is given in `CUDBG_INITIATE_DEBUGGER_ATTACH_PROCEDURE_FD` variable and write a single byte to it.

   On Linux, this can be achieved by using the `/proc` filesystem and the fd file `/proc/PID/FD`.

   c). Resume all the threads of the attached program.

   d). Wait until the `CUDBG_REPORT_ATTACH_PROCEDURE_FINISHED` breakpoint is hit, remove the breakpoint and then stop/freeze all of the threads again.

   e). Call the `initialize()` API method. It should now succeed.

7. Read the value of the `CUDBG_RESUME_FOR_ATTACH_DETACH` variable from the memory space of the application:

   - If the value is non-zero, resume the CUDA application so that more data can be collected about the application and sent to the debugger. When the application is resumed, the debug client can expect to receive various CUDA events from the CUDA application. Once all state has been collected, the debug client will receive the event `CUDBG_EVENT_ATTACH_COMPLETE`.
   - If the value is zero, there is no more attach data to collect. Set the `CUDBG_IPC_FLAG_NAME` variable to 1 in the application's process space, which enables further events from the CUDA application.

8. At this point, attaching to the CUDA application is complete and all GPUs belonging to the CUDA application will be suspended.

The debug client must take the following steps to detach from a running CUDA application:

1. Check to see if the `CUDBG_IPC_FLAG_NAME` variable is accessible from the memory space of the application, and that the CUDA debug API is initialized. If either of these conditions is not met, treat the application as CPU-only and detach from the application.
2. Next, make the `clearAttachState` API call to prepare the CUDA debug API for detach.
3. Make a dynamic (inferior) function call to the function `cudbgApiDetach()` in the memory space of the application, e.g. by using ptrace(2) on Linux. This causes CUDA driver to setup state for detach.
4. Read the value of the `CUDBG_RESUME_FOR_ATTACH_DETACH` variable from the memory space of the application. If the value is non-zero, make the `requestCleanupOnDetach` API call.
5. Set the `CUDBG_DEBUGGER_INITIALIZED` variable to 0 in the memory space of the application. This makes sure the debugger is reinitialized from scratch if the debug client re-attaches to the application in the future.

6. If the value of the `CUDBG_RESUME_FOR_ATTACH_DETACH` variable was found to be non-zero in step 4, delete all breakpoints and resume the CUDA application. This allows the CUDA driver to perform cleanups before the debug client detaches from it. Once the cleanup is complete, the debug client will receive the event `CUDBG_EVENT_DETACH_COMPLETE`.
7. Set the `CUDBG_IPC_FLAG_NAME` variable to zero in the memory space of the application. This prevents any more callbacks from the CUDA application to the debugger.
8. The client must then finalize the CUDA debug API.
9. Finally, detach from the CPU part of the CUDA application. At this point all GPUs belonging to the CUDA application will be resumed.

Chapter 3. Modules

Here is a list of all modules:

- General
- Initialization
- Device Execution Control
- Breakpoints
- Device State Inspection
- Device State Alteration
- Grid Properties
- Device Properties
- DWARF Utilities
- Events

3.1. General

struct CUDBGCudaLogMessage

CUDA Log Message.

enum CUDBGCudaLogLevel

CUDA Log severity level.

Values

CUDBG_CUDA_LOG_LEVEL_INVALID = 0xFFFFFFFFU
Invalid log level.

CUDBG_CUDA_LOG_LEVEL_ERROR = 0
Error log level, matches CU_LOG_LEVEL_ERROR.

CUDBG_CUDA_LOG_LEVEL_WARNING = 1
Warning log level, matches CU_LOG_LEVEL_WARNING.

enum CUDBGResult

Result values of all the API routines.

Values

CUDBG_SUCCESS = 0x0000
The API call executed successfully.

CUDBG_ERROR_UNKNOWN = 0x0001
Error type not listed below.

CUDBG_ERROR_BUFFER_TOO_SMALL = 0x0002
Cannot copy all the queried data into the buffer argument.

CUDBG_ERROR_UNKNOWN_FUNCTION = 0x0003
Function cannot be found in the CUDA kernel.

CUDBG_ERROR_INVALID_ARGS = 0x0004
Wrong use of arguments (NULL pointer, illegal value,....).

CUDBG_ERROR_UNINITIALIZED = 0x0005
Debugger API has not yet been properly initialized.

CUDBG_ERROR_INVALID_COORDINATES = 0x0006
Invalid block or thread coordinates were provided.

CUDBG_ERROR_INVALID_MEMORY_SEGMENT = 0x0007
Invalid memory segment requested.

CUDBG_ERROR_INVALID_MEMORY_ACCESS = 0x0008
Requested address (+size) is not within proper segment boundaries.

CUDBG_ERROR_MEMORY_MAPPING_FAILED = 0x0009
Memory is not mapped and cannot be mapped.

CUDBG_ERROR_INTERNAL = 0x000a
A debugger internal error occurred.

CUDBG_ERROR_INVALID_DEVICE = 0x000b
Specified device cannot be found.

CUDBG_ERROR_INVALID_SM = 0x000c
Specified sm cannot be found.

CUDBG_ERROR_INVALID_WARP = 0x000d
Specified warp cannot be found.

CUDBG_ERROR_INVALID_LANE = 0x000e
Specified lane cannot be found.

CUDBG_ERROR_SUSPENDED_DEVICE = 0x000f
The requested operation is not allowed when the device is suspended.

CUDBG_ERROR_RUNNING_DEVICE = 0x0010
Device is running and not suspended.

CUDBG_ERROR_RESERVED_0 = 0x0011

CUDBG_ERROR_INVALID_ADDRESS = 0x0012
Address is out-of-range.

CUDBG_ERROR_INCOMPATIBLE_API = 0x0013
The requested API is not available.
CUDBG_ERROR_INITIALIZATION_FAILURE = 0x0014
The API could not be initialized.
CUDBG_ERROR_INVALID_GRID = 0x0015
The specified grid is not valid.
CUDBG_ERROR_NO_EVENT_AVAILABLE = 0x0016
The event queue is empty and there is no event left to be processed.
CUDBG_ERROR_SOME_DEVICES_WATCHDOGGED = 0x0017
Some devices were excluded because they have a watchdog associated with them.
CUDBG_ERROR_ALL_DEVICES_WATCHDOGGED = 0x0018
All devices were exclude because they have a watchdog associated with them.
CUDBG_ERROR_INVALID_ATTRIBUTE = 0x0019
Specified attribute does not exist or is incorrect.
CUDBG_ERROR_ZERO_CALL_DEPTH = 0x001a
No function calls have been made on the device.
CUDBG_ERROR_INVALID_CALL_LEVEL = 0x001b
Specified call level is invalid.
CUDBG_ERROR_COMMUNICATION_FAILURE = 0x001c
Communication error between the debugger and the application.
CUDBG_ERROR_INVALID_CONTEXT = 0x001d
Specified context cannot be found.
CUDBG_ERROR_ADDRESS_NOT_IN_DEVICE_MEM = 0x001e
Requested address was not originally allocated from device memory (most likely visible in system memory).
CUDBG_ERROR_MEMORY_UNMAPPING_FAILED = 0x001f
Requested address is not mapped and cannot be unmapped.
CUDBG_ERROR_INCOMPATIBLE_DISPLAY_DRIVER = 0x0020
The display driver is incompatible with the API.
CUDBG_ERROR_INVALID_MODULE = 0x0021
The specified module is not valid.
CUDBG_ERROR_LANE_NOT_IN_SYSCALL = 0x0022
The specified lane is not inside a device syscall.
CUDBG_ERROR_RESERVED_1 = 0x0023
CUDBG_ERROR_INVALID_ENVVAR_ARGS = 0x0024
Some environment variable's value is invalid.
CUDBG_ERROR_OS_RESOURCES = 0x0025
Error while allocating resources from the OS.
CUDBG_ERROR_FORK_FAILED = 0x0026
Error while forking the debugger process.
CUDBG_ERROR_NO_DEVICE_AVAILABLE = 0x0027
No CUDA capable device was found.

CUDBG_ERROR_ATTACH_NOT_POSSIBLE = 0x0028
Attaching to the CUDA program is not possible.
CUDBG_ERROR_WARP_RESUME_NOT_POSSIBLE = 0x0029
CUDBG_ERROR_INVALID_WARP_MASK = 0x002a
CUDBG_ERROR_AMBIGUOUS_MEMORY_ADDRESS = 0x002b
Specified device pointer cannot be resolved to a GPU unambiguously because it is valid on more than one GPU.
CUDBG_ERROR_RECURSIVE_API_CALL = 0x002c
CUDBG_ERROR_MISSING_DATA = 0x002d
CUDBG_ERROR_NOT_SUPPORTED = 0x002e

3.2. Initialization

CUDBGResult (*CUDBGAPI_st::finalize) ()

Finalize the API and free all memory.

Returns

CUDBG_SUCCESS, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_COMMUNICATION_FAILURE, CUDBG_ERROR_UNKNOWN

Since CUDA 3.0.

See also:

initialize

CUDBGResult (*CUDBGAPI_st::getSupportedDebuggerCapabilities) (CUDBGCapabilityFlags *capabilities)

Returns debugger capabilities that are supported by this version of the API.

Parameters

capabilities
- returned debugger capabilities

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS,

Since CUDA 12.5.

This API method can be called without initializing the API.

CUDBGResult (*CUDBGAPI_st::initialize) ()

Initialize the API.

Returns

CUDBG_SUCCESS, CUDBG_ERROR_UNKNOWN

Since CUDA 3.0.

See also:

finalize

3.3. Device Execution Control

CUDBGResult (*CUDBGAPI_st::resumeDevice) (uint32_t dev)

Resume a suspended CUDA device.

Parameters

dev
- device index

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_RUNNING_DEVICE, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

suspendDevice

singleStepWarp

CUDBGResult (*CUDBGAPI_st::resumeWarpsUntilPC) (uint32_t devId, uint32_t sm, uint64_t warpMask, uint64_t virtPC)

Inserts a temporary breakpoint at the specified virtual PC, and resumes all warps in the specified bitmask on a given SM. As compared to CUDBGAPI_st::resumeDevice, CUDBGAPI_st::resumeWarpsUntilPC provides finer-grain control by resuming a selected set of

warps on the same SM. The main intended usage is to accelerate the single-stepping process when the target PC is known in advance. Instead of single-stepping each warp individually until the target PC is hit, the client can issue this API. When this API is used, errors within CUDA kernels will no longer be reported precisely. In the situation where resuming warps is not possible, this API will return CUDBG_ERROR_WARP_RESUME_NOT_POSSIBLE. The client should then fall back to using CUDBGAPI_st::singleStepWarp or CUDBGAPI_st::resumeDevice.

Parameters

devId
- device index

sm
- the SM index

warpMask
- the bitmask of warps to resume (1 = resume, 0 = do not resume)

virtPC
- the virtual PC where the temporary breakpoint will be inserted

Returns

CUDBG_SUCCESS CUDBG_ERROR_INVALID_ARGS CUDBG_ERROR_INVALID_DEVICE CUDBG_ERROR_INVALID_SM CUDBG_ERROR_INVALID_WARP_MASK CUDBG_ERROR_WARP_RESUME_NOT_POSSIBLE CUDBG_ERROR_UNINITIALIZED

Since CUDA 6.0.

See also:

resumeDevice

CUDBGResult (*CUDBGAPI_st::singleStepWarp) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t laneHint, uint32_t nsteps, uint32_t flags, uint64_t *warpMask)

Single step an individual warp nsteps times on a suspended CUDA device. Only the last instruction in a range should be a control flow instruction.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

laneHint
nsteps
- number of single steps

flags
warpMask
- the warps that have been single-stepped

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_RUNNING_DEVICE, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_UNKNOWN

Since CUDA 7.5.

See also:

resumeDevice

suspendDevice

CUDBGResult (*CUDBGAPI_st::singleStepWarp40)(uint32_t dev, uint32_t sm, uint32_t wp)

Single step an individual warp on a suspended CUDA device.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_RUNNING_DEVICE, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_UNKNOWN, CUDBG_ERROR_WARP_RESUME_NOT_POSSIBLE

Since CUDA 3.0.

> Note:
>
> Deprecated in CUDA 4.1.

See also:

resumeDevice

suspendDevice

singleStepWarp

CUDBGResult (*CUDBGAPI_st::singleStepWarp41) (uint32_t dev, uint32_t sm, uint32_t wp, uint64_t *warpMask)

Single step an individual warp on a suspended CUDA device.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

warpMask
- the warps that have been single-stepped

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_RUNNING_DEVICE, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_UNKNOWN

Since CUDA 4.1.

> Note:
>
> Deprecated in CUDA 7.5.

See also:

resumeDevice

suspendDevice

CUDBGResult (*CUDBGAPI_st::suspendDevice) (uint32_t dev)

Suspends a running CUDA device.

Parameters

dev
- device index

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_RUNNING_DEVICE, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

resumeDevice

singleStepWarp

3.4. Breakpoints

CUDBGResult (*CUDBGAPI_st::getAdjustedCodeAddress) (uint32_t devId, uint64_t address, uint64_t *adjustedAddress, CUDBGAdjAddrAction adjAction)

The client must call this function before inserting a breakpoint, or when the previous or next code address is needed. Returns the adjusted code address for a given code address for a given device.

Parameters

devId
- the device index

address

adjustedAddress
- adjusted address

adjAction
- whether the adjusted next, previous or current address is needed

Returns

CUDBG_SUCCESS, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_INVALID_ADDRESS, CUDBG_ERROR_INVALID_DEVICE

Since CUDA 5.5.

See also:

unsetBreakpoint

CUDBGResult (*CUDBGAPI_st::setBreakpoint) (uint32_t dev, uint64_t addr)

Sets a breakpoint at the given instruction address for the given device. Before setting a breakpoint, CUDBGAPI_st::getAdjustedCodeAddress should be called to get the adjusted breakpoint address.

Parameters

dev
- the device index

addr
- instruction address

Returns

CUDBG_SUCCESS, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_INVALID_ADDRESS, CUDBG_ERROR_INVALID_DEVICE

Since CUDA 3.2.

See also:

unsetBreakpoint

CUDBGResult (*CUDBGAPI_st::setBreakpoint31) (uint64_t addr)

Sets a breakpoint at the given instruction address.

Parameters

addr
- instruction address

Returns

CUDBG_SUCCESS, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_INVALID_ADDRESS

Since CUDA 3.0.

> Note:
>
> Deprecated in CUDA 3.2.

See also:

unsetBreakpoint31

CUDBGResult (*CUDBGAPI_st::unsetBreakpoint) (uint32_t dev, uint64_t addr)

Unsets a breakpoint at the given instruction address for the given device.

Parameters

dev
- the device index

addr
- instruction address

Returns

CUDBG_SUCCESS, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_INVALID_ADDRESS, CUDBG_ERROR_INVALID_DEVICE

Since CUDA 3.2.

See also:

setBreakpoint

CUDBGResult (*CUDBGAPI_st::unsetBreakpoint31) (uint64_t addr)

Unsets a breakpoint at the given instruction address.

Parameters

addr
- instruction address

Returns

CUDBG_SUCCESS, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

> Note:
>
> Deprecated in CUDA 3.2.

See also:

setBreakpoint31

3.5. Device State Inspection

CUDBGResult (*CUDBGAPI_st::consumeCudaLogs) (CUDBGCudaLogMessage *logMessages, uint32_t numMessages, uint32_t *numConsumed)

Get CUDA error log entries. This consumes the log entries, so they will not be available in subsequent calls.

Parameters

logMessages
- client-allocated array to store log entries

numMessages
- capacity of the logMessages array, in number of elements

numConsumed
- returned number of entries written to logMessages

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_NO_EVENT_AVAILABLE, CUDBG_ERROR_NOT_SUPPORTED,

Since CUDA 12.9.

CUDBGResult (*CUDBGAPI_st::generateCoredump) (const char *filename, CUDBGCoredumpGenerationFlags flags)

Generates a coredump for the current GPU state.

Parameters

filename
- target coredump file name

flags
- coredump generation flags/options

Returns

CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_NOT_SUPPORTED

Since CUDA 12.3

CUDBGResult (*CUDBGAPI_st::getCbuWarpState) (uint32_t dev, uint32_t sm, uint64_t warpMask, CUDBGCbuWarpState *warpStates, uint32_t numWarpStates)

Gets CBU state of a given warp.

Parameters

dev
- device index

sm
- SM index

warpMask
- bitmask of the warps which states should be returned in warpStates

warpStates
- pointer to the array of CUDBGCbuWarpState structures

numWarpStates
- number of elements in warpStates array

Returns

CUDBG_ERROR_NOT_SUPPORTED,

Since CUDA 12.9.

CUDBGResult (*CUDBGAPI_st::getClusterExceptionTargetBlock)(uint32_t dev, uint32_t sm, uint32_t wp, CuDim3 *blockIdx, bool *blockIdxValid)

Retrieves the target block index and validity status for a given device, streaming multiprocessor, and warp for cluster exceptions.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

blockIdx
- pointer to a `CuDim3` structure that will be populated with the target block index

blockIdxValid
- pointer to a boolean variable that will be set to `true` if the target block index is valid, and `false` otherwise. Value will be set to false if the warp is not stopped on a cluster exception

Returns

CUDBG_SUCCESS, CUDBG_ERROR_NOT_SUPPORTED, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_INVALID_ARGS,

Since CUDA 12.7.

CUDBGResult (*CUDBGAPI_st::getConstBankAddress)(uint32_t dev, uint64_t gridId64, uint32_t bank, uint64_t *address, uint32_t *size)

Get constant bank GPU VA and size.

Parameters

dev
- device index

gridId64
- grid ID of the grid containing the constant bank

bank
- constant bank number

address
- (output) GPU VA of the bank memory

size
- (output) bank size

Returns

CUDBG_ERROR_NOT_SUPPORTED

Since CUDA 12.4

CUDBGResult (*CUDBGAPI_st::getConstBankAddress123) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t bank, uint32_t offset, uint64_t *address)

Convert constant bank number and offset into GPU VA.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

bank
- constant bank number

offset
- offset within the bank

address
- (output) GPU VA

Returns

CUDBG_ERROR_NOT_SUPPORTED

Since CUDA 12.3

> Note:
>
> Deprecated in CUDA 12.4.

CUDBGResult (*CUDBGAPI_st::getCudaExceptionString) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, char *buf, uint32_t bufSz, uint32_t *msgSz)

Get error string for CUDA Exceptions.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

buf
- buffer for the error string

bufSz
- buffer size

msgSz
- error message size with null character, can be null

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_BUFFER_TOO_SMALL, CUDBG_ERROR_NOT_SUPPORTED

Since CUDA 13.0.

CUDBGResult (*CUDBGAPI_st::getHardwareBarrierInfo)(uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, CUDBGBarrierScope *scope, char *buf, uint32_t bufSz, uint32_t *msgSz)

Get hardware barrier information.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

scope
- barrier scope

buf
- buffer for the barrier information

bufSz
- buffer size

msgSz
- error message size with null character, can be null

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_BUFFER_TOO_SMALL, CUDBG_ERROR_NOT_SUPPORTED

Since CUDA 13.1.

CUDBGResult (*CUDBGAPI_st::getLoadedFunctionInfo) (uint32_t devId, uint64_t handle, CUDBGLoadedFunctionInfo *info, uint32_t startIndex, uint32_t numEntries)

Get the section number and address of loaded functions for a given module.

Parameters

devId
handle
- ELF/cubin image handle

info
startIndex
numEntries
- number of function load entries to read

Returns

CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_NOT_SUPPORTED

Since CUDA 11.8

CUDBGResult (*CUDBGAPI_st::getLoadedFunctionInfo118) (uint32_t devId, uint64_t handle, CUDBGLoadedFunctionInfo *info, uint32_t numEntries)

Get the section number and address of loaded functions for a given module.

Parameters

devId
handle
- ELF/cubin image handle

info
numEntries
- number of function load entries to read

Returns

CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_NOT_SUPPORTED

Since CUDA 11.8

> Note:
>
> Deprecated in CUDA 12.3.

CUDBGResult (*CUDBGAPI_st::getManagedMemoryRegionInfo)(uint64_t startAddress, CUDBGMemoryInfo *memoryInfo, uint32_t memoryInfo_size, uint32_t *numEntries)

Returns a sorted list of managed memory regions The sorted list of memory regions starts from a region containing the specified starting address. If the starting address is set to 0, a sorted list of managed memory regions is returned which starts from the managed memory region with the lowest start address.

Parameters

startAddress

- The address that the first region in the list must contain. If the starting address is set to 0, the list of managed memory regions returned starts from the managed memory region with the lowest start address.

memoryInfo

- Client-allocated array of memory region records of type CUDBGMemoryInfo.

memoryInfo_size

- Number of records of type CUDBGMemoryInfo that memoryInfo can hold.

numEntries

- Pointer to a client-allocated variable holding the number of valid entries retured in memoryInfo. Valid entries are continguous and start from memoryInfo[0].

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_ADDRESS, CUDBG_ERROR_INTERNAL

Since CUDA 6.0.

CUDBGResult (*CUDBGAPI_st::memcheckReadErrorAddress) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint64_t *address, ptxStorageKind *storage)

Get the address that memcheck detected an error on.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

address
- returned address detected by memcheck

storage
- returned address class of address

Returns

CUDBG_ERROR_NOT_SUPPORTED,

Since CUDA 5.0.

CUDBGResult (*CUDBGAPI_st::readActiveLanes) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t *activeLanesMask)

Reads the bitmask of active lanes on a valid warp.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

activeLanesMask
- the returned bitmask of active lanes

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

readGridId

readBlockIdx

readThreadIdx

readBrokenWarps

readValidWarps

readValidLanes

CUDBGResult (*CUDBGAPI_st::readAllVirtualReturnAddresses) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint64_t *addrs, uint32_t numAddrs, uint32_t *callDepth, uint32_t *syscallCallDepth)

Reads all the virtual return addresses.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

addrs
- the returned addresses array

numAddrs
- number of elements in addrs array

callDepth
- the returned call depth

syscallCallDepth
- the returned syscall call depth

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_UNKNOWN_FUNCTION, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_INTERNAL

Since CUDA 12.5.

See also:

readCallDepth

readReturnAddress

CUDBGResult (*CUDBGAPI_st::readBlockIdx) (uint32_t dev, uint32_t sm, uint32_t wp, CuDim3 *blockIdx)

Reads the CUDA block index running on a valid warp.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

blockIdx
- the returned CUDA block index

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 4.0.

See also:

readGridId

readThreadIdx

readBrokenWarps

readValidWarps

readValidLanes

readActiveLanes

CUDBGResult (*CUDBGAPI_st::readBlockIdx32) (uint32_t dev, uint32_t sm, uint32_t wp, CuDim2 *blockIdx)

Reads the two-dimensional CUDA block index running on a valid warp.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

blockIdx
- the returned CUDA block index

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

> Note:
>
> Deprecated in CUDA 4.0.

See also:

readGridId

readThreadIdx

readBrokenWarps

readValidWarps

readValidLanes

readActiveLanes

CUDBGResult (*CUDBGAPI_st::readBrokenWarps) (uint32_t dev, uint32_t sm, uint64_t *brokenWarpsMask)

Reads the bitmask of warps that are at a breakpoint on a given SM.

Parameters

dev
- device index

sm
- SM index

brokenWarpsMask
- the returned bitmask of broken warps

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

readGridId

readBlockIdx

readThreadIdx

readValidWarps

readValidLanes

readActiveLanes

CUDBGResult (*CUDBGAPI_st::readCallDepth) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint32_t *depth)

Reads the call depth (number of calls) for a given lane.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

depth
- the returned call depth

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_UNINITIALIZED

Since CUDA 4.0.

See also:

readReturnAddress

readVirtualReturnAddress

CUDBGResult (*CUDBGAPI_st::readCallDepth32) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t *depth)

Reads the call depth (number of calls) for a given warp.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

depth
- the returned call depth

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.1.

> Note:
>
> Deprecated in CUDA 4.0.

See also:

readReturnAddress32

readVirtualReturnAddress32

CUDBGResult (*CUDBGAPI_st::readCCRegister) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint32_t *val)

Reads the hardware CC register.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

val
- buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 6.5.

See also:

readCodeMemory

readConstMemory129

readGenericMemory

readGlobalMemory

readParamMemory

readSharedMemory

readTextureMemory

readLocalMemory

readRegister

readPC

readPredicates

CUDBGResult (*CUDBGAPI_st::readClusterIdx) (uint32_t dev, uint32_t sm, uint32_t wp, CuDim3 *clusterIdx)

Reads the CUDA cluster index running on a valid warp.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

clusterIdx
- the returned CUDA cluster index

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 12.0.

> Note:
>
> Deprecated in CUDA 12.7.

See also:

readGridId

readThreadIdx

readBlockIdx

readBrokenWarps

readValidWarps

readValidLanes

readActiveLanes

CUDBGResult (*CUDBGAPI_st::readCodeMemory) (uint32_t dev, uint64_t addr, void *buf, uint32_t sz)

Reads content at address in the code memory segment.

Parameters

dev
- device index

addr
- memory address

buf
- buffer

sz
- size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_MEMORY_MAPPING_FAILED

Since CUDA 3.0.

See also:

readConstMemory129

readGenericMemory

readParamMemory

readSharedMemory

readTextureMemory

readLocalMemory

readRegister

readPC

CUDBGResult (*CUDBGAPI_st::readConstMemory129) (uint32_t dev, uint64_t addr, void *buf, uint32_t sz)

Reads content at address in the constant memory segment.

Parameters

dev
- device index

addr
- memory address

buf
- buffer

sz
- size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_MEMORY_MAPPING_FAILED

Since CUDA 3.0.

> Note:
>
> Deprecated in CUDA 13.0.

See also:

readCodeMemory

readGenericMemory

readParamMemory

readSharedMemory

readTextureMemory

readLocalMemory

readRegister

readPC

CUDBGResult (*CUDBGAPI_st::readCPUCallStack) (uint32_t dev, uint64_t gridId64, uint64_t *addrs, uint32_t numAddrs, uint32_t *totalNumAddrs)

Read CPU call stack captured at the time of kernel launch.

Parameters

dev
- device index

gridId64
- 64-bit grid ID

addrs
- the returned addresses array, can be NULL

numAddrs
- capacity of addrs (possibly 0)

totalNumAddrs
- the actual size of the stack (number of frames) is written here; the value written can be greater than numAddrs

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_INTERNAL, CUDBG_ERROR_NOT_SUPPORTED

Since CUDA 12.9.

This method is only supported when the CUDBG_DEBUGGER_CAPABILITY_COLLECT_CPU_CALL_STACK_FOR_KERNEL_LAUNCHES capability has been enabled.

CUDBGResult (*CUDBGAPI_st::readErrorPC) (uint32_t devId, uint32_t sm, uint32_t wp, uint64_t *errorPC, bool *errorPCValid)

Get the hardware reported error PC if it exists.

Parameters

devId
- the device index

sm
- the SM index

wp

errorPC
- PC ofthe exception

errorPCValid
- boolean to indicate that the returned error PC is valid

Returns

CUDBG_SUCCESS CUDBG_ERROR_UNINITIALIZED CUDBG_ERROR_INVALID_DEVICE CUDBG_ERROR_INVALID_SM CUDBG_ERROR_INVALID_WARP CUDBG_ERROR_INVALID_ARGS CUDBG_ERROR_UNKNOWN_FUNCTION

Since CUDA 6.0

CUDBGResult (*CUDBGAPI_st::readGenericMemory) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint64_t addr, void *buf, uint32_t sz)

Reads content at an address in the generic address space. This function determines if the given address falls into the local, shared, or global memory window. It then accesses memory taking into account the hardware co-ordinates provided as inputs.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

addr
- memory address

buf
- buffer

sz

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_MEMORY_MAPPING_FAILED, CUDBG_ERROR_ADDRESS_NOT_IN_DEVICE_MEM

Since CUDA 6.0.

See also:

readCodeMemory

readConstMemory129

readParamMemory

readSharedMemory

readTextureMemory

readLocalMemory

readRegister

readPC

CUDBGResult (*CUDBGAPI_st::readGlobalMemory) (uint64_t addr, void *buf, uint32_t sz)

Reads content at an address in the global address space. If the address is valid on more than one device and one of those devices does not support UVA, an error is returned.

Parameters

addr

- memory address

buf

- buffer

sz

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_MEMORY_MAPPING_FAILED, CUDBG_ERROR_INVALID_MEMORY_ACCESS, CUDBG_ERROR_ADDRESS_NOT_IN_DEVICE_MEM CUDBG_ERROR_AMBIGUOUS_MEMORY_ADDRESS_

Since CUDA 6.0.

See also:

readCodeMemory

readConstMemory129

readParamMemory

readSharedMemory

readTextureMemory

readLocalMemory

readRegister

readPC

CUDBGResult (*CUDBGAPI_st::readGlobalMemory31) (uint32_t dev, uint64_t addr, void *buf, uint32_t sz)

Reads content at address in the global memory segment.

Parameters

dev
- device index

addr
- memory address

buf
- buffer

sz
- size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_MEMORY_MAPPING_FAILED

Since CUDA 3.0.

> Note:
>
> Deprecated in CUDA 3.2.

See also:

readCodeMemory

readConstMemory129

readParamMemory

readSharedMemory

readTextureMemory

readLocalMemory

readRegister

readPC

CUDBGResult (*CUDBGAPI_st::readGlobalMemory55) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint64_t addr, void *buf, uint32_t sz)

Reads content at address in the global memory segment (entire 40-bit VA on Fermi+).

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

addr
- memory address

buf
- buffer

sz
- size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_MEMORY_MAPPING_FAILED, CUDBG_ERROR_ADDRESS_NOT_IN_DEVICE_MEM

Since CUDA 3.2.

> Note:
>
> Deprecated in CUDA 6.0.

See also:

readCodeMemory

readConstMemory129

readParamMemory

readSharedMemory

readTextureMemory

readLocalMemory

readRegister

readPC

CUDBGResult (*CUDBGAPI_st::readGridId) (uint32_t dev, uint32_t sm, uint32_t wp, uint64_t *gridId64)

Reads the 64-bit CUDA grid index running on a valid warp.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

gridId64

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 5.5.

See also:

readBlockIdx

readThreadIdx

readBrokenWarps

readValidWarps

readValidLanes

readActiveLanes

CUDBGResult (*CUDBGAPI_st::readGridId50) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t *gridId)

Reads the CUDA grid index running on a valid warp.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

gridId
- the returned CUDA grid index

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

> Note:
>
> Deprecated in CUDA 5.5.

See also:

readBlockIdx

readThreadIdx

readBrokenWarps

readValidWarps

readValidLanes

readActiveLanes

CUDBGResult (*CUDBGAPI_st::readLaneException) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, CUDBGException_t *exception)

Reads the exception type for a given lane.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

exception
- the returned exception type

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.1.

CUDBGResult (*CUDBGAPI_st::readLaneStatus) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, bool *error)

Reads the status of the given lane. For specific error values, use readLaneException.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

error
- true if there is an error

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

CUDBGResult (*CUDBGAPI_st::readLocalMemory) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint64_t addr, void *buf, uint32_t sz)

Reads content at address in the local memory segment.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

addr
- memory address

buf
- buffer

sz
- size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_MEMORY_MAPPING_FAILED

Since CUDA 3.0.

See also:

readCodeMemory

readConstMemory129

readGenericMemory

readParamMemory

readSharedMemory

readTextureMemory

readRegister

readPC

CUDBGResult (*CUDBGAPI_st::readParamMemory) (uint32_t dev, uint32_t sm, uint32_t wp, uint64_t addr, void *buf, uint32_t sz)

Reads content at address in the param memory segment.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

addr
- memory address

buf
- buffer

sz
- size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_MEMORY_MAPPING_FAILED

Since CUDA 3.0.

See also:

readCodeMemory

readConstMemory129

readGenericMemory

readSharedMemory

readTextureMemory

readLocalMemory

readRegister

readPC

CUDBGResult (*CUDBGAPI_st::readPC) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint64_t *pc)

Reads the PC on the given active lane.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

pc
- the returned PC

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNKNOWN_FUNCTION, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

readCodeMemory

readConstMemory129

readGenericMemory

readParamMemory

readSharedMemory

readTextureMemory

readLocalMemory

readRegister

readVirtualPC

CUDBGResult (*CUDBGAPI_st::readPinnedMemory) (uint64_t addr, void *buf, uint32_t sz)

Reads content at pinned address in system memory.

Parameters

addr

- system memory address

buf

- buffer

sz

- size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_MEMORY_MAPPING_FAILED, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.2.

See also:

readCodeMemory

readConstMemory129

readGenericMemory

readParamMemory

readSharedMemory

readTextureMemory

readLocalMemory

readRegister

readPC

CUDBGResult (*CUDBGAPI_st::readPredicates) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint32_t predicates_size, uint32_t *predicates)

Reads content of hardware predicate registers.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

predicates_size
- number of predicate registers to read

predicates
- buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 6.5.

See also:

readCodeMemory

readConstMemory129

readGenericMemory

readGlobalMemory

readParamMemory

readSharedMemory

readTextureMemory

readLocalMemory

readRegister

readPC

CUDBGResult (*CUDBGAPI_st::readRegister) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint32_t regno, uint32_t *val)

Reads content of a hardware register.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

regno
- register index

val
- buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

readCodeMemory

readConstMemory129

readGenericMemory

readParamMemory

readSharedMemory

readTextureMemory

readLocalMemory

readPC

CUDBGResult (*CUDBGAPI_st::readRegisterRange) (uint32_t devId, uint32_t sm, uint32_t wp, uint32_t ln, uint32_t index, uint32_t registers_size, uint32_t *registers)

Reads content of a hardware range of hardware registers.

Parameters

devId

sm

- SM index

wp

- warp index

ln

- lane index

index

- index of the first register to read

registers_size

- number of registers to read

registers

- buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 6.0.

See also:

readCodeMemory

readConstMemory129

readGenericMemory

readParamMemory

readSharedMemory

readTextureMemory

readLocalMemory

readPC

readRegister

CUDBGResult (*CUDBGAPI_st::readReturnAddress) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint32_t level, uint64_t *ra)

Reads the physical return address for a call level.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

level
- the specified call level

ra
- the returned return address for level

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_INVALID_CALL_LEVEL, CUDBG_ERROR_ZERO_CALL_DEPTH, CUDBG_ERROR_UNKNOWN_FUNCTION, CUDBG_ERROR_UNINITIALIZED

Since CUDA 4.0.

See also:

readCallDepth

readVirtualReturnAddress

CUDBGResult (*CUDBGAPI_st::readReturnAddress32) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t level, uint64_t *ra)

Reads the physical return address for a call level.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

level
- the specified call level

ra
- the returned return address for level

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_INVALID_CALL_LEVEL, CUDBG_ERROR_ZERO_CALL_DEPTH, CUDBG_ERROR_UNKNOWN_FUNCTION, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.1.

> Note:
>
> Deprecated in CUDA 4.0.

See also:

readCallDepth32

readVirtualReturnAddress32

CUDBGResult (*CUDBGAPI_st::readSharedMemory) (uint32_t dev, uint32_t sm, uint32_t wp, uint64_t addr, void *buf, uint32_t sz)

Reads content at address in the shared memory segment.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

addr
- memory address

buf
- buffer

sz
- size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_MEMORY_MAPPING_FAILED

Since CUDA 3.0.

See also:

readCodeMemory

readConstMemory129

readGenericMemory

readParamMemory

readLocalMemory

readTextureMemory

readRegister

readPC

CUDBGResult (*CUDBGAPI_st::readSmException) (uint32_t dev, uint32_t sm, CUDBGException_t *exception, uint64_t *errorPC, bool *errorPCValid)

Get the SM exception status if it exists.

Parameters

dev
- the device index

sm
- the SM index

exception
- returned exception

errorPC
- returned PC of the exception

errorPCValid
- boolean to indicate that the returned error PC is valid

Returns

CUDBG_SUCCESS CUDBG_ERROR_UNINITIALIZED CUDBG_ERROR_INVALID_DEVICE CUDBG_ERROR_INVALID_SM CUDBG_ERROR_INVALID_ARGS CUDBG_ERROR_UNKNOWN_FUNCTION

Since CUDA 12.5.

CUDBGResult (*CUDBGAPI_st::readSyscallCallDepth) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint32_t *depth)

Reads the call depth of syscalls for a given lane.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

depth
- the returned call depth

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_UNINITIALIZED

Since CUDA 4.1.

See also:

readReturnAddress

readVirtualReturnAddress

CUDBGResult (*CUDBGAPI_st::readTextureMemory) (uint32_t devId, uint32_t vsm, uint32_t wp, uint32_t id, uint32_t dim, uint32_t *coords, void *buf, uint32_t sz)

This method is no longer supported since CUDA 12.0.

Parameters

devId
- device index

vsm
- SM index

wp
- warp index

id
- texture id (the value of DW_AT_location attribute in the relocated ELF image)

dim
- texture dimension (1 to 4)

coords
- array of coordinates of size dim

buf
- result buffer

sz
- size of the buffer

Returns

CUDBG_ERROR_NOT_SUPPORTED,

See also:

readCodeMemory

readConstMemory129

readGenericMemory

readParamMemory

readSharedMemory

readLocalMemory

readRegister

readPC

CUDBGResult (*CUDBGAPI_st::readTextureMemoryBindless) (uint32_t devId, uint32_t vsm, uint32_t wp, uint32_t texSymtabIndex, uint32_t dim, uint32_t *coords, void *buf, uint32_t sz)

This method is no longer supported since CUDA 12.0.

Parameters

devId
- device index

vsm
- SM index

wp
- warp index

texSymtabIndex
- global symbol table index of the texture symbol

dim
- texture dimension (1 to 4)

coords
- array of coordinates of size dim

buf
- result buffer

sz
- size of the buffer

Returns

CUDBG_ERROR_NOT_SUPPORTED

See also:

readCodeMemory

readConstMemory129

readGenericMemory

readParamMemory

readSharedMemory

readLocalMemory

readRegister

readPC

CUDBGResult (*CUDBGAPI_st::readThreadIdx) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, CuDim3 *threadIdx)

Reads the CUDA thread index running on valid lane.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

threadIdx
- the returned CUDA thread index

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

readGridId

readBlockIdx

readBrokenWarps

readValidWarps

readValidLanes

readActiveLanes

CUDBGResult (*CUDBGAPI_st::readUniformPredicates) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t predicates_size, uint32_t *predicates)

Reads contents of uniform predicate registers.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

predicates_size
- number of predicate registers to read

predicates
- buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 10.0.

See also:

readPredicates

CUDBGResult (*CUDBGAPI_st::readUniformRegisterRange) (uint32_t devId, uint32_t sm, uint32_t wp, uint32_t regno, uint32_t registers_size, uint32_t *registers)

Reads a range of uniform registers.

Parameters

devId

sm
- SM index

wp
- warp index

regno
- starting index into uniform register file

registers_size
- number of bytes to read

registers
- pointer to buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 10.0.

See also:

readRegister

CUDBGResult (*CUDBGAPI_st::readValidLanes) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t *validLanesMask)

Reads the bitmask of valid lanes on a given warp.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

validLanesMask
- the returned bitmask of valid lanes

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

readGridId

readBlockIdx

readThreadIdx

readBrokenWarps

readValidWarps

readActiveLanes

CUDBGResult (*CUDBGAPI_st::readValidWarps)(uint32_t dev, uint32_t sm, uint64_t *validWarpsMask)

Reads the bitmask of valid warps on a given SM.

Parameters

dev
- device index

sm
- SM index

validWarpsMask
- the returned bitmask of valid warps

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

readGridId

readBlockIdx

readThreadIdx

readBrokenWarps

readValidLanes

readActiveLanes

CUDBGResult (*CUDBGAPI_st::readVirtualPC) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint64_t *pc)

Reads the virtual PC on the given active lane.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

pc
- the returned PC

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_UNKNOWN_FUNCTION

Since CUDA 3.0.

See also:

readPC

CUDBGResult (*CUDBGAPI_st::readVirtualReturnAddress) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint32_t level, uint64_t *ra)

Reads the virtual return address for a call level.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

level
- the specified call level

ra
- the returned virtual return address for level

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_INVALID_CALL_LEVEL, CUDBG_ERROR_ZERO_CALL_DEPTH, CUDBG_ERROR_UNKNOWN_FUNCTION, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_INTERNAL

Since CUDA 4.0.

See also:

readCallDepth

readReturnAddress

CUDBGResult (*CUDBGAPI_st::readVirtualReturnAddress32) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t level, uint64_t *ra)

Reads the virtual return address for a call level.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

level
- the specified call level

ra
- the returned virtual return address for level

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_INVALID_CALL_LEVEL, CUDBG_ERROR_ZERO_CALL_DEPTH, CUDBG_ERROR_UNKNOWN_FUNCTION, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_INTERNAL

Since CUDA 3.1.

> Note:
>
> Deprecated in CUDA 4.0.

See also:

readCallDepth32

readReturnAddress32

CUDBGResult (*CUDBGAPI_st::readWarpResources) (uint32_t dev, uint32_t sm, uint32_t wp, CUDBGWarpResources *resources)

Get the resources assigned to a given warp.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

resources
- pointer to structure that contains warp resources

Returns

CUDBG_ERROR_NOT_SUPPORTED,

Since CUDA 12.8.

CUDBGResult (*CUDBGAPI_st::readWarpState) (uint32_t dev, uint32_t sm, uint32_t wp, CUDBGWarpState *state)

Get state of a given warp.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

state
- pointer to structure that contains warp state

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED,

Since CUDA 12.9.

CUDBGResult (*CUDBGAPI_st::readWarpState120) (uint32_t dev, uint32_t sm, uint32_t wp, CUDBGWarpState120 *state)

Get state of a given warp.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

state
- pointer to structure that contains warp status

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED,

Since CUDA 12.0.

> Note:
>
> Deprecated in CUDA 12.7.

CUDBGResult (*CUDBGAPI_st::readWarpState127) (uint32_t dev, uint32_t sm, uint32_t wp, CUDBGWarpState127 *state)

Get state of a given warp.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

state
- pointer to structure that contains warp status

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED,

Since CUDA 12.7.

> Note:
>
> Deprecated in CUDA 12.9.

CUDBGResult (*CUDBGAPI_st::readWarpState60) (uint32_t devId, uint32_t sm, uint32_t wp, CUDBGWarpState60 *state)

Get state of a given warp.

Parameters

devId

sm
- SM index

wp
- warp index

state
- pointer to structure that contains warp status

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED,

Since CUDA 6.0.

> Note:
>
> Deprecated in CUDA 12.0.

CUDBGResult (*CUDBGAPI_st::writePinnedMemory) (uint64_t addr, const void *buf, uint32_t sz)

Writes content to pinned address in system memory.

Parameters

addr
- system memory address

buf
- buffer

sz
- size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_MEMORY_MAPPING_FAILED, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.2.

See also:

readCodeMemory

readConstMemory129

readGenericMemory

readParamMemory

readSharedMemory

readLocalMemory

readRegister

readPC

CUDBGResult (*CUDBGAPI_st::writePredicates) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint32_t predicates_size, const uint32_t *predicates)

Writes content to hardware predicate registers.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

predicates_size
- number of predicate registers to write

predicates
- buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 6.5.

See also:

writeConstMemory

writeGenericMemory

writeGlobalMemory

writeParamMemory

writeSharedMemory

writeTextureMemory

writeLocalMemory

writeRegister

CUDBGResult (*CUDBGAPI_st::writeUniformPredicates) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t predicates_size, const uint32_t *predicates)

Writes to uniform predicate registers.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

predicates_size
- number of predicate registers to write

predicates
- buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 10.0.

See also:

readUniformPredicate

writeRegister

3.6. Device State Alteration

CUDBGResult (*CUDBGAPI_st::writeCCRegister) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint32_t val)

Writes the hardware CC register.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

val
- value to write to the CC register

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 6.5.

See also:

writeConstMemory

writeGenericMemory

writeGlobalMemory

writeParamMemory

writeSharedMemory

writeTextureMemory

writeLocalMemory

writeRegister

writePredicates

CUDBGResult (*CUDBGAPI_st::writeGenericMemory) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint64_t addr, const void *buf, uint32_t sz)

Writes content to an address in the generic address space. This function determines if the given address falls into the local, shared, or global memory window. It then accesses memory taking into account the hardware co-ordinates provided as inputs.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

addr
- memory address

buf
- buffer

sz

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_MEMORY_MAPPING_FAILED, CUDBG_ERROR_ADDRESS_NOT_IN_DEVICE_MEM

Since CUDA 6.0.

See also:

writeParamMemory

writeSharedMemory

writeLocalMemory

writeRegister

CUDBGResult (*CUDBGAPI_st::writeGlobalMemory) (uint64_t addr, const void *buf, uint32_t sz)

Writes content to an address in the global address space. If the address is valid on more than one device and one of those devices does not support UVA, an error is returned.

Parameters

addr
- memory address

buf
- buffer

sz

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_MEMORY_MAPPING_FAILED, CUDBG_ERROR_INVALID_MEMORY_ACCESS, CUDBG_ERROR_ADDRESS_NOT_IN_DEVICE_MEM CUDBG_ERROR_AMBIGUOUS_MEMORY_ADDRESS_

Since CUDA 6.0.

See also:

writeParamMemory

writeSharedMemory

writeLocalMemory

writeRegister

CUDBGResult (*CUDBGAPI_st::writeGlobalMemory31) (uint32_t dev, uint64_t addr, const void *buf, uint32_t sz)

Writes content to address in the global memory segment.

Parameters

dev
- device index

addr
- memory address

buf
- buffer

sz
- size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_MEMORY_MAPPING_FAILED

Since CUDA 3.0.

> Note:
>
> Deprecated in CUDA 3.2.

See also:

writeParamMemory

writeSharedMemory

writeLocalMemory

writeRegister

CUDBGResult (*CUDBGAPI_st::writeGlobalMemory55) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint64_t addr, const void *buf, uint32_t sz)

Writes content to address in the global memory segment (entire 40-bit VA on Fermi+).

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

addr
- memory address

buf
- buffer

sz
- size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_MEMORY_MAPPING_FAILED, CUDBG_ERROR_ADDRESS_NOT_IN_DEVICE_MEM

Since CUDA 3.2.

> Note:
>
> Deprecated in CUDA 6.0.

See also:

writeParamMemory

writeSharedMemory

writeLocalMemory

writeRegister

CUDBGResult (*CUDBGAPI_st::writeLocalMemory) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint64_t addr, const void *buf, uint32_t sz)

Writes content to address in the local memory segment.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

addr
- memory address

buf
- buffer

sz
- size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_MEMORY_MAPPING_FAILED

Since CUDA 3.0.

See also:

writeGenericMemory

writeParamMemory

writeSharedMemory

writeRegister

CUDBGResult (*CUDBGAPI_st::writeParamMemory)(uint32_t dev, uint32_t sm, uint32_t wp, uint64_t addr, const void *buf, uint32_t sz)

Writes content to address in the param memory segment.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

addr
- memory address

buf
- buffer

sz
- size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_MEMORY_MAPPING_FAILED

Since CUDA 3.0.

See also:

writeGenericMemory

writeSharedMemory

writeLocalMemory

writeRegister

CUDBGResult (*CUDBGAPI_st::writeRegister) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint32_t regno, uint32_t val)

Writes content to a hardware register.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

regno
- register index

val
- buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

writeGenericMemory

writeParamMemory

writeSharedMemory

writeLocalMemory

CUDBGResult (*CUDBGAPI_st::writeSharedMemory) (uint32_t dev, uint32_t sm, uint32_t wp, uint64_t addr, const void *buf, uint32_t sz)

Writes content to address in the shared memory segment.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

addr
- memory address

buf
- buffer

sz
- size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_MEMORY_MAPPING_FAILED

Since CUDA 3.0.

See also:

writeGenericMemory

writeParamMemory

writeLocalMemory

writeRegister

CUDBGResult (*CUDBGAPI_st::writeUniformRegister) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t regno, uint32_t val)

Writes content to a uniform register.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

regno
- register index

val
- buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 10.0.

See also:

writeRegister

readUniformRegisterRange

3.7. Grid Properties

struct CUDBGGridInfo

Grid info.

enum CUDBGGridStatus

Grid status.

Values

CUDBG_GRID_STATUS_INVALID
An invalid grid ID was passed, or an error occurred during status lookup.

CUDBG_GRID_STATUS_PENDING
The grid was launched but is not running on the HW yet.

CUDBG_GRID_STATUS_ACTIVE
The grid is currently running on the HW.

CUDBG_GRID_STATUS_SLEEPING
The grid is on the device, doing a join.

CUDBG_GRID_STATUS_TERMINATED
The grid has finished executing.

CUDBG_GRID_STATUS_UNDETERMINED
The grid is either QUEUED or TERMINATED.

CUDBGResult (*CUDBGAPI_st::getBlockDim) (uint32_t dev, uint32_t sm, uint32_t wp, CuDim3 *blockDim)

Get the number of threads in the given block.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

blockDim
- the returned number of threads in the block

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

getGridDim

CUDBGResult (*CUDBGAPI_st::getClusterDim) (uint32_t dev, uint32_t sm, uint32_t wp, CuDim3 *clusterDim)

Get the number of blocks in the given cluster.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

clusterDim
- the returned number of blocks in the cluster

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_UNINITIALIZED

Since CUDA 12.7.

See also:

getBlockDim

getGridDim

CUDBGResult (*CUDBGAPI_st::getClusterDim120) (uint32_t dev, uint64_t gridId64, CuDim3 *clusterDim)

Get the number of blocks in the given cluster.

Parameters

dev
- device index

gridId64
- grid ID

clusterDim
- the returned number of blocks in the cluster

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_UNINITIALIZED

Since CUDA 12.0.

> Note:
>
> Deprecated in CUDA 12.7.

See also:

getBlockDim

getGridDim

CUDBGResult (*CUDBGAPI_st::getElfImage) (uint32_t dev, uint32_t sm, uint32_t wp, bool relocated, void **elfImage, uint64_t *size)

Get the relocated or non-relocated ELF image and size for the grid on the given device.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

relocated
- set to true to specify the relocated ELF image, false otherwise

***elfImage**
- pointer to the ELF image

size
- size of the ELF image (64 bits)

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_UNINITIALIZED

Since CUDA 4.0.

CUDBGResult (*CUDBGAPI_st::getElfImage32) (uint32_t dev, uint32_t sm, uint32_t wp, bool relocated, void **elfImage, uint32_t *size)

Get the relocated or non-relocated ELF image and size for the grid on the given device.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

relocated
- set to true to specify the relocated ELF image, false otherwise

***elfImage**
- pointer to the ELF image

size
- size of the ELF image (32 bits)

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

> Note:
>
> Deprecated in CUDA 4.0.

CUDBGResult (*CUDBGAPI_st::getGridAttribute) (uint32_t dev, uint32_t sm, uint32_t wp, CUDBGAttribute attr, uint64_t *value)

Get the value of a grid attribute.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

attr
- the attribute

value
- the returned value of the attribute

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_INVALID_ATTRIBUTE, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.1.

CUDBGResult (*CUDBGAPI_st::getGridAttributes) (uint32_t dev, uint32_t sm, uint32_t wp, CUDBGAttributeValuePair *pairs, uint32_t numPairs)

Get several grid attribute values in a single API call.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

pairs
- array of attribute/value pairs

numPairs
- the number of attribute/values pairs in the array

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_INVALID_ATTRIBUTE, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.1.

CUDBGResult (*CUDBGAPI_st::getGridDim) (uint32_t dev, uint32_t sm, uint32_t wp, CuDim3 *gridDim)

Get the number of blocks in the given grid.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

gridDim
- the returned number of blocks in the grid

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_UNINITIALIZED

Since CUDA 4.0.

See also:

getBlockDim

CUDBGResult (*CUDBGAPI_st::getGridDim32) (uint32_t dev, uint32_t sm, uint32_t wp, CuDim2 *gridDim)

Get the number of blocks in the given grid.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

gridDim
- the returned number of blocks in the grid

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

> Note:
>
> Deprecated in CUDA 4.0.

See also:

getBlockDim

CUDBGResult (*CUDBGAPI_st::getGridInfo) (uint32_t dev, uint64_t gridId64, CUDBGGridInfo *gridInfo)

Get information about the specified grid. If the context of the grid has already been destroyed, the function will return CUDBG_ERROR_INVALID_GRID, although the grid id is correct.

Parameters

dev
gridId64
gridInfo
- pointer to a client allocated structure in which grid info will be returned.

Returns

CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_GRID, CUDBG_SUCCESS

Since CUDA 12.7.

CUDBGResult (*CUDBGAPI_st::getGridInfo120) (uint32_t dev, uint64_t gridId64, CUDBGGridInfo120 *gridInfo)

Get information about the specified grid. If the context of the grid has already been destroyed, the function will return CUDBG_ERROR_INVALID_GRID, although the grid id is correct.

Parameters

dev
gridId64
gridInfo
- pointer to a client allocated structure in which grid info will be returned.

Returns

CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_GRID, CUDBG_SUCCESS

Since CUDA 12.0.

> Note:
>
> Deprecated in CUDA 12.3.

CUDBGResult (*CUDBGAPI_st::getGridInfo55) (uint32_t dev, uint64_t gridId64, CUDBGGridInfo55 *gridInfo)

Get information about the specified grid. If the context of the grid has already been destroyed, the function will return CUDBG_ERROR_INVALID_GRID, although the grid id is correct.

Parameters

dev
gridId64
gridInfo
- pointer to a client allocated structure in which grid info will be returned.

Returns

CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_GRID, CUDBG_SUCCESS

Since CUDA 5.5.

> Note:
>
> Deprecated in CUDA 12.0.

CUDBGResult (*CUDBGAPI_st::getGridStatus) (uint32_t dev, uint64_t gridId64, CUDBGGridStatus *status)

Check whether the grid corresponding to the given gridId is still present on the device.

Parameters

dev

gridId64

- 64-bit grid ID

status

- enum indicating whether the grid status is INVALID, PENDING, ACTIVE, SLEEPING, TERMINATED or UNDETERMINED

Returns

CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_INTERNAL

Since CUDA 5.5.

CUDBGResult (*CUDBGAPI_st::getGridStatus50) (uint32_t dev, uint32_t gridId, CUDBGGridStatus *status)

Check whether the grid corresponding to the given gridId is still present on the device.

Parameters

dev

gridId

- grid ID

status

- enum indicating whether the grid status is INVALID, PENDING, ACTIVE, SLEEPING, TERMINATED or UNDETERMINED

Returns

CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_INTERNAL

Since CUDA 5.0.

> Note:
>
> Deprecated in CUDA 5.5.

CUDBGResult (*CUDBGAPI_st::getTID) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t *tid)

Get the ID of the Linux thread hosting the context of the grid.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

tid
- the returned thread id

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

3.8. Device Properties

CUDBGResult (*CUDBGAPI_st::getDeviceName) (uint32_t dev, char *buf, uint32_t sz)

Get the device name string.

Parameters

dev
- device index

buf
- the destination buffer

sz
- the size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_BUFFER_TOO_SMALL, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNINITIALIZED

Since CUDA 6.5.

See also:

getSMType

getDeviceType

CUDBGResult (*CUDBGAPI_st::getDeviceType) (uint32_t dev, char *buf, uint32_t sz)

Get the string description of the device.

Parameters

dev
- device index

buf
- the destination buffer

sz
- the size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_BUFFER_TOO_SMALL, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

getSMType

CUDBGResult (*CUDBGAPI_st::getNumDevices) (uint32_t *numDev)

Get the number of installed CUDA devices.

Parameters

numDev
- the returned number of devices

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

getNumSMs

getNumWarps

getNumLanes

getNumRegisters

CUDBGResult (*CUDBGAPI_st::getNumLanes) (uint32_t dev, uint32_t *numLanes)

Get the number of lanes per warp on the device.

Parameters

dev
- device index

numLanes
- the returned number of lanes

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

getNumDevices

getNumSMs

getNumWarps

getNumRegisters

CUDBGResult (*CUDBGAPI_st::getNumPredicates) (uint32_t dev, uint32_t *numPredicates)

Get the number of predicate registers per lane on the device.

Parameters

dev
- device index

numPredicates
- the returned number of predicate registers

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNINITIALIZED

Since CUDA 6.5.

See also:

getNumDevices

getNumSMs

getNumWarps

getNumLanes

getNumRegisters

CUDBGResult (*CUDBGAPI_st::getNumRegisters) (uint32_t dev, uint32_t *numRegs)

Get the number of registers per lane on the device.

Parameters

dev
- device index

numRegs
- the returned number of registers

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

getNumDevices

getNumSMs

getNumWarps

getNumLanes

CUDBGResult (*CUDBGAPI_st::getNumSMs) (uint32_t dev, uint32_t *numSMs)

Get the total number of SMs on the device.

Parameters

dev
- device index

numSMs
- the returned number of SMs

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

getNumDevices

getNumWarps

getNumLanes

getNumRegisters

CUDBGResult (*CUDBGAPI_st::getNumUniformPredicates) (uint32_t dev, uint32_t *numPredicates)

Get the number of uniform predicate registers per warp on the device.

Parameters

dev
- device index

numPredicates
- the returned number of uniform predicate registers

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNINITIALIZED

Since CUDA 10.0.

See also:

getNumUniformPredicates

CUDBGResult (*CUDBGAPI_st::getNumUniformRegisters) (uint32_t dev, uint32_t *numRegs)

Get the number of uniform registers per warp on the device.

Parameters

dev
- device index

numRegs
- the returned number of uniform registers

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNINITIALIZED

Since CUDA 10.0.

See also:

getNumRegisters

CUDBGResult (*CUDBGAPI_st::getNumWarps) (uint32_t dev, uint32_t *numWarps)

Get the number of warps per SM on the device.

Parameters

dev
- device index

numWarps
- the returned number of warps

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

getNumDevices

getNumSMs

getNumLanes

getNumRegisters

CUDBGResult (*CUDBGAPI_st::getSmType) (uint32_t dev, char *buf, uint32_t sz)

Get the SM type of the device.

Parameters

dev
- device index

buf
- the destination buffer

sz
- the size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_BUFFER_TOO_SMALL, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

getDeviceType

3.9. DWARF Utilities

CUDBGResult (*CUDBGAPI_st::disassemble) (uint32_t dev, uint64_t addr, uint32_t *instSize, char *buf, uint32_t sz)

Disassemble instruction at instruction address.

Parameters

dev
- device index

addr
- instruction address

instSize
- instruction size (32 or 64 bits)

buf
- disassembled instruction buffer

sz
- disassembled instruction buffer size

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNKNOWN

Since CUDA 3.0.

CUDBGResult (*CUDBGAPI_st::getElfImageByHandle) (uint32_t devId, uint64_t handle, CUDBGElfImageType type, void *elfImage, uint64_t size)

Get the relocated or non-relocated ELF image for the given handle on the given device.

Parameters

devId
- device index

handle
- elf image handle

type
- type of the requested ELF image

elfImage
- pointer to the ELF image

size

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNINITIALIZED

The handle is provided in the ELF Image Loaded notification event.

Since CUDA 6.0.

CUDBGResult (*CUDBGAPI_st::getHostAddrFromDeviceAddr) (uint32_t dev, uint64_t device_addr, uint64_t *host_addr)

given a device virtual address, return a corresponding system memory virtual address.

Parameters

dev
- device index

device_addr
- device memory address

host_addr
- returned system memory address

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_CONTEXT, CUDBG_ERROR_INVALID_MEMORY_SEGMENT

Since CUDA 4.1.

See also:

readGenericMemory

writeGenericMemory

CUDBGResult (*CUDBGAPI_st::getPhysicalRegister30) (uint64_t pc, char *reg, uint32_t *buf, uint32_t sz, uint32_t *numPhysRegs, CUDBGRegClass *regClass)

Get the physical register number(s) assigned to a virtual register name 'reg' at a given PC, if 'reg' is live at that PC.

Parameters

pc
- Program counter

reg
- virtual register index

buf
- physical register name(s)

sz
- the physical register name buffer size

numPhysRegs
- number of physical register names returned

regClass
- the class of the physical registers

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_UKNOWN_FUNCTION, CUDBG_ERROR_UNKNOWN

Since CUDA 3.0.

> Note:
>
> Deprecated in CUDA 3.1.

CUDBGResult (*CUDBGAPI_st::getPhysicalRegister40) (uint32_t dev, uint32_t sm, uint32_t wp, uint64_t pc, char *reg, uint32_t *buf, uint32_t sz, uint32_t *numPhysRegs, CUDBGRegClass *regClass)

Get the physical register number(s) assigned to a virtual register name 'reg' at a given PC, if 'reg' is live at that PC.

Parameters

dev
- device index

sm
- SM index

wp
- warp indx

pc
- Program counter

reg
- virtual register index

buf
- physical register name(s)

sz
- the physical register name buffer size

numPhysRegs
- number of physical register names returned

regClass
- the class of the physical registers

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_UKNOWN_FUNCTION, CUDBG_ERROR_UNKNOWN

Get the physical register number(s) assigned to a virtual register name 'reg' at a given PC, if 'reg' is live at that PC. If a virtual register name is mapped to more than one physical register, the physical register with the lowest physical register index will contain the highest bits of the virtual register, and the physical register with the highest physical register index will contain the lowest bits.

Since CUDA 3.1.

> Note:
>
> Deprecated in CUDA 4.1.

CUDBGResult (*CUDBGAPI_st::isDeviceCodeAddress) (uintptr_t addr, bool *isDeviceAddress)

Determines whether a virtual address resides within device code.

Parameters

addr
- virtual address

isDeviceAddress
- true if address resides within device code

Returns

CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_UNINITIALIZED, CUDBG_SUCCESS

Since CUDA 3.0.

CUDBGResult (*CUDBGAPI_st::isDeviceCodeAddress55) (uintptr_t addr, bool *isDeviceAddress)

Determines whether a virtual address resides within device code. This API is strongly deprecated. Use CUDBGAPI_st::isDeviceCodeAddress instead.

Parameters

addr
- virtual address

isDeviceAddress
- true if address resides within device code

Returns

CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_UNINITIALIZED, CUDBG_SUCCESS

Since CUDA 3.0.

> Note:
>
> Deprecated in CUDA 6.0

CUDBGResult (*CUDBGAPI_st::lookupDeviceCodeSymbol) (char *symName, bool *symFound, uintptr_t *symAddr)

Determines whether a symbol represents a function in device code and returns its virtual address.

Parameters

symName
- symbol name

symFound
- set to true if the symbol is found

symAddr
- the symbol virtual address if found

Returns

CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_UNINITIALIZED, CUDBG_SUCCESS

Since CUDA 3.0.

3.10. Events

One of those events will create a CUDBGEvent:

- the elf image of the current kernel has been loaded and the addresses within its DWARF sections have been relocated (and can now be used to set breakpoints),
- a device breakpoint has been hit,
- a CUDA kernel is ready to be launched,
- a CUDA kernel has terminated.

When a CUDBGEvent is created, the debugger is notified by calling the callback functions registered with setNotifyNewEventCallback() after the API struct initialization. It is up to the debugger to decide what method is best to be notified. The debugger API routines cannot be called from within the callback function or the routine will return an error.

Upon notification the debugger is responsible for handling the CUDBGEvents in the event queue by using CUDBGAPI_st::getNextEvent(), and for acknowledging the debugger API that the event has been handled by calling CUDBGAPI_st::acknowledgeEvent(). In the case of an event raised by the device itself, such as a breakpoint being hit, the event queue will be empty. It is the responsibility of the debugger to inspect the hardware any time a CUDBGEvent is received.

Example:

```
CUDBGEvent event;
```

```
CUDBGResult res;
for (res = cudbgAPI->getNextEvent(&event);
     res == CUDBG_SUCCESS && event.kind != CUDBG_EVENT_INVALID;
     res = cudbgAPI->getNextEvent(&event)) {
    switch (event.kind)
        {
        case CUDBG_EVENT_ELF_IMAGE_LOADED:
            //...
            break;
        case CUDBG_EVENT_KERNEL_READY:
            //...
            break;
        case CUDBG_EVENT_KERNEL_FINISHED:
            //...
            break;
        default:
            error(...);
        }
    }
```

See cuda-tdep.c and cuda-linux-nat.c files in the cuda-gdb source code for a more detailed example on how to use CUDBGEvent.

struct CUDBGEvent

Event information container.

struct CUDBGEventCallbackData

Event information passed to callback set with setNotifyNewEventCallback function.

struct CUDBGEventCallbackData40

Event information passed to callback set with setNotifyNewEventCallback function.

enum CUDBGEventKind

CUDA Kernel Events.

Values

CUDBG_EVENT_INVALID = 0x000

Invalid event.

CUDBG_EVENT_ELF_IMAGE_LOADED = 0x001

The ELF image for a CUDA source module is available.

CUDBG_EVENT_KERNEL_READY = 0x002

A CUDA kernel is about to be launched.

CUDBG_EVENT_KERNEL_FINISHED = 0x003

A CUDA kernel has terminated.

CUDBG_EVENT_INTERNAL_ERROR = 0x004

An internal error occur. The debugging framework may be unstable.

CUDBG_EVENT_CTX_PUSH = 0x005

A CUDA context was pushed.

CUDBG_EVENT_CTX_POP = 0x006
A CUDA CTX was popped.
CUDBG_EVENT_CTX_CREATE = 0x007
A CUDA CTX was created.
CUDBG_EVENT_CTX_DESTROY = 0x008
A CUDA context was destroyed.
CUDBG_EVENT_TIMEOUT = 0x009
An timeout event is sent at regular interval. This event can safely ge ignored.
CUDBG_EVENT_ATTACH_COMPLETE = 0x00a
The attach process has completed and debugging of device code may start.
CUDBG_EVENT_DETACH_COMPLETE = 0x00b
CUDBG_EVENT_ELF_IMAGE_UNLOADED = 0x00c
CUDBG_EVENT_FUNCTIONS_LOADED = 0x00d
CUDBG_EVENT_ALL_DEVICES_SUSPENDED = 0x00e
CUDBG_EVENT_CUDA_LOGS_AVAILABLE = 0x00f
CUDBG_EVENT_CUDA_LOGS_THRESHOLD_REACHED = 0x010

typedef (*CUDBGNotifyNewEventCallback) (CUDBGEventCallbackData* data)

function type of the function called to notify debugger of the presence of a new event in the event queue.

typedef (*CUDBGNotifyNewEventCallback31) (void* data)

function type of the function called to notify debugger of the presence of a new event in the event queue.

> Note:
>
> Deprecated in CUDA 3.2.

CUDBGResult (*CUDBGAPI_st::acknowledgeEvent30) (CUDBGEvent30 *event)

Inform the debugger API that the event has been processed.

Parameters

event
- pointer to the event that has been processed

Returns

CUDBG_SUCCESS

Since CUDA 3.0.

> Note:
>
> Deprecated in CUDA 3.1.

CUDBGResult (*CUDBGAPI_st::acknowledgeEvents42) ()

Inform the debugger API that synchronous events have been processed.

Returns

CUDBG_SUCCESS

Since CUDA 3.1.

> Note:
>
> Deprecated in CUDA 5.0.

CUDBGResult (*CUDBGAPI_st::acknowledgeSyncEvents) ()

Inform the debugger API that synchronous events have been processed.

Returns

CUDBG_SUCCESS

Since CUDA 5.0.

CUDBGResult (*CUDBGAPI_st::getErrorStringEx) (char *buf, uint32_t bufSz, uint32_t *msgSz)

Fills a user-provided buffer with an error message encoded as a null-terminated ASCII string. The error message is specific to the last failed API call and is invalidated after every API call.

Parameters

buf

- the destination buffer

bufSz
- the size of the destination buffer in bytes

msgSz
- the size of an error message including the terminating null character.

Returns

CUDBG_SUCCESS, CUDBG_ERROR_BUFFER_TOO_SMALL
CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_UNINITIALIZED

Since CUDA 12.2.

See also:

getErrorString

CUDBGResult (*CUDBGAPI_st::getNextAsyncEvent50) (CUDBGEvent50 *event)

Copies the next available event in the asynchronous event queue into 'event' and removes it from the queue. The asynchronous event queue is held separate from the normal event queue, and does not require acknowledgement from the debug client.

Parameters

event
- pointer to an event container where to copy the event parameters

Returns

CUDBG_SUCCESS, CUDBG_ERROR_NO_EVENT_AVAILABLE,
CUDBG_ERROR_INVALID_ARGS

Since CUDA 5.0.

> Note:
>
> Deprecated in CUDA 5.5.

CUDBGResult (*CUDBGAPI_st::getNextAsyncEvent55) (CUDBGEvent55 *event)

Copies the next available event in the asynchronous event queue into 'event' and removes it from the queue. The asynchronous event queue is held separate from the normal event queue, and does not require acknowledgement from the debug client.

Parameters

event

- pointer to an event container where to copy the event parameters

Returns

CUDBG_SUCCESS, CUDBG_ERROR_NO_EVENT_AVAILABLE, CUDBG_ERROR_INVALID_ARGS

Since CUDA 5.5.

> Note:
>
> Deprecated in CUDA 6.0.

CUDBGResult (*CUDBGAPI_st::getNextEvent) (CUDBGEventQueueType type, CUDBGEvent *event)

Copies the next available event into 'event' and removes it from the queue.

Parameters

type

- application event queue type

event

- pointer to an event container where to copy the event parameters

Returns

CUDBG_SUCCESS, CUDBG_ERROR_NO_EVENT_AVAILABLE, CUDBG_ERROR_INVALID_ARGS

Since CUDA 6.0.

CUDBGResult (*CUDBGAPI_st::getNextEvent30) (CUDBGEvent30 *event)

Copies the next available event in the event queue into 'event' and removes it from the queue.

Parameters

event

- pointer to an event container where to copy the event parameters

Returns

CUDBG_SUCCESS, CUDBG_ERROR_NO_EVENT_AVAILABLE, CUDBG_ERROR_INVALID_ARGS

Since CUDA 3.0.

> Note:
>
> Deprecated in CUDA 3.1.

CUDBGResult (*CUDBGAPI_st::getNextEvent32) (CUDBGEvent32 *event)

Copies the next available event in the event queue into 'event' and removes it from the queue.

Parameters

event

- pointer to an event container where to copy the event parameters

Returns

CUDBG_SUCCESS, CUDBG_ERROR_NO_EVENT_AVAILABLE, CUDBG_ERROR_INVALID_ARGS

Since CUDA 3.1.

> Note:
>
> Deprecated in CUDA 4.0

CUDBGResult (*CUDBGAPI_st::getNextEvent42) (CUDBGEvent42 *event)

Copies the next available event in the event queue into 'event' and removes it from the queue.

Parameters

event

- pointer to an event container where to copy the event parameters

Returns

CUDBG_SUCCESS, CUDBG_ERROR_NO_EVENT_AVAILABLE, CUDBG_ERROR_INVALID_ARGS

Since CUDA 4.0.

> Note:
>
> Deprecated in CUDA 5.0

CUDBGResult (*CUDBGAPI_st::getNextSyncEvent50) (CUDBGEvent50 *event)

Parameters

event

- pointer to an event container where to copy the event parameters

Returns

CUDBG_SUCCESS, CUDBG_ERROR_NO_EVENT_AVAILABLE, CUDBG_ERROR_INVALID_ARGS

Since CUDA 5.0.

> Note:
>
> Deprecated in CUDA 5.5.

CUDBGResult (*CUDBGAPI_st::getNextSyncEvent55) (CUDBGEvent55 *event)

Copies the next available event in the synchronous event queue into 'event' and removes it from the queue.

Parameters

event

- pointer to an event container where to copy the event parameters

Returns

CUDBG_SUCCESS, CUDBG_ERROR_NO_EVENT_AVAILABLE, CUDBG_ERROR_INVALID_ARGS

Since CUDA 5.5.

> Note:
>
> Deprecated in CUDA 6.0.

CUDBGResult (*CUDBGAPI_st::setNotifyNewEventCallback) (CUDBGNotifyNewEventCallback callback, void *userData)

Provides the API with the function to call to notify the debugger of a new application or device event.

Parameters

callback

- the callback function

userData

- user data to be passed to the callback

Returns

CUDBG_SUCCESS

Since CUDA 13.0.

CUDBGResult (*CUDBGAPI_st::setNotifyNewEventCallback31) (CUDBGNotifyNewEventCallback31 callback, void *data)

Provides the API with the function to call to notify the debugger of a new application or device event.

Parameters

callback
- the callback function

data
- a pointer to be passed to the callback when called

Returns

CUDBG_SUCCESS

Since CUDA 3.0.

> Note:
>
> Deprecated in CUDA 3.2.

CUDBGResult (*CUDBGAPI_st::setNotifyNewEventCallback40) (CUDBGNotifyNewEventCallback40 callback)

Provides the API with the function to call to notify the debugger of a new application or device event.

Parameters

callback
- the callback function

Returns

CUDBG_SUCCESS

Since CUDA 3.2.

> Note:
>
> Deprecated in CUDA 4.1.

CUDBGResult (*CUDBGAPI_st::setNotifyNewEventCallback41) (CUDBGNotifyNewEventCallback41 callback)

Provides the API with the function to call to notify the debugger of a new application or device event.

Parameters

callback

- the callback function

Returns

CUDBG_SUCCESS

Since CUDA 4.1.

> Note:
>
> Deprecated in CUDA 13.0.

Chapter 4. Data Structures

Here are the data structures with brief descriptions:

cudbgGetAPI
The CUDA debugger API routines

CUDBGCudaLogMessage
CUDA Log Message

CUDBGEvent
Event information container

CUDBGEvent::CUDBGEvent::cases_st

CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::contextCreate_st

CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::contextDestroy_st

CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::contextPop_st

CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::contextPush_st

CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::elfImageLoaded_st

CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::internalError_st

CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::kernelFinished_st

CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::kernelReady_st

CUDBGEventCallbackData
Event information passed to callback set with setNotifyNewEventCallback function

CUDBGEventCallbackData40
Event information passed to callback set with setNotifyNewEventCallback function

CUDBGGridInfo
Grid info

4.1. CUDBGAPI_st Struct Reference

The CUDA debugger API routines.

Get the API associated with the major/minor/revision version numbers.

See also:

cudbgGetAPIVersion

CUDBGResult (*acknowledgeEvent30) (CUDBGEvent30 *event)

Inform the debugger API that the event has been processed.

Parameters

event

- pointer to the event that has been processed

Returns

CUDBG_SUCCESS

Since CUDA 3.0.

> Note:
>
> Deprecated in CUDA 3.1.

CUDBGResult (*acknowledgeEvents42) ()

Inform the debugger API that synchronous events have been processed.

Returns

CUDBG_SUCCESS

Since CUDA 3.1.

> Note:
>
> Deprecated in CUDA 5.0.

CUDBGResult (*acknowledgeSyncEvents) ()

Inform the debugger API that synchronous events have been processed.

Returns

CUDBG_SUCCESS

Since CUDA 5.0.

CUDBGResult (*clearAttachState) ()

Clear attach-specific state prior to detach.

Returns

CUDBG_SUCCESS

Since CUDA 5.0.

CUDBGResult (*consumeCudaLogs) (CUDBGCudaLogMessage *logMessages, uint32_t numMessages, uint32_t *numConsumed)

Get CUDA error log entries. This consumes the log entries, so they will not be available in subsequent calls.

Parameters

logMessages
- client-allocated array to store log entries

numMessages
- capacity of the logMessages array, in number of elements

numConsumed
- returned number of entries written to logMessages

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_NO_EVENT_AVAILABLE, CUDBG_ERROR_NOT_SUPPORTED,

Since CUDA 12.9.

CUDBGResult (*disassemble) (uint32_t dev, uint64_t addr, uint32_t *instSize, char *buf, uint32_t sz)

Disassemble instruction at instruction address.

Parameters

dev
- device index

addr
- instruction address

instSize
- instruction size (32 or 64 bits)

buf
- disassembled instruction buffer

sz
- disassembled instruction buffer size

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNKNOWN

Since CUDA 3.0.

CUDBGResult (*finalize) ()

Finalize the API and free all memory.

Returns

CUDBG_SUCCESS, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_COMMUNICATION_FAILURE, CUDBG_ERROR_UNKNOWN

Since CUDA 3.0.

See also:

initialize

CUDBGResult (*generateCoredump) (const char *filename, CUDBGCoredumpGenerationFlags flags)

Generates a coredump for the current GPU state.

Parameters

filename
- target coredump file name

flags
- coredump generation flags/options

Returns

CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_NOT_SUPPORTED

Since CUDA 12.3

CUDBGResult (*getAdjustedCodeAddress) (uint32_t devId, uint64_t address, uint64_t *adjustedAddress, CUDBGAdjAddrAction adjAction)

The client must call this function before inserting a breakpoint, or when the previous or next code address is needed. Returns the adjusted code address for a given code address for a given device.

Parameters

devId
- the device index

address

adjustedAddress
- adjusted address

adjAction
- whether the adjusted next, previous or current address is needed

Returns

CUDBG_SUCCESS, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_INVALID_ADDRESS, CUDBG_ERROR_INVALID_DEVICE

Since CUDA 5.5.

See also:

unsetBreakpoint

CUDBGResult (*getBlockDim) (uint32_t dev, uint32_t sm, uint32_t wp, CuDim3 *blockDim)

Get the number of threads in the given block.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

blockDim
- the returned number of threads in the block

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

getGridDim

CUDBGResult (*getCbuWarpState) (uint32_t dev, uint32_t sm, uint64_t warpMask, CUDBGCbuWarpState *warpStates, uint32_t numWarpStates)

Gets CBU state of a given warp.

Parameters

dev
- device index

sm
- SM index

warpMask
- bitmask of the warps which states should be returned in warpStates

warpStates
- pointer to the array of CUDBGCbuWarpState structures

numWarpStates
- number of elements in warpStates array

Returns

CUDBG_ERROR_NOT_SUPPORTED,

Since CUDA 12.9.

CUDBGResult (*getClusterDim) (uint32_t dev, uint32_t sm, uint32_t wp, CuDim3 *clusterDim)

Get the number of blocks in the given cluster.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

clusterDim
- the returned number of blocks in the cluster

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_UNINITIALIZED

Since CUDA 12.7.

See also:

getBlockDim

getGridDim

CUDBGResult (*getClusterDim120) (uint32_t dev, uint64_t gridId64, CuDim3 *clusterDim)

Get the number of blocks in the given cluster.

Parameters

dev
- device index

gridId64
- grid ID

clusterDim
- the returned number of blocks in the cluster

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_UNINITIALIZED

Since CUDA 12.0.

> Note:
>
> Deprecated in CUDA 12.7.

See also:

getBlockDim

getGridDim

CUDBGResult (*getClusterExceptionTargetBlock) (uint32_t dev, uint32_t sm, uint32_t wp, CuDim3 *blockIdx, bool *blockIdxValid)

Retrieves the target block index and validity status for a given device, streaming multiprocessor, and warp for cluster exceptions.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

blockIdx
- pointer to a `CuDim3` structure that will be populated with the target block index

blockIdxValid
- pointer to a boolean variable that will be set to `true` if the target block index is valid, and `false` otherwise. Value will be set to false if the warp is not stopped on a cluster exception

Returns

CUDBG_SUCCESS, CUDBG_ERROR_NOT_SUPPORTED, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_INVALID_ARGS,

Since CUDA 12.7.

CUDBGResult (*getConstBankAddress) (uint32_t dev, uint64_t gridId64, uint32_t bank, uint64_t *address, uint32_t *size)

Get constant bank GPU VA and size.

Parameters

dev
- device index

gridId64
- grid ID of the grid containing the constant bank

bank
- constant bank number

address
- (output) GPU VA of the bank memory

size
- (output) bank size

Returns

CUDBG_ERROR_NOT_SUPPORTED

Since CUDA 12.4

CUDBGResult (*getConstBankAddress123) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t bank, uint32_t offset, uint64_t *address)

Convert constant bank number and offset into GPU VA.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

bank
- constant bank number

offset
- offset within the bank

address
- (output) GPU VA

Returns

CUDBG_ERROR_NOT_SUPPORTED

Since CUDA 12.3

> Note:
>
> Deprecated in CUDA 12.4.

CUDBGResult (*getCudaExceptionString) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, char *buf, uint32_t bufSz, uint32_t *msgSz)

Get error string for CUDA Exceptions.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

buf
- buffer for the error string

bufSz
- buffer size

msgSz
- error message size with null character, can be null

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_BUFFER_TOO_SMALL, CUDBG_ERROR_NOT_SUPPORTED

Since CUDA 13.0.

CUDBGResult (*getDeviceName) (uint32_t dev, char *buf, uint32_t sz)

Get the device name string.

Parameters

dev
- device index

buf
- the destination buffer

sz
- the size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_BUFFER_TOO_SMALL, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNINITIALIZED

Since CUDA 6.5.

See also:

getSMType

getDeviceType

CUDBGResult (*getDevicePCIBusInfo) (uint32_t devId, uint32_t *pciBusId, uint32_t *pciDevId)

Get PCI bus and device ids associated with device devId.

Parameters

devId
- the cuda device id

pciBusId
- pointer where corresponding PCI BUS ID would be stored

pciDevId
- pointer where corresponding PCI DEVICE ID would be stored

Returns

CUDBG_ERROR_INVALID_ARGS, CUDBG_SUCCESS, CUDBG_ERROR_INVALID_DEVICE

CUDBGResult (*getDeviceType) (uint32_t dev, char *buf, uint32_t sz)

Get the string description of the device.

Parameters

dev
- device index

buf
- the destination buffer

sz
- the size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_BUFFER_TOO_SMALL, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

getSMType

CUDBGResult (*getElfImage) (uint32_t dev, uint32_t sm, uint32_t wp, bool relocated, void **elfImage, uint64_t *size)

Get the relocated or non-relocated ELF image and size for the grid on the given device.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

relocated
- set to true to specify the relocated ELF image, false otherwise

***elfImage**
- pointer to the ELF image

size
- size of the ELF image (64 bits)

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_UNINITIALIZED

Since CUDA 4.0.

CUDBGResult (*getElfImage32) (uint32_t dev, uint32_t sm, uint32_t wp, bool relocated, void **elfImage, uint32_t *size)

Get the relocated or non-relocated ELF image and size for the grid on the given device.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

relocated
- set to true to specify the relocated ELF image, false otherwise

***elfImage**
- pointer to the ELF image

size
- size of the ELF image (32 bits)

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

> Note:
>
> Deprecated in CUDA 4.0.

CUDBGResult (*getElfImageByHandle) (uint32_t devId, uint64_t handle, CUDBGElfImageType type, void *elfImage, uint64_t size)

Get the relocated or non-relocated ELF image for the given handle on the given device.

Parameters

devId
- device index

handle
- elf image handle

type
- type of the requested ELF image

elfImage
- pointer to the ELF image

size

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNINITIALIZED

The handle is provided in the ELF Image Loaded notification event.

Since CUDA 6.0.

CUDBGResult (*getErrorStringEx) (char *buf, uint32_t bufSz, uint32_t *msgSz)

Fills a user-provided buffer with an error message encoded as a null-terminated ASCII string. The error message is specific to the last failed API call and is invalidated after every API call.

Parameters

buf
- the destination buffer

bufSz
- the size of the destination buffer in bytes

msgSz
- the size of an error message including the terminating null character.

Returns

CUDBG_SUCCESS, CUDBG_ERROR_BUFFER_TOO_SMALL
CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_UNINITIALIZED

Since CUDA 12.2.

See also:

getErrorString

CUDBGResult (*getGridAttribute) (uint32_t dev, uint32_t sm, uint32_t wp, CUDBGAttribute attr, uint64_t *value)

Get the value of a grid attribute.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

attr
- the attribute

value
- the returned value of the attribute

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_INVALID_ATTRIBUTE, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.1.

CUDBGResult (*getGridAttributes) (uint32_t dev, uint32_t sm, uint32_t wp, CUDBGAttributeValuePair *pairs, uint32_t numPairs)

Get several grid attribute values in a single API call.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

pairs
- array of attribute/value pairs

numPairs
- the number of attribute/values pairs in the array

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_INVALID_ATTRIBUTE, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.1.

CUDBGResult (*getGridDim) (uint32_t dev, uint32_t sm, uint32_t wp, CuDim3 *gridDim)

Get the number of blocks in the given grid.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

gridDim
- the returned number of blocks in the grid

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_UNINITIALIZED

Since CUDA 4.0.

See also:

getBlockDim

CUDBGResult (*getGridDim32) (uint32_t dev, uint32_t sm, uint32_t wp, CuDim2 *gridDim)

Get the number of blocks in the given grid.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

gridDim
- the returned number of blocks in the grid

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

> Note:
>
> Deprecated in CUDA 4.0.

See also:

getBlockDim

CUDBGResult (*getGridInfo) (uint32_t dev, uint64_t gridId64, CUDBGGridInfo *gridInfo)

Get information about the specified grid. If the context of the grid has already been destroyed, the function will return CUDBG_ERROR_INVALID_GRID, although the grid id is correct.

Parameters

dev
gridId64
gridInfo
- pointer to a client allocated structure in which grid info will be returned.

Returns

CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_GRID, CUDBG_SUCCESS

Since CUDA 12.7.

CUDBGResult (*getGridInfo120) (uint32_t dev, uint64_t gridId64, CUDBGGridInfo120 *gridInfo)

Get information about the specified grid. If the context of the grid has already been destroyed, the function will return CUDBG_ERROR_INVALID_GRID, although the grid id is correct.

Parameters

dev
gridId64
gridInfo
- pointer to a client allocated structure in which grid info will be returned.

Returns

CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_GRID, CUDBG_SUCCESS

Since CUDA 12.0.

> Note:
>
> Deprecated in CUDA 12.3.

CUDBGResult (*getGridInfo55) (uint32_t dev, uint64_t gridId64, CUDBGGridInfo55 *gridInfo)

Get information about the specified grid. If the context of the grid has already been destroyed, the function will return CUDBG_ERROR_INVALID_GRID, although the grid id is correct.

Parameters

dev
gridId64
gridInfo
- pointer to a client allocated structure in which grid info will be returned.

Returns

CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_GRID, CUDBG_SUCCESS

Since CUDA 5.5.

> Note:
>
> Deprecated in CUDA 12.0.

CUDBGResult (*getGridStatus) (uint32_t dev, uint64_t gridId64, CUDBGGridStatus *status)

Check whether the grid corresponding to the given gridId is still present on the device.

Parameters

dev

gridId64

- 64-bit grid ID

status

- enum indicating whether the grid status is INVALID, PENDING, ACTIVE, SLEEPING, TERMINATED or UNDETERMINED

Returns

CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_INTERNAL

Since CUDA 5.5.

CUDBGResult (*getGridStatus50) (uint32_t dev, uint32_t gridId, CUDBGGridStatus *status)

Check whether the grid corresponding to the given gridId is still present on the device.

Parameters

dev

gridId

- grid ID

status

- enum indicating whether the grid status is INVALID, PENDING, ACTIVE, SLEEPING, TERMINATED or UNDETERMINED

Returns

CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_INTERNAL

Since CUDA 5.0.

> Note:
>
> Deprecated in CUDA 5.5.

CUDBGResult (*getHardwareBarrierInfo) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, CUDBGBarrierScope *scope, char *buf, uint32_t bufSz, uint32_t *msgSz)

Get hardware barrier information.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

scope
- barrier scope

buf
- buffer for the barrier information

bufSz
- buffer size

msgSz
- error message size with null character, can be null

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_BUFFER_TOO_SMALL, CUDBG_ERROR_NOT_SUPPORTED

Since CUDA 13.1.

CUDBGResult (*getHostAddrFromDeviceAddr) (uint32_t dev, uint64_t device_addr, uint64_t *host_addr)

given a device virtual address, return a corresponding system memory virtual address.

Parameters

dev
- device index

device_addr
- device memory address

host_addr
- returned system memory address

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_CONTEXT, CUDBG_ERROR_INVALID_MEMORY_SEGMENT

Since CUDA 4.1.

See also:

readGenericMemory

writeGenericMemory

CUDBGResult (*getLoadedFunctionInfo) (uint32_t devId, uint64_t handle, CUDBGLoadedFunctionInfo *info, uint32_t startIndex, uint32_t numEntries)

Get the section number and address of loaded functions for a given module.

Parameters

devId

handle
- ELF/cubin image handle

info

startIndex

numEntries
- number of function load entries to read

Returns

CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_NOT_SUPPORTED

Since CUDA 11.8

CUDBGResult (*getLoadedFunctionInfo118) (uint32_t devId, uint64_t handle, CUDBGLoadedFunctionInfo *info, uint32_t numEntries)

Get the section number and address of loaded functions for a given module.

Parameters

devId

handle

- ELF/cubin image handle

info

numEntries

- number of function load entries to read

Returns

CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_NOT_SUPPORTED

Since CUDA 11.8

> Note:
>
> Deprecated in CUDA 12.3.

CUDBGResult (*getManagedMemoryRegionInfo) (uint64_t startAddress, CUDBGMemoryInfo *memoryInfo, uint32_t memoryInfo_size, uint32_t *numEntries)

Returns a sorted list of managed memory regions The sorted list of memory regions starts from a region containing the specified starting address. If the starting address is set to 0, a sorted list of managed memory regions is returned which starts from the managed memory region with the lowest start address.

Parameters

startAddress

- The address that the first region in the list must contain. If the starting address is set to 0, the list of managed memory regions returned starts from the managed memory region with the lowest start address.

memoryInfo

- Client-allocated array of memory region records of type CUDBGMemoryInfo.

memoryInfo_size

- Number of records of type CUDBGMemoryInfo that memoryInfo can hold.

numEntries

- Pointer to a client-allocated variable holding the number of valid entries retured in memoryInfo. Valid entries are continguous and start from memoryInfo[0].

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_ADDRESS, CUDBG_ERROR_INTERNAL

Since CUDA 6.0.

CUDBGResult (*getNextAsyncEvent50) (CUDBGEvent50 *event)

Copies the next available event in the asynchronous event queue into 'event' and removes it from the queue. The asynchronous event queue is held separate from the normal event queue, and does not require acknowledgement from the debug client.

Parameters

event

- pointer to an event container where to copy the event parameters

Returns

CUDBG_SUCCESS, CUDBG_ERROR_NO_EVENT_AVAILABLE, CUDBG_ERROR_INVALID_ARGS

Since CUDA 5.0.

> Note:
>
> Deprecated in CUDA 5.5.

CUDBGResult (*getNextAsyncEvent55) (CUDBGEvent55 *event)

Copies the next available event in the asynchronous event queue into 'event' and removes it from the queue. The asynchronous event queue is held separate from the normal event queue, and does not require acknowledgement from the debug client.

Parameters

event

- pointer to an event container where to copy the event parameters

Returns

CUDBG_SUCCESS, CUDBG_ERROR_NO_EVENT_AVAILABLE, CUDBG_ERROR_INVALID_ARGS

Since CUDA 5.5.

> Note:
>
> Deprecated in CUDA 6.0.

CUDBGResult (*getNextEvent) (CUDBGEventQueueType type, CUDBGEvent *event)

Copies the next available event into 'event' and removes it from the queue.

Parameters

type
- application event queue type

event
- pointer to an event container where to copy the event parameters

Returns

CUDBG_SUCCESS, CUDBG_ERROR_NO_EVENT_AVAILABLE, CUDBG_ERROR_INVALID_ARGS

Since CUDA 6.0.

CUDBGResult (*getNextEvent30) (CUDBGEvent30 *event)

Copies the next available event in the event queue into 'event' and removes it from the queue.

Parameters

event
- pointer to an event container where to copy the event parameters

Returns

CUDBG_SUCCESS, CUDBG_ERROR_NO_EVENT_AVAILABLE, CUDBG_ERROR_INVALID_ARGS

Since CUDA 3.0.

> Note:
>
> Deprecated in CUDA 3.1.

CUDBGResult (*getNextEvent32) (CUDBGEvent32 *event)

Copies the next available event in the event queue into 'event' and removes it from the queue.

Parameters

event

- pointer to an event container where to copy the event parameters

Returns

CUDBG_SUCCESS, CUDBG_ERROR_NO_EVENT_AVAILABLE, CUDBG_ERROR_INVALID_ARGS

Since CUDA 3.1.

> Note:
>
> Deprecated in CUDA 4.0

CUDBGResult (*getNextEvent42) (CUDBGEvent42 *event)

Copies the next available event in the event queue into 'event' and removes it from the queue.

Parameters

event

- pointer to an event container where to copy the event parameters

Returns

CUDBG_SUCCESS, CUDBG_ERROR_NO_EVENT_AVAILABLE, CUDBG_ERROR_INVALID_ARGS

Since CUDA 4.0.

> Note:

Deprecated in CUDA 5.0

CUDBGResult (*getNextSyncEvent50) (CUDBGEvent50 *event)

Parameters

event

- pointer to an event container where to copy the event parameters

Returns

CUDBG_SUCCESS, CUDBG_ERROR_NO_EVENT_AVAILABLE, CUDBG_ERROR_INVALID_ARGS

Since CUDA 5.0.

Note:

Deprecated in CUDA 5.5.

CUDBGResult (*getNextSyncEvent55) (CUDBGEvent55 *event)

Copies the next available event in the synchronous event queue into 'event' and removes it from the queue.

Parameters

event

- pointer to an event container where to copy the event parameters

Returns

CUDBG_SUCCESS, CUDBG_ERROR_NO_EVENT_AVAILABLE, CUDBG_ERROR_INVALID_ARGS

Since CUDA 5.5.

Note:

Deprecated in CUDA 6.0.

CUDBGResult (*getNumDevices) (uint32_t *numDev)

Get the number of installed CUDA devices.

Parameters

numDev
- the returned number of devices

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

getNumSMs

getNumWarps

getNumLanes

getNumRegisters

CUDBGResult (*getNumLanes) (uint32_t dev, uint32_t *numLanes)

Get the number of lanes per warp on the device.

Parameters

dev
- device index

numLanes
- the returned number of lanes

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

getNumDevices

getNumSMs

getNumWarps

getNumRegisters

CUDBGResult (*getNumPredicates) (uint32_t dev, uint32_t *numPredicates)

Get the number of predicate registers per lane on the device.

Parameters

dev
- device index

numPredicates
- the returned number of predicate registers

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNINITIALIZED

Since CUDA 6.5.

See also:

getNumDevices

getNumSMs

getNumWarps

getNumLanes

getNumRegisters

CUDBGResult (*getNumRegisters) (uint32_t dev, uint32_t *numRegs)

Get the number of registers per lane on the device.

Parameters

dev
- device index

numRegs
- the returned number of registers

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

getNumDevices

getNumSMs

getNumWarps

getNumLanes

CUDBGResult (*getNumSMs) (uint32_t dev, uint32_t *numSMs)

Get the total number of SMs on the device.

Parameters

dev
- device index

numSMs
- the returned number of SMs

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

getNumDevices

getNumWarps

getNumLanes

getNumRegisters

CUDBGResult (*getNumUniformPredicates) (uint32_t dev, uint32_t *numPredicates)

Get the number of uniform predicate registers per warp on the device.

Parameters

dev
- device index

numPredicates
- the returned number of uniform predicate registers

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNINITIALIZED

Since CUDA 10.0.

See also:

getNumUniformPredicates

CUDBGResult (*getNumUniformRegisters) (uint32_t dev, uint32_t *numRegs)

Get the number of uniform registers per warp on the device.

Parameters

dev
- device index

numRegs
- the returned number of uniform registers

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNINITIALIZED

Since CUDA 10.0.

See also:

getNumRegisters

CUDBGResult (*getNumWarps) (uint32_t dev, uint32_t *numWarps)

Get the number of warps per SM on the device.

Parameters

dev
- device index

numWarps
- the returned number of warps

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

getNumDevices

getNumSMs

getNumLanes

getNumRegisters

CUDBGResult (*getPhysicalRegister30) (uint64_t pc, char *reg, uint32_t *buf, uint32_t sz, uint32_t *numPhysRegs, CUDBGRegClass *regClass)

Get the physical register number(s) assigned to a virtual register name 'reg' at a given PC, if 'reg' is live at that PC.

Parameters

pc
- Program counter

reg
- virtual register index

buf
- physical register name(s)

sz
- the physical register name buffer size

numPhysRegs
- number of physical register names returned

regClass
- the class of the physical registers

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_UKNOWN_FUNCTION, CUDBG_ERROR_UNKNOWN

Since CUDA 3.0.

Note:

Deprecated in CUDA 3.1.

CUDBGResult (*getPhysicalRegister40) (uint32_t dev, uint32_t sm, uint32_t wp, uint64_t pc, char *reg, uint32_t *buf, uint32_t sz, uint32_t *numPhysRegs, CUDBGRegClass *regClass)

Get the physical register number(s) assigned to a virtual register name 'reg' at a given PC, if 'reg' is live at that PC.

Parameters

dev
- device index

sm
- SM index

wp
- warp indx

pc
- Program counter

reg
- virtual register index

buf
- physical register name(s)

sz
- the physical register name buffer size

numPhysRegs
- number of physical register names returned

regClass
- the class of the physical registers

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_UKNOWN_FUNCTION, CUDBG_ERROR_UNKNOWN

Get the physical register number(s) assigned to a virtual register name 'reg' at a given PC, if 'reg' is live at that PC. If a virtual register name is mapped to more than one physical register, the physical register with the lowest physical register index will contain the highest bits of the virtual register, and the physical register with the highest physical register index will contain the lowest bits.

Since CUDA 3.1.

Note:

Deprecated in CUDA 4.1.

CUDBGResult (*getSmType) (uint32_t dev, char *buf, uint32_t sz)

Get the SM type of the device.

Parameters

dev
- device index

buf
- the destination buffer

sz
- the size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_BUFFER_TOO_SMALL, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

getDeviceType

CUDBGResult (*getSupportedDebuggerCapabilities) (CUDBGCapabilityFlags *capabilities)

Returns debugger capabilities that are supported by this version of the API.

Parameters

capabilities
- returned debugger capabilities

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS,

Since CUDA 12.5.

This API method can be called without initializing the API.

CUDBGResult (*getTID) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t *tid)

Get the ID of the Linux thread hosting the context of the grid.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

tid
- the returned thread id

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

CUDBGResult (*initialize) ()

Initialize the API.

Returns

CUDBG_SUCCESS, CUDBG_ERROR_UNKNOWN

Since CUDA 3.0.

See also:

finalize

CUDBGResult (*initializeAttachStub) ()

Initialize the attach stub.

Returns

CUDBG_SUCCESS

Since CUDA 5.0.

CUDBGResult (*isDeviceCodeAddress) (uintptr_t addr, bool *isDeviceAddress)

Determines whether a virtual address resides within device code.

Parameters

addr
- virtual address

isDeviceAddress
- true if address resides within device code

Returns

CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_UNINITIALIZED, CUDBG_SUCCESS

Since CUDA 3.0.

CUDBGResult (*isDeviceCodeAddress55) (uintptr_t addr, bool *isDeviceAddress)

Determines whether a virtual address resides within device code. This API is strongly deprecated. Use CUDBGAPI_st::isDeviceCodeAddress instead.

Parameters

addr
- virtual address

isDeviceAddress
- true if address resides within device code

Returns

CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_UNINITIALIZED, CUDBG_SUCCESS

Since CUDA 3.0.

> Note:
>
> Deprecated in CUDA 6.0

CUDBGResult (*lookupDeviceCodeSymbol) (char *symName, bool *symFound, uintptr_t *symAddr)

Determines whether a symbol represents a function in device code and returns its virtual address.

Parameters

symName
- symbol name

symFound
- set to true if the symbol is found

symAddr
- the symbol virtual address if found

Returns

CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_UNINITIALIZED, CUDBG_SUCCESS

Since CUDA 3.0.

CUDBGResult (*memcheckReadErrorAddress) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint64_t *address, ptxStorageKind *storage)

Get the address that memcheck detected an error on.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

address
- returned address detected by memcheck

storage
- returned address class of address

Returns

CUDBG_ERROR_NOT_SUPPORTED,

Since CUDA 5.0.

CUDBGResult (*readActiveLanes) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t *activeLanesMask)

Reads the bitmask of active lanes on a valid warp.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

activeLanesMask
- the returned bitmask of active lanes

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

readGridId

readBlockIdx

readThreadIdx

readBrokenWarps

readValidWarps

readValidLanes

CUDBGResult (*readAllVirtualReturnAddresses) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint64_t *addrs, uint32_t numAddrs, uint32_t *callDepth, uint32_t *syscallCallDepth)

Reads all the virtual return addresses.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

addrs
- the returned addresses array

numAddrs
- number of elements in addrs array

callDepth
- the returned call depth

syscallCallDepth
- the returned syscall call depth

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_UNKNOWN_FUNCTION, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_INTERNAL

Since CUDA 12.5.

See also:

readCallDepth

readReturnAddress

CUDBGResult (*readBlockIdx) (uint32_t dev, uint32_t sm, uint32_t wp, CuDim3 *blockIdx)

Reads the CUDA block index running on a valid warp.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

blockIdx
- the returned CUDA block index

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 4.0.

See also:

readGridId

readThreadIdx

readBrokenWarps

readValidWarps

readValidLanes

readActiveLanes

CUDBGResult (*readBlockIdx32) (uint32_t dev, uint32_t sm, uint32_t wp, CuDim2 *blockIdx)

Reads the two-dimensional CUDA block index running on a valid warp.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

blockIdx
- the returned CUDA block index

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

> Note:
>
> Deprecated in CUDA 4.0.

See also:

readGridId

readThreadIdx

readBrokenWarps

readValidWarps

readValidLanes

readActiveLanes

CUDBGResult (*readBrokenWarps) (uint32_t dev, uint32_t sm, uint64_t *brokenWarpsMask)

Reads the bitmask of warps that are at a breakpoint on a given SM.

Parameters

dev
- device index

sm
- SM index

brokenWarpsMask
- the returned bitmask of broken warps

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

readGridId

readBlockIdx

readThreadIdx

readValidWarps

readValidLanes

readActiveLanes

CUDBGResult (*readCallDepth) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint32_t *depth)

Reads the call depth (number of calls) for a given lane.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

depth
- the returned call depth

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_UNINITIALIZED

Since CUDA 4.0.

See also:

readReturnAddress

readVirtualReturnAddress

CUDBGResult (*readCallDepth32) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t *depth)

Reads the call depth (number of calls) for a given warp.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

depth
- the returned call depth

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.1.

> Note:
>
> Deprecated in CUDA 4.0.

See also:

readReturnAddress32

readVirtualReturnAddress32

CUDBGResult (*readCCRegister) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint32_t *val)

Reads the hardware CC register.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

val
- buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 6.5.

See also:

readCodeMemory

readConstMemory129

readGenericMemory

readGlobalMemory

readParamMemory

readSharedMemory

readTextureMemory

readLocalMemory

readRegister

readPC

readPredicates

CUDBGResult (*readClusterIdx) (uint32_t dev, uint32_t sm, uint32_t wp, CuDim3 *clusterIdx)

Reads the CUDA cluster index running on a valid warp.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

clusterIdx
- the returned CUDA cluster index

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 12.0.

> Note:
>
> Deprecated in CUDA 12.7.

See also:

readGridId

readThreadIdx

readBlockIdx

readBrokenWarps

readValidWarps

readValidLanes

readActiveLanes

CUDBGResult (*readCodeMemory) (uint32_t dev, uint64_t addr, void *buf, uint32_t sz)

Reads content at address in the code memory segment.

Parameters

dev
- device index

addr
- memory address

buf
- buffer

sz
- size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_MEMORY_MAPPING_FAILED

Since CUDA 3.0.

See also:

readConstMemory129

readGenericMemory

readParamMemory

readSharedMemory

readTextureMemory

readLocalMemory

readRegister

readPC

CUDBGResult (*readConstMemory129) (uint32_t dev, uint64_t addr, void *buf, uint32_t sz)

Reads content at address in the constant memory segment.

Parameters

dev
- device index

addr
- memory address

buf
- buffer

sz
- size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_MEMORY_MAPPING_FAILED

Since CUDA 3.0.

Note:

Deprecated in CUDA 13.0.

See also:

readCodeMemory

readGenericMemory

readParamMemory

readSharedMemory

readTextureMemory

readLocalMemory

readRegister

readPC

CUDBGResult (*readCPUCallStack) (uint32_t dev, uint64_t gridId64, uint64_t *addrs, uint32_t numAddrs, uint32_t *totalNumAddrs)

Read CPU call stack captured at the time of kernel launch.

Parameters

dev
- device index

gridId64
- 64-bit grid ID

addrs
- the returned addresses array, can be NULL

numAddrs
- capacity of addrs (possibly 0)

totalNumAddrs
- the actual size of the stack (number of frames) is written here; the value written can be greater than numAddrs

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_INTERNAL, CUDBG_ERROR_NOT_SUPPORTED

Since CUDA 12.9.

This method is only supported when the CUDBG_DEBUGGER_CAPABILITY_COLLECT_CPU_CALL_STACK_FOR_KERNEL_LAUNCHES capability has been enabled.

CUDBGResult (*readDeviceExceptionState) (uint32_t devId, uint64_t *mask, uint32_t numWords)

Get the exception state of the SMs on the device.

Parameters

devId
- the cuda device id

mask
- Arbitrarily sized bit field containing a 1 at (1 << i) if SM i hit an exception

numWords

Returns

CUDBG_ERROR_INVALID_ARGS, CUDBG_SUCCESS, CUDBG_ERROR_INVALID_DEVICE

Since CUDA 9.0

See also:

getNumSMs

CUDBGResult (*readDeviceExceptionState80) (uint32_t devId, uint64_t *exceptionSMMask)

Get the exception state of the SMs on the device.

Parameters

devId
- the cuda device id

exceptionSMMask
- Bit field containing a 1 at (1 << i) if SM i hit an exception

Returns

CUDBG_ERROR_INVALID_ARGS, CUDBG_SUCCESS, CUDBG_ERROR_INVALID_DEVICE

Since CUDA 5.5

Note:

Deprecated in CUDA 9.0.

CUDBGResult (*readErrorPC) (uint32_t devId, uint32_t sm, uint32_t wp, uint64_t *errorPC, bool *errorPCValid)

Get the hardware reported error PC if it exists.

Parameters

devId
- the device index

sm
- the SM index

wp

errorPC
- PC ofthe exception

errorPCValid
- boolean to indicate that the returned error PC is valid

Returns

CUDBG_SUCCESS CUDBG_ERROR_UNINITIALIZED CUDBG_ERROR_INVALID_DEVICE CUDBG_ERROR_INVALID_SM CUDBG_ERROR_INVALID_WARP CUDBG_ERROR_INVALID_ARGS CUDBG_ERROR_UNKNOWN_FUNCTION

Since CUDA 6.0

CUDBGResult (*readGenericMemory) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint64_t addr, void *buf, uint32_t sz)

Reads content at an address in the generic address space. This function determines if the given address falls into the local, shared, or global memory window. It then accesses memory taking into account the hardware co-ordinates provided as inputs.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

addr
- memory address

buf
- buffer

sz

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_MEMORY_MAPPING_FAILED, CUDBG_ERROR_ADDRESS_NOT_IN_DEVICE_MEM

Since CUDA 6.0.

See also:

readCodeMemory

readConstMemory129

readParamMemory

readSharedMemory

readTextureMemory

readLocalMemory

readRegister

readPC

CUDBGResult (*readGlobalMemory) (uint64_t addr, void *buf, uint32_t sz)

Reads content at an address in the global address space. If the address is valid on more than one device and one of those devices does not support UVA, an error is returned.

Parameters

addr
- memory address

buf
- buffer

sz

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_MEMORY_MAPPING_FAILED, CUDBG_ERROR_INVALID_MEMORY_ACCESS, CUDBG_ERROR_ADDRESS_NOT_IN_DEVICE_MEM CUDBG_ERROR_AMBIGUOUS_MEMORY_ADDRESS_

Since CUDA 6.0.

See also:

readCodeMemory

readConstMemory129

readParamMemory

readSharedMemory

readTextureMemory

readLocalMemory

readRegister

readPC

CUDBGResult (*readGlobalMemory31) (uint32_t dev, uint64_t addr, void *buf, uint32_t sz)

Reads content at address in the global memory segment.

Parameters

dev
- device index

addr
- memory address

buf
- buffer

sz
- size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_MEMORY_MAPPING_FAILED

Since CUDA 3.0.

> Note:
>
> Deprecated in CUDA 3.2.

See also:

readCodeMemory

readConstMemory129

readParamMemory

readSharedMemory

readTextureMemory

readLocalMemory

readRegister

readPC

CUDBGResult (*readGlobalMemory55) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint64_t addr, void *buf, uint32_t sz)

Reads content at address in the global memory segment (entire 40-bit VA on Fermi+).

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

addr
- memory address

buf
- buffer

sz
- size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_MEMORY_MAPPING_FAILED, CUDBG_ERROR_ADDRESS_NOT_IN_DEVICE_MEM

Since CUDA 3.2.

> Note:
>
> Deprecated in CUDA 6.0.

See also:

readCodeMemory

readConstMemory129

readParamMemory

readSharedMemory

readTextureMemory

readLocalMemory

readRegister

readPC

CUDBGResult (*readGridId) (uint32_t dev, uint32_t sm, uint32_t wp, uint64_t *gridId64)

Reads the 64-bit CUDA grid index running on a valid warp.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

gridId64

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 5.5.

See also:

readBlockIdx

readThreadIdx

readBrokenWarps

readValidWarps

readValidLanes

readActiveLanes

CUDBGResult (*readGridId50) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t *gridId)

Reads the CUDA grid index running on a valid warp.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

gridId
- the returned CUDA grid index

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

Note:

Deprecated in CUDA 5.5.

See also:

readBlockIdx

readThreadIdx

readBrokenWarps

readValidWarps

readValidLanes

readActiveLanes

CUDBGResult (*readLaneException) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, CUDBGException_t *exception)

Reads the exception type for a given lane.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

exception
- the returned exception type

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.1.

CUDBGResult (*readLaneStatus) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, bool *error)

Reads the status of the given lane. For specific error values, use readLaneException.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

error
- true if there is an error

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

CUDBGResult (*readLocalMemory) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint64_t addr, void *buf, uint32_t sz)

Reads content at address in the local memory segment.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

addr
- memory address

buf
- buffer

sz
- size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_MEMORY_MAPPING_FAILED

Since CUDA 3.0.

See also:

readCodeMemory

readConstMemory129

readGenericMemory

readParamMemory

readSharedMemory

readTextureMemory

readRegister

readPC

CUDBGResult (*readParamMemory) (uint32_t dev, uint32_t sm, uint32_t wp, uint64_t addr, void *buf, uint32_t sz)

Reads content at address in the param memory segment.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

addr
- memory address

buf
- buffer

sz
- size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_MEMORY_MAPPING_FAILED

Since CUDA 3.0.

See also:

readCodeMemory

readConstMemory129

readGenericMemory

readSharedMemory

readTextureMemory

readLocalMemory

readRegister

readPC

CUDBGResult (*readPC) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint64_t *pc)

Reads the PC on the given active lane.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

pc
- the returned PC

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNKNOWN_FUNCTION, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

readCodeMemory

readConstMemory129

readGenericMemory

readParamMemory

readSharedMemory

readTextureMemory

readLocalMemory

readRegister

readVirtualPC

CUDBGResult (*readPinnedMemory) (uint64_t addr, void *buf, uint32_t sz)

Reads content at pinned address in system memory.

Parameters

addr
- system memory address

buf
- buffer

sz
- size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_MEMORY_MAPPING_FAILED, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.2.

See also:

readCodeMemory

readConstMemory129

readGenericMemory

readParamMemory

readSharedMemory

readTextureMemory

readLocalMemory

readRegister

readPC

CUDBGResult (*readPredicates) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint32_t predicates_size, uint32_t *predicates)

Reads content of hardware predicate registers.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

predicates_size
- number of predicate registers to read

predicates
- buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 6.5.

See also:

readCodeMemory

readConstMemory129

readGenericMemory

readGlobalMemory

readParamMemory

readSharedMemory

readTextureMemory

readLocalMemory

readRegister

readPC

CUDBGResult (*readRegister) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint32_t regno, uint32_t *val)

Reads content of a hardware register.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

regno
- register index

val
- buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

readCodeMemory

readConstMemory129

readGenericMemory

readParamMemory

readSharedMemory

readTextureMemory

readLocalMemory

readPC

CUDBGResult (*readRegisterRange) (uint32_t devId, uint32_t sm, uint32_t wp, uint32_t ln, uint32_t index, uint32_t registers_size, uint32_t *registers)

Reads content of a hardware range of hardware registers.

Parameters

devId

sm
- SM index

wp
- warp index

ln
- lane index

index
- index of the first register to read

registers_size
- number of registers to read

registers
- buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 6.0.

See also:

readCodeMemory

readConstMemory129

readGenericMemory

readParamMemory

readSharedMemory

readTextureMemory

readLocalMemory

readPC

readRegister

CUDBGResult (*readReturnAddress) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint32_t level, uint64_t *ra)

Reads the physical return address for a call level.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

level
- the specified call level

ra
- the returned return address for level

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_INVALID_CALL_LEVEL, CUDBG_ERROR_ZERO_CALL_DEPTH, CUDBG_ERROR_UNKNOWN_FUNCTION, CUDBG_ERROR_UNINITIALIZED

Since CUDA 4.0.

See also:

readCallDepth

readVirtualReturnAddress

CUDBGResult (*readReturnAddress32) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t level, uint64_t *ra)

Reads the physical return address for a call level.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

level
- the specified call level

ra
- the returned return address for level

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_INVALID_CALL_LEVEL, CUDBG_ERROR_ZERO_CALL_DEPTH, CUDBG_ERROR_UNKNOWN_FUNCTION, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.1.

> Note:
>
> Deprecated in CUDA 4.0.

See also:

readCallDepth32

readVirtualReturnAddress32

CUDBGResult (*readSharedMemory) (uint32_t dev, uint32_t sm, uint32_t wp, uint64_t addr, void *buf, uint32_t sz)

Reads content at address in the shared memory segment.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

addr
- memory address

buf
- buffer

sz
- size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_MEMORY_MAPPING_FAILED

Since CUDA 3.0.

See also:

readCodeMemory

readConstMemory129

readGenericMemory

readParamMemory

readLocalMemory

readTextureMemory

readRegister

readPC

CUDBGResult (*readSmException) (uint32_t dev, uint32_t sm, CUDBGException_t *exception, uint64_t *errorPC, bool *errorPCValid)

Get the SM exception status if it exists.

Parameters

dev
- the device index

sm
- the SM index

exception
- returned exception

errorPC
- returned PC of the exception

errorPCValid
- boolean to indicate that the returned error PC is valid

Returns

CUDBG_SUCCESS CUDBG_ERROR_UNINITIALIZED CUDBG_ERROR_INVALID_DEVICE CUDBG_ERROR_INVALID_SM CUDBG_ERROR_INVALID_ARGS CUDBG_ERROR_UNKNOWN_FUNCTION

Since CUDA 12.5.

CUDBGResult (*readSyscallCallDepth) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint32_t *depth)

Reads the call depth of syscalls for a given lane.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

depth
- the returned call depth

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_UNINITIALIZED

Since CUDA 4.1.

See also:

readReturnAddress

readVirtualReturnAddress

CUDBGResult (*readTextureMemory) (uint32_t devId, uint32_t vsm, uint32_t wp, uint32_t id, uint32_t dim, uint32_t *coords, void *buf, uint32_t sz)

This method is no longer supported since CUDA 12.0.

Parameters

devId
- device index

vsm
- SM index

wp
- warp index

id
- texture id (the value of DW_AT_location attribute in the relocated ELF image)

dim
- texture dimension (1 to 4)

coords
- array of coordinates of size dim

buf
- result buffer

sz
- size of the buffer

Returns

CUDBG_ERROR_NOT_SUPPORTED,

See also:

readCodeMemory

readConstMemory129

readGenericMemory

readParamMemory

readSharedMemory

readLocalMemory

readRegister

readPC

CUDBGResult (*readTextureMemoryBindless) (uint32_t devId, uint32_t vsm, uint32_t wp, uint32_t texSymtabIndex, uint32_t dim, uint32_t *coords, void *buf, uint32_t sz)

This method is no longer supported since CUDA 12.0.

Parameters

devId
- device index

vsm
- SM index

wp
- warp index

texSymtabIndex
- global symbol table index of the texture symbol

dim
- texture dimension (1 to 4)

coords
- array of coordinates of size dim

buf
- result buffer

sz
- size of the buffer

Returns

CUDBG_ERROR_NOT_SUPPORTED

See also:

readCodeMemory

readConstMemory129

readGenericMemory

readParamMemory

readSharedMemory

readLocalMemory

readRegister

readPC

CUDBGResult (*readThreadIdx) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, CuDim3 *threadIdx)

Reads the CUDA thread index running on valid lane.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

threadIdx
- the returned CUDA thread index

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

readGridId

readBlockIdx

readBrokenWarps

readValidWarps

readValidLanes

readActiveLanes

CUDBGResult (*readUniformPredicates) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t predicates_size, uint32_t *predicates)

Reads contents of uniform predicate registers.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

predicates_size
- number of predicate registers to read

predicates
- buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 10.0.

See also:

readPredicates

CUDBGResult (*readUniformRegisterRange) (uint32_t devId, uint32_t sm, uint32_t wp, uint32_t regno, uint32_t registers_size, uint32_t *registers)

Reads a range of uniform registers.

Parameters

devId

sm
- SM index

wp
- warp index

regno
- starting index into uniform register file

registers_size
- number of bytes to read

registers
- pointer to buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 10.0.

See also:

readRegister

CUDBGResult (*readValidLanes) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t *validLanesMask)

Reads the bitmask of valid lanes on a given warp.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

validLanesMask
- the returned bitmask of valid lanes

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

readGridId

readBlockIdx

readThreadIdx

readBrokenWarps

readValidWarps

readActiveLanes

CUDBGResult (*readValidWarps) (uint32_t dev, uint32_t sm, uint64_t *validWarpsMask)

Reads the bitmask of valid warps on a given SM.

Parameters

dev
- device index

sm
- SM index

validWarpsMask
- the returned bitmask of valid warps

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

readGridId

readBlockIdx

readThreadIdx

readBrokenWarps

readValidLanes

readActiveLanes

CUDBGResult (*readVirtualPC) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint64_t *pc)

Reads the virtual PC on the given active lane.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

pc
- the returned PC

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_UNKNOWN_FUNCTION

Since CUDA 3.0.

See also:

readPC

CUDBGResult (*readVirtualReturnAddress) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint32_t level, uint64_t *ra)

Reads the virtual return address for a call level.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

level
- the specified call level

ra
- the returned virtual return address for level

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_INVALID_CALL_LEVEL, CUDBG_ERROR_ZERO_CALL_DEPTH, CUDBG_ERROR_UNKNOWN_FUNCTION, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_INTERNAL

Since CUDA 4.0.

See also:

readCallDepth

readReturnAddress

CUDBGResult (*readVirtualReturnAddress32) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t level, uint64_t *ra)

Reads the virtual return address for a call level.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

level
- the specified call level

ra
- the returned virtual return address for level

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_INVALID_GRID, CUDBG_ERROR_INVALID_CALL_LEVEL,

CUDBG_ERROR_ZERO_CALL_DEPTH, CUDBG_ERROR_UNKNOWN_FUNCTION, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_INTERNAL

Since CUDA 3.1.

> Note:
>
> Deprecated in CUDA 4.0.

See also:

readCallDepth32

readReturnAddress32

CUDBGResult (*readWarpResources) (uint32_t dev, uint32_t sm, uint32_t wp, CUDBGWarpResources *resources)

Get the resources assigned to a given warp.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

resources
- pointer to structure that contains warp resources

Returns

CUDBG_ERROR_NOT_SUPPORTED,

Since CUDA 12.8.

CUDBGResult (*readWarpState) (uint32_t dev, uint32_t sm, uint32_t wp, CUDBGWarpState *state)

Get state of a given warp.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

state
- pointer to structure that contains warp state

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED,

Since CUDA 12.9.

CUDBGResult (*readWarpState120) (uint32_t dev, uint32_t sm, uint32_t wp, CUDBGWarpState120 *state)

Get state of a given warp.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

state
- pointer to structure that contains warp status

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED,

Since CUDA 12.0.

> Note:
>
> Deprecated in CUDA 12.7.

CUDBGResult (*readWarpState127) (uint32_t dev, uint32_t sm, uint32_t wp, CUDBGWarpState127 *state)

Get state of a given warp.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

state
- pointer to structure that contains warp status

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED,

Since CUDA 12.7.

> Note:
>
> Deprecated in CUDA 12.9.

CUDBGResult (*readWarpState60) (uint32_t devId, uint32_t sm, uint32_t wp, CUDBGWarpState60 *state)

Get state of a given warp.

Parameters

devId

sm
- SM index

wp
- warp index

state
- pointer to structure that contains warp status

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED,

Since CUDA 6.0.

> Note:
>
> Deprecated in CUDA 12.0.

CUDBGResult (*requestCleanupOnDetach) (uint32_t appResumeFlag)

Request for cleanup of driver state when detaching.

Parameters

appResumeFlag
- value of CUDBG_RESUME_FOR_ATTACH_DETACH as read from the application's process space.

Returns

CUDBG_SUCCESS CUDBG_ERROR_COMMUNICATION_FAILURE CUDBG_ERROR_INVALID_ARGS CUDBG_ERROR_INTERNAL

Since CUDA 6.0.

CUDBGResult (*requestCleanupOnDetach55) ()

Request for cleanup of driver state when detaching.

Returns

CUDBG_SUCCESS CUDBG_ERROR_COMMUNICATION_FAILURE CUDBG_ERROR_INVALID_ARGS CUDBG_ERROR_INTERNAL

Since CUDA 5.0.

> Note:

Deprecated in CUDA 6.0

CUDBGResult (*resumeDevice) (uint32_t dev)

Resume a suspended CUDA device.

Parameters

dev

- device index

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_RUNNING_DEVICE, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

suspendDevice

singleStepWarp

CUDBGResult (*resumeWarpsUntilPC) (uint32_t devId, uint32_t sm, uint64_t warpMask, uint64_t virtPC)

Inserts a temporary breakpoint at the specified virtual PC, and resumes all warps in the specified bitmask on a given SM. As compared to CUDBGAPI_st::resumeDevice, CUDBGAPI_st::resumeWarpsUntilPC provides finer-grain control by resuming a selected set of warps on the same SM. The main intended usage is to accelerate the single-stepping process when the target PC is known in advance. Instead of single-stepping each warp individually until the target PC is hit, the client can issue this API. When this API is used, errors within CUDA kernels will no longer be reported precisely. In the situation where resuming warps is not possible, this API will return CUDBG_ERROR_WARP_RESUME_NOT_POSSIBLE. The client should then fall back to using CUDBGAPI_st::singleStepWarp or CUDBGAPI_st::resumeDevice.

Parameters

devId

- device index

sm

- the SM index

warpMask

- the bitmask of warps to resume (1 = resume, 0 = do not resume)

virtPC

- the virtual PC where the temporary breakpoint will be inserted

Returns

CUDBG_SUCCESS CUDBG_ERROR_INVALID_ARGS CUDBG_ERROR_INVALID_DEVICE CUDBG_ERROR_INVALID_SM CUDBG_ERROR_INVALID_WARP_MASK CUDBG_ERROR_WARP_RESUME_NOT_POSSIBLE CUDBG_ERROR_UNINITIALIZED

Since CUDA 6.0.

See also:

resumeDevice

CUDBGResult (*setBreakpoint) (uint32_t dev, uint64_t addr)

Sets a breakpoint at the given instruction address for the given device. Before setting a breakpoint, CUDBGAPI_st::getAdjustedCodeAddress should be called to get the adjusted breakpoint address.

Parameters

dev
- the device index

addr
- instruction address

Returns

CUDBG_SUCCESS, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_INVALID_ADDRESS, CUDBG_ERROR_INVALID_DEVICE

Since CUDA 3.2.

See also:

unsetBreakpoint

CUDBGResult (*setBreakpoint31) (uint64_t addr)

Sets a breakpoint at the given instruction address.

Parameters

addr
- instruction address

Returns

CUDBG_SUCCESS, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_INVALID_ADDRESS

Since CUDA 3.0.

> Note:
>
> Deprecated in CUDA 3.2.

See also:

unsetBreakpoint31

CUDBGResult (*setKernelLaunchNotificationMode) (CUDBGKernelLaunchNotifyMode mode)

Set the launch notification policy.

Parameters

mode
- mode to deliver kernel launch notifications in

Returns

CUDBG_SUCCESS

Since CUDA 5.5.

CUDBGResult (*setNotifyNewEventCallback) (CUDBGNotifyNewEventCallback callback, void *userData)

Provides the API with the function to call to notify the debugger of a new application or device event.

Parameters

callback
- the callback function

userData
- user data to be passed to the callback

Returns

CUDBG_SUCCESS

Since CUDA 13.0.

CUDBGResult (*setNotifyNewEventCallback31) (CUDBGNotifyNewEventCallback31 callback, void *data)

Provides the API with the function to call to notify the debugger of a new application or device event.

Parameters

callback
- the callback function

data
- a pointer to be passed to the callback when called

Returns

CUDBG_SUCCESS

Since CUDA 3.0.

> Note:
>
> Deprecated in CUDA 3.2.

CUDBGResult (*setNotifyNewEventCallback40) (CUDBGNotifyNewEventCallback40 callback)

Provides the API with the function to call to notify the debugger of a new application or device event.

Parameters

callback
- the callback function

Returns

CUDBG_SUCCESS

Since CUDA 3.2.

> Note:
>
> Deprecated in CUDA 4.1.

CUDBGResult (*setNotifyNewEventCallback41) (CUDBGNotifyNewEventCallback41 callback)

Provides the API with the function to call to notify the debugger of a new application or device event.

Parameters

callback
- the callback function

Returns

CUDBG_SUCCESS

Since CUDA 4.1.

> Note:
>
> Deprecated in CUDA 13.0.

CUDBGResult (*singleStepWarp) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t laneHint, uint32_t nsteps, uint32_t flags, uint64_t *warpMask)

Single step an individual warp nsteps times on a suspended CUDA device. Only the last instruction in a range should be a control flow instruction.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

laneHint

nsteps
- number of single steps

flags

warpMask
- the warps that have been single-stepped

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_RUNNING_DEVICE, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_UNKNOWN

Since CUDA 7.5.

See also:

resumeDevice

suspendDevice

CUDBGResult (*singleStepWarp40) (uint32_t dev, uint32_t sm, uint32_t wp)

Single step an individual warp on a suspended CUDA device.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_RUNNING_DEVICE, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_UNKNOWN, CUDBG_ERROR_WARP_RESUME_NOT_POSSIBLE

Since CUDA 3.0.

> Note:
>
> Deprecated in CUDA 4.1.

See also:

resumeDevice

suspendDevice

singleStepWarp

CUDBGResult (*singleStepWarp41) (uint32_t dev, uint32_t sm, uint32_t wp, uint64_t *warpMask)

Single step an individual warp on a suspended CUDA device.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

warpMask
- the warps that have been single-stepped

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_RUNNING_DEVICE, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_UNKNOWN

Since CUDA 4.1.

> Note:
>
> Deprecated in CUDA 7.5.

See also:

resumeDevice

suspendDevice

CUDBGResult (*suspendDevice) (uint32_t dev)

Suspends a running CUDA device.

Parameters

dev
- device index

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_RUNNING_DEVICE, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

resumeDevice

singleStepWarp

CUDBGResult (*unsetBreakpoint) (uint32_t dev, uint64_t addr)

Unsets a breakpoint at the given instruction address for the given device.

Parameters

dev
- the device index

addr
- instruction address

Returns

CUDBG_SUCCESS, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_INVALID_ADDRESS, CUDBG_ERROR_INVALID_DEVICE

Since CUDA 3.2.

See also:

setBreakpoint

CUDBGResult (*unsetBreakpoint31) (uint64_t addr)

Unsets a breakpoint at the given instruction address.

Parameters

addr
- instruction address

Returns

CUDBG_SUCCESS, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

> Note:
>
> Deprecated in CUDA 3.2.

See also:

setBreakpoint31

CUDBGResult (*writeCCRegister) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint32_t val)

Writes the hardware CC register.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

val
- value to write to the CC register

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 6.5.

See also:

writeConstMemory

writeGenericMemory

writeGlobalMemory

writeParamMemory

writeSharedMemory

writeTextureMemory

writeLocalMemory

writeRegister

writePredicates

CUDBGResult (*writeGenericMemory) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint64_t addr, const void *buf, uint32_t sz)

Writes content to an address in the generic address space. This function determines if the given address falls into the local, shared, or global memory window. It then accesses memory taking into account the hardware co-ordinates provided as inputs.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

addr
- memory address

buf
- buffer

sz

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_MEMORY_MAPPING_FAILED, CUDBG_ERROR_ADDRESS_NOT_IN_DEVICE_MEM

Since CUDA 6.0.

See also:

writeParamMemory

writeSharedMemory

writeLocalMemory

writeRegister

CUDBGResult (*writeGlobalMemory) (uint64_t addr, const void *buf, uint32_t sz)

Writes content to an address in the global address space. If the address is valid on more than one device and one of those devices does not support UVA, an error is returned.

Parameters

addr
- memory address

buf
- buffer

sz

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_MEMORY_MAPPING_FAILED, CUDBG_ERROR_INVALID_MEMORY_ACCESS, CUDBG_ERROR_ADDRESS_NOT_IN_DEVICE_MEM CUDBG_ERROR_AMBIGUOUS_MEMORY_ADDRESS_

Since CUDA 6.0.

See also:

writeParamMemory

writeSharedMemory

writeLocalMemory

writeRegister

CUDBGResult (*writeGlobalMemory31) (uint32_t dev, uint64_t addr, const void *buf, uint32_t sz)

Writes content to address in the global memory segment.

Parameters

dev
- device index

addr
- memory address

buf
- buffer

sz
- size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_MEMORY_MAPPING_FAILED

Since CUDA 3.0.

> Note:
>
> Deprecated in CUDA 3.2.

See also:

writeParamMemory

writeSharedMemory

writeLocalMemory

writeRegister

CUDBGResult (*writeGlobalMemory55) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint64_t addr, const void *buf, uint32_t sz)

Writes content to address in the global memory segment (entire 40-bit VA on Fermi+).

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

addr
- memory address

buf
- buffer

sz
- size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_MEMORY_MAPPING_FAILED, CUDBG_ERROR_ADDRESS_NOT_IN_DEVICE_MEM

Since CUDA 3.2.

> Note:
>
> Deprecated in CUDA 6.0.

See also:

writeParamMemory

writeSharedMemory

writeLocalMemory

writeRegister

CUDBGResult (*writeLocalMemory) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint64_t addr, const void *buf, uint32_t sz)

Writes content to address in the local memory segment.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

addr
- memory address

buf
- buffer

sz
- size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_MEMORY_MAPPING_FAILED

Since CUDA 3.0.

See also:

writeGenericMemory

writeParamMemory

writeSharedMemory

writeRegister

CUDBGResult (*writeParamMemory) (uint32_t dev, uint32_t sm, uint32_t wp, uint64_t addr, const void *buf, uint32_t sz)

Writes content to address in the param memory segment.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

addr
- memory address

buf
- buffer

sz
- size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_MEMORY_MAPPING_FAILED

Since CUDA 3.0.

See also:

writeGenericMemory

writeSharedMemory

writeLocalMemory

writeRegister

CUDBGResult (*writePinnedMemory) (uint64_t addr, const void *buf, uint32_t sz)

Writes content to pinned address in system memory.

Parameters

addr
- system memory address

buf
- buffer

sz
- size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_MEMORY_MAPPING_FAILED, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.2.

See also:

readCodeMemory

readConstMemory129

readGenericMemory

readParamMemory

readSharedMemory

readLocalMemory

readRegister

readPC

CUDBGResult (*writePredicates) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint32_t predicates_size, const uint32_t *predicates)

Writes content to hardware predicate registers.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

predicates_size
- number of predicate registers to write

predicates
- buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 6.5.

See also:

writeConstMemory

writeGenericMemory

writeGlobalMemory

writeParamMemory

writeSharedMemory

writeTextureMemory

writeLocalMemory

writeRegister

CUDBGResult (*writeRegister) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t ln, uint32_t regno, uint32_t val)

Writes content to a hardware register.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

ln
- lane index

regno
- register index

val
- buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_LANE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 3.0.

See also:

writeGenericMemory

writeParamMemory

writeSharedMemory

writeLocalMemory

CUDBGResult (*writeSharedMemory) (uint32_t dev, uint32_t sm, uint32_t wp, uint64_t addr, const void *buf, uint32_t sz)

Writes content to address in the shared memory segment.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

addr
- memory address

buf
- buffer

sz
- size of the buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED, CUDBG_ERROR_MEMORY_MAPPING_FAILED

Since CUDA 3.0.

See also:

writeGenericMemory

writeParamMemory

writeLocalMemory

writeRegister

CUDBGResult (*writeUniformPredicates) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t predicates_size, const uint32_t *predicates)

Writes to uniform predicate registers.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

predicates_size
- number of predicate registers to write

predicates
- buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 10.0.

See also:

readUniformPredicate

writeRegister

CUDBGResult (*writeUniformRegister) (uint32_t dev, uint32_t sm, uint32_t wp, uint32_t regno, uint32_t val)

Writes content to a uniform register.

Parameters

dev
- device index

sm
- SM index

wp
- warp index

regno
- register index

val
- buffer

Returns

CUDBG_SUCCESS, CUDBG_ERROR_INVALID_ARGS, CUDBG_ERROR_INVALID_DEVICE, CUDBG_ERROR_INVALID_SM, CUDBG_ERROR_INVALID_WARP, CUDBG_ERROR_UNINITIALIZED

Since CUDA 10.0.

See also:

writeRegister

readUniformRegisterRange

4.2. CUDBGCudaLogMessage Struct Reference

CUDA Log Message.

CUDBGCudaLogLevel CUDBGCudaLogMessage::logLevel

The log severity level of the message.

char CUDBGCudaLogMessage::message

The log message string.

uint32_t CUDBGCudaLogMessage::osThreadId

The OS thread ID of the thread that generated the log message.

uint64_t CUDBGCudaLogMessage::unixTimestampNs

The timestamp the log message was received at, in nanoseconds since the Unix epoch.

4.3. CUDBGEvent Struct Reference

Event information container.

CUDBGEvent::cases

Information for each type of event.

CUDBGEventKind CUDBGEvent::kind

Event type.

4.4. CUDBGEvent::cases_st Union Reference

struct CUDBGEvent::cases_st::contextCreate_st
CUDBGEvent::cases_st::contextCreate

Information about the context being created.

struct CUDBGEvent::cases_st::contextDestroy_st
CUDBGEvent::cases_st::contextDestroy

Information about the context being destroyed.

struct CUDBGEvent::cases_st::contextPop_st
CUDBGEvent::cases_st::contextPop

Information about the context being popped.

struct CUDBGEvent::cases_st::contextPush_st
CUDBGEvent::cases_st::contextPush

Information about the context being pushed.

struct CUDBGEvent::cases_st::elfImageLoaded_st
CUDBGEvent::cases_st::elfImageLoaded

Information about the loaded ELF image.

struct CUDBGEvent::cases_st::internalError_st
CUDBGEvent::cases_st::internalError

Information about internal erros.

struct CUDBGEvent::cases_st::kernelFinished_st
CUDBGEvent::cases_st::kernelFinished

Information about the kernel that just terminated.

struct CUDBGEvent::cases_st::kernelReady_st
CUDBGEvent::cases_st::kernelReady

Information about the kernel ready to be launched.

4.5. CUDBGEvent::cases_st::contextCreate_st Struct Reference

uint64_t CUDBGEvent::cases_st::contextCreate_st::context

the context being created.

uint32_t CUDBGEvent::cases_st::contextCreate_st::dev

device index of the context.

uint32_t CUDBGEvent::cases_st::contextCreate_st::tid

host thread id (or LWP id) of the thread hosting the context (Linux only).

4.6. CUDBGEvent::cases_st::contextDestroy_st Struct Reference

uint64_t CUDBGEvent::cases_st::contextDestroy_st::context

the context being destroyed.

uint32_t CUDBGEvent::cases_st::contextDestroy_st::dev

device index of the context.

uint32_t CUDBGEvent::cases_st::contextDestroy_st::tid

host thread id (or LWP id) of the thread hosting the context (Linux only).

4.7. CUDBGEvent::cases_st::contextPop_st Struct Reference

uint64_t CUDBGEvent::cases_st::contextPop_st::context

the context being popped.

uint32_t CUDBGEvent::cases_st::contextPop_st::dev

device index of the context.

uint32_t CUDBGEvent::cases_st::contextPop_st::tid

host thread id (or LWP id) of the thread hosting the context (Linux only).

4.8. CUDBGEvent::cases_st::contextPush_st Struct Reference

uint64_t CUDBGEvent::cases_st::contextPush_st::context

the context being pushed.

uint32_t CUDBGEvent::cases_st::contextPush_st::dev

device index of the context.

uint32_t CUDBGEvent::cases_st::contextPush_st::tid

host thread id (or LWP id) of the thread hosting the context (Linux only).

4.9. CUDBGEvent::cases_st::elfImageLoaded_st Struct Reference

uint64_t CUDBGEvent::cases_st::elfImageLoaded_st::context

context of the kernel.

uint32_t CUDBGEvent::cases_st::elfImageLoaded_st::dev

device index of the kernel.

uint64_t CUDBGEvent::cases_st::elfImageLoaded_st::handle

ELF image handle.

uint64_t CUDBGEvent::cases_st::elfImageLoaded_st::module

module of the kernel.

uint32_t CUDBGEvent::cases_st::elfImageLoaded_st::properties

ELF image properties.

uint64_t CUDBGEvent::cases_st::elfImageLoaded_st::size

size of the ELF image (64-bit).

4.10. CUDBGEvent::cases_st::internalError_st Struct Reference

CUDBGResult CUDBGEvent::cases_st::internalError_st::errorType

Type of the internal error.

4.11. CUDBGEvent::cases_st::kernelFinished_st Struct Reference

uint64_t CUDBGEvent::cases_st::kernelFinished_st::context

context of the kernel.

uint32_t CUDBGEvent::cases_st::kernelFinished_st::dev

device index of the kernel.

uint64_t CUDBGEvent::cases_st::kernelFinished_st::function

function of the kernel.

uint64_t CUDBGEvent::cases_st::kernelFinished_st::functionEntry

entry PC of the kernel.

uint64_t CUDBGEvent::cases_st::kernelFinished_st::gridId

grid index of the kernel.

uint64_t CUDBGEvent::cases_st::kernelFinished_st::module

module of the kernel.

uint32_t CUDBGEvent::cases_st::kernelFinished_st::tid

host thread id (or LWP id) of the thread hosting the kernel (Linux only).

4.12. CUDBGEvent::cases_st::kernelReady_st Struct Reference

CuDim3 CUDBGEvent::cases_st::kernelReady_st::blockDim

block dimensions of the kernel.

uint64_t CUDBGEvent::cases_st::kernelReady_st::context

context of the kernel.

uint32_t CUDBGEvent::cases_st::kernelReady_st::dev

device index of the kernel.

uint64_t CUDBGEvent::cases_st::kernelReady_st::function

function of the kernel.

uint64_t CUDBGEvent::cases_st::kernelReady_st::functionEntry

entry PC of the kernel.

CuDim3 CUDBGEvent::cases_st::kernelReady_st::gridDim

grid dimensions of the kernel.

uint64_t CUDBGEvent::cases_st::kernelReady_st::gridId

grid index of the kernel.

uint64_t CUDBGEvent::cases_st::kernelReady_st::module

module of the kernel.

uint64_t CUDBGEvent::cases_st::kernelReady_st::parentGridId

64-bit grid index of the parent grid.

uint32_t CUDBGEvent::cases_st::kernelReady_st::tid

host thread id (or LWP id) of the thread hosting the kernel (Linux only).

CUDBGKernelType CUDBGEvent::cases_st::kernelReady_st::type

the type of the kernel: system or application.

4.13. CUDBGEventCallbackData Struct Reference

Event information passed to callback set with setNotifyNewEventCallback function.

uint32_t CUDBGEventCallbackData::tid

Host thread id of the context generating the event. Zero if not available.

4.14. CUDBGEventCallbackData40 Struct Reference

Event information passed to callback set with setNotifyNewEventCallback function.

> Note:
>
> Deprecated in CUDA 4.1.

uint32_t CUDBGEventCallbackData40::tid

Host thread id of the context generating the event. Zero if not available.

4.15. CUDBGGridInfo Struct Reference

Grid info.

CuDim3 CUDBGGridInfo::blockDim

The block dimensions.

uint64_t CUDBGGridInfo::context

The context this grid belongs to.

uint32_t CUDBGGridInfo::dev

The index of the device this grid is running on.

uint64_t CUDBGGridInfo::function

The function corresponding to this grid.

uint64_t CUDBGGridInfo::functionEntry

The entry address of the function corresponding to this grid.

CuDim3 CUDBGGridInfo::gridDim

The grid dimensions.

uint64_t CUDBGGridInfo::gridId64

The 64-bit grid ID of this grid.

uint64_t CUDBGGridInfo::module

The module this grid belongs to.

CUDBGKernelOrigin CUDBGGridInfo::origin

The origin of this grid, CPU or GPU.

uint64_t CUDBGGridInfo::parentGridId

The 64-bit grid ID that launched this grid.

uint32_t CUDBGGridInfo::tid

The host thread ID that launched this grid.

CUDBGKernelType CUDBGGridInfo::type

The type of the grid.

Chapter 5. Data Fields

Here is a list of all documented struct and union fields with links to the struct/union documentation for each field:

A

acknowledgeEvent30
- cudbgGetAPI

acknowledgeEvents42
- cudbgGetAPI

acknowledgeSyncEvents
- cudbgGetAPI

B

blockDim
- CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::kernelReady_st
- CUDBGGridInfo

C

cases
- CUDBGEvent

clearAttachState
- cudbgGetAPI

consumeCudaLogs
- cudbgGetAPI

context
- CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::elfImageLoaded_st
- CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::contextPop_st
- CUDBGGridInfo
- CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::contextDestroy_st
- CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::contextCreate_st
- CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::kernelReady_st
- CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::contextPush_st
- CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::kernelFinished_st

contextCreate
CUDBGEvent::CUDBGEvent::cases_st
contextDestroy
CUDBGEvent::CUDBGEvent::cases_st
contextPop
CUDBGEvent::CUDBGEvent::cases_st
contextPush
CUDBGEvent::CUDBGEvent::cases_st

D

dev
CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::elfImageLoaded_st
CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::kernelReady_st
CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::contextPush_st
CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::contextDestroy_st
CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::contextCreate_st
CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::contextPop_st
CUDBGGridInfo
CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::kernelFinished_st
disassemble
cudbgGetAPI

E

elfImageLoaded
CUDBGEvent::CUDBGEvent::cases_st
errorType
CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::internalError_st

F

finalize
cudbgGetAPI
function
CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::kernelReady_st
CUDBGGridInfo
CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::kernelFinished_st
functionEntry
CUDBGGridInfo
CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::kernelReady_st
CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::kernelFinished_st

G

generateCoredump
cudbgGetAPI

getAdjustedCodeAddress
cudbgGetAPI
getBlockDim
cudbgGetAPI
getCbuWarpState
cudbgGetAPI
getClusterDim
cudbgGetAPI
getClusterDim120
cudbgGetAPI
getClusterExceptionTargetBlock
cudbgGetAPI
getConstBankAddress
cudbgGetAPI
getConstBankAddress123
cudbgGetAPI
getCudaExceptionString
cudbgGetAPI
getDeviceName
cudbgGetAPI
getDevicePCIBusInfo
cudbgGetAPI
getDeviceType
cudbgGetAPI
getElfImage
cudbgGetAPI
getElfImage32
cudbgGetAPI
getElfImageByHandle
cudbgGetAPI
getErrorStringEx
cudbgGetAPI
getGridAttribute
cudbgGetAPI
getGridAttributes
cudbgGetAPI
getGridDim
cudbgGetAPI
getGridDim32
cudbgGetAPI
getGridInfo
cudbgGetAPI

getGridInfo120
cudbgGetAPI
getGridInfo55
cudbgGetAPI
getGridStatus
cudbgGetAPI
getGridStatus50
cudbgGetAPI
getHardwareBarrierInfo
cudbgGetAPI
getHostAddrFromDeviceAddr
cudbgGetAPI
getLoadedFunctionInfo
cudbgGetAPI
getLoadedFunctionInfo118
cudbgGetAPI
getManagedMemoryRegionInfo
cudbgGetAPI
getNextAsyncEvent50
cudbgGetAPI
getNextAsyncEvent55
cudbgGetAPI
getNextEvent
cudbgGetAPI
getNextEvent30
cudbgGetAPI
getNextEvent32
cudbgGetAPI
getNextEvent42
cudbgGetAPI
getNextSyncEvent50
cudbgGetAPI
getNextSyncEvent55
cudbgGetAPI
getNumDevices
cudbgGetAPI
getNumLanes
cudbgGetAPI
getNumPredicates
cudbgGetAPI
getNumRegisters
cudbgGetAPI

getNumSMs
cudbgGetAPI
getNumUniformPredicates
cudbgGetAPI
getNumUniformRegisters
cudbgGetAPI
getNumWarps
cudbgGetAPI
getPhysicalRegister30
cudbgGetAPI
getPhysicalRegister40
cudbgGetAPI
getSmType
cudbgGetAPI
getSupportedDebuggerCapabilities
cudbgGetAPI
getTID
cudbgGetAPI
gridDim
CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::kernelReady_st
CUDBGGridInfo
gridId
CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::kernelFinished_st
CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::kernelReady_st
gridId64
CUDBGGridInfo

H

handle
CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::elfImageLoaded_st

I

initialize
cudbgGetAPI
initializeAttachStub
cudbgGetAPI
internalError
CUDBGEvent::CUDBGEvent::cases_st
isDeviceCodeAddress
cudbgGetAPI
isDeviceCodeAddress55
cudbgGetAPI

K

kernelFinished
CUDBGEvent::CUDBGEvent::cases_st
kernelReady
CUDBGEvent::CUDBGEvent::cases_st
kind
CUDBGEvent

L

logLevel
CUDBGCudaLogMessage
lookupDeviceCodeSymbol
cudbgGetAPI

M

memcheckReadErrorAddress
cudbgGetAPI
message
CUDBGCudaLogMessage
module
CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::kernelFinished_st
CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::kernelReady_st
CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::elfImageLoaded_st
CUDBGGridInfo

O

origin
CUDBGGridInfo
osThreadId
CUDBGCudaLogMessage

P

parentGridId
CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::kernelReady_st
CUDBGGridInfo
properties
CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::elfImageLoaded_st

R

readActiveLanes
cudbgGetAPI

readAllVirtualReturnAddresses
cudbgGetAPI
readBlockIdx
cudbgGetAPI
readBlockIdx32
cudbgGetAPI
readBrokenWarps
cudbgGetAPI
readCallDepth
cudbgGetAPI
readCallDepth32
cudbgGetAPI
readCCRegister
cudbgGetAPI
readClusterIdx
cudbgGetAPI
readCodeMemory
cudbgGetAPI
readConstMemory129
cudbgGetAPI
readCPUCallStack
cudbgGetAPI
readDeviceExceptionState
cudbgGetAPI
readDeviceExceptionState80
cudbgGetAPI
readErrorPC
cudbgGetAPI
readGenericMemory
cudbgGetAPI
readGlobalMemory
cudbgGetAPI
readGlobalMemory31
cudbgGetAPI
readGlobalMemory55
cudbgGetAPI
readGridId
cudbgGetAPI
readGridId50
cudbgGetAPI
readLaneException
cudbgGetAPI

readLaneStatus
cudbgGetAPI
readLocalMemory
cudbgGetAPI
readParamMemory
cudbgGetAPI
readPC
cudbgGetAPI
readPinnedMemory
cudbgGetAPI
readPredicates
cudbgGetAPI
readRegister
cudbgGetAPI
readRegisterRange
cudbgGetAPI
readReturnAddress
cudbgGetAPI
readReturnAddress32
cudbgGetAPI
readSharedMemory
cudbgGetAPI
readSmException
cudbgGetAPI
readSyscallCallDepth
cudbgGetAPI
readTextureMemory
cudbgGetAPI
readTextureMemoryBindless
cudbgGetAPI
readThreadIdx
cudbgGetAPI
readUniformPredicates
cudbgGetAPI
readUniformRegisterRange
cudbgGetAPI
readValidLanes
cudbgGetAPI
readValidWarps
cudbgGetAPI
readVirtualPC
cudbgGetAPI

readVirtualReturnAddress
cudbgGetAPI
readVirtualReturnAddress32
cudbgGetAPI
readWarpResources
cudbgGetAPI
readWarpState
cudbgGetAPI
readWarpState120
cudbgGetAPI
readWarpState127
cudbgGetAPI
readWarpState60
cudbgGetAPI
requestCleanupOnDetach
cudbgGetAPI
requestCleanupOnDetach55
cudbgGetAPI
resumeDevice
cudbgGetAPI
resumeWarpsUntilPC
cudbgGetAPI

S

setBreakpoint
cudbgGetAPI
setBreakpoint31
cudbgGetAPI
setKernelLaunchNotificationMode
cudbgGetAPI
setNotifyNewEventCallback
cudbgGetAPI
setNotifyNewEventCallback31
cudbgGetAPI
setNotifyNewEventCallback40
cudbgGetAPI
setNotifyNewEventCallback41
cudbgGetAPI
singleStepWarp
cudbgGetAPI
singleStepWarp40
cudbgGetAPI

singleStepWarp41
cudbgGetAPI
size
CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::elfImageLoaded_st
suspendDevice
cudbgGetAPI

T

tid
CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::kernelReady_st
CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::kernelFinished_st
CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::contextPop_st
CUDBGEventCallbackData
CUDBGGridInfo
CUDBGEventCallbackData40
CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::contextDestroy_st
CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::contextCreate_st
CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::contextPush_st
type
CUDBGEvent::CUDBGEvent::cases_st::CUDBGEvent::cases_st::kernelReady_st
CUDBGGridInfo

U

unixTimestampNs
CUDBGCudaLogMessage
unsetBreakpoint
cudbgGetAPI
unsetBreakpoint31
cudbgGetAPI

W

writeCCRegister
cudbgGetAPI
writeGenericMemory
cudbgGetAPI
writeGlobalMemory
cudbgGetAPI
writeGlobalMemory31
cudbgGetAPI
writeGlobalMemory55
cudbgGetAPI
writeLocalMemory
cudbgGetAPI

writeParamMemory
cudbgGetAPI
writePinnedMemory
cudbgGetAPI
writePredicates
cudbgGetAPI
writeRegister
cudbgGetAPI
writeSharedMemory
cudbgGetAPI
writeUniformPredicates
cudbgGetAPI
writeUniformRegister
cudbgGetAPI

Notice

This document is provided for information purposes only and shall not be regarded as a warranty of a certain functionality, condition, or quality of a product. NVIDIA Corporation ("NVIDIA") makes no representations or warranties, expressed or implied, as to the accuracy or completeness of the information contained in this document and assumes no responsibility for any errors contained herein. NVIDIA shall have no liability for the consequences or use of such information or for any infringement of patents or other rights of third parties that may result from its use. This document is not a commitment to develop, release, or deliver any Material (defined below), code, or functionality.

NVIDIA reserves the right to make corrections, modifications, enhancements, improvements, and any other changes to this document, at any time without notice.

Customer should obtain the latest relevant information before placing orders and should verify that such information is current and complete.

NVIDIA products are sold subject to the NVIDIA standard terms and conditions of sale supplied at the time of order acknowledgement, unless otherwise agreed in an individual sales agreement signed by authorized representatives of NVIDIA and customer ("Terms of Sale"). NVIDIA hereby expressly objects to applying any customer general terms and conditions with regards to the purchase of the NVIDIA product referenced in this document. No contractual obligations are formed either directly or indirectly by this document.

OpenCL

OpenCL is a trademark of Apple Inc. used under license to the Khronos Group Inc.

Trademarks

NVIDIA and the NVIDIA logo are trademarks or registered trademarks of NVIDIA Corporation in the U.S. and other countries. Other company and product names may be trademarks of the respective companies with which they are associated.

Copyright

© 2007-2024 NVIDIA Corporation & affiliates. All rights reserved.

NVIDIA Corporation | 2788 San Tomas Expressway, Santa Clara, CA 95051
https://www.nvidia.com