



Appendix – SM Default Files

The SM default files are located under the following paths:

- Default SM configuration file – /opt/ufm/files/conf/opensm/opensm.conf
- Default node name map file – /opt/ufm/files/conf/opensm/ib-node-name-map
- Default partition configuration file – /opt/ufm/files/conf/opensm/partitions.conf
- Default QOS policy configuration file – /opt/ufm/files/conf/opensm/qos-policy.conf
- Default prefix routes file – /opt/ufm/files/conf/opensm/prefix-routes.conf

Copyright 2024. PDF Generated on 08/14/2024