



Data Streaming

This section allows users to configure System Logs settings via web UI.

Data Streaming Configurations

System Logs

Status

Disabled

Enabled

Mode

Local

Remote

Destination

:

System logs level

Warning
▼

Streaming Data

UFM logs
 Event logs (allows selecting which events to stream from [Events policy](#))

Save

Field	Description
Status	Enable/disable exporting UFM logs to system logs
Mode	Export logs to local or remote system logs
Destination	Remote server IP/hostname and port
System Logs Level	Log level to export
Streaming Data	Logs to export to system logs. <div style="background-color: #fff9c4; padding: 10px; margin-top: 10px;"> <p>Note</p> </div>

Field	Description
	Events logs are selected one by one from Events Policy settings when the system logs feature is enabled.

Copyright 2024. PDF Generated on 06/06/2024