

# **NVIDIA DGX B200 Service Manual**

**NVIDIA Corporation** 

May 28, 2025

## Contents

1	Introd 1.1 1.2 1.3 1.4	duction Customer-replaceable Components Recommended Tools Customer Support Running the Pre-flight Test	<b>3</b> 4 4 5
2	<b>Remo</b> 2.1 2.2	wing and Attaching the Bezel Bezel Removal	<b>7</b> 7 8
3	Powe 3.1 3.2 3.3 3.4 3.5	r Supply Replacement Power Supply Replacement Overview	<b>11</b> 11 15 16 18
4	<b>Front</b> 4.1 4.2 4.3	Fan Module ReplacementFront Fan Module Replacement OverviewIdentifying a Failed Fan ModuleReplacing and Returning the Front Fan Module	<b>19</b> 19 19 22
5	<b>Front</b> 5.1 5.2	Console Board Replacement         Front Console Board Replacement Overview         Front Console Board Replacement	
6	Moth 6.1 6.2 6.3 6.4 6.5 6.6 6.7 6.8	Pull the Motherboard from the ChassisOpen the Motherboard I/O DoorClose the Motherboard I/O DoorLock the Motherboard LidInsert the Motherboard	30 31 32 33 34
7	Moth 7.1 7.2 7.3 7.4 7.5 7.6 7.7	Release the MotherboardPull the Motherboard from the ChassisRemove the Motherboard Tray LidClose the Motherboard Tray LidInsert the Motherboard Tray into the Chassis	

7.8	Finalize Motherboard Closing	46
8 U.2 N 8.1 8.2 8.3 8.4 8.5 8.6	U.2 NVMe Cache Drive Replacement Overview	<b>47</b> 47 48 48 49 50
<b>9 U.2 N</b> 9.1	IVMe Cache Drive Post-Installation Tasks Re-creating the RAID Arrays	<b>51</b> 51
<b>10 M.2</b> 10.1 10.2 10.3 10.4 10.5 10.6 10.7	M.2 NVMe Boot Drive Replacement OverviewIdentify the Failed M.2 DriveRemove the M.2 Boot Drive CarrierRemove the M.2 DriveReplace the M.2 DriveInstall the M.2 Boot Drive Carrier and Close the System	<b>53</b> 54 54 57 59 60 62
11 M.2 11.1 11.2 11.3 11.4 11.5	M.2 Boot Drive Riser Assembly Replacement OverviewPreparing the System for ReplacementRemove the M.2 Boot Drive CarrierInstall the M.2 Boot Drive Carrier and Close the System	<b>63</b> 64 64 66 68
12 Conr 12.1 12.2 12.3 12.4 12.5 12.6 12.7 12.8 12.9	ConnectX-7 I/O Card Replacement Overview	73 74
<b>13 Netv</b> 13.1 13.2 13.3 13.4 13.5	Network Card Replacement Overview         Prepare the System for Replacement         Remove the Non-Functional Card         Install the New Card and Close the Lock	<b>77</b> 77 78 79 80
14 Upda	ating the ConnectX-7 Firmware	81
15 Blue 15.1 15.2 15.3 15.4 15.5	• •	84 84

15.6 15.7 15.8	Install the BlueField-3 Card       Install the I/O Card and Close the System       Install the I/O Card and Close the System         Power on the System and Confirm the Replacement       Install the I/O Card and Close the System	88
16 DIMN 16.1 16.2 16.2 16.2 16.2	DIMM Upgrade Procedure       8         DIMM Replacement Overview       8         1       Identifying the Failed DIMM         2       Replacing the DIMM	<b>89</b> 89 90 90 92
17 Moth 17.1 17.2 17.3 17.4 17.5 17.6 17.7 17.8 17.9 17.10 17.11	Motherboard Tray Battery Replacement Overview       9         Identify a Failed Battery       9	94 94 96 97 98 99 00 01
18 Trust 18.1 18.2 18.3 18.4 18.5	Trusted Platform Module Replacement10Trusted Platform Module Replacement Overview10Prepare the System for Replacement10Replace the TPM Module10Install the OSFP Carrier Module10Finalize the TPM Replacement10	06 06 08
<b>19 Rack</b> 19.1 19.2 19.3 19.4 19.5 19.6 19.7	Mount Kit Replacement1Rack Mount Kit Description1Remove Rack Mount Kit - Front1Remove Rack Mount Kit - Rear1Confirm Necessary Screws and Washers1Install Cage Nuts Using Template1Install Rack Mount Kit - Front1Install Rack Mount Kit - Rear1	12 13 15 16 17
20.1	Safety Information       12         Safety Warnings and Cautions       12         Intended Application Uses       12         Site Selection       12         Equipment Handling Practices       12         Electrical Precautions       12         5.1       Power and Electrical Warnings       12	21 23 24 24 25 25 26 27 27

	D.3 Battery Replacement127D.4 Cooling and Airflow128
21 Comp	liance 129
21.1	United States
21.2	United States/Canada
21.3	Canada
21.4	CE
21.5	Australia and New Zealand
21.6	Brazil
21.7	Japan
21.8	South Korea
21.9	China
21.10	Taiwan
21.11	Russia/Kazakhstan/Belarus
21.12	Israel
21.13	India
21.14	South Africa
21.15	Great Britain (England, Wales, and Scotland)
22 Third	-Party License Notices 139
22.1	Micron msecli
22.2	Mellanox (OFED)
23 Notic	es 141
23.1	Notice
23.2	Trademarks

The NVIDIA DGX B200 Service Manual is also available as a PDF.

# Chapter 1. Introduction

This topic contains instructions for replacing the NVIDIA DGX<sup>™</sup> B200 system components. Make sure to familiarize yourself with the NVIDIA Terms and Conditions documents before attempting to perform any modification or repair to the DGX B200 system. These Terms and Conditions for the DGX B200 system can be found through the NVIDIA DGX Systems Support page.

Contact NVIDIA Enterprise Support to obtain an RMA number for any system or component that needs to be returned for repair or replacement. When replacing a component, use only the replacement supplied to you by NVIDIA.

## 1.1. Customer-replaceable Components

List of customer-replaceable components in the DGX B200 system.

Be sure to familiarize yourself with the NVIDIA Terms & Conditions documents before attempting to perform any modification or repair to the DGX B200 system. These Terms & Conditions for the DGX B200 system can be found through the NVIDIA DGX Systems Support page.

#### **Customer Replaceable Units**

Contact NVIDIA Enterprise Support to obtain an RMA number for any system or component that needs to be returned for repair or replacement. When replacing a component, use only the replacement supplied to you by NVIDIA.

You can obtain the following components for replacement in your data center.

- Bezel
- Locking power cords
- Power supply
- ► Fan module
- Front Console Board
- U.2 data drive
- M.2 boot (OS) storage drive
- Riser assembly with 2 M.2 drives
- ConnectX-7 PCI card (Storage Network)
- 50 Gb Ethernet NIC replacement
- DIMMs

- Rackmount kit
- Trusted Platform Module
- Battery

Contact NVIDIA Enterprise Support for replacement instructions and guidance for specific components if those instructions are not included in this document.

## 1.2. Recommended Tools

Here are the tools that are required for the procedures outlined in the presentation. Each procedure will indicate which tool is needed for the different actions.

#### Important

Hearing protection is mandatory when working with or in the vicinity of this equipment

- Laptop
- USB key with tools and drivers
- USB key imaged with the DGX Server OS ISO
- Screwdrivers
  - Phillips #1
  - Phillips #2
  - ► Torx T15
  - ► Torx T10
- KVM Crash Cart
- Electro Static Discharge strap and/or mat
- Masking tape or label maker
- ▶ Tie wraps or VELCRO<sup>®</sup> Brand for cable management
- Box cutter
- Black Permanent Marker or Labels/labeler for cable identification
- Packing materials

## 1.3. Customer Support

Contact NVIDIA Enterprise Support for assistance in reporting, troubleshooting, or diagnosing problems with your DGX B200 system. Also contact NVIDIA Enterprise Support for assistance in installing or moving the DGX B200 system.

For details on how to obtain support, visit the NVIDIA Enterprise Support web site (https://www.nvidia. com/en-us/support/enterprise/).

## 1.4. Running the Pre-flight Test

Instructions for running the DGX stress test.

NVIDIA recommends running the pre-flight stress test before putting a system into a production environment or after servicing. You can specify running the test on the GPUs, CPU, memory, and storage, and also specify the duration of the tests.

To run the tests, use NVSM.

#### Syntax:

<pre>sudo nvsm stress-test [usage] [force</pre>	<pre>[no-prompt] [<test>] [DURATION]</test></pre>
-------------------------------------------------	---------------------------------------------------

For help on running the test, issue the following.

sudo nvsm stress-test --usage

#### **Recommended Command**

The following command runs the test on all supported components (GPU, CPU, memory, and storage), and takes approximately 20 minutes.

```
sudo nvsm stress-test --force
```

# Chapter 2. Removing and Attaching the Bezel

## 2.1. Bezel Removal

1. Grab the bezel on both sides by the side handles.



2. Pull the bezel away from the system with a horizontal motion to release it from the magnets that keep it in place.



## 2.2. Bezel Installation

1. Align the pins on the bezel to the notches on the system fascia.



2. Attach the bezel to the system, ensuring that the pins fit in the notches and that the magnetic latch holds the bezel securely in place.



# Chapter 3. Power Supply Replacement

## 3.1. Power Supply Replacement Overview

This is a high-level overview of the procedure to replace a power supply on the NVIDIA DGX  $^{\rm M}$  B200 system.

- 1. Identify the broken power supply by the amber color LED or the power supply number.
- 2. Request a replacement from NVIDIA Enterprise Support.
- 3. Remove the locking power cord from the power supply.
- 4. Replace the power supply.
- 5. Install the locking power cord.
- 6. Confirm that both LEDs light up green on the power supply.
- 7. Ensure the BMC reports no power supply failures.
- 8. If requested, send the failed unit to NVIDIA Enterprise Support using the packaging provided.

## 3.2. Identifying the Failed Power Supply


You can identify a failed power supply using any of the following methods:

- ▶ Run the sudo nvsm show health command to identify the failed power supply.
- > Access the BMC Web User Interface and select **Sensors** from the left-side navigation menu bar.
- ▶ From the console, run the ipmitool sdr | grep -i psu command.

Note which power supply has no temperature reading or an irregular output reading (close to or equal to zero).

Contact NVIDIA Enterprise Support to request a replacement. The team might ask for this or similar information to confirm that the power supply needs to be replaced.

The nvsm command output and the BMC web user interface identify each power supply as PSUx, where x is 0 to 5. The following diagram shows the physical location of each PSU.



#### Viewing the Power Supply LEDs

> Access the rear of the system and view the status LEDs while the system is powered on.



If the PSU is good, both LEDs should be solid green. If either of the LEDs is not green or blinks, contact NVIDIA Enterprise Support to troubleshoot the issue.

#### **Running the show psus Command**

> Run the following command to display information about the PSUs:

sudo  $n\nu \text{sm}$  show psus

The output shows information for each PSU. Look for any that do not report Status\_Health=OK.

#### Viewing PSUs from the BMC Web User Interface

- 1. Access the BMC web user interface and select **Sensors** from the left-side navigation menu bar.
  - ► Confirm PSU presence:

B PSU0 STATUS	Presence Detected
B PSU1 STATUS	Presence Detected
B PSU2 STATUS	Presence Detected
PSU3 STATUS	Presence Detected
PSU4 STATUS	Presence Detected
PSU5 STATUS	Presence Detected

#### Confirm power output:

B PWR_PSU0	182.000 Watts
B PWR_PSU1	182.000 Watts
B PWR_PSU2	351.000 Watts
PWR_PSU3	351.000 Watts
B PWR_PSU4	260.000 Watts
B PWR_PSU5	351.000 Watts

► Confirm fan speeds:

♣ SPD_FAN_PSU0_F	7040 Rpm
♣ SPD_FAN_PSU0_R	5500 Rpm
♣ SPD_FAN_PSU1_F	6930 Rpm
♣ SPD_FAN_PSU1_R	5280 Rpm
A SPD FAN PSU2 F	7040 Hpm
♣ SPD_FAN_PSU2_R	5610 Rpm
♣ SPD_FAN_PSU3_F	7040 Rpm
♣ SPD_FAN_PSU3_R	5390 Rpm
♣ SPD_FAN_PSU4_F	7040 Rpm
♣ SPD FAN PSU4 R	5060 Rpm
* SPD_FAN_PSU5_F	7040 Rpm
* SPD_FAN_PSU5_R	5060 Rpm

#### ► Confirm the PSU temperature readings:

L TEMP_PSU0	26.000 °C
L TEMP_PSU1	27.000 °C
L TEMP_PSU2	30.000 °C
L TEMP_PSU3	29.000 °C
L TEMP_PSU4	29.000 °C
L TEMP_PSU5	27.000 °C

2. Run the ipmitool command to view information about the PSUs:

```
sudo ipmitool sdr | grep -i psu
```

Look for power supplies with no temperature or output reading close to or equal to zero.

#### Determining the Manufacturer

All PSUs in the system must be from the same manufacturer.	

▶ Run the following nvsm command to determine the PSU manufacturer:

sudo nvsm show /chassis/localhost/power/PSUx

Replace x in the preceding command with the PSU identifier.

Example output:

The following output is for PSUO and shows that the manufacturer is Delta.


```
/chassis/localhost/power/PSU0
Properties:
    FirmwareVersion = 02.02.02.01.02.02
    LastPowerOutputWatts = 0
    Manufacturer = Delta
    MemberId = PSU0
    Model = ECD16020137
    Name = PSU0
    Oem_PSU_Error = Presence detected | Power Supply AC Lost | AC Lost or
→out-of-range
    PowerSupplyType = AC
    SerialNumber = DTHTCT2233078
    Status_Health = Critical
    Status_State = Present
Targets:
Verbs:
    cd
    show
```


Obtain the replacement PSU (of the same manufacturer) from NVIDIA Enterprise Support.

# 3.3. Preparing the Power Supply for Replacement

- 1. After the new power supply arrives, look at the system and identify which needs to be replaced.
- If the system is on, ensure at least five power supplies are fully functional by confirming the IN and OUT LEDs are lit green.

The system can operate at full capacity with five fully functional power supplies.





3. Unplug the power cord from the failed power supply, following the instructions described in *Lock-ing Power Cords*.

Before replacing the power supply, remove the locking power cable.

## 3.4. Replacing the Power Supply

1. Remove the power supply by pressing the green tab to unlock the unit, and then pull on the black handle.

### 😤 Caution

Once the power supply is out of the chassis, replace it with the new power supply in less than 30 seconds to avoid airflow disruptions in the system - especially if it is up and running.



2. Replace the power supply with the new unit making sure the green tab locks into place.



- 3. Install the locking power cord.
- 4. Confirm that both the IN and OUT LEDs light up green on the new power supply.
- 5. Ensure that the BMC Web UI reports no power supply failures.
- 6. Run the sudo nvsm show health command and confirm that the output does not report any

errors.

7. After the replacement is complete, return the failed power supply to NVIDIA Enterprise Support using the provided packaging.

## 3.5. Locking Power Cords

To use the twisting locking power cords that ship with the system:

- > On the power distribution unit (PDU) side
  - 1. To insert, push the cable into the PDU socket.
  - 2. To remove, press the clips on both sides simultaneously to pull the cord out of the socket.
- ▶ On the power supply side
  - 1. Ensure the cable is unlocked:
    - ▶ To insert, push the cable into the socket.
    - ▶ To remove, pull the cable out of the socket.
  - 2. To unlock the power cord, twist the gray locking ring to the unlocked position. The indicator will show an unlocked padlock.
  - 3. To lock the power cord, twist the gray locking ring to the locked position.

The indicator will show a closed padlock.



Power Distribution Unit side

. To INSERT, just push the cable into the PDU socket

To REMOVE, press the clips together and pull the cord out of the socket



#### Power Supply (System) side

To INSERT or REMOVE make sure the cable is UNLOCKED and push/pull into/out of the socket

To UNLOCK the power cord, twist the gray locking ring to the unlocked position (indicator will show unlocked padlock)

To LOCK the power cord, twist the gray locking ring to the locked position (indicator should show closed padlock)

## Chapter 4. Front Fan Module Replacement

## 4.1. Front Fan Module Replacement Overview

This is a high-level overview of the procedure to replace the front fan modules on the NVIDIA DGX™ B200 system.

- 1. Identify the failed front fan module through BMC or with the fan module LED and submit a service ticket.
- 2. Get a replacement from NVIDIA Enterprise Support.
- 3. Remove the failed fan module.
- 4. Insert new fan module.
- 5. Confirm that the new fan module works correctly through the BMC or the operating system tools.
- 6. Return the failed unit to NVIDIA Enterprise Support using the packaging provided.

## 4.2. Identifying a Failed Fan Module

You can identify a failed fan module using one of the following methods:

- ▶ Remove the system bezel and visually inspect the fan module LEDs.
- ▶ Run the nvsm show fans command and view the command output.
- Access the BMC Web User Interface and view the sensor data from the fans. If a fan runs at an abnormal speed, that fan needs to be replaced.

#### Viewing the Fan Module LEDs

1. Expose the fan modules following the instructions in *Removing and Attaching the Bezel*.

After you remove the bezel, the system looks like the following figure.



2. Identify the failed fan using the fan module fault LED, as shown in the following figure.



3. Look for the fault LED lit in the upper right corner of the faulty fan module, as shown in the following figure.



#### Running the nvsm command

From the operating system, run:

sudo nvsm show fans

View the command output for alerts, failures, or an unhealthy status.

#### Viewing Fan Modules from the BMC Web User Interface

- 1. Identify the faulty fan module using the BMC dashboard.
- 2. Log on to the BMC.
- 3. Select **Sensor** from the left-side navigation menu.
- 4. Review the Normal Sensors section.
- 5. Look for abnormal fan speeds in the right column.

SPD_FAN_SYS0_F	3654 Rpm
SPD_FAN_SYSO_R	3248 Rpm
SPD_FAN_SYS1_F	3654 Rpm
SPD_FAN_SYS1_R	3248 Rpm
SPD_FAN_SYS2_F	3654 Rpm
SPD_FAN_SYS2_R	3248 Rpm
SPD_FAN_SYS3_F	3654 Rpm
SPD_FAN_SYS3_R	3248 Rpm
SPD_FAN_SYS4_F	4408 Rpm
♣ SPD_FAN_SYS4_R	3886 Rpm
♣ SPD_FAN_SYS4_R ♣ SPD_FAN_SYS5_F	3886 Rpm 4408 Rpm
SPD_FAN_SYS5_F	4408 Rpm
♣ SPD_FAN_SYS5_F ♣ SPD_FAN_SYS5_R	4408 Rpm 3886 Rpm
♣ SPD_FAN_SYS5_F ♣ SPD_FAN_SYS5_R ♣ SPD_FAN_SYS6_F	4408 Rpm 3886 Rpm 4408 Rpm

The fan module has two fans, identified by SPD\_FAN\_SYSn\_F and SPD\_FAN\_SYSn\_R, where n is the module ID. If either fan fails, the entire module must be replaced.

6. Use the nvsm command to confirm the fan issue.

sudo nvsm show fans

View the output and confirm that the status is unhealthy for the same fan.

# 4.3. Replacing and Returning the Front Fan Module

- 1. Remove the new fan module from its packaging and be ready to install it.
- 2. Expose the fan modules following the instructions in *Removing and Attaching the Bezel*.
- 3. To remove the failed fan module, unlock the fan module by pressing the release button and then pull the module out of the chassis.



4. Replace the failed fan module with the new one.

### Important

Replace the old fan with the new one within 30 seconds to prevent overheating.



- 5. Confirm that the fan module is healthy and working correctly by performing the following tasks:
  - ▶ Use the BMC Web User Interface.
  - ▶ Verify that the amber LED on the fan module is extinguished.

- ▶ Run the sudo nvsm show fans command.
- ► Install the bezel as described in *Removing and Attaching the Bezel*.

Return the failed fan module to NVIDIA Enterprise Support using the packaging from the new fan module.

## Chapter 5. Front Console Board Replacement

## 5.1. Front Console Board Replacement Overview

This is a high-level overview of the procedure to replace the front console board on the NVIDIA DGX™ B200 system.

- 1. Unpack the new front console board.
- 2. Shut down the system.
- 3. Remove the bezel.
- 4. Use a Philips #2 screwdriver to loosen the captive screws on the front console board and pull the front console board out of the system.
- 5. Insert the new front console board.
- 6. Tighten the screws.
- 7. Power on the system and confirm the ports work.
- 8. Install the bezel.
- 9. Return the failed unit to NVIDIA Enterprise Support.

## 5.2. Front Console Board Replacement

You can diagnose a front console board malfunction using the following methods:

- No display or connectivity occurs after you plug in a keyboard and monitor to the front of the system.
- ▶ The USB ports do not work.
- > The front temperature sensor does not provide a temperature reading.

Contact NVIDIA Enterprise Services to request a replacement.

When the new board arrives, unpack it and keep the packaging to send back the old board.

#### 🚼 Caution

**Static Sensitive Devices**: Be sure to observe the best practices for electrostatic discharge (ESD) protection. This includes ensuring personnel and equipment are connected to a common ground, such as by wearing a wrist strap connected to the chassis ground and placing components on static-free work surfaces.

- 1. Power down the system.
- 2. Remove the bezel. For more information, refer to *Removing and Attaching the Bezel*.
- 3. Replace the front console board.
  - 1. Using a Phillips #2 screwdriver, loosen the two captive screws that secure the front console board:



2. Replace the front console board:



3. Tighten the screws:



- 4. Confirm functionality:
  - 1. Power on the system and confirm that the ports work correctly.
  - 2. Run sudo nvsm show health to verify that the temperature sensor is working properly
  - 3. Replace the bezel as described in *Removing and Attaching the Bezel*.
- 5. Send the failed unit to NVIDIA Enterprise Support using the packaging provided.

# Chapter 6. Motherboard Tray - Opening and Closing the I/O Door

You will need to completely remove the motherboard tray from the server to service the following components. If this is the case, refer to the section that describes the procedure for removing the motherboard.

- DIMMs (either adding or replacing)
- Trusted Platform Module (TPM)

## 6.1. Preparing the Motherboard for Service


Before pulling the motherboard out of the system, the system must be shut down and cables must be removed from the system.

#### 😤 Caution

Wear an ESD strap during any procedure that involves touching electronic components.

- 1. Shut down the system.
- 2. To avoid misconfigurations, label all the cables before unplugging them.


Label all network, monitor, and USB cables.



- 3. Unplug all power cords.
- 4. Unplug all network, monitor, and USB cables.

## 6.2. Release the Motherboard

1. Unlock the motherboard by loosening the captive screws that hold the ejection levers in place:



2. Pull the ejection levers to disengage the midplane connectors:



### 6.3. Pull the Motherboard from the Chassis

- 1. Pull the motherboard out until the locking mechanism in the lid engages and prevents further movement.
- 2. Unscrew the thumbscrews indicated by the green arrows in the following figure to release the lid from the motherboard tray:




3. Lift the lid I/O section so that it can be folded:




### 6.4. Open the Motherboard I/O Door

1. Fold the lid I/O opening section as shown in the following figure:



2. Secure the folding section until it stays in place so you can work on the I/O section of the motherboard:




#### 6.5. Close the Motherboard I/O Door

- 1. Before closing the lid, ensure all components are correctly installed and nothing is blocking the lid.
- 2. Slide the lid as shown in the following figure to close the motherboard I/O section:



#### 6.6. Lock the Motherboard Lid

1. Close the lid so that you can lock it in place:



2. Use the thumbscrews indicated in the following figure to secure the lid to the motherboard tray. Open the tray levers:




3. Push the motherboard tray into the system chassis until the levers on both sides engage with the sides.

#### 6.7. Insert the Motherboard

1. Use the levers to engage the midplane connectors:



2. After the levers are fully closed, tighten the green thumbscrews to hold the ejection levers in place:



#### 6.8. Finalize Motherboard Closing

1. Use the labels on the cables to reconnect them to the correct ports.



- 2. Install all power cords.
- 3. Power on the system.

# Chapter 7. Motherboard Tray - Removal and Installation

You will need to completely remove the motherboard tray from the server to service the following components.

- DIMMs (either adding or replacing)
- Trusted Platform Module (TPM)

#### 7.1. Preparing the Motherboard for Service


Before pulling the motherboard out of the system, the system must be shut down and cables must be removed from the system.

#### 😤 Caution

Wear an ESD strap during any procedure that involves touching electronic components.

- 1. Shut down the system.
- 2. To avoid misconfigurations, label all the cables before unplugging them.


Label all network, monitor, and USB cables.



- 3. Unplug all power cords.
- 4. Unplug all network, monitor, and USB cables.

#### 7.2. Release the Motherboard

1. Unlock the motherboard by loosening the captive screws that hold the ejection levers in place:




2. Pull the ejection levers to disengage the midplane connectors:



### 7.3. Pull the Motherboard from the Chassis

Ensure that you have a solid, flat surface to rest the motherboard tray.

- 1. Pull the motherboard tray out until the locking mechanism in the lid engages and prevents further movement.
- 2. Push down on the buttons identified in the following figure to release the motherboard tray:



3. Pull the motherboard tray out of the chassis completely:



- > Do not hold the motherboard tray by the ejection handles. The handles can bend or break.
- Be careful with the connectors at the back of the module to prevent damage.
- 4. Place the motherboard tray on a solid, flat surface.

#### 7.4. Remove the Motherboard Tray Lid


1. Loosen the two screws on the port side of the motherboard tray, as shown in the following figure:




2. Loosen the two screws on the connector side of the motherboard tray, as shown in the following figure:



- 3. To remove the tray lid, perform the following steps:
  - 1. Lift on the connector side of the tray lid so that you can push it forward to release it from the tray.
  - 2. After the triangular markers align, lift the tray lid to remove it.



4. (Optional) Depending on the procedure being performed, remove the air baffles from the motherboard.



#### 7.5. Close the Motherboard Tray Lid

Before you perform the following steps, ensure that all components are installed correctly so that they do not interfere with the air baffles or tray lid.

1. Insert the motherboard tray baffles and then place the tray lid over the motherboard tray.



- 2. To close the tray lid, perform the following steps:
  - 1. Position the tray lid correctly by aligning the markers, as shown in the following figure.
  - 2. Push the tray lid toward the I/O section of the tray until the folding section is flush.
  - 3. Press the folding section down so that the thumbscrews align with the screw holes.



3. Tighten the two lid screws on the port side of the motherboard tray, as shown in the following figure:



4. Tighten the two lid screws on the connector side of the motherboard tray, as shown in the following figure:



## 7.6. Insert the Motherboard Tray into the Chassis

1. Insert the motherboard tray into the chassis partially. Open the ejection levers before you insert the motherboard tray into the chassis:



2. Push the motherboard tray into the chassis until the levers on both sides engage with the sides:




#### 7.7. Insert the Motherboard

1. Use the levers to engage the midplane connectors:



2. After the levers are fully closed, tighten the green thumbscrews to hold the ejection levers in place:



#### 7.8. Finalize Motherboard Closing

1. Use the labels on the cables to reconnect them to the correct ports.



- 2. Install all power cords.
- 3. Power on the system.

## Chapter 8. U.2 NVMe Cache Drive Replacement

#### 8.1. U.2 NVMe Cache Drive Replacement Overview

This is a high-level overview of the procedure to replace a cache Non-Volatile Memory Express (NVMe) drive.

- 1. Identify the failed SSD.
- 2. Request a replacement SSD from NVIDIA Enterprise Support.
- 3. Power off the system.
- 4. Remove the failed SSD identified earlier.
- 5. Insert the new SSD.
- 6. Power on the system.
- 7. Rebuild the RAID volume and mount the filesystem.
- 8. Return the failed unit to NVIDIA Enterprise Support using the packaging provided.

#### 8.2. Identifying the Failed U.2 NVMe SSD

#### Identifying the Failed NVMe from the Front

If physical access to the system is available, you can identify a failed drive by the illuminated amber LED.

a,						
	0 (2a:00.0)	1 (2b:00.0)	© 0 0 ©	2 (ab:00.0)	3 (ac:00.0)	
	4 (2c:00.0)	5 (2d:00.0)		6 (ad:00.0)	7 (ae:00.0)	

#### Identifying the Failed NVMe from the Console

▶ To identify the failed data drive, you can use the nvsm command:

sudo nvsm show health

View the command output and look for drive alerts to identify the failed drive.

Alternatively, you can use the BMC Web User Interface to access the Sensor screen, the IPMI event log, and the System log to identify issues with the U.2 drives.

## 8.3. Identifying the NVMe Manufacturer and Model

▶ Use the nvsm command to display the drive information:

```
sudo nvsm show /systems/localhost/storage/drives/nvmeXn1
```

Replace X in the preceding command with the number that corresponds to the Linux device name of the failed drive.

Example Output

```
/systems/localhost/storage/drives/nvme5n1
Properties:
    PhysicalLocation_Info = SlotU.2_Slot3
    BlockSizeBytes = 512
    SerialNumber = 22L0A01WT2N8
    Model = KCM6DRUL3T84
    Revision = 0107
    Manufacturer = KIOXIA Corporation
    Status_State = Enabled
    Status Health = OK
    Name = n \sqrt{me5n1}
    MediaType = SSD
    EncryptionStatus = Unlocked
    CapacityBytes = 3840755982336
    Id = nvme5n1
Targets:
Verbs:
    cd
    set
    show
```

Refer to the Manufacturer and Model fields in the output. Request a replacement NVMe from NVIDIA Enterprise Support, specifying this information.

#### 8.4. Replacing the U.2 NVMe Drive

- 1. Ensure that you requested and obtained the replacement drive from NVIDIA Enterprise Support.
- 2. Back up any critical data to a network shared volume or other backup means.
- 3. Power off the system using the power button.
- 4. Remove the bezel. Refer to Removing and Attaching the Bezel for more information.

After the system powers off, use the following figure to identify the drive to replace in the chassis.
 The figures in the following procedures show replacing drive number 7 at PCI address ae.



- 6. Remove the NVMe drive.
  - 1. Press the tab on the right side of the drive to release the lever:



2. Pull the drive out by using the lever:



3. Remove the drive:



#### 8.5. Insert the U.2 NVMe Drive

1. Open the new drive's ejector handle by pressing the release tab, and insert the drive all the way until the connector on the drive engages with the midplane:



2. Use the handle on the drive to secure it in place:



3. Confirm that the drive is flush with the system:



4. Install the bezel after the drive replacement is complete.

#### 8.6. Next Steps

▶ U.2 NVMe Cache Drive Post-Installation Tasks.

## Chapter 9. U.2 NVMe Cache Drive Post-Installation Tasks

This section describes the tasks that you typically need to perform after replacing a U.2 NVMe drive.

#### 9.1. Re-creating the RAID Arrays

- 1. Power on the system and log in.
- 2. Confirm that all installed drives are visible from the OS by using the nvme command:

sudo nvme list

The output can indicate two boot drives and eight cache drives, depending on how many are installed in the system.

Example Output:

Node	SN	Model
→ Namespace	Usage	Format FW Rev
↔		
/dev/nvme0n1	S4YPNE0N200093	SAMSUNG MZWLJ3T8HBLS-00007
→ 1	3.84 TB / 3.84	TB 512 B + 0 B EPK9CB5Q
/dev/nvme1n1	S4YPNE0N200040	SAMSUNG MZWLJ3T8HBLS-00007
<ul> <li>→ 1</li> </ul>	3.84 TB / 3.84	TB 512 B + 0 B EPK9CB5Q
/dev/nvme2n1	S436NA0N106764	SAMSUNG MZ1LB1T9HALS-00007
<ul> <li>→ 1</li> </ul>	44.44 GB / 1.92	TB 512 B + 0 B EDA7602Q
/dev/nvme3n1	S436NA0N106850	SAMSUNG MZ1LB1T9HALS-00007
<ul> <li>→ 1</li> </ul>	45.18 GB / 1.92	TB 512 B + 0 B EDA7602Q
/dev/nvme4n1	S4YPNE0N200144	SAMSUNG MZWLJ3T8HBLS-00007
<ul> <li>→ 1</li> </ul>	3.84 TB / 3.84	TB 512 B + 0 B EPK9CB5Q
/dev/nvme5n1	S4YPNE0N200171	SAMSUNG MZWLJ3T8HBLS-00007
→ 1	3.84 TB / 3.84	TB 512 B + 0 B EPK9CB5Q
/dev/nvme6n1	S4YPNE0N200481	SAMSUNG MZWLJ3T8HBLS-00007
<ul> <li>→ 1</li> </ul>	3.84 TB / 3.84	TB 512 B + 0 B EPK9CB5Q
/dev/nvme7n1	S4YPNE0N200094	SAMSUNG MZWLJ3T8HBLS-00007
→ 1	3.84 TB / 3.84	TB 512 B + 0 B EPK9CB5Q
/dev/nvme8n1	S4YPNE0N200064	SAMSUNG MZWLJ3T8HBLS-00007
→ 1	3.84 TB / 3.84	TB 512 B + 0 B EPK9CB5Q
		(continues on next page)

(continued from previous page)

/dev/nvme9n1	S4YPNE0N200055	SAMSUNG MZWLJ3T8HBLS-00007
	3.84 TB / 3.84	TB 512 B + 0 B EPK9CB5Q

3. If the cache volume was encrypted previously with an access key, disable the encryption before re-creating the RAID volume:

```
sudo nv-disk-encrypt disable
```

The disk encryption packages must be installed on the system. For more information, refer to the Managing Self-Encrypting Drives topic in the *DGX OS 7.0 User Guide*.

4. Re-create the cache volume and the /raid filesystem:

configure\_raid\_array.py -c -f

At the prompt, enter y to confirm the rebuild action.

- 5. (Optional) To encrypt the volume with an access key, refer to the Managing Self-Encrypting Drives topic in the *DGX OS 7.0 User Guide*.
- 6. Confirm the volume is healthy:

sudo nvsm show volumes

7. Send the old drive to NVIDIA Enterprise Support using the packaging from the new drive.

## Chapter 10. M.2 NVMe Boot Drive Replacement

This topic describes how to replace the boot drive in the NVIDIA DGX<sup>™</sup> B200 system.

#### 😤 Caution

**Static Sensitive Devices**: Be sure to observe best practices for electrostatic discharge (ESD) protection. This includes ensuring personnel and equipment are connected to a common ground, such as by wearing a wrist strap connected to the chassis ground and placing components on static-free work surfaces.

#### 10.1. M.2 NVMe Boot Drive Replacement Overview

This is a high-level overview of the procedure to replace a boot drive.

- 1. Determine which M.2 device needs to be replaced with the help of NVIDIA Enterprise Support.
- 2. Get a replacement M.2 disk from NVIDIA Enterprise Support.
- 3. Ensure the system is shut down.
- 4. If cables do not reach, label all the cables and unplug them from the motherboard tray.
- 5. Slide the motherboard out until it locks in place.
- 6. Open the rear compartment.
- 7. Pull out the M.2 riser card with both M.2 disks attached.
- 8. Replace the failed M.2 device on the riser card.
- 9. Install the M.2 riser card with both M.2 disks.
- 10. Close the rear motherboard compartment.
- 11. Slide the motherboard back into the system.
- 12. Plug in all the cables using the labels as a reference.
- 13. Power on the system.
- 14. Confirm the M.2 RAID 1 mirror is synchronizing.

15. Send the failed unit to NVIDIA Enterprise Support using the packaging provided.

#### 10.2. Identify the Failed M.2 Drive

The NVIDIA DGX<sup>™</sup> B200 system automatically sets the failed M.2 drive offline when it detects the failure. The boot drives are mirrored, so the mdadm command-line utility can identify the drive to replace.

1. Determine which drive failed:

sudo nvsm show health

The command output indicates the drive name, nvme0n1 or nvme1n1.

2. Confirm the drive name by using the mdadm command:

sudo mdadm -D /dev/md0

The command output indicates the drive names and the drive state.

- 3. Contact NVIDIA Enterprise Support to request a replacement M.2 drive.
- 4. Back up any critical data to a network shared volume or other backup option.
- 5. When the new drive arrives, remove the failed drive from the mirrored volume.

Run the following commands to mark the drive as failed and to remove the drive from the array.

1. Mark the disk as failed, if it is not already marked as failed:

sudo mdadm --manage /dev/md0 --fail /dev/nvme[0/1]n1

2. Remove the failed disk from the array:

sudo mdadm --manage /dev/md0 --remove /dev/nvme[0/1]n1

6. Power off the system.

#### 10.3. Remove the M.2 Boot Drive Carrier

Before attempting to remove the M.2 boot drive carrier, perform the following prerequisites:


- Label all network, monitor, and USB cables connected to the motherboard tray for easy identification when reconnecting.
- Unplug all power cords, network, monitor, and USB cables.

For more information, refer to Motherboard Tray - Opening and Closing the I/O Door.

1. After the I/O section of the motherboard is open, loosen the black captive thumbscrew on the right side of the motherboard for the PCI card locking mechanism:



2. Rotate the locking mechanism for the PCI carrier out of the way:




3. Loosen the captive screw on the support bracket of the M.2 riser card:



4. Pull the M.2 riser card from the slot:




5. Lift the M.2 riser card to remove it from the system:




#### 10.4. Remove the M.2 Drive

Before attempting to remove one of the M.2 NVMe drives, perform the following prerequisites:


- ▶ Determine the location ID of the faulty M.2 drive.
- ▶ Obtain the replacement M.2 drive and save the packaging for returning the faulty drive.
- 1. Identify the M.2 NVMe that needs to be replaced:




2. Loosen the screw of the identified M.2 drive:



3. Pull the left end of the M.2 drive up about 30  $^\circ\colon$ 




4. Release the M.2 drive from the connector:




#### 10.5. Replace the M.2 Drive


1. To insert the M.2 drive, set it at an angle and insert it into the connector:



2. Lower the M.2 drive and align it with the screw post:




3. Install and tighten the screw to secure the drive to the riser:




#### 10.6. Install the M.2 Boot Drive Carrier and Close the System

1. Lower the M.2 riser card into the slot:



2. Install the M.2 carrier card into the PCI riser by aligning it with the slot and then pressing it against the PCI slot riser:



3. Tighten the captive screw on the support bracket of the M.2 PCI riser card:



4. Close the latch to secure the M.2 carrier card and secure it in place:



5. Tighten the thumbscrew to ensure the locking mechanism stays in place:



## 10.7. Integrate the New Drive and Complete the Installation

1. Return the motherboard to its regular position and power on the system.

For more information, refer to *Motherboard Tray - Opening and Closing the I/O Door*.

- 2. Boot the operating system.
- 3. Run the following command to rebuild the boot drive mirror:

sudo nvsm start /systems/localhost/storage/volumes/md0/rebuild/

4. When prompted, enter the device name of the spare (replaced) drive, nvme0n1 or nvme1n1.

- 1. After entering **y** at the prompt to start the RAID 1 rebuild, the Initiating rebuild ... message appears.
- 2. After about 30 seconds, the Rebuilding RAID-1 ... message should appear.

If this message remains at Initiating RAID-1 rebuild for more than 30 seconds, the rebuild process cannot be completed successfully. In this case, ensure the name of the replacement drive is correct and try again.

5. Use the packaging from the new drive to send the failed drive to NVIDIA Enterprise Support.

#### Note

If your organization purchased a media retention policy, you might be able to keep the failed drives for destruction. Check with NVIDIA Enterprise Support on the status of the policy for specifics.

## Chapter 11. M.2 Boot Drive Assembly Replacement

When you must replace both M.2 operating system drives, a replacement assembly, which includes both M.2 NVMe drives, should be ordered.

#### 11.1. M.2 Boot Drive Riser Assembly Replacement Overview

This is a high-level overview of the procedure to replace the boot drive riser assembly.

#### \rm 1 Note

If your organization purchased a media retention policy, you might be able to keep the failed drives for destruction. Check with NVIDIA Enterprise Support on the status of the policy for specifics.

- 1. Get a replacement M.2 boot drive assembly from NVIDIA Enterprise Support.
- 2. Make sure the system is shut down
- 3. If the cables do not reach, label all cables and unplug them from the motherboard tray.
- 4. Slide the motherboard out until it locks in place.
- 5. Open the rear compartment.
- 6. Pull out the M.2 riser card with both M.2 disks attached.
- 7. Install the M.2 riser card with both M.2 disks.
- 8. Close the rear motherboard compartment.
- 9. Slide the motherboard back into the system.
- 10. Plug in all cables using the labels as a reference.
- 11. Power on the system.
- 12. Re-install using the latest DGX operating system.
- 13. Ship the failed unit to NVIDIA Enterprise Support using the packaging provided.

### 11.2. Preparing the System for Replacement

This failure is hard to diagnose because the system does not boot as both boot drives are unavailable.

After the replacement part arrives from NVIDIA, shut down the system and proceed by opening the I/O door of the motherboard. Refer to *Motherboard Tray - Opening and Closing the I/O Door* to access the M.2 boot drive carrier.

#### 11.3. Remove the M.2 Boot Drive Carrier

Before attempting to remove the M.2 boot drive carrier, perform the following prerequisites:

- Label all network, monitor, and USB cables connected to the motherboard tray for easy identification when reconnecting.
- ▶ Unplug all power cords, network, monitor, and USB cables.

For more information, refer to *Motherboard Tray - Opening and Closing the I/O Door*.

1. After the I/O section of the motherboard is open, loosen the black captive thumbscrew on the right side of the motherboard for the PCI card locking mechanism:



2. Rotate the locking mechanism for the PCI carrier out of the way:






3. Loosen the captive screw on the support bracket of the M.2 riser card:



4. Pull the M.2 riser card from the slot:




5. Lift the M.2 riser card to remove it from the system:



#### 11.4. Install the M.2 Boot Drive Carrier and Close the System

1. Lower the M.2 riser card into the slot:



2. Install the M.2 carrier card into the PCI riser by aligning it with the slot and then pressing it against the PCI slot riser:



3. Tighten the captive screw on the support bracket of the M.2 PCI riser card:



4. Close the latch to secure the M.2 carrier card and secure it in place:



5. Tighten the thumbscrew to ensure the locking mechanism stays in place:



# 11.5. Re-install the System and Complete the Procedure

- 1. Close the lid and insert the motherboard tray. Refer to *Motherboard Tray Opening and Closing the I/O Door* for more information.
- 2. Reinstall the system following the instructions in the *DGX OS User Guide*.
- 3. Confirm the system is in working order by running:

sudo nvsm show health

4. Use the packaging from the new component to send the failed unit to NVIDIA Enterprise Support.

## Chapter 12. ConnectX-7 I/O Replacement

This topic describes how to replace the ConnectX-7 I/O card in the NVIDIA DGX™ B200 system.

## 12.1. ConnectX-7 I/O Card Replacement Overview

This is a high-level overview of the procedure to replace a ConnectX-7 I/O card.


- 1. Identify the failed card.
- 2. Get a replacement ConnectX-7 I/O card from NVIDIA Enterprise Support.
- 3. Ensure the system is shut down.
- 4. If cables do not reach, label all the cables and unplug them from the motherboard tray.
- 5. Slide the motherboard out until it locks in place.
- 6. Open the rear compartment.
- 7. Pull out the card directly above the failed ConnectX-7 to make room for the procedure.
- 8. Pull out the ConnectX-7 I/O card.
- 9. Remove the IPEX cables from the failed card.
- 10. Install the IPEX cables to the new card.
- 11. Install the new ConnectX-7 I/O card.
- 12. Install the card that goes over the ConnectX-7 card.
- 13. Close the rear motherboard compartment.
- 14. Slide the motherboard back into the system.
- 15. Plug in all cables using the labels as a reference.
- 16. Power on the system.
- 17. Update the firmware if necessary and test the ConnectX-7 I/O card.
- 18. Send the failed unit to NVIDIA Enterprise Support using the packaging provided.

## 12.2. Prepare the System for Replacement

1. Identify which I/O card to replace.

Use the nvsm command or network tools to determine which card failed. After you have this information, contact NVIDIA Enterprise Support to get a replacement.

- 2. When the new card arrives, power off the system.
- 3. Based on the nvsm output, identify which card needs replacing, the card in slot 1 or slot 2.



# 12.3. Remove the I/O Card above the ConnectX-7 Card to be Replaced


- 1. Pull out the motherboard tray and access the I/O door. Refer to *Motherboard Tray Opening and Closing the I/O Door* for information about accessing the I/O door.
- 2. Remove the I/O card that is above the ConnectX-7 card. The card can be the M.2 boot drive assembly or a network interface card.
  - ▶ Refer to *M.2 Boot Drive Assembly Replacement* to remove the M.2 boot drive carrier.

The images at the preceding link show how to remove the boot drive carrier on the right, above the ConnectX-7 card in slot 2. If you need to replace the ConnectX-7 card in slot 1, follow the instructions, but use the thumbscrew on the left side of the motherboard tray.

▶ Refer to Network Interface Card Replacement to remove the Ethernet NIC.


## 12.4. Remove the ConnectX-7 Card

1. Pull the card out of the slot:



2. Before you pull the card too far, remove the white and black IPEX cables from the card.

The white cable connects to the top of the card and the black cable connects to the bottom (heatsink) of the card:



3. Follow the instructions in *Remove an IPEX Cable* to remove the IPEX connectors.

## 12.5. Remove an IPEX Cable

Repeat this process for both white and black cables.

1. Locate the IPEX cable attached to the connector:



2. Lift the locking door:




3. Push the cable away from the connector:



## 12.6. Install ConnectX-7 Card


1. Attach the IPEX cables following the instructions in the figure:

The white cable connects to the top of the card and the black cable connects to the bottom (heatsink) of the card. These cables need to be installed before inserting the card.



- 2. Follow the instructions in *Insert an IPEX Cable* to insert the IPEX connectors.
- 3. Insert the card in the slot:

Note the two IPEX cables on the right side of the card.



## 12.7. Insert an IPEX Cable

Repeat this process for both white and black cables.

1. Align the IPEX cable to the connector:




2. Press the cable into the connector:



3. Confirm the cable is in the connector:



4. Close the latching mechanism:



5. Make sure the cable is locked to the connector on the board:



### 12.8. Install the I/O Card above the ConnectX-7 Card

- Reinstall the I/O card that is above the ConnectX-7 card. Refer to one of the two following procedures:
  - ▶ M.2 boot driver carrier. Refer to *M.2 Boot Drive Assembly Replacement* for more information.
  - ▶ Ethernet NIC. Refer to *Network Interface Card Replacement* for more information.
- 2. Close the motherboard tray I/O door and insert the motherboard tray. Refer to *Motherboard Tray* - *Opening and Closing the I/O Door* for more information.

# 12.9. Power on the System and Confirm the Replacement

- 1. Power on and boot the system.
- 2. Update the firmware on the card.

For more information, refer to *Updating the ConnectX-7 Firmware*.

3. Use the nvsm command to confirm that the system is operating correctly:

sudo nvsm show health

4. Send the failed unit to NVIDIA Enterprise Support using the packaging provided.

## Chapter 13. Network Interface Card Replacement

## 13.1. Network Card Replacement Overview

This is a high-level overview of the procedure to replace one or more network cards on the NVIDIA DGX™ B200 system.

- 1. Identify the failed card.
- 2. Get a replacement Ethernet card from NVIDIA Enterprise Support.
- 3. Ensure the system is shut down.
- 4. If cables do not reach, label all cables and unplug them from the motherboard tray.
- 5. Slide the motherboard out until it locks in place.
- 6. Open the rear compartment.
- 7. Pull out the failed Ethernet card.
- 8. Install the new Ethernet card.
- 9. Close the rear motherboard compartment.
- 10. Slide the motherboard back into the system.
- 11. Plug in all cables using the labels as a reference.
- 12. Power on the system.
- 13. Test the Ethernet card.
- 14. Send the failed unit to NVIDIA Enterprise Support using the packaging provided.

## 13.2. Prepare the System for Replacement

Usually, a network interface card fails to function for the following reasons:

- > The operating system does not detect the device.
- ▶ The device does not transmit or receive data.

After you rule out external connectivity issues, contact NVIDIA Enterprise Support to receive a replacement card.

When you receive the card, begin the replacement by performing the following actions:

- 1. Power off the system.
- 2. Open the motherboard tray I/O door to access the rear section of the motherboard. Refer to *Motherboard Tray Opening and Closing the I/O Door* for more information.


## 13.3. Remove the Non-Functional Card


First, turn the locking mechanism 90 degrees so the card can be extracted from the PCI slot:

1. Confirm the motherboard tray service lid is open and loosen the thumbscrew for the PCI card locking mechanism next to slots 1 and 3:




2. Release the PCI cards by turning the locking mechanism 90 degrees as shown in the following figure:






3. Pull the PCI Ethernet card out of the slot:




4. Remove the card from the system:




## 13.4. Install the New Card and Close the Lock

1. Insert the new card into the upper PCI slot:



2. Turn the locking mechanism to secure the PCI cards:



3. Secure the locking mechanism by tightening the black thumbscrew:



## 13.5. Finalize the Network Interface Card Replacement

- 1. Close the motherboard tray I/O door and insert the motherboard tray. Refer to *Motherboard Tray Opening and Closing the I/O Door* for more information.
- 2. Power on and boot the system.
- 3. Check for network connectivity on the replacement card.
- 4. Confirm that the system is operating correctly by running the nvsm command:

sudo nvsm show health

5. Send the failed unit to NVIDIA Enterprise Support using the packaging provided.

## Chapter 14. Updating the ConnectX-7 Firmware

After replacing or installing the ConnectX-7 cards, make sure the firmware on the cards is up to date. Refer to the *NVIDIA DGX B200 Firmware Update Guide* to find the most recent firmware version.

- 1. Download the firmware from https://network.nvidia.com/support/firmware/connectx7ib/. Download the firmware for both OPN options.
- 2. Transfer the firmware ZIP file to the DGX system and extract the archive.
- 3. Update the firmware on the cards that are used for cluster communication:

sudo mlxfwmanager -d 5e:00.0 -i fw-ConnectX7-rel-28\_43\_2026-MCX750500B-→0D00\_Ax\_Bx-UEFI-14.36.21-FlexBoot-3.7.500.signed.bin sudo mlxfwmanager -d dc:00.0 -i fw-ConnectX7-rel-28\_43\_2026-MCX750500B-→0D00\_Ax\_Bx-UEFI-14.36.21-FlexBoot-3.7.500.signed.bin sudo mlxfwmanager -d c0:00.0 -i fw-ConnectX7-rel-28\_43\_2026-MCX750500B-→0D00\_Ax\_Bx-UEFI-14.36.21-FlexBoot-3.7.500.signed.bin sudo mlxfwmanager -d 18:00.0 -i fw-ConnectX7-rel-28\_43\_2026-MCX750500B-→0D00\_Ax\_Bx-UEFI-14.36.21-FlexBoot-3.7.500.signed.bin sudo mlxfwmanager -d 40:00.0 -i fw-ConnectX7-rel-28\_43\_2026-MCX750500B-→0D00\_Ax\_Bx-UEFI-14.36.21-FlexBoot-3.7.500.signed.bin sudo mlxfwmanager -d 4f:00.0 -i fw-ConnectX7-rel-28\_43\_2026-MCX750500B-→0D00\_Ax\_Bx-UEFI-14.36.21-FlexBoot-3.7.500.signed.bin sudo mlxfwmanager -d ce:00.0 -i fw-ConnectX7-rel-28\_43\_2026-MCX750500B-→0D00\_Ax\_Bx-UEFI-14.36.21-FlexBoot-3.7.500.signed.bin sudo mlxfwmanager -d 9a:00.0 -i fw-ConnectX7-rel-28\_43\_2026-MCX750500B-→0D00\_Ax\_Bx-UEFI-14.36.21-FlexBoot-3.7.500.signed.bin

4. Update the firmware on the cards that are used for storage communication:

```
sudo mlxfwmanager -d aa:00.0 -i fw-ConnectX7-rel-28_43_2026-MCX755206AS-

→NEA_Ax-UEFI-14.36.21-FlexBoot-3.7.500.signed.bin

sudo mlxfwmanager -d 29:00.0 -i fw-ConnectX7-rel-28_43_2026-MCX755206AS-

→NEA_Ax-UEFI-14.36.21-FlexBoot-3.7.500.signed.bin
```

- Perform an AC power cycle on the system for the firmware update to take effect. Wait for the operating system to boot.
- 6. After the system starts, log in and confirm the firmware versions are all the same:

\$ cat /sys/class/infiniband/mlx5\_\*/fw\_ver

## Chapter 15. BlueField-3 I/O Card Replacement

This topic describes how to replace the NVIDIA<sup>®</sup> BlueField<sup>®</sup>-3 card in the NVIDIA DGX<sup>™</sup> B200 system.

## 15.1. BlueField-3 I/O Card Replacement Overview

- 1. Identify the failed BlueField-3 I/O card.
- 2. Get a replacement BlueField-3 I/O card from NVIDIA Enterprise Support.
- 3. Ensure that the system is shut down.
- 4. If cables do not reach, label all cables and unplug them from the motherboard tray.
- 5. Slide the motherboard out until it locks in place.
- 6. Open the rear compartment.
- 7. Pull the card directly above the failed Bluefield-3 card to make room for the procedure.
- 8. Pull out the BlueField-3 I/O card.
- 9. Remove the IPEX and power cables from the old card.
- 10. Install the IPEX and power cables to the new card.
- 11. Install the new BlueField-3 I/O card.
- 12. Install the card that goes over the BlueField-3 card.
- 13. Close the rear motherboard compartment.
- 14. Slide the motherboard back into the system.
- 15. Plug in all cables using the labels as a reference.
- 16. Power on the system.
- 17. Update the firmware if necessary and test the BlueField-3 I/O card.
- 18. Send the failed unit to NVIDIA Enterprise Support using the packaging provided.

## 15.2. Prepare the System for Replacement


1. Identify which I/O card to replace.

Use the nvsm command or network tools to determine the failed card, and then contact NVIDIA Enterprise Support to get a replacement card.

2. When you receive the replacement card, power off the system.

To access the rear section of the motherboard, refer to *Motherboard Tray* - *Opening and Closing the I/O Door*.

3. Based on the output from the nvsm command, identify which card needs to be replaced, the card in slot 1 or slot 2.



## 15.3. Remove the I/O Card above the BlueField-3 Card to be Replaced

- 1. Pull out the motherboard tray and access the I/O door. Refer to *Motherboard Tray Opening and Closing the I/O Door* for information about accessing the IO door.
- 2. Remove the I/O card that is above the BlueField-3 card. The card can be the M.2 boot drive assembly or a network interface card.
  - ▶ Refer to *M.2 Boot Drive Assembly Replacement* to remove the M.2 boot drive carrier.


The images at the preceding link show how to remove the boot drive carrier on the right above the BlueField-3 card in slot 2. If you need to replace the BlueField-3 card in slot 1, follow the instructions but use the thumbscrew on the left side of the motherboard tray.

▶ Refer to Network Interface Card Replacement to remove the Ethernet NIC.

## 15.4. Remove the BlueField-3 Card

 Remove the power cable from the BlueField-3 card side only: Do not unplug the power cable from the motherboard side.


Chapter 15. BlueField-3 I/O Card Replacement




Power cable motherboard side

2. Before pulling the card too far, ensure to unplug the white and black IPEX cables from the card following the instructions in *Remove an IPEX Cable*.

The white cable connects to the top of the card and the black cable connects to the bottom (heatsink) of the card:



3. Pull the card out of the slot and remove it from the system:



## 15.5. Remove an IPEX Cable

Repeat this procedure for both the white and black cables. The following image shows the IPEX cable attached to the connector:



1. Lift the locking door:




2. Push the cable away from the connector:




## 15.6. Install the BlueField-3 Card

1. After you connect the IPEX cables, install the new BlueField-3 card in the bottom slot in the PCI riser:




2. Attach the IPEX and power cables as shown in *Insert an IPEX Cable*.



Connect one end of the power cable to the BlueField-3 card and the other end of the power cable to the motherboard.

3. Insert the BlueField-3 card in the bottom PCI slot:



## 15.7. Install the I/O Card and Close the System

- Reinstall the I/O card that is above the BlueField-3 card. Refer to one of the two following procedures:
  - ▶ M.2 boot driver carrier. Refer to *M.2 Boot Drive Assembly Replacement* for more information.
  - ▶ Ethernet NIC. Refer to *Network Interface Card Replacement* for more information.
- 2. Close the motherboard tray I/O door and insert the motherboard tray. Refer to *Motherboard Tray* - *Opening and Closing the I/O Door* for more information.

# 15.8. Power on the System and Confirm the Replacement

- 1. Power on and boot the system.
- 2. Update the firmware on the card.

Refer to the NVIDIA BlueField-3 Networking Platform User Guide.

3. Reset the Bluefield-3 password.

Refer to Changing Default Password in the NVIDIA BlueField documentation.

- 4. To change passwords other than the one from the BMC user, refer to Changing BMC Password Using bf.cfg in the NVIDIA BlueField documentation.
- 5. Confirm that the system is working correctly by using the nvsm command:

sudo nvsm show health

6. Use the packaging from the new card to send the failed card to NVIDIA Enterprise Support.

# Chapter 16. DIMM Upgrade and Replacement

#### 拴 Caution

**Static Sensitive Devices**: Be sure to observe best practices for electrostatic discharge (ESD) protection. Ensure that personnel and equipment are connected to a common ground, such as wearing a wrist strap connected to the chassis ground and placing components on static-free work surfaces.

## 16.1. DIMM Upgrade Procedure

To upgrade DIMMs,

- 1. Contact NVIDIA to obtain the complete upgrade kit.
- 2. Replace all DIMMs following the instructions in the DIMM Replacement section.

## 16.2. DIMM Replacement Overview

This is a high-level overview of the procedure to replace a dual inline memory module (DIMM) on the NVIDIA DGX<sup>™</sup> B200 system.

- 1. Use the nvsm health command to identify the failed DIMM.
- 2. Get a replacement DIMM from NVIDIA Enterprise Support.
- 3. Shut down the system.
- 4. Label all motherboard tray cables and unplug them.
- 5. Remove the motherboard tray and place it on a solid flat surface.
- 6. Remove the motherboard tray lid.
- 7. Use the reference diagram on the lid of the motherboard tray to identify the failed DIMM.
- 8. Replace the failed DIMM with the new one.
- 9. Close the lid on the motherboard tray.
- 10. Insert the motherboard tray into the system.
- 11. Plug in all cables using the labels as a reference.

- 12. Power on the system.
- 13. Verify that all DIMMs are now healthy with the nvsm health command.
- 14. Send the failed unit to NVIDIA Enterprise Support using the packaging provided.

#### \rm Note

You should observe the following DIMM population guidelines:

- Each memory channel (A, B, C, D, E, F, G, H) should be populated with identical DIMMs for optimal performance in a dual-memory configuration. For example, DIMMs in slots CPU1\_B0 and CPU1\_B1 within channel B should have the same part number.
- ▶ Different memory channels can be populated with DIMMs of different part numbers. For example, DIMMs in slots CPU1\_A0 and CPU1\_A1 should have the same part number, while DIMMs in slots CPU1\_B0 and CPU1\_B1 should have the same part number. However, the DIMM manufacturer in channel A can differ from the DIMM manufacturer in channel B.

### 16.2.1. Identifying the Failed DIMM

1. From the console, run the following nvsm command to identify the failed DIMM:

sudo nvsm show health

2. Determine the DIMM manufacturer.

sudo nvsm show memory

3. Request a replacement DIMM from NVIDIA Enterprise Support, specifying the manufacturer.


### 16.2.2. Replacing the DIMM

- 1. Power off the system.
- 2. Remove the motherboard tray. Refer to *Motherboard Tray Removal and Installation* for more information.
- 3. Pull the motherboard out of the system and place it on a solid, flat surface.


Remove the lid and air baffles to expose the DIMMs.

4. Identify the failed DIMM on the motherboard.

Use the label on the lid to identify the position of the DIMM to be replaced. The names of the DIMMs also include the CPU numbering for easier identification.



5. To remove the failed DIMM, press down on the ejection levers to eject the DIMM out of the socket.



6. To insert the new DIMM, position it in the socket and press down until the levers close and the DIMM clicks into place.





### 16.2.3. Finalize the DIMM Replacement

- 1. Install the air baffles, close the motherboard, and install the tray in the chassis. For more information, refer to *Motherboard Tray - Removal and Installation*.
- 2. Plug in all cables.
- 3. Install all power cords.
- 4. Power on system.
- 5. Log in and use the nvsm command to confirm the system is healthy:

sudo nvsm show health

6. Send the failed DIMM to NVIDIA Enterprise Support.

## Chapter 17. Motherboard Tray Battery Replacement

#### 拴 Caution

**Static Sensitive Devices**: Be sure to observe best practices for electrostatic discharge (ESD) protection. Ensure that personnel and equipment are connected to a common ground, such as wearing a wrist strap connected to the chassis ground and placing components on static-free work surfaces.

## 17.1. Motherboard Tray Battery Replacement Overview

This is a high-level overview of the procedure to replace the motherboard tray battery of the NVIDIA DGX™ B200 system.

- 1. Purchase a CR2032 battery.
- 2. Shut down the system.
- 3. Label all motherboard cables and unplug them.
- 4. Slide out the motherboard tray.
- 5. Open the motherboard tray I/O compartment.
- 6. Pull out the PCI cards on the left side of the motherboard (slots 1 and 3).
- 7. Replace the battery on the motherboard.
- 8. Install the PCI cards on the left side of the motherboard (slots 1 and 3).
- 9. Close the lid I/O compartment on the motherboard tray.
- 10. Slide the motherboard tray into the system.
- 11. Plug in all cables using the labels as a reference.
- 12. Power on the system.
- 13. Configure the system settings.
- 14. Confirm the system is healthy by running nvsm show health.

## 17.2. Identify a Failed Battery

When the battery fails, some of these symptoms might occur:

- Invalid configuration will appear on your screen
- Setup appears on your screen before booting
- Press F1 to continue appears on the console
- A Clock Error or Clock Message appears on your screen
- ▶ The system clock loses time and date

Call NVIDIA Enterprise Support to confirm that the battery is the right component to replace.

#### \rm 1 Note

NVIDIA does not provide the CR2032 battery, which can be found at a convenience store. After you purchase a battery, perform the following procedures.

## 17.3. Prepare the System for Replacement

- 1. Power off the system.
- 2. Open the motherboard tray I/O door to access the rear section of the motherboard.


For more information, refer to Motherboard Tray - Opening and Closing the I/O Door.

## 17.4. Remove the PCI Ethernet Card


- 1. Confirm the motherboard tray I/O lid is open.
- 2. Loosen the thumbscrew for the PCI card locking mechanism by loosening the captive black thumbscrew that corresponds to the slot you need to work on:




3. Rotate the locking mechanism out of the way to release the PCI cards:



4. Pull the PCI Ethernet card from the slot in the riser:




5. Remove the card and prepare the ConnectX-7 card by identifying the IPEX cables that should be removed:



## 17.5. Remove the BlueField-3 Card


- 1. Remove the power cable from the BlueField-3 card side only:
  - Do not unplug the power cable from the motherboard side.




Power cable motherboard side

2. Before pulling the card too far, ensure to unplug the white and black IPEX cables from the card following the instructions in *Remove an IPEX Cable*.

The white cable connects to the top of the card and the black cable connects to the bottom (heatsink) of the card:



3. Pull the card out of the slot and remove it from the system:



## 17.6. Remove an IPEX Cable

Repeat this procedure for both the white and black cables. The following image shows the IPEX cable attached to the connector:



1. Lift the locking door:




2. Push the cable away from the connector:




## 17.7. Replace the Battery

1. Use a thin tool to lift the battery from the battery holder gently:



2. Rotate the battery as shown in the following figure:




3. Replace the battery with a new CR2032, installing it in the battery holder. Make sure the positive side is on top:




## 17.8. Install the BlueField-3 Card

1. After you connect the IPEX cables, install the new BlueField-3 card in the bottom slot in the PCI riser:




2. Attach the IPEX and power cables as shown in *Insert an IPEX Cable*.



Connect one end of the power cable to the BlueField-3 card and the other end of the power cable to the motherboard.

3. Insert the BlueField-3 card in the bottom PCI slot:




## 17.9. Insert an IPEX Cable

1. Align the IPEX cable to the connector:




2. Press the cable into the connector:



3. Confirm the cable is in the connector:



4. Close the latching mechanism:




5. Ensure the cable is locked to the connector on the board:




## 17.10. Install the PCI Ethernet Card


1. Position the card in the system:



2. Push the card into the PCI slot:



3. Close the latch to lock the PCI cards in place:




4. Secure the locking mechanism by tightening the black thumbscrew:



# 17.11. Power On the System and Confirm the Replacement

- 1. Close the motherboard tray I/O door and insert the motherboard tray. Refer to *Motherboard Tray Opening and Closing the I/O Door* for more information.
- 2. Connect all the cables and power cords to the motherboard tray.



3. Apply power to the system.

4. To restore the date on the system, manually set the date using NTP:

sudo date [MMDDhhmm[[CC]YY][.ss]]

5. Sync the date and time to the hardware real-time clock:

sudo hwclock -w

6. Reset the BMC:

sudo ipmitool mc reset cold

7. Log in and run nvsm shown health:

sudo nvsm show health

8. Confirm that the time and date on the system are updated.

# Chapter 18. Trusted Platform Module Replacement

#### 拴 Caution

**Static Sensitive Devices**: Be sure to observe best practices for electrostatic discharge (ESD) protection. Ensure that personnel and equipment are connected to a common ground, such as wearing a wrist strap connected to the chassis ground and placing components on static-free work surfaces.

### 18.1. Trusted Platform Module Replacement Overview

This is a high-level overview of the procedure to replace the trusted platform module (TPM) on the NVIDIA DGX<sup>™</sup> B200 system.

- 1. If enabled, disable drive encryption.
- 2. Shut down the system.
- 3. Label all motherboard tray cables and unplug them.
- 4. Slide out the motherboard tray.
- 5. Remove the tray lid and the DIMM air baffle.
- 6. Lift the OSFP carrier module to access the TPM.
- 7. Replace the TPM on the motherboard.
- 8. Install the OSFP carrier module.
- 9. Install the DIMM air baffle and motherboard tray lid.
- 10. Slide the motherboard tray into the system.
- 11. Plug in all cables using the labels as a reference.
- 12. Power on the system.
- 13. Confirm the system is healthy by running nvsm show health.
- 14. If the data drives need to be protected, enable encryption.

### 18.2. Prepare the System for Replacement

- 1. Obtain a new TPM from NVIDIA.
- 2. If data drives are encrypted, the tpm2 OS package is installed, and the TPM is enabled in SBIOS, disable encryption:


sudo nv-disk-encrypt disable

- 3. Shut down the system.
- 4. Label all network, monitor, and USB cables
- 5. Remove the motherboard tray. Refer to *Motherboard Tray Removal and Installation* for more information.
- 6. Remove the DIMM air baffle.




### 18.3. Replace the TPM Module


1. Locate the OSFP carrier module on the motherboard, as indicated by the green arrow in the following figure:




Move the OSFP carrier module toward the DIMMs, as shown in the following figure.
 Ensure the OSFP cages at the rear of the system do not interfere with the tray sheet metal before you tilt the carrier:



3. Rotate the OSFP carrier module to access the TPM, as shown in the following diagram:




4. Replace the TPM. Ensure that you position the TPM in the same direction as the original.




### 18.4. Install the OSFP Carrier Module

1. Rotate the OSFP carrier module to return it to its original position. While you rotate the module, pull the module toward the DIMMs so that the ports do not interfere with the motherboard tray frame:



2. Move the OSFP carrier toward the outside of the tray so that the OSFP cages go through the openings on the sheet metal:



## 18.5. Finalize the TPM Replacement

- 1. Install the air baffles, close the motherboard, and install the tray in the chassis. Refer to *Motherboard Tray Removal and Installation* for more information.
- 2. Plug in all cables.
- 3. Install all power cords.
- 4. Power on the system.

5. If data drives were encrypted, the tpm2 OS package was installed, and the TPM was enabled in SBIOS before the replacement, enable encryption:

sudo nv-disk-encrypt init -g -r -k <your vault password>

6. Use the nvsm command to confirm the system is healthy:

sudo nvsm show health

# Chapter 19. Rack Mount Kit Replacement

This is a high-level overview of the procedure to replace a rack mount kit on the NVIDIA DGX<sup>™</sup> B200 system.

- 1. Remove the two front screws and washers.
- 2. Remove the two rear screws.
- 3. Use the clips to release the front and rear from each side of the kit.
- 4. Remove the cage nuts from the rack posts.
- 5. Install on the new rack by using the clips to position the kit at the right height.
- 6. Use the template to install the cage nuts on the right.
- 7. Use the four screws and two washers to secure the rack mount kit in place.

### 19.1. Rack Mount Kit Description


The rack mount kit acts as a shelf in the rack, it does not allow the system to be moved once installed. All components are serviceable from the front or rear.

This rack mount kit can extend lengthwise, and the distance between the posts ranges from 29 through 35 in (0.74-0.9 m).

#### 🚯 Note

The lip at the bottom will hold the bottom of the system.

- These prongs enter the holes of the rack (square or round).
- Metal plates keep the rack kit in place.
- Secure the rack mount kit to the rack with the provided screws.
- Identify the front of the rackmount with the embossed labels.



- 1. On the lower part, a lip labeled 1, when installed in a rack, will hold the system in place like a shelf.
- 2. On either end, spring-loaded prongs, as labeled 2 on the diagram, fit into the rack's holes (either square or round.)
- 3. Together with the metal clips labeled 3, they hold the rack mount kit in place for ease of installation.
- 4. Labeled with a number 4 are the holes where the screws that secure the rack kit in place must be installed.
- 5. Label 5 identifies where that part of the rack mount kit should be installed in the rack.


### 19.2. Remove Rack Mount Kit - Front

- 1. To remove the rack mount kit, first remove the flat head screw and the countersunk washer, and keep them in a safe place.
  - Push on the clip to release the rack mount kit rail from the post, and push it towards the back while holding the rail.




2. Pull on the clip to release the rack mount kit from the post so it can slide back and the prongs can be released from the post.

- 1. Remove the rail from the front post and hold it in place while the rear is released.
- 2. Remove all cage nuts from the rack posts so they can be used during installation.




### 19.3. Remove Rack Mount Kit - Rear

1. To release the rear of the rack mount kit, remove the round head screw and keep next to the other screws and washers.



2. Pull on the metal clip and slide the rail away from the post so the progs are free from the rack.



### 19.4. Confirm Necessary Screws and Washers

These items are in the rack mount kit box with the rack mount kit. All these components should have been removed from the previous installation.

#### Note

Front screws are different from the screws used for the back of the rack mount kit. If the correct screws are not used in the front, the server will not be flush when pushed against the rack and it will be difficult to secure the other eight captive screws.


Ensure all cage nuts are removed from the rack as they will be needed to install the rack mount kit at its new location.



### 19.5. Install Cage Nuts Using Template

A printed copy of this template is included as part of the rack kit, and it should be used to align the desired location of the system to where the included cage nuts should be installed.


The template is double sided so it can be used as a reference on the left and right posts of the rack.



#### Note

RACKS WITH C-CHANNEL POSTS: They have an obstruction that prevents the rack mount kit from


being installed in the frontmost post. Use a third pair of cage nuts so the bottom system screws have something to engage with.



### 19.6. Install Rack Mount Kit - Front


You can start with either side to install the rack mount kit on the rack. The following instructions describe the installation of the left side.

- 1. Align the lip to the bottom of the rack unit where the system needs to be installed as shown in the diagram.
- 2. Insert the spring-loaded prongs into the rack post's holes and open the clips to ensure the prongs are inserted as far as they go.



- 3. Close the clip and make sure the rack kit is securely attached to the rack.
- 4. Install the flat head screw and the countersunk washer in the bottom hole as shown in the figure


to secure the rack mount kit to the post.




Flat head screw Washer

### 19.7. Install Rack Mount Kit - Rear

- 1. To install the rear section of the rack mount kit, follow the same steps to align the bottom lip to the bottom of where the system should be.
- 2. Pull open the clip and insert the prongs through the corresponding holes in the second rack unit. Make sure the prongs are fully extended. Release the clip so it locks the rack mount kit into place.



3. Install the round head screw in the rack mount kit to secure it to the post.



4. Repeat the procedure for the right side of the rack mount kit.

# Chapter 20. Safety

This section provides information about how to safely use the NVIDIA DGX<sup>™</sup> B200 system.

# 20.1. Safety Information

To reduce the risk of bodily injury, electrical shock, fire, and equipment damage, read this document and observe all warnings and precautions in this guide before installing or maintaining your server product.

In the event of a conflict between the information in this document and information provided with the product or on the website for a particular product, the product documentation takes precedence.

Your server should be integrated and serviced only by technically qualified persons.

You must adhere to the guidelines in this guide and the assembly instructions in your server manuals to ensure and maintain compliance with existing product certifications and approvals. Use only the described, regulated components specified in this guide. Use of other products I components will void the UL Listing and other regulatory approvals of the product and may result in noncompliance with product regulations in the region(s) in which the product is sold.

## 20.2. Safety Warnings and Cautions

To avoid personal injury or property damage, before you begin installing the product, read, observe, and adhere to all the following safety instructions and information.

The following safety symbols may be used throughout the documentation and may be marked on the product and the product packaging.

Symbol	Description
CAUTION	Indicates the presence of a hazard that may cause minor personal injury or prop- erty damage if the CAUTION is ignored.
WARNING	Indicates the presence of a hazard that may result in serious personal injury if the WARNING is ignored.

Symbol	Description
	Indicates potential hazard if indicated information is ignored.
4	Indicates shock hazards that result in serious injury or death if safety instructions are not followed.
	Indicates hot components or surfaces.
	Indicates do not touch fan blades, may result in injury.
	<ul> <li>Shock hazard: The product might be equipped with multiple power cords. To remove all hazardous voltages, disconnect all power cords.</li> <li>High leakage current ground (earth) connection to the Power Supply is essential before connecting the supply.</li> </ul>
53	Recycle the battery.
	The rail racks are designed to carry only the weight of the server sys- tem. Do not use rail- mounted equipment as a workspace. Do not place additional load onto any rail-mounted equipment.

安全警告和注意事項

為了避免人身傷害或財產損失,在開始安裝產品之前,閱讀,觀察,並遵守所有的以下安全提示 和信息。以下安全符號會在整個文件中使用,並且在產品和/或產品包裝標記。

Symbol	Meaning
CAUTION	如果危險存在而忽略 CAUTION,表示可能導致輕微的人身 傷害和財產損失。
WARNING	如果危險存在而忽略 Warning, 表示可能會導致嚴重的人身 傷害。
	表示如果信息被忽略會有潛在危險。
4	表示如果不遵照安全說明會導致嚴重傷害或死亡的觸電危 險
	表示零件或表面有熱度。
	表示請勿碰觸風扇葉片,碰觸可能會導致受傷
▲ WARNING. AVERTISSEMENT.           Bioinformation         Image: Amage: Ama	觸電危險 - 產品可能配備多根電源線。要除去所有危險電 壓,請斷開所有電源線。
	在連接電源之前,請必須先連接高漏電電流地線到電源供應器。
53	電池回收.
R	導軌架被設計成只能承受伺服器系統的重量。不要使用軌 道安裝設備為工作區。不要把額外的負載加到任何軌道安 裝設備上。

### 20.3. Intended Application Uses

This product was evaluated as Information Technology Equipment (ITE), which may be installed in offices, schools, computer rooms, and similar commercial type locations.

The suitability of this product for other product categories and environments (such as medical, industrial, residential, alarm systems, and test equipment), other than an ITE application, may require further evaluation.

### 20.4. Site Selection

Here is some information about how to select the correct site for the DGX B200 system. Choose a site that is:

- ▶ Clean, dry, and free of airborne particles (other than normal room dust).
- ▶ Well-ventilated and away from sources of heat including direct sunlight and radiators.
- > Away from sources of vibration or physical shock.
- In regions that are susceptible to electrical storms, we recommend you plug your system into a surge suppressor and disconnect telecommunication lines to your modem during an electrical storm.
- Provided with a properly grounded wall outlet.
- Provided with sufficient space to access the power supply cord(s), because they serve as the product's main power disconnect.

### 20.5. Equipment Handling Practices

To reduce the risk of personal injury or equipment damage, do the following:

- Conform to local occupational health and safety requirements when moving and lifting equipment.
- ▶ Use mechanical assistance or other suitable assistance when moving and lifting equipment.

### 20.6. Electrical Precautions

### 20.6.1. Power and Electrical Warnings

#### 😤 Caution

The power button, indicated by the stand-by power marking, DOES NOT completely turn off the system AC power; standby power is active whenever the system is plugged in. To remove power from system, you must unplug the AC power cord from the wall outlet. Make sure all AC power cords are unplugged before you open the chassis, or add or remove any non hot-plug components.

Do not attempt to modify or use an AC power cord if it is not the exact type required. A separate AC cord is required for each system power supply.

Some power supplies in servers use Neutral Pole Fusing. To avoid risk of shock use caution when working with power supplies that use Neutral Pole Fusing.

The power supply in this product contains no user-serviceable parts. Do not open the power supply. Hazardous voltage, current and energy levels are present inside the power supply. Return to manufacturer for servicing.

When replacing a hot-plug power supply, unplug the power cord to the power supply being replaced before removing it from the server.

To avoid risk of electric shock, tum off the server and disconnect the power cords, telecommunications systems, networks, and modems attached to the server before opening it.

### 20.6.2. Power Cord Warnings

#### 拴 Caution

To avoid electrical shock or fire, check the power cord(s) that will be used with the product as follows:

- Do not attempt to modify or use the AC power cord(s) if they are not the exact type required to fit into the grounded electrical outlets.
- ▶ The power cord(s) must meet the following criteria:
  - The power cord must have an electrical rating that is greater than that of the electrical current rating marked on the product.
  - The power cord must have safety ground pin or contact that is suitable for the electrical outlet.
  - The power supply cord(s) is/ are the main disconnect device to AC power. The socket outlet(s) must be near the equipment and readily accessible for disconnection.
  - The power supply cord(s) must be plugged into socket-outlet(s) that is /are provided with a suitable earth ground.

### 20.7. System Access Warnings

To avoid personal injury or property damage, the following safety instructions apply whenever accessing the inside of the product:

- ▶ Turn off all peripheral devices connected to this product.
- > Turn off the system by pressing the power button to off.
- > Disconnect the AC power by unplugging all AC power cords from the system or wall outlet.
- > Disconnect all cables and telecommunication lines that are connected to the system.
- Retain all screws or other fasteners when removing access cover(s). Upon completion of accessing inside the product, refasten access cover with original screws or fasteners.
- > Do not access the inside of the power supply. There are no serviceable parts in the power supply.
- Return to manufacturer for servicing.
- Power down the server and disconnect all power cords before adding or replacing any non hotplug component.
- When replacing a hot-plug power supply, unplug the power cord to the power supply being replaced before removing the power supply from the server.

#### 😫 Caution

If the server has been running, any installed processor(s) and heat sink(s) may be hot. Unless you are adding or removing a hot-plug component, allow the system to cool before opening the covers. To avoid the possibility of coming into contact with hot component(s) during a hot-plug installation, be careful when removing or installing the hot-plug component(s).

#### 😤 Caution

To avoid injury do not contact moving fan blades. Your system is supplied with a guard over the fan, do not operate the system without the fan guard in place.

### 20.8. Rack Mount Warnings

The following installation guidelines are required by UL to maintain safety compliance when installing your system into a rack.

The equipment rack must be anchored to an unmovable support to prevent it from tipping when a server or piece of equipment is extended from it. The equipment rack must be installed according to the rack manufacturer's instructions.

Install equipment in the rack from the bottom up with the heaviest equipment at the bottom of the rack.

Extend only one piece of equipment from the rack at a time.

You are responsible for installing a main power disconnect for the entire rack unit. This main disconnect must be readily accessible, and it must be labeled as controlling power to the entire unit, not just to the server(s).

To avoid risk of potential electric shock, a proper safety ground must be implemented for the rack and each piece of equipment installed in it.

Elevated Operating Ambient- If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than room ambient. Therefore, consideration should be given to installing the equipment in an environment compatible with the maximum ambient temperature (Tma) specified by the manufacturer.

Reduced Air Flow -Installation of the equipment in a rack should be such that the amount of air flow required for safe operation of the equipment is not compromised.

Mechanical Loading- Mounting of the equipment in the rack should be such that a hazardous condition is not achieved due to uneven mechanical loading.

Circuit Overloading- Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of the circuits might have on overcurrent protection and supply wiring. Appropriate consideration of equipment nameplate ratings should be used when addressing this concern.

Reliable Earthing- Reliable earthing of rack-mounted equipment should be maintained.

Particular attention should be given to supply connections other than direct connections to the branch circuit (for example, the use of power strips).

### 20.9. Electrostatic Discharge

#### 拴 Caution

ESD can damage drives, boards, and other parts. We recommend that you perform all procedures at an ESD workstation. If one is not available, provide some ESD protection by wearing an antistatic

wrist strap attached to chassis ground (any unpainted metal surface) on your server when handling parts.

Always handle boards carefully. They can be extremely sensitive to ESD. Hold boards only by their edges. After removing a board from its protective wrapper or from the server, place the board component side up on a grounded, static free surface. Use a conductive foam pad if available but not the board wrapper. Do not slide board over any surface.

### 20.10. Other Hazards

### 20.10.1. CALIFORNIA DEPARTMENT OF TOXIC SUBSTANCES CONTROL

Perchlorate Material - Lithium Coin/Button Cell battery. Please dispose of properly. Special handling may apply. See www.dtsc.ca.gov/hazardouswaste/perchlorate.

### 20.10.2. NICKEL



NVIDIA Bezel. The bezel's decorative metal foam contains some nickel. The metal foam is not intended for direct and prolonged skin contact. Please use the handles to remove, attach or carry the bezel. While nickel exposure is unlikely to be a problem, you should be aware of the possibility in case you are susceptible to nickel-related reactions.

### 20.10.3. Battery Replacement

#### 拴 Caution

There is the danger of explosion if the battery is incorrectly replaced. When replacing the battery, use only the battery recommended by the equipment manufacturer.

Dispose of batteries according to local ordinances and regulations. Do not attempt to recharge a battery.

Do not attempt to disassemble, puncture, or otherwise damage a battery.

更換電池警告:

警告

```
更換不正確之電池型式會有爆炸的風險。 請依製造商說明書處理用過之電池。
```

### 20.10.4. Cooling and Airflow

#### 拴 Caution

Carefully route cables as directed to minimize airflow blockage and cooling problems. For proper cooling and airflow, operate the system only with the chassis covers installed.

Operating the system without the covers in place can damage system parts. To install the covers:

- > Check first to make sure you have not left loose tools or parts inside the system.
- Check that cables, add-in cards, and other components are properly installed.
- > Attach the covers to the chassis according to the product instructions.

The equipment is intended for installation only in a Server Room/Computer Room where both these conditions apply:

- Access can only be gained by SERVICE PERSONS or by USERS who have been instructed about the reasons for the restrictions applied to the location and about any precautions that shall be taken.
- Access is through the use of a TOOL or lock and key, or other means of security, and is controlled by the authority responsible for the location.

# Chapter 21. Compliance

The NVIDIA DGX<sup>™</sup> B200 Server is compliant with the regulations listed in this section.

### 21.1. United States

Federal Communications Commission (FCC)

FCC Marking (Class A)

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including any interference that may cause undesired operation of the device.

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

California Department of Toxic Substances Control

Perchlorate Material - Lithium Coin/Button Cell battery. Please dispose it properly.

special handling may apply. See www.dtsc.ca.gov/hazardouswaste/perchlorate.

## 21.2. United States/Canada

TÜV Rheinland of North America is accredited as a Nationally Recognized Testing Laboratory (NRTL), by OSHA (The Occupational Safety and Health Administration) in the United States, and as a Product Certification Body by SCC (Standards Council of Canada) in Canada. Refer to https://www.tuv.com/usa/en/ctuvus-certification.html

#### cTUVus Mark



### 21.3. Canada

Innovation, Science and Economic Development Canada (ISED) CAN ICES(A)/NMB(A)

The Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulation.

Cet appareil numerique de la class A respecte toutes les exigences du Reglement sur le materiel brouilleur du Canada.

### 21.4. CE

European Conformity; Conformité Européenne (CE)



This is a Class A product. In a domestic environment, this product may cause radio frequency interference in which case the user may be required to take adequate measures.

This device bears the CE mark in accordance with Directive 2014/53/EU. This device complies with the following Directives:

- **EMC** Directive A, I.T.E Equipment.
- ▶ Low Voltage Directive for electrical safety.
- ▶ RoHS Directive for hazardous substances.
- ▶ Energy-related Products Directive (ErP).

For the full text of EU declaration of conformity, refer to http://www.nvidia.com/support.

A copy of the Declaration of Conformity to the essential requirements may be obtained directly from NVIDIA GmbH (Bavaria Towers – Blue Tower, Einsteinstrasse 172, D-81677 Munich, Germany).

### 21.5. Australia and New Zealand

Australian Communications and Media Authority



This product meets the applicable EMC requirements for Class A, I.T.E equipment.

### 21.6. Brazil

INMETRO



### 21.7. Japan

Voluntary Control Council for Interference (VCCI)



この装置は、クラスA機器です。この装置を住宅環境で使用すると電波妨害 を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう 要求されることがあります。 VCCI-A

This is a Class A product.

In a domestic environment, this product may cause radio interference, in which case the user may be required to take corrective actions. VCCI-A.

2008年、日本における製品含有表示方法、JISC0950が公示されました。製造事業者は、 2006年7月1日以降に販売される電気・電子機器の特定化学物質の含有に付きまして情報 提供を義務付けられました。製品の部材表示に付きましては、以下をご覧ください。

A Japanese regulatory requirement, defined by specification JIS C 0950, 2008, mandates that manufacturers provide Material Content Declarations for certain categories of electronic products offered for sale after July 1, 2006.

To view the JIS C 0950 material declaration for this product, visit www.nvidia.com.

#### Japan RoHS Material Content Declaration

日本工業規格 JIS C 0950:2008 により、2006 年7月1日以降に販売される特定分野の電気および電子機器に ついて、製造者による含有物質の表示が義務付けられます。

さん八綱	特定化学物質記号							
主な分類	Pb	Hg	Cd	Cr(VI)	PBB	PBDE		
PCB ボード	0	0	0	0	0	0		
パッシブ電子部品	除外項目	0	0	0	0	0		
アクティブ電子部品	除外項目	0	0	0	0	0		
プロセッサー	0	0	0	0	0	0		
ノモリ	0	0	0	0	0	0		
機械部品及びファン	除外項目	0	0	0	0	0		
ケーブル/コネクター	除外項目	0	0	0	0	0		
はんだ付け材料	0	0	0	0	0	0		
フラックス、クリームはんだ、ラ ベル、その他消耗品	0	0	0	0	0	0		

注:

1. [0] は、特定化学物質の含有率が日本工業規格 JIS C 0950:2008 に記載されている含有率基準値より低いことを示します。

2.「除外項目」は、特定化学物質が含有マークの除外項目に該当するため、特定化学物質について、日本工業 規格 JIS C 0950:2008 に基づく含有マークの表示が不要であることを示します。

3. [0.1wt%超」または「0.01wt%超」は、特定化学物質の含有率が日本工業規格 JIS C 0950:2008 に記載されている含有率基準値を超えていることを示します。

A Japanese regulatory requirement, defined by specification JIS C 0950: 2008, mandates that manufacturers provide Material Content Declarations for certain categories of electronic products offered for sale after July 1, 2006.

Product Model Number: P4387B Server

Major Classification	Symbols of Specified Chemical Substance							
Major Classification	Pb	Hg	Cd	Cr(VI)	PBB	PBDE		
PCB	0	0	0	0	0	0		
Passive components	Exempt	0	0	0	0	0		
Active components	Exempt	0	0	0	0	0		
Processor	0	0	0	0	0	0		
Memory	0	0	0	0	0	0		
Mechanical parts and Fan	Exempt	0	0	0	0	0		
Cables/Connectors	Exempt	0	0	0	0	0		
Soldering material	0	0	0	0	0	0		
Flux, Solder Paste, label and other consumable materials	0	0	0	0	0	0		

Notes:

1. "0" indicates that the level of the specified chemical substance is less than the threshold level specified in the standard, JIS C 0950: 2008.

 "Exempt" indicates that the specified chemical substance is exempt from marking and it is not required to display the marking for that specified chemical substance per the standard, JIS C 0950: 2008.

 "Exceeding 0.1wt%" or "Exceeding 0.01wt%" is entered in the table if the level of the specified chemical substance exceeds the threshold level specified in the standard, JIS C 0950: 2008.

### 21.8. South Korea

**Korea Certification (KC)** 



이 기기는 업무용 환경에서 사용할 목적으로 적합성평가를 받은 기기로서 가정용 환경에서 사용하는 경우 전파간섭의 우려가 있습니다

### 21.9. China

#### **China Compulsory Certificate**

No certification is needed for China. The NVIDIA DGX B200 is a server with rated current over than 6A.

#### **China RoHS Material Content Declaration**

	产品中有	害物质的名	3称及含量	ł		
The Table of			1000 0110			
根据中国《						Flootsianl
as required by Management Me		Restricted		azardous S	ubstances in	Electrical
		eccionic ri		<b>宇</b> 害物质		
部件名称				us Substar	nces	
Parts	铅	汞	锔	六价铬	多溴联苯	多溴二苯酯
	(Pb)	(Hg)	(Cd)	(Cr(VI))	(PBB)	(PBDE)
PCB 板 PCB	0	0	0	0	0	0
被动电子零件 Passive components	x	о	о	о	0	о
主动电子零件 Active components	x	0	0	0	0	0
处理器 Processor	0	ο	0	0	0	0
内存 Memory	0	о	0	0	0	0
结构件以及风扇 Mechanical parts and Fan	x	0	0	0	0	0
线材/连接器 Cable/Connectors	x	ο	0	о	о	o
焊接金属 Soldering material	0	0	0	0	0	0
助焊剂,锡膏,标签及耗材 Flux, Solder Paste, label and other consumable materials	ο	ο	ο	о	0	о

本表格依据 SJ/T 11364-2014 的规定编制 The table according to SJ/T 11364

O: 表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 标准规定的限量要求以 下。

O: Indicates that this hazardous substance contained in all of the homogeneous materials for this

part is below the limit requirement in GB/T 26572. X:表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 标准规定的限量 要求。

X: Indicates that this hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.

此表中所有名称中含 "X" 的部件均符合欧盟 RoHS 立法。

All parts named in this table with an "X" are in compliance with the European Union's RoHS Legislation.

注: 环保使用期限的参考标识取决于产品正常工作的温度和湿度等条件 Note: The referenced Environmental Protection Use Period Marking was determined according to normal operating use conditions of the product such as temperature and humidity.

### 21.10. Taiwan

#### Bureau of Standards, Metrology & Inspection (BSMI)



警告使用者: 此為甲類資訊技術設備,於居住環境中使用時,可能會造成射頻擾動,在此種 情況下,使用者會被要求採取某些這當的對策

報驗義務人:

香港商輝達香港控股有限公司台灣分公司・・統一編號: 80022300

臺北市內湖區基湖路8號.

#### Taiwan RoHS Material Content Declaration

Taiwan RoHS Material Content Declaration

	际 DGX 伺	/JK 667					
quipment I	Name: DG	X server					
限用物質及其化學符號 Restricted substances and its chemical symbols							
鉛 (Pb)	汞 (Hg)	鍋 (Cd)	六價路 (Cr <sup>+6</sup> )	多溴聯 苯 (PBB)	多溴二苯酯 (PBDE)		
o	o	o	o	0	0		
	0	0	0	0	0		
-	o	o	o	o	0		
o	0	0	0	0	0		
0	0	0	0	0	0		
	o	o	o	o	o		
-	0	0	o	0	0		
0	0	0	0	0	0		
o	o	o	o	o	o		
content of th stance corres RoHS 立法。	sponds to th	e exemption		-	ntage of		
	Ri           鉛           (Pb)           0           -           0           -           0           0           -           0           0           -           0           -           0           -           0           -           0           -           0           -           0           -           0           -           0           -           0           -           0           -           -           0           -           -           -           -           -           -           -           -           -           -           -           -           -           -           -           -           -           -           - <td>Restricted s           鉛         汞           (Pb)         (Hg)           0         0           -         0           -         0           -         0           0         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         <t< td=""><td>Restricted substances           鉛         泉         編           (Pb)         (Hg)         (Cd)           0         0         0           -         0         0           -         0         0           -         0         0           0         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         -         0</td><td>限用物質及其化學術           Restricted substances and its ch           鉛         汞         鎬         六價路           (Pb)         (Hg)         (Cd)         (Cr*6)           0         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0</td></t<><td>限用物質及其化學符號           Restricted substances and its chemical sy           鉛         来         編         六價路         多溴聯           次(Pb)         (Hg)         (Cd)         (Cr*6)         多溴酸           0         0         0         0         0           -         0         0         0         0         0           -         0         0         0         0         0           -         0         0         0         0         0           -         0         0         0         0         0           -         0         0         0         0         0           -         0         0         0         0         0           -         0         0         0         0         0           -         0         0         0         0         0         0           -         0         0         0         0         0         0         0           -         0         0         0         0         0         0         0         0           -         0         0         0</td></td>	Restricted s           鉛         汞           (Pb)         (Hg)           0         0           -         0           -         0           -         0           0         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           -         0           - <t< td=""><td>Restricted substances           鉛         泉         編           (Pb)         (Hg)         (Cd)           0         0         0           -         0         0           -         0         0           -         0         0           0         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         -         0</td><td>限用物質及其化學術           Restricted substances and its ch           鉛         汞         鎬         六價路           (Pb)         (Hg)         (Cd)         (Cr*6)           0         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0</td></t<> <td>限用物質及其化學符號           Restricted substances and its chemical sy           鉛         来         編         六價路         多溴聯           次(Pb)         (Hg)         (Cd)         (Cr*6)         多溴酸           0         0         0         0         0           -         0         0         0         0         0           -         0         0         0         0         0           -         0         0         0         0         0           -         0         0         0         0         0           -         0         0         0         0         0           -         0         0         0         0         0           -         0         0         0         0         0           -         0         0         0         0         0         0           -         0         0         0         0         0         0         0           -         0         0         0         0         0         0         0         0           -         0         0         0</td>	Restricted substances           鉛         泉         編           (Pb)         (Hg)         (Cd)           0         0         0           -         0         0           -         0         0           -         0         0           0         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         0         0           -         -         0	限用物質及其化學術           Restricted substances and its ch           鉛         汞         鎬         六價路           (Pb)         (Hg)         (Cd)         (Cr*6)           0         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0           -         0         0         0	限用物質及其化學符號           Restricted substances and its chemical sy           鉛         来         編         六價路         多溴聯           次(Pb)         (Hg)         (Cd)         (Cr*6)         多溴酸           0         0         0         0         0           -         0         0         0         0         0           -         0         0         0         0         0           -         0         0         0         0         0           -         0         0         0         0         0           -         0         0         0         0         0           -         0         0         0         0         0           -         0         0         0         0         0           -         0         0         0         0         0         0           -         0         0         0         0         0         0         0           -         0         0         0         0         0         0         0         0           -         0         0         0		

### 21.11. Russia/Kazakhstan/Belarus

**Customs Union Technical Regulations (CU TR)** 



This device complies with the technical regulations of the Customs Union (CU TR)

ТЕХНИЧЕСКИЙ РЕГЛАМЕНТ ТАМОЖЕННОГО СОЮЗА О безопасности низковольтного оборудования (ТР ТС 004/2011)

ТЕХНИЧЕСКИЙ РЕГЛАМЕНТ ТАМОЖЕННОГО СОЮЗА Электромагнитная совместимость технических средств (ТР ТС 020/2011)

Технический регламент Евразийского экономического союза "Об ограничении применения опасных веществ в изделиях электротехники и радиоэлектроники" (ТР ЕАЭС 037/2016)

#### Federal Agency of Communication (FAC)

This device complies with the rules set forth by the Federal Agency of Communications and the Ministry of Communications and Mass Media.

A Federal Security Service notification has been filed.

### 21.12. Israel

SII

ודא שלמות ותקינות כבל החשמל והתקע אין להכניס או להוציא את התקע מרשת החשמל בידיים רטובות . אין לפתוח את המכשיר , במקרה של בעיה כלשהו יש לפנות למעבדת השירות הקרובה. יש להרחיק את המכשיר מנוזלים . במקרה של ריח מוזר, רעשים שמקורם במכשיר , יש לנתקו מיידית מרשת החשמל ולפנות למעבדת שירות המכשיר מיועד לשימוש בתוך המבנה , ולא לשימוש חיצוני ולא לשימוש בסביבה לחה. אין לחתוך, לשבור, ולעקם את הכבל החשמל. אין להניח חפצים על הכבל החשמל או להניח לו להתחמם יתר על המידה , שכן עלול לגרום לנזק ,דליקה או התחשמלות . יש להקפיד לחזק את התקן הניתוק במצב תפעולי מוכן לשימוש. אזהרה: אין להחליף את כבל הזינה בתחליפים לא מקוריים, חיבור לקוי עלול לגרום התקן הניתוק במצב תפעולי מוכן לשימוש. אזהרה: אין להמליף את כבל הזינה בתחליפים לא מקוריים, חיבור לקוי עלול לגרום . להתחשמלות המשתמש. בשימוש על כבל מאריך יש לוודא תקינות מוליך הארקה שבכבל

### 21.13. India

#### **Bureau of India Standards (BIS)**



Authenticity may be verified by visiting the Bureau of Indian Standards website at http://www.bis.gov. in.

#### India RoHS Compliance Statement

This product, as well as its related consumables and spares, complies with the reduction in hazardous substances provisions of the "India E-waste (Management and Handling) Rule 2016".

It does not contain lead, mercury, hexavalent chromium, polybrominated biphenyls or polybrominated diphenyl ethers in concentrations exceeding 0.1 weight % and 0.01 weight % for cadmium, except for where allowed pursuant to the exemptions set in Schedule 2 of the Rule.

### 21.14. South Africa

#### South African Bureau of Standards (SABS)

This device complies with the following SABS Standards: SANS 2332: 2017/CISPR 32:2015 SANS 2335:2018/ CISPR 35:2016

#### National Regulator of Compulsory Specification (NRCS)

This device complies with following standard under VC 8055: SANS IEC 60950-1

# 21.15. Great Britain (England, Wales, and Scotland)

**UK Conformity Assessed** 



This device complies with the following Regulations:

- SI 2016/1091: Electromagnetic Compatibility (EMC)
- ▶ SI 2016/1101: The Low Voltage Electrical Equipment (Safety)
- SI 2012/3032: The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment (As Amended)

A copy of the Declaration of Conformity to the essential requirements may be obtained directly from NVIDIA Ltd. (100 Brook Drive, 3rd Floor Green Park, Reading RG2 6UJ, United Kingdom)

# Chapter 22. Third-Party License Notices

This NVIDIA product contains third party software that is being made available to you under their respective open source software licenses. Some of those licenses also require specific legal information to be included in the product. This section provides such information.

### 22.1. Micron msecli

The msecli utility is provided under the following terms:

Micron Technology, Inc. Software License Agreement PLEASE READ THIS LICENSE AGREEMENT ("AGREEMENT") FROM MICRON TECHNOLOGY, INC. ("MTI") CAREFULLY: BY INSTALLING, COPYING OR OTHERWISE USING THIS SOFTWARE AND ANY RELATED PRINTED MATERIALS ("SOFTWARE"), YOU ARE ACCEPTING AND AGREEING TO THE TERMS OF THIS AGREEMENT. IF YOU DO NOT AGREE WITH THE TERMS OF THIS AGREEMENT, DO NOT INSTALL THE SOFTWARE. LICENSE: MTI hereby grants to you the following rights: You may use and make one (1) backup copy the Software subject to the terms of this Agreement. You must maintain all copyright notices on all copies of the Software. You agree not to modify, adapt, decompile, reverse engineer, disassemble, or otherwise translate the Software. MTI may make changes to the Software at any time without notice to you. In addition MTI is under no obligation whatsoever to update, maintain, or provide new versions or other support for the Software. OWNERSHIP OF MATERIALS: You acknowledge and agree that the Software is proprietary property of MTI (and/or its licensors) and is protected by United States copyright law and international treaty provisions. Except as expressly provided herein, MTI does not grant any express or implied right to you under any patents, copyrights, trademarks, or trade secret information. You further acknowledge and agree that all right, title, and interest in and to the Software, including associated proprietary rights, are and shall remain with MTI (and/or its licensors). This Agreement does not convey to you an interest in or to the Software, but only a limited right to use and copy the Software in accordance with the terms of this Agreement. The Software is licensed to you and not sold.

#### DISCLAIMER OF WARRANTY:

THE SOFTWARE IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND. MTI EXPRESSLY DISCLAIMS ALL WARRANTIES EXPRESS ORMIMPLIED, INCLUDING BUT NOT LIMITED TO, NONINFRINGEMENT OF THIRD PARTY RIGHTS, AND ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. MTI DOES NOT WARRANT THAT THE SOFTWARE WILL MEET YOUR REQUIREMENTS, OR THAT THE OPERATION OF THE SOFTWARE WILL BE UNINTERRUPTED OR ERROR-FREE. FURTHERMORE, MTI DOES NOT MAKE ANY REPRESENTATIONS REGARDING THE USE OR THE RESULTS OF THE USE OF THE SOFTWARE IN TERMS OF ITS CORRECTNESS, ACCURACY, RELIABILITY, OR OTHERWISE. THE ENTIRE RISK ARISING OUT OF USE OR PERFORMANCE OF THE SOFTWARE REMAINS WITH YOU. IN NO EVENT SHALL MTI, ITS AFFILIATED COMPANIES OR THEIR SUPPLIERS BE LIABLE FOR ANY DIRECT, INDIRECT, CONSEQUENTIAL, INCIDENTAL, OR SPECIAL DAMAGES (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF PROFITS, BUSINESS INTERRUPTION, OR LOSS OF INFORMATION) ARISING OUT OF YOUR USE OF OR INABILITY TO USE THE SOFTWARE, EVEN IF MTI

HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Because some jurisdictions prohibit the exclusion or limitation of liability for consequential or incidental damages, the above limitation may not apply to you.

TERMINATION OF THIS LICENSE: MTI may terminate this license at any time if you are in breach of any of the terms of this Agreement. Upon termination, you will immediately destroy all copies the Software.

GENERAL: This Agreement constitutes the entire agreement between MTI and you regarding the subject matter hereof and supersedes all previous oral or written communications between the parties. This Agreement shall be governed by the laws of the State of Idaho without regard to its conflict of laws rules.

CONTACT: If you have any questions about the terms of this Agreement, please contact MTI's legal department at (208) 368-4500. By proceeding with the installation of the Software, you agree to the terms of this Agreement. You must agree to the terms in order to install and use the Software.

### 22.2. Mellanox (OFED)

*MLNX\_OFED <http://www.mellanox.com/>* is provided under the following terms:

Copyright (c) 2006 Mellanox Technologies. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- 1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCI-DENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSI-NESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CON-TRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

# Chapter 23. Notices

### 23.1. Notice

This document is provided for information purposes only and shall not be regarded as a warranty of a certain functionality, condition, or quality of a product. NVIDIA Corporation ("NVIDIA") makes no representations or warranties, expressed or implied, as to the accuracy or completeness of the information contained in this document and assumes no responsibility for any errors contained herein. NVIDIA shall have no liability for the consequences or use of such information or for any infringement of patents or other rights of third parties that may result from its use. This document is not a commitment to develop, release, or deliver any Material (defined below), code, or functionality.

NVIDIA reserves the right to make corrections, modifications, enhancements, improvements, and any other changes to this document, at any time without notice.

Customer should obtain the latest relevant information before placing orders and should verify that such information is current and complete.

NVIDIA products are sold subject to the NVIDIA standard terms and conditions of sale supplied at the time of order acknowledgement, unless otherwise agreed in an individual sales agreement signed by authorized representatives of NVIDIA and customer ("Terms of Sale"). NVIDIA hereby expressly objects to applying any customer general terms and conditions with regards to the purchase of the NVIDIA product referenced in this document. No contractual obligations are formed either directly or indirectly by this document.

NVIDIA products are not designed, authorized, or warranted to be suitable for use in medical, military, aircraft, space, or life support equipment, nor in applications where failure or malfunction of the NVIDIA product can reasonably be expected to result in personal injury, death, or property or environmental damage. NVIDIA accepts no liability for inclusion and/or use of NVIDIA products in such equipment or applications and therefore such inclusion and/or use is at customer's own risk.

NVIDIA makes no representation or warranty that products based on this document will be suitable for any specified use. Testing of all parameters of each product is not necessarily performed by NVIDIA. It is customer's sole responsibility to evaluate and determine the applicability of any information contained in this document, ensure the product is suitable and fit for the application planned by customer, and perform the necessary testing for the application in order to avoid a default of the application or the product. Weaknesses in customer's product designs may affect the quality and reliability of the NVIDIA product and may result in additional or different conditions and/or requirements beyond those contained in this document. NVIDIA accepts no liability related to any default, damage, costs, or problem which may be based on or attributable to: (i) the use of the NVIDIA product in any manner that is contrary to this document or (ii) customer product designs.

No license, either expressed or implied, is granted under any NVIDIA patent right, copyright, or other NVIDIA intellectual property right under this document. Information published by NVIDIA regarding third-party products or services does not constitute a license from NVIDIA to use such products or

services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property rights of the third party, or a license from NVIDIA under the patents or other intellectual property rights of NVIDIA.

Reproduction of information in this document is permissible only if approved in advance by NVIDIA in writing, reproduced without alteration and in full compliance with all applicable export laws and regulations, and accompanied by all associated conditions, limitations, and notices.

THIS DOCUMENT AND ALL NVIDIA DESIGN SPECIFICATIONS, REFERENCE BOARDS, FILES, DRAWINGS, DIAGNOSTICS, LISTS, AND OTHER DOCUMENTS (TOGETHER AND SEPARATELY, "MATERIALS") ARE BEING PROVIDED "AS IS." NVIDIA MAKES NO WARRANTIES, EXPRESSED, IMPLIED, STATUTORY, OR OTHERWISE WITH RESPECT TO THE MATERIALS, AND EXPRESSLY DISCLAIMS ALL IMPLIED WARRANTIES OF NONINFRINGEMENT, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE. TO THE EXTENT NOT PROHIBITED BY LAW, IN NO EVENT WILL NVIDIA BE LIABLE FOR ANY DAMAGES, INCLUDING WITHOUT LIMITATION ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES, HOWEVER CAUSED AND REGARDLESS OF THE THEORY OF LIABILITY, ARIS-ING OUT OF ANY USE OF THIS DOCUMENT, EVEN IF NVIDIA HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Notwithstanding any damages that customer might incur for any reason whatso-ever, NVIDIA's aggregate and cumulative liability towards customer for the products described herein shall be limited in accordance with the Terms of Sale for the product.

# 23.2. Trademarks

NVIDIA, the NVIDIA logo, DGX, DGX-1, DGX-2, DGX A100, DGX H100, DGX H200, DGX B200, DGX Station, and DGX Station A100 are trademarks and/or registered trademarks of NVIDIA Corporation in the Unites States and other countries. Other company and product names may be trademarks of the respective companies with which they are associated.

### Copyright

©2022-2025, NVIDIA Corporation