



Function holoscan::viz::Init(GLFWwindow *, InitFlags)

Table of contents

Function Documentation

- Defined in [File holoviz.hpp](#)

Function Documentation

```
void holoscan::viz::Init(GLFWwindow *window, InitFlags flags = InitFlags::NONE)
```

Initialize Holoviz using an existing GLFW window.

Parameters

- **window** – GLFW window
- **flags** – init flags

© Copyright 2022-2024, NVIDIA.. PDF Generated on 06/06/2024