



**Function holoscan::viz::SetCurrent**

# Table of contents

Function Documentation

---

- Defined in [File holoviz.hpp](#)

## Function Documentation

void holoscan::viz::SetCurrent([InstanceHandle](#) instance)

Set the current instance for the active thread.

Parameters

**instance** – instance to set

© Copyright 2022-2024, NVIDIA.. PDF Generated on 06/06/2024